SUZUKI

PARTS CATALOGUE

DF8A/9.9A

DF8A
DF8AR
DF9.9A
DF9.9AR

SUZUKI Way of Life!

OUTBOARD MOTOR

P01

2014-5

1ST EDITION

PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF8A/9.9A production start 2014.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E.NO.	: Engine number	OS	: Over size
F.NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	W/	: with
LH(PORT)	: Left hand side	S,L	: Transom type
RH(STBD)	: Right hand side	SUS	: Stainless steel
～123456	: Up to E.NO.00994F-123456		
123456～	: From E.NO.00994F-123456		

12 x 34 x 5.6····· Figures in the description column show the dimensions of parts.
ID OD T(or W,L)

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual. When assembling, use "SUZUKI SERVICE MANUAL".

6. SPECIFICATION CODE

This catalogue contains the parts for the model designed for the following spec.;

spec. code : DF8A(R) : P1 DF9.9A(R) : P1

7. MODEL NAME AND ENGINE NUMBER

MODEL	DESTINATION	TYPE	TRANSOM	ENGINE NO.
DF8A	P01	00801F	S,L	00801F-510001～
DF8AR	P01	00801F	S,L	00801F-510001～
DF9.9A	P01	00994F	S,L	00994F-510001～
DF9.9AR	P01	00994F	S,L	00994F-510001～

MILLIMETER → INCH CONVERSION CHART

	0	1	2	3	4	5	6	7	8	9
00	.000	.039	.079	.118	.157	.197	.236	.276	.315	.354
10	.394	.433	.472	.512	.551	.591	.630	.669	.709	.748
20	.787	.827	.866	.906	.945	.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.535
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.214	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.031	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898


How to read

	0	1	2	3	4
00	…	…	…	…	…
10	…	…	…	…	…
20	…	…	…	0.906	…
30	…	…	…	…	…

23 millimeters equal 0.906 inch


Contents are subject to change without notice or obligation.

FIG.111A




DF9A_9.9A_P01_010_111A
CYLINDER HEAD

FIG.113A




DF9A_9.9A_P01_010_113A
CYLINDER BLOCK

FIG.116A




DF9A_9.9A_P01_010_116A
CRANKSHAFT

FIG.120A




DF9A_9.9A_P01_010_120A
TIMING BELT

FIG.120B




DF9A_9.9A_P01_010_120B
TIMING BELT

FIG.120C




DF9A_9.9A_P01_010_120C
TIMING BELT

FIG.120D




DF9A_9.9A_P01_010_120D
TIMING BELT

FIG.121A




DF9A_9.9A_P01_010_121A
CAMSHAFT

FIG.121B




DF9A_9.9A_P01_010_121B
CAMSHAFT

FIG.121C




DF9A_9.9A_P01_010_121C
CAMSHAFT

FIG.121D




DF9A_9.9A_P01_010_121D
CAMSHAFT

FIG.126A




DF9A_9.9A_P01_010_126A
INLET MANIFOLD

FIG.128A




DF9A_9.9A_P01_010_128A
CARBURETOR

FIG.128B




DF9A_9.9A_P01_010_128B
CARBURETOR

FIG.128C




DF9A_9.9A_P01_010_128C
CARBURETOR

FIG.128D




DF9A_9.9A_P01_010_128D
CARBURETOR

FIG.146A




DF9A_9.9A_P01_01S_146A
FUEL PUMP

FIG.150A




DF9A_9.9A_P01_01S_150A
OIL PUMP

FIG.160A




DF9A_9.9A_P01_01S_160A
WATER PUMP

FIG.162A




DF9A_9.9A_P01_01S_162A
THERMOSTAT

FIG.166A




DF9A_9.9A_P01_01S_166A
THROTTLE CONTROL

FIG.166B




DF9A_9.9A_P01_01S_166B
THROTTLE CONTROL

FIG.166C




DF9A_9.9A_P01_01S_166C
THROTTLE CONTROL

FIG.166D




DF9A_9.9A_P01_01S_166D
THROTTLE CONTROL

FIG.167A




DF9A_9.9A_P01_01S_167A
RECOIL STARTER

FIG.206A




DF9A_9.9A_P01_01S_206A
CLUTCH ROD

FIG.206B




DF9A_9.9A_P01_01S_206B
CLUTCH ROD

FIG.206C




DF9A_9.9A_P01_01S_206C
CLUTCH ROD

FIG.206D




DF9A_9.9A_P01_01S_206D
CLUTCH ROD

FIG.210A




DF9A_9.9A_P01_01S_210A
SHIFT ROD

FIG.220A




DF9A_9.9A_P01_01S_220A
TRANSMISSION

FIG.301A




DF9A_9.9A_P01_01S_301A
STARTING MOTOR

FIG.303A




DF9A_9.9A_P01_01S_303A
MAGNETO

FIG.303B




DF9A_9.9A_P01_01S_303B
MAGNETO

FIG.303C




DF9A_9.9A_P01_01S_303C
MAGNETO

FIG.303D




DF9A_9.9A_P01_01S_303D
MAGNETO

FIG.310A




DF9A_9.9A_P01_01S_310A
RECTIFIER/IGNITION COIL

FIG.310B




DF9A_9.9A_P01_01S_310B
RECTIFIER/IGNITION COIL

FIG.310C




DF9A_9.9A_P01_01S_310C
RECTIFIER/IGNITION COIL

FIG.310D




DF9A_9.9A_P01_01S_310D
RECTIFIER/IGNITION COIL

FIG.322A




DF9A_9.9A_P01_01S_322A
HARNESS

FIG.322B




DF9A_9.9A_P01_01S_322B
HARNESS

FIG.322C




DF9A_9.9A_P01_01S_322C
HARNESS

FIG.322D




DF9A_9.9A_P01_01S_322D
HARNESS

FIG.334A




DF9A_9.9A_P01_01S_334A
SENSOR/SWITCH

FIG.334B




DF9A_9.9A_P01_01S_334B
SENSOR/SWITCH

FIG.334C




DF9A_9.9A_P01_01S_334C
SENSOR/SWITCH

FIG.334D




DF9A_9.9A_P01_01S_334D
SENSOR/SWITCH

FIG.335A




DF9A_9.9A_P01_01S_335A
CLAMP BRACKET

FIG.335B




DF9A_9.9A_P01_01S_335B
CLAMP BRACKET

FIG.335C




DF9A_9.9A_P01_01S_335C
CLAMP BRACKET

FIG.335D




DF9A_9.9A_P01_01S_335D
CLAMP BRACKET

FIG.336A




DF9A_9.9A_P01_01S_336A
SWIVEL BRACKET

FIG.336B




DF9A_9.9A_P01_01S_336B
SWIVEL BRACKET

FIG.336C




DF9A_9.9A_P01_01S_336C
SWIVEL BRACKET

FIG.336D




DF9A_9.9A_P01_01S_336D
SWIVEL BRACKET

FIG.401A




DF9A_9.9A_P01_010_401A
ENGINE HOLDER

FIG.405A




DF9A_9.9A_P01_010_405A
DRIVE SHAFT HOUSING

FIG.407A




DF9A_9.9A_P01_010_407A
GEAR CASE

FIG.410A




DF9A_9.9A_P01_010_410A
SIDE COVER

FIG.410B




DF9A_9.9A_P01_010_410B
SIDE COVER

FIG.410C




DF9A_9.9A_P01_010_410C
SIDE COVER

FIG.410D




DF9A_9.9A_P01_010_410D
SIDE COVER

FIG.420A




DF9A_9.9A_P01_010_420A
ENGINE COVER

FIG.420B




DF9A_9.9A_P01_010_420B
ENGINE COVER

FIG.420C




DF9A_9.9A_P01_010_420C
ENGINE COVER

FIG.420D




DF9A_9.9A_P01_010_420D
ENGINE COVER

FIG.432A




DF9A_9.9A_P01_010_432A
FUEL TANK

FIG.442A




DF9A_9.9A_P01_010_442A
DRAG LEVA

FIG.442B




DF9A_9.9A_P01_010_442B
DRAG LEVA

FIG.444A




DF9A_9.9A_P01_010_444A
TILLER HANDLE

FIG.444B




DF9A_9.9A_P01_010_444B
TILLER HANDLE

FIG.450A




DF9A_9.9A_P01_010_450A
REMOTE CONTROL

FIG.450B




DF9A_9.9A_P01_010_450B
REMOTE CONTROL

FIG.454A




DF9A_9.9A_P01_010_454A
REMOCON CABLE HOLDER

FIG.454B




DF9A_9.9A_P01_010_454B
REMOCON CABLE HOLDER

FIG.501A




DF9A_9.9A_P01_010_501A
OPT:METER

FIG.501B




DF9A_9.9A_P01_010_501B
OPT:METER

FIG.513A




DF9A_9.9A_P01_010_513A
OPT:REMOTE CONTROL PARTS

FIG.513B




DF9A_9.9A_P01_010_513B
OPT:REMOTE CONTROL PARTS

FIG.515A




DF9A_9.9A_P01_010_515A
OPT:REMOCON CABLE

FIG.515B




DF9A_9.9A_P01_010_515B
OPT:REMOCON CABLE

FIG.515C




DF9A_9.9A_P01_010_515C
OPT:REMOCON CABLE

FIG.515D




DF9A_9.9A_P01_010_515D
OPT:REMOCON CABLE

FIG.544A




DF9A_9.9A_P01_010_544A
OPT:REMOTE CONTROL ASSY SINGLE (1)

FIG.545A




DF9A_9.9A_P01_010_545A
OPT:REMOTE CONTROL ASSY SINGLE (2)

FIG.553A




DF9A_9.9A_P01_010_553A
OPT:ELECTRICAL (MANUAL STARTER)

FIG.553B




DF9A_9.9A_P01_010_553B
OPT:ELECTRICAL (MANUAL STARTER)

FIG.561A




DF9A_9.9A_P01_015_561A
OPT:STARTING MOTOR (MANUAL STARTER)

FIG.561B



DF9A_9.9A_P01_015_561B
OPT:STARTING MOTOR (MANUAL STARTER)

FIG.583A



DF9A_9.9A_P01_015_583A
OPT:FUEL TANK

FIG.111A




FIG.111A (1-B-2) CYLINDER HEAD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11110-99J00	HEAD, CYLINDER	1	
2	11141-99J00	GASKET, CYLINDER HEAD	1	
3	11118-99JL0	BOLT, NO.1 (8X67)	2	
4	11119-99JL0	BOLT, NO.2 (8X77)	4	
5	01550-06257	BOLT	3	
6	11216-90J00	GASKET, OIL GALLERY PLUG	1	
7	09248-22002	PLUG (22X11)	1	
8	11261-93J00	COVER, PROTECTION ANODE	1	
9	09280-22019	O RING (D:1.9,ID:21.8)	1	
10	55321-87J00	ANODE, PROTECTION	1	
11	09103-06281	BOLT (6X14)	1	
12	01550-08207	BOLT	1	
13	11382-93E00	CAP, OIL FILLER	1	
14	09280-17003	O RING (D:3.1,ID:16.8)	1	
15	04211-09109	PIN	2	
16	11170-99J00	COVER, CYLINDER HEAD	1	
17	11178-99J00	O RING, CYLINDER HEAD COVER	1	
18	01550-06207	BOLT	4	
19	11196-99J00	HOSE, BREATHER	1	
20	11173-99J00	PLATE, BREATHER	1	
21	01550-0612A	BOLT	4	
22	09482-00528	SPARK PLUG (CR6E)	2	NGK
23	11115-09G00-001	GUIDE, VALVE (OS)	4	OPT

FIG.113A




FIG.113A (1-B-3) CYLINDER BLOCK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11301-99J10	BLOCK ASSY, CYLINDER	1	
2	01560-08557	.BOLT	6	
3	04211-09109	.PIN	2	
4	16440-11D00	REGULATOR ASSY, ENGINE	1	
5	09403-12406	CLAMP	1	
6	01550-06127	BOLT	1	

FIG.116A




FIG.116A (1-B-4) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12111-99JL0-0B0	PISTON	2	
2	12140-99J00	RING SET, PISTON	2	
3	12151-99JL0	PIN, PISTON	2	
4	09381-14001	SNAP RING	4	
5	12160-99JL0	CONNROD ASSY	2	
6	12163-99JL0	.BOLT, CONNROD	4	
7	12220-99JL0	CRANKSHAFT	1	
8	12341-99J00	BEARING, CRANKSHAFT	4	
9	09283-30075	OIL SEAL (28.8X45.5X6.5)	2	
10	12100-99JL0-050	PISTON SET (OS:0.50)	2	OPT

FIG. 120A




FIG.120A (1-B-5) TIMING BELT (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12631-99JM0	PULLEY, CRANKSHAFT (NT:17)	1	
2	12635-99J00	GUIDE, TIMING BELT (UPPER)	1	
3	12636-99J00	GUIDE, TIMING BELT (LOWER)	1	
4	12637-99J00	NUT, TIMING PULLEY (M24)	1	
5	12638-99J00	WASHER, PULLEY NUT LOCK	1	
6	12741-99JL0	PULLEY, CAMSHAFT (NT:34)	1	
7	09103-06267	BOLT (6X18)	1	
8	09160-06171	WASHER (6.5X24X4)	1	
9	08341-31039	KEY	1	
10	08341-31039	KEY	1	
11-1	12625-99J00	BASE, STATOR	1	W/ELECTRIC STARTER
11-2	12625-99J10	BASE, STATOR	1	W/MANUAL STARTER
12	04211-09149	PIN	2	
13	01550-06307	BOLT	3	
14	01550-08307	BOLT	1	W/ELECTRIC STARTER
15	01550-06127	BOLT	1	W/MANUAL STARTER
16	12761-99J00	BELT, TIMING	1	
17	12764-99J00	COVER, TIMING BELT	1	
18	09308-08011	GROMMET	2	
19	61493-99J00	LABEL, CLEARANCE	1	
20	61494-99J00	LABEL, OIL	1	

FIG.120B




FIG.120B (1-B-6) TIMING BELT (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12631-99JM0	PULLEY, CRANKSHAFT (NT:17)	1	
2	12635-99J00	GUIDE, TIMING BELT (UPPER)	1	
3	12636-99J00	GUIDE, TIMING BELT (LOWER)	1	
4	12637-99J00	NUT, TIMING PULLEY (M24)	1	
5	12638-99J00	WASHER, PULLEY NUT LOCK	1	
6	12741-99JL0	PULLEY, CAMSHAFT (NT:34)	1	
7	09103-06267	BOLT (6X18)	1	
8	09160-06171	WASHER (6.5X24X4)	1	
9	08341-31039	KEY	1	
10	08341-31039	KEY	1	
11	12625-99J00	BASE, STATOR	1	
12	04211-09149	PIN	2	
13	01550-06307	BOLT	3	
14	01550-08307	BOLT	1	
15	12761-99J00	BELT, TIMING	1	
16	12764-99J00	COVER, TIMING BELT	1	
17	09308-08011	GROMMET	2	
18	61493-99J00	LABEL, CLEARANCE	1	
19	61494-99J00	LABEL, OIL	1	

FIG. 120C




FIG.120C (1-B-7) TIMING BELT (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12631-99JM0	PULLEY, CRANKSHAFT (NT:17)	1	
2	12635-99J00	GUIDE, TIMING BELT (UPPER)	1	
3	12636-99J00	GUIDE, TIMING BELT (LOWER)	1	
4	12637-99J00	NUT, TIMING PULLEY (M24)	1	
5	12638-99J00	WASHER, PULLEY NUT LOCK	1	
6	12741-99JL0	PULLEY, CAMSHAFT (NT:34)	1	
7	09103-06267	BOLT (6X18)	1	
8	09160-06171	WASHER (6.5X24X4)	1	
9	08341-31039	KEY	1	
10	08341-31039	KEY	1	
11-1	12625-99J00	BASE, STATOR	1	W/ELECTRIC STARTER
11-2	12625-99J10	BASE, STATOR	1	W/MANUAL STARTER
12	04211-09149	PIN	2	
13	01550-06307	BOLT	3	
14	01550-08307	BOLT	1	W/ELECTRIC STARTER
15	01550-06127	BOLT	1	W/MANUAL STARTER
16	12761-99J00	BELT, TIMING	1	
17	12764-99J00	COVER, TIMING BELT	1	
18	09308-08011	GROMMET	2	
19	61493-99J00	LABEL, CLEARANCE	1	
20	61494-99J00	LABEL, OIL	1	

FIG.120D




FIG.120D (1-B-8) TIMING BELT (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12631-99JM0	PULLEY, CRANKSHAFT (NT:17)	1	
2	12635-99J00	GUIDE, TIMING BELT (UPPER)	1	
3	12636-99J00	GUIDE, TIMING BELT (LOWER)	1	
4	12637-99J00	NUT, TIMING PULLEY (M24)	1	
5	12638-99J00	WASHER, PULLEY NUT LOCK	1	
6	12741-99JL0	PULLEY, CAMSHAFT (NT:34)	1	
7	09103-06267	BOLT (6X18)	1	
8	09160-06171	WASHER (6.5X24X4)	1	
9	08341-31039	KEY	1	
10	08341-31039	KEY	1	
11	12625-99J00	BASE, STATOR	1	
12	04211-09149	PIN	2	
13	01550-06307	BOLT	3	
14	01550-08307	BOLT	1	
15	12761-99J00	BELT, TIMING	1	
16	12764-99J00	COVER, TIMING BELT	1	
17	09308-08011	GROMMET	2	
18	61493-99J00	LABEL, CLEARANCE	1	
19	61494-99J00	LABEL, OIL	1	

FIG. 121A




FIG.121A (1-B-9) CAMSHAFT (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12700-99JL0	CAMSHAFT ASSY	1	W/MANUAL STARTER W/DECOMP
1-2	12711-99JM0	CAMSHAFT	1	W/ELECTRIC STARTER N/DECOMP
2	09283-21009	OIL SEAL (19.7X33X6)	1	
3	12840-99J00	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12843-99J00	SPACER, ROCKER ARM (13X18X9)	2	
7	12861-99JL0	SHAFT, ROCKER ARM (9X13X142.5)	1	
8	12891-99J00	SPRING, ROCKER SHAFT	1	
9	09164-13008	WASHER	1	
10	12911-99J00	VALVE, INTAKE	2	
11	12915-99J00	VALVE, EXHAUST	2	
12	12921-99J00	SPRING, VALVE	4	
13	12931-09420	RETAINER, VALVE SPRING	4	
14	12932-09G00	COTTER, VALVE	8	
15	12933-71C00	SEAT, VALVE SPRING	4	
16	09289-05008	OIL SEAL (5X10.5X8.4)	4	

FIG.121B




FIG.121B (1-B-10) CAMSHAFT (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12711-99JM0	CAMSHAFT	1	
2	09283-21009	OIL SEAL (19.7X33X6)	1	
3	12840-99J00	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12843-99J00	SPACER, ROCKER ARM (13X18X9)	2	
7	12861-99JL0	SHAFT, ROCKER ARM (9X13X142.5)	1	
8	12891-99J00	SPRING, ROCKER SHAFT	1	
9	09164-13008	WASHER	1	
10	12911-99J00	VALVE, INTAKE	2	
11	12915-99J00	VALVE, EXHAUST	2	
12	12921-99J00	SPRING, VALVE	4	
13	12931-09420	RETAINER, VALVE SPRING	4	
14	12932-09G00	COTTER, VALVE	8	
15	12933-71C00	SEAT, VALVE SPRING	4	
16	09289-05008	OIL SEAL (5X10.5X8.4)	4	




FIG.121C (1-B-11) CAMSHAFT (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12700-99JL0	CAMSHAFT ASSY	1	W/MANUAL STARTER W/DECOMP
1-2	12711-99JM0	CAMSHAFT	1	W/ELECTRIC STARTER N/DECOMP
2	09283-21009	OIL SEAL (19.7X33X6)	1	
3	12840-99J00	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12843-99J00	SPACER, ROCKER ARM (13X18X9)	2	
7	12861-99JL0	SHAFT, ROCKER ARM (9X13X142.5)	1	
8	12891-99J00	SPRING, ROCKER SHAFT	1	
9	09164-13008	WASHER	1	
10	12911-99J00	VALVE, INTAKE	2	
11	12915-99J00	VALVE, EXHAUST	2	
12	12921-99J00	SPRING, VALVE	4	
13	12931-09420	RETAINER, VALVE SPRING	4	
14	12932-09G00	COTTER, VALVE	8	
15	12933-71C00	SEAT, VALVE SPRING	4	
16	09289-05008	OIL SEAL (5X10.5X8.4)	4	

FIG.121D




FIG.121D (1-B-12) CAMSHAFT (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12711-99JM0	CAMSHAFT	1	
2	09283-21009	OIL SEAL (19.7X33X6)	1	
3	12840-99J00	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12843-99J00	SPACER, ROCKER ARM (13X18X9)	2	
7	12861-99JL0	SHAFT, ROCKER ARM (9X13X142.5)	1	
8	12891-99J00	SPRING, ROCKER SHAFT	1	
9	09164-13008	WASHER	1	
10	12911-99J00	VALVE, INTAKE	2	
11	12915-99J00	VALVE, EXHAUST	2	
12	12921-99J00	SPRING, VALVE	4	
13	12931-09420	RETAINER, VALVE SPRING	4	
14	12932-09G00	COTTER, VALVE	8	
15	12933-71C00	SEAT, VALVE SPRING	4	
16	09289-05008	OIL SEAL (5X10.5X8.4)	4	

FIG. 126A




FIG.126A (1-B-13) INLET MANIFOLD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-99J00	MANIFOLD, INLET	1	
2	13119-99J00	GASKET, INLET MANIFOLD	1	
3	01560-06457	BOLT	3	
4	04221-05109	PIN	2	
5	13810-99J00	SILENCER	1	
6	13710-99J00	ARRESTER, FLAME	1	
7	09180-06290	SPACER (6.5X10X12)	2	
8	13832-94J00	SEAL, SILENCER	1	
9	09169-06082	WASHER	1	
10	01550-06167	BOLT	1	

FIG. 128A




FIG.128A (1-B-14) CARBURETOR (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	13200-99J00	CARBURETOR ASSY	1	W/MANUAL STARTER
1-2	13200-99J10	CARBURETOR ASSY	1	W/ELECTRIC STARTER
2	13236-99J00	.NOZZLE, MAIN	1	
3-1	09491-70020	.JET, MAIN (70)	1	
3-2	09491-68008	.JET, MAIN (68)	1	
4-1	09492-38011	.JET, PILOT (38)	1	
4-2	09492-35033	.JET, PILOT (35)	1	
5	13239-94J00	.CAP, RUBBER	1	
6	13250-99J00	.FLOAT	1	
7	13370-94J00	.VALVE, FLOAT	1	
8	13247-94J00	.SCREW	4	
9	13375-26E00	.CLIP	1	
10	13254-94J00	.PIN, ARM	1	
11	13802-94J00	.SCREW	1	
12	13534-94J00	.SCREW, STOP	1	
13	13268-94J00	.SPRING	1	
14-1	13240-99J00	.CHAMBER ASSY, FLOAT	1	W/MANUAL STARTER
14-2	13240-99J10	.CHAMBER ASSY, FLOAT	1	W/ELECTRIC SATRTER
15	13251-99J00	..GASKET, FLOAT CHAMBER	1	
16	13279-99J00	..SCREW, DRAIN	1	
17	13275-99J00	..WASHER, PLANE	1	
18	13283-99J00	.PACKING	1	
19	13282-99J00	.PLATE	1	
20	13367-94J00	.SCREW	3	
21	13361-99J00	.HOLDER, CABLE	1	W/MANUAL STARTER
22	13362-94J00	.GUIDE, CABLE	1	W/MANUAL STARTER
23	13363-94J00	.CAP, CABLE SEALING	1	W/MANUAL STARTER
24	13364-94J00	.VALVE, STARTER	1	W/MANUAL STARTER
25	13365-94J00	.SPRING	1	W/MANUAL STARTER
26	13295-14G00	.O RING	1	W/MANUAL STARTER
27	13367-94J00	.SCREW	1	W/ELECTRIC SATRTER
28	13368-99J00	.STARTER ASSY	1	W/ELECTRIC STARTER
29	13281-99J00	.SCREW, PAN	1	
30	09103-06276	BOLT (6X100)	2	

FIG. 128A




FIG.128A (1-B-15) CARBURETOR (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	13125-99J00	GASKET, CARBURETOR	2	
32	13124-99J00	INSULATOR	1	
33	13436-91J00	CONNECTOR, THROTTLE ROD	1	
34	13513-99J00	ROD, THROTTLE	1	
35	13640-99JL0	KNOB ASSY, STARTER	1	W/MANUAL STARTER
36	09159-14032	NUT	1	W/MANUAL STARTER
37	09320-10501	CUSHION	1	W/MANUAL STARTER

FIG. 128B




FIG.128B (1-C-2) CARBURETOR (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13200-99J10	CARBURETOR ASSY	1	
2	13236-99J00	.NOZZLE, MAIN	1	
3-1	09491-70020	.JET, MAIN (70)	1	
3-2	09491-68008	.JET, MAIN (68)	1	
4-1	09492-38011	.JET, PILOT (38)	1	
4-2	09492-35033	.JET, PILOT (35)	1	
5	13239-94J00	.CAP, RUBBER	1	
6	13250-99J00	.FLOAT	1	
7	13370-94J00	.VALVE, FLOAT	1	
8	13247-94J00	.SCREW	4	
9	13375-26E00	.CLIP	1	
10	13254-94J00	.PIN, ARM	1	
11	13802-94J00	.SCREW	1	
12	13534-94J00	.SCREW, STOP	1	
13	13268-94J00	.SPRING	1	
14	13240-99J10	.CHAMBER ASSY, FLOAT	1	
15	13251-99J00	..GASKET, FLOAT CHAMBER	1	
16	13279-99J00	..SCREW, DRAIN	1	
17	13275-99J00	..WASHER, PLANE	1	
18	13283-99J00	.PACKING	1	
19	13282-99J00	.PLATE	1	
20	13367-94J00	.SCREW	3	
21	13367-94J00	.SCREW	1	
22	13368-99J00	.STARTER ASSY	1	
23	13281-99J00	.SCREW, PAN	1	
24	09103-06276	BOLT (6X100)	2	
25	13125-99J00	GASKET, CARBURETOR	2	
26	13124-99J00	INSULATOR	1	
27	13436-91J00	CONNECTOR, THROTTLE ROD	1	
28	13513-99J00	ROD, THROTTLE	1	

FIG. 128C




FIG.128C (1-C-3) CARBURETOR (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	13200-99J20	CARBURETOR ASSY	1	W/MANUAL STARTER
1-2	13200-99J30	CARBURETOR ASSY	1	W/ELECTRIC SATRTER
2	13236-99J20	.NOZZLE, MAIN	1	
3-1	09491-82013	.JET, MAIN (82)	1	
3-2	09491-80017	.JET, MAIN (80)	1	
4-1	09492-38011	.JET, PILOT (38)	1	
4-2	09492-35033	.JET, PILOT (35)	1	
5	13239-94J00	.CAP, RUBBER	1	
6	13250-99J00	.FLOAT	1	
7	13370-94J00	.VALVE, FLOAT	1	
8	13247-94J00	.SCREW	4	
9	13375-26E00	.CLIP	1	
10	13254-94J00	.PIN, ARM	1	
11	13802-94J00	.SCREW	1	
12	13534-94J00	.SCREW, STOP	1	
13	13268-94J00	.SPRING	1	
14-1	13240-99J20	.CHAMBER ASSY, FLOAT	1	W/MANUAL STARTER
14-2	13240-99J30	.CHAMBER ASSY, FLOAT	1	W/ELECTRIC SATRTER
15	13251-99J00	..GASKET, FLOAT CHAMBER	1	
16	13279-99J00	..SCREW, DRAIN	1	
17	13275-99J00	..WASHER, PLANE	1	
18	13441-99J00	..SPRING	1	
19	13443-99J00	..SCREW, SPECIAL	1	
20	13493-99J00	..PLUNGER	1	
21	13283-99J00	.PACKING	1	
22	13282-99J00	.PLATE	1	
23	13367-94J00	.SCREW	3	
24	13361-99J00	.HOLDER, CABLE	1	W/MANUAL STARTER
25	13362-94J00	.GUIDE, CABLE	1	W/MANUAL STARTER
26	13363-94J00	.CAP, CABLE SEALING	1	W/MANUAL STARTER
27	13364-94J00	.VALVE, STARTER	1	W/MANUAL STARTER
28	13365-94J00	.SPRING	1	W/MANUAL STARTER
29	13295-14G00	.O RING	1	W/MANUAL STARTER
30	13428-06F30	.PLATE	1	W/ELECTRIC SATRTER

FIG. 128C




FIG.128C (1-C-4) CARBURETOR (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	13367-94J00	.SCREW	1	W/ELECTRIC SATRTER
32	13368-99J00	.STARTER ASSY	1	W/ELECTRIC STARTER
33	13494-94J00	.CLIP	1	
34	13495-94J00	.CAP, RUBBER	1	
35	13496-99J00	.ROD, LINK	1	
36	13281-99J00	.SCREW, PAN	1	
37	09103-06276	BOLT (6X100)	2	
38	13125-99J00	GASKET, CARBURETOR	2	
39	13124-99J00	INSULATOR	1	
40	13436-91J00	CONNECTOR, THROTTLE ROD	1	
41	13513-99J00	ROD, THROTTLE	1	
42	13640-99JL0	KNOB ASSY, STARTER	1	W/MANUAL STARTER
43	09159-14032	NUT	1	W/MANUAL STARTER
44	09320-10501	CUSHION	1	W/MANUAL STARTER

FIG. 128D




FIG.128D (1-C-5) CARBURETOR (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13200-99J30	CARBURETOR ASSY	1	
2	13236-99J20	.NOZZLE, MAIN	1	
3-1	09491-82013	.JET, MAIN (82)	1	
3-2	09491-80017	.JET, MAIN (80)	1	
4-1	09492-38011	.JET, PILOT (38)	1	
4-2	09492-35033	.JET, PILOT (35)	1	
5	13239-94J00	.CAP, RUBBER	1	
6	13250-99J00	.FLOAT	1	
7	13370-94J00	.VALVE, FLOAT	1	
8	13247-94J00	.SCREW	4	
9	13375-26E00	.CLIP	1	
10	13254-94J00	.PIN, ARM	1	
11	13802-94J00	.SCREW	1	
12	13534-94J00	.SCREW, STOP	1	
13	13268-94J00	.SPRING	1	
14	13240-99J30	.CHAMBER ASSY, FLOAT	1	
15	13251-99J00	..GASKET, FLOAT CHAMBER	1	
16	13279-99J00	..SCREW, DRAIN	1	
17	13275-99J00	..WASHER, PLANE	1	
18	13441-99J00	..SPRING	1	
19	13443-99J00	..SCREW, SPECIAL	1	
20	13493-99J00	..PLUNGER	1	
21	13283-99J00	.PACKING	1	
22	13282-99J00	.PLATE	1	
23	13367-94J00	.SCREW	3	
24	13428-06F30	.PLATE	1	
25	13367-94J00	.SCREW	1	
26	13368-99J00	.STARTER ASSY	1	
27	13494-94J00	.CLIP	1	
28	13495-94J00	.CAP, RUBBER	1	
29	13496-99J00	.ROD, LINK	1	
30	13281-99J00	.SCREW, PAN	1	
31	09103-06276	BOLT (6X100)	2	
32	13125-99J00	GASKET, CARBURETOR	2	

FIG. 128D




FIG.128D (1-C-6) CARBURETOR (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	13124-99J00	INSULATOR	1	
34	13436-91J00	CONNECTOR, THROTTLE ROD	1	
35	13513-99J00	ROD, THROTTLE	1	

FIG.146A




FIG.146A (1-C-7) FUEL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15410-98500	FILTER, FUEL	1	
2	01550-06257	BOLT	2	
3	09280-26005	O RING (D:2.4,ID:26.2)	1	
4	15192-99JL0	HOSE, FUEL (CONN TO FILTER)	1	
5	15193-99JL0	HOSE, FUEL (FILTER TO PUMP)	1	
6	15191-99J11	HOSE, FUEL (PUMP TO CARB)	1	
7	09401-09404	CLIP	5	
8	09401-11422	CLIP	1	
9	09408-00054	CLAMP	1	
10	15100-94J02	PUMP ASSY, FUEL	1	
11	15170-94J02	.DIAPHRAGM SET	1	
12	15251-93E00	.SCREW	6	
13	15131-99J00	ROD, FUEL PUMP	1	
14	09403-12406	CLAMP	1	
15	01550-06127	BOLT	1	
16	18498-99J00	PROTECTOR, FUEL HOSE (100)	1	

FIG. 150A




FIG.150A (1-C-8) OIL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	16400-99JL0	PUMP ASSY, OIL	1	
2	16542-99J00	GASKET, OIL PUMP	1	
3	09261-03009	ROLLER	1	
4	01550-06357	BOLT	3	
5	16510-45H10	FILTER, ENGINE OIL	1	
6	16512-99J00	CAP, OIL FILTER	1	
7	09280-13004	O RING (D:1.9,ID:13)	1	
8	09280-54001	O RING (D:2.4,ID:52.6)	1	
9	09440-18002	SPRING	1	
10	01550-06207	BOLT	3	
11	01550-06127	BOLT	1	
12	16910-99J00	GAUGE, OIL LEVEL	1	
13	16930-99JL0	GUIDE, OIL LEVEL GAUGE	1	
14	09280-10016	O RING (D:1.9,ID:9.8)	1	

FIG. 160A




FIG.160A (1-C-9) WATER PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
8	17563-94J00	GROMMET, WATER TUBE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03141-0416A	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X99)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.162A




FIG.162A (1-C-10) THERMOSTAT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17670-94J00	THERMOSTAT (60C)	1	
2	17681-99J10	COVER, THERMOSTAT	1	
3	01550-08307	BOLT	2	
4	11197-99J00	HOSE, WATER RETURN	1	
5	09401-12413	CLIP	2	
6	09408-00173	CLAMP	1	
7	11291-91B50	HOOK, ENGINE	1	OPT
8	01550-08207	BOLT	1	OPT

FIG. 166A




FIG.166A (1-C-11) THROTTLE CONTROL (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	19120-99J00	DRUM, THROTTLE CONTROL	1	
2	19131-95502	CONNECTOR, THROTTLE ROD	2	
3	19148-99J00	LEVER, INTERLINK THROTTLE NO.1	1	
4	19184-99J00	BRACKET, THROTTLE CABLE	1	
5	19656-99J00	ROD, THROTTLE	1	
6	19810-99J00	STOPPER, THROTTLE	1	
7	09140-05005	NUT	2	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	09160-06046	WASHER (6.5X20X1.5)	2	
10	09180-06186	SPACER (6.2X12.6X21)	1	
11	09180-06230	SPACER (6.2X12.6X12.5)	1	
12	09180-12158	SPACER (12.2X20X19.9)	1	
13	01550-06167	BOLT	1	
14	01550-06307	BOLT	1	
15	01550-06357	BOLT	1	

FIG.166B




FIG.166B (1-C-12) THROTTLE CONTROL (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	19120-99J11	LEVER, THROTTLE CONTROL	1	
2	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
3	19148-99J10	LEVER, INTERLINK THROTTLE NO.1	1	
4	19184-99J10	PLATE, THROTTLE LINK	1	
5	19185-99J00	SPRING, THROTTLE LEVER	1	
6	09160-06046	WASHER (6.5X20X1.5)	1	
7	09180-06186	SPACER (6.2X12.6X21)	1	
8	01550-06167	BOLT	1	
9	01550-06357	BOLT	1	

FIG.166C




FIG.166C (1-C-13) THROTTLE CONTROL (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	19120-99J00	DRUM, THROTTLE CONTROL	1	
2	19131-95502	CONNECTOR, THROTTLE ROD	2	
3	19148-99J00	LEVER, INTERLINK THROTTLE NO.1	1	
4	19184-99J00	BRACKET, THROTTLE CABLE	1	
5	19656-99J00	ROD, THROTTLE	1	
6	19810-99J00	STOPPER, THROTTLE	1	
7	09140-05005	NUT	2	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	09160-06046	WASHER (6.5X20X1.5)	2	
10	09180-06186	SPACER (6.2X12.6X21)	1	
11	09180-06230	SPACER (6.2X12.6X12.5)	1	
12	09180-12158	SPACER (12.2X20X19.9)	1	
13	01550-06167	BOLT	1	
14	01550-06307	BOLT	1	
15	01550-06357	BOLT	1	

FIG.166D




FIG.166D (1-C-14) THROTTLE CONTROL (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	19120-99J11	LEVER, THROTTLE CONTROL	1	
2	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
3	19148-99J10	LEVER, INTERLINK THROTTLE NO.1	1	
4	19184-99J10	PLATE, THROTTLE LINK	1	
5	19185-99J00	SPRING, THROTTLE LEVER	1	
6	09160-06046	WASHER (6.5X20X1.5)	1	
7	09180-06186	SPACER (6.2X12.6X21)	1	
8	01550-06167	BOLT	1	
9	01550-06357	BOLT	1	

FIG.167A




FIG.167A (1-C-15) RECOIL STARTER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-99J00	STARTER ASSY, RECOIL	1	
2	18120-99J00	.REEL	1	
3	18130-99J00	.RATCHET SET	1	
4	18142-98600	.SPRING, SPIRAL	1	
5	18181-99J00	.GUIDE, ROPE	1	
6	18210-99J00	.GRIP ASSY	1	
7	18280-99J00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1380
9	18193-99J00	SEAL, RECOIL STARTER	1	
10	01550-06307	BOLT	3	
11	18290-99J02	CABLE ASSY, NSI	1	
12	03542-06129	SCREW	2	
13	37726-99J01	BRACKET, NSI CABLE	1	
14	01550-06167	BOLT	2	
15	69711-93E10	LABEL (S.I.G.P.)	1	
16	61472-94J10	LABEL, RECOIL STARTER	1	

FIG.206A




FIG.206A (1-D-2) CLUTCH ROD (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21122-99J10	PLATE, CLUTCH NOTCH	1	
2	09160-06082	WASHER (6.5X13X1.0)	1	
3	09260-10006	BALL	1	
4	09381-14004	CIRCLIP	1	
5	09440-07079	SPRING	1	
6	02112-06127	SCREW	2	
7	21126-99J00	HOLDER, CLUTCH SHAFT	2	
8	01550-06167	BOLT	2	
9	21210-99J00	SHAFT, CLUTCH LEVER	1	
10-1	23111-99J00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
10-2	23111-99J10	ROD, CLUTCH (L)	1	W/TRANSOM(L)
11	23131-99J00	BOOT, CLUTCH ROD	1	
12	09383-04002	E RING	1	
13	01550-06167	BOLT	2	
14	23115-99J00	LINK, SHIFT DRUM	1	
15	21111-89L00	LEVER, CLUTCH	1	
16	23115-99J10	LINK, CLUTCH LEVER	1	
17	29141-93J00	NUT	1	
18	23210-99J11	LEVER, CLUTCH CONTROL	1	
19	23312-94JL0	CONNECTOR, CLUTCH LINK	1	
20	01550-06207	BOLT	1	
21	09116-06234	BOLT (6X35)	1	
22	09160-06046	WASHER (6.5X20X1.5)	1	
23	09160-06168	WASHER (6X14X1)	1	
24	09164-14008	WASHER	2	
25	09180-06186	SPACER (6.2X12.6X21)	1	
26	09180-06370	SPACER (6.1X8X10)	1	

FIG.206B




FIG.206B (1-D-3) CLUTCH ROD (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21122-99J00	PLATE, CLUTCH NOTCH	1	
2	09160-06082	WASHER (6.5X13X1.0)	1	
3	09260-10006	BALL	1	
4	09381-14004	CIRCLIP	1	
5	09440-07079	SPRING	1	
6	02112-06127	SCREW	2	
7	21126-99J00	HOLDER, CLUTCH SHAFT	1	
8	01550-06167	BOLT	2	
9	21210-99J00	SHAFT, CLUTCH LEVER	1	
10-1	23111-99J00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
10-2	23111-99J10	ROD, CLUTCH (L)	1	W/TRANSOM(L)
11	23131-99J00	BOOT, CLUTCH ROD	1	
12	09383-04002	E RING	1	
13	21241-99J00	LINK, CLUTCH LEVER	1	
14	23210-99J00	LEVER, CLUTCH CONTROL	1	
15	09204-01002	PIN	1	
16	09160-05029	WASHER (5.5X12X0.8)	2	
17	09385-04003	CLIP	1	

FIG.206C




FIG.206C (1-D-4) CLUTCH ROD (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21122-99J10	PLATE, CLUTCH NOTCH	1	
2	09160-06082	WASHER (6.5X13X1.0)	1	
3	09260-10006	BALL	1	
4	09381-14004	CIRCLIP	1	
5	09440-07079	SPRING	1	
6	02112-06127	SCREW	2	
7	21126-99J00	HOLDER, CLUTCH SHAFT	2	
8	01550-06167	BOLT	2	
9	21210-99J00	SHAFT, CLUTCH LEVER	1	
10-1	23111-99J00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
10-2	23111-99J10	ROD, CLUTCH (L)	1	W/TRANSOM(L)
11	23131-99J00	BOOT, CLUTCH ROD	1	
12	09383-04002	E RING	1	
13	01550-06167	BOLT	2	
14	23115-99J00	LINK, SHIFT DRUM	1	
15	21111-89L00	LEVER, CLUTCH	1	
16	23115-99J10	LINK, CLUTCH LEVER	1	
17	29141-93J00	NUT	1	
18	23210-99J11	LEVER, CLUTCH CONTROL	1	
19	23312-94JL0	CONNECTOR, CLUTCH LINK	1	
20	01550-06207	BOLT	1	
21	09116-06234	BOLT (6X35)	1	
22	09160-06046	WASHER (6.5X20X1.5)	1	
23	09160-06168	WASHER (6X14X1)	1	
24	09164-14008	WASHER	2	
25	09180-06186	SPACER (6.2X12.6X21)	1	
26	09180-06370	SPACER (6.1X8X10)	1	

FIG.206D




FIG.206D (1-D-5) CLUTCH ROD (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21122-99J00	PLATE, CLUTCH NOTCH	1	
2	09160-06082	WASHER (6.5X13X1.0)	1	
3	09260-10006	BALL	1	
4	09381-14004	CIRCLIP	1	
5	09440-07079	SPRING	1	
6	02112-06127	SCREW	2	
7	21126-99J00	HOLDER, CLUTCH SHAFT	1	
8	01550-06167	BOLT	2	
9	21210-99J00	SHAFT, CLUTCH LEVER	1	
10-1	23111-99J00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
10-2	23111-99J10	ROD, CLUTCH (L)	1	W/TRANSOM(L)
11	23131-99J00	BOOT, CLUTCH ROD	1	
12	09383-04002	E RING	1	
13	21241-99J00	LINK, CLUTCH LEVER	1	
14	23210-99J00	LEVER, CLUTCH CONTROL	1	
15	09204-01002	PIN	1	
16	09160-05029	WASHER (5.5X12X0.8)	2	
17	09385-04003	CLIP	1	

FIG.210A




FIG.210A (1-D-6) SHIFT ROD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	23311-95J00	CONNECTOR, CLUTCH ROD	1	
2	25111-99J01	ROD, SHIFT	1	
3	25311-99J00	CAM, SHIFT	1	
4	09205-02004	SPRING PIN (2.5X12)	2	
5	25211-99JL0	GUIDE, SHIFT ROD	1	
6	25215-99J00	STOPPER, SHIFT ROD GUIDE	1	
7	29141-93J00	NUT, CLUTCH ROD (M6)	1	
8	09160-06082	WASHER (6.5X13X1.0)	1	
9	09280-06012	O RING (D:1.7,ID:5.8)	2	
10	09280-09012	O RING (D:2.3,ID:9)	1	
11	09289-06L02	DUST SEAL (5X17X3.5)	1	

FIG.220A




FIG.220A (1-D-7) TRANSMISSION

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-99JN0	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-99JP0	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION (NT:12)	1	
9	57510-99J10	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	
11-2	09160-17039	WASHER (T:1.2)	1	
11-3	09160-17025	WASHER (T:1.3)	1	
11-4	09160-17040	WASHER (T:1.4)	1	
11-5	09160-17026	WASHER (T:1.5)	1	
11-6	09160-17041	WASHER (T:1.6)	1	
11-7	09160-17027	WASHER (T:1.7)	1	
11-8	09160-17042	WASHER (T:1.8)	1	
11-9	09160-17028	WASHER (T:1.9)	1	
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (25X34X1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	

FIG.220A




FIG.220A (1-D-8) TRANSMISSION

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.301A






FIG.301A (1-D-9) STARTING MOTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-94J22	STARTING MOTOR	1	
2	31131-94J00	.BRUSH SET, PLUS	1	
3	31135-90J00	.SPRING	4	
4	31151-94J01	.CASE, GEAR	1	
5	31152-90J00	.PLATE, CENTER	1	
6	31153-90J00	.BRACKET, PLANET GEAR	1	
7	31171-96J00	.COVER KIT, DUST	1	
8	31173-94J01	.HOLDER ASSY, BRUSH	1	
9	31191-96J00	.LEVER, SHIFT	1	
10	31220-94J00	.SWITCH, MAGNET	1	
11	31310-90J00	.ARMATURE	1	
12	31320-94J00	.PINION	1	
13	31341-94J00	.SHAFT, PINION	1	
14	31343-90J00	.INTERNAL GEAR	1	
15	31344-90J00	.GEAR, PLANETARY	3	
16	31360-93J01	.WASHER SET	1	
17	31170-94J00	.COVER ASSY,STARTER MOTOR REAR	1	
18	31912-99J00	BAND, STARTING MOTOR	1	
19	31918-94J00	DAMPER, LOWER	1	
20	38860-76F01	RELAY, STARTING MOTOR	1	
21	38915-90J00	HOLDER, RELAY	1	
22	01550-06167	BOLT	2	LOWER
23	01550-08257	BOLT	2	UPPER
24	08316-10087	NUT	1	

FIG.303A





FWD

FIG.303A (1-D-10) MAGNETO (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-99J00	COIL, STATOR & PULSER	1	W/ELECTRIC SATRTER
2	09125-06035	SCREW (6X25)	3	W/ELECTRIC SATRTER
3	32120-99J10	COIL, BATTERY CHARGING	1	W/MANUAL STARTER
4	32140-99J10	COIL, EXITER / PULSER	1	W/MANUAL STARTER
5	01550-05127	BOLT	2	
6-1	32102-99J00	FLYWHEEL	1	W/ELECTRIC SATRTER
6-2	32102-99J10	FLYWHEEL	1	W/MANUAL STARTER
7	09140-14008	NUT	1	
8	09160-15057	WASHER (15X27X4)	1	
9	08341-31039	KEY	1	
10	09407-14407	CLAMP (L:145)	1	
11	09407-14403	CLAMP (L:125)	1	W/MANUAL STARTER
12	02112-06307	SCREW	4	W/MANUAL STARTER






FIG.303B (1-D-11) MAGNETO (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-99J00	COIL, STATOR & PULSER	1	
2	09125-06035	SCREW (6X25)	3	
3	01550-05127	BOLT	2	
4	32102-99J00	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	1	

FIG.303C





FWD

FIG.303C (1-D-12) MAGNETO (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-99J00	COIL, STATOR & PULSER	1	W/ELECTRIC SATRTER
2	09125-06035	SCREW (6X25)	3	W/ELECTRIC SATRTER
3	32120-99J10	COIL, BATTERY CHARGING	1	W/MANUAL STARTER
4	32140-99J10	COIL, EXITER / PULSER	1	W/MANUAL STARTER
5	01550-05127	BOLT	2	
6-1	32102-99J00	FLYWHEEL	1	W/ELECTRIC SATRTER
6-2	32102-99J10	FLYWHEEL	1	W/MANUAL STARTER
7	09140-14008	NUT	1	
8	09160-15057	WASHER (15X27X4)	1	
9	08341-31039	KEY	1	
10	09407-14407	CLAMP (L:145)	1	
11	09407-14403	CLAMP (L:125)	1	W/MANUAL STARTER
12	02112-06307	SCREW	4	W/MANUAL STARTER

FIG.303D (1-D-13) MAGNETO (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-99J00	COIL, STATOR & PULSER	1	
2	09125-06035	SCREW (6X25)	3	
3	01550-05127	BOLT	2	
4	32102-99J00	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	1	




FIG.310A




FIG.310A (1-D-14) RECTIFIER/IGNITION COIL (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-99J00	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	01550-06257	BOLT	2	W/ELECTRIC STARTER
3	32890-99J00	HOLDER, ELECTRIC PARTS	1	
4	09160-06084	WASHER (6.5X18X1.6)	2	
5	09169-06062	WASHER	2	
6	09320-09016	CUSHION	2	
7	01550-06257	BOLT	2	
8-1	32900-99J00	CDI UNIT	1	W/ELECTRIC STARTER
8-2	32900-99J10	CDI UNIT	1	W/MANUAL STARTER
9	32980-99J00	CUSHION, CDI	1	
10	33500-07H00	CAP, SPARK PLUG	2	
11	33410-99J00	COIL, IGNITION	1	
12	01550-06257	BOLT	2	
13	33833-94JL0	TUBE, IGN COIL LEAD (L:120)	1	
14	33833-94J10	PROTECTOR, HIGH TENSION (L:50)	1	W/ELECTRIC STARTER
15	09407-14407	CLAMP (L:145)	1	W/ELECTRIC STARTER




FIG.310B (1-D-15) RECTIFIER/IGNITION COIL (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-99J00	RECTIFIER/REGULATOR ASSY	1	
2	01550-06257	BOLT	2	
3	32890-99J00	HOLDER, ELECTRIC PARTS	1	
4	09160-06084	WASHER (6.5X18X1.6)	2	
5	09169-06062	WASHER	2	
6	09320-09016	CUSHION	2	
7	01550-06257	BOLT	2	
8	32900-99J00	CDI UNIT	1	
9	32980-99J00	CUSHION, CDI	1	
10	33500-07H00	CAP, SPARK PLUG	2	
11	33410-99J00	COIL, IGNITION	1	
12	01550-06257	BOLT	2	
13	33833-94JL0	TUBE, IGN COIL LEAD (L:120)	1	
14	33833-94J10	PROTECTOR, HIGH TENSION (L:50)	1	
15	09407-14407	CLAMP (L:145)	1	

FIG.310C




FIG.310C (1-E-2) RECTIFIER/IGNITION COIL (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-99J00	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	01550-06257	BOLT	2	W/ELECTRIC STARTER
3	32890-99J00	HOLDER, ELECTRIC PARTS	1	
4	09160-06084	WASHER (6.5X18X1.6)	2	
5	09169-06062	WASHER	2	
6	09320-09016	CUSHION	2	
7	01550-06257	BOLT	2	
8-1	32900-99J00	CDI UNIT	1	W/ELECTRIC STARTER
8-2	32900-99J10	CDI UNIT	1	W/MANUAL STARTER
9	32980-99J00	CUSHION, CDI	1	
10	33500-07H00	CAP, SPARK PLUG	2	
11	33410-99J00	COIL, IGNITION	1	
12	01550-06257	BOLT	2	
13	33833-94JL0	TUBE, IGN COIL LEAD (L:120)	1	
14	33833-94J10	PROTECTOR, HIGH TENSION (L:50)	1	W/ELECTRIC STARTER
15	09407-14407	CLAMP (L:145)	1	W/ELECTRIC STARTER

FIG.310D




FIG.310D (1-E-3) RECTIFIER/IGNITION COIL (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-99J00	RECTIFIER/REGULATOR ASSY	1	
2	01550-06257	BOLT	2	
3	32890-99J00	HOLDER, ELECTRIC PARTS	1	
4	09160-06084	WASHER (6.5X18X1.6)	2	
5	09169-06062	WASHER	2	
6	09320-09016	CUSHION	2	
7	01550-06257	BOLT	2	
8	32900-99J00	CDI UNIT	1	
9	32980-99J00	CUSHION, CDI	1	
10	33500-07H00	CAP, SPARK PLUG	2	
11	33410-99J00	COIL, IGNITION	1	
12	01550-06257	BOLT	2	
13	33833-94JL0	TUBE, IGN COIL LEAD (L:120)	1	
14	33833-94J10	PROTECTOR, HIGH TENSION (L:50)	1	
15	09407-14407	CLAMP (L:145)	1	

FIG.322A




FIG.322A (1-E-4) HARNESS (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-99J00	CABLE, STARTER	1	W/ELECTRIC STARTER
2	09407-14403	CLAMP (L:125)	1	W/ELECTRIC STARTER
3-1	36610-99J00	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
3-2	36610-99J10	HARNESS ASSY, WIRING	1	W/MANUAL STARTER
4	09481-20501	.FUSE (20A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6-1	36615-96300	TERMINAL, RESIN	1	W/ELECTRIC SATRTER
6-2	36615-96300	TERMINAL, RESIN	3	W/MANUAL STARTER
7	36656-99J00	GROMMET, CABLE (PORT)	1	
8	09403-13311	CLAMP	1	
9	09407-14403	CLAMP (L:125)	1	
10	09408-00265	CLAMP	1	
11	33833-99J10	TUBE, HARNESS LEAD	1	W/ELECTRIC STARTER
12	09407-14407	CLAMP (L:145)	1	

FIG.322B




FIG.322B (1-E-5) HARNESS (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-99J00	CABLE, STARTER	1	
2	36610-99J20	HARNESS ASSY, WIRING	1	
3	09481-20501	.FUSE (20A)	1	
4	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
5	36656-99J10	GROMMET, CABLE (PORT)	1	
6	09403-13311	CLAMP	1	
7	09407-14403	CLAMP (L:125)	1	
8	09408-00265	CLAMP	1	
9	33833-99J10	TUBE, HARNESS LEAD	1	
10	09407-14407	CLAMP (L:145)	1	

FIG.322C




FIG.322C (1-E-6) HARNESS (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-99J00	CABLE, STARTER	1	W/ELECTRIC STARTER
2	09407-14403	CLAMP (L:125)	1	W/ELECTRIC STARTER
3-1	36610-99J00	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
3-2	36610-99J10	HARNESS ASSY, WIRING	1	W/MANUAL STARTER
4	09481-20501	.FUSE (20A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6-1	36615-96300	TERMINAL, RESIN	1	W/ELECTRIC SATRTER
6-2	36615-96300	TERMINAL, RESIN	3	W/MANUAL STARTER
7	36656-99J00	GROMMET, CABLE (PORT)	1	
8	09403-13311	CLAMP	1	
9	09407-14403	CLAMP (L:125)	1	
10	09408-00265	CLAMP	1	
11	33833-99J10	TUBE, HARNESS LEAD	1	W/ELECTRIC STARTER
12	09407-14407	CLAMP (L:145)	1	

FIG.322D




FIG.322D (1-E-7) HARNESS (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-99J00	CABLE, STARTER	1	
2	36610-99J20	HARNESS ASSY, WIRING	1	
3	09481-20501	.FUSE (20A)	1	
4	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
5	36656-99J10	GROMMET, CABLE (PORT)	1	
6	09403-13311	CLAMP	1	
7	09407-14403	CLAMP (L:125)	1	
8	09408-00265	CLAMP	1	
9	33833-99J10	TUBE, HARNESS LEAD	1	
10	09407-14407	CLAMP (L:145)	1	

FIG.334A




FIG.334A (1-E-8) SENSOR/SWITCH (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34830-87J20	SENSOR ASSY, TEMP	1	
2	37820-93E10	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J00	INDICATOR, OIL PRESSURE	1	
4	36367-99J00	LABEL, WARNING	1	
5	37161-89E13	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	09159-14032	NUT	1	W/ELECTRIC STARTER
7	37721-99J10	SWITCH ASSY, NEUTRAL	1	W/ELECTRIC STARTER
8	37724-99J00	ROD, SW PUSH	1	W/ELECTRIC STARTER
9	37726-99J10	BRACKET, NEUTRAL SW	1	W/ELECTRIC STARTER
10	09137-04004	SCREW (4X16)	2	W/ELECTRIC STARTER
11	33833-99J00	TUBE, SW LEAD (L:80)	1	
12	09407-14407	CLAMP (L:145)	1	

FIG.334B




FIG.334B (1-E-9) SENSOR/SWITCH (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34830-87J20	SENSOR ASSY, TEMP	1	
2	37820-93E10	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-99J00	LABEL, WARNING	1	
5	37721-99J10	SWITCH ASSY, NEUTRAL	1	
6	37724-99J00	ROD, SW PUSH	1	
7	37726-99J10	BRACKET, NEUTRAL SW	1	
8	09137-04004	SCREW (4X16)	2	
9	33833-99J00	TUBE, SW LEAD (L:80)	1	
10	09407-14407	CLAMP (L:145)	1	

FIG.334C




FIG.334C (1-E-10) SENSOR/SWITCH (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34830-87J20	SENSOR ASSY, TEMP	1	
2	37820-93E10	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J00	INDICATOR, OIL PRESSURE	1	
4	36367-99J00	LABEL, WARNING	1	
5	37161-89E13	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	09159-14032	NUT	1	W/ELECTRIC STARTER
7	37721-99J10	SWITCH ASSY, NEUTRAL	1	W/ELECTRIC STARTER
8	37724-99J00	ROD, SW PUSH	1	W/ELECTRIC STARTER
9	37726-99J10	BRACKET, NEUTRAL SW	1	W/ELECTRIC STARTER
10	09137-04004	SCREW (4X16)	2	W/ELECTRIC STARTER
11	33833-99J00	TUBE, SW LEAD (L:80)	1	
12	09407-14407	CLAMP (L:145)	1	

FIG.334D




FIG.334D (1-E-11) SENSOR/SWITCH (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34830-87J20	SENSOR ASSY, TEMP	1	
2	37820-93E10	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-99J00	LABEL, WARNING	1	
5	37721-99J10	SWITCH ASSY, NEUTRAL	1	
6	37724-99J00	ROD, SW PUSH	1	
7	37726-99J10	BRACKET, NEUTRAL SW	1	
8	09137-04004	SCREW (4X16)	2	
9	33833-99J00	TUBE, SW LEAD (L:80)	1	
10	09407-14407	CLAMP (L:145)	1	

FIG.335A




FIG.335A (1-E-12) CLAMP BRACKET (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-99J00-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-99J00-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	09100-10320	BOLT (10X145)	1	
8	09159-10050	NUT	1	
9	09160-10082	WASHER (10.5X19X2)	2	
10	09100-06177	BOLT (6X140)	1	
11	09160-06082	WASHER (6.5X13X1.0)	1	
12	09180-06357	SPACER (6.5X10.5X104)	1	
13	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
14	45261-94J00	LEVER, RELEASE	1	
15	09306-10023	BUSH	2	
16	45420-99JM0	PIN, TILT LOCK	1	
17	45425-94J01	STOPPER, TILT LOCK PIN	1	
18	09441-17001	SPRING	1	
19	45269-94J20	MARK, REVERSE LOCK	1	
20	69911-91J40	MARK, CLAMP BRACKET	1	
21	41210-99JL1	SCREW SET, CLAMP	1	OPT

FIG.335B




FIG.335B (1-E-13) CLAMP BRACKET (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-94J20-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-94J20-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-93E03	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06177	BOLT (6X140)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06357	SPACER (6.5X10.5X104)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-94J00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	45420-99JM0	PIN, TILT LOCK	1	
16	45425-94J01	STOPPER, TILT LOCK PIN	1	
17	09441-17001	SPRING	1	
18	45269-94J20	MARK, REVERSE LOCK	1	
19	69911-91J40	MARK, CLAMP BRACKET	1	
20	41210-99JL1	SCREW SET, CLAMP	1	OPT

FIG.335C




FIG.335C (1-E-14) CLAMP BRACKET (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-99J00-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-99J00-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	09100-10320	BOLT (10X145)	1	
8	09159-10050	NUT	1	
9	09160-10082	WASHER (10.5X19X2)	2	
10	09100-06177	BOLT (6X140)	1	
11	09160-06082	WASHER (6.5X13X1.0)	1	
12	09180-06357	SPACER (6.5X10.5X104)	1	
13	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
14	45261-94J00	LEVER, RELEASE	1	
15	09306-10023	BUSH	2	
16	45420-99JM0	PIN, TILT LOCK	1	
17	45425-94J01	STOPPER, TILT LOCK PIN	1	
18	09441-17001	SPRING	1	
19	45269-94J20	MARK, REVERSE LOCK	1	
20	69911-91J40	MARK, CLAMP BRACKET	1	
21	41210-99JL1	SCREW SET, CLAMP	1	OPT

FIG.335D




FIG.335D (1-E-15) CLAMP BRACKET (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-94J20-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-94J20-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-93E03	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06177	BOLT (6X140)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06357	SPACER (6.5X10.5X104)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-94J00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	45420-99JM0	PIN, TILT LOCK	1	
16	45425-94J01	STOPPER, TILT LOCK PIN	1	
17	09441-17001	SPRING	1	
18	45269-94J20	MARK, REVERSE LOCK	1	
19	69911-91J40	MARK, CLAMP BRACKET	1	
20	41210-99JL1	SCREW SET, CLAMP	1	OPT

FIG.336A




FIG.336A (1-F-2) SWIVEL BRACKET (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-99J40-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-99J50-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-99J00	BUSH, SWIVEL BRACKET	2	
8	41225-89L00	PIN, RELEASE ARM	1	
9	45212-95L00	SPRING, REVERSE LOCK ARM	2	
10	45231-89L00	ARM, REVERSE LOCK	1	
11	45241-89L00	LINK, REVERSE LOCK ARM	1	
12	09204-01002	PIN	1	
13	45247-99J00	PIN, REV LOCK ARM COTTER	1	
14	45250-89L03	LINK, RELEASE	1	
15	09200-06061	PIN	1	
16	09160-06082	WASHER (6.5X13X1.0)	1	
17	09200-05014	PIN	1	
18	43411-939L0	PLATE, STEERING ADJUSTER	1	
19	43412-93900	COVER, STRG ADJUSTER	1	
20	29440-93J00	SPRING, STEERING ADJUSTER	1	
21	09160-08082	WASHER (8.5X16X1.2)	1	
22	09100-08232	BOLT (8X30)	1	
23	43410-99J00	LEVER, STEERING ADJUSTER	1	
24	43412-99J00	COVER, STEERING ADJUSTER	1	
25	43415-99J00	PLATE, STEERING ADJUSTER	1	
26	43420-99J10	PLATE, ADJ FRICTION	1	
27	43424-99J00	HOLDER, ADJ NUT	1	
28	43427-99J00	SPACER, ADJ NUT	1	
29	43428-99J00	BUSH, ADJ NUT	1	
30	43512-99J00	SHAFT, ADJ THREAD	1	
31	43514-94J00	PLATE, ADJ FRICTION	1	
32	43514-99J00	WASHER, ADJ FRICTION PLATE	2	

FIG.336A




FIG.336A (1-F-3) SWIVEL BRACKET (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	43516-89J00	WASHER, STRG ADJ	2	
34	09116-06225	BOLT (6X15)	2	
35	09116-06229	BOLT (6X25)	1	
36	09159-08059	NUT	1	
37	45710-99JL0	ARM, SHALLOW DRIVE	1	
38	45722-94J11	SPRING, ARM	1	
39	09111-10067	BOLT (10X20.5)	2	
40	45269-99J00	MARK, STRG ADJ	1	
41	09160-27012	WASHER (27.5X47X1)	1	

FIG.336B




FIG.336B (1-F-4) SWIVEL BRACKET (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-99J60-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-99J70-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (BLACK)	1	W/TRANSOM(L)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	43755-99J00	ATTACHMENT, STRG BRKT	1	
9	09108-08286	STUD BOLT	2	
10	09159-08059	NUT	2	
11	09160-08082	WASHER (8.5X16X1.2)	2	
12	41225-89L00	PIN, RELEASE ARM	1	
13	45212-95L00	SPRING, REVERSE LOCK ARM	2	
14	45231-89L00	ARM, REVERSE LOCK	1	
15	45241-89L00	LINK, REVERSE LOCK ARM	1	
16	09204-01002	PIN	1	
17	45247-99J00	PIN, REV LOCK ARM COTTER	1	
18	45250-89L03	LINK, RELEASE	1	
19	09200-06061	PIN	1	
20	09160-06082	WASHER (6.5X13X1.0)	1	
21	09200-05014	PIN	1	
22	43411-939L0	PLATE, STRG ADJUSTER	1	
23	43412-93900	COVER, STRG ADJUSTER	1	
24	29440-93J00	SPRING, STRG ADJUSTER	1	
25	09160-08082	WASHER (8.5X16X1.2)	1	
26	09100-08232	BOLT (8X30)	1	
27	45710-99JL0	ARM, SHALLOW DRIVE	1	
28	45722-94J11	SPRING, ARM	1	
29	09111-10067	BOLT (10X20.5)	2	
30	09160-27012	WASHER (27.5X47X1)	1	

FIG.336C




FIG.336C (1-F-5) SWIVEL BRACKET (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-99J40-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-99J50-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-99J00	BUSH, SWIVEL BRACKET	2	
8	41225-89L00	PIN, RELEASE ARM	1	
9	45212-95L00	SPRING, REVERSE LOCK ARM	2	
10	45231-89L00	ARM, REVERSE LOCK	1	
11	45241-89L00	LINK, REVERSE LOCK ARM	1	
12	09204-01002	PIN	1	
13	45247-99J00	PIN, REV LOCK ARM COTTER	1	
14	45250-89L03	LINK, RELEASE	1	
15	09200-06061	PIN	1	
16	09160-06082	WASHER (6.5X13X1.0)	1	
17	09200-05014	PIN	1	
18	43411-939L0	PLATE, STEERING ADJUSTER	1	
19	43412-93900	COVER, STRG ADJUSTER	1	
20	29440-93J00	SPRING, STEERING ADJUSTER	1	
21	09160-08082	WASHER (8.5X16X1.2)	1	
22	09100-08232	BOLT (8X30)	1	
23	43410-99J00	LEVER, STEERING ADJUSTER	1	
24	43412-99J00	COVER, STEERING ADJUSTER	1	
25	43415-99J00	PLATE, STEERING ADJUSTER	1	
26	43420-99J10	PLATE, ADJ FRICTION	1	
27	43424-99J00	HOLDER, ADJ NUT	1	
28	43427-99J00	SPACER, ADJ NUT	1	
29	43428-99J00	BUSH, ADJ NUT	1	
30	43512-99J00	SHAFT, ADJ THREAD	1	
31	43514-94J00	PLATE, ADJ FRICTION	1	
32	43514-99J00	WASHER, ADJ FRICTION PLATE	2	

FIG.336C




FIG.336C (1-F-6) SWIVEL BRACKET (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	43516-89J00	WASHER, STRG ADJ	2	
34	09116-06225	BOLT (6X15)	2	
35	09116-06229	BOLT (6X25)	1	
36	09159-08059	NUT	1	
37	45710-99JL0	ARM, SHALLOW DRIVE	1	
38	45722-94J11	SPRING, ARM	1	
39	09111-10067	BOLT (10X20.5)	2	
40	45269-99J00	MARK, STRG ADJ	1	
41	09160-27012	WASHER (27.5X47X1)	1	

FIG.336D




FIG.336D (1-F-7) SWIVEL BRACKET (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-99J60-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-99J70-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (BLACK)	1	W/TRANSOM(L)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	43755-99J00	ATTACHMENT, STRG BRKT	1	
9	09108-08286	STUD BOLT	2	
10	09159-08059	NUT	2	
11	09160-08082	WASHER (8.5X16X1.2)	2	
12	41225-89L00	PIN, RELEASE ARM	1	
13	45212-95L00	SPRING, REVERSE LOCK ARM	2	
14	45231-89L00	ARM, REVERSE LOCK	1	
15	45241-89L00	LINK, REVERSE LOCK ARM	1	
16	09204-01002	PIN	1	
17	45247-99J00	PIN, REV LOCK ARM COTTER	1	
18	45250-89L03	LINK, RELEASE	1	
19	09200-06061	PIN	1	
20	09160-06082	WASHER (6.5X13X1.0)	1	
21	09200-05014	PIN	1	
22	43411-939L0	PLATE, STRG ADJUSTER	1	
23	43412-93900	COVER, STRG ADJUSTER	1	
24	29440-93J00	SPRING, STRG ADJUSTER	1	
25	09160-08082	WASHER (8.5X16X1.2)	1	
26	09100-08232	BOLT (8X30)	1	
27	45710-99JL0	ARM, SHALLOW DRIVE	1	
28	45722-94J11	SPRING, ARM	1	
29	09111-10067	BOLT (10X20.5)	2	
30	09160-27012	WASHER (27.5X47X1)	1	

FIG.401A




FIG.401A (1-F-8) ENGINE HOLDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51110-99J00	HOLDER, ENGINE	1	
2	51211-99J00	GASKET, ENGINE HOLDER	1	
3	09116-08151	BOLT (8X30)	2	
4	09202-06023	PIN (6X10)	2	
5	09282-12017	OIL SEAL (11X24X4.5)	1	
6	16515-99J10	HOSE, OIL	1	
7	09401-12413	CLIP	1	
8	54112-99J01	BOLT, UPR MOUNT (L:123)	2	
9	54113-99JM0	WASHER, UPR MOUNT BOLT	2	
10	54120-99JL0	MOUNT, UPR THRUST	1	
11	54122-99J00	SPACER, UPR MOUNT (10.2X16X15)	2	
12	54125-99J00	STOPPER, UPR REVERSE THRUST	2	
13	54126-99JL0	STOPPER, UPR THRUST	1	
14	54130-99J00	MOUNT, UPPER	2	
15	54148-99J00	COVER, UPR MOUNT	2	
16	09116-08137	BOLT (8X22)	4	
17	09140-10031	NUT	2	
18	16520-99J00	STRAINER, OIL	1	
19	09401-13424	CLIP	1	

FIG.405A




FIG.405A (1-F-9) DRIVE SHAFT HOUSING

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17913-93J00	PLUG, WATER	1	
2	17914-93J00	GASKET, WATER PLUG	1	
3-1	52110-99J00-0EP	HOUSING, DRIVE SHAFT (S) (BLACK)	1	W/TRANSOM(S)
3-2	52110-99J10-0EP	HOUSING, DRIVE SHAFT (L) (BLACK)	1	W/TRANSOM(L)
4	52113-99J00	GASKET, DRIVE SHAFT HSG	1	
5	57135-99J00	GUIDE, DRIVE SHAFT	1	
6	09100-08312	BOLT (8X105)	4	
7	09116-08151	BOLT (8X30)	4	
8	09160-08082	WASHER (8.5X16X1.2)	4	
9	09202-06023	PIN (6X10)	2	
10	09168-12017	GASKET (12X17X1)	1	
11	09248-12009	PLUG (12X18.65)	1	
12	54151-99J00	MOUNT, LOWER THRUST	1	
13	54167-99J01	MOUNT, LOWER SIDE	2	
14	54211-99J01-0EP	COVER, LWR MOUNT STBD (BLACK)	1	
15	54221-99J01-0EP	COVER, LWR MOUNT PORT (BLACK)	1	
16	54213-93901	PIN, KNOCK	2	
17	09116-08154	BOLT (8X40)	2	

FIG.407A




FIG.407A (1-F-10) GEAR CASE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55100-99J40-0EP	CASE, GEAR (BLACK)	1	
2	09263-17L03	.BEARING (17X24X27.5)	1	
3	09262-25003	.BEARING (25X52X15)	1	
4	09202-06023	PIN (6X10)	2	
5	09116-08151	BOLT (8X30)	4	
6	55321-87J00	ANODE, PROTECTION	1	
7	09103-06281	BOLT (6X14)	1	
8	59178-97J00	GASKET, DRAIN PLUG	2	
9	09248-08001	PLUG (8X7.5)	2	
10	56120-99J40-0EP	HOUSING, PROPELLER SHAFT (BLACK)	1	
11	08110-60050	.BEARING	1	
12	09280-57002	.O RING (D:3.5,ID:65.2)	1	
13	09289-17L02	.OIL SEAL (17X30X6)	2	
14	09116-06227	BOLT (6X20)	2	
15-1	58100-89L00-019	PROPELLER, 3X9-1/4X7 (M701) (BLACK)	1	
15-2	58100-89L20-019	PROPELLER, 3X9-1/4X9 (M930) (BLACK)	1	
15-3	58100-89L30-019	PROPELLER, 3X9-1/4X10 (M1001) (BLACK)	1	
15-4	58100-89L40-019	PROPELLER, 3X9-1/4X11 (M1101) (BLACK)	1	
15-5	58100-90L40-019	PROPELLER, 3X9-1/4X8 (M821) (BLACK)	1	
15-6	58100-90L50-019	PROPELLER, 3X9-1/4X9 (M911) (BLACK)	1	
15-7	58100-90L60-019	PROPELLER, 3X9-1/4X10 (M1011) (BLACK)	1	
16	58120-89L00	.BUSH, PROPELLER	1	

FIG.407A




FIG.407A (1-F-11) GEAR CASE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	57632-94J00	STOPPER, PROPELLER BUSH	1	
18	09141-12005	NUT	1	
19	09160-12066	WASHER (12.5X22X2.5)	1	
20	09204-02004	PIN	1	
21	55331-99J10	CORE, EXHAUST SEAL	1	
22	55332-99J10	RUBBER, EXHAUST SEAL	1	
23	55300-95500	ZINC ASSY, PROTECTION	1	OPT
24	09126-06006	.SCREW (6X20)	2	OPT
25	29141-93J00	.NUT	2	OPT
26	29162-93J00	.WASHER	2	OPT
27	55321-87J10	ANODE (MAGNESIUM)	1	OPT

FIG.410A




FIG.410A (1-F-12) SIDE COVER (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-99J02-0EP	COVER, SIDE STBD (BLACK)	1	
2	61155-94500	.TUBE, WATER INSP	1	
3	61820-99J01-0EP	COVER, SIDE PORT (BLACK)	1	
4	09136-06169	SCREW (6X35)	8	
5	61112-99J00	RUBBER, SIDE COVER	1	
6	61134-99JL0	SEAL, SIDE COVER	1	
7	61157-99J00	HOSE, WATER INSPECTION	1	
8	09401-08413	CLIP	2	
9	09403-12316	CLAMP	1	
10	61851-93E10	PROTECTOR, SIDE COVER	2	
11	03542-05169	SCREW	4	
12	61831-99J00-0EP	PANEL, INSTRUMENT (BLACK)	1	
13	09116-06230	BOLT (6X25)	2	
14	09169-06075	WASHER	2	
15	09320-09039	CUSHION	2	
16	09148-06017	NUT	2	
17	02142-06167	SCREW	2	
18	61412-99J00	HOOK, FRONT PANEL	1	
19	61643-99J00	SCREW, HOOK	2	
20	09160-05029	WASHER (5.5X12X0.8)	2	
21	61610-90L00	FASTENER	1	
22	61616-93EL0	PIN, LEVER	1	
23	61642-99J00	HOLDER, FASTENER LEVER	1	
24	09161-04012	WASHER (4.2X11X1)	1	
25	09385-04003	CLIP	1	
26	09116-06223	BOLT (6X12)	1	
27	08310-00067	NUT	1	
28	61124-99J21	GROMMET, CABLE (STBD)	1	
29	61151-99J00	CUSHION, SIDE COVER HOLDER	1	
30	61827-99J00	HOLDER, SIDE COVER	1	W/MANUAL STARTER
31	02142-06167	SCREW	1	W/MANUAL STARTER
32	61813-99J01	CUSION, SIDE COVER	1	
33	36617-93J10	BRACKET, HARNESS	1	
34	17917-87LL0	CONNECTOR, FLUSH WATER	1	OPT

FIG.410B




FIG.410B (1-F-13) SIDE COVER (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-99J02-0EP	COVER, SIDE STBD (BLACK)	1	
2	61155-94500	.TUBE, WATER INSP	1	
3	61820-99J01-0EP	COVER, SIDE PORT (BLACK)	1	
4	09136-06169	SCREW (6X35)	8	
5	61112-99J00	RUBBER, SIDE COVER	1	
6	61134-99JL0	SEAL, SIDE COVER	1	
7	61157-99J00	HOSE, WATER INSPECTION	1	
8	09401-08413	CLIP	2	
9	09403-12316	CLAMP	1	
10	61851-93E10	PROTECTOR, SIDE COVER	2	
11	03542-05169	SCREW	4	
12	61831-99J00-0EP	PANEL, INSTRUMENT (BLACK)	1	
13	09116-06230	BOLT (6X25)	2	
14	09169-06075	WASHER	2	
15	09320-09039	CUSHION	2	
16	09148-06017	NUT	2	
17	02142-06167	SCREW	2	
18	61412-99J00	HOOK, FRONT PANEL	1	
19	61643-99J00	SCREW, HOOK	2	
20	09160-05029	WASHER (5.5X12X0.8)	2	
21	61610-90L00	FASTENER	1	
22	61616-93EL0	PIN, LEVER	1	
23	61642-99J00	HOLDER, FASTENER LEVER	1	
24	09161-04012	WASHER (4.2X11X1)	1	
25	09385-04003	CLIP	1	
26	09116-06223	BOLT (6X12)	1	
27	08310-00067	NUT	1	
28	61124-99J10	GROMMET, R/CON CABLE (STBD)	1	
29	61151-99J00	CUSHION, SIDE COVER HOLDER	1	
30	61813-99J01	CUSION, SIDE COVER	1	
31	36617-93J10	BRACKET, HARNESS	1	
32	17917-87LL0	CONNECTOR, FLUSH WATER	1	OPT

FIG.410C




FIG.410C (1-F-14) SIDE COVER (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-99J02-0EP	COVER, SIDE STBD (BLACK)	1	
2	61155-94500	.TUBE, WATER INSP	1	
3	61820-99J01-0EP	COVER, SIDE PORT (BLACK)	1	
4	09136-06169	SCREW (6X35)	8	
5	61112-99J00	RUBBER, SIDE COVER	1	
6	61134-99JL0	SEAL, SIDE COVER	1	
7	61157-99J00	HOSE, WATER INSPECTION	1	
8	09401-08413	CLIP	2	
9	09403-12316	CLAMP	1	
10	61851-93E10	PROTECTOR, SIDE COVER	2	
11	03542-05169	SCREW	4	
12	61831-99J00-0EP	PANEL, INSTRUMENT (BLACK)	1	
13	09116-06230	BOLT (6X25)	2	
14	09169-06075	WASHER	2	
15	09320-09039	CUSHION	2	
16	09148-06017	NUT	2	
17	02142-06167	SCREW	2	
18	61412-99J00	HOOK, FRONT PANEL	1	
19	61643-99J00	SCREW, HOOK	2	
20	09160-05029	WASHER (5.5X12X0.8)	2	
21	61610-90L00	FASTENER	1	
22	61616-93EL0	PIN, LEVER	1	
23	61642-99J00	HOLDER, FASTENER LEVER	1	
24	09161-04012	WASHER (4.2X11X1)	1	
25	09385-04003	CLIP	1	
26	09116-06223	BOLT (6X12)	1	
27	08310-00067	NUT	1	
28	61124-99J21	GROMMET, CABLE (STBD)	1	
29	61151-99J00	CUSHION, SIDE COVER HOLDER	1	
30	61827-99J00	HOLDER, SIDE COVER	1	W/MANUAL STARTER
31	02142-06167	SCREW	1	W/MANUAL STARTER
32	61813-99J01	CUSION, SIDE COVER	1	
33	36617-93J10	BRACKET, HARNESS	1	
34	17917-87LL0	CONNECTOR, FLUSH WATER	1	OPT

FIG.410D




FIG.410D (1-F-15) SIDE COVER (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-99J02-0EP	COVER, SIDE STBD (BLACK)	1	
2	61155-94500	.TUBE, WATER INSP	1	
3	61820-99J01-0EP	COVER, SIDE PORT (BLACK)	1	
4	09136-06169	SCREW (6X35)	8	
5	61112-99J00	RUBBER, SIDE COVER	1	
6	61134-99JL0	SEAL, SIDE COVER	1	
7	61157-99J00	HOSE, WATER INSPECTION	1	
8	09401-08413	CLIP	2	
9	09403-12316	CLAMP	1	
10	61851-93E10	PROTECTOR, SIDE COVER	2	
11	03542-05169	SCREW	4	
12	61831-99J00-0EP	PANEL, INSTRUMENT (BLACK)	1	
13	09116-06230	BOLT (6X25)	2	
14	09169-06075	WASHER	2	
15	09320-09039	CUSHION	2	
16	09148-06017	NUT	2	
17	02142-06167	SCREW	2	
18	61412-99J00	HOOK, FRONT PANEL	1	
19	61643-99J00	SCREW, HOOK	2	
20	09160-05029	WASHER (5.5X12X0.8)	2	
21	61610-90L00	FASTENER	1	
22	61616-93EL0	PIN, LEVER	1	
23	61642-99J00	HOLDER, FASTENER LEVER	1	
24	09161-04012	WASHER (4.2X11X1)	1	
25	09385-04003	CLIP	1	
26	09116-06223	BOLT (6X12)	1	
27	08310-00067	NUT	1	
28	61124-99J10	GROMMET, R/CON CABLE (STBD)	1	
29	61151-99J00	CUSHION, SIDE COVER HOLDER	1	
30	61813-99J01	CUSION, SIDE COVER	1	
31	36617-93J10	BRACKET, HARNESS	1	
32	17917-87LL0	CONNECTOR, FLUSH WATER	1	OPT

FIG.420A




FIG.420A (1-G-2) ENGINE COVER (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-99J01-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-99J00	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61443-99J00	STRIPE, ENGINE COVER STBD	1	
5	61453-99J00	STRIPE, ENGINE COVER PORT	1	
6	68111-99J00	EMBLEM (S)	1	
7	61435-99J00	MARK, EMBLEM REAR (8)	1	
8	61458-89L00	LABEL, ENGINE COVER	1	
9	59800-99J01	TOOL ASSY	1	
10	99011-99J40-055	MANUAL, OWNER'S	1	
11	68110-89L00	COVER, WEATHER	1	OPT

FIG.420B




FIG.420B (1-G-3) ENGINE COVER (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-99J01-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-99J00	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61443-99J00	STRIPE, ENGINE COVER STBD	1	
5	61453-99J00	STRIPE, ENGINE COVER PORT	1	
6	68111-99J00	EMBLEM (S)	1	
7	61435-99J00	MARK, EMBLEM REAR (8)	1	
8	61458-89L00	LABEL, ENGINE COVER	1	
9	59800-99J01	TOOL ASSY	1	
10	99011-99J40-055	MANUAL, OWNER'S	1	
11	68110-89L00	COVER, WEATHER	1	OPT

FIG.420C




FIG.420C (1-G-4) ENGINE COVER (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-99J01-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-99J00	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61443-99J00	STRIPE, ENGINE COVER STBD	1	
5	61453-99J00	STRIPE, ENGINE COVER PORT	1	
6	68111-99J00	EMBLEM (S)	1	
7	61435-99J10	MARK, EMBLEM REAR (9.9)	1	
8	61458-89L00	LABEL, ENGINE COVER	1	
9	59800-99J01	TOOL ASSY	1	
10	99011-99J40-055	MANUAL, OWNER'S	1	
11	68110-89L00	COVER, WEATHER	1	OPT

FIG.420D




FIG.420D (1-G-5) ENGINE COVER (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-99J01-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-99J00	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61443-99J00	STRIPE, ENGINE COVER STBD	1	
5	61453-99J00	STRIPE, ENGINE COVER PORT	1	
6	68111-99J00	EMBLEM (S)	1	
7	61435-99J10	MARK, EMBLEM REAR (9.9)	1	
8	61458-89L00	LABEL, ENGINE COVER	1	
9	59800-99J01	TOOL ASSY	1	
10	99011-99J40-055	MANUAL, OWNER'S	1	
11	68110-89L00	COVER, WEATHER	1	OPT

FIG.432A




FIG.432A (1-G-6) FUEL TANK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65000-89L10	TANK ASSY, FUEL (12L)	1	
2	65520-99100	.CAP ASSY, FUEL TANK	1	
3	65561-95D00	.GASKET, TANK CAP	1	
4	65831-95D00	.FILTER, OUTLET	1	
5	65890-99100	.OUTLET	1	
6	65892-95D00	.O RING	1	
7	65740-95D01	.PLUG, FUEL CONNECTOR	1	
8	65700-89L30	HOSE, FUEL	1	
9	65750-87JL0	.SOCKET, FUEL HOSE	1	
10	65750-955L0	.SOCKET, FUEL HOSE	1	
11	65770-89L00	.PUMP, SQUEEZE	1	
12	65781-98500	.CLIP	4	
13	65720-986L0	PLUG, FUEL CONNECTOR	1	
14	09103-06237	BOLT (6X12.5)	1	
15	09160-06085	WASHER (6.5X15X1)	1	




FIG.442A (1-G-7) DRAG LINK (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.442B




FIG.442B (1-G-8) DRAG LINK (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	




FIG.444A (1-G-9) TILLER HANDLE (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-0EP	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-0EP	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L10	GRIP, HANDLE	1	
7	63220-94J00	ROD, HANDLE	1	
8	63225-94J00	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-99J00	CABLE ASSY, THROTTLE	2	
15	09116-08151	BOLT (8X30)	2	
16	09126-06015	SCREW (6X23)	1	
17	09136-05041	SCREW (5X20)	2	
18	09163-06001	LOCK WASHER	1	
19	09440-12027	SPRING	1	
20	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->150
21	63114-99J01	PLATE, WARNING INDICATOR	1	
22	63122-99J00	PROTECTOR, HANDLE COVER	1	
23	63131-99J11-0EP	BRACKET, TILLER HANDLE (BLACK)	1	
24	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
25	09116-08155	BOLT (8X45)	2	
26	09125-05042	SCREW (5X10)	1	
27	63215-93110	MARK, HANDLE GRIP	1	
28	37830-99J10	SWITCH ASSY, EMERGENCY	1	
29	37823-97J00	.PLATE, LOCK	1	
30	37826-97J00	.NUT	1	
31	37835-95D00	LABEL, STOP	1	
32	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444B




FIG.444B (1-G-10) TILLER HANDLE (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-0EP	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-0EP	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L10	GRIP, HANDLE	1	
7	63220-94J00	ROD, HANDLE	1	
8	63225-94J00	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-99J00	CABLE ASSY, THROTTLE	2	
15	09116-08151	BOLT (8X30)	2	
16	09126-06015	SCREW (6X23)	1	
17	09136-05041	SCREW (5X20)	2	
18	09163-06001	LOCK WASHER	1	
19	09440-12027	SPRING	1	
20	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->150
21	63114-99J01	PLATE, WARNING INDICATOR	1	
22	63122-99J00	PROTECTOR, HANDLE COVER	1	
23	63131-99J11-0EP	BRACKET, TILLER HANDLE (BLACK)	1	
24	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
25	09116-08155	BOLT (8X45)	2	
26	09125-05042	SCREW (5X10)	1	
27	63215-93110	MARK, HANDLE GRIP	1	
28	37830-99J10	SWITCH ASSY, EMERGENCY	1	
29	37823-97J00	.PLATE, LOCK	1	
30	37826-97J00	.NUT	1	
31	37835-95D00	LABEL, STOP	1	
32	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.450A




FIG.450A (1-G-11) REMOTE CONTROL (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	.GROMMET, WIRING HARNESS	1	
3	37110-94J02	.SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	.SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SWITCH LOCK	1	
9	37826-92J00	..NUT	1	
10	37859-90J00	.SPACER	1	
11	37864-94J10	.CAP, PTT SW	1	
12	38500-93J00	.BUZZER ASSY, WARNING	1	
13	67212-95600	.WASHER	1	
14	67214-92E00	.SCREW (5X10)	1	
15	67220-95630	.PLATE ASSY	1	
16	67223-99E10	.KNOB, BRAKE ADJUST	1	
17	67229-95600	.ROLLER	1	
18	67232-95600	.BUSH	1	
19	67238-87D00	.GEAR, DRIVE	1	
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	

FIG.450A




FIG.450A (1-G-12) REMOTE CONTROL (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	
52	36620-94J01	WIRE ASSY,REMOTE CONTROL	1	
53	09481-10501	.FUSE (10A)	1	

FIG.450B




FIG.450B (1-G-13) REMOTE CONTROL (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	.GROMMET, WIRING HARNESS	1	
3	37110-94J02	.SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	.SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SWITCH LOCK	1	
9	37826-92J00	..NUT	1	
10	37859-90J00	.SPACER	1	
11	37864-94J10	.CAP, PTT SW	1	
12	38500-93J00	.BUZZER ASSY, WARNING	1	
13	67212-95600	.WASHER	1	
14	67214-92E00	.SCREW (5X10)	1	
15	67220-95630	.PLATE ASSY	1	
16	67223-99E10	.KNOB, BRAKE ADJUST	1	
17	67229-95600	.ROLLER	1	
18	67232-95600	.BUSH	1	
19	67238-87D00	.GEAR, DRIVE	1	
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	

FIG.450B




FIG.450B (1-G-14) REMOTE CONTROL (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	
52	36620-94J01	WIRE ASSY,REMOTE CONTROL	1	
53	09481-10501	.FUSE (10A)	1	

FIG.454A




FIG.454A (1-G-15) REMOCON CABLE HOLDER (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67467-89J01	CONNECTOR, R/CON CABLE	2	
2	09160-06055	WASHER (7X12X1)	2	
3	09385-06012	CLIP	2	
4	67340-99J00	HOLDER, REMOCON CABLE	1	
5	01550-06167	BOLT	2	

FIG.454B (1-H-2) REMOCON CABLE HOLDER (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67467-89J01	CONNECTOR, R/CON CABLE	2	
2	09160-06055	WASHER (7X12X1)	2	
3	09385-06012	CLIP	2	
4	67340-99J00	HOLDER, REMOCON CABLE	1	
5	01550-06167	BOLT	2	






FIG.501A (1-H-3) OPT:METER (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34200-93J20	TACHOMETER ASSY	1	BLACK
1-2	34200-93J32	TACHOMETER ASSY	1	WHITE
2	09471-12028	.BULB (12V,3.4W)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	




FIG.501B (1-H-4) OPT:METER (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34200-93J20	TACHOMETER ASSY	1	BLACK
1-2	34200-93J32	TACHOMETER ASSY	1	WHITE
2	09471-12028	.BULB (12V,3.4W)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	




FIG.513A




FIG.513A (1-H-5) OPT:REMOTE CONTROL PARTS (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67130-99J01	PARTS SET, REMOTE CONTROL	1	
2	19120-99J11	.DRUM, THROTTLE CONTROL	1	
3	19122-99J00	.LEVER, INTERLINK THROTTLE NO.2	1	
4	19184-99J10	.PLATE, THROTTLE LINK	1	
5	19185-99J00	.SPRING, THROTTLE LEVER	1	
6	21241-99J00	.LINK, CLUTCH LEVER	1	
7	23210-99J00	.LEVER, CLUTCH CONTROL	1	
8	09204-01002	.PIN	1	
9	09160-05029	.WASHER (5.5X12X0.8)	2	
10	09385-04003	.CLIP	1	
11	43755-99J00	.ATTACHMENT, STRG BRKT	1	
12	09108-08286	.STUD BOLT	2	
13	09159-08059	.NUT	2	
14	09160-08082	.WASHER (8.5X16X1.2)	2	
15	36360-99J10	.INDICATOR, OIL PRESSURE	1	
16	36610-99J20	.HARNESS ASSY, WIRING	1	
17	09481-20501	..FUSE (20A)	1	
18	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
19	36656-99J10	.GROMMET, CABLE (PORT)	1	
20	09407-14403	.CLAMP (L:125)	1	
21	09407-14407	.CLAMP (L:145)	1	
22	61124-99J10	.GROMMET, R/CON CABLE (STBD)	1	
23	67467-89J01	.CONNECTOR, R/CON CABLE	2	
24	09160-06055	.WASHER (7X12X1)	2	
25	09385-06012	.CLIP	2	
26	67340-99J00	.HOLDER, REMOCON CABLE	1	
27	01550-06167	.BOLT	2	

FIG.513B




FIG.513B (1-H-6) OPT:REMOTE CONTROL PARTS (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67130-99J01	PARTS SET, REMOTE CONTROL	1	
2	19120-99J11	.DRUM, THROTTLE CONTROL	1	
3	19122-99J00	.LEVER, INTERLINK THROTTLE NO.2	1	
4	19184-99J10	.PLATE, THROTTLE LINK	1	
5	19185-99J00	.SPRING, THROTTLE LEVER	1	
6	21241-99J00	.LINK, CLUTCH LEVER	1	
7	23210-99J00	.LEVER, CLUTCH CONTROL	1	
8	09204-01002	.PIN	1	
9	09160-05029	.WASHER (5.5X12X0.8)	2	
10	09385-04003	.CLIP	1	
11	43755-99J00	.ATTACHMENT, STRG BRKT	1	
12	09108-08286	.STUD BOLT	2	
13	09159-08059	.NUT	2	
14	09160-08082	.WASHER (8.5X16X1.2)	2	
15	36360-99J10	.INDICATOR, OIL PRESSURE	1	
16	36610-99J20	.HARNESS ASSY, WIRING	1	
17	09481-20501	..FUSE (20A)	1	
18	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
19	36656-99J10	.GROMMET, CABLE (PORT)	1	
20	09407-14403	.CLAMP (L:125)	1	
21	09407-14407	.CLAMP (L:145)	1	
22	61124-99J10	.GROMMET, R/CON CABLE (STBD)	1	
23	67467-89J01	.CONNECTOR, R/CON CABLE	2	
24	09160-06055	.WASHER (7X12X1)	2	
25	09385-06012	.CLIP	2	
26	67340-99J00	.HOLDER, REMOCON CABLE	1	
27	01550-06167	.BOLT	2	





FIG.515A (1-H-7) OPT:REMOCON CABLE (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	2	
1-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	2	
1-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	2	
1-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	2	
1-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	2	
1-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	2	
1-7	67320-93J60	CABLE, REMOCON 20F (6.0M)	2	
1-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	2	
1-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	2	
2	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	W/ELECTRIC STARTER
3	09481-10501	.FUSE (10A)	1	W/ELECTRIC STARTER
4	36990-87D00	TERMINAL & SLEEVE SET	1	W/ELECTRIC STARTER

FIG.515B (1-H-8) OPT:REMOCON CABLE (DF8AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	2	
1-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	2	
1-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	2	
1-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	2	
1-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	2	
1-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	2	
1-7	67320-93J60	CABLE, REMOCON 20F (6.0M)	2	
1-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	2	
1-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	2	






FIG.515C (1-H-9) OPT:REMOCON CABLE (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	2	
1-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	2	
1-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	2	
1-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	2	
1-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	2	
1-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	2	
1-7	67320-93J60	CABLE, REMOCON 20F (6.0M)	2	
1-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	2	
1-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	2	
2	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	W/ELECTRIC STARTER
3	09481-10501	.FUSE (10A)	1	W/ELECTRIC STARTER
4	36990-87D00	TERMINAL & SLEEVE SET	1	W/ELECTRIC STARTER

FIG.515D (1-H-10) OPT:REMOCON CABLE (DF9.9AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	2	
1-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	2	
1-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	2	
1-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	2	
1-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	2	
1-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	2	
1-7	67320-93J60	CABLE, REMOCON 20F (6.0M)	2	
1-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	2	
1-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	2	




FIG.544A




FIG.544A (1-H-11) OPT:REMOTE CONTROL ASSY SINGLE (1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.545A




FIG.545A (1-H-12) OPT:REMOTE CONTROL ASSY SINGLE (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, NEUTRAL	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545A




FIG.545A (1-H-13) OPT:REMOTE CONTROL ASSY SINGLE (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.553A




FIG.553A (1-H-14) OPT:ELECTRICAL (MANUAL STARTER) (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-99J00	KIT, BATTERY CHARGING	1	
2	32801-95J01	.RECTIFIER/REGULATOR SET	1	
3	32800-95J01	..RECTIFIER/REGULATOR ASSY	1	
4	36615-96300	..TERMINAL, RESIN	2	
5	29404-93J10	..CLAMP, RECT/RGLTR LEAD	1	
6	09407-10404	..CLAMP (L:100)	1	
7	09408-00024	..CLIP (ID:23)	1	
8	01550-06257	..BOLT	2	
9	39600-94J01	.RECEPTACLE SET	1	
10	33816-94J01	..CLAMP, CABLE	1	
11	36740-94J00	..CASE ASSY, FUSE	1	
12	37801-98300	..LEAD RECEPTACLE GROUND	1	
13	39601-95D00	..RECEPTACLE ASSY, LIGHTING	1	
14	36634-93910	...CAP	1	
15	39602-93900	..PLUG, RECEPTACLE	1	
16	39603-94400	..GROMMET, RECEPTACLE	1	
17	09407-10404	..CLAMP (L:100)	1	
18	09407-25402	..CLAMP (L:250)	1	
19	09407-14403	..CLAMP (L:125)	2	
20	03241-0625A	..SCREW	1	
21	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.553B




FIG.553B (1-H-15) OPT:ELECTRICAL (MANUAL STARTER) (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-99J00	KIT, BATTERY CHARGING	1	
2	32801-95J01	.RECTIFIER/REGULATOR SET	1	
3	32800-95J01	..RECTIFIER/REGULATOR ASSY	1	
4	36615-96300	..TERMINAL, RESIN	2	
5	29404-93J10	..CLAMP, RECT/RGLTR LEAD	1	
6	09407-10404	..CLAMP (L:100)	1	
7	09408-00024	..CLIP (ID:23)	1	
8	01550-06257	..BOLT	2	
9	39600-94J01	.RECEPTACLE SET	1	
10	33816-94J01	..CLAMP, CABLE	1	
11	36740-94J00	..CASE ASSY, FUSE	1	
12	37801-98300	..LEAD RECEPTACLE GROUND	1	
13	39601-95D00	..RECEPTACLE ASSY, LIGHTING	1	
14	36634-93910	...CAP	1	
15	39602-93900	..PLUG, RECEPTACLE	1	
16	39603-94400	..GROMMET, RECEPTACLE	1	
17	09407-10404	..CLAMP (L:100)	1	
18	09407-25402	..CLAMP (L:250)	1	
19	09407-14403	..CLAMP (L:125)	2	
20	03241-0625A	..SCREW	1	
21	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.561A




FIG.561A (1-I-2) OPT:STARTING MOTOR (MANUAL STARTER) (DF8A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-99J01	STARTER SET, ELECTRIC	1	
2	12625-99J00	.BASE, STATOR	1	
3	31101-99J00	.MOTOR SET, STARTING	1	
4	31100-94J22	..MOTOR ASSY, STARTING	1	
5	31912-99J00	..BAND	1	
6	31918-94J00	..DAMPER	1	
7	38860-76F01	..RELAY ASSY	1	
8	38915-90J00	..HOLDER	1	
9	01550-06167	..BOLT	2	
10	01550-08257	..BOLT	2	
11	08316-10087	..NUT	1	
12	32104-99J00	.MAGNETO SET	1	
13	32102-99J00	..FLYWHEEL, MAGNETO	1	
14	32120-99J00	..COIL, STATOR & PULSER	1	
15	09125-06035	..SCREW (6X25)	3	
16	32801-99J00	.RECTIFIER/REGULATOR SET	1	
17	32800-99J00	..RECTIFIER/REGULATOR ASSY	1	
18	01550-06257	..BOLT	2	
19	32900-99J00	.UNIT, CDI	1	
20	33800-99J01	.CABLE SET, STARTING	1	
21	33810-99J00	..CABLE, STARTER	1	
22	36655-99J00	..PLATE, CABLE GROMMET	1	
23	36656-99J20	..GROMMET, CABLE (PORT)	1	
24	37161-89E13	..SWITCH ASSY, STARTER	1	
25	37721-99J10	..SWITCH ASSY, NEUTRAL	1	
26	37724-99J00	..ROD, SWITCH PUSH	1	
27	37726-99J10	..BRACKET, NEUTRAL SW	1	
28	09137-04004	..SCREW (4X16)	2	
29	09159-14032	..NUT	1	
30	36610-99J00	.HARNESS ASSY, WIRING	1	
31	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
32	09481-20501	..FUSE (20A)	1	
33	09407-14403	.CLAMP (L:125)	2	
34	09407-14407	.CLAMP (L:145)	4	

FIG.561B




FIG.561B (1-I-3) OPT:STARTING MOTOR (MANUAL STARTER) (DF9.9A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-99J01	STARTER SET, ELECTRIC	1	
2	12625-99J00	.BASE, STATOR	1	
3	31101-99J00	.MOTOR SET, STARTING	1	
4	31100-94J22	..MOTOR ASSY, STARTING	1	
5	31912-99J00	..BAND	1	
6	31918-94J00	..DAMPER	1	
7	38860-76F01	..RELAY ASSY	1	
8	38915-90J00	..HOLDER	1	
9	01550-06167	..BOLT	2	
10	01550-08257	..BOLT	2	
11	08316-10087	..NUT	1	
12	32104-99J00	.MAGNETO SET	1	
13	32102-99J00	..FLYWHEEL, MAGNETO	1	
14	32120-99J00	..COIL, STATOR & PULSER	1	
15	09125-06035	..SCREW (6X25)	3	
16	32801-99J00	.RECTIFIER/REGULATOR SET	1	
17	32800-99J00	..RECTIFIER/REGULATOR ASSY	1	
18	01550-06257	..BOLT	2	
19	32900-99J00	.UNIT, CDI	1	
20	33800-99J01	.CABLE SET, STARTING	1	
21	33810-99J00	..CABLE, STARTER	1	
22	36655-99J00	..PLATE, CABLE GROMMET	1	
23	36656-99J20	..GROMMET, CABLE (PORT)	1	
24	37161-89E13	..SWITCH ASSY, STARTER	1	
25	37721-99J10	..SWITCH ASSY, NEUTRAL	1	
26	37724-99J00	..ROD, SWITCH PUSH	1	
27	37726-99J10	..BRACKET, NEUTRAL SW	1	
28	09137-04004	..SCREW (4X16)	2	
29	09159-14032	..NUT	1	
30	36610-99J00	.HARNESS ASSY, WIRING	1	
31	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
32	09481-20501	..FUSE (20A)	1	
33	09407-14403	.CLAMP (L:125)	2	
34	09407-14407	.CLAMP (L:145)	4	

FIG.583A




FIG.583A (1-I-4) OPT:FUEL TANK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65000-95D01	TANK ASSY, FUEL (25L)	1	
2	65520-95D01	.CAP, FUEL TANK	1	
3	65561-95D00	.GASKET, TANK CAP	1	
4	65740-95D01	.PLUG, FUEL CONNECTOR	1	
5	65831-95D00	.FILTER, OUTLET	1	
6	65890-95D00	.OUTLET ASSY	1	
7	65892-95D00	.O RING	1	
8	65700-87J15	HOSE, FUEL	1	
9	65750-87J11	.SOCKET, FUEL HOSE	1	
10	65750-95500	.SOCKET, FUEL HOSE	1	
11	65770-90J11	.PUMP, SQUEEZE	1	
12	65781-98500	.CLIP	4	

10000

PART NO.	FIG.NO.-REF.NO.
11110-99J00	111A-1
11115-09G00-001	111A-23
11118-99JL0	111A-3
11119-99JL0	111A-4
11141-99J00	111A-2
11170-99J00	111A-16
11173-99J00	111A-20
11178-99J00	111A-17
11196-99J00	111A-19
11197-99J00	162A-4
11216-90J00	111A-6
11261-93J00	111A-8
11291-91B50	162A-7
11301-99J10	113A-1
11382-93E00	111A-13
12100-99JL0-050	116A-10
12111-99JL0-0B0	116A-1
12140-99J00	116A-2
12151-99JL0	116A-3
12160-99JL0	116A-5
12163-99JL0	116A-6
12220-99JL0	116A-7
12341-99J00	116A-8
12625-99J00	120A-11-1
	120B-11
	120C-11-1
	120D-11
	561A-2
	561B-2
12625-99J10	120A-11-2
	120C-11-2
12631-99JM0	120A-1
	120B-1
	120C-1
	120D-1
12635-99J00	120A-2
	120B-2
	120C-2
	120D-2
12636-99J00	120A-3
	120B-3
	120C-3
	120D-3
12637-99J00	120A-4
	120B-4
	120C-4
	120D-4
12638-99J00	120A-5
	120B-5
	120C-5
	120D-5
12700-99JL0	121A-1-1
	121C-1-1
12711-99JM0	121A-1-2
	121B-1
	121C-1-2
	121D-1
12741-99JL0	120A-6
	120B-6
	120C-6
	120D-6
12761-99J00	120A-16
	120B-15
	120C-16
	120D-15
12764-99J00	120A-17
	120B-16
	120C-17
	120D-16
12840-99J00	121A-3
	121B-3
	121C-3
	121D-3
12842-49201	121A-4
	121B-4
	121C-4
	121D-4
12843-27A00	121A-5
	121B-5
	121C-5
	121D-5
12843-99J00	121A-6
	121B-6
	121C-6
	121D-6
12861-99JL0	121A-7
	121B-7
	121C-7
	121D-7
12891-99J00	121A-8
	121B-8
	121C-8
	121D-8
12911-99J00	121A-10
	121B-10
	121C-10
	121D-10
12915-99J00	121A-11
	121B-11
	121C-11
	121D-11
12921-99J00	121A-12
	121B-12
	121C-12
	121D-12
12931-09420	121A-13
	121B-13
	121C-13
	121D-13
12932-09G00	121A-14
	121B-14
	121C-14
	121D-14
12933-71C00	121A-15
	121B-15
	121C-15
	121D-15
13111-99J00	126A-1
13119-99J00	126A-2
13124-99J00	128A-32
	128B-26
	128C-39
	128D-33
13125-99J00	128A-31
	128B-25
	128C-38
	128D-32
13200-99J00	128A-1-1
13200-99J10	128A-1-2
	128B-1
13200-99J20	128C-1-1
13200-99J30	128C-1-2
	128D-1
13236-99J00	128A-2
	128B-2
13236-99J20	128C-2
	128D-2
13239-94J00	128A-5
	128B-5
	128C-5
	128D-5
13240-99J00	128A-14-1
13240-99J10	128A-14-2
	128D-14
13240-99J20	128C-14-1
13240-99J30	128C-14-2
	128D-14
13247-94J00	128A-8
	128B-8
	128C-8
	128D-8
13250-99J00	128A-6
	128B-6
	128C-6
	128D-6
13251-99J00	128A-15
	128B-15
	128C-15
	128D-15
13254-94J00	128A-10
	128B-10
	128C-10
	128D-10
13268-94J00	128A-13
	128B-13
	128C-13
	128D-13
13275-99J00	128A-17
	128B-17
	128C-17
	128D-17
13279-99J00	128A-16
	128B-16
	128C-16
	128D-16
13281-99J00	128A-29
	128B-23
	128C-36
	128D-30
13282-99J00	128A-19
	128B-19
	128C-22
	128D-22
13283-99J00	128A-18
	128B-18
	128C-21
	128D-21
13295-14G00	128A-26
	128C-29
13361-99J00	128A-21
	128C-24
13362-94J00	128A-22
	128C-25
13363-94J00	128A-23
	128C-26
13364-94J00	128A-24
	128C-27
13365-94J00	128A-25
	128C-28
13367-94J00	128A-20
	128C-8
	128D-8
	128A-27
	128B-20
	128B-21
	128C-23
	128C-31
	128D-23
	128D-25
13368-99J00	128A-28
	128B-22
	128C-32
	128D-26
13370-94J00	128A-7
	128B-7
	128C-7
	128D-7
13375-26E00	128A-9
	128B-9
	128C-9
	128D-9
13428-06F30	128C-30
	128D-24
13436-91J00	128A-33
	128B-27
	128C-40
	128D-34
13441-99J00	128C-18
	128D-18
13443-99J00	128C-19
	128D-19
13493-99J00	128C-20
	128D-20
13494-94J00	128C-33
	128D-27
13495-94J00	128C-34
	128D-28
13496-99J00	128C-35
	128D-29
13513-99J00	128A-34
	128B-28
	128C-41
	128D-35
13534-94J00	128A-12
	128B-12
	128C-12
	128D-12
13640-99JL0	128A-35
	128C-42
13710-99J00	126A-6
13802-94J00	128A-11
	128B-11
	128C-11
	128D-11
13810-99J00	126A-5
13832-94J00	126A-8
15100-94J02	146A-10
15131-99J00	146A-13
15170-94J02	146A-11
15191-99J11	146A-6
15192-99JL0	146A-4
15193-99JL0	146A-5
15251-93E00	146A-12
15410-98500	146A-1
16400-99JL0	150A-1
16440-11D00	113A-4
16510-45H10	150A-5
16512-99J00	150A-6
16515-99J10	401A-6
16520-99J00	401A-18
16542-99J00	150A-2
16910-99J00	150A-12
16930-99JL0	150A-13
17400-99J01	160A-19
17411-94J00	160A-1
17413-94J00	160A-2
17461-939M0	160A-3
17471-99J00	160A-4
17472-99J00	160A-5
17473-94J00	160A-6
17561-99J00	160A-7-1
17561-99J10	160A-7-2
17563-94J00	160A-8
17564-99J00	160A-9
17565-99J00	160A-18
17631-99J20	160A-10
17632-99J30	160A-11
17670-94J00	162A-1
17681-99J10	162A-2
17913-93J00	405A-1
17914-93J00	405A-2
17917-87LL0	410A-34
	410B-32
	410C-34
	410D-32
18100-99J00	167A-1
18120-99J00	167A-2

PART NO.	FIG.NO.-REF.NO.
18130-99J00	167A-3
18142-98600	167A-4
18181-99J00	167A-5
18193-99J00	167A-9
18210-99J00	167A-6
18280-99J00	167A-7
18290-99J02	167A-11
18498-99J00	146A-16
19120-99J00	166A-1
	166C-1
19120-99J11	166B-1
	166D-1
	513A-2
	513B-2
19122-99J00	166B-2
	166D-2
	513A-3
	513B-3
19131-95502	166A-2
	166C-2
19148-99J00	166A-3
	166C-3
19148-99J10	166B-3
	166D-3
19184-99J00	166A-4
	166C-4
19184-99J10	166B-4
	166D-4
	513A-4
	513B-4
19185-99J00	166B-5
	166D-5
	513A-5
	513B-5
19656-99J00	166A-5
	166C-5
19810-99J00	166A-6
	166C-6
20000	
21111-89L00	206A-15
	206C-15
21122-99J00	206B-1
	206D-1
21122-99J10	206A-1
21126-99J00	206A-7
	206B-7
	206C-7
	206D-7
21131-94J00	444A-32
	444B-32
21210-99J00	206A-9
	206B-9
	206C-9
	206D-9
21241-99J00	206B-13
	206D-13
	513A-6
	513B-6
22511-99011	336A-1
	336B-1
	336C-1
	336D-1
23111-99J00	206A-10-1
	206B-10-1
	206C-10-1
	206D-10-1
23111-99J10	206A-10-2
	206B-10-2
	206C-10-2
	206D-10-2
23115-99J00	206A-14
	206C-14
23115-99J10	206A-16
	206C-16
23131-99J00	206A-11
	206B-11
	206C-11
	206D-11
23210-99J00	206B-14
	206D-14
	513A-7
	513B-7
23210-99J11	206A-18
	206C-18
23311-95J00	210A-1
23312-94JL0	206A-19
	206C-19
25111-99J01	210A-2
25211-99JL0	210A-5
25215-99J00	210A-6
25311-99J00	210A-3
29141-93J00	160A-13
	206A-17
29162-93J00	407A-26
29404-93J10	553A-5
	553B-5
29440-93J00	336A-20
	336B-24
	336C-20
	336D-24
30000	
31000-99J01	561A-1
	561B-1
31100-94J22	301A-1
	561A-4
	561B-4
31101-99J00	561A-3
	561B-3
31131-94J00	301A-2
31135-90J00	301A-3
31151-94J01	301A-4
31152-90J00	301A-5
31153-90J00	301A-6
31170-94J00	301A-17
31171-96J00	301A-7
31173-94J01	301A-8
31191-96J00	301A-9
31220-94J00	301A-10
31310-90J00	301A-11
31320-94J00	301A-12
31341-94J00	301A-13
31343-90J00	301A-14
31344-90J00	301A-15
31360-93J01	301A-16
31912-99J00	301A-18
	561A-5
31918-94J00	301A-19
	561A-6
	561B-6
32000-99J00	553A-1

PART NO.	FIG.NO.-REF.NO.
	553B-1
32102-99J00	303A-6-1
	303B-4
	303C-6-1
	303D-4
	561A-13
	561B-13
32102-99J10	303A-6-2
	303C-6-2
32104-99J00	561A-12
	561B-12
32120-99J00	303A-1
	303B-1
	303C-1
	303D-1
	561A-14
	561B-14
32120-99J10	303A-3
	303C-3
32140-99J10	303A-4
	303C-4
32800-95J01	553A-3
	553B-3
32800-99J00	310A-1
	310B-1
	310C-1
	310D-1
	561A-17
	561B-17
32801-95J01	553A-2
	553B-2
32801-99J00	561A-16
	561B-16
32890-99J00	310A-3
	310B-3
	310C-3
	310D-3
32900-99J00	310A-8-1
	310B-8
	310C-8-1
	310D-8
	561A-19
	561B-19
32900-99J10	310A-8-2
	310C-8-2
32980-99J00	310A-9
	310B-9
	310C-9
	310D-9
33410-99J00	310A-11
33500-07H00	310A-10
	310B-10
	310C-10
	310D-10
33800-99J01	561A-20
	561B-20
33810-99J00	322A-1
	322B-1
	322C-1
	322D-1
	561A-21
	561B-21
33816-94J01	553A-10
	553B-10
33833-91J00	444A-20
	444B-20
33833-94J10	310A-14
	310B-14
	310C-14
	310D-14
33833-94JL0	310A-13
	310B-13
	310C-13
	310D-13
33833-99J00	334A-11
	334B-9
	334C-11
	334D-9
33833-99J10	322A-11
	322B-9
	322C-11
	322D-9
34200-93J20	501A-1-1
	501B-1-1
34200-93J32	501A-1-2
	501B-1-2
34830-87J20	334A-1
	334B-1
	334C-1
	334D-1
36360-99J00	334A-3
	334C-3
36360-99J10	334B-3
	334D-3
	513A-15
	513B-15
36367-99J00	334A-4
36610-99J00	322A-3-1
	322C-3-1
	561A-30
	561B-30
36610-99J10	322A-3-2
	322C-3-2
36610-99J20	322B-2
	322D-2
	513A-16
	513B-16
36615-96300	322A-6-1
	322A-6-2
	322C-6-1
	322C-6-2
	553A-4
	553B-4
36617-93J10	410A-33
	410B-31
	410C-33
	410D-31
36618-43410	322A-5
	322B-4
	322C-5
	322D-4
	513A-18
	513B-18
	561A-31
	561B-31
36620-94J01	450A-52
	450B-52
	515A-2
	515C-2
36628-92E00	450A-2
	450B-2
36634-93910	553A-14
	553B-14
36655-99J00	561A-22
	561B-22
36656-99J00	322A-7
	322C-7
36656-99J10	322B-5
	322D-5
	513A-19
	513B-19
36656-99J20	561A-23
	561B-23
36740-94J00	553A-11

PART NO.	FIG.NO.-REF.NO.
	553B-11
36890-93J00	544A-16
36990-87D00	501A-3
	501B-3
	515A-4
	515C-4
	553A-21
	553B-21
37110-94J02	450A-3
	450B-3
37141-99E00	450A-4-1
	450B-4-1
37141-99E10	450A-4-2
	450B-4-2
37141-99E20	450A-4-3
	450B-4-3
37141-99E30	450A-4-4
	450B-4-4
37141-99E40	450A-4-5
	450B-4-5
37141-99E50	450A-4-6
	450B-4-6
37141-99E60	450A-4-7
	450B-4-7
37141-99E70	450A-4-8
	450B-4-8
37141-99E80	450A-4-9
	450B-4-9
37141-99E90	450A-4-10
	450B-4-10
37141-99EA0	450A-4-11
	450B-4-11
37141-99EB0	450A-4-12
	450B-4-12
37143-99E00	450A-5
	450B-5
37149-93J00	450A-6
	450B-6
37161-89E13	334A-5
	334C-5
	561A-24
	561B-24
37721-95500	545A-11
37721-99J10	334A-7
	334B-5
	334C-7
	334D-5
	561A-25
	561B-25
37724-99J00	334A-8
	334B-6
	334C-8
	334D-6
	561A-26
	561B-26
	167A-13
37726-99J01	334A-9
37726-99J10	334B-7
	334C-9
	334D-7
	561A-27
	561B-27
37801-98300	553A-12
	553B-12
37820-93E10	334A-2
	334B-2
	334C-2
	334D-2
37820-93J04	450A-7
	450B-7
37823-92E01	450A-8
	450B-8
37823-97J00	444A-29
	444B-29
37826-92J00	450A-9
	450B-9
37826-97J00	444A-30
	444B-30
37830-99J10	444A-28
	444B-28
37835-95D00	444A-31
	444B-31
37850-93J10	544A-4
37859-90J00	450A-10
	450B-10
37864-94J10	450A-11
	450B-11
38500-93J00	450A-12
	450B-12
38860-76F01	301A-20
	561A-7
	561B-7
38915-90J00	301A-21
	561A-8
	561B-8
39600-94J01	553A-9
	553B-9
39601-95D00	553A-13
	553B-13
39602-93900	553A-15
	553B-15
39603-94400	553A-16
	553B-16

40000

PART NO.	FIG.NO.-REF.NO.
41111-94J20-0EP	335B-1
	335D-1
41111-99J00-0EP	335A-1
	335C-1
41121-94J20-0EP	335B-2
	335D-2
41121-99J00-0EP	335A-2
	335C-2
41130-93E03	335B-7
	335D-7
41161-94400	442A-1
	442B-1
41210-99JL1	335A-21
	335B-20
	335C-21
	335D-20
41211-99JL0	335A-3
	335B-3
	335C-3
	335D-3
41212-91J00	335A-4
	335B-4
	335C-4
	335D-4
41213-94J01	335A-5
	335B-5
	335C-5
	335D-5
41225-89L00	336A-8
	336B-12
	336C-8
	336D-12
43111-99J40-0EP	336A-2-1
	336C-2-1
43111-99J50-0EP	336A-2-2
	336C-2-2
43111-99J60-0EP	336B-2-1
	336D-2-1
43111-99J70-0EP	336B-2-2
	336D-2-2
43211-87JL0	336B-7
	336D-7
43211-99J00	336A-7
	336C-7
43410-99J00	336A-23
	336C-23
43411-939L0	336A-18
	336B-22
	336C-18
	336D-22
43412-93900	336A-19
	336B-23
	336C-19
	336D-23
43412-99J00	336A-24
	336C-24
43415-99J00	336A-25
	336C-25
43420-99J10	336A-26
	336C-26
43424-99J00	336A-27
	336C-27
43427-99J00	336A-28
	336C-28
43428-99J00	336A-29
	336C-29
43512-99J00	336A-30
	336C-30
43514-94J00	336A-31
	336C-31
43514-99J00	336A-32
	336C-32
43516-89J00	336A-33
	336C-33
43711-99J00	336A-3
	336B-3
	336C-3
	336D-3
43750-99J60-0EP	336A-4-1
	336B-4-1
	336C-4-1
	336D-4-1
43750-99J70-0EP	336A-4-2
	336B-4-2
	336C-4-2
	336D-4-2
43755-99J00	336B-8
	336D-8
	513A-11
	513B-11
45212-95L00	336A-9
	336B-13
	336C-9
	336D-13
45231-89L00	336A-10
	336B-14
	336C-10
	336D-14
45241-89L00	336A-11
	336B-15
	336C-11
	336D-15
45247-99J00	336A-13
	336B-17
	336C-13
	336D-17
45250-89L03	336A-14
	336B-18
	336C-14
	336D-18
45261-94J00	335A-14
	335B-13
	335C-14
	335D-13
45269-94J20	335A-19
	335B-18
45269-99J00	336A-40
	336C-40
45420-99JM0	335A-16
	335B-15
	335C-16
	335D-15
45425-94J01	335A-17
	335B-16
	335C-17
	335D-16
45710-99JL0	336A-37
	336B-27
	336C-37
	336D-27
45722-94J11	336A-38
	336B-28
	336C-38
	336D-28
51110-99J00	401A-1
51211-99J00	401A-2
52110-99J00-0EP	405A-3-1
52110-99J10-0EP	405A-3-2
52113-99J00	405A-4
54112-99J01	401A-8
54113-99JM0	401A-9
54120-99JL0	401A-10
54122-99J00	401A-11
54125-99J00	401A-12
54126-99JL0	401A-13
54130-99J00	401A-14
54148-99J00	401A-15
54151-99J00	405A-12
54167-99J01	405A-13
54211-99J01-0EP	405A-14
54213-93901	405A-16
54221-99J01-0EP	405A-15
55100-99J40-0EP	407A-1
55300-95500	407A-23
55321-87J00	111A-10
	407A-6
55321-87J10	407A-27
55331-99J10	407A-21
55332-99J10	407A-22
56120-99J40-0EP	407A-10
56130-99J30	220A-21
56132-99J10	220A-23
57100-99JN0	220A-1-1
57100-99JP0	220A-1-2
57135-99J00	405A-5
57311-99J10	220A-8
57510-99J10	220A-9
57521-99J10	220A-10
57610-99JL0	220A-14
57621-99J11	220A-15
57631-93901	220A-19
57632-94J00	407A-17
57632-98501	220A-20
58100-89L00-019	407A-15-1
58100-89L20-019	407A-15-2
58100-89L30-019	407A-15-3
58100-89L40-019	407A-15-4
58100-90L40-019	407A-15-5
58100-90L50-019	407A-15-6

50000

PART NO.	FIG.NO.-REF.NO.
58100-90L60-019	407A-15-7
58120-89L00	407A-16
59178-97J00	407A-8
59441-94J00	220A-17
59441-99J00	220A-18
59800-99J01	420A-9
	420B-9
	420C-9
	420D-9
60000	
61112-99J00	410A-5
	410B-5
	410C-5
	410D-5
61124-99J10	410B-28
	410D-28
	513A-22
	513B-22
61124-99J21	410A-28
	410C-28
61134-99JL0	410A-6
	410B-6
	410C-6
	410D-6
61151-99J00	410A-29
	410B-29
	410C-29
	410D-29
61155-94500	410A-2
	410B-2
	410C-2
	410D-2
61157-99J00	410A-7
	410B-7
	410C-7
	410D-7
61400-99J01-0EP	420A-1
	420B-1
	420C-1
	420D-1
61412-99J00	410A-18
	410B-18
	410C-18
	410D-18
61433-99J00	420A-2
	420B-2
	420C-2
	420D-2
61435-99J00	420A-7
	420B-7
61435-99J10	420C-7
	420D-7
61443-99J00	420A-4
	420B-4
	420C-4
	420D-4
61453-99J00	420A-5
	420B-5
	420C-5
	420D-5
61458-89L00	420A-8
	420B-8
	420C-8
	420D-8
61472-94J10	167A-16
61493-99J00	120A-19
	120B-18
	120C-19
	120D-18
61494-99J00	120A-20
	120B-19
	120C-20
	120D-19
61610-90L00	410A-21
	410B-21
	410C-21
	410D-21
61616-93EL0	410A-22
	410B-22
	410C-22
	410D-22
61642-99J00	410A-23
	410B-23
	410C-23
	410D-23
61643-99J00	410A-19
	410B-19
	410C-19
	410D-19
61810-99J02-0EP	410A-1
	410B-1
	410C-1
	410D-1
61813-99J01	410A-32
	410B-30
	410C-32
	410D-30
61820-99J01-0EP	410A-3
	410B-3
	410C-3
	410D-3
61827-99J00	410A-30
	410C-30
61831-99J00-0EP	410A-12
	410B-12
	410C-12
61851-93E10	410A-10
	410B-10
	410C-10
	410D-10
63111-89L00-0EP	444A-1
	444B-1
63114-99J01	444A-21
	444B-21
63115-99J00	444A-3
	444B-3
63115-99J10	444A-2
	444B-2
63116-99J00	444A-4
	444B-4
63121-99J00-0EP	444A-5
	444B-5
63122-99J00	444A-22
	444B-22
63131-99J11-0EP	444A-23
	444B-23
63133-89L00	444A-24
	444B-24
63210-89L10	444A-6
	444B-6
63215-93110	444A-27
	444B-27
63220-94J00	444A-7
	444B-7
63225-93200	444A-9
	444B-9
63225-94J00	444A-8
	444B-8
63240-94J10	444A-10
	444B-10
63241-986B0	444A-11
	444B-11
63244-94J00	444A-12
	444B-12
63610-99J00	444A-14
	444B-14
65000-89L10	432A-1
65000-95D01	583A-1
65520-95D01	583A-2
65520-99100	432A-2
65561-95D00	432A-3
	583A-3
65700-87J15	583A-8
65700-89L30	432A-8
65720-986L0	432A-13
65740-95D01	432A-7
	583A-4
65750-87J11	583A-9
65750-87JL0	432A-9
65750-95500	583A-10
65750-955L0	432A-10
65770-89L00	432A-11
65770-90J11	583A-11
65781-98500	432A-12
	583A-12
65831-95D00	432A-4
	583A-5
65890-95D00	583A-6
65890-99100	432A-5
65892-95D00	432A-6
	583A-7
67130-99J01	513A-1
	513B-1
67200-93J13	544A-1
	545A-1
67200-94J20	450A-1
	450B-1
67211-93J00	544A-27
67212-95600	450A-13
	450B-13
67214-92E00	450A-14
	450B-14
67220-95630	450A-15
	450B-15
67221-92E00	545A-8
67222-92E00	545A-2
67223-92E00	545A-3
67223-99E10	450A-16
	450B-16
67224-92E00	545A-9
67226-92E00	545A-15
67226-92E10	545A-16
67227-92E00	545A-24
67228-92E00	545A-18
67229-95600	450A-17
	450B-17
67230-92E00	545A-20
67231-92E00	545A-41
67232-95600	450A-18
	450B-18
	545A-42
67232-95620	545A-28
67233-92E00	545A-26
67234-92E00	545A-22
67235-92E00	545A-27
67236-92E00	545A-32
67237-92E01	545A-33
67238-87D00	450A-19
	450B-19
67238-92E00	545A-34
67239-92E00	545A-35
67239-92E10	545A-45
67240-92E00	545A-17
67241-92E10	545A-43
67241-99E10	450A-20
	450B-20
67243-92E00	545A-44
67243-95600	450A-21
	450B-21
67244-95600	450A-22
	450B-22
67245-92E00	545A-23
67245-95600	450A-23
	450B-23
67246-92E00	545A-36
67251-93J00	544A-12
67251-99E20	450A-24
	450B-24
67252-92E10	545A-39
67252-95600	450A-25
	450B-25
67253-92E00	544A-15
67253-92E10	545A-38
67253-95600	450A-26
	450B-26
	545A-40
67255-99E10	450A-27
	450B-27
67256-95600	450A-28
	450B-28
67257-92E00	544A-11
67257-99E10	450A-29
	450B-29
67258-99E00	450A-30
	450B-30
67259-87D00	450A-31
	450B-31
67261-93J00	544A-2
67261-99E10	450A-32
	450B-32
67263-93J00	544A-3
67264-95600	450A-34
	450B-34
67267-93J00	450A-35
	450B-35
67269-92E00	545A-29
67271-92E00	544A-26
67273-92E00	544A-23
67273-95600	450A-36
	450B-36
	544A-22
67274-92E00	544A-24
67275-95600	450A-37
	450B-37
	544A-21
67281-93J00	544A-17
67282-94L00	450A-38
	450B-38
67284-94L00	450A-39
	450B-39
67286-92E00	545A-19
67287-92E00	544A-20
67288-92E00	545A-4
67288-92E10	545A-6
67288-92E20	544A-7
67288-92E30	544A-14
67288-92E40	544A-10
67291-92E00	545A-7
67291-92E10	545A-37
67292-94300	450A-40
	450B-40
	545A-5
67294-92E00	545A-10
67294-95600	450A-41
	450B-41
67295-92E00	544A-8
67295-92E10	544A-5
67296-88D10	544A-6
	545A-13
	545A-30
67296-90J00	450A-42
	450B-42
67296-92E11	545A-12
67296-92E20	545A-14

PART NO.	FIG.NO.-REF.NO.
67296-92E30	544A-18
67296-92E60	544A-13
67296-92E70	544A-9
	544A-28
67296-94300	450A-43
	450B-43
67296-94310	450A-33
	450B-33
67296-95600	450A-44
	450B-44
67296-95610	450A-45
	450B-45
	544A-25
67297-95600	450A-46
	450B-46
67320-93J00	515A-1-1
	515B-1-1
	515C-1-1
	515D-1-1
67320-93J10	515A-1-2
	515B-1-2
	515C-1-2
	515D-1-2
67320-93J20	515A-1-3
	515B-1-3
	515C-1-3
	515D-1-3
67320-93J30	515A-1-4
	515B-1-4
	515C-1-4
	515D-1-4
67320-93J40	515A-1-5
	515B-1-5
	515C-1-5
	515D-1-5
67320-93J50	515A-1-6
	515B-1-6
	515C-1-6
	515D-1-6
67320-93J60	515A-1-7
	515B-1-7
	515C-1-7
	515D-1-7
67320-93J70	515A-1-8
	515B-1-8
	515C-1-8
	515D-1-8
67320-93J80	515A-1-9
	515B-1-9
	515C-1-9

PART NO.	FIG.NO.-REF.NO.
	515D-1-9
67340-99J00	454A-4
	454B-4
	513A-26
	513B-26
67467-89J01	454A-1
	454B-1
	513A-23
	513B-23
67500-93J00	544A-29
67701-99J02	442A-2
	442B-2
67721-93E10	442A-3
	442B-3
67725-96J00	442A-4
	442B-4
67726-99E00	442A-5
	442B-5
67728-99E00	442A-6
	442B-6
68110-89L00	420A-11
	420B-11
	420C-11
	420D-11
68111-99J00	420A-6
	420B-6
	420C-6
	420D-6
69711-93E10	167A-15
69911-91J40	335A-20
	335B-19
	335C-20
	335D-19
70000	
77811-54GB0-0PG	450A-47
	450B-47
90000	

PART NO.	FIG.NO.-REF.NO.
99000-81158-50M	167A-8
99011-99J40-055	420A-10
	420B-10
	420C-10
	420D-10
00000	
01550-05127	303A-5
	303B-3
	303C-5
	303D-3
01550-06127	113A-6
	120A-15
	120C-15
	146A-15
	150A-11
01550-0612A	111A-21
01550-06167	126A-10
	166A-13
	166B-8
	166C-13
	166D-8
	167A-14
	206A-8
	206A-13
	206B-8
	206C-8
	206C-13
	206D-8
	301A-22
	454A-5
	454B-5
	513A-27
	513B-27
	561A-9
	561B-9
01550-06207	111A-18
	150A-10
	206A-20
	206C-20
01550-06257	111A-5
	146A-2
	310A-2
	310A-7
	310A-12
	310B-2
	310B-7

PART NO.	FIG.NO.-REF.NO.
	310B-12
	310C-2
	310C-7
	310C-12
	310D-2
	310D-7
	310D-12
	553A-8
	553B-8
	561A-18
	561B-18
01550-06307	120A-13
	120B-13
	120C-13
	120D-13
	166A-14
	166C-14
	167A-10
01550-06357	150A-4
	166A-15
	166B-9
	166C-15
	166D-9
01550-08207	111A-12
	162A-8
01550-08257	301A-23
	561A-10
	561B-10
01550-08307	120A-14
	120B-14
	120C-14
	120D-14
	162A-3
01560-06457	126A-3
01560-08557	113A-2
02112-06127	206A-6
	206B-6
	206C-6
	206D-6
02112-06307	303A-12
	303C-12
02142-06167	410A-17
	410A-31
	410B-17
	410C-17
	410C-31
	410D-17
03141-0416A	160A-12
03241-0625A	553A-20
	553B-20

PART NO.	FIG.NO.-REF.NO.
03542-05169	410A-11
	410B-11
	410C-11
	410D-11
	420A-3
	420B-3
	420C-3
	420D-3
03542-06129	167A-12
04211-09109	111A-15
	113A-3
04211-09149	120A-12
	120B-12
	120C-12
	120D-12
04221-05109	126A-4
08110-60020	220A-2
08110-60050	407A-11
08310-00067	410A-27
	410B-27
	410C-27
	410D-27
08316-10087	301A-24
	561A-11
	561B-11
08341-31039	120A-9
	120A-10
	120B-9
	120B-10
	120C-9
	120C-10
	120D-9
	120D-10
	303A-9
	303B-7
	303C-9
	303D-7
09100-06177	335A-10
	335B-9
	335C-10
	335D-9
09100-08232	336A-22
	336B-26
	336C-22
	336D-26
	450A-48
	450B-48
09100-08312	405A-6
09100-10320	335A-7
	335C-7

PART NO.	FIG.NO.-REF.NO.
09103-06237	432A-14
09103-06267	120A-7
	120B-7
	120C-7
	120D-7
09103-06276	128A-30
	128B-24
	128C-37
	128D-31
09103-06281	111A-11
	407A-7
09108-06141	160A-14
09108-08286	336B-9
	336D-9
	513A-12
	513B-12
09111-10067	336A-39
	336B-29
	336C-39
	336D-29
09116-06223	410A-26
	410B-26
	410C-26
	410D-26
09116-06225	336A-34
	336C-34
09116-06227	407A-14
09116-06229	220A-24
	336A-35
	336C-35
09116-06230	410A-13
	410B-13
	410C-13
	410D-13
09116-06234	206A-21
	206C-21
09116-08137	401A-16
09116-08151	401A-3
	405A-7
	407A-5
	444A-15
	444B-15
09116-08154	405A-17
09116-08155	444A-25
	444B-25
09125-05042	444A-26
	444B-26
	545A-21
09125-05135	544A-30
09125-06035	303A-2

PART NO.	FIG.NO.-REF.NO.
	303B-2
	303C-2
	303D-2
	561A-15
	561B-15
09126-05003	450A-49
	450B-49
09126-06006	407A-24
	545A-25
09126-06015	444A-16
	444B-16
09136-05041	444A-17
	444B-17
09136-06169	410A-4
	410B-4
	410C-4
	410D-4
09137-04004	334A-10
	334B-8
	334C-10
	334D-8
	561A-28
	561B-28
09140-05005	166A-7
	166C-7
	544A-32
09140-06020	450A-50
	450B-50
	545A-31
09140-10031	401A-17
09140-14008	303A-7
	303B-5
	303C-7
	303D-5
09141-12005	407A-18
09148-06008	444A-13
	444B-13
09148-06017	410A-16
	410B-16
	410C-16
	410D-16
09159-08059	336A-36
	336B-10
	336C-36
	336D-10
	513A-13
	513B-13
09159-10050	335A-8
	335C-8
09159-14032	128A-36
	128C-43
	334A-6
	334C-6
	561A-29
	561B-29
09159-22006	335B-8
	335D-8
09160-05024	544A-19
09160-05029	206B-16
	206D-16
	410A-20
	410B-20
	410C-20
	410D-20
	513A-9
	513B-9
	544A-31
09160-06046	166A-8
	166A-9
	166B-6
	166C-8
	166C-9
	166D-6
	206A-22
	206C-22
09160-06055	454A-2
	454B-2
	513A-24
	513B-24
09160-06082	160A-15
	206A-2
	206B-2
	206C-2
	206D-2
	210A-8
	335A-11
	335B-10
	335C-11
	335D-10
	336A-16
	336B-20
	336C-16
	336D-20
09160-06084	310A-4
	310B-4
	310C-4
	310D-4
09160-06085	432A-15
09160-06104	450A-51
	450B-51
09160-06168	206A-23
	206C-23
09160-06171	120A-8
	120B-8
	120C-8
	120D-8
09160-08082	336A-21
	336B-11
	336B-25
	336C-21
	336D-11
	336D-25
	405A-8
	513A-14
	513B-14
09160-10082	335A-9
	335C-9
09160-12066	407A-19
09160-15057	303A-8
	303B-6
	303C-8
	303D-6
09160-17024	220A-11-1
09160-17025	220A-11-3
09160-17026	220A-11-5
09160-17027	220A-11-7
09160-17028	220A-11-9
09160-17039	220A-11-2
09160-17040	220A-11-4
09160-17041	220A-11-6
09160-17042	220A-11-8
09160-20027	220A-4
09160-20042	220A-5-2
09160-20043	220A-5-3
09160-20044	220A-5-4
09160-21009	220A-6
09160-25040	220A-12-4
09160-25041	220A-12-5
09160-25042	220A-12-6
09160-27012	336A-5
	336A-41
	336B-5
	336B-30
	336C-5
	336C-41
	336D-5
	336D-30
09161-04012	410A-24
	410B-24
	410C-24

PART NO.	FIG.NO.-REF.NO.
	410D-24
09163-06001	444A-18
	444B-18
09164-13008	121A-9
	121B-9
	121C-9
	121D-9
09164-14008	206A-24
	206C-24
09168-12017	405A-10
09169-06062	310A-5
	310B-5
	310C-5
	310D-5
09169-06075	410A-14
	410B-14
	410C-14
	410D-14
09169-06082	126A-9
09180-06186	166A-10
	166B-7
	166C-10
	166D-7
	206A-25
	206C-25
09180-06230	166A-11
	166C-11
09180-06290	126A-7
09180-06357	335A-12
	335B-11
	335C-12
	335D-11
09180-06370	206A-26
	206C-26
09180-12158	166A-12
	166C-12
09181-15241	220A-13
09181-20244	220A-5-5
09181-20246	220A-5-6
09181-20248	220A-5-7
09181-20251	220A-5-1
09181-25160	220A-12-1
09181-25162	220A-12-2
09181-25164	220A-12-3
09181-25181	220A-12-7
09200-05014	336A-17
	336B-21
	336C-17
	336D-21
09200-06061	336A-15
	336B-19
	336C-15
	336D-19
09202-04008	160A-17
09202-04025	220A-16
09202-06023	401A-4
	405A-9
	407A-4
09204-01002	206B-15
	206D-15
	336A-12
	336B-16
	336C-12
	336D-16
	513A-8
	513B-8
09204-02004	407A-20
09205-02004	210A-4
09205-06021	335A-6
	335B-6
	335C-6
	335D-6
09248-08001	407A-9
09248-12009	405A-11
09248-22002	111A-7
09260-10006	206A-3
	206B-3
	206C-3
	206D-3
09261-03009	150A-3
09262-25003	407A-3
09263-17L03	407A-2
09263-20L04	220A-7
09280-06012	210A-9
09280-09012	210A-10
09280-10016	150A-14
09280-13004	150A-7
09280-17003	111A-14
09280-22019	111A-9
09280-26005	146A-3
09280-54001	150A-8
09280-57002	407A-12
09282-12017	401A-5
09282-13L01	220A-22
09282-27002	336A-6
	336B-6
	336C-6
	336D-6
09283-21009	121A-2
	121B-2
	121C-2
	121D-2
09283-30075	116A-9
09289-05008	121A-16
	121B-16
	121C-16
	121D-16
09289-06L02	210A-11
09289-17L02	407A-13
09306-10023	335A-15
	335C-15
09306-22006	335B-14
	335D-14
09308-08011	120A-18
	120B-17
	120C-18
	120D-17
09320-09016	310A-6
	310B-6
	310C-6
	310D-6
09320-09039	410A-15
	410B-15
	410C-15
	410D-15
09320-10501	128A-37
	128C-44
09380-15001	220A-3
09381-14001	116A-4
09381-14004	206A-4
	206B-4
	206C-4
	206D-4
09383-04002	206A-12
	206B-12
	206C-12
	206D-12
09385-04003	206B-17
	206D-17
	410A-25
	410B-25
	410C-25
	410D-25
	513A-10
	513B-10
09385-06012	454A-3
	454B-3
	513A-25
	513B-25
09401-08413	410A-8

PART NO.	FIG.NO.-REF.NO.
	410B-8
	410C-8
	410D-8
09401-09404	146A-7
09401-11422	146A-8
09401-12413	162A-5
	401A-7
09401-13424	401A-19
09403-12316	410A-9
	410B-9
	410C-9
	410D-9
09403-12406	113A-5
	146A-14
09403-13311	322A-8
	322B-6
	322C-8
	322D-6
09407-10404	553A-6
	553A-17
	553B-6
	553B-17
09407-14403	303A-11
	303C-11
	322A-2
	322A-9
	322B-7
	322C-2
	322C-9
	322D-7
	513A-20
	513B-20
	553A-19
	553B-19
	561A-33
	561B-33
09407-14407	303A-10
	303B-8
	303C-10
	303D-8
	310A-15
	310B-15
	310C-15
	310D-15
	322A-12
	322B-10
	322C-12
	322D-10
	334A-12
	334B-10
	334C-12
	334D-10
	513A-21
	513B-21
	561A-34
	561B-34
09407-25402	553A-18
	553B-18
09408-00024	553A-7
	553B-7
09408-00054	146A-9
09408-00173	162A-6
09408-00265	322A-10
	322B-8
	322C-10
	322D-8
09420-03009	160A-16
09440-07079	206A-5
	206B-5
	206C-5
	206D-5
09440-12027	444A-19
	444B-19
09440-18002	150A-9
09441-17001	335A-18
	335B-17
	335C-18
	335D-17
09471-12028	501A-2
	501B-2
09481-10501	450A-53
	450B-53
	515A-3
	515C-3
09481-20501	322A-4
	322B-3
	322C-4
	322D-3
	513A-17
	513B-17
	561A-32
	561B-32
09482-00528	111A-22
09491-68008	128A-3-2
	128B-3-2
09491-70020	128A-3-1
	128B-3-1
09491-80017	128C-3-2
	128D-3-2
09491-82013	128C-3-1
	128D-3-1
09492-35033	128A-4-2
	128B-4-2
	128C-4-2
	128D-4-2
09492-38011	128A-4-1
	128B-4-1
	128C-4-1
	128D-4-1

PART NO.	FIG.NO.-REF.NO.

PART NO.	FIG.NO.-REF.NO.

PART NO.	FIG.NO.-REF.NO.

SUZUKI **DF8A/9.9A** PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved
No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION
Technical Readiness Group, Quality Administration Department
300 Takatsuka, Minami, Hamamatsu, Japan

Reprint Prohibited

SUZUKI MOTOR CORPORATION

PRINTED IN JAPAN

9900B-45302