

SUZUKI

PARTS CATALOGUE

DF9. 9B/15A/20A

DF9.9B/BR

DF9.9BT

DF15A/AR

DF15ATH

DF20A/AR

DF20AT/ATH



OUTBOARD MOTOR

P01/P40

2014-9

1ST EDITION

PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF9.9B/15A/20A production start 2014.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E. NO.	: Engine number	OS	: Over size
F. NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	W/	: with
LH(PORT)	: Left hand side	S, L	: Transom type
RH(STBD)	: Right hand side	SUS	: Stainless steel
~123456	: Up to E. NO. 02002F-123456		
123456~	: From E. NO. 02002F-123456		

12 x 34 x 5.6..... Figures in the description column

| | | show the dimensions of parts.

ID OD T(or W, L)

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual.
When assembling, use "SUZUKI SERVICE MANUAL".

6. SPECIFICATION CODE

This catalogue contains the parts for the model designed for the following spec.:

spec. code :	DF9.9B : P1	DF9.9BR : P1
	DF15A : P1	DF15AR : P1
	DF20A : P1, P40	DF20AR : P1

7. MODEL NAME AND ENGINE NUMBER

MODEL	DESTINATION	TYPE	TRANSOM	ENGINE NO.
DF9.9B	P01	00995F	S, L, X	00995F-510001~
DF9.9BR	P01	00995F	S, L, X	00995F-510001~
DF9.9BT	P01	00995F	S, L, X	00995F-510001~
DF15A	P01	01504F	S, L, X	01504F-510001~
DF15AR	P01	01504F	S, L, X	01504F-510001~
DF15ATH	P01	01504F	S, L, X	01504F-510001~
DF20A	P01, P40	02002F	S, L, X	02002F-510001~
DF20AR	P01	02002F	S, L, X	02002F-510001~
DF20AT	P01	02002F	S, L, X	02002F-510001~
DF20ATH	P01	02002F	S, L, X	02002F-510001~

MILLIMETER → INCH CONVERSION CHART


	0	1	2	3	4	5	6	7	8	9
00	.000	.039	.079	.118	.157	.197	.236	.276	.315	.354
10	.394	.433	.472	.512	.551	.591	.630	.669	.709	.748
20	.787	.827	.866	.906	.945	.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.535
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.214	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.031	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

How to read

	0	1	2	3	4
00	...	...	...	...	...
10	...	...	...	...	...
20	...	...	...	0.906	...
30	...	...	...	...	...


23 millimeters equal 0.906 inch

FIG.111A




DC90A_P01_012_111A
TURBINE HEAD

FIG.113A




DC90A_P01_012_113A
TURBINE BODY

FIG.116A




DC90A_P01_012_116A
TURBINE BODY

FIG.120A




DC90A_P01_012_120A
TURBINE BODY

FIG.121A




DC90A_P01_012_121A
TURBINE BODY

FIG.121B




DC90A_P01_012_121B
TURBINE BODY

FIG.121C




DC90A_P01_012_121C
TURBINE BODY

FIG.121D




DC90A_P01_012_121D
TURBINE BODY

FIG. 121E




DC90A_P01_012_021E
CAMBOSWET

FIG. 121F




DC90A_P01_012_021F
CAMBOSWET

FIG. 121G




DC90A_P01_012_021G
CAMBOSWET

FIG. 121H




DC90A_P01_012_021H
CAMBOSWET

FIG. 121J




DC90A_P01_012_021J
CAMBOSWET

FIG. 121K




DC90A_P01_012_021K
CAMBOSWET

FIG. 121L




DC90A_P01_012_021L
CAMBOSWET

FIG. 126A




DC90A_P01_012_026A
PIELET MARVELLO

FIG. 126B




DC90A_P01_015_0262
PIELET MARKING

FIG. 126C




DC90A_P01_015_0262
PIELET MARKING

FIG. 126D




DC90A_P01_015_0262
PIELET MARKING

FIG. 126E




DC90A_P01_015_0262
PIELET MARKING

FIG. 126F




DC90A_P01_015_0262
PIELET MARKING

FIG. 126G




DC90A_P01_015_0262
PIELET MARKING

FIG. 126H




DC90A_P01_015_0262
PIELET MARKING

FIG. 126J




DC90A_P01_015_0262
PIELET MARKING

FIG.126K




DC904_P01_012_126K
PULST-MANIPULI

FIG.126L




DC904_P01_012_126L
PULST-MANIPULI

FIG.144A




DC904_P01_012_144A
PULST-MANIPULI

FIG.146A




DC904_P01_012_146A
PULST-MANIPULI

FIG.160A




DC904_P01_012_160A
WATER PUMP

FIG.160B




DC904_P01_012_160B
WATER PUMP

FIG.160C




DC904_P01_012_160C
WATER PUMP

FIG.160D




DC904_P01_012_160D
WATER PUMP

FIG. 160E




DC9M_P01_012_16E
WATER PUMP

FIG. 160F




DC9M_P01_012_16F
WATER PUMP

FIG. 160G




DC9M_P01_012_16G
WATER PUMP

FIG. 160H




DC9M_P01_012_16H
WATER PUMP

FIG. 160I




DC9M_P01_012_16I
WATER PUMP

FIG. 160K




DC9M_P01_012_16K
WATER PUMP

FIG. 160L




DC9M_P01_012_16L
WATER PUMP

FIG. 162A




DC9M_P01_012_16M
THERMOSTAT

FIG. 163A




DC60A_R11_015_163A
THROTTLE-320V

FIG. 163B




DC60A_R11_015_163B
THROTTLE-320V

FIG. 163C




DC60A_R11_015_163C
THROTTLE-320V

FIG. 163D




DC60A_R11_015_163D
THROTTLE-320V

FIG. 163E




DC60A_R11_015_163E
THROTTLE-320V

FIG. 163F




DC60A_R11_015_163F
THROTTLE-320V

FIG. 163G




DC60A_R11_015_163G
THROTTLE-320V

FIG. 163H




DC60A_R11_015_163H
THROTTLE-320V

FIG.163J




DC04A_P01_015_163J
TARGET/EE-320V

FIG.163K




DC04A_P01_015_163K
TARGET/EE-320V

FIG.163L




DC04A_P01_015_163L
TARGET/EE-320V

FIG.166A




DC04A_P01_015_166A
TARGET/EE-320V

FIG.166B




DC04A_P01_015_166B
TARGET/EE-320V

FIG.166C




DC04A_P01_015_166C
TARGET/EE-320V

FIG.166D




DC04A_P01_015_166D
TARGET/EE-320V

FIG.166E




DC04A_P01_015_166E
TARGET/EE-320V

FIG.167A




DC004_P01_032_167A
RECEIVE STARTER

FIG.167B




DC004_P01_032_167B
RECEIVE STARTER

FIG.167C




DC004_P01_032_167C
RECEIVE STARTER

FIG.167D




DC004_P01_032_167D
RECEIVE STARTER

FIG.167E




DC004_P01_032_167E
RECEIVE STARTER

FIG.167F




DC004_P01_032_167F
RECEIVE STARTER

FIG.167G




DC004_P01_032_167G
RECEIVE STARTER

FIG.167H




DC004_P01_032_167H
RECEIVE STARTER

FIG.167J




DC904_R01_032_167J
BECK STARTEO

FIG.167K




DC904_R01_032_167K
BECK STARTEO

FIG.167L




DC904_R01_032_167L
BECK STARTEO

FIG.175A




DC904_R01_032_175A
GOL JUMP

FIG.206A




DC904_R01_032_206A
CLUTON ADD

FIG.206B




DC904_R01_032_206B
CLUTON ADD

FIG.206C




DC904_R01_032_206C
CLUTON ADD

FIG.206D




DC904_R01_032_206D
CLUTON ADD

FIG.206E




DK04_R01_015_206E
(CLUTCH ROD)

FIG.206F




DK04_R01_015_206F
(CLUTCH ROD)

FIG.206G




DK04_R01_015_206G
(CLUTCH ROD)

FIG.206H




DK04_R01_015_206H
(CLUTCH ROD)

FIG.206J




DK04_R01_015_206J
(CLUTCH ROD)

FIG.206K




DK04_R01_015_206K
(CLUTCH ROD)

FIG.206L




DK04_R01_015_206L
(CLUTCH ROD)

FIG.210A




DK04_R01_015_210A
(SHIFT ROD)

FIG.220A




DC604_R01_015_2804
TRANSMISSION

FIG.220B




DC604_R01_015_2805
TRANSMISSION

FIG.220C




DC604_R01_015_2806
TRANSMISSION

FIG.220D




DC604_R01_015_2807
TRANSMISSION

FIG.220E




DC604_R01_015_2808
TRANSMISSION

FIG.220F




DC604_R01_015_2809
TRANSMISSION

FIG.220G




DC604_R01_015_2810
TRANSMISSION

FIG.220H




DC604_R01_015_2811
TRANSMISSION

FIG.220J




DC604_P01_015_280J
FRANCOBOLD201

FIG.220K




DC604_P01_015_280K
FRANCOBOLD201

FIG.220L




DC604_P01_015_280L
FRANCOBOLD201

FIG.301A




DC604_P01_015_301A
STARLING240700

FIG.303A




DC604_P01_015_303A
MAGNETO

FIG.303B




DC604_P01_015_303B
MAGNETO

FIG.303C




DC604_P01_015_303C
MAGNETO

FIG.303D




DC604_P01_015_303D
MAGNETO

FIG.303E




DCRM_P01_012_010F
RECIPIERREVISION CODE

FIG.310A




DCRM_P01_012_010A
RECIPIERREVISION CODE

FIG.310B




DCRM_P01_012_010B
RECIPIERREVISION CODE

FIG.310C




DCRM_P01_012_010C
RECIPIERREVISION CODE

FIG.310D




DCRM_P01_012_010D
RECIPIERREVISION CODE

FIG.310E




DCRM_P01_012_010E
RECIPIERREVISION CODE

FIG.310F




DCRM_P01_012_010F
RECIPIERREVISION CODE

FIG.310G




DCRM_P01_012_010G
RECIPIERREVISION CODE

FIG.310H




DCRM_R01_012_010V
REV.20180504/IRON/COX

FIG.310J




DCRM_R01_012_010J
REV.20180504/IRON/COX

FIG.310K




DCRM_R01_012_010K
REV.20180504/IRON/COX

FIG.310L




DCRM_R01_012_010L
REV.20180504/IRON/COX

FIG.322A




DCRM_R01_012_032A
HARNESS

FIG.322B




DCRM_R01_012_032B
HARNESS

FIG.322C




DCRM_R01_012_032C
HARNESS

FIG.322D




DCRM_R01_012_032D
HARNESS

FIG.322E




DC604_R01_012_202F
HARNESS

FIG.322F




DC604_R01_012_202F
HARNESS

FIG.322G




DC604_R01_012_202G
HARNESS

FIG.322H




DC604_R01_012_202H
HARNESS

FIG.322J




DC604_R01_012_202J
HARNESS

FIG.322K




DC604_R01_012_202K
HARNESS

FIG.322L




DC604_R01_012_202L
HARNESS

FIG.327A




DC604_R01_012_202A
PTT SWITCH

FIG.327B




DK6M_P01_03_207D
PTT SWITCH

FIG.327C




DK6M_P01_03_207C
PTT SWITCH

FIG.327D




DK6M_P01_03_207D
PTT SWITCH

FIG.334A




DK6M_P01_03_304A
SENSOR SWITCH

FIG.334B




DK6M_P01_03_304B
SENSOR SWITCH

FIG.334C




DK6M_P01_03_304C
SENSOR SWITCH

FIG.334D



DK6M_P01_03_304D
SENSOR SWITCH

FIG.334E



DK6M_P01_03_304E
SENSOR SWITCH

FIG. 334F


DF204_P01_01S_33AF
SENSOR SWITCH

FIG. 334G




DF204_P01_015_33AG
SENSOR SWITCH

FIG. 334H




IN204_P01_015_334H
SENSOR SWITCH

FIG. 334J



DFRM_P01_015_3341
SENSOR SWITCH

FIG. 334K



DEFINITION: 015_334K
SENSOR/ SWITCH

FIG. 334L




DF204_P01_015_33M
SENSOR/ SWITCH

FIG. 335A




DF204_P01_015_3050
CLAMP BRACKET

FIG. 335B



INFORM_P01_015_3353
CLAMP BRACKET

FIG. 335C



DFRM_P01_015_230C
CLAMP BRACKET

FIG. 335D




DFRM_P01_015_3350
CLAMP BRACKET

FIG. 335E




INFORM_015_005
CLAMP BRACKET

FIG. 335F



CLAMP BRACKET

FIG. 335G



DEFORM_01_015_225G
CLAMP BRACKET

FIG. 335H




DFRM_P01_015_3354
CLAMP BRACKET

FIG. 335J




CLAMP BRACKET

FIG. 335K




DEFRA_P01_015_335K
CLAMP BRACKET

FIG.335L




DC94A_P01_015_335L
CLAMP BRACKET

FIG.336A




DC94A_P01_015_336A
SWIVEL BRACKET

FIG.336B




DC94A_P01_015_336B
SWIVEL BRACKET

FIG.336C




DC94A_P01_015_336C
SWIVEL BRACKET

FIG.336D




DC94A_P01_015_336D
SWIVEL BRACKET

FIG.336E




DC94A_P01_015_336E
SWIVEL BRACKET

FIG.336F




DC94A_P01_015_336F
SWIVEL BRACKET

FIG.336G




DC94A_P01_015_336G
SWIVEL BRACKET

FIG.336H




DC904_R01_015_286V
OPTICAL BRACKET

FIG.336J




DC904_R01_015_286V
OPTICAL BRACKET

FIG.336K




DC904_R01_015_286V
OPTICAL BRACKET

FIG.336L




DC904_R01_015_286
OPTICAL BRACKET

FIG.338A




DC904_R01_015_285A
TILT CYLINDER

FIG.338B




DC904_R01_015_285B
TILT CYLINDER

FIG.338C




DC904_R01_015_285C
TILT CYLINDER

FIG.338D




DC904_R01_015_285D
TILT CYLINDER

FIG.340A




DCRM_R11_012_340A
PIT 847020

FIG.340B




DCRM_R11_012_340B
PIT 847020

FIG.340C




DCRM_R11_012_340C
PIT 847020

FIG.340D




DCRM_R11_012_340D
PIT 847020

FIG.401A




DCRM_R11_012_401A
ENGINE HOUSING

FIG.405A




DCRM_R11_012_405A
DRIVE SHAFT ASSEMBLY

FIG.407A




DCRM_R11_012_407A
GEAR CASE

FIG.410A




DCRM_R11_012_410A
SIDE COVER

FIG.410B




DC9M_P01_012_410B
SEE COVER

FIG.410C




DC9M_P01_012_410C
SEE COVER

FIG.410D




DC9M_P01_012_410D
SEE COVER

FIG.410E




DC9M_P01_012_410E
SEE COVER

FIG.410F




DC9M_P01_012_410F
SEE COVER

FIG.410G




DC9M_P01_012_410G
SEE COVER

FIG.410H




DC9M_P01_012_410H
SEE COVER

FIG.410J




DC9M_P01_012_410J
SEE COVER

FIG.410K




DC60A, P11, 015, 410K
ENGINE COVER

FIG.410L




DC60A, P11, 015, 410L
ENGINE COVER

FIG.420A




DC60A, P11, 015, 420A
ENGINE COVER

FIG.420B




DC60A, P11, 015, 420B
ENGINE COVER

FIG.420C




DC60A, P11, 015, 420C
ENGINE COVER

FIG.420D




DC60A, P11, 015, 420D
ENGINE COVER

FIG.420E




DC60A, P11, 015, 420E
ENGINE COVER

FIG.420F




DC60A, P11, 015, 420F
ENGINE COVER

FIG.420G




DC904_R01_015_420G
ENGINE COVER

FIG.420H




DC904_R01_015_420H
ENGINE COVER

FIG.420J




DC904_R01_015_420J
ENGINE COVER

FIG.420K




DC904_R01_015_420K
ENGINE COVER

FIG.420L




DC904_R01_015_420L
ENGINE COVER

FIG.432A




DC904_R01_015_432A
FUEL TANK

FIG.442A




DC904_R01_015_442A
FUEL TANK

FIG.442B




DC904_R01_015_442B
FUEL TANK

FIG.442C




DK04_P01_032_442C
ORIGLIN

FIG.442D




DK04_P01_032_442D
ORIGLIN

FIG.442E




DK04_P01_032_442E
ORIGLIN

FIG.444A




DK04_P01_032_444A
TILLER HANDLE

FIG.444B




DK04_P01_032_444B
TILLER HANDLE

FIG.444C




DK04_P01_032_444C
TILLER HANDLE

FIG.444D




DK04_P01_032_444D
TILLER HANDLE

FIG.444E




DK04_P01_032_444E
TILLER HANDLE

FIG.444F




DC904_P01_015_44F
TOILET WASH C

FIG.450A




DC904_P01_015_45A
REMOTE CONTROL

FIG.450B




DC904_P01_015_45B
REMOTE CONTROL

FIG.450C




DC904_P01_015_45C
REMOTE CONTROL

FIG.450D




DC904_P01_015_45D
REMOTE CONTROL

FIG.450E




DC904_P01_015_45E
REMOTE CONTROL

FIG.502A




DC904_P01_015_50A
OPT-9675H (1)

FIG.502B




DC904_P01_015_50B
OPT-9675H (1)

FIG.502C




DCRM_R01_03_80C
OPT-METER (1)

FIG.502D




DCRM_R01_03_80D
OPT-METER (1)

FIG.502E




DCRM_R01_03_80E
OPT-METER (1)

FIG.503A




DCRM_R01_03_80A
OPT-METER (2)

FIG.503B




DCRM_R01_03_80B
OPT-METER (2)

FIG.503C




DCRM_R01_03_80C
OPT-METER (2)

FIG.503D



DCRM_R01_03_80D
OPT-METER (2)

FIG.503E



DCRM_R01_03_80E
OPT-METER (2)

FIG.508A




FIG. 508A
OPTIMIZED CONTROL

FIG.508B




FIG. 508B
OPTIMIZED CONTROL

FIG.508C




FIG. 508C
OPTIMIZED CONTROL

FIG.508D




FIG. 508D
OPTIMIZED CONTROL

FIG.513A




FIG. 513A
OPTIMIZED CONTROL PARTS

FIG.513B




FIG. 513B
OPTIMIZED CONTROL PARTS

FIG.513C




FIG. 513C
OPTIMIZED CONTROL PARTS

FIG.513D








FIG. 513D
OPTIMIZED CONTROL PARTS

FIG.515A





DC6A_R11_015_515A
OPT.FIBER CORD CABLE

FIG.515B





DC6A_R11_015_515B
OPT.FIBER CORD CABLE

FIG.515C





DC6A_R11_015_515C
OPT.FIBER CORD CABLE

FIG.515D





DC6A_R11_015_515D
OPT.FIBER CORD CABLE

FIG.515E





DC6A_R11_015_515E
OPT.FIBER CORD CABLE

FIG.515F





DC6A_R11_015_515F
OPT.FIBER CORD CABLE

FIG.515G





DC6A_R11_015_515G
OPT.FIBER CORD CABLE

FIG.515H




DC6A_R11_015_515H
OPT.FIBER CORD CABLE

FIG.515J




DC04_R11_015_01J
OPT.PARAM CONTROL

FIG.530A




DC04_R11_015_03A
OPT.SWITCH

FIG.530B




DC04_R11_015_03B
OPT.SWITCH

FIG.530C




DC04_R11_015_03C
OPT.SWITCH

FIG.530D




DC04_R11_015_03D
OPT.SWITCH

FIG.530E




DC04_R11_015_03E
OPT.SWITCH

FIG.544A




DC04_R11_015_04A
OPT.PARAM CONTROL ASSY SINGLE (1)

FIG.544B




DC04_R11_015_04B
OPT.PARAM CONTROL ASSY SINGLE (1)

FIG.544C




DC90A_P01_03_844C
OPT-REMOTE CONTROL ASSY SINGLE (7)

FIG.544D




DC90A_P01_03_844D
OPT-REMOTE CONTROL ASSY SINGLE (7)

FIG.544E




DC90A_P01_03_844E
OPT-REMOTE CONTROL ASSY SINGLE (7)

FIG.544F




DC90A_P01_03_844F
OPT-REMOTE CONTROL ASSY SINGLE (7)

FIG.544G




DC90A_P01_03_844G
OPT-REMOTE CONTROL ASSY SINGLE (7)

FIG.544H




DC90A_P01_03_844H
OPT-REMOTE CONTROL ASSY SINGLE (7)

FIG.544J




DC90A_P01_03_844J
OPT-REMOTE CONTROL ASSY SINGLE (7)

FIG.545A




DC90A_P01_03_845A
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545B




DCRM_P01_015_8452
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545C




DCRM_P01_015_8452
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545D




DCRM_P01_015_8452
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545E




DCRM_P01_015_8452
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545F




DCRM_P01_015_8457
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545G




DCRM_P01_015_8452
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545H




DCRM_P01_015_8457
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545J




DCRM_P01_015_8457
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.546A




DC00A_P01_015_0400
OPT. REMOTE CABLE (ELECTRIC STARTER)

FIG.546B




DC00A_P01_015_0402
OPT. REMOTE CABLE (ELECTRIC STARTER)

FIG.546C




DC00A_P01_015_0403
OPT. REMOTE CABLE (ELECTRIC STARTER)

FIG.546D




DC00A_P01_015_0403
OPT. REMOTE CABLE (ELECTRIC STARTER)

FIG.546E




DC00A_P01_015_0407
OPT. REMOTE CABLE (ELECTRIC STARTER)

FIG.546F




DC00A_P01_015_0407
OPT. REMOTE CABLE (ELECTRIC STARTER)

FIG.553A




DC00A_P01_015_0504
OPT. ELECTRICAL (MANUAL STARTER)

FIG.553B




DC00A_P01_015_0507
OPT. ELECTRICAL (MANUAL STARTER)

FIG.553C




DC90A_P01_03.553C
OPT.ELECTRICAL (MANUAL STARTER)

FIG.553D




DC90A_P01_03.553D
OPT.ELECTRICAL (MANUAL STARTER)

FIG.561A




DC90A_P01_03.561A
OPT.STARTING MOTOR (MANUAL STARTER)

FIG.561B




DC90A_P01_03.561B
OPT.STARTING MOTOR (MANUAL STARTER)

FIG.561C




DC90A_P01_03.561C
OPT.STARTING MOTOR (MANUAL STARTER)

FIG.561D




DC90A_P01_03.561D
OPT.STARTING MOTOR (MANUAL STARTER)

FIG.575A




DC90A_P01_03.575A
OPT.LONG LIGN

FIG.575B




DC90A_P01_03.575B
OPT.LONG LIGN

FIG.575C




DCDMA_P01_015_575C
OPT. LONGANCE GAUGE

FIG.575D




DCDMA_P01_015_575D
OPT. LONGANCE GAUGE

FIG.583A




DCDMA_P01_015_583A
OPT. LONGANCE GAUGE

FIG.588A




DCDMA_P01_015_588A
OPT. LONGANCE GAUGE

FIG.588B




DCDMA_P01_015_588B
OPT. LONGANCE GAUGE

FIG.588C




DCDMA_P01_015_588C
OPT. LONGANCE GAUGE

FIG.588D



DCDMA_P01_015_588D
OPT. LONGANCE GAUGE

FIG.588E



DCDMA_P01_015_588E
OPT. LONGANCE GAUGE

FIG.111A

FIG.111A (1-B-2) CYLINDER HEAD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11110-89L01	HEAD, CYLINDER	1	
2	11141-89L00	GASKET, CYLINDER HEAD	1	
3	09119-08L02	BOLT (8X72)	6	
4	09119-08L01	BOLT (8X77)	2	
5	11261-93J00	COVER, PROTECTION ANODE	1	
6	09280-22019	O RING (D:1.9,ID:21.8)	1	
7	55321-87J00	ANODE, PROTECTION	1	
8	09103-06281	BOLT (6X14)	1	
9	01550-08207	BOLT	1	
10	11382-93E00	CAP, OIL FILLER	1	
11	09280-17003	O RING (D:3.1,ID:16.8)	1	
12	04211-11129	PIN	2	
13	11170-89L00	COVER, CYLINDER HEAD	1	
14	11162-89L00	GASKET, CYLINDER HEAD COVER	1	
15	01550-06207	BOLT	6	
16	11174-89L00	HOSE, BREATHER	1	
17	09401-12413	CLIP	2	
18	09482-00L04	SPARK PLUG (CPR6EA-9)	2	NGK
19	11115-93E00-001	GUIDE, VALVE (OS:0.3)	4	OPT




FIG.113A




FIG.113A (1-B-3) CYLINDER BLOCK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11300-89L01	BLOCK ASSY, CYLINDER	1	
2	01550-06357	.BOLT	6	
3	01560-08757	.BOLT	4	
4	04211-11129	.PIN	2	
5	16440-11D00	REGULATOR ASSY, ENGINE	1	
6	11291-91B50	HOOK, ENGINE	1	OPT
7	01550-08207	BOLT	1	OPT

FIG.116A




FIG.116A (1-B-4) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12111-89L00-0B0	PISTON	2	
2	12140-89L00	RING SET, PISTON	2	
3	12151-89L00	PIN, PISTON	2	
4	09381-16001	SNAP RING	4	
5	12160-89L00	CONNROD ASSY	2	
6	12163-89L00	.BOLT, CONNROD	4	
7	12220-89L00	CRANKSHAFT	1	
8	12341-89L10	BEARING, CRANKSHAFT	4	
9	09283-32039	OIL SEAL (32X44X6.5)	2	
10	12100-89L00-050	PISTON SET (OS:0.50)	2	OPT
11	12140-89L00-050	.RING SET, PISTON	2	OPT



FIG.120A




FIG.120A (1-B-5) TIMING BELT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12631-89L10	PULLEY, CRANKSHAFT (NT:17)	1	
2	12635-89L00	GUIDE, TIMING BELT	1	
3	12636-89L00	GUIDE, TIMING BELT (LOWER)	1	
4	12637-89L00	NUT, TIMING PULLEY	1	
5	12638-89L00	WASHER, PULLEY NUT LOCK	1	
6	12741-89L00	PULLEY, CAMSHAFT (NT:34)	1	
7	09103-06267	BOLT (6X18)	1	
8	09160-06171	WASHER (6.5X24X4)	1	
9	08341-31039	KEY	1	
10	08341-31039	KEY	1	
11	12625-89L01	BASE, STATOR	1	
12	04211-09149	PIN	2	
13	01550-06257	BOLT	2	
14	01550-06357	BOLT	2	
15	02122-04127	SCREW	3	
16	12761-93EL0	BELT, TIMING	1	
17	12744-89L00	PLATE, SENSING	1	

FIG.121A




FIG.121A (1-B-6) CAMSHAFT (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12700-89L00	CAMSHAFT ASSY	1	W/MANUAL STARTER
1-2	12700-89L20	CAMSHAFT ASSY	1	W/ELECTRIC STARTER
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J01	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121B




FIG.121B (1-B-7) CAMSHAFT (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L20	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J01	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121C




FIG.121C (1-B-8) CAMSHAFT (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L20	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J01	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121D




FIG.121D (1-B-9) CAMSHAFT (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12700-89L00	CAMSHAFT ASSY	1	W/MANUAL STARTER
1-2	12700-89L20	CAMSHAFT ASSY	1	W/ELECTRIC STARTER
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J01	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121E




FIG.121E (1-B-10) CAMSHAFT (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L20	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J01	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121F




FIG.121F (1-B-11) CAMSHAFT (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L20	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J01	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121G




FIG.121G (1-B-12) CAMSHAFT (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12700-89L00	CAMSHAFT ASSY	1	W/MANUAL STARTER
1-2	12700-89L20	CAMSHAFT ASSY	1	W/ELECTRIC STARTER
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J01	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121H




FIG.121H (1-B-13) CAMSHAFT (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12700-89L00	CAMSHAFT ASSY	1	W/MANUAL STARTER
1-2	12700-89L20	CAMSHAFT ASSY	1	W/ELECTRIC STARTER
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J01	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121J




FIG.121J (1-B-14) CAMSHAFT (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L20	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J01	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121K




FIG.121K (1-B-15) CAMSHAFT (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L20	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J01	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121L




FIG.121L (1-C-2) CAMSHAFT (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L20	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J01	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.126A




FIG.126A (1-C-3) INLET MANIFOLD (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06202	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L10	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	



FIG.126B




FIG.126B (1-C-4) INLET MANIFOLD (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06202	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L10	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	

FIG.126C




FIG.126C (1-C-5) INLET MANIFOLD (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06202	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L10	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	

FIG.126D




FIG.126D (1-C-6) INLET MANIFOLD (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06202	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L00	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	

FIG.126E




FIG.126E (1-C-7) INLET MANIFOLD (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06202	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L00	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	

FIG.126F




FIG.126F (1-C-8) INLET MANIFOLD (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06202	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L00	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	



FIG.126G




FIG.126G (1-C-9) INLET MANIFOLD (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06202	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	

FIG.126H




FIG.126H (1-C-10) INLET MANIFOLD (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06202	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	

FIG.126J




FIG.126J (1-C-11) INLET MANIFOLD (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06202	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	

FIG.126K




FIG.126K (1-C-12) INLET MANIFOLD (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06202	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	

FIG.126L




FIG.126L (1-C-13) INLET MANIFOLD (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06202	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	



FIG.144A




FIG.144A (1-C-14) FUEL INJECTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-89L00	HOSE, FUEL(PUMP TO DLVY)	1	
2	15710-89L00	INJECTOR ASSY, FUEL	2	
3	15716-65DT0	.GROMMET SET, FUEL INJECTOR	2	
4	15734-89L00	SPACER, DELIVERY PIPE	1	
5	15735-89L00	INSULATOR, DELIVERY PIPE	1	
6	15751-89L00	PIPE, DELIVERY	1	
7	09320-08062	CUSHION	2	
8	09401-11425	CLIP	2	
9	01550-06507	BOLT	2	



FIG.146A




FIG.146A (1-C-15) FUEL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L01	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L01	CHAMBER, EVAPORATION	1	
7	15770-89L01	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-06257	BOLT	2	
12	09116-06202	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-06167	BOLT	2	
21	01550-06207	BOLT	2	
22	01550-06257	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L10	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	

FIG.146A




FIG.146A (1-D-2) FUEL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	

FIG.160A




FIG.160A (1-D-3) WATER PUMP (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160B




FIG.160B (1-D-4) WATER PUMP (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160C




FIG.160C (1-D-5) WATER PUMP (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160D




FIG.160D (1-D-6) WATER PUMP (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160E




FIG.160E (1-D-7) WATER PUMP (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160F




FIG.160F (1-D-8) WATER PUMP (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160G




FIG.160G (1-D-9) WATER PUMP (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160H




FIG.160H (1-D-10) WATER PUMP (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J10	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J10	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J11	KIT, WATER PUMP REPAIR	1	OPT

FIG.160J




FIG.160J (1-D-11) WATER PUMP (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160K




FIG.160K (1-D-12) WATER PUMP (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160L




FIG.160L (1-D-13) WATER PUMP (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.162A




FIG.162A (1-D-14) THERMOSTAT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17670-91J00	THERMOSTAT (50C)	1	
2	17680-89L00	COVER, THERMOSTAT	1	
3	01550-06207	BOLT	3	
4	17712-89L10	HOSE, WATER (COOLER TO HOUSING)	1	
5	17712-89L00	HOSE, WATER (HOUSING TO COOLER)	1	
6	09401-08413	CLIP	4	
7	17685-89L00	SEAL, THERMOSTAT COVER	1	
8	18498-94J20	PROTECTOR,FUEL HOSE (L:320)	1	L:320->50
9	09408-00070	CLAMP	1	

FIG.163A




FIG.163A (1-D-15) THROTTLE BODY (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L00	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-06127	BOLT	1	
9	01550-06207	BOLT	2	

FIG.163B




FIG.163B (1-E-2) THROTTLE BODY (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L10	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-06207	BOLT	2	

FIG.163C




FIG.163C (1-E-3) THROTTLE BODY (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L10	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-06207	BOLT	2	

FIG.163D




FIG.163D (1-E-4) THROTTLE BODY (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L00	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-06127	BOLT	1	
9	01550-06207	BOLT	2	

FIG.163E




FIG.163E (1-E-5) THROTTLE BODY (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L10	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-06207	BOLT	2	



FIG.163F




FIG.163F (1-E-6) THROTTLE BODY (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L00	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-06127	BOLT	1	
9	01550-06207	BOLT	2	

FIG.163G




FIG.163G (1-E-7) THROTTLE BODY (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L00	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-06127	BOLT	1	
9	01550-06207	BOLT	2	

FIG.163H




FIG.163H (1-E-8) THROTTLE BODY (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L00	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-06127	BOLT	1	
9	01550-06207	BOLT	2	



FIG.163J





FIG.163J (1-E-9) THROTTLE BODY (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L10	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-06207	BOLT	2	

FIG.163K



DF20A_P01_015_163K
THROTTLE BODY

FIG.163K (1-E-10) THROTTLE BODY (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L10	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-06207	BOLT	2	

FIG.163L




FIG.163L (1-E-11) THROTTLE BODY (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L00	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-06127	BOLT	1	
9	01550-06207	BOLT	2	

FIG.166A

FIG.166A (1-E-12) THROTTLE CONTROL (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-06127	BOLT	1	
10	01550-06167	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	




FIG.166B




FIG.166B (1-E-13) THROTTLE CONTROL (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-06127	BOLT	1	
10	01550-06167	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	

FIG.166C

FIG.166C (1-E-14) THROTTLE CONTROL (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-06127	BOLT	1	
10	01550-06167	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	




FIG.166D

FIG.166D (1-E-15) THROTTLE CONTROL (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-06127	BOLT	1	
10	01550-06167	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	




FIG.166E




FIG.166E (1-F-2) THROTTLE CONTROL (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-06127	BOLT	1	
10	01550-06167	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	

FIG.167A




FIG.167A (1-F-3) RECOIL STARTER (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-94J10	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	61493-94J00	LABEL, CLEARANCE	1	
16	61494-94J00	LABEL, OIL	1	

FIG.167B




FIG.167B (1-F-4) RECOIL STARTER (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-94J10	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	61493-94J00	LABEL, CLEARANCE	1	
16	61494-94J00	LABEL, OIL	1	

FIG. 167C

Exploded view diagram of a mechanical assembly, likely a watch movement, showing various components labeled 1 through 17. The diagram includes a central assembly (1) with a circular base (2), a spiral spring (4), and a winding mechanism (10). Other components include a bezel (13), a crown (14), a pusher (15), a strap (16), and a strap buckle (17). A warning symbol is present in the bottom left corner.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-94J10	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	61493-94J00	LABEL, CLEARANCE	1	
16	61494-94J00	LABEL, OIL	1	
17	09403-12406	CLAMP	1	

FIG.167D




FIG.167D (1-F-6) RECOIL STARTER (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-94J10	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	61493-94J00	LABEL, CLEARANCE	1	
16	61494-94J00	LABEL, OIL	1	

FIG.167E




FIG.167E (1-F-7) RECOIL STARTER (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-94J10	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	61493-94J00	LABEL, CLEARANCE	1	
16	61494-94J00	LABEL, OIL	1	

FIG.167F




FIG.167F (1-F-8) RECOIL STARTER (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-94J10	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	61493-94J00	LABEL, CLEARANCE	1	
16	61494-94J00	LABEL, OIL	1	
17	09403-12406	CLAMP	1	

FIG.167G




FIG.167G (1-F-9) RECOIL STARTER (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-94J10	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	61493-94J00	LABEL, CLEARANCE	1	
16	61494-94J00	LABEL, OIL	1	

FIG.167H




FIG.167H (1-F-10) RECOIL STARTER (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-94J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	61493-94J00	LABEL, CLEARANCE	1	
16	61494-94J00	LABEL, OIL	1	

FIG.167J




FIG.167J (1-F-11) RECOIL STARTER (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-94J10	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	61493-94J00	LABEL, CLEARANCE	1	
16	61494-94J00	LABEL, OIL	1	

FIG.167K




FIG.167K (1-F-12) RECOIL STARTER (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-94J10	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	61493-94J00	LABEL, CLEARANCE	1	
16	61494-94J00	LABEL, OIL	1	
17	09403-12406	CLAMP	1	

FIG.167L




FIG.167L (1-F-13) RECOIL STARTER (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-94J10	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	61493-94J00	LABEL, CLEARANCE	1	
16	61494-94J00	LABEL, OIL	1	
17	09403-12406	CLAMP	1	

FIG.175A




FIG.175A (1-F-14) OIL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	16400-89L00	PUMP ASSY, OIL	1	
2	16510-45H10	FILTER, ENGINE OIL	1	
3	16512-99J00	CAP, OIL FILTER	1	
4	09280-13004	O RING (D:1.9,ID:13)	1	
5	09280-54001	O RING (D:2.4,ID:52.6)	1	
6	09440-18002	SPRING	1	
7	01550-06207	BOLT	3	
8	01550-06127	BOLT	1	
9	16910-89L00	GAUGE, OIL LEVEL	1	
10	16930-89L00	GUIDE, OIL LEVEL GAUGE	1	
11	09280-09008	O RING (D:2.1,ID:8.8)	1	
12	16431-89L00	BLOCK, OIL GALLERY	1	
13	59262-94J00	PIN, OIL PUMP	1	
14	02122-0630A	SCREW	3	

FIG.206A




FIG.206A (1-F-15) CLUTCH ROD (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L00	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.5)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-06127	BOLT	1	
18	01550-06257	BOLT	1	
19	02142-06207	SCREW	2	



FIG.206B




FIG.206B (1-G-2) CLUTCH ROD (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L00	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-06127	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-06127	BOLT	1	
16	01550-06257	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-06167	BOLT	2	

FIG.206C




FIG.206C (1-G-3) CLUTCH ROD (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L00	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-06127	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-06127	BOLT	1	
16	01550-06257	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-06167	BOLT	2	

FIG.206D




FIG.206D (1-G-4) CLUTCH ROD (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L00	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.5)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-06127	BOLT	1	
18	01550-06257	BOLT	1	
19	02142-06207	SCREW	2	



FIG.206E




FIG.206E (1-G-5) CLUTCH ROD (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L00	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-06127	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-06127	BOLT	1	
16	01550-06257	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-06167	BOLT	2	

FIG.206F




FIG.206F (1-G-6) CLUTCH ROD (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L00	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.5)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-06127	BOLT	1	
18	01550-06257	BOLT	1	
19	02142-06207	SCREW	2	



FIG.206G




FIG.206G (1-G-7) CLUTCH ROD (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L00	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.5)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-06127	BOLT	1	
18	01550-06257	BOLT	1	
19	02142-06207	SCREW	2	



FIG.206H




FIG.206H (1-G-8) CLUTCH ROD (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L00	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.5)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-06127	BOLT	1	
18	01550-06257	BOLT	1	
19	02142-06207	SCREW	2	



FIG.206J





FIG.206J (1-G-9) CLUTCH ROD (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L00	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-06127	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-06127	BOLT	1	
16	01550-06257	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-06167	BOLT	2	

FIG.206K



DF20A_P01_015_206K
CLUTCH ROD

FIG.206K (1-G-10) CLUTCH ROD (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L00	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-06127	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-06127	BOLT	1	
16	01550-06257	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-06167	BOLT	2	

DF20A_P01_015

FIG.206L




FIG.206L (1-G-11) CLUTCH ROD (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L00	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.5)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-06127	BOLT	1	
18	01550-06257	BOLT	1	
19	02142-06207	SCREW	2	



FIG.220A





FIG.220A (1-G-13) TRANSMISSION (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J10	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

FIG.220A




DF20A_P01_015_220A
TRANSMISSION

FIG.220A (1-G-14) TRANSMISSION (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

DF20A_P01_015

FIG.220B



DF20A_P01_015_220B
TRANSMISSION

FIG.220B (1-G-15) TRANSMISSION (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J10	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_015

FIG.220B





FIG.220B (1-H-2) TRANSMISSION (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.220C




DF20A_P01_015_220C
TRANSMISSION

FIG.220C (1-H-3) TRANSMISSION (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J10	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17053	WASHER (T:1.1)	1	REV
11-2	09160-17054	WASHER (T:1.2)	1	REV
11-3	09160-17055	WASHER (T:1.3)	1	REV
11-4	09160-17056	WASHER (T:1.4)	1	REV
11-5	09160-17057	WASHER (T:1.5)	1	REV
11-6	09160-17058	WASHER (T:1.6)	1	REV
11-7	09160-17059	WASHER (T:1.7)	1	REV
11-8	09160-17060	WASHER (T:1.8)	1	REV
11-9	09160-17061	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_015

FIG.220C




DF20A_P01_015_220C
TRANSMISSION

FIG.220C (1-H-4) TRANSMISSION (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

DF20A_P01_015

FIG.220D




DF20A_P01_015_220D
TRANSMISSION

FIG.220D (1-H-5) TRANSMISSION (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J10	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_015

FIG.220D




DF20A_P01_015_220D
TRANSMISSION

FIG.220D (1-H-6) TRANSMISSION (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

DF20A_P01_015

FIG.220E




DF20A_P01_015_220E
TRANSMISSION

FIG.220E (1-H-7) TRANSMISSION (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J10	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_015

FIG.220E




DF20A_P01_015_220E
TRANSMISSION

FIG.220E (1-H-8) TRANSMISSION (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

DF20A_P01_015

FIG.220F




DF20A_P01_015_220F
TRANSMISSION

FIG.220F (1-H-9) TRANSMISSION (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J10	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17053	WASHER (T:1.1)	1	REV
11-2	09160-17054	WASHER (T:1.2)	1	REV
11-3	09160-17055	WASHER (T:1.3)	1	REV
11-4	09160-17056	WASHER (T:1.4)	1	REV
11-5	09160-17057	WASHER (T:1.5)	1	REV
11-6	09160-17058	WASHER (T:1.6)	1	REV
11-7	09160-17059	WASHER (T:1.7)	1	REV
11-8	09160-17060	WASHER (T:1.8)	1	REV
11-9	09160-17061	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_015

FIG.220F



DF20A_P01_015_220F
TRANSMISSION

FIG.220F (1-H-10) TRANSMISSION (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

DF20A_P01_015

FIG.220G




FIG.220G (1-H-11) TRANSMISSION (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J10	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

FIG.220G




FIG.220G (1-H-12) TRANSMISSION (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.220H




FIG.220H (1-H-13) TRANSMISSION (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J10	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

FIG.220H





FIG.220H (1-H-14) TRANSMISSION (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.220J



DF20A_P01_015_220J
TRANSMISSION

FIG.220J (1-H-15) TRANSMISSION (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J10	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_015

FIG.220J





FIG.220J (1-I-2) TRANSMISSION (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.220K



DF20A_P01_015_220K
TRANSMISSION

FIG.220K (1-I-3) TRANSMISSION (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J10	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17053	WASHER (T:1.1)	1	REV
11-2	09160-17054	WASHER (T:1.2)	1	REV
11-3	09160-17055	WASHER (T:1.3)	1	REV
11-4	09160-17056	WASHER (T:1.4)	1	REV
11-5	09160-17057	WASHER (T:1.5)	1	REV
11-6	09160-17058	WASHER (T:1.6)	1	REV
11-7	09160-17059	WASHER (T:1.7)	1	REV
11-8	09160-17060	WASHER (T:1.8)	1	REV
11-9	09160-17061	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_015

FIG.220K





FIG.220K (1-I-4) TRANSMISSION (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.220L



DF20A_P01_015_220L
TRANSMISSION

FIG.220L (1-I-5) TRANSMISSION (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J10	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17053	WASHER (T:1.1)	1	REV
11-2	09160-17054	WASHER (T:1.2)	1	REV
11-3	09160-17055	WASHER (T:1.3)	1	REV
11-4	09160-17056	WASHER (T:1.4)	1	REV
11-5	09160-17057	WASHER (T:1.5)	1	REV
11-6	09160-17058	WASHER (T:1.6)	1	REV
11-7	09160-17059	WASHER (T:1.7)	1	REV
11-8	09160-17060	WASHER (T:1.8)	1	REV
11-9	09160-17061	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_015

FIG.220L




FIG.220L (1-1-6) TRANSMISSION (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.301A




FIG.301A (1-1-7) STARTING MOTOR (ELECTRIC STARTER)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-94J22	STARTING MOTOR	1	
2	31131-94J00	.BRUSH SET, PLUS	1	
3	31135-90J00	.SPRING	4	
4	31151-94J01	.CASE, GEAR	1	
5	31152-90J00	.PLATE, CENTER	1	
6	31153-90J00	.BRACKET, PLANET GEAR	1	
7	31171-96J00	.COVER KIT, DUST	1	
8	31173-94J01	.HOLDER ASSY, BRUSH	1	
9	31191-96J00	.LEVER, SHIFT	1	
10	31220-94J00	.SWITCH, MAGNET	1	
11	31310-90J00	.ARMATURE	1	
12	31320-94J00	.PINION	1	
13	31341-94J00	.SHAFT, PINION	1	
14	31343-90J00	.INTERNAL GEAR	1	
15	31344-90J00	.GEAR, PLANETARY	3	
16	31360-93J01	.WASHER SET	1	
17	31170-94J00	.COVER ASSY, STATER MOTOR REAR	1	
18	31912-89L00	BAND, STARTING MOTOR	1	
19	31918-94J00	DAMPER, LOWER	1	
20	38860-76F01	RELAY, STARTING MOTOR	1	
21	38915-90J00	HOLDER, RELAY	1	
22	01550-08207	BOLT	2	LOWER
23	01550-08307	BOLT	2	
24	08316-10087	NUT	1	

FIG.303A

FIG.303A (1-I-8) MAGNETO (MANUAL STARTER) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-89L10	COIL, STATOR & PULSER	1	
2	01547-0630A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L10	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	7	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	
11	08322-0106A	WASHER	3	
12	36615-96300	TERMINAL, RESIN	2	




FIG.303B




FIG.303B (1-I-9) MAGNETO (MANUAL STARTER) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-89L10	COIL, STATOR & PULSER	1	
2	01547-0630A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L10	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	7	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	
11	08322-0106A	WASHER	3	
12	36615-96300	TERMINAL, RESIN	2	



FIG.303C




FIG.303C (1-I-10) MAGNETO (MANUAL STARTER) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-89L10	COIL, STATOR & PULSER	1	
2	01547-0630A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L10	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	7	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	
11	08322-0106A	WASHER	3	
12	36615-96300	TERMINAL, RESIN	2	




FIG.303D (1-I-11) MAGNETO (MANUAL STARTER) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	32120-89L10	COIL, STATOR & PULSER	1	
2	01547-0630A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L10	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	7	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	
11	08322-0106A	WASHER	3	
12	36615-96300	TERMINAL, RESIN	2	

FIG.303E




FIG.303E (1-I-12) MAGNETO (ELECTRIC STARTER)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-89L00	COIL, STATOR & PULSER	1	
2	01547-0625A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L00	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	7	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	

FIG.310A




FIG.310A (1-I-13) RECTIFIER/IGNITION COIL (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	W/ELECTRIC STARTER
8	01550-06167	BOLT	1	W/ELECTRIC STARTER
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L00	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13-1	33920-89L41	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
13-2	33920-89L51	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
16	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
17	09160-06168	WASHER (6X14X1)	1	

FIG.310B

FIG.310B (1-1-14) RECTIFIER/IGNITION COIL (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L00	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13	33920-89L41	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310C

FIG.310C (1-1-15) RECTIFIER/IGNITION COIL (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L00	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13	33920-89L41	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310D




FIG.310D (1-J-2) RECTIFIER/IGNITION COIL (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	W/ELECTRIC STARTER
8	01550-06167	BOLT	1	W/ELECTRIC STARTER
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L00	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13-1	33920-89L02	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
13-2	33920-89L12	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
16	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
17	09160-06168	WASHER (6X14X1)	1	

FIG.310E

FIG.310E (1-J-3) RECTIFIER/IGNITION COIL (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L00	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13	33920-89L02	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310F

FIG.310F (1-J-4) RECTIFIER/IGNITION COIL (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L00	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13	33920-89L02	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310G




FIG.310G (1-J-5) RECTIFIER/IGNITION COIL (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	W/ELECTRIC STARTER
8	01550-06167	BOLT	1	W/ELECTRIC STARTER
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L00	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13-1	33920-89L22	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
13-2	33920-89L32	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
16	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
17	09160-06168	WASHER (6X14X1)	1	

FIG.310H




FIG.310H (1-J-6) RECTIFIER/IGNITION COIL (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	W/ELECTRIC STARTER
8	01550-06167	BOLT	1	W/ELECTRIC STARTER
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L00	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13-1	33920-89L61	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
13-2	33920-89L71	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
16	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
17	09160-06168	WASHER (6X14X1)	1	

FIG.310J

FIG.310J (1-J-7) RECTIFIER/IGNITION COIL (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L00	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13	33920-89L22	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310K

FIG.310K (1-J-8) RECTIFIER/IGNITION COIL (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L00	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13	33920-89L22	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310L




FIG.310L (1-J-9) RECTIFIER/IGNITION COIL (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L00	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13	33920-89L22	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	

FIG.322A

FIG.322A (1-J-10) HARNESS (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	W/ELECTRIC STARTER
2	09407-14403	CLAMP (L:125)	1	W/ELECTRIC STARTER
3	09407-14407	CLAMP (L:145)	1	W/ELECTRIC STARTER
4	01547-06167	BOLT	2	W/ELECTRIC STARTER
5-1	36610-89L03	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
5-2	36610-89L13	HARNESS ASSY, WIRING	1	W/MANUAL STARTER
6	09481-10501	.FUSE (10A)	1	W/ELECTRIC STARTER
7	09481-30501	.FUSE (30A)	1	W/ELECTRIC STARTER
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10	09407-14407	CLAMP (L:145)	4	
11	32916-89L00	COVER, CONNECTOR	1	W/ELECTRIC STARTER
12	36617-89L10	BRACKET, HARNESS	1	W/ELECTRIC STARTER
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L01	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-06127	BOLT	2	
21	01550-06127	BOLT	1	




FIG.322B




FIG.322B (1-J-11) HARNESS (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89L22	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	4	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L01	BRACKET, HARNESS	1	
10	36617-91J00	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00008	CLIP (ID:20)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-06127	BOLT	2	
16	01550-06127	BOLT	1	
17-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
17-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

FIG.322C




FIG.322C (1-J-12) HARNESS (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89L51	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	2	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L30	BRACKET, HARNESS	1	
10	36617-89L20	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00024	CLIP (ID:23)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-06127	BOLT	4	
16	01550-06127	BOLT	1	
17	36617-89L40	BRACKET, HARNESS	1	
18	36991-91J00	CLAMP, EMERGENCY SWITCH LEAD	1	
19-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
19-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

FIG.322D

FIG.322D (1-J-13) HARNESS (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	W/ELECTRIC STARTER
2	09407-14403	CLAMP (L:125)	1	W/ELECTRIC STARTER
3	09407-14407	CLAMP (L:145)	1	W/ELECTRIC STARTER
4	01547-06167	BOLT	2	W/ELECTRIC STARTER
5-1	36610-89L03	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
5-2	36610-89L13	HARNESS ASSY, WIRING	1	W/MANUAL STARTER
6	09481-10501	.FUSE (10A)	1	W/ELECTRIC STARTER
7	09481-30501	.FUSE (30A)	1	W/ELECTRIC STARTER
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10	09407-14407	CLAMP (L:145)	4	
11	32916-89L00	COVER, CONNECTOR	1	W/ELECTRIC STARTER
12	36617-89L10	BRACKET, HARNESS	1	W/ELECTRIC STARTER
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L01	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-06127	BOLT	2	
21	01550-06127	BOLT	1	




FIG.322E




FIG.322E (1-J-14) HARNESS (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89L22	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	4	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L01	BRACKET, HARNESS	1	
10	36617-91J00	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00008	CLIP (ID:20)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-06127	BOLT	2	
16	01550-06127	BOLT	1	
17-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT
17-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000 OPT L:3000

FIG.322F




FIG.322F (1-J-15) HARNESS (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	09407-14403	CLAMP (L:125)	1	
3	09407-14407	CLAMP (L:145)	1	
4	01547-06167	BOLT	2	
5	36610-89L41	HARNESS ASSY, WIRING	1	
6	09481-10501	.FUSE (10A)	1	
7	09481-30501	.FUSE (30A)	1	
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10	09407-14407	CLAMP (L:145)	2	
11	32916-89L00	COVER, CONNECTOR	1	
12	36617-89L10	BRACKET, HARNESS	1	
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L30	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-06127	BOLT	4	
21	01550-06127	BOLT	1	
22	36617-89L40	BRACKET, HARNESS	1	
23	36991-91J00	CLAMP, EMERGENCY SWITCH LEAD	1	

FIG.322G




FIG.322G (1-K-2) HARNESS (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	W/ELECTRIC STARTER
2	09407-14403	CLAMP (L:125)	1	W/ELECTRIC STARTER
3	09407-14407	CLAMP (L:145)	1	W/ELECTRIC STARTER
4	01547-06167	BOLT	2	W/ELECTRIC STARTER
5-1	36610-89L03	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
5-2	36610-89L13	HARNESS ASSY, WIRING	1	W/MANUAL STARTER
6	09481-10501	.FUSE (10A)	1	W/ELECTRIC STARTER
7	09481-30501	.FUSE (30A)	1	W/ELECTRIC STARTER
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10	09407-14407	CLAMP (L:145)	4	
11	32916-89L00	COVER, CONNECTOR	1	W/ELECTRIC STARTER
12	36617-89L10	BRACKET, HARNESS	1	W/ELECTRIC STARTER
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L01	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-06127	BOLT	2	
21	01550-06127	BOLT	1	

FIG.322H

FIG.322H (1-K-3) HARNESS (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	W/ELECTRIC STARTER
2	09407-14403	CLAMP (L:125)	1	W/ELECTRIC STARTER
3	09407-14407	CLAMP (L:145)	1	W/ELECTRIC STARTER
4	01547-06167	BOLT	2	W/ELECTRIC STARTER
5-1	36610-89L03	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
5-2	36610-89L13	HARNESS ASSY, WIRING	1	W/MANUAL STARTER
6	09481-10501	.FUSE (10A)	1	W/ELECTRIC STARTER
7	09481-30501	.FUSE (30A)	1	W/ELECTRIC STARTER
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10	09407-14407	CLAMP (L:145)	4	
11	32916-89L00	COVER, CONNECTOR	1	W/ELECTRIC STARTER
12	36617-89L10	BRACKET, HARNESS	1	W/ELECTRIC STARTER
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L01	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-06127	BOLT	2	
21	01550-06127	BOLT	1	




FIG.322J




FIG.322J (1-K-4) HARNESS (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89L22	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	4	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L01	BRACKET, HARNESS	1	
10	36617-91J00	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00008	CLIP (ID:20)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-06127	BOLT	2	
16	01550-06127	BOLT	1	
17-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
17-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

FIG.322K




FIG.322K (1-K-5) HARNESS (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89L51	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	2	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L30	BRACKET, HARNESS	1	
10	36617-89L20	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00024	CLIP (ID:23)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-06127	BOLT	4	
16	01550-06127	BOLT	1	
17	36617-89L40	BRACKET, HARNESS	1	
18	36991-91J00	CLAMP, EMERGENCY SWITCH LEAD	1	
19-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
19-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

FIG.322L




FIG.322L (1-K-6) HARNESS (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	09407-14403	CLAMP (L:125)	1	
3	09407-14407	CLAMP (L:145)	1	
4	01547-06167	BOLT	2	
5	36610-89L41	HARNESS ASSY, WIRING	1	
6	09481-10501	.FUSE (10A)	1	
7	09481-30501	.FUSE (30A)	1	
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10	09407-14407	CLAMP (L:145)	2	
11	32916-89L00	COVER, CONNECTOR	1	
12	36617-89L10	BRACKET, HARNESS	1	
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L30	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-06127	BOLT	4	
21	01550-06127	BOLT	1	
22	36617-89L40	BRACKET, HARNESS	1	
23	36991-91J00	CLAMP, EMERGENCY SWITCH LEAD	1	

FIG.327A




FIG.327A (1-K-7) PTT SWITCH (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J20	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-99E04	SWITCH ASSY, PTT	1	
4	09116-06202	BOLT (6X25)	2	
5	09169-06062	WASHER	2	

FIG.327B




FIG.327B (1-K-8) PTT SWITCH (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J20	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-94JA2	SWITCH ASSY, PTT	1	
4	37852-94JA0	PLATE, PTT SWITCH	1	
5	09125-05046	SCREW (5X12)	2	
6	29103-93J00	BOLT, PTT SW BRACKET (6X12)	2	
7	09140-05005	NUT	2	
8	09116-06202	BOLT (6X25)	2	
9	09169-06062	WASHER	2	
10	37851-89L00	HOLDER, PTT SWITCH	1	

FIG.327C




FIG.327C (1-K-9) PTT SWITCH (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J20	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-99E04	SWITCH ASSY, PTT	1	
4	09116-06202	BOLT (6X25)	2	
5	09169-06062	WASHER	2	

FIG.327D




FIG.327D (1-K-10) PTT SWITCH (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J20	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-94JA2	SWITCH ASSY, PTT	1	
4	37852-94JA0	PLATE, PTT SWITCH	1	
5	09125-05046	SCREW (5X12)	2	
6	29103-93J00	BOLT, PTT SW BRACKET (6X12)	2	
7	09140-05005	NUT	2	
8	09116-06202	BOLT (6X25)	2	
9	09169-06062	WASHER	2	
10	37851-89L00	HOLDER, PTT SWITCH	1	

FIG.334A




FIG.334A (1-K-11) SENSOR/SWITCH (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G00	SENSOR ENGINE, TEMP	1	
2	37820-80001	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L01	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	37163-89L00	PLUG, STARTING SWITCH HOLE	1	W/MANUAL STARTER
7	37721-89L00	SWITCH ASSY, NEUTRAL	1	
8	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
9	01550-06167	BOLT	1	
10	36616-89L02	HOLDER, CONNECTOR	1	
11	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
12	13650-52G00	SENSOR, INLET AIR TEMP	1	
13	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
14	18590-58M00	SENSOR, MAP	1	
15	01550-06207	BOLT	1	

FIG.334B




FIG.334B (1-K-12) SENSOR/SWITCH (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G00	SENSOR ENGINE, TEMP	1	
2	37820-80001	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-06167	BOLT	1	
9	36616-89L02	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-06207	BOLT	1	

FIG.334C




FIG.334C (1-K-13) SENSOR/SWITCH (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G00	SENSOR ENGINE, TEMP	1	
2	37820-80001	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-06167	BOLT	1	
9	36616-89L02	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-06207	BOLT	1	

FIG.334D




FIG.334D (1-K-14) SENSOR/SWITCH (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G00	SENSOR ENGINE, TEMP	1	
2	37820-80001	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L01	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	37163-89L00	PLUG, STARTING SWITCH HOLE	1	W/MANUAL STARTER
7	37721-89L00	SWITCH ASSY, NEUTRAL	1	
8	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
9	01550-06167	BOLT	1	
10	36616-89L02	HOLDER, CONNECTOR	1	
11	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
12	13650-52G00	SENSOR, INLET AIR TEMP	1	
13	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
14	18590-58M00	SENSOR, MAP	1	
15	01550-06207	BOLT	1	

FIG.334E




FIG.334E (1-K-15) SENSOR/SWITCH (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G00	SENSOR ENGINE, TEMP	1	
2	37820-80001	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-06167	BOLT	1	
9	36616-89L02	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-06207	BOLT	1	

FIG.334F




FIG.334F (1-L-2) SENSOR/SWITCH (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G00	SENSOR ENGINE, TEMP	1	
2	37820-80001	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L01	SWITCH ASSY, STARTER MOTOR	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-06167	BOLT	1	
9	36616-89L02	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-06207	BOLT	1	

FIG.334G




FIG.334G (1-L-3) SENSOR/SWITCH (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G00	SENSOR ENGINE, TEMP	1	
2	37820-80001	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L01	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	37163-89L00	PLUG, STARTING SWITCH HOLE	1	W/MANUAL STARTER
7	37721-89L00	SWITCH ASSY, NEUTRAL	1	
8	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
9	01550-06167	BOLT	1	
10	36616-89L02	HOLDER, CONNECTOR	1	
11	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
12	13650-52G00	SENSOR, INLET AIR TEMP	1	
13	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
14	18590-58M00	SENSOR, MAP	1	
15	01550-06207	BOLT	1	

FIG.334H




FIG.334H (1-L-4) SENSOR/SWITCH (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G00	SENSOR ENGINE, TEMP	1	
2	37820-80001	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L01	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	37163-89L00	PLUG, STARTING SWITCH HOLE	1	W/MANUAL STARTER
7	37721-89L00	SWITCH ASSY, NEUTRAL	1	
8	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
9	01550-06167	BOLT	1	
10	36616-89L02	HOLDER, CONNECTOR	1	
11	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
12	13650-52G00	SENSOR, INLET AIR TEMP	1	
13	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
14	18590-58M00	SENSOR, MAP	1	
15	01550-06207	BOLT	1	

FIG.334J




FIG.334J (1-L-5) SENSOR/SWITCH (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G00	SENSOR ENGINE, TEMP	1	
2	37820-80001	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-06167	BOLT	1	
9	36616-89L02	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-06207	BOLT	1	

FIG.334K




FIG.334K (1-L-6) SENSOR/SWITCH (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G00	SENSOR ENGINE, TEMP	1	
2	37820-80001	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-06167	BOLT	1	
9	36616-89L02	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-06207	BOLT	1	

FIG.334L





FIG.334L (1-L-7) SENSOR/SWITCH (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G00	SENSOR ENGINE, TEMP	1	
2	37820-80001	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L01	SWITCH ASSY, STARTER MOTOR	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-06167	BOLT	1	
9	36616-89L02	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-06207	BOLT	1	

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	41111-89L00-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-90L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J40	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

FIG.335B



DF20A_P01_015_335B
CLAMP BRACKET

FIG.335B (1-L-9) CLAMP BRACKET (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-89L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J40	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

DF20A_P01_015

FIG.335C




FIG.335C (1-L-10) CLAMP BRACKET (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89LA0-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89LA0-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	09205-06021	SPRING PIN (6X25)	2	
4	41211-95J00	SCREW, CLAMP	2	
5	41212-91J00	HANDLE, CLAMP	2	
6	41213-94J01	PLATE, CLAMP	2	
7	41130-94JA1	SHAFT, CLAMP BRKT	1	
8	41135-93JL0	WASHER, CLAMP BRKT SHAFT	1	
9	36894-87D00	LEAD, SWIVEL TO CLAMP	1	
10	36894-87D00	LEAD, PWR TILT TO CLAMP PORT	1	
11	36895-87D01	LEAD, PWR TILT TO CLAMP STBD	1	
12	09125-06063	SCREW (6X10)	5	
13	09159-22006	NUT	1	
14	41221-94JA0	KNOB, TILT STOPPER	1	
15	41222-94JA0	PIN, TILT STOPPER	1	
16	41226-94JA0	BUSH, TILT STOPPER	1	
17	45421-94JA0	PIN, TILT LOCK	2	
18	09116-08128	BOLT (8X40)	2	
19	09205-03004	SPRING PIN (3X20)	1	
20-1	55321-87J00	ANODE, PROTECTION	2	
20-2	55321-87J10	ANODE(MAGNESIUM)	1	OPT
21	09103-06281	BOLT (6X14)	2	
22	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
23	09160-08081	WASHER (8.5X23X1.5)	2	
24	09100-08311	BOLT (8X90)	2	
25	09140-08023-XC0	NUT	2	
26	09160-08170	WASHER (8.5X16X2)	2	
27	69911-91J40	MARK, CLAMP BRACKET	1	
28	41210-89LA0	SCREW SET, CLAMP	1	OPT

FIG.335D





FIG.335D (1-L-11) CLAMP BRACKET (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-90L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J40	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

FIG.335E




DF20A_P01_015_335E
CLAMP BRACKET

FIG.335E (1-L-12) CLAMP BRACKET (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-OEP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-OEP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-89L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J40	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

DF20A_P01_015

FIG.335F



DF20A_P01_015_335F
CLAMP BRACKET

FIG.335F (1-L-13) CLAMP BRACKET (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89LA0-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89LA0-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	09205-06021	SPRING PIN (6X25)	2	
4	41211-95J00	SCREW, CLAMP	2	
5	41212-91J00	HANDLE, CLAMP	2	
6	41213-94J01	PLATE, CLAMP	2	
7	41130-94JA1	SHAFT, CLAMP BRKT	1	
8	41135-93JL0	WASHER, CLAMP BRKT SHAFT	1	
9	36894-87D00	LEAD, SWIVEL TO CLAMP	1	
10	36894-87D00	LEAD, PWR TILT TO CLAMP PORT	1	
11	36895-87D01	LEAD, PWR TILT TO CLAMP STBD	1	
12	09125-06063	SCREW (6X10)	5	
13	09159-22006	NUT	1	
14	41221-94JA0	KNOB, TILT STOPPER	1	
15	41222-94JA0	PIN, TILT STOPPER	1	
16	41226-94JA0	BUSH, TILT STOPPER	1	
17	45421-94JA0	PIN, TILT LOCK	2	
18	09116-08128	BOLT (8X40)	2	
19	09205-03004	SPRING PIN (3X20)	1	
20-1	55321-87J00	ANODE, PROTECTION	2	
20-2	55321-87J10	ANODE(MAGNESIUM)	1	OPT
21	09103-06281	BOLT (6X14)	2	
22	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
23	09160-08081	WASHER (8.5X23X1.5)	2	
24	09100-08311	BOLT (8X90)	2	
25	09140-08023-XC0	NUT	2	
26	09160-08170	WASHER (8.5X16X2)	2	
27	69911-91J40	MARK, CLAMP BRACKET	1	
28	41210-89LA0	SCREW SET, CLAMP	1	OPT

DF20A_P01_015

FIG.335G





FIG.335G (1-L-14) CLAMP BRACKET (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-90L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J40	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	41111-89L00-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-90L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J00	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

FIG.335J




DF20A_P01_015_335J
CLAMP BRACKET

FIG.335J (2-B-2) CLAMP BRACKET (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-89L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J40	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

DF20A_P01_015

FIG.335K



DF20A_P01_015_335K
CLAMP BRACKET

FIG.335K (2-B-3) CLAMP BRACKET (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89LA0-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89LA0-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	09205-06021	SPRING PIN (6X25)	2	
4	41211-95J00	SCREW, CLAMP	2	
5	41212-91J00	HANDLE, CLAMP	2	
6	41213-94J01	PLATE, CLAMP	2	
7	41130-94JA1	SHAFT, CLAMP BRKT	1	
8	41135-93JL0	WASHER, CLAMP BRKT SHAFT	1	
9	36894-87D00	LEAD, SWIVEL TO CLAMP	1	
10	36894-87D00	LEAD, PWR TILT TO CLAMP PORT	1	
11	36895-87D01	LEAD, PWR TILT TO CLAMP STBD	1	
12	09125-06063	SCREW (6X10)	5	
13	09159-22006	NUT	1	
14	41221-94JA0	KNOB, TILT STOPPER	1	
15	41222-94JA0	PIN, TILT STOPPER	1	
16	41226-94JA0	BUSH, TILT STOPPER	1	
17	45421-94JA0	PIN, TILT LOCK	2	
18	09116-08128	BOLT (8X40)	2	
19	09205-03004	SPRING PIN (3X20)	1	
20-1	55321-87J00	ANODE, PROTECTION	2	
20-2	55321-87J10	ANODE(MAGNESIUM)	1	OPT
21	09103-06281	BOLT (6X14)	2	
22	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
23	09160-08081	WASHER (8.5X23X1.5)	2	
24	09100-08311	BOLT (8X90)	2	
25	09140-08023-XC0	NUT	2	
26	09160-08170	WASHER (8.5X16X2)	2	
27	69911-91J40	MARK, CLAMP BRACKET	1	
28	41210-89LA0	SCREW SET, CLAMP	1	OPT

DF20A_P01_015

FIG.335L




FIG.335L (2-B-4) CLAMP BRACKET (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89LA0-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89LA0-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	09205-06021	SPRING PIN (6X25)	2	
4	41211-95J00	SCREW, CLAMP	2	
5	41212-91J00	HANDLE, CLAMP	2	
6	41213-94J01	PLATE, CLAMP	2	
7	41130-94JA1	SHAFT, CLAMP BRKT	1	
8	41135-93JL0	WASHER, CLAMP BRKT SHAFT	1	
9	36894-87D00	LEAD, SWIVEL TO CLAMP	1	
10	36894-87D00	LEAD, PWR TILT TO CLAMP PORT	1	
11	36895-87D01	LEAD, PWR TILT TO CLAMP STBD	1	
12	09125-06063	SCREW (6X10)	5	
13	09159-22006	NUT	1	
14	41221-94JA0	KNOB, TILT STOPPER	1	
15	41222-94JA0	PIN, TILT STOPPER	1	
16	41226-94JA0	BUSH, TILT STOPPER	1	
17	45421-94JA0	PIN, TILT LOCK	2	
18	09116-08128	BOLT (8X40)	2	
19	09205-03004	SPRING PIN (3X20)	1	
20-1	55321-87J00	ANODE, PROTECTION	2	
20-2	55321-87J10	ANODE(MAGNESIUM)	1	OPT
21	09103-06281	BOLT (6X14)	2	
22	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
23	09160-08081	WASHER (8.5X23X1.5)	2	
24	09100-08311	BOLT (8X90)	2	
25	09140-08023-XC0	NUT	2	
26	09160-08170	WASHER (8.5X16X2)	2	
27	69911-91J40	MARK, CLAMP BRACKET	1	
28	41210-89LA0	SCREW SET, CLAMP	1	OPT

FIG.336A





FIG.336A (2-B-5) SWIVEL BRACKET (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43411-89L00	LEVER, STEERING ADJUSTER	1	
28	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
29	43420-89L00	PLATE, STRG ADJ FRICTION	1	

DF20A_P01_015_336B
SWIVEL BRACKET



DF20A_P01_015

DF20A_P01_015

FIG.336B




FIG.336B (2-B-8) SWIVEL BRACKET (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	09159-08059	NUT	2	
31	43759-89L00	HOLDER, DRAIN HOSE	1	
32	09116-06225	BOLT (6X15)	1	

FIG.336C




FIG.336C (2-B-9) SWIVEL BRACKET (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE	3	W/TRANSOM(S)
1-2	22511-99011	NIPPLE	4	W/TRANSOM(L) W/TRANSOM(X)
2-1	43111-89LB0-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89LA0-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-94JA0	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	43411-939L0	PLATE, STEERING ADJUSTER	1	
10	43412-93900	COVER, STEERING ADJUSTER	1	
11	29440-93J00	SPRING, STEERING ADJUSTER	1	
12	09160-08082	WASHER (8.5X16X1.2)	1	
13	09100-08232	BOLT (8X30)	1	
14	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
15	09160-08082	WASHER (8.5X16X1.2)	2	
16	09108-08286	STUD BOLT	2	
17	09159-08059	NUT	2	
18	43759-89L00	HOLDER, DRAIN HOSE	1	
19	09116-06225	BOLT (6X15)	1	
20-1	55321-87J00	ANODE, PROTECTION	1	W/TRANSOM(L) W/TRANSOM(X)
20-2	55321-87J10	ANODE(MAGNESIUM)	1	OPT W/TRANSOM(L) W/TRANSOM(X)
21	09103-06281	BOLT (6X14)	1	W/TRANSOM(L) W/TRANSOM(X)

FIG.336D




FIG.336D (2-B-10) SWIVEL BRACKET (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43411-89L00	LEVER, STEERING ADJUSTER	1	
28	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
29	43420-89L00	PLATE, STRG ADJ FRICTION	1	

FIG.336D





FIG.336D (2-B-11) SWIVEL BRACKET (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	43425-89L00	PLATE, STRG ADJ UPPER	1	
31	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
32	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
33	43516-89J00	WASHER, STEERING ADJUSTER	2	
34	43517-89L00	SPACER, STEERING ADJUSTER	1	
35	09116-06225	BOLT (6X15)	4	
36	09159-08L02	NUT	1	
37	09161-08019	WASHER (8.2X18X1.2)	1	

FIG.336E




DF20A_P01_015_336E
SWIVEL BRACKET

FIG.336E (2-B-12) SWIVEL BRACKET (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
28	09160-08082	WASHER (8.5X16X1.2)	2	
29	09108-08286	STUD BOLT	2	

DF20A_P01_015

FIG.336E



DF20A_P01_015_336E
SWIVEL BRACKET

FIG.336E (2-B-13) SWIVEL BRACKET (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	09159-08059	NUT	2	
31	43759-89L00	HOLDER, DRAIN HOSE	1	
32	09116-06225	BOLT (6X15)	1	

DF20A_P01_015

FIG.336F




FIG.336F (2-B-14) SWIVEL BRACKET (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE	3	W/TRANSOM(S)
1-2	22511-99011	NIPPLE	4	W/TRANSOM(L) W/TRANSOM(X)
2-1	43111-89LB0-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89LA0-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-94JA0	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	43411-939L0	PLATE, STRG ADJUSTER	1	
10	43412-93900	COVER, STEERING ADJUSTER	1	
11	29440-93J00	SPRING, STEERING ADJUSTER	1	
12	09160-08082	WASHER (8.5X16X1.2)	1	
13	09100-08232	BOLT (8X30)	1	
14	43411-89LA0	LEVER, STEERING ADJUSTER	1	
15	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
16	43420-89L00	PLATE, STRG ADJ FRICTION	1	
17	43425-89L00	PLATE, STRG ADJ UPPER	1	
18	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
19	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
20	43516-89J00	WASHER, STEERING ADJUSTER	2	
21	43517-89L00	SPACER, STEERING ADJUSTER	1	
22	09116-06225	BOLT (6X15)	4	
23	09159-08L02	NUT	1	
24	09161-08019	WASHER (8.2X18X1.2)	1	

FIG.336F




FIG.336F (2-B-15) SWIVEL BRACKET (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25-1	55321-87J00	ANODE, PROTECTION	1	W/TRANSOM(L) W/TRANSOM(X)
25-2	55321-87J10	ANODE(MAGNESIUM)	1	OPT W/TRANSOM(L) W/TRANSOM(X)
26	09103-06281	BOLT (6X14)	1	W/TRANSOM(L) W/TRANSOM(X)



FIG.336G




FIG.336G (2-C-2) SWIVEL BRACKET (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43411-89L00	LEVER, STEERING ADJUSTER	1	
28	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
29	43420-89L00	PLATE, STRG ADJ FRICTION	1	

FIG.336H




FIG.336H (2-C-4) SWIVEL BRACKET (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43411-89L00	LEVER, STEERING ADJUSTER	1	
28	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
29	43420-89L00	PLATE, STRG ADJ FRICTION	1	

FIG.336H




FIG.336H (2-C-5) SWIVEL BRACKET (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	43425-89L00	PLATE, STRG ADJ UPPER	1	
31	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
32	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
33	43516-89J00	WASHER, STEERING ADJUSTER	2	
34	43517-89L00	SPACER, STEERING ADJUSTER	1	
35	09116-06225	BOLT (6X15)	4	
36	09159-08L02	NUT	1	
37	09161-08019	WASHER (8.2X18X1.2)	1	

FIG.336J




FIG.336J (2-C-6) SWIVEL BRACKET (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
28	09160-08082	WASHER (8.5X16X1.2)	2	
29	09108-08286	STUD BOLT	2	

FIG.336K




FIG.336K (2-C-8) SWIVEL BRACKET (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE	3	W/TRANSOM(S)
1-2	22511-99011	NIPPLE	4	W/TRANSOM(L) W/TRANSOM(X)
2-1	43111-89LB0-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89LA0-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-94JA0	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	43411-939L0	PLATE, STEERING ADJUSTER	1	
10	43412-93900	COVER, STEERING ADJUSTER	1	
11	29440-93J00	SPRING, STEERING ADJUSTER	1	
12	09160-08082	WASHER (8.5X16X1.2)	1	
13	09100-08232	BOLT (8X30)	1	
14	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
15	09160-08082	WASHER (8.5X16X1.2)	2	
16	09108-08286	STUD BOLT	2	
17	09159-08059	NUT	2	
18	43759-89L00	HOLDER, DRAIN HOSE	1	
19	09116-06225	BOLT (6X15)	1	
20-1	55321-87J00	ANODE, PROTECTION	1	W/TRANSOM(L) W/TRANSOM(X)
20-2	55321-87J10	ANODE(MAGNESIUM)	1	OPT W/TRANSOM(L) W/TRANSOM(X)
21	09103-06281	BOLT (6X14)	1	W/TRANSOM(L) W/TRANSOM(X)

FIG.336L




FIG.336L (2-C-9) SWIVEL BRACKET (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE	3	W/TRANSOM(S)
1-2	22511-99011	NIPPLE	4	W/TRANSOM(L) W/TRANSOM(X)
2-1	43111-89LB0-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89LA0-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-94JA0	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	43411-939L0	PLATE, STRG ADJUSTER	1	
10	43412-93900	COVER, STEERING ADJUSTER	1	
11	29440-93J00	SPRING, STEERING ADJUSTER	1	
12	09160-08082	WASHER (8.5X16X1.2)	1	
13	09100-08232	BOLT (8X30)	1	
14	43411-89LA0	LEVER, STEERING ADJUSTER	1	
15	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
16	43420-89L00	PLATE, STRG ADJ FRICTION	1	
17	43425-89L00	PLATE, STRG ADJ UPPER	1	
18	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
19	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
20	43516-89J00	WASHER, STEERING ADJUSTER	2	
21	43517-89L00	SPACER, STEERING ADJUSTER	1	
22	09116-06225	BOLT (6X15)	4	
23	09159-08L02	NUT	1	
24	09161-08019	WASHER (8.2X18X1.2)	1	

FIG.336L





FIG.336L (2-C-10) SWIVEL BRACKET (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25-1	55321-87J00	ANODE, PROTECTION	1	W/TRANSOM(L) W/TRANSOM(X)
25-2	55321-87J10	ANODE(MAGNESIUM)	1	OPT W/TRANSOM(L) W/TRANSOM(X)
26	09103-06281	BOLT (6X14)	1	W/TRANSOM(L) W/TRANSOM(X)

FIG.338A




DF20A_P01_015_338A
TILT CYLINDER

FIG.338A (2-C-11) TILT CYLINDER (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-89LA0	POWER TILT ASSY	1	
2	48864-89LA0	.MANUAL VALVE	1	
3	48681-87J11	.CIRCLIP	1	
4	48553-88L00	.SEAL WASHER	1	
5	48510-94600	.PUMP ASSY, GEAR	1	
6	48583-95E00	.JOINT, DRIVE	1	
7	31123-89J10	.O RING	1	
8	48572-94J00	.CAP	1	
9	48664-87D00	.O RING	1	
10	31193-94J00	.BAND	1	
11	31192-94J01	.SCREW	1	
12	31281-94J01	.BOLT	2	
13	48582-97E00	.FILTER	1	
14	38100-89LA0	.MOTOR ASSY, PTT	1	
15	48664-87D00	.O RING	2	
16	48121-94JA0	SHAFT, TILT CYL LOWER	1	
17	48321-97E01	SHAFT, TILT CYL UPPER	1	
18	48325-97E00	BUSH	4	
19-1	55321-87J00	ANODE	1	
19-2	55321-87J10	ANODE(MAGNESIUM)	1	OPT
20	09103-06281	BOLT (6X14)	1	
21	09116-08150	BOLT (8X27)	2	
22	09380-12002	SNAP RING	2	
23	09407-14407	CLAMP (L:145)	3	

DF20A_P01_015

FIG.338B




DF20A_P01_015_338B
TILT CYLINDER

FIG.338B (2-C-12) TILT CYLINDER (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-89LA0	POWER TILT ASSY	1	
2	48864-89LA0	.MANUAL VALVE	1	
3	48681-87J11	.CIRCLIP	1	
4	48553-88L00	.SEAL WASHER	1	
5	48510-94600	.PUMP ASSY, GEAR	1	
6	48583-95E00	.JOINT, DRIVE	1	
7	31123-89J10	.O RING	1	
8	48572-94J00	.CAP	1	
9	48664-87D00	.O RING	1	
10	31193-94J00	.BAND	1	
11	31192-94J01	.SCREW	1	
12	31281-94J01	.BOLT	2	
13	48582-97E00	.FILTER	1	
14	38100-89LA0	.MOTOR ASSY, PTT	1	
15	48664-87D00	.O RING	2	
16	48121-94JA0	SHAFT, TILT CYL LOWER	1	
17	48321-97E01	SHAFT, TILT CYL UPPER	1	
18	48325-97E00	BUSH	4	
19-1	55321-87J00	ANODE	1	
19-2	55321-87J10	ANODE(MAGNESIUM)	1	OPT
20	09103-06281	BOLT (6X14)	1	
21	09116-08150	BOLT (8X27)	2	
22	09380-12002	SNAP RING	2	
23	09407-14407	CLAMP (L:145)	3	

DF20A_P01_015

FIG.338C




DF20A_P01_015_338C
TILT CYLINDER

FIG.338C (2-C-13) TILT CYLINDER (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-89LA0	POWER TILT ASSY	1	
2	48864-89LA0	.MANUAL VALVE	1	
3	48681-87J11	.CIRCLIP	1	
4	48553-88L00	.SEAL WASHER	1	
5	48510-94600	.PUMP ASSY, GEAR	1	
6	48583-95E00	.JOINT, DRIVE	1	
7	31123-89J10	.O RING	1	
8	48572-94J00	.CAP	1	
9	48664-87D00	.O RING	1	
10	31193-94J00	.BAND	1	
11	31192-94J01	.SCREW	1	
12	31281-94J01	.BOLT	2	
13	48582-97E00	.FILTER	1	
14	38100-89LA0	.MOTOR ASSY, PTT	1	
15	48664-87D00	.O RING	2	
16	48121-94JA0	SHAFT, TILT CYL LOWER	1	
17	48321-97E01	SHAFT, TILT CYL UPPER	1	
18	48325-97E00	BUSH	4	
19-1	55321-87J00	ANODE	1	
19-2	55321-87J10	ANODE(MAGNESIUM)	1	OPT
20	09103-06281	BOLT (6X14)	1	
21	09116-08150	BOLT (8X27)	2	
22	09380-12002	SNAP RING	2	
23	09407-14407	CLAMP (L:145)	3	

DF20A_P01_015

FIG.338D



DF20A_P01_015_338D
TILT CYLINDER

FIG.338D (2-C-14) TILT CYLINDER (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-89LA0	POWER TILT ASSY	1	
2	48864-89LA0	.MANUAL VALVE	1	
3	48681-87J11	.CIRCLIP	1	
4	48553-88L00	.SEAL WASHER	1	
5	48510-94600	.PUMP ASSY, GEAR	1	
6	48583-95E00	.JOINT, DRIVE	1	
7	31123-89J10	.O RING	1	
8	48572-94J00	.CAP	1	
9	48664-87D00	.O RING	1	
10	31193-94J00	.BAND	1	
11	31192-94J01	.SCREW	1	
12	31281-94J01	.BOLT	2	
13	48582-97E00	.FILTER	1	
14	38100-89LA0	.MOTOR ASSY, PTT	1	
15	48664-87D00	.O RING	2	
16	48121-94JA0	SHAFT, TILT CYL LOWER	1	
17	48321-97E01	SHAFT, TILT CYL UPPER	1	
18	48325-97E00	BUSH	4	
19-1	55321-87J00	ANODE	1	
19-2	55321-87J10	ANODE(MAGNESIUM)	1	OPT
20	09103-06281	BOLT (6X14)	1	
21	09116-08150	BOLT (8X27)	2	
22	09380-12002	SNAP RING	2	
23	09407-14407	CLAMP (L:145)	3	

DF20A_P01_015

FIG.340A




FIG.340A (2-C-15) PTT MOTOR (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-89LA0	MOTOR ASSY, PTT	1	
2	31174-89LA0	.BRACKET	1	
3	31136-94J00	..BRAKER	1	
4	31133-94900	..BRUSH	1	
5	31123-94J01	..O RING	1	
6	33799-97E00	..SEAL, OIL	1	
7	31135-94900	..SPRING	2	
8	09136-05041	..SCREW (5X20)	2	
9	31311-94J00	..ARMATURE	1	

FIG.340B




FIG.340B (2-D-2) PTT MOTOR (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-89LA0	MOTOR ASSY, PTT	1	
2	31174-89LA0	.BRACKET	1	
3	31136-94J00	..BRAKER	1	
4	31133-94900	..BRUSH	1	
5	31123-94J01	..O RING	1	
6	33799-97E00	..SEAL, OIL	1	
7	31135-94900	..SPRING	2	
8	09136-05041	..SCREW (5X20)	2	
9	31311-94J00	..ARMATURE	1	

FIG.340C




FIG.340C (2-D-3) PTT MOTOR (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-89LA0	MOTOR ASSY, PTT	1	
2	31174-89LA0	.BRACKET	1	
3	31136-94J00	..BRAKER	1	
4	31133-94900	..BRUSH	1	
5	31123-94J01	..O RING	1	
6	33799-97E00	..SEAL, OIL	1	
7	31135-94900	..SPRING	2	
8	09136-05041	..SCREW (5X20)	2	
9	31311-94J00	..ARMATURE	1	

FIG.340D




FIG.340D (2-D-4) PTT MOTOR (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-89LA0	MOTOR ASSY, PTT	1	
2	31174-89LA0	.BRACKET	1	
3	31136-94J00	..BRAKER	1	
4	31133-94900	..BRUSH	1	
5	31123-94J01	..O RING	1	
6	33799-97E00	..SEAL, OIL	1	
7	31135-94900	..SPRING	2	
8	09136-05041	..SCREW (5X20)	2	
9	31311-94J00	..ARMATURE	1	

FIG.401A




FIG.401A (2-D-5) ENGINE HOLDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51110-89L02	HOLDER, ENGINE	1	
2	51211-89L00	GASKET, ENGINE HOLDER	1	
3	09116-08151	BOLT (8X30)	3	
4	09202-06023	PIN (6X10)	2	
5	09282-12L04	OIL SEAL (12X25X7)	1	
6	16515-89L10	HOSE, OIL	1	
7	54112-99J01	BOLT, UPR MOUNT (L:123)	2	
8	54113-99JM0	WASHER, UPPER MOUNT BOLT	2	
9	54127-89L00	MOUNT, UPRER SIDE	1	
10	54125-99J00	STOPPER, UPR REVERSE THRUST	2	
11	54130-89L00	MOUNT, UPPER	2	
12	54137-89L00	COVER, UPPER MOUNT	2	
13	09116-08137	BOLT (8X22)	4	
14	09140-10031	NUT	2	
15	01560-08307	BOLT	7	
16	09401-12413	CLIP	1	
17	16520-99J00	STRAINER, OIL	1	
18	09401-13424	CLIP	1	

FIG.405A




FIG.405A (2-D-6) DRIVE SHAFT HOUSING

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17913-93J00	PLUG, WATER	1	
2	17914-93J00	GASKET, WATER PLUG	1	
3-1	52110-89L00-0EP	HOUSING, DRIVE SHAFT (S) (BLACK)	1	W/TRANSOM(S)
3-2	52110-89L10-0EP	HOUSING, DRIVE SHAFT (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
4	43112-99E00	.PIPE, EXHAUST	1	
5	52113-89L00	GASKET, DRIVE SHAFT HOUSING	1	
6	09116-08151	BOLT (8X30)	6	
7	09202-06023	PIN (6X10)	2	
8	09168-12017	GASKET (12X17X1)	1	
9	09248-12009	PLUG (12X18.65)	1	
10	54151-99J00	MOUNT, LOWER THRUST	1	
11	54167-99J01	MOUNT, LOWER SIDE	2	
12	54211-99J01-0EP	COVER, LWR MOUNT STBD (BLACK)	1	
13	54221-99J01-0EP	COVER, LWR MOUNT PORT (BLACK)	1	
14	54213-93901	PIN, KNOCK	2	
15	09116-08154	BOLT (8X40)	2	
16	52131-89L00-0EP	CASE, EXTENSION (BLACK)	1	W/TRANSOM(X)
17	09116-08151	BOLT (8X30)	4	W/TRANSOM(X)
18	09320-13022	BUSH	1	W/TRANSOM(X)

FIG.407A




FIG.407A (2-D-7) GEAR CASE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55100-99J40-0EP	CASE, GEAR (BLACK)	1	
2	09263-17L03	.BEARING (17X24X27.5)	1	
3	09262-25003	.BEARING (25X52X15)	1	
4	09202-06023	PIN (6X10)	2	
5	09116-08151	BOLT (8X30)	4	
6	55321-87J00	ANODE, PROTECTION	1	
7	09103-06281	BOLT (6X14)	1	
8	59178-97J00	GASKET, DRAIN PLUG	2	
9	09248-08001	PLUG (8X7.5)	2	
10	56120-99J40-0EP	HOUSING, PROPELLER SHAFT (BLACK)	1	
11	08110-60050	.BEARING	1	
12	09280-57002	.O RING (D:3.5,ID:65.2)	1	
13	09289-17L02	.OIL SEAL (17X30X6)	2	
14	09116-06227	BOLT (6X20)	2	
15-1	58100-89L00-019	PROPELLER, 3X9-1/4X7 (M701) (BLACK)	1	
15-2	58100-89L20-019	PROPELLER, 3X9-1/4X9 (M930) (BLACK)	1	
15-3	58100-89L30-019	PROPELLER, 3X9-1/4X10 (M1001) (BLACK)	1	
15-4	58100-89L40-019	PROPELLER, 3X9-1/4X11 (M1101) (BLACK)	1	
15-5	58100-89L50-019	PROPELLER, 3X9-1/4X12 (M1201) (BLACK)	1	
15-6	58100-90L40-019	PROPELLER, 3X9-1/4X8 (M821) (BLACK)	1	
15-7	58100-90L50-019	PROPELLER, 3X9-1/4X9 (M911) (BLACK)	1	
15-8	58100-90L60-019	PROPELLER, 3X9-1/4X10 (M1011) (BLACK)	1	
16	58120-89L00	.BUSH, PROPELLER	1	

FIG.407A




FIG.407A (2-D-8) GEAR CASE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	57632-94J00	STOPPER, PROPELLER BUSH	1	
18	09141-12005	NUT	1	
19	09160-12066	WASHER (12.5X22X2.5)	1	
20	09204-02004	PIN	1	
21	55331-99J10	CORE, EXHAUST SEAL	1	
22	55332-99J10	RUBBER, EXHAUST SEAL	1	
23	55321-87J10	ANODE (MAGNESIUM)	1	OPT

FIG.410A




FIG.410A (2-D-9) SIDE COVER (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L00-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L10	SEAL, UPPER MOUNT STBD	1	
18	54145-89L00	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410B




FIG.410B (2-D-10) SIDE COVER (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L00-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L20	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L10	SEAL, UPPER MOUNT STBD	1	
18	54145-89L00	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410C




FIG.410C (2-D-11) SIDE COVER (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L10-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L10-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L30	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L10	SEAL, UPPER MOUNT STBD	1	
18	54145-89L00	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	09403-07308	CLAMP	2	
23	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410D




FIG.410D (2-D-12) SIDE COVER (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L00-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L10	SEAL, UPPER MOUNT STBD	1	
18	54145-89L00	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410E




FIG.410E (2-D-13) SIDE COVER (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L00-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L20	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L10	SEAL, UPPER MOUNT STBD	1	
18	54145-89L00	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410F




FIG.410F (2-D-14) SIDE COVER (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L10-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L10	SEAL, UPPER MOUNT STBD	1	
18	54145-89L00	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	09403-07308	CLAMP	2	
23	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410G




FIG.410G (2-D-15) SIDE COVER (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L00-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L10	SEAL, UPPER MOUNT STBD	1	
18	54145-89L00	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410H




FIG.410H (2-E-2) SIDE COVER (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L00-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L10	SEAL, UPPER MOUNT STBD	1	
18	54145-89L00	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410J




FIG.410J (2-E-3) SIDE COVER (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L00-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L20	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L10	SEAL, UPPER MOUNT STBD	1	
18	54145-89L00	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410K




FIG.410K (2-E-4) SIDE COVER (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L10-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L10-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L30	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L10	SEAL, UPPER MOUNT STBD	1	
18	54145-89L00	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	09403-07308	CLAMP	2	
23	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410L




FIG.410L (2-E-5) SIDE COVER (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L10-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L10	SEAL, UPPER MOUNT STBD	1	
18	54145-89L00	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	09403-07308	CLAMP	2	
23	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.420A




FIG.420A (2-E-6) ENGINE COVER (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-99J10	MARK, EMBLEM REAR (9.9)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L00	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L00	TOOL ASSY	1	
13	99011-89L20-055	MANUAL, OWNER'S	1	
14	68110-89L00	COVER, WEATHER	1	OPT

FIG.420B




FIG.420B (2-E-7) ENGINE COVER (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-99J10	MARK, EMBLEM REAR (9.9)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L00	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L00	TOOL ASSY	1	
13	99011-89L20-055	MANUAL, OWNER'S	1	
14	68110-89L00	COVER, WEATHER	1	OPT

FIG.420C




FIG.420C (2-E-8) ENGINE COVER (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-99J10	MARK, EMBLEM REAR (9.9)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L00	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L00	TOOL ASSY	1	
13	99011-89L20-055	MANUAL, OWNER'S	1	
14	61447-94J00	MARK, EMBLEM POWER TILT	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.420D




FIG.420D (2-E-9) ENGINE COVER (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-94J30	MARK, EMBLEM REAR (15)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L00	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L00	TOOL ASSY	1	
13	99011-89L20-055	MANUAL, OWNER'S	1	
14	68110-89L00	COVER, WEATHER	1	OPT

FIG.420E




FIG.420E (2-E-10) ENGINE COVER (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-94J30	MARK, EMBLEM REAR (15)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L00	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L00	TOOL ASSY	1	
13	99011-89L20-055	MANUAL, OWNER'S	1	
14	68110-89L00	COVER, WEATHER	1	OPT

FIG.420F




FIG.420F (2-E-11) ENGINE COVER (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-94J30	MARK, EMBLEM REAR (15)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L00	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L00	TOOL ASSY	1	
13	99011-89L20-055	MANUAL, OWNER'S	1	
14	61447-94J00	MARK, EMBLEM POWER TILT	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.420G




FIG.420G (2-E-12) ENGINE COVER (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-89L00	MARK, EMBLEM REAR (20)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L00	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L00	TOOL ASSY	1	
13	99011-89L20-055	MANUAL, OWNER'S	1	
14	68110-89L00	COVER, WEATHER	1	OPT

FIG.420H




FIG.420H (2-E-13) ENGINE COVER (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-89L00	MARK, EMBLEM REAR (20)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L00	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L00	TOOL ASSY	1	
13	99011-89L20-055	MANUAL, OWNER'S	1	
14	68110-89L00	COVER, WEATHER	1	OPT

FIG.420J




FIG.420J (2-E-14) ENGINE COVER (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-89L00	MARK, EMBLEM REAR (20)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L00	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L00	TOOL ASSY	1	
13	99011-89L20-055	MANUAL, OWNER'S	1	
14	68110-89L00	COVER, WEATHER	1	OPT

FIG.420K




FIG.420K (2-E-15) ENGINE COVER (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-89L00	MARK, EMBLEM REAR (20)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L00	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L00	TOOL ASSY	1	
13	99011-89L20-055	MANUAL, OWNER'S	1	
14	61447-94J00	MARK, EMBLEM POWER TILT	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.420L




FIG.420L (2-F-2) ENGINE COVER (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-89L00	MARK, EMBLEM REAR (20)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L00	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L00	TOOL ASSY	1	
13	99011-89L20-055	MANUAL, OWNER'S	1	
14	61447-94J00	MARK, EMBLEM POWER TILT	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.442A




FIG.442A (2-F-4) DRAG LINK (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.442B




FIG.442B (2-F-5) DRAG LINK (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.442C




FIG.442C (2-F-6) DRAG LINK (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.442D




FIG.442D (2-F-7) DRAG LINK (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.442E




FIG.442E (2-F-8) DRAG LINK (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	



FIG.444A




FIG.444A (2-F-9) TILLER HANDLE (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-0EP	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-0EP	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L10	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06015	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-0EP	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L00	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444B




FIG.444B (2-F-10) TILLER HANDLE (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-0EP	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-0EP	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L10	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06015	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-0EP	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L00	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444C




FIG.444C (2-F-11) TILLER HANDLE (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-0EP	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-0EP	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L10	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06015	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-0EP	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L00	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444D




FIG.444D (2-F-12) TILLER HANDLE (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-0EP	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-0EP	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L10	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06015	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-0EP	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L00	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444E




FIG.444E (2-F-13) TILLER HANDLE (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-0EP	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-0EP	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L10	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06015	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-0EP	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L00	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444F





FIG.444F (2-F-14) TILLER HANDLE (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-0EP	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-0EP	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L10	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06015	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-0EP	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L00	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.450A




DF20A_P01_015_450A
REMOTE CONTROL

FIG.450A (2-F-15) REMOTE CONTROL (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SWITCH LOCK	1	
9	37826-92J00	..NUT	1	
10	37859-90J00	..SPACER	1	
11	37864-94J10	..CAP, PTT SW	1	
12	38500-93J00	..BUZZER ASSY, WARNING	1	
13	67212-95600	..WASHER	1	
14	67214-92E00	..SCREW (5X10)	1	
15	67220-95630	..PLATE ASSY	1	
16	67223-99E10	..KNOB, BRAKE ADJUST	1	
17	67229-95600	..ROLLER	1	
18	67232-95600	..BUSH	1	
19	67238-87D00	..GEAR, DRIVE	1	

DF20A_P01_015

FIG.450A



DF20A_P01_015_450A
REMOTE CONTROL

FIG.450A (2-G-2) REMOTE CONTROL (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	
52	36620-94J01	.WIRE ASSY,REMOTE CONTROL	1	
53	09481-10501	.FUSE (10A)	1	


DF20A_P01_015

This exploded perspective view illustrates the assembly of a vehicle interior component, possibly a center console or gear shift assembly. The main housing (1) is shown with various mounting points and internal structures. Key components include:

- Electrical Components:** A multi-pin connector (2) is connected to a cable (3) that leads to a control unit (13). A coiled spring cable (10) is also shown. A cable (55) with multiple connectors is shown at the bottom left.
- Mechanical Components:** A large gear or pulley (20) is mounted on a shaft (26). A bracket (30) is attached to the side. A cable (43) is connected to a component (36).
- Fasteners and Hardware:** Numerous screws (e.g., 32, 34, 35, 37, 44, 45), bolts (e.g., 17, 28, 29, 31), and washers (e.g., 14, 15, 16, 18, 19, 21, 22, 23, 24, 25, 27, 38, 39, 40, 41, 42, 46, 47, 48, 49, 50, 51, 52, 53, 54) are shown in their respective assembly positions.
- Other Parts:** A handle or lever (33) is shown on the left. A bracket (3) is shown at the bottom center. A cable (2) is shown at the bottom right.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	67200-93J50	REMOTE CONTROL ASSY	1	
2	36646-93J01	.WIRE ASSY, PTT SW ADAPTER	1	
3	36628-92E00	.GROMMET, WIRE HARNESS	1	
4	37110-93J11	.SWITCH ASSY, IGNITION	1	
5-1	37141-99E00	..KEY (931)	2	
5-2	37141-99E10	..KEY (932)	2	
5-3	37141-99E20	..KEY (933)	2	
5-4	37141-99E30	..KEY (934)	2	
5-5	37141-99E40	..KEY (935)	2	
5-6	37141-99E50	..KEY (936)	2	
5-7	37141-99E60	..KEY (937)	2	
5-8	37141-99E70	..KEY (938)	2	
5-9	37141-99E80	..KEY (939)	2	
5-10	37141-99E90	..KEY (940)	2	
5-11	37141-99EA0	..KEY (941)	2	
5-12	37141-99EB0	..KEY (942)	2	
6	37143-99E00	..CAP, KEY	2	
7	37149-93J00	..CAP CYLINDER BODY	1	
8	37721-93J91	.SWITCH, NEUTRAL	1	
9	37820-93J04	.SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE	1	
11	37826-92J00	..NUT	1	
12	37850-90J05	.SWITCH ASSY, PTT	1	
13	38500-93J90	.BUZZER	1	
14	67212-95600	.WASHER	1	
15	67296-92E11	.SCREW, NEUTRAL SW	2	
16	67220-95630	.PLATE ASSY	1	
17	67223-99E10	.KNOB, BRAKE ADJ	1	
18	67229-95600	.ROLLER	1	
19	67232-95600	.BUSH	1	
20	67238-87D00	.GEAR, DRIVE	1	
21	67241-99E10	.LEVER, FREE THROTTLE	1	

FIG.450B




DF20A_P01_015_450B
REMOTE CONTROL

FIG.450B (2-G-4) REMOTE CONTROL (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	67243-95600	.BUSH	1	
23	67244-95600	.WASHER, WAVE	1	
24	67245-95600	.DRUM, FREE THROTTLE	1	
25	67251-99E20	.LEVER, HANDLE	1	
26	67252-95600	.BUSH	2	
27	67253-95600	.WASHER	1	
28	67255-99E10	.ARM, LOCK	1	
29	67256-95600	.HOLDER, NEUT LOCK	1	
30	67257-99E10	.CAP, LEVER	1	
31	67258-99E00	.BRACKET, LOCK ARM	1	
32	67259-87D00	.SPRING, NEUTRAL ARM	1	
33	67261-99E10	.GRIP	1	
34	67296-94310	.SCREW	1	
35	67264-95600	.WASHER	1	
36	67267-93J00	.COVER, WIRE	1	
37	67273-95600	.SPACER	1	
38	67275-95600	.END, CABLE	2	
39	67292-94300	.E RING	3	
40	67294-95600	.SPACER	3	
41	67296-90J00	.SCREW	5	
42	67296-94300	.SCREW	2	
43	67296-95600	.SCREW	3	
44	67296-95610	.SCREW	2	
45	67297-95600	.WASHER	2	
46	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
47	09100-08232	.BOLT (8X30)	1	
48	09126-05003	.SCREW (5X12)	2	
49	09140-06020	.NUT	3	
50	09160-06104	.WASHER (6.5X24X2)	3	
51	37859-90J00	.SPACER	1	
52	67282-94L00	.DECAL, REMOCON SIDE	1	
53	67284-94L00	.MARK, HANDLE LEVER	1	
54	36620-93J02	WIRE ASSY, REMOTE CONTROL	1	
55	09481-10501	.FUSE (10A)	1	

DF20A_P01_015

FIG.450C




DF20A_P01_015_450C
REMOTE CONTROL

FIG.450C (2-G-5) REMOTE CONTROL (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SWITCH LOCK	1	
9	37826-92J00	..NUT	1	
10	37859-90J00	..SPACER	1	
11	37864-94J10	..CAP, PTT SW	1	
12	38500-93J00	..BUZZER ASSY, WARNING	1	
13	67212-95600	..WASHER	1	
14	67214-92E00	..SCREW (5X10)	1	
15	67220-95630	..PLATE ASSY	1	
16	67223-99E10	..KNOB, BRAKE ADJUST	1	
17	67229-95600	..ROLLER	1	
18	67232-95600	..BUSH	1	
19	67238-87D00	..GEAR, DRIVE	1	

DF20A_P01_015

FIG.450C




DF20A_P01_015_450C
REMOTE CONTROL

FIG.450C (2-G-6) REMOTE CONTROL (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	
52	36620-94J01	WIRE ASSY,REMOTE CONTROL	1	
53	09481-10501	.FUSE (10A)	1	

DF20A_P01_015

FIG.450D




DF20A_P01_015_450D
REMOTE CONTROL

FIG.450D (2-G-7) REMOTE CONTROL (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SWITCH LOCK	1	
9	37826-92J00	..NUT	1	
10	37859-90J00	..SPACER	1	
11	37864-94J10	..CAP, PTT SW	1	
12	38500-93J00	..BUZZER ASSY, WARNING	1	
13	67212-95600	..WASHER	1	
14	67214-92E00	..SCREW (5X10)	1	
15	67220-95630	..PLATE ASSY	1	
16	67223-99E10	..KNOB, BRAKE ADJUST	1	
17	67229-95600	..ROLLER	1	
18	67232-95600	..BUSH	1	
19	67238-87D00	..GEAR, DRIVE	1	

DF20A_P01_015

FIG.450D




DF20A_P01_015_450D
REMOTE CONTROL

FIG.450D (2-G-8) REMOTE CONTROL (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	
52	36620-94J01	WIRE ASSY,REMOTE CONTROL	1	
53	09481-10501	.FUSE (10A)	1	

DF20A_P01_015

FIG.450E




DF20A_P01_015_450E
REMOTE CONTROL

FIG.450E (2-G-9) REMOTE CONTROL (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J50	REMOTE CONTROL ASSY	1	
2	36646-93J01	..WIRE ASSY, PTT SW ADAPTER	1	
3	36628-92E00	..GROMMET, WIRE HARNESS	1	
4	37110-93J11	..SWITCH ASSY, IGNITION	1	
5-1	37141-99E00	..KEY (931)	2	
5-2	37141-99E10	..KEY (932)	2	
5-3	37141-99E20	..KEY (933)	2	
5-4	37141-99E30	..KEY (934)	2	
5-5	37141-99E40	..KEY (935)	2	
5-6	37141-99E50	..KEY (936)	2	
5-7	37141-99E60	..KEY (937)	2	
5-8	37141-99E70	..KEY (938)	2	
5-9	37141-99E80	..KEY (939)	2	
5-10	37141-99E90	..KEY (940)	2	
5-11	37141-99EA0	..KEY (941)	2	
5-12	37141-99EB0	..KEY (942)	2	
6	37143-99E00	..CAP, KEY	2	
7	37149-93J00	..CAP CYLINDER BODY	1	
8	37721-93J91	..SWITCH, NEUTRAL	1	
9	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE	1	
11	37826-92J00	..NUT	1	
12	37850-90J05	..SWITCH ASSY, PTT	1	
13	38500-93J90	..BUZZER	1	
14	67212-95600	..WASHER	1	
15	67296-92E11	..SCREW, NEUTRAL SW	2	
16	67220-95630	..PLATE ASSY	1	
17	67223-99E10	..KNOB, BRAKE ADJ	1	
18	67229-95600	..ROLLER	1	
19	67232-95600	..BUSH	1	
20	67238-87D00	..GEAR, DRIVE	1	
21	67241-99E10	..LEVER, FREE THROTTLE	1	

DF20A_P01_015

FIG.450E



DF20A_P01_015_450E
REMOTE CONTROL

FIG.450E (2-G-10) REMOTE CONTROL (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	67243-95600	.BUSH	1	
23	67244-95600	.WASHER, WAVE	1	
24	67245-95600	.DRUM, FREE THROTTLE	1	
25	67251-99E20	.LEVER, HANDLE	1	
26	67252-95600	.BUSH	2	
27	67253-95600	.WASHER	1	
28	67255-99E10	.ARM, LOCK	1	
29	67256-95600	.HOLDER, NEUT LOCK	1	
30	67257-99E10	.CAP, LEVER	1	
31	67258-99E00	.BRACKET, LOCK ARM	1	
32	67259-87D00	.SPRING, NEUTRAL ARM	1	
33	67261-99E10	.GRIP	1	
34	67296-94310	.SCREW	1	
35	67264-95600	.WASHER	1	
36	67267-93J00	.COVER, WIRE	1	
37	67273-95600	.SPACER	1	
38	67275-95600	.END, CABLE	2	
39	67292-94300	.E RING	3	
40	67294-95600	.SPACER	3	
41	67296-90J00	.SCREW	5	
42	67296-94300	.SCREW	2	
43	67296-95600	.SCREW	3	
44	67296-95610	.SCREW	2	
45	67297-95600	.WASHER	2	
46	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
47	09100-08232	.BOLT (8X30)	1	
48	09126-05003	.SCREW (5X12)	2	
49	09140-06020	.NUT	3	
50	09160-06104	.WASHER (6.5X24X2)	3	
51	37859-90J00	.SPACER	1	
52	67282-94L00	.DECAL, REMOCON SIDE	1	
53	67284-94L00	.MARK, HANDLE LEVER	1	
54	36620-93J02	WIRE ASSY, REMOTE CONTROL	1	
55	09481-10501	.FUSE (10A)	1	

DF20A_P01_015

FIG.502A




FIG.502A (2-G-11) OPT:METER (1) (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-88L04	KIT, 4 IN MULTI GAUGE	1	
2	34200-88L02	.GAUGE ASSY, 4 IN MULTI	1	
3	34922-88L03	.UNIT, INTERFACE	1	
4	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
5	36665-88L00	.UNIT, RESISTOR FEMALE	1	
6	36665-88L10	.UNIT, RESISTOR MALE	1	
7	34011-89L02	KIT, 2 IN MULTI GAUGE	1	
8	34800-88L01	.GAUGE ASSY, 2 IN MULTI	1	
9	34922-88L03	.UNIT, INTERFACE	1	
10	36662-88L00	.WIRE, 25 EXTENSION	1	
11	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
12	36665-88L00	.UNIT, RESISTOR FEMALE	1	
13	36665-88L10	.UNIT, RESISTOR MALE	1	
14	36660-89L01	.SET, ENG TO INTERFACE WIRE	1	
15	29404-93J10	..CLAMP	1	
16	09407-14407	..CLAMP (L:145)	4	
17	36682-92E00	WIRE, TRIM METER	1	
18-1	36663-98J00	HARNESS, ACTIVE HUB POWER	1	2.5M
18-2	36663-98J10	HARNESS, ACTIVE HUB POWER	1	6M
19	09481-05501	.FUSE (5A)	1	
20-1	34500-93J00	METER ASSY, HOUR	1	BLACK
20-2	34500-93J11	METER ASSY, HOUR	1	WHITE
21	09471-12103	.BULB (12V,3W,T6.5)	1	
22	36615-96300	.TERMINAL	4	

FIG.502A





FIG.502A (2-G-12) OPT:METER (1) (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23-1	34600-93J00	METER ASSY, VOLTAGE	1	BLACK
23-2	34600-93J11	METER ASSY, VOLTAGE	1	WHITE
24	09471-12103	.BULB (12V,3W,T6.5)	1	
25	36615-96300	.TERMINAL	4	
26-1	34100-93J20	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
26-2	34100-93J31	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
26-3	34100-93J40	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
26-4	34100-93J51	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
27	09471-12028	.BULB (12V,3.4W)	1	
28	34191-92E00	.TUBE	1	
29	09407-14407	.CLAMP (L:145)	2	
30	36615-96300	.TERMINAL, RESIN	2	
31	34190-95500	SENDER ASSY, SPEEDOMETER	1	
32	03112-06303	.SCREW	2	
33	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
34-1	34200-93J20	TACHOMETER ASSY	1	BLACK
34-2	34200-93J32	TACHOMETER ASSY	1	WHITE
35-1	09471-12028	.BULB (12V,3.4W)	1	
36-1	34300-93J00	GAUGE ASSY, FUEL	1	BLACK
36-2	34300-93J11	GAUGE ASSY, FUEL	1	WHITE
37	34310-92E00	.LEAD, FUEL GAUGE	1	
38	34360-92E00	.ADAPTER, FUEL GAUGE	1	
39	09471-12103	.BULB (12V,3W,T6.5)	1	
40	36615-96300	.TERMINAL	5	

FIG.502B



DF20A_P01_015_502B
OPT:METER (1)

FIG.502B (2-G-13) OPT:METER (1) (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-88L04	KIT, 4 IN MULTI GAUGE	1	
2	34200-88L02	.GAUGE ASSY, 4 IN MULTI	1	
3	34922-88L03	.UNIT, INTERFACE	1	
4	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
5	36665-88L00	.UNIT, RESISTOR FEMALE	1	
6	36665-88L10	.UNIT, RESISTOR MALE	1	
7	34011-89L02	KIT, 2 IN MULTI GAUGE	1	
8	34800-88L01	.GAUGE ASSY, 2 IN MULTI	1	
9	34922-88L03	.UNIT, INTERFACE	1	
10	36662-88L00	.WIRE, 25 EXTENSION	1	
11	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
12	36665-88L00	.UNIT, RESISTOR FEMALE	1	
13	36665-88L10	.UNIT, RESISTOR MALE	1	
14	36660-89L01	.SET, ENG TO INTERFACE WIRE	1	
15	29404-93J10	..CLAMP	1	
16	09407-14407	..CLAMP (L:145)	4	
17	36682-92E00	WIRE, TRIM METER	1	
18-1	36663-98J00	HARNESS, ACTIVE HUB POWER	1	2.5M
18-2	36663-98J10	HARNESS, ACTIVE HUB POWER	1	6M
19	09481-05501	.FUSE (5A)	1	
20-1	34500-93J00	METER ASSY, HOUR	1	BLACK
20-2	34500-93J11	METER ASSY, HOUR	1	WHITE
21	09471-12103	.BULB (12V,3W,T6.5)	1	
22	36615-96300	.TERMINAL	4	

DF20A_P01_015

FIG.502B




FIG.502B (2-G-14) OPT:METER (1) (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23-1	34600-93J00	METER ASSY, VOLTAGE	1	BLACK
23-2	34600-93J11	METER ASSY, VOLTAGE	1	WHITE
24	09471-12103	.BULB (12V,3W,T6.5)	1	
25	36615-96300	.TERMINAL	4	
26-1	34100-93J20	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
26-2	34100-93J31	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
26-3	34100-93J40	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
26-4	34100-93J51	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
27	09471-12028	.BULB (12V,3.4W)	1	
28	34191-92E00	.TUBE	1	
29	09407-14407	.CLAMP (L:145)	2	
30	36615-96300	.TERMINAL, RESIN	2	
31	34190-95500	SENDER ASSY, SPEEDOMETER	1	
32	03112-06303	.SCREW	2	
33	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
34-1	34200-93J20	TACHOMETER ASSY	1	BLACK
34-2	34200-93J32	TACHOMETER ASSY	1	WHITE
35-1	09471-12028	.BULB (12V,3.4W)	1	
36-1	34300-93J00	GAUGE ASSY, FUEL	1	BLACK
36-2	34300-93J11	GAUGE ASSY, FUEL	1	WHITE
37	34310-92E00	.LEAD, FUEL GAUGE	1	
38	34360-92E00	.ADAPTER, FUEL GAUGE	1	
39	09471-12103	.BULB (12V,3W,T6.5)	1	
40	36615-96300	.TERMINAL	5	

FIG.502C




FIG.502C (2-G-15) OPT:METER (1) (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-88L04	KIT, 4 IN MULTI GAUGE	1	
2	34200-88L02	.GAUGE ASSY, 4 IN MULTI	1	
3	34922-88L03	.UNIT, INTERFACE	1	
4	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
5	36665-88L00	.UNIT, RESISTOR FEMALE	1	
6	36665-88L10	.UNIT, RESISTOR MALE	1	
7	34011-89L02	KIT, 2 IN MULTI GAUGE	1	
8	34800-88L01	.GAUGE ASSY, 2 IN MULTI	1	
9	34922-88L03	.UNIT, INTERFACE	1	
10	36662-88L00	.WIRE, 25 EXTENSION	1	
11	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
12	36665-88L00	.UNIT, RESISTOR FEMALE	1	
13	36665-88L10	.UNIT, RESISTOR MALE	1	
14	36660-89L01	.SET, ENG TO INTERFACE WIRE	1	
15	29404-93J10	..CLAMP	1	
16	09407-14407	..CLAMP (L:145)	4	
17	36682-92E00	WIRE, TRIM METER	1	
18-1	36663-98J00	HARNESS, ACTIVE HUB POWER	1	2.5M
18-2	36663-98J10	HARNESS, ACTIVE HUB POWER	1	6M
19	09481-05501	.FUSE (5A)	1	
20-1	34500-93J00	METER ASSY, HOUR	1	BLACK
20-2	34500-93J11	METER ASSY, HOUR	1	WHITE
21	09471-12103	.BULB (12V,3W,T6.5)	1	
22	36615-96300	.TERMINAL	4	

FIG.502C




FIG.502C (2-H-2) OPT:METER (1) (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23-1	34600-93J00	METER ASSY, VOLTAGE	1	BLACK
23-2	34600-93J11	METER ASSY, VOLTAGE	1	WHITE
24	09471-12103	.BULB (12V,3W,T6.5)	1	
25	36615-96300	.TERMINAL	4	
26-1	34100-93J20	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
26-2	34100-93J31	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
26-3	34100-93J40	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
26-4	34100-93J51	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
27	09471-12028	.BULB (12V,3.4W)	1	
28	34191-92E00	.TUBE	1	
29	09407-14407	.CLAMP (L:145)	2	
30	36615-96300	.TERMINAL, RESIN	2	
31	34190-95500	SENDER ASSY, SPEEDOMETER	1	
32	03112-06303	.SCREW	2	
33	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
34-1	34200-93J20	TACHOMETER ASSY	1	BLACK
34-2	34200-93J32	TACHOMETER ASSY	1	WHITE
35-1	09471-12028	.BULB (12V,3.4W)	1	
36-1	34300-93J00	GAUGE ASSY, FUEL	1	BLACK
36-2	34300-93J11	GAUGE ASSY, FUEL	1	WHITE
37	34310-92E00	.LEAD, FUEL GAUGE	1	
38	34360-92E00	.ADAPTER, FUEL GAUGE	1	
39	09471-12103	.BULB (12V,3W,T6.5)	1	
40	36615-96300	.TERMINAL	5	

FIG.502D




FIG.502D (2-H-3) OPT:METER (1) (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-88L04	KIT, 4 IN MULTI GAUGE	1	
2	34200-88L02	.GAUGE ASSY, 4 IN MULTI	1	
3	34922-88L03	.UNIT, INTERFACE	1	
4	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
5	36665-88L00	.UNIT, RESISTOR FEMALE	1	
6	36665-88L10	.UNIT, RESISTOR MALE	1	
7	34011-89L02	KIT, 2 IN MULTI GAUGE	1	
8	34800-88L01	.GAUGE ASSY, 2 IN MULTI	1	
9	34922-88L03	.UNIT, INTERFACE	1	
10	36662-88L00	.WIRE, 25 EXTENSION	1	
11	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
12	36665-88L00	.UNIT, RESISTOR FEMALE	1	
13	36665-88L10	.UNIT, RESISTOR MALE	1	
14	36660-89L01	.SET, ENG TO INTERFACE WIRE	1	
15	29404-93J10	..CLAMP	1	
16	09407-14407	..CLAMP (L:145)	4	
17	36682-92E00	WIRE, TRIM METER	1	
18-1	36663-98J00	HARNESS, ACTIVE HUB POWER	1	2.5M
18-2	36663-98J10	HARNESS, ACTIVE HUB POWER	1	6M
19	09481-05501	.FUSE (5A)	1	
20-1	34500-93J00	METER ASSY, HOUR	1	BLACK
20-2	34500-93J11	METER ASSY, HOUR	1	WHITE
21	09471-12103	.BULB (12V,3W,T6.5)	1	
22	36615-96300	.TERMINAL	4	

FIG.502D





FIG.502D (2-H-4) OPT:METER (1) (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23-1	34600-93J00	METER ASSY, VOLTAGE	1	BLACK
23-2	34600-93J11	METER ASSY, VOLTAGE	1	WHITE
24	09471-12103	.BULB (12V,3W,T6.5)	1	
25	36615-96300	.TERMINAL	4	
26-1	34100-93J20	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
26-2	34100-93J31	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
26-3	34100-93J40	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
26-4	34100-93J51	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
27	09471-12028	.BULB (12V,3.4W)	1	
28	34191-92E00	.TUBE	1	
29	09407-14407	.CLAMP (L:145)	2	
30	36615-96300	.TERMINAL, RESIN	2	
31	34190-95500	SENDER ASSY, SPEEDOMETER	1	
32	03112-06303	.SCREW	2	
33	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
34-1	34200-93J20	TACHOMETER ASSY	1	BLACK
34-2	34200-93J32	TACHOMETER ASSY	1	WHITE
35-1	09471-12028	.BULB (12V,3.4W)	1	
36-1	34300-93J00	GAUGE ASSY, FUEL	1	BLACK
36-2	34300-93J11	GAUGE ASSY, FUEL	1	WHITE
37	34310-92E00	.LEAD, FUEL GAUGE	1	
38	34360-92E00	.ADAPTER, FUEL GAUGE	1	
39	09471-12103	.BULB (12V,3W,T6.5)	1	
40	36615-96300	.TERMINAL	5	

FIG.502E



DF20A_P01_015_502E
OPT:METER (1)

FIG.502E (2-H-5) OPT:METER (1) (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-88L04	KIT, 4 IN MULTI GAUGE	1	
2	34200-88L02	.GAUGE ASSY, 4 IN MULTI	1	
3	34922-88L03	.UNIT, INTERFACE	1	
4	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
5	36665-88L00	.UNIT, RESISTOR FEMALE	1	
6	36665-88L10	.UNIT, RESISTOR MALE	1	
7	34011-89L02	KIT, 2 IN MULTI GAUGE	1	
8	34800-88L01	.GAUGE ASSY, 2 IN MULTI	1	
9	34922-88L03	.UNIT, INTERFACE	1	
10	36662-88L00	.WIRE, 25 EXTENSION	1	
11	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
12	36665-88L00	.UNIT, RESISTOR FEMALE	1	
13	36665-88L10	.UNIT, RESISTOR MALE	1	
14	36660-89L01	.SET, ENG TO INTERFACE WIRE	1	
15	29404-93J10	..CLAMP	1	
16	09407-14407	..CLAMP (L:145)	4	
17	36682-92E00	WIRE, TRIM METER	1	
18-1	36663-98J00	HARNESS, ACTIVE HUB POWER	1	2.5M
18-2	36663-98J10	HARNESS, ACTIVE HUB POWER	1	6M
19	09481-05501	.FUSE (5A)	1	
20-1	34500-93J00	METER ASSY, HOUR	1	BLACK
20-2	34500-93J11	METER ASSY, HOUR	1	WHITE
21	09471-12103	.BULB (12V,3W,T6.5)	1	
22	36615-96300	.TERMINAL	4	

DF20A_P01_015

FIG.502E




FIG.502E (2-H-6) OPT:METER (1) (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23-1	34600-93J00	METER ASSY, VOLTAGE	1	BLACK
23-2	34600-93J11	METER ASSY, VOLTAGE	1	WHITE
24	09471-12103	.BULB (12V,3W,T6.5)	1	
25	36615-96300	.TERMINAL	4	
26-1	34100-93J20	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
26-2	34100-93J31	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
26-3	34100-93J40	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
26-4	34100-93J51	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
27	09471-12028	.BULB (12V,3.4W)	1	
28	34191-92E00	.TUBE	1	
29	09407-14407	.CLAMP (L:145)	2	
30	36615-96300	.TERMINAL, RESIN	2	
31	34190-95500	SENDER ASSY, SPEEDOMETER	1	
32	03112-06303	.SCREW	2	
33	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
34-1	34200-93J20	TACHOMETER ASSY	1	BLACK
34-2	34200-93J32	TACHOMETER ASSY	1	WHITE
35-1	09471-12028	.BULB (12V,3.4W)	1	
36-1	34300-93J00	GAUGE ASSY, FUEL	1	BLACK
36-2	34300-93J11	GAUGE ASSY, FUEL	1	WHITE
37	34310-92E00	.LEAD, FUEL GAUGE	1	
38	34360-92E00	.ADAPTER, FUEL GAUGE	1	
39	09471-12103	.BULB (12V,3W,T6.5)	1	
40	36615-96300	.TERMINAL	5	

FIG.503A




FIG.503A (2-H-7) OPT:METER (2) (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-87L00	KIT, SINGLE GAUGE	1	
2	34200-87L12	.GAUGE ASSY, MULTI	1	
3	34211-87L00	..COVER, FRONT	1	
4	36661-87L00	.ADAPTER, GAUGE	1	
5	36615-96300	..TERMINAL, RESIN	5	
6	36663-98J10	.HARNESS,ACTIVE HUB PWR (6M)	1	
7	09481-05501	..FUSE (5A)	1	
8	36990-87D00	.TERMINAL & SLEEVE SET	1	
9	39950-87L00	.MODULE ASSY, GPS RECEIVER	1	
10	34011-87L10	KIT, DUAL GAUGE	1	
11	34200-87L12	.GAUGE ASSY, MULTI	2	
12	34211-87L00	..COVER, FRONT	2	
13	36661-87L00	ADAPTER, GAUGE	2	
14	36615-96300	..TERMINAL, RESIN	10	
15	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
16	36663-98J10	.HARNESS,ACTIVE HUB PWR (6M)	1	
17	09481-05501	..FUSE (5A)	1	
18	36664-88L00	.CONNECTOR, BRANCH	3	
19	36665-87L00	ADAPTER, GAUGE FOR MULTI	1	
20	36665-88L00	.UNIT, RESISTOR FEMALE	1	
21	36665-88L10	.UNIT, RESISTOR MALE	1	
22	36666-87L00	.WIRE, NETWORK	2	
23	36990-87D00	.TERMINAL & SLEEVE SET	1	
24	39950-87L00	.MODULE ASSY, GPS RECEIVER	1	
25	34011-87L40	KIT, SNGL GAUGE & DUAL STATION	1	
26	34200-87L12	.GAUGE ASSY, MULTI	1	
27	34211-87L00	..COVER, FRONT	1	
28	36662-88L00	.WIRE, 25 EXTENSION	1	
29	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
30	36664-87L00	ADAPTER, GAUGE FOR DUAL	1	
31	36664-88L00	.CONNECTOR, BRANCH	3	
32	36665-87L00	ADAPTER, GAUGE FOR MULTI	1	
33	36665-88L00	.UNIT, RESISTOR FEMALE	1	
34	36665-88L10	.UNIT, RESISTOR MALE	1	
35	36666-87L00	.WIRE, NETWORK	2	
36	36682-92E00	.WIRE, TRIM METER EXT (L:6500)	1	

FIG.503A




FIG.503A (2-H-8) OPT:METER (2) (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
37	34011-87L50	KIT, DUAL GAUGE & DUAL STATION	1	
38	34200-87L12	.GAUGE ASSY, MULTI	2	
39	34211-87L00	..COVER, FRONT	2	
40	36662-88L00	.WIRE, 25 EXTENSION	1	
41	36664-87L00	ADAPTER, GAUGE FOR DUAL	2	
42	36664-88L00	.CONNECTOR, BRANCH	2	
43	36666-87L00	.WIRE, NETWORK	2	
44	36682-92E00	.WIRE, TRIM METER EXT (L-6500)	2	

FIG.503B




FIG.503B (2-H-9) OPT:METER (2) (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-87L00	KIT, SINGLE GAUGE	1	
2	34200-87L12	.GAUGE ASSY, MULTI	1	
3	34211-87L00	..COVER, FRONT	1	
4	36661-87L00	.ADAPTER, GAUGE	1	
5	36615-96300	..TERMINAL, RESIN	5	
6	36663-98J10	.HARNESS,ACTIVE HUB PWR (6M)	1	
7	09481-05501	..FUSE (5A)	1	
8	36990-87D00	.TERMINAL & SLEEVE SET	1	
9	39950-87L00	.MODULE ASSY, GPS RECEIVER	1	
10	34011-87L10	KIT, DUAL GAUGE	1	
11	34200-87L12	.GAUGE ASSY, MULTI	2	
12	34211-87L00	..COVER, FRONT	2	
13	36661-87L00	ADAPTER, GAUGE	2	
14	36615-96300	..TERMINAL, RESIN	10	
15	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
16	36663-98J10	.HARNESS,ACTIVE HUB PWR (6M)	1	
17	09481-05501	..FUSE (5A)	1	
18	36664-88L00	.CONNECTOR, BRANCH	3	
19	36665-87L00	ADAPTER, GAUGE FOR MULTI	1	
20	36665-88L00	.UNIT, RESISTOR FEMALE	1	
21	36665-88L10	.UNIT, RESISTOR MALE	1	
22	36666-87L00	.WIRE, NETWORK	2	
23	36990-87D00	.TERMINAL & SLEEVE SET	1	
24	39950-87L00	.MODULE ASSY, GPS RECEIVER	1	
25	34011-87L40	KIT, SNGL GAUGE & DUAL STATION	1	
26	34200-87L12	.GAUGE ASSY, MULTI	1	
27	34211-87L00	..COVER, FRONT	1	
28	36662-88L00	.WIRE, 25 EXTENSION	1	
29	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
30	36664-87L00	ADAPTER, GAUGE FOR DUAL	1	
31	36664-88L00	.CONNECTOR, BRANCH	3	
32	36665-87L00	ADAPTER, GAUGE FOR MULTI	1	
33	36665-88L00	.UNIT, RESISTOR FEMALE	1	
34	36665-88L10	.UNIT, RESISTOR MALE	1	
35	36666-87L00	.WIRE, NETWORK	2	
36	36682-92E00	.WIRE, TRIM METER EXT (L:6500)	1	

FIG.503B








FIG.503B (2-H-10) OPT:METER (2) (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
37	34011-87L50	KIT, DUAL GAUGE & DUAL STATION	1	
38	34200-87L12	.GAUGE ASSY, MULTI	2	
39	34211-87L00	..COVER, FRONT	2	
40	36662-88L00	.WIRE, 25 EXTENSION	1	
41	36664-87L00	ADAPTER, GAUGE FOR DUAL	2	
42	36664-88L00	.CONNECTOR, BRANCH	2	
43	36666-87L00	.WIRE, NETWORK	2	
44	36682-92E00	.WIRE, TRIM METER EXT (L-6500)	2	

FIG.503C



DF20A_P01_015.503C
OPT:METER (2)

FIG.503C (2-H-11) OPT:METER (2) (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-87L00	KIT, SINGLE GAUGE	1	
2	34200-87L12	.GAUGE ASSY, MULTI	1	
3	34211-87L00	..COVER, FRONT	1	
4	36661-87L00	.ADAPTER, GAUGE	1	
5	36615-96300	..TERMINAL, RESIN	5	
6	36663-98J10	.HARNESS,ACTIVE HUB PWR (6M)	1	
7	09481-05501	..FUSE (5A)	1	
8	36990-87D00	.TERMINAL & SLEEVE SET	1	
9	39950-87L00	.MODULE ASSY, GPS RECEIVER	1	
10	34011-87L10	KIT, DUAL GAUGE	1	
11	34200-87L12	.GAUGE ASSY, MULTI	2	
12	34211-87L00	..COVER, FRONT	2	
13	36661-87L00	ADAPTER, GAUGE	2	
14	36615-96300	..TERMINAL, RESIN	10	
15	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
16	36663-98J10	.HARNESS,ACTIVE HUB PWR (6M)	1	
17	09481-05501	..FUSE (5A)	1	
18	36664-88L00	.CONNECTOR, BRANCH	3	
19	36665-87L00	ADAPTER, GAUGE FOR MULTI	1	
20	36665-88L00	.UNIT, RESISTOR FEMALE	1	
21	36665-88L10	.UNIT, RESISTOR MALE	1	
22	36666-87L00	.WIRE, NETWORK	2	
23	36990-87D00	.TERMINAL & SLEEVE SET	1	
24	39950-87L00	.MODULE ASSY, GPS RECEIVER	1	
25	34011-87L40	KIT, SNGL GAUGE & DUAL STATION	1	
26	34200-87L12	.GAUGE ASSY, MULTI	1	
27	34211-87L00	..COVER, FRONT	1	
28	36662-88L00	.WIRE, 25 EXTENSION	1	
29	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
30	36664-87L00	ADAPTER, GAUGE FOR DUAL	1	
31	36664-88L00	.CONNECTOR, BRANCH	3	
32	36665-87L00	ADAPTER, GAUGE FOR MULTI	1	
33	36665-88L00	.UNIT, RESISTOR FEMALE	1	
34	36665-88L10	.UNIT, RESISTOR MALE	1	
35	36666-87L00	.WIRE, NETWORK	2	
36	36682-92E00	.WIRE, TRIM METER EXT (L:6500)	1	

DF20A_P01_015

FIG.503C




FIG.503C (2-H-12) OPT:METER (2) (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
37	34011-87L50	KIT, DUAL GAUGE & DUAL STATION	1	
38	34200-87L12	.GAUGE ASSY, MULTI	2	
39	34211-87L00	..COVER, FRONT	2	
40	36662-88L00	.WIRE, 25 EXTENSION	1	
41	36664-87L00	ADAPTER, GAUGE FOR DUAL	2	
42	36664-88L00	.CONNECTOR, BRANCH	2	
43	36666-87L00	.WIRE, NETWORK	2	
44	36682-92E00	.WIRE, TRIM METER EXT (L-6500)	2	

FIG.503D




FIG.503D (2-H-13) OPT:METER (2) (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-87L00	KIT, SINGLE GAUGE	1	
2	34200-87L12	.GAUGE ASSY, MULTI	1	
3	34211-87L00	..COVER, FRONT	1	
4	36661-87L00	.ADAPTER, GAUGE	1	
5	36615-96300	..TERMINAL, RESIN	5	
6	36663-98J10	.HARNESS,ACTIVE HUB PWR (6M)	1	
7	09481-05501	..FUSE (5A)	1	
8	36990-87D00	.TERMINAL & SLEEVE SET	1	
9	39950-87L00	.MODULE ASSY, GPS RECEIVER	1	
10	34011-87L10	KIT, DUAL GAUGE	1	
11	34200-87L12	.GAUGE ASSY, MULTI	2	
12	34211-87L00	..COVER, FRONT	2	
13	36661-87L00	ADAPTER, GAUGE	2	
14	36615-96300	..TERMINAL, RESIN	10	
15	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
16	36663-98J10	.HARNESS,ACTIVE HUB PWR (6M)	1	
17	09481-05501	..FUSE (5A)	1	
18	36664-88L00	.CONNECTOR, BRANCH	3	
19	36665-87L00	ADAPTER, GAUGE FOR MULTI	1	
20	36665-88L00	.UNIT, RESISTOR FEMALE	1	
21	36665-88L10	.UNIT, RESISTOR MALE	1	
22	36666-87L00	.WIRE, NETWORK	2	
23	36990-87D00	.TERMINAL & SLEEVE SET	1	
24	39950-87L00	.MODULE ASSY, GPS RECEIVER	1	
25	34011-87L40	KIT, SNGL GAUGE & DUAL STATION	1	
26	34200-87L12	.GAUGE ASSY, MULTI	1	
27	34211-87L00	..COVER, FRONT	1	
28	36662-88L00	.WIRE, 25 EXTENSION	1	
29	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
30	36664-87L00	ADAPTER, GAUGE FOR DUAL	1	
31	36664-88L00	.CONNECTOR, BRANCH	3	
32	36665-87L00	ADAPTER, GAUGE FOR MULTI	1	
33	36665-88L00	.UNIT, RESISTOR FEMALE	1	
34	36665-88L10	.UNIT, RESISTOR MALE	1	
35	36666-87L00	.WIRE, NETWORK	2	
36	36682-92E00	.WIRE, TRIM METER EXT (L:6500)	1	

FIG.503D







FIG.503D (2-H-14) OPT:METER (2) (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
37	34011-87L50	KIT, DUAL GAUGE & DUAL STATION	1	
38	34200-87L12	.GAUGE ASSY, MULTI	2	
39	34211-87L00	..COVER, FRONT	2	
40	36662-88L00	.WIRE, 25 EXTENSION	1	
41	36664-87L00	ADAPTER, GAUGE FOR DUAL	2	
42	36664-88L00	.CONNECTOR, BRANCH	2	
43	36666-87L00	.WIRE, NETWORK	2	
44	36682-92E00	.WIRE, TRIM METER EXT (L-6500)	2	

FIG.503E




FIG.503E (2-H-15) OPT:METER (2) (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-87L00	KIT, SINGLE GAUGE	1	
2	34200-87L12	.GAUGE ASSY, MULTI	1	
3	34211-87L00	..COVER, FRONT	1	
4	36661-87L00	.ADAPTER, GAUGE	1	
5	36615-96300	..TERMINAL, RESIN	5	
6	36663-98J10	.HARNESS,ACTIVE HUB PWR (6M)	1	
7	09481-05501	..FUSE (5A)	1	
8	36990-87D00	.TERMINAL & SLEEVE SET	1	
9	39950-87L00	.MODULE ASSY, GPS RECEIVER	1	
10	34011-87L10	KIT, DUAL GAUGE	1	
11	34200-87L12	.GAUGE ASSY, MULTI	2	
12	34211-87L00	..COVER, FRONT	2	
13	36661-87L00	ADAPTER, GAUGE	2	
14	36615-96300	..TERMINAL, RESIN	10	
15	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
16	36663-98J10	.HARNESS,ACTIVE HUB PWR (6M)	1	
17	09481-05501	..FUSE (5A)	1	
18	36664-88L00	.CONNECTOR, BRANCH	3	
19	36665-87L00	ADAPTER, GAUGE FOR MULTI	1	
20	36665-88L00	.UNIT, RESISTOR FEMALE	1	
21	36665-88L10	.UNIT, RESISTOR MALE	1	
22	36666-87L00	.WIRE, NETWORK	2	
23	36990-87D00	.TERMINAL & SLEEVE SET	1	
24	39950-87L00	.MODULE ASSY, GPS RECEIVER	1	
25	34011-87L40	KIT, SNGL GAUGE & DUAL STATION	1	
26	34200-87L12	.GAUGE ASSY, MULTI	1	
27	34211-87L00	..COVER, FRONT	1	
28	36662-88L00	.WIRE, 25 EXTENSION	1	
29	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
30	36664-87L00	ADAPTER, GAUGE FOR DUAL	1	
31	36664-88L00	.CONNECTOR, BRANCH	3	
32	36665-87L00	ADAPTER, GAUGE FOR MULTI	1	
33	36665-88L00	.UNIT, RESISTOR FEMALE	1	
34	36665-88L10	.UNIT, RESISTOR MALE	1	
35	36666-87L00	.WIRE, NETWORK	2	
36	36682-92E00	.WIRE, TRIM METER EXT (L:6500)	1	

FIG.503E




FIG.503E (2-I-2) OPT:METER (2) (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
37	34011-87L50	KIT, DUAL GAUGE & DUAL STATION	1	
38	34200-87L12	.GAUGE ASSY, MULTI	2	
39	34211-87L00	..COVER, FRONT	2	
40	36662-88L00	.WIRE, 25 EXTENSION	1	
41	36664-87L00	ADAPTER, GAUGE FOR DUAL	2	
42	36664-88L00	.CONNECTOR, BRANCH	2	
43	36666-87L00	.WIRE, NETWORK	2	
44	36682-92E00	.WIRE, TRIM METER EXT (L-6500)	2	

FIG.508A




FIG.508A (2-I-3) OPT:REMOTE CONTROL (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY	1	
9	37826-92J00	SWITCH LOCK	1	
10	37859-90J00	..NUT	1	
11	37864-94J10	..SPACER	1	
12	38500-93J00	..CAP, PTT SW	1	
13	67212-95600	..BUZZER ASSY, WARNING	1	
14	67214-92E00	..WASHER	1	
15	67220-95630	..SCREW (5X10)	1	
16	67223-99E10	..PLATE ASSY	1	
17	67229-95600	..KNOB, BRAKE ADJUST	1	
18	67232-95600	..ROLLER	1	
19	67238-87D00	..BUSH	1	
		..GEAR, DRIVE	1	

FIG.508A




FIG.508A (2-I-4) OPT:REMOTE CONTROL (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	

FIG.508B




FIG.508B (2-I-5) OPT:REMOTE CONTROL (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY	1	
9	37826-92J00	SWITCH LOCK	1	
10	37859-90J00	..NUT	1	
11	37864-94J10	..SPACER	1	
12	38500-93J00	..CAP, PTT SW	1	
13	67212-95600	..BUZZER ASSY, WARNING	1	
14	67214-92E00	..WASHER	1	
15	67220-95630	..SCREW (5X10)	1	
16	67223-99E10	..PLATE ASSY	1	
17	67229-95600	..KNOB, BRAKE ADJUST	1	
18	67232-95600	..ROLLER	1	
19	67238-87D00	..BUSH	1	
		..GEAR, DRIVE	1	

FIG.508B




FIG.508B (2-I-6) OPT:REMOTE CONTROL (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	

FIG.508C




FIG.508C (2-I-7) OPT:REMOTE CONTROL (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY	1	
9	37826-92J00	SWITCH LOCK	1	
10	37859-90J00	..NUT	1	
11	37864-94J10	..SPACER	1	
12	38500-93J00	..CAP, PTT SW	1	
13	67212-95600	..BUZZER ASSY, WARNING	1	
14	67214-92E00	..WASHER	1	
15	67220-95630	..SCREW (5X10)	1	
16	67223-99E10	..PLATE ASSY	1	
17	67229-95600	..KNOB, BRAKE ADJUST	1	
18	67232-95600	..ROLLER	1	
19	67238-87D00	..BUSH	1	
		..GEAR, DRIVE	1	

FIG.508C




FIG.508C (2-I-8) OPT:REMOTE CONTROL (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	

FIG.508D




FIG.508D (2-I-9) OPT:REMOTE CONTROL (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY	1	
		SWITCH LOCK		
9	37826-92J00	..NUT	1	
10	37859-90J00	..SPACER	1	
11	37864-94J10	..CAP, PTT SW	1	
12	38500-93J00	..BUZZER ASSY, WARNING	1	
13	67212-95600	..WASHER	1	
14	67214-92E00	..SCREW (5X10)	1	
15	67220-95630	..PLATE ASSY	1	
16	67223-99E10	..KNOB, BRAKE ADJUST	1	
17	67229-95600	..ROLLER	1	
18	67232-95600	..BUSH	1	
19	67238-87D00	..GEAR, DRIVE	1	

FIG.508D





FIG.508D (2-I-10) OPT:REMOTE CONTROL (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	

FIG.513A



DF20A_P01_015_513A
OPT:REMOTE CONTROL PARTS

FIG.513A (2-I-11) OPT:REMOTE CONTROL PARTS (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67130-89L02	PARTS SET, R/CON	1	
2	13513-89L10	.ROD,THROTTLE	1	
3	19120-99J11	.LEVER, THROTTLE CONTROL	1	
4	19122-99J00	.LEVER, INTERLINK THROTTLE NO.2	1	
5	19131-89L00	.CONNECTOR	2	
6	19148-89L10	.LEVER, INTERLINK THROTTLE NO.1	1	
7	19150-89L00	.BRACKET, THROTTLE LEVER	1	
8	19185-99J00	.SPRING,THROTTLE LEVER	1	
9	21110-89L10	.LEVER, CLUTCH	1	
10	23115-89L10	.LINK, CLUTCH LEVER	1	
11	36610-89L22	.HARNESS ASSY, WIRING	1	
12	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
13	09481-10501	..FUSE (10A)	1	
14	09481-30501	..FUSE (30A)	1	
15	37163-89L00	.PLUG, STARTING SWITCH HOLE	1	
16	41130-89L00	.SHAFT, CLAMP BRACKET	1	
17	43755-99J00	.ATTACHMENT, STEERING BRACKET	1	
18	43759-89L00	.HOLDER, DRAIN HOSE	1	
19	09204-01002	.PIN	2	
20	09160-08082	.WASHER (8.5X16X1.2)	2	
21	61124-89L20	.GROMMET, R/CON CABLE	1	
22	67340-89L00	.HOLDER,, R/CON CABLE	1	
23	67467-89J01	.CONNECTOR	2	
24	09108-08286	.STUD BOLT	2	
25	09116-06225	.BOLT (6X15)	1	
26	09159-08059	.NUT	2	
27	09159-22006	.NUT	1	

DF20A_P01_015

FIG.513A





FIG.513A (2-I-12) OPT:REMOTE CONTROL PARTS (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09160-05029	.WASHER (5.5X12X0.8)	2	
29	09160-06046	.WASHER (6.5X20X1.5)	2	
30	09160-06055	.WASHER (7X12X1)	2	
31	09385-06012	.CLIP	2	
32	09407-14407	.CLAMP (L:145)	12	
33	01547-06167	.BOLT	2	
34	01550-06127	.BOLT	2	
35	01550-06167	.BOLT	2	

FIG.513B



DF20A_P01_015_513B
OPT:REMOTE CONTROL PARTS

FIG.513B (2-I-13) OPT:REMOTE CONTROL PARTS (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67130-89L02	PARTS SET, R/CON	1	
2	13513-89L10	.ROD,THROTTLE	1	
3	19120-99J11	.LEVER, THROTTLE CONTROL	1	
4	19122-99J00	.LEVER, INTERLINK THROTTLE NO.2	1	
5	19131-89L00	.CONNECTOR	2	
6	19148-89L10	.LEVER, INTERLINK THROTTLE NO.1	1	
7	19150-89L00	.BRACKET, THROTTLE LEVER	1	
8	19185-99J00	.SPRING,THROTTLE LEVER	1	
9	21110-89L10	.LEVER, CLUTCH	1	
10	23115-89L10	.LINK, CLUTCH LEVER	1	
11	36610-89L22	.HARNESS ASSY, WIRING	1	
12	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
13	09481-10501	..FUSE (10A)	1	
14	09481-30501	..FUSE (30A)	1	
15	37163-89L00	.PLUG, STARTING SWITCH HOLE	1	
16	41130-89L00	.SHAFT, CLAMP BRACKET	1	
17	43755-99J00	.ATTACHMENT, STEERING BRACKET	1	
18	43759-89L00	.HOLDER, DRAIN HOSE	1	
19	09204-01002	.PIN	2	
20	09160-08082	.WASHER (8.5X16X1.2)	2	
21	61124-89L20	.GROMMET, R/CON CABLE	1	
22	67340-89L00	.HOLDER,, R/CON CABLE	1	
23	67467-89J01	.CONNECTOR	2	
24	09108-08286	.STUD BOLT	2	
25	09116-06225	.BOLT (6X15)	1	
26	09159-08059	.NUT	2	
27	09159-22006	.NUT	1	

DF20A_P01_015

FIG.513B





FIG.513B (2-I-14) OPT:REMOTE CONTROL PARTS (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09160-05029	.WASHER (5.5X12X0.8)	2	
29	09160-06046	.WASHER (6.5X20X1.5)	2	
30	09160-06055	.WASHER (7X12X1)	2	
31	09385-06012	.CLIP	2	
32	09407-14407	.CLAMP (L:145)	12	
33	01547-06167	.BOLT	2	
34	01550-06127	.BOLT	2	
35	01550-06167	.BOLT	2	

FIG.513C



DF20A_P01_015_513C
OPT:REMOTE CONTROL PARTS

FIG.513C (2-I-15) OPT:REMOTE CONTROL PARTS (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67130-89L02	PARTS SET, R/CON	1	
2	13513-89L10	.ROD,THROTTLE	1	
3	19120-99J11	.LEVER, THROTTLE CONTROL	1	
4	19122-99J00	.LEVER, INTERLINK THROTTLE NO.2	1	
5	19131-89L00	.CONNECTOR	2	
6	19148-89L10	.LEVER, INTERLINK THROTTLE NO.1	1	
7	19150-89L00	.BRACKET, THROTTLE LEVER	1	
8	19185-99J00	.SPRING,THROTTLE LEVER	1	
9	21110-89L10	.LEVER, CLUTCH	1	
10	23115-89L10	.LINK, CLUTCH LEVER	1	
11	36610-89L22	.HARNESS ASSY, WIRING	1	
12	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
13	09481-10501	..FUSE (10A)	1	
14	09481-30501	..FUSE (30A)	1	
15	37163-89L00	.PLUG, STARTING SWITCH HOLE	1	
16	41130-89L00	.SHAFT, CLAMP BRACKET	1	
17	43755-99J00	.ATTACHMENT, STEERING BRACKET	1	
18	43759-89L00	.HOLDER, DRAIN HOSE	1	
19	09204-01002	.PIN	2	
20	09160-08082	.WASHER (8.5X16X1.2)	2	
21	61124-89L20	.GROMMET, R/CON CABLE	1	
22	67340-89L00	.HOLDER,, R/CON CABLE	1	
23	67467-89J01	.CONNECTOR	2	
24	09108-08286	.STUD BOLT	2	
25	09116-06225	.BOLT (6X15)	1	
26	09159-08059	.NUT	2	
27	09159-22006	.NUT	1	

DF20A_P01_015

FIG.513C




FIG.513C (2-J-2) OPT:REMOTE CONTROL PARTS (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09160-05029	.WASHER (5.5X12X0.8)	2	
29	09160-06046	.WASHER (6.5X20X1.5)	2	
30	09160-06055	.WASHER (7X12X1)	2	
31	09385-06012	.CLIP	2	
32	09407-14407	.CLAMP (L:145)	12	
33	01547-06167	.BOLT	2	
34	01550-06127	.BOLT	2	
35	01550-06167	.BOLT	2	

FIG.513D




FIG.513D (2-J-3) OPT:REMOTE CONTROL PARTS (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67130-89L02	PARTS SET, R/CON	1	
2	13513-89L10	.ROD,THROTTLE	1	
3	19120-99J11	.LEVER, THROTTLE CONTROL	1	
4	19122-99J00	.LEVER, INTERLINK THROTTLE NO.2	1	
5	19131-89L00	.CONNECTOR	2	
6	19148-89L10	.LEVER, INTERLINK THROTTLE NO.1	1	
7	19150-89L00	.BRACKET, THROTTLE LEVER	1	
8	19185-99J00	.SPRING,THROTTLE LEVER	1	
9	21110-89L10	.LEVER, CLUTCH	1	
10	23115-89L10	.LINK, CLUTCH LEVER	1	
11	36610-89L22	.HARNESS ASSY, WIRING	1	
12	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
13	09481-10501	..FUSE (10A)	1	
14	09481-30501	..FUSE (30A)	1	
15	37163-89L00	.PLUG, STARTING SWITCH HOLE	1	
16	41130-89L00	.SHAFT, CLAMP BRACKET	1	
17	43755-99J00	.ATTACHMENT, STEERING BRACKET	1	
18	43759-89L00	.HOLDER, DRAIN HOSE	1	
19	09204-01002	.PIN	2	
20	09160-08082	.WASHER (8.5X16X1.2)	2	
21	61124-89L20	.GROMMET, R/CON CABLE	1	
22	67340-89L00	.HOLDER,, R/CON CABLE	1	
23	67467-89J01	.CONNECTOR	2	
24	09108-08286	.STUD BOLT	2	
25	09116-06225	.BOLT (6X15)	1	
26	09159-08059	.NUT	2	
27	09159-22006	.NUT	1	

FIG.513D




FIG.513D (2-J-4) OPT:REMOTE CONTROL PARTS (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09160-05029	.WASHER (5.5X12X0.8)	2	
29	09160-06046	.WASHER (6.5X20X1.5)	2	
30	09160-06055	.WASHER (7X12X1)	2	
31	09385-06012	.CLIP	2	
32	09407-14407	.CLAMP (L:145)	12	
33	01547-06167	.BOLT	2	
34	01550-06127	.BOLT	2	
35	01550-06167	.BOLT	2	

FIG.515A





FIG.515A (2-J-5) OPT:REMOCON CABLE (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515B





FIG.515B (2-J-6) OPT:REMOCON CABLE (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515C





FIG.515C (2-J-7) OPT:REMOCON CABLE (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515D





FIG.515D (2-J-8) OPT:REMOCON CABLE (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515E





FIG.515E (2-J-9) OPT:REMOCON CABLE (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515F





FIG.515F (2-J-10) OPT:REMOCON CABLE (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515G





FIG.515G (2-J-11) OPT:REMOCON CABLE (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515H





FIG.515H (2-J-12) OPT:REMOCON CABLE (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515J





FIG.515J (2-J-13) OPT:REMOCON CABLE (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.530A




FIG.530A (2-J-14) OPT:SWITCH (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	..SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	..PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER ASSY, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37825-99E00	..PANEL, EMERGENCY SW	1	
11	37210-93J00	PANEL ASSY, LIGHTING SW	1	
12	37212-93J00	..PANEL, LIGHTING SW	1	

FIG.530A




FIG.530A (2-J-15) OPT:SWITCH (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
13	37100-96J24	PANEL ASSY, ENGINE SW	1	
14	37110-93J01	..SWITCH ASSY, IGNITION	1	
15-1	37141-99E00	..KEY (931)	2	
15-2	37141-99E10	..KEY (932)	2	
15-3	37141-99E20	..KEY (933)	2	
15-4	37141-99E30	..KEY (934)	2	
15-5	37141-99E40	..KEY (935)	2	
15-6	37141-99E50	..KEY (936)	2	
15-7	37141-99E60	..KEY (937)	2	
15-8	37141-99E70	..KEY (938)	2	
15-9	37141-99E80	..KEY (939)	2	
15-10	37141-99E90	..KEY (940)	2	
15-11	37141-99EA0	..KEY (941)	2	
15-12	37141-99EB0	..KEY (942)	2	
16	37143-99E00	..CAP, KEY	1	
17	37149-93J00	..CAP, CYLINDER BODY	1	
18	37139-99E20	..PANEL, IGNITION SWITCH	1	
19	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
20	37823-92E01	..PLATE ASSY, EMERGENCY	1	
21	37826-92J00	..NUT	1	
22	03121-0516A	..SCREW	4	
23	38500-93J90	..BUZZER ASSY, WARNING	1	
24	09407-08401	..CLAMP (L:80)	1	

FIG.530B




FIG.530B (2-K-2) OPT:SWITCH (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	..SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	..PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER ASSY, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37825-99E00	..PANEL, EMERGENCY SW	1	
11	37210-93J00	PANEL ASSY, LIGHTING SW	1	
12	37212-93J00	..PANEL, LIGHTING SW	1	

FIG.530B




FIG.530B (2-K-3) OPT:SWITCH (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
13	37100-96J24	PANEL ASSY, ENGINE SW	1	
14	37110-93J01	..SWITCH ASSY, IGNITION	1	
15-1	37141-99E00	..KEY (931)	2	
15-2	37141-99E10	..KEY (932)	2	
15-3	37141-99E20	..KEY (933)	2	
15-4	37141-99E30	..KEY (934)	2	
15-5	37141-99E40	..KEY (935)	2	
15-6	37141-99E50	..KEY (936)	2	
15-7	37141-99E60	..KEY (937)	2	
15-8	37141-99E70	..KEY (938)	2	
15-9	37141-99E80	..KEY (939)	2	
15-10	37141-99E90	..KEY (940)	2	
15-11	37141-99EA0	..KEY (941)	2	
15-12	37141-99EB0	..KEY (942)	2	
16	37143-99E00	..CAP, KEY	1	
17	37149-93J00	..CAP, CYLINDER BODY	1	
18	37139-99E20	..PANEL, IGNITION SWITCH	1	
19	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
20	37823-92E01	..PLATE ASSY, EMERGENCY	1	
21	37826-92J00	..NUT	1	
22	03121-0516A	..SCREW	4	
23	38500-93J90	..BUZZER ASSY, WARNING	1	
24	09407-08401	..CLAMP (L:80)	1	

FIG.530C




FIG.530C (2-K-4) OPT:SWITCH (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	..SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	..PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER ASSY, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37825-99E00	..PANEL, EMERGENCY SW	1	
11	37210-93J00	PANEL ASSY, LIGHTING SW	1	
12	37212-93J00	..PANEL, LIGHTING SW	1	

FIG.530C




FIG.530C (2-K-5) OPT:SWITCH (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
13	37100-96J24	PANEL ASSY, ENGINE SW	1	
14	37110-93J01	..SWITCH ASSY, IGNITION	1	
15-1	37141-99E00	..KEY (931)	2	
15-2	37141-99E10	..KEY (932)	2	
15-3	37141-99E20	..KEY (933)	2	
15-4	37141-99E30	..KEY (934)	2	
15-5	37141-99E40	..KEY (935)	2	
15-6	37141-99E50	..KEY (936)	2	
15-7	37141-99E60	..KEY (937)	2	
15-8	37141-99E70	..KEY (938)	2	
15-9	37141-99E80	..KEY (939)	2	
15-10	37141-99E90	..KEY (940)	2	
15-11	37141-99EA0	..KEY (941)	2	
15-12	37141-99EB0	..KEY (942)	2	
16	37143-99E00	..CAP, KEY	1	
17	37149-93J00	..CAP, CYLINDER BODY	1	
18	37139-99E20	..PANEL, IGNITION SWITCH	1	
19	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
20	37823-92E01	..PLATE ASSY, EMERGENCY	1	
21	37826-92J00	..NUT	1	
22	03121-0516A	..SCREW	4	
23	38500-93J90	..BUZZER ASSY, WARNING	1	
24	09407-08401	..CLAMP (L:80)	1	

FIG.530D




FIG.530D (2-K-6) OPT:SWITCH (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	..SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	..PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER ASSY, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37825-99E00	..PANEL, EMERGENCY SW	1	
11	37210-93J00	PANEL ASSY, LIGHTING SW	1	
12	37212-93J00	..PANEL, LIGHTING SW	1	

FIG.530D





FIG.530D (2-K-7) OPT:SWITCH (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
13	37100-96J24	PANEL ASSY, ENGINE SW	1	
14	37110-93J01	..SWITCH ASSY, IGNITION	1	
15-1	37141-99E00	..KEY (931)	2	
15-2	37141-99E10	..KEY (932)	2	
15-3	37141-99E20	..KEY (933)	2	
15-4	37141-99E30	..KEY (934)	2	
15-5	37141-99E40	..KEY (935)	2	
15-6	37141-99E50	..KEY (936)	2	
15-7	37141-99E60	..KEY (937)	2	
15-8	37141-99E70	..KEY (938)	2	
15-9	37141-99E80	..KEY (939)	2	
15-10	37141-99E90	..KEY (940)	2	
15-11	37141-99EA0	..KEY (941)	2	
15-12	37141-99EB0	..KEY (942)	2	
16	37143-99E00	..CAP, KEY	1	
17	37149-93J00	..CAP, CYLINDER BODY	1	
18	37139-99E20	..PANEL, IGNITION SWITCH	1	
19	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
20	37823-92E01	..PLATE ASSY, EMERGENCY	1	
21	37826-92J00	..NUT	1	
22	03121-0516A	..SCREW	4	
23	38500-93J90	..BUZZER ASSY, WARNING	1	
24	09407-08401	..CLAMP (L:80)	1	

FIG.530E



DF20A_P01_015_530E
OPT:SWITCH

FIG.530E (2-K-8) OPT:SWITCH (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	..SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	..PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER ASSY, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37825-99E00	..PANEL, EMERGENCY SW	1	
11	37210-93J00	PANEL ASSY, LIGHTING SW	1	
12	37212-93J00	..PANEL, LIGHTING SW	1	

DF20A_P01_015

FIG.530E




FIG.530E (2-K-9) OPT:SWITCH (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
13	37100-96J24	PANEL ASSY, ENGINE SW	1	
14	37110-93J01	..SWITCH ASSY, IGNITION	1	
15-1	37141-99E00	..KEY (931)	2	
15-2	37141-99E10	..KEY (932)	2	
15-3	37141-99E20	..KEY (933)	2	
15-4	37141-99E30	..KEY (934)	2	
15-5	37141-99E40	..KEY (935)	2	
15-6	37141-99E50	..KEY (936)	2	
15-7	37141-99E60	..KEY (937)	2	
15-8	37141-99E70	..KEY (938)	2	
15-9	37141-99E80	..KEY (939)	2	
15-10	37141-99E90	..KEY (940)	2	
15-11	37141-99EA0	..KEY (941)	2	
15-12	37141-99EB0	..KEY (942)	2	
16	37143-99E00	..CAP, KEY	1	
17	37149-93J00	..CAP, CYLINDER BODY	1	
18	37139-99E20	..PANEL, IGNITION SWITCH	1	
19	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
20	37823-92E01	..PLATE ASSY, EMERGENCY	1	
21	37826-92J00	..NUT	1	
22	03121-0516A	..SCREW	4	
23	38500-93J90	..BUZZER ASSY, WARNING	1	
24	09407-08401	..CLAMP (L:80)	1	

FIG.544A




FIG.544A (2-K-10) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544B




FIG.544B (2-K-11) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544C




FIG.544C (2-K-12) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544D




FIG.544D (2-K-13) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544E




FIG.544E (2-K-14) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544F




FIG.544F (2-K-15) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544G




FIG.544G (2-L-2) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544H




FIG.544H (2-L-3) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544J




FIG.544J (2-L-4) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.545A




FIG.545A (2-L-5) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545A





FIG.545A (2-L-6) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545B



DF20A_P01_015_545B
OPT:REMOTE CONTROL ASSY SINGLE (2)

FIG.545B (2-L-7) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

DF20A_P01_015

FIG.545B




FIG.545B (2-L-8) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

This exploded view diagram illustrates the assembly of a mechanical device, likely a pump or motor component. The parts are numbered as follows:

- 1**: Main housing or frame.
- 2**: A bracket or support arm.
- 3**: A small pin or clip.
- 4**: A small pin or clip.
- 5**: A small pin or clip.
- 6**: A small pin or clip.
- 7**: A small pin or clip.
- 8**: A small pin or clip.
- 9**: A small pin or clip.
- 10**: A small pin or clip.
- 11**: A cable or hose.
- 12**: A small pin or clip.
- 13**: A small pin or clip.
- 14**: A small pin or clip.
- 15**: A small pin or clip.
- 16**: A small pin or clip.
- 17**: A small pin or clip.
- 18**: A small pin or clip.
- 19**: A small pin or clip.
- 20**: A small pin or clip.
- 21**: A small pin or clip.
- 22**: A small pin or clip.
- 23**: A small pin or clip.
- 24**: A small pin or clip.
- 25**: A small pin or clip.
- 26**: A small pin or clip.
- 27**: A small pin or clip.
- 28**: A small pin or clip.
- 29**: A small pin or clip.
- 30**: A small pin or clip.
- 31**: A small pin or clip.
- 32**: A small pin or clip.
- 33**: A small pin or clip.
- 34**: A small pin or clip.
- 35**: A small pin or clip.
- 36**: A small pin or clip.
- 37**: A small pin or clip.
- 38**: A small pin or clip.
- 39**: A small pin or clip.
- 40**: A small pin or clip.
- 41**: A small pin or clip.
- 42**: A small pin or clip.
- 43**: A small pin or clip.
- 44**: A small pin or clip.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545C





FIG.545C (2-L-10) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545D



DF20A_P01_015_545D


OPT:REMOTE CONTROL ASSY SINGLE (2)

FIG.545D (2-L-11) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

DF20A_P01_015

FIG.545D



DF20A_P01_015_545D
OPT:REMOTE CONTROL ASSY SINGLE (2)

FIG.545D (2-L-12) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

DF20A_P01_015

FIG.545E




FIG.545E (2-L-13) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545E





FIG.545E (2-L-14) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545F



DF20A_P01_015_545F
OPT:REMOTE CONTROL ASSY SINGLE (2)

FIG.545F (2-L-15) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

DF20A_P01_015

FIG.545F




FIG.545F (3-B-2) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20A P01)


REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

This exploded view diagram illustrates the assembly of a mechanical device, likely a pump or motor component. The parts are numbered as follows:

- 1**: Main housing or frame.
- 2**: A bracket or support arm.
- 3**: A small pin or fastener.
- 4**: A small pin or fastener.
- 5**: A small pin or fastener.
- 6**: A small pin or fastener.
- 7**: A small pin or fastener.
- 8**: A small pin or fastener.
- 9**: A small pin or fastener.
- 10**: A small pin or fastener.
- 11**: A cable or hose with a connector.
- 12**: A small pin or fastener.
- 13**: A small pin or fastener.
- 14**: A small pin or fastener.
- 15**: A small pin or fastener.
- 16**: A small pin or fastener.
- 17**: A small pin or fastener.
- 18**: A small pin or fastener.
- 19**: A small pin or fastener.
- 20**: A small pin or fastener.
- 21**: A small pin or fastener.
- 22**: A circular component, possibly a cover or end plate.
- 23**: A small pin or fastener.
- 24**: A small pin or fastener.
- 25**: A small pin or fastener.
- 26**: A small pin or fastener.
- 27**: A small pin or fastener.
- 28**: A small pin or fastener.
- 29**: A small pin or fastener.
- 30**: A small pin or fastener.
- 31**: A small pin or fastener.
- 32**: A small pin or fastener.
- 33**: A small pin or fastener.
- 34**: A small pin or fastener.
- 35**: A small pin or fastener.
- 36**: A small pin or fastener.
- 37**: A small pin or fastener.
- 38**: A small pin or fastener.
- 39**: A small pin or fastener.
- 40**: A small pin or fastener.
- 41**: A small pin or fastener.
- 42**: A small pin or fastener.
- 43**: A small pin or fastener.
- 44**: A small pin or fastener.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545G



DF20A_P01_015_545G
OPT:REMOTE CONTROL ASSY SINGLE (2)

FIG.545G (3-B-4) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

DF20A_P01_015

FIG.545H




FIG.545H (3-B-5) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545H




FIG.545H (3-B-6) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

This exploded view diagram illustrates the assembly of a mechanical device, likely a pump or motor component. The parts are numbered as follows:

- 1**: Main housing or frame.
- 2**: A bracket or support arm.
- 3**: A small pin or clip.
- 4**: A small pin or clip.
- 5**: A small pin or clip.
- 6**: A small pin or clip.
- 7**: A small pin or clip.
- 8**: A small pin or clip.
- 9**: A small pin or clip.
- 10**: A small pin or clip.
- 11**: A cable or hose.
- 12**: A small pin or clip.
- 13**: A small pin or clip.
- 14**: A small pin or clip.
- 15**: A small pin or clip.
- 16**: A small pin or clip.
- 17**: A small pin or clip.
- 18**: A small pin or clip.
- 19**: A small pin or clip.
- 20**: A small pin or clip.
- 21**: A small pin or clip.
- 22**: A small pin or clip.
- 23**: A small pin or clip.
- 24**: A small pin or clip.
- 25**: A small pin or clip.
- 26**: A small pin or clip.
- 27**: A small pin or clip.
- 28**: A small pin or clip.
- 29**: A small pin or clip.
- 30**: A small pin or clip.
- 31**: A small pin or clip.
- 32**: A small pin or clip.
- 33**: A small pin or clip.
- 34**: A small pin or clip.
- 35**: A small pin or clip.
- 36**: A small pin or clip.
- 37**: A small pin or clip.
- 38**: A small pin or clip.
- 39**: A small pin or clip.
- 40**: A small pin or clip.
- 41**: A small pin or clip.
- 42**: A small pin or clip.
- 43**: A small pin or clip.
- 44**: A small pin or clip.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545J




FIG.545J (3-B-8) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.546A

FIG.546A (3-B-9) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	





FIG.546B

FIG.546B (3-B-10) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	





FIG.546C

FIG.546C (3-B-11) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF15ATH PO

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	





FIG.546D

FIG.546D (3-B-12) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	





FIG.546E

FIG.546E (3-B-13) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	







FIG.546F

FIG.546F (3-B-14) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF20ATH P01_015)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	



This diagram shows an exploded view of a cable assembly. The components are numbered as follows:

- 1**: A small circular component, possibly a connector or plug.
- 2**: A long, thin rod or pin.
- 3**: A rectangular component with multiple internal slots or channels.
- 4**: A bracket or support structure.
- 5**: A screw or bolt.
- 6**: A small circular component, possibly a connector or plug.
- 7**: A small circular component, possibly a connector or plug.
- 8**: A small rectangular component, possibly a connector or plug.
- 9**: A small circular component, possibly a connector or plug.
- 10**: A cable with a connector.
- 11**: A cable with a connector.
- 12**: A cable with a connector.
- 13**: A cable with a connector.
- 14**: A cable with a connector.
- 15**: A long, thin rod or pin.
- 16**: A long, thin rod or pin.
- 17**: A small rectangular component, possibly a connector or plug.

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-89L00	KIT,BATTERY CHARGING	1	
2	32801-89L00	..RECTIFIER & REGULATOR SET	1	
3	32800-94J11	..RECTIFIER/REGULATOR ASSY	1	
4	32815-89L10	..BRACKET, RECTIFIER	1	
5	01550-08207	..BOLT	2	
6	01550-06207	..BOLT	2	
7	09407-14407	..CLAMP (L:145)	3	
8	09408-00184	..CLAMP	1	
9	39600-89L00	..RECEPTACLE SET	1	
10	36740-94J00	..CASE ASSY, FUSE	1	
11	37801-98300	..LEAD RECEPTACLE GROUND	1	
12	39601-95D00	..RECEPTACLE ASSY, LIGHTING	1	
13	36634-93910	...CAP	1	
14	39602-93900	..PLUG, RECEPTACLE	1	
15	09407-14403	..CLAMP (L:125)	2	
16	09407-14407	..CLAMP (L:145)	3	
17	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.553B




FIG.553B (3-C-2) OPT:ELECTRICAL (MANUAL STARTER) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-89L00	KIT,BATTERY CHARGING	1	
2	32801-89L00	..RECTIFIER & REGULATOR SET	1	
3	32800-94J11	..RECTIFIER/REGULATOR ASSY	1	
4	32815-89L10	..BRACKET, RECTIFIER	1	
5	01550-08207	..BOLT	2	
6	01550-06207	..BOLT	2	
7	09407-14407	..CLAMP (L:145)	3	
8	09408-00184	..CLAMP	1	
9	39600-89L00	..RECEPTACLE SET	1	
10	36740-94J00	..CASE ASSY, FUSE	1	
11	37801-98300	..LEAD RECEPTACLE GROUND	1	
12	39601-95D00	..RECEPTACLE ASSY, LIGHTING	1	
13	36634-93910	...CAP	1	
14	39602-93900	..PLUG, RECEPTACLE	1	
15	09407-14403	..CLAMP (L:125)	2	
16	09407-14407	..CLAMP (L:145)	3	
17	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.553C




FIG.553C (3-C-3) OPT:ELECTRICAL (MANUAL STARTER) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-89L00	KIT,BATTERY CHARGING	1	
2	32801-89L00	..RECTIFIER & REGULATOR SET	1	
3	32800-94J11	..RECTIFIER/REGULATOR ASSY	1	
4	32815-89L10	..BRACKET, RECTIFIER	1	
5	01550-08207	..BOLT	2	
6	01550-06207	..BOLT	2	
7	09407-14407	..CLAMP (L:145)	3	
8	09408-00184	..CLAMP	1	
9	39600-89L00	..RECEPTACLE SET	1	
10	36740-94J00	..CASE ASSY, FUSE	1	
11	37801-98300	..LEAD RECEPTACLE GROUND	1	
12	39601-95D00	..RECEPTACLE ASSY, LIGHTING	1	
13	36634-93910	...CAP	1	
14	39602-93900	..PLUG, RECEPTACLE	1	
15	09407-14403	..CLAMP (L:125)	2	
16	09407-14407	..CLAMP (L:145)	3	
17	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.553D




FIG.553D (3-C-4) OPT:ELECTRICAL (MANUAL STARTER) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-89L00	KIT,BATTERY CHARGING	1	
2	32801-89L00	..RECTIFIER & REGULATOR SET	1	
3	32800-94J11	..RECTIFIER/REGULATOR ASSY	1	
4	32815-89L10	..BRACKET, RECTIFIER	1	
5	01550-08207	..BOLT	2	
6	01550-06207	..BOLT	2	
7	09407-14407	..CLAMP (L:145)	3	
8	09408-00184	..CLAMP	1	
9	39600-89L00	..RECEPTACLE SET	1	
10	36740-94J00	..CASE ASSY, FUSE	1	
11	37801-98300	..LEAD RECEPTACLE GROUND	1	
12	39601-95D00	..RECEPTACLE ASSY, LIGHTING	1	
13	36634-93910	...CAP	1	
14	39602-93900	..PLUG, RECEPTACLE	1	
15	09407-14403	..CLAMP (L:125)	2	
16	09407-14407	..CLAMP (L:145)	3	
17	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.561A




FIG.561A (3-C-5) OPT:STARTING MOTOR (MANUAL STARTER) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L03	STARTER SET, ELECTRIC	1	
2	31101-89L00	.MOTOR SET, STARTING	1	
3	31100-94J22	..MOTOR ASSY, STARTING	1	
4	32102-89L00	.FLYWHEEL, MAGNETO	1	
5	32120-89L00	.COIL, STATOR & PULSER	1	
6	32800-89L00	.RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	.BRACKET, RECTIFIER	1	
8	01550-06167	.BOLT	1	
9	01550-06207	.BOLT	2	
10	01547-0625A	.BOLT	3	
11	09408-00184	.CLAMP	1	
12	33800-89L01	.CABLE SET, STARTER	1	
13	33810-89L02	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L01	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19	36610-89L03	.HARNESS ASSY, WIRING	1	
20	38860-76F01	.RELAY ASSY	1	
21	38915-90J00	.HOLDER, RELAY	1	
22	09407-14407	.CLAMP (L:145)	11	
23	12700-89L20	.CAMSHAFT ASSY	1	
24	33920-89L41	UNIT, ENGINE CONTROL	1	

FIG.561B




FIG.561B (3-C-6) OPT:STARTING MOTOR (MANUAL STARTER) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L03	STARTER SET, ELECTRIC	1	
2	31101-89L00	.MOTOR SET, STARTING	1	
3	31100-94J22	..MOTOR ASSY, STARTING	1	
4	32102-89L00	.FLYWHEEL, MAGNETO	1	
5	32120-89L00	.COIL, STATOR & PULSER	1	
6	32800-89L00	.RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	.BRACKET, RECTIFIER	1	
8	01550-06167	.BOLT	1	
9	01550-06207	.BOLT	2	
10	01547-0625A	.BOLT	3	
11	09408-00184	.CLAMP	1	
12	33800-89L01	.CABLE SET, STARTER	1	
13	33810-89L02	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L01	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19	36610-89L03	.HARNESS ASSY, WIRING	1	
20	38860-76F01	.RELAY ASSY	1	
21	38915-90J00	.HOLDER, RELAY	1	
22	09407-14407	.CLAMP (L:145)	11	
23	12700-89L20	.CAMSHAFT ASSY	1	
24	33920-89L02	UNIT, ENGINE CONTROL	1	

FIG.561C




FIG.561C (3-C-7) OPT:STARTING MOTOR (MANUAL STARTER) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L03	STARTER SET, ELECTRIC	1	
2	31101-89L00	.MOTOR SET, STARTING	1	
3	31100-94J22	..MOTOR ASSY, STARTING	1	
4	32102-89L00	.FLYWHEEL, MAGNETO	1	
5	32120-89L00	.COIL, STATOR & PULSER	1	
6	32800-89L00	.RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	.BRACKET, RECTIFIER	1	
8	01550-06167	.BOLT	1	
9	01550-06207	.BOLT	2	
10	01547-0625A	.BOLT	3	
11	09408-00184	.CLAMP	1	
12	33800-89L01	.CABLE SET, STARTER	1	
13	33810-89L02	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L01	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19	36610-89L03	.HARNESS ASSY, WIRING	1	
20	38860-76F01	.RELAY ASSY	1	
21	38915-90J00	.HOLDER, RELAY	1	
22	09407-14407	.CLAMP (L:145)	11	
23	12700-89L20	.CAMSHAFT ASSY	1	
24	33920-89L22	UNIT, ENGINE CONTROL	1	

FIG.561D




FIG.561D (3-C-8) OPT:STARTING MOTOR (MANUAL STARTER) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L03	STARTER SET, ELECTRIC	1	
2	31101-89L00	.MOTOR SET, STARTING	1	
3	31100-94J22	..MOTOR ASSY, STARTING	1	
4	32102-89L00	..FLYWHEEL, MAGNETO	1	
5	32120-89L00	..COIL, STATOR & PULSER	1	
6	32800-89L00	..RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	..BRACKET, RECTIFIER	1	
8	01550-06167	..BOLT	1	
9	01550-06207	..BOLT	2	
10	01547-0625A	..BOLT	3	
11	09408-00184	..CLAMP	1	
12	33800-89L01	..CABLE SET, STARTER	1	
13	33810-89L02	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L01	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19	36610-89L03	..HARNESS ASSY, WIRING	1	
20	38860-76F01	..RELAY ASSY	1	
21	38915-90J00	..HOLDER, RELAY	1	
22	09407-14407	..CLAMP (L:145)	11	
23	12700-89L20	..CAMSHAFT ASSY	1	
24	33920-89L61	UNIT, ENGINE CONTROL	1	

FIG.575A





FIG.575A (3-C-9) OPT:DRAG LINK (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.575B




DF20A_P01_015_575B
OPT:DRAG LINK

FIG.575B (3-C-10) OPT:DRAG LINK (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.575C



DF20A_P01_015_575C
OPT:DRAG LINK

FIG.575C (3-C-11) OPT:DRAG LINK (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.575D




FIG.575D (3-C-12) OPT:DRAG LINK (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.583A




FIG.583A (3-C-13) OPT:FUEL TANK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65000-95D01	TANK ASSY, FUEL (25L)	1	
2	65520-95D01	.CAP, FUEL TANK	1	
3	65561-95D00	.GASKET, TANK CAP	1	
4	65740-95D01	.PLUG, FUEL CONNECTOR	1	
5	65831-95D00	.FILTER, OUTLET	1	
6	65890-95D00	.OUTLET ASSY	1	
7	65892-95D00	.O RING	1	
8	65700-87J15	HOSE, FUEL	1	
9	65750-87JL0	.SOCKET, FUEL HOSE	1	
10	65750-955L0	.SOCKET, FUEL HOSE	1	
11	65770-90J11	.PUMP, SQUEEZE	1	
12	65781-98500	.CLIP	4	

FIG.588A




FIG.588A (3-C-14) OPT:LOWRANCE GAUGE (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34190-88L00	SENSOR ASSY,PAD WHEEL	1	
2	34193-88L00	BEZEL, 4 IN CHR	1	
3	34193-88L20	BEZEL, 4 IN WHITE	1	
4	34193-88L40	BEZEL, 2 IN CHR	1	
5	34193-88L60	BEZEL, 2 IN WHITE	1	
6	34455-88L00	SENSOR ASSY, WATER TEMP	1	
7	34455-88L10	SENSOR ASSY, WATER TEMP	1	
8	34810-88L00	SENSOR ASSY, FLUID LEVEL	1	
9	34960-88L00	SENSOR ASSY, WATER PRESSURE	1	
10	36662-88L10	WIRE, 2 EXTENSION	1	
11	36662-88L20	WIRE, 6 EXTENSION	1	
12	36662-88L30	WIRE, 15 EXTENSION	1	
13	36663-88L10	HARNESS ASSY, NETWORK POWER	1	
14	36666-88L00	WIRE, ADAPTER TO N NETWORK	1	
15	36666-88L10	WIRE, ADAPTER TO L NETWORK	1	
16	39950-88L00	MODULE ASSY, GPS RECEIVER	1	
17	36664-88L00	CONNECTOR, BRANCH	1	

FIG.588B




FIG.588B (3-C-15) OPT:LOWRANCE GAUGE (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34190-88L00	SENSOR ASSY,PAD WHEEL	1	
2	34193-88L00	BEZEL, 4 IN CHR	1	
3	34193-88L20	BEZEL, 4 IN WHITE	1	
4	34193-88L40	BEZEL, 2 IN CHR	1	
5	34193-88L60	BEZEL, 2 IN WHITE	1	
6	34455-88L00	SENSOR ASSY, WATER TEMP	1	
7	34455-88L10	SENSOR ASSY, WATER TEMP	1	
8	34810-88L00	SENSOR ASSY, FLUID LEVEL	1	
9	34960-88L00	SENSOR ASSY, WATER PRESSURE	1	
10	36662-88L10	WIRE, 2 EXTENSION	1	
11	36662-88L20	WIRE, 6 EXTENSION	1	
12	36662-88L30	WIRE, 15 EXTENSION	1	
13	36663-88L10	HARNESS ASSY, NETWORK POWER	1	
14	36666-88L00	WIRE, ADAPTER TO N NETWORK	1	
15	36666-88L10	WIRE, ADAPTER TO L NETWORK	1	
16	39950-88L00	MODULE ASSY, GPS RECEIVER	1	
17	36664-88L00	CONNECTOR, BRANCH	1	

FIG.588C




FIG.588C (3-D-2) OPT:LOWRANCE GAUGE (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34190-88L00	SENSOR ASSY,PAD WHEEL	1	
2	34193-88L00	BEZEL, 4 IN CHR	1	
3	34193-88L20	BEZEL, 4 IN WHITE	1	
4	34193-88L40	BEZEL, 2 IN CHR	1	
5	34193-88L60	BEZEL, 2 IN WHITE	1	
6	34455-88L00	SENSOR ASSY, WATER TEMP	1	
7	34455-88L10	SENSOR ASSY, WATER TEMP	1	
8	34810-88L00	SENSOR ASSY, FLUID LEVEL	1	
9	34960-88L00	SENSOR ASSY, WATER PRESSURE	1	
10	36662-88L10	WIRE, 2 EXTENSION	1	
11	36662-88L20	WIRE, 6 EXTENSION	1	
12	36662-88L30	WIRE, 15 EXTENSION	1	
13	36663-88L10	HARNESS ASSY, NETWORK POWER	1	
14	36666-88L00	WIRE, ADAPTER TO N NETWORK	1	
15	36666-88L10	WIRE, ADAPTER TO L NETWORK	1	
16	39950-88L00	MODULE ASSY, GPS RECEIVER	1	
17	36664-88L00	CONNECTOR, BRANCH	1	

FIG.588D




FIG.588D (3-D-3) OPT:LOWRANCE GAUGE (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34190-88L00	SENSOR ASSY,PAD WHEEL	1	
2	34193-88L00	BEZEL, 4 IN CHR	1	
3	34193-88L20	BEZEL, 4 IN WHITE	1	
4	34193-88L40	BEZEL, 2 IN CHR	1	
5	34193-88L60	BEZEL, 2 IN WHITE	1	
6	34455-88L00	SENSOR ASSY, WATER TEMP	1	
7	34455-88L10	SENSOR ASSY, WATER TEMP	1	
8	34810-88L00	SENSOR ASSY, FLUID LEVEL	1	
9	34960-88L00	SENSOR ASSY, WATER PRESSURE	1	
10	36662-88L10	WIRE, 2 EXTENSION	1	
11	36662-88L20	WIRE, 6 EXTENSION	1	
12	36662-88L30	WIRE, 15 EXTENSION	1	
13	36663-88L10	HARNESS ASSY, NETWORK POWER	1	
14	36666-88L00	WIRE, ADAPTER TO N NETWORK	1	
15	36666-88L10	WIRE, ADAPTER TO L NETWORK	1	
16	39950-88L00	MODULE ASSY, GPS RECEIVER	1	
17	36664-88L00	CONNECTOR, BRANCH	1	

FIG.588E




FIG.588E (3-D-4) OPT:LOWRANCE GAUGE (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34190-88L00	SENSOR ASSY,PAD WHEEL	1	
2	34193-88L00	BEZEL, 4 IN CHR	1	
3	34193-88L20	BEZEL, 4 IN WHITE	1	
4	34193-88L40	BEZEL, 2 IN CHR	1	
5	34193-88L60	BEZEL, 2 IN WHITE	1	
6	34455-88L00	SENSOR ASSY, WATER TEMP	1	
7	34455-88L10	SENSOR ASSY, WATER TEMP	1	
8	34810-88L00	SENSOR ASSY, FLUID LEVEL	1	
9	34960-88L00	SENSOR ASSY, WATER PRESSURE	1	
10	36662-88L10	WIRE, 2 EXTENSION	1	
11	36662-88L20	WIRE, 6 EXTENSION	1	
12	36662-88L30	WIRE, 15 EXTENSION	1	
13	36663-88L10	HARNESS ASSY, NETWORK POWER	1	
14	36666-88L00	WIRE, ADAPTER TO N NETWORK	1	
15	36666-88L10	WIRE, ADAPTER TO L NETWORK	1	
16	39950-88L00	MODULE ASSY, GPS RECEIVER	1	
17	36664-88L00	CONNECTOR, BRANCH	1	

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
10000		12744-89L00	120A-17		121E-7
		12761-93E0	120A-16		121F-7
		12840-93E01	121A-3		121G-7
			121B-3		121H-7
			121C-3		121J-7
11110-89L01	111A-1		121D-3		121K-7
11115-93E00-001	111A-19		121E-3		121L-7
11141-89L00	111A-2		121F-3		121A-8
11162-89L00	111A-14		121G-3		121B-8
11170-89L00	111A-13		121H-3		121C-8
11174-89L00	111A-16		121J-3		121D-8
11261-93J00	111A-5		121K-3		121E-8
11291-91B50	113A-6		121L-3		121F-8
11300-89L01	113A-1		121A-4		121G-8
11382-93E00	111A-10		121B-4		121H-8
12100-89L00-050	116A-10		121C-4		121J-8
12111-89L00-0B0	116A-1		121D-4		121K-8
12140-89L00	116A-2		121E-4		121L-8
12140-89L00-050	116A-11		121F-4		121A-9
12151-89L00	116A-3		121G-4		121B-9
12160-89L00	116A-5		121H-4		121C-9
12163-89L00	116A-6		121J-4		121D-9
12220-89L00	116A-7		121K-4		121E-9
12341-89L10	116A-8		121L-4		121F-9
12625-89L01	120A-11		121A-5		121G-9
12631-89L10	120A-1		121B-5		121H-9
12635-89L00	120A-2		121C-5		121J-9
12636-89L00	120A-3		121D-5		121K-9
12637-89L00	120A-4		121E-5		121L-9
12638-89L00	120A-5		121F-5		121A-10
12700-89L00	121A-1-1		121G-5		121B-10
	121D-1-1		121H-5		121C-10
	121G-1-1		121J-5		121D-10
	121H-1-1		121K-5		121E-10
12700-89L20	121A-1-2		121L-5		121F-10
	121B-1		121A-6		121G-10
	121C-1		121B-6		121H-10
	121D-1-2		121C-6		121J-10
	121E-1		121D-6		121K-10
	121F-1		121E-6		121L-10
	121G-1-2		121F-6		121A-11
	121H-1-2		121G-6		121B-11
	121J-1		121H-6		121C-11
	121K-1		121J-6		121D-11
	121L-1		121K-6		121E-11
	561A-23		121L-6		121F-11
	561B-23		121A-7		121G-11
	561C-23		121B-7		121H-11
	561D-23		121C-7		121J-11
12741-89L00	120A-6		121D-7		121K-11

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
12932-24400	121L-11		126F-2	13425-33G00	163A-3
	121A-12		126G-2		163B-3
	121B-12		126H-2		163C-3
	121C-12		126J-2		163D-3
	121D-12		126K-2		163E-3
	121E-12		126L-2		163F-3
	121F-12		163A-1		163G-3
	121G-12		163D-1		163H-3
	121H-12		163F-1		163J-3
	121J-12		163G-1		163K-3
	121K-12		163H-1		163L-3
	121L-12		163I-1		166A-1
	121A-13		163B-1		166B-1
	121B-13		163C-1		166C-1
	121C-13		163E-1		166D-1
	121D-13		163J-1		166E-1
	121E-13		163K-1		513A-2
	121F-13		163A-4		513B-2
	121G-13		163B-4		513C-2
	121H-13		163C-4		513D-2
	121J-13		163D-4		334A-1
	121K-13		163E-4		334B-1
	121L-13		163F-4		334C-1
	126A-1		163G-4		334D-1
	126B-1		163H-4		334E-1
	126C-1		163J-4		334F-1
	126D-1		163K-4		334G-1
	126E-1		163L-4		334H-1
	126F-1		163A-2		334J-1
	126G-1		163B-2		334K-1
	126H-1		163C-2		334L-1
	126J-1		163D-2		334A-12
	126K-1		163E-2		334B-11
	126L-1		163F-2		334C-11
	126A-8		163G-2		334D-12
	126B-8		163H-2		334E-11
	126C-8		163J-2		334F-11
	126D-8		163K-2		334G-12
	126E-8		163L-2		334H-12
	126F-8		163A-5		334J-11
	126G-10		163B-5		334K-11
	126H-10		163C-5		334L-11
	126J-10		163D-5		334A-13
	126K-10		163E-5		334B-12
	126L-10		163F-5		334C-12
	126A-2		163G-5		334D-13
	126B-2		163H-5		334E-12
	126C-2		163J-5		334F-12
	126D-2		163K-5		334G-13
	126E-2		163L-5		334H-13

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
13684-89L00	334J-12	15194-89L00	146A-32	17400-99J11	160H-19
	334K-12	15200-89L01	146A-2	17411-94J00	160A-1
	334L-12	15211-91J00-130	163A-6		160B-1
	146A-1		163B-6		160C-1
13710-89L00	126G-6		163C-6		160D-1
	126H-6		163D-6		160E-1
	126J-6		163E-6		160F-1
	126K-6		163F-6		160G-1
	126L-6		163G-6		160H-1
13811-89L00	126A-5		163H-6		160J-1
	126B-5		163J-6		160K-1
	126C-5		163K-6		160L-1
	126D-5		163L-6	17413-94J00	160A-2
	126E-5	15217-89L00	146A-3		160B-2
	126F-5	15218-89L00	146A-4		160C-2
	126G-5	15410-87L00	146A-33		160D-2
	126H-5	15419-87J00	146A-35		160E-2
	126J-5	15421-89L01	146A-36		160F-2
	126K-5	15422-89L00	146A-37		160G-2
	126L-5	15600-89L00	146A-5		160J-2
13820-89L00	126D-9	15629-89L00	146A-8		160K-2
	126E-9	15681-89L00	144A-1		160L-2
	126F-9	15685-89L00	146A-38	17413-94J10	160H-2
13820-89L10	126A-9	15690-89L01	146A-6	17461-939M0	160A-3
	126B-9	15710-89L00	144A-2		160B-3
	126C-9	15716-65DT0	144A-3		160C-3
13831-89L00	126A-11	15734-89L00	144A-4		160D-3
	126B-11	15735-89L00	144A-5		160E-3
	126C-11	15751-89L00	144A-6		160F-3
	126D-11	15770-89L01	146A-7		160G-3
	126E-11	15790-89L00	146A-9		160H-3
	126F-11	16400-89L00	175A-1		160J-3
	126G-11	16431-89L00	175A-12		160K-3
	126H-11	16440-11D00	113A-5		160L-3
	126J-11	16510-45H10	175A-2	17471-99J00	160A-4
	126K-11	16512-99J00	175A-3		160B-4
13832-89L00	126L-11	16515-89L10	401A-6		160C-4
	126G-7	16520-99J00	401A-17		160D-4
	126H-7	16910-89L00	175A-9		160E-4
	126J-7	16930-89L00	175A-10		160F-4
	126K-7	17400-99J01	160A-19		160G-4
	126L-7		160B-19		160J-4
15100-89L10	146A-24		160C-19		160K-4
15191-89L00	146A-25		160D-19		160L-4
15192-89L00	146A-26		160E-19	17471-99J10	160H-4
15192-89L10	146A-27		160F-19	17472-99J00	160A-5
15192-89L20	146A-28		160G-19		160B-5
15192-89L30	146A-29		160J-19		160C-5
15192-89L40	146A-30		160K-19		160D-5
15193-89L00	146A-31		160L-19		160E-5

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	160F-5	17563-94J00	160A-8		160G-11
	160G-5		160B-8		160H-11
	160H-5		160C-8		160J-11
	160J-5		160D-8		160K-11
	160K-5		160E-8		160L-11
	160L-5		160F-8	17670-91J00	162A-1
17473-94J00	160A-6		160G-8	17680-89L00	162A-2
	160B-6		160H-8	17685-89L00	162A-7
	160C-6		160J-8	17712-89L00	162A-5
	160D-6		160K-8	17712-89L10	162A-4
	160E-6		160L-8	17913-93J00	405A-1
	160F-6	17564-99J00	160A-9	17914-93J00	405A-2
	160G-6		160B-9	17917-87LL0	410A-22
	160H-6		160C-9		410B-22
	160J-6		160D-9		410C-23
	160K-6		160E-9		410D-22
17561-99J00	160L-6		160F-9		410E-22
	160A-7-1		160G-9		410F-23
	160B-7-1		160H-9		410G-22
	160C-7-1		160J-9		410H-22
	160D-7-1		160K-9		410J-22
	160E-7-1	17565-99J00	160L-9		410K-23
	160F-7-1		160A-18	18100-94JN0	167A-1
	160G-7-1		160B-18		167B-1
	160H-7-1		160C-18		167C-1
	160J-7-1		160D-18		167D-1
17561-99J10	160K-7-1		160E-18		167E-1
	160L-7-1		160F-18		167F-1
	160A-7-2		160G-18		167G-1
	160B-7-2		160H-18		167H-1
	160C-7-2		160J-18		167J-1
	160D-7-2		160K-18		167K-1
	160E-7-2		160L-18		167L-1
	160F-7-2	17631-99J20	160A-10	18121-94JL0	167A-2
	160G-7-2		160B-10		167B-2
	160H-7-2		160C-10		167C-2
	160J-7-2		160D-10		167D-2
	160K-7-2		160E-10		167E-2
	160L-7-2		160F-10		167F-2
17561-99J20	160A-7-3		160G-10		167G-2
	160B-7-3		160H-10		167H-2
	160C-7-3		160J-10		167J-2
	160D-7-3		160K-10		167K-2
	160E-7-3		160L-10		167L-2
	160F-7-3	17632-99J30	160A-11		167A-3
	160G-7-3		160B-11	18130-93E01	167B-3
	160H-7-3		160C-11		167C-3
	160J-7-3		160D-11		167D-3
	160K-7-3		160E-11		167E-3
	160L-7-3		160F-11		

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
18132-89L00	167F-3	18290-94J01	167A-10	19148-89L10	513D-5
	167G-3		167B-10		166A-5
	167H-3		167C-10		166B-5
	167J-3		167D-10		166C-5
	167K-3		167E-10		166D-5
	167L-3		167F-10		166E-5
	167A-5		167G-10		513A-6
	167B-5		167H-10		513B-6
	167C-5		167J-10		513C-6
	167D-5		167K-10		513D-6
18142-93E00	167E-5		167L-10	19150-89L00	166A-6
	167F-5	18498-87JC0	146A-10		166B-6
	167G-5	18498-94J20	162A-8		166C-6
	167H-5	18590-58M00	334A-14		166D-6
	167J-5		334B-13		166E-6
	167K-5		334C-13		513A-7
	167L-5		334D-14		513B-7
	167A-4		334E-13		513C-7
	167B-4		334F-13		513D-7
	167C-4		334G-14		166A-7
18210-95L00	167D-4		334H-14	19185-99J00	166B-7
	167E-4		334J-13		166C-7
	167F-4		334K-13		166D-7
	167G-4		334L-13		166E-7
	167H-4	19120-99J11	166A-2		513A-8
	167J-4		166B-2		513B-8
	167K-4		166C-2		513C-8
	167L-4		166D-2		513D-8
	167A-6		166E-2		
	167B-6		513A-3		
18280-93E00	167C-6	19122-99J00	513B-3	20000	21110-89L10
	167D-6		513C-3		
	167E-6		513D-3		
	167F-6		166A-3		
	167G-6		166B-3		
	167H-6		166C-3		
	167J-6		166D-3		
	167K-6		166E-3		
	167L-6		513A-4		
	167A-7		513B-4		
18280-93E00	167B-7	19131-89L00	513C-4	21111-89L00	21110-89L10
	167C-7		513D-4		
	167D-7		166A-4		
	167E-7		166B-4		
	167F-7		166C-4		
	167G-7		166D-4		
	167H-7		166E-4		
	167J-7		513A-5		
	167K-7		513B-5		
	167L-7		513C-5		

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
21120-89L00	206A-2	23111-89L00	336K-1-1	29141-93J00	206K-7
	206B-2		336K-1-2		206L-7
	206C-2		336L-1-1		210A-1
	206D-2		336L-1-2		210A-2-1
	206E-2		206A-5-1		210A-2-2
	206F-2		206B-5-1		210A-5
	206G-2		206C-5-1		210A-6
	206H-2		206D-5-1		210A-3
	206J-2		206E-5-1		327B-6
	206K-2		206F-5-1		327D-6
21122-89L00	206L-2	23111-89L10	206G-5-1	29162-93J10	160A-13
	206A-3		206H-5-1		160B-13
	206B-3		206J-5-1		160C-13
	206C-3		206K-5-1		160D-13
	206D-3		206L-5-1		160E-13
	206E-3		206A-5-2		160F-13
	206F-3		206B-5-2		160G-13
	206G-3		206C-5-2		160H-13
	206H-3		206D-5-2		160J-13
	206J-3		206E-5-2		160K-13
21131-94J00	206K-3	23115-89L00	206F-5-2	29162-93J10	160L-13
	206L-3		206G-5-2		210A-7
	444A-36		206H-5-2		335A-12
	444B-36		206J-5-2		335B-12
	444C-36		206K-5-2		335D-12
	444D-36		206L-5-2		335E-12
	444E-36		206A-6		335G-12
	444F-36		206D-6		335H-12
	206A-4		206F-6		335J-12
	206B-4		206G-6		335A-18
21210-89L00	206C-4	23115-89L10	206H-6	29404-93J10	335B-18
	206D-4		206L-6		335C-22
	206E-4		206B-6		335D-18
	206F-4		206C-6		335E-18
	206G-4		206E-6		335F-22
	206H-4		206J-6		335G-18
	206J-4		206K-6		335H-18
	206K-4		513A-10		335J-18
	206L-4		513B-10		335K-22
	336A-1		513C-10		335L-22
22511-99011	336B-1	23211-89L00	513D-10	29440-93J00	502A-15
	336C-1-1		206A-7		502B-15
	336C-1-2		206B-7		502C-15
	336D-1		206C-7		502D-15
	336E-1		206D-7		502E-15
	336F-1-1		206E-7		336A-21
	336F-1-2		206F-7		336B-21
	336G-1		206G-7		336C-11
	336H-1		206H-7		336D-21
	336J-1		206J-7		336E-21

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	336F-11	31151-94J01	301A-4		561A-5
	336G-21	31152-90J00	301A-5		561B-5
	336H-21	31153-90J00	301A-6		561C-5
	336J-21	31170-94J00	301A-17		561D-5
	336K-11	31171-96J00	301A-7	32120-89L10	303A-1
	336L-11	31173-94J01	301A-8		303B-1
		31174-89LA0	340A-2		303C-1
			340B-2	32800-89L00	303D-1
			340C-2		310A-1
			340D-2		310B-1
		31191-96J00	301A-9		310C-1
		31192-94J01	338A-11		310D-1
			338B-11		310E-1
			338C-11		310F-1
			338D-11		310G-1
			338A-10		310H-1
			338B-10		310J-1
			338C-10		310K-1
			338D-10		310L-1
		31220-94J00	301A-10		561A-6
		31281-94J01	338A-12		561B-6
			338B-12		561C-6
			338C-12	32800-94J11	561D-6
			338D-12		553A-3
					553B-3
		31310-90J00	301A-11		553C-3
		31311-94J00	340A-9		553D-3
			340B-9	32801-89L00	553A-2
			340C-9		553B-2
			340D-9		553C-2
		31320-94J00	301A-12		553D-2
		31341-94J00	301A-13	32815-89L00	310A-2
		31343-90J00	301A-14		310B-2
		31344-90J00	301A-15		310C-2
		31360-93J01	301A-16		310D-2
		31912-89L00	301A-18		310E-2
		31918-94J00	301A-19		310F-2
		32000-89L00	553A-1		310G-2
			553B-1		310H-2
			553C-1		310J-2
			553D-1		310K-2
		32102-89L00	303E-4		310L-2
			561A-4		561A-7
			561B-4		561C-4
			561C-4		561D-4
			561D-4		561C-7
		32102-89L10	303A-4		561D-7
			303B-4	32815-89L10	553A-4
			303C-4		553B-4
			303D-4		553C-4
		32120-89L00	303E-1		553D-4

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
32890-89L01	310A-4		322B-8	33920-89L41	310A-13-1
	310B-4		322C-8		310B-13
	310C-4		322D-13		310C-13
	310D-4		322E-8		561A-24
	310E-4		322F-13	33920-89L51	310A-13-2
	310F-4		322G-13	33920-89L61	310H-13-1
	310G-4		322H-13		561D-24
	310H-4		322J-8	33920-89L71	310H-13-2
	310J-4		322K-8	33925-89L00	310A-14
	310K-4		322L-13		310B-14
	310L-4	33799-97E00	340A-6		310C-14
32916-89L00	322A-11		340B-6		310D-14
	322B-7		340C-6		310E-14
	322C-7		340D-6		310F-14
	322D-11	33800-89L01	561A-12		310G-14
	322E-7		561B-12		310H-14
	322F-11		561C-12		310J-14
	322G-11		561D-12		310K-14
	322H-11	33810-89L02	322A-1		310L-14
	322J-7		322B-1	34011-87L00	503A-1
	322K-7		322C-1		503B-1
	322L-11		322D-1		503C-1
33220-84M10	303A-9		322E-1		503D-1
	303B-9		322F-1		503E-1
	303C-9		322G-1	34011-87L10	503A-10
	303D-9		322H-1		503B-10
	303E-9		322J-1		503C-10
33410-89L00	310A-11		322K-1		503D-10
	310B-11		322L-1		503E-10
	310C-11		561A-13	34011-87L40	503A-25
	310D-11		561B-13		503B-25
	310E-11		561C-13		503C-25
	310F-11		561D-13		503D-25
	310G-11	33833-91J00	444A-21		503E-25
	310H-11		444B-21	34011-87L50	503A-37
	310J-11		444C-21		503B-37
	310K-11		444D-21		503C-37
	310L-11		444E-21		503D-37
33500-07H00	310A-9		444F-21		503E-37
	310B-9	33920-89L02	310D-13-1	34011-88L04	502A-1
	310C-9		310E-13		502B-1
	310D-9		310F-13		502C-1
	310E-9		561B-24		502D-1
	310F-9	33920-89L12	310D-13-2		502E-1
	310G-9	33920-89L22	310G-13-1	34011-89L02	502A-7
	310H-9		310J-13		502B-7
	310J-9		310K-13		502C-7
	310K-9		310L-13		502D-7
	310L-9		561C-24		502E-7
33634-96J00	322A-13	33920-89L32	310G-13-2	34100-93J20	502A-26-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
34100-93J31	502B-26-1	34193-88L60	588B-4		503B-27
	502C-26-1		588C-4		503B-39
	502D-26-1		588D-4		503C-3
	502E-26-1		588E-4		503C-12
34100-93J40	502A-26-2	34200-87L12	588A-5		503C-27
	502B-26-2		588B-5		503C-39
	502C-26-2		588C-5		503D-3
	502D-26-2		588D-5		503D-12
34100-93J51	502E-26-2		588E-5		503D-27
	502A-26-3		503A-2		503D-39
	502B-26-3		503A-11		503E-3
	502C-26-3		503A-26		503E-12
34190-87D00	502D-26-3		503A-38	34300-93J00	503E-27
	502E-26-3		503B-2		503E-39
	502A-26-4		503B-11		502A-36-1
	502B-26-4		503B-26		502B-36-1
34190-88L00	502C-26-4		503B-38	34300-93J11	502C-36-1
	502D-26-4		503C-2		502D-36-1
	502E-26-4		503C-11		502E-36-1
	502A-33		503C-26		502A-36-2
34190-95500	502B-33	34200-88L02	503C-38	34310-92E00	502B-36-2
	502C-33		503D-2		502C-36-2
	502D-33		503D-11		502D-36-2
	502E-33		503D-26		502E-36-2
34190-98L00	588A-1		503D-38	34360-92E00	502A-38
	588B-1		503E-2		502B-38
	588C-1		503E-11		502C-38
	588D-1		503E-26		502D-38
34191-92E00	588E-1	34200-93J20	503E-38	34455-88L00	502E-38
	502A-31		502A-2		588A-6
	502B-31		502B-2		588B-6
	502C-31		502C-2		588C-6
34193-88L00	502D-31	34200-93J32	502D-2	34455-88L10	588D-6
	502E-31		502E-2		588E-6
	502A-28		502A-34-1		588A-7
	502B-28		502B-34-1		588B-7
34193-88L20	502C-28		502C-34-1	34500-93J00	588C-7
	502D-28		502D-34-1		588D-7
	502E-28		502E-34-1		588E-7
	588A-2		502A-34-2		502A-20-1
34193-88L40	588B-2	34211-87L00	502B-34-2	34500-93J11	502B-20-1
	588C-2		502C-34-2		502C-20-1
	588D-2		502D-34-2		502D-20-1
	588E-2		502E-34-2		502E-20-1
34193-88L40	588A-3		503A-3		502A-20-2
	588B-3		503A-12		
	588C-3		503A-27		
	588D-3		503A-39		
	588E-3		503B-3		
	588A-4		503B-12		

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
34600-93J00	502B-20-2	36367-89L00	334A-4		502B-30
	502C-20-2		334B-4		502B-40
	502D-20-2		334C-4		502C-22
	502E-20-2		334D-4		502C-25
34600-93J11	502A-23-1		334E-4	36610-89L03	502C-30
	502B-23-1		334F-4		502C-40
	502C-23-1		334G-4		502D-22
	502D-23-1		334H-4		502D-25
34800-88L01	502E-23-1		334J-4		502D-30
	502A-23-2		334K-4		502D-40
	502B-23-2		334L-4		502E-22
	502C-23-2		322A-5-1		502E-25
34810-88L00	502D-23-2		322D-5-1	36610-89L13	502E-30
	502E-23-2		322G-5-1		502E-40
	502A-8		322H-5-1		503A-5
	502B-8		561A-19		503A-14
34922-88L03	502C-8		561B-19	36610-89L22	503B-5
	502D-8		561C-19		503B-14
	502E-8		561D-19		503C-5
	588A-8		322A-5-2		503C-14
34960-88L00	588B-8		322D-5-2	36616-89L02	503D-5
	588C-8		322G-5-2		503D-14
	588D-8		322H-5-2		503E-5
	588E-8		322B-2		503E-14
36360-99J10	502A-3		322E-2	36617-89L01	334A-10
	502B-3		322J-2		334B-9
	502B-9		513A-11		334C-9
	502C-3		513B-11		334D-10
36360-99J10	502C-9	36610-89L41	513C-11	36615-96300	334E-9
	502D-3		513D-11		334F-9
	502D-9		322F-5		334G-10
	502E-3		322L-5		334H-10
36360-99J10	502E-9	36610-89L51	322C-2		334J-9
	588A-9		322K-2		334K-9
	588B-9		303A-12		334L-9
	588C-9		303B-12		322A-14
36360-99J10	588D-9		303C-12	36617-89L10	322B-9
	588E-9		303D-12		322D-14
	334A-3		322A-9		322E-9
	334B-3		322D-9		322G-14
36360-99J10	334C-3		322F-9		322H-14
	334D-3		322G-9		322J-9
	334E-3		322H-9		322A-12
	334F-3		322L-9		322D-12
36360-99J10	334G-3		502A-22		322F-12
	334H-3		502A-25		322G-12
	334J-3		502A-30		322H-12
	334K-3		502A-40		322L-12
36360-99J10	334L-3		502B-22		561A-14
			502B-25		561B-14

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
36617-89L20	561C-14		450D-52	36662-88L10	503E-28
	561D-14		546A-1		503E-40
	322C-10		546B-1		588A-10
	322K-10		546C-1		588B-10
36617-89L30	322C-9	36628-92E00	546D-1	36662-88L20	588C-10
36617-89L40	322F-14		546E-1		588D-10
	322K-9		546F-1		588E-10
	322L-14		450A-2		588A-11
36617-91J00	322C-17		450B-3	36662-88L30	588B-11
	322F-22		450C-2		588C-11
	322K-17		450D-2		588D-11
	322L-22		450E-3		588E-11
	322A-15	36634-93910	508A-2	36663-88L00	588A-12
	322B-10		508B-2		588B-12
	322D-15		508C-2		588C-12
	322E-10		508D-2		588D-12
36618-43410	322F-15	36646-93J01	553A-13		588E-12
	322G-15		553B-13		502A-4
	322H-15		553C-13		502A-11
	322J-10		553D-13		502B-4
	322L-15	36660-89L01	450B-2	36664-88L00	502B-11
	322A-8		450E-2		502C-4
	322B-5		502A-14		502C-11
	322C-5		502B-14		502D-4
	322D-8	36661-87L00	502C-14		502D-11
	322E-5		502D-14		502E-4
	322F-8		502E-14		502E-11
	322G-8		503A-4		503A-15
	322H-8		503A-13	36665-88L10	503A-29
	322J-5		503B-4		503B-15
	322K-5		503B-13		503B-29
	322L-8		503C-4		503C-15
	513A-12	36620-93J02	503C-13	36663-88L10	503C-29
	513B-12		503D-4		503D-15
	513C-12		503D-13		503D-29
	513D-12		503E-4		503E-15
36620-93J10	450B-54	36662-88L00	503E-13		503E-29
	450E-54		502A-10		588A-13
	322B-17-1		502B-10		588B-13
	322C-19-1		502C-10		588C-13
	322E-17-1		502D-10	36663-98J00	588D-13
	322J-17-1		502E-10		588E-13
	322K-19-1		503A-28		502A-18-1
	322B-17-2		503A-40		502B-18-1
36620-93J40	322C-19-2		503B-28	36663-98J10	502C-18-1
	322E-17-2		503B-40		502D-18-1
	322J-17-2		503C-28		502E-18-1
	322K-19-2		503C-40		502A-18-2
36620-94J01	450A-52		503D-28		502B-18-2
	450C-52		503D-40		502C-18-2

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	502D-18-2	36665-88L00	503E-19		503C-43
	502E-18-2		503E-32		503D-22
	503A-6		503D-5		503D-35
	503A-16		502A-12		503D-43
	503B-6		502B-5	36666-88L00	503E-22
	503B-16		502B-12		503E-35
	503C-6		502C-5		503E-43
	503C-16		502C-12		588A-14
36664-87L00	503D-6		502D-5	36666-88L10	588B-14
	503D-16		502D-12		588C-14
	503E-6		502E-5		588D-14
	503E-16		502E-12		588E-14
	503A-30		503A-20	36682-92E00	588A-15
	503A-41		503A-33		588B-15
	503B-30		503B-20		588C-15
	503B-41		503B-33		588D-15
	503C-30	36665-88L10	503C-20		588E-15
	503C-41		503C-33		502A-17
	503D-30		503D-20		502B-17
	503D-41		503D-33		502C-17
36664-88L00	503E-30		503E-20	36740-94J00	502D-17
	503E-41		503E-33		502E-17
	503A-18		502A-6		503A-36
	503A-31		502A-13		503A-44
	503A-42		502B-6	36890-93J00	503B-36
	503B-18		502B-13		503B-44
	503B-31		502C-6		503C-36
	503B-42		502C-13		503C-44
	503C-18		503D-6	36740-94J00	503D-36
	503C-31		502D-13		503D-44
	503C-42		502E-6		503E-36
	503D-18		502E-13		503E-44
	503D-31	36665-87L00	503A-21		553A-10
	503D-42		503A-34		553B-10
	503E-18		503B-21		553C-10
	503E-31		503B-34		553D-10
	503E-42	36666-87L00	503C-21	36890-93J00	544A-16
	588A-17		503C-34		544B-16
	588B-17		503D-21		544C-16
	588C-17		503D-34		544D-16
	588D-17		503E-21	36894-87D00	544E-16
	588E-17		503E-34		544F-16
	503A-19		503A-22		544G-16
	503A-32		503A-35		544H-16
	503B-19		503A-43		544J-16
	503B-32		503B-22		335C-9
	503C-19		503B-35		335C-10
	503C-32		503B-43		335F-9
	503D-19		503C-22		335F-10
	503D-32		503C-35		335K-9

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
36895-87D01	335K-10	37110-93J11	530E-14		530B-3-2
	335L-9		450B-4		530B-15-2
	335L-10		450E-4		530C-3-2
	335C-11		450A-3		530C-15-2
36990-87D00	335F-11	37110-94J02	450C-3	37141-99E20	530D-3-2
	335K-11		450D-3		530D-15-2
	335L-11		508A-3		530E-3-2
	503A-8		508B-3		530E-15-2
	503A-23		508C-3		450A-4-3
	503B-8		508D-3		450B-5-3
	503B-23		530A-6		450C-4-3
	503C-8		530B-6		450D-4-3
	503C-23		530C-6		450E-5-3
	503D-8		530D-6		508A-4-3
	503D-23	37139-99E00	530E-6	37141-99E20	508B-4-3
	503E-8		530A-18		508C-4-3
	503E-23		530B-18		508D-4-3
	546A-3		530C-18		530A-3-3
	546B-3		530D-18		530A-15-3
	546C-3		530E-18		530B-3-3
	546D-3		450A-4-1		530B-15-3
	546E-3		450B-5-1		530C-3-3
36991-91J00	546F-3	37141-99E00	450C-4-1	37141-99E30	530C-15-3
	553A-17		450D-4-1		530D-3-3
	553B-17		450E-5-1		530D-15-3
	553C-17		508A-4-1		530E-3-3
	553D-17		508B-4-1		530E-15-3
	322C-18		508C-4-1		450A-4-4
	322F-23		508D-4-1		450B-5-4
	322K-18		530A-3-1		450C-4-4
	322L-23		530A-15-1		450D-4-4
	530A-1		530B-3-1		450E-5-4
37100-96J00	530B-1	37100-96J24	530B-15-1	37141-99E10	508A-4-4
	530C-1		530C-3-1		508B-4-4
	530D-1		530C-15-1		508C-4-4
	530E-1		530D-3-1		508D-4-4
	530A-13	37110-93J01	530D-15-1	37141-99E40	530A-3-4
	530B-13		530E-3-1		530A-15-4
	530C-13		530E-15-1		530B-3-4
	530D-13		450A-4-2		530B-15-4
	530E-13	37110-93J01	450B-5-2	37141-99E40	530C-3-4
	530A-2		450C-4-2		530C-15-4
	530A-14		450D-4-2		530D-3-4
	530B-2		450E-5-2		530D-15-4
	530B-14	37110-93J01	508A-4-2	37141-99E40	530E-3-4
	530C-2		508B-4-2		530E-15-4
	530C-14		508C-4-2		450A-4-5
	530D-2		508D-4-2		450B-5-5
	530D-14		530A-3-2		450C-4-5
	530E-2		530A-15-2		450D-4-5

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	450E-5-5	37141-99E70	530D-15-7		530A-3-10
	508A-4-5		530E-3-7		530A-15-10
	508B-4-5		530E-15-7		530B-3-10
	508C-4-5		450A-4-8		530B-15-10
	508D-4-5	37141-99E70	450B-5-8	37141-99E80	530C-3-10
	530A-3-5		450C-4-8		530C-15-10
	530A-15-5		450D-4-8		530D-3-10
	530B-3-5		450E-5-8		530D-15-10
	530B-15-5		508A-4-8		530E-3-10
	530C-3-5		508B-4-8		530E-15-10
	530C-15-5		508C-4-8		450A-4-11
	530D-3-5		530D-4-8		450B-5-11
	530D-15-5		530A-3-8		450C-4-11
	530E-3-5		530A-15-8		450D-4-11
37141-99E50	530E-15-5	37141-99E50	530B-3-8	37141-99E80	450E-5-11
	450A-4-6		530B-15-8		508A-4-11
	450B-5-6		530C-3-8		508B-4-11
	450C-4-6		530C-15-8		508C-4-11
	450D-4-6		530D-3-8		508D-4-11
	450E-5-6		530D-15-8		530A-3-11
	508A-4-6		530E-3-8		530A-15-11
	508B-4-6		530E-15-8		530B-3-11
	508C-4-6	37141-99E80	450A-4-9	37141-99E80	530B-15-11
	508D-4-6		450B-5-9		530C-3-11
	530A-3-6		450C-4-9		530C-15-11
	530A-15-6		450D-4-9		530D-3-11
	530B-3-6		450E-5-9		530D-15-11
	530B-15-6		508A-4-9		530E-3-11
	530C-3-6		508B-4-9		530E-15-11
	530C-15-6		508C-4-9		450A-4-12
	530D-3-6		508D-4-9		450B-5-12
	530D-15-6		530A-3-9		450C-4-12
37141-99E60	530E-3-6	37141-99E60	530A-15-9	37141-99E90	450D-4-12
	530E-15-6		530B-3-9		450E-5-12
	450A-4-7		530B-15-9		508A-4-12
	450B-5-7		530C-3-9		508B-4-12
	450C-4-7		530C-15-9		508C-4-12
	450D-4-7		530D-3-9		508D-4-12
	450E-5-7		530D-15-9		530A-3-12
	508A-4-7		530E-3-9		530A-15-12
	508B-4-7		530E-15-9		530B-3-12
	508C-4-7		450A-4-10		530B-15-12
	508D-4-7	37141-99E90	450B-5-10	37143-99E00	530C-3-12
	530A-3-7		450C-4-10		530C-15-12
	530A-15-7		450D-4-10		530D-3-12
	530B-3-7		450E-5-10		530D-15-12
	530B-15-7		508A-4-10		530E-3-12
	530C-3-7		508B-4-10		530E-15-12
	530C-15-7	37143-99E00	508C-4-10		450A-5
	530D-3-7		508D-4-10		450B-6

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	450C-5		334E-5		334K-10
	450D-5		334G-6		334L-10
	450E-6		334H-6	37726-89L00	334A-8
	508A-5		334J-5		334B-7
	508B-5		334K-5		334C-7
	508C-5		513A-15		334D-8
	508D-5		513B-15		334E-7
	530A-4		513C-15		334F-7
	530A-16		513D-15		334G-8
	530B-4	37210-93J00	530A-11		334H-8
	530B-16		530B-11		334J-7
	530C-4		530C-11		334K-7
	530C-16		530D-11		334L-7
	530D-4		530E-11	37801-98300	553A-11
	530D-16	37212-93J00	530A-12		553B-11
	530E-4		530B-12		553C-11
37149-93J00	530E-16		530C-12		553D-11
	450A-6		530D-12	37803-93J04	530A-9
	450B-7		530E-12		530B-9
	450C-6	37721-89L00	334A-7		530C-9
	450D-6		334B-6		530D-9
	450E-7		334C-6		530E-9
	508A-6		334D-7	37820-80001	334A-2
	508B-6		334E-6		334B-2
	508C-6		334F-6		334C-2
	508D-6		334G-7		334D-2
	530A-5		334H-7		334E-2
	530A-17		334J-6		334F-2
	530B-5		334K-6		334G-2
	530B-17		334L-6		334H-2
	530C-5	37721-93J91	450B-8		334J-2
	530C-17		450E-8		334K-2
	530D-5	37721-95500	545A-11		334L-2
	530D-17		545B-11	37820-93J04	450A-7
	530E-5		545C-11		450B-9
37161-89L01	530E-17		545D-11		450C-7
	334A-5		545E-11		450D-7
	334D-5		545F-11		450E-9
	334F-5		545G-11		508A-7
	334G-5		545H-11		508B-7
	334H-5		545J-11		508C-7
	334L-5	37725-89L01	334A-11		508D-7
	561A-15		334B-10		530A-19
	561B-15		334C-10		530B-19
	561C-15		334D-11		530C-19
37163-89L00	561D-15		334E-10		530D-19
	334A-6		334F-10		530E-19
	334B-5		334G-11	37823-92E01	450A-8
	334C-5		334H-11		450B-10
	334D-6		334J-10		450C-8

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	450D-8		444C-35		327D-1
	450E-10		444D-35	38415-89L00	327A-2
	508A-8		444E-35		327B-2
	508B-8		444F-35		327C-2
	508C-8	37850-90J05	450B-12		327D-2
	508D-8		450E-12	38500-93J00	450A-12
	530A-20	37850-93J10	544A-4		450C-12
	530B-20		544B-4		450D-12
	530C-20		544C-4		508A-12
	530D-20		544D-4		508B-12
	530E-20		544E-4		508C-12
37823-97J00	444A-33		544F-4		508D-12
	444B-33		544G-4	38500-93J90	450B-13
	444C-33		544H-4		450E-13
	444D-33		544J-4		530A-7
	444E-33	37850-94JA2	327B-3		530A-23
	444F-33		327D-3		530B-7
37825-99E00	530A-10	37850-99E04	327A-3		530B-23
	530B-10		327C-3		530C-7
	530C-10	37851-89L00	327B-10		530C-23
	530D-10		327D-10		530D-7
37826-92J00	530E-10	37852-94JA0	327B-4		530D-23
	450A-9		327D-4		530E-7
	450B-11	37859-90J00	450A-10		530E-23
	450C-9		450B-51	38860-76F01	301A-20
	450D-9		450C-10		310A-15
	450E-11		450D-10		310B-15
	508A-9		450E-51		310C-15
	508B-9		508A-10		310D-15
	508C-9		508B-10		310E-15
	508D-9		508C-10		310F-15
	530A-21	37864-94J10	508D-10		310G-15
	530B-21		450A-11		310H-15
	530C-21		450C-11		310J-15
	530D-21		450D-11		310K-15
37826-97J00	530E-21		508A-11		310L-15
	444A-34		508B-11		561A-20
	444B-34		508C-11		561B-20
	444C-34		508D-11		561C-20
	444D-34	38100-89LA0	338A-14		561D-20
	444E-34		338B-14	38915-90J00	301A-21
	444F-34		338C-14		310A-16
37830-89L00	444A-32		338D-14		310B-16
	444B-32		340A-1		310C-16
	444C-32		340B-1		310D-16
	444D-32		340C-1		310E-16
	444E-32		340D-1		310F-16
	444F-32	38410-93J20	327A-1		310G-16
37835-95D00	444A-35		327B-1		310H-16
	444B-35		327C-1		310J-16

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	310K-16		335L-1		335J-25
	310L-16	41121-89L00-0EP	335A-2	41211-95J00	335C-4
	561A-21		335B-2		335F-4
	561B-21		335D-2		335K-4
	561C-21		335E-2		335L-4
39600-89L00	561D-21		335G-2	41211-99JL0	335A-3
	553A-9		335H-2		335B-3
	553B-9	41121-89LA0-0EP	335J-2		335D-3
	553C-9		335C-2		335E-3
	553D-9		335F-2		335G-3
39601-95D00	553A-12		335K-2		335H-3
	553B-12		335L-2		335J-3
	553C-12	41130-89L00	335B-7	41212-91J00	335A-4
	553D-12		335E-7		335B-4
39602-93900	553A-14		335J-7		335C-5
	553B-14		513A-16		335D-4
	553C-14		513B-16		335E-4
	553D-14		513C-16		335F-5
39950-87L00	503A-9		513D-16		335G-4
	503A-24	41130-90L00	335A-7		335H-4
	503B-9		335D-7		335J-4
	503B-24		335G-7		335K-5
	503C-9		335H-7		335L-5
	503C-24	41130-94JA1	335C-7	41213-94J01	335A-5
	503D-9		335F-7		335B-5
	503D-24		335K-7		335C-6
	503E-9		335L-7		335D-5
39950-88L00	503E-24	41135-93JL0	335C-8		335E-5
	588A-16		335F-8		335F-6
	588B-16		335K-8		335G-5
	588C-16		335L-8		335H-5
	588D-16	41161-94400	442A-1		335J-5
	588E-16		442B-1		335K-6
			442C-1		335L-6
			442D-1	41221-94JA0	335C-14
			442E-1		335F-14
40000			575A-1		335K-14
			575B-1		335L-14
			575C-1	41222-94JA0	335C-15
			575D-1		335F-15
41111-89L00-0EP	335A-1	41210-89LA0	335C-28		335K-15
	335B-1		335F-28		335L-15
	335D-1		335K-28	41225-89L00	336A-9
	335E-1		335L-28		336B-9
	335G-1	41210-99JL1	335A-25		336D-9
	335H-1		335B-25		336E-9
	335J-1		335D-25		336G-9
41111-89LA0-0EP	335C-1		335E-25		336H-9
	335F-1		335G-25		336J-9
	335K-1		335H-25	41226-94JA0	335C-16

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	335F-16		336H-19		336L-20
	335K-16		336J-19	43517-89L00	336A-34
43111-89L00-0EP	335L-16		336K-9		336D-34
	336A-2-1		336L-9		336F-21
	336B-2-1	43412-93900	336A-20		336G-34
	336D-2-1		336B-20		336H-34
	336E-2-1		336C-10	43711-94JA0	336L-21
	336G-2-1		336D-20		336C-3
	336H-2-1		336E-20		336F-3
	336J-2-1		336F-10		336K-3
43111-89L11-0EP	336A-2-2		336G-20		336L-3
	336B-2-2		336H-20	43711-99J00	336A-3
	336D-2-2		336J-20		336B-3
	336E-2-2		336K-10		336D-3
	336G-2-2		336L-10		336E-3
	336H-2-2	43415-89L00	336A-28		336G-3
43111-89LA0-0EP	336J-2-2		336D-28		336H-3
	336C-2-2		336F-15		336J-3
	336F-2-2		336G-28	43750-99J60-0EP	336A-4-1
	336K-2-2		336H-28		336B-4-1
	336L-2-2		336L-15		336C-4-1
43111-89LB0-0EP	336C-2-1	43420-89L00	336A-29		336D-4-1
	336F-2-1		336D-29		336E-4-1
	336K-2-1		336F-16		336F-4-1
	336L-2-1		336G-29		336G-4-1
43112-99E00	405A-4		336H-29		336H-4-1
43211-87JL0	336A-7		336L-16		336J-4-1
	336B-7	43425-89L00	336A-30		336K-4-1
	336C-7		336D-30		336L-4-1
	336D-7		336F-17	43750-99J70-0EP	336A-4-2
	336E-7		336G-30		336B-4-2
	336F-7		336H-30		336C-4-2
	336G-7		336L-17		336D-4-2
	336H-7	43512-89L00	336A-31		336E-4-2
	336J-7		336D-31		336F-4-2
	336K-7		336F-18		336G-4-2
43411-89L00	336L-7		336G-31		336H-4-2
	336A-27		336H-31		336J-4-2
	336D-27		336L-18		336K-4-2
	336G-27	43515-88L00	336A-32		336L-4-2
	336H-27		336D-32	43755-99J00	336B-27
43411-89LA0	336F-14		336F-19		336C-14
	336L-14		336G-32		336E-27
43411-939L0	336A-19		336H-32		336J-27
	336B-19		336L-19		336K-14
	336C-9	43516-89J00	336A-33		513A-17
	336D-19		336D-33		513B-17
	336E-19		336F-20		513C-17
	336F-9		336G-33		513D-17
	336G-19		336H-33	43759-89L00	336B-31

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	336C-18	45269-89L00	335A-23	48121-94JA0	338A-16
	336E-31		335B-23		338B-16
	336J-31		335D-23		338C-16
	336K-18		335E-23		338D-16
	513A-18		335G-23	48321-97E01	338A-17
	513B-18		335H-23		338B-17
	513C-18		335J-23		338C-17
	513D-18	45420-89L00	335A-19		338D-17
45212-89L00	336A-10		335B-19	48325-97E00	338A-18
	336B-10		335D-19		338B-18
	336D-10		335E-19		338C-18
	336E-10		335G-19		338D-18
	336G-10		335H-19	48510-94600	338A-5
	336H-10		335J-19		338B-5
	336J-10	45421-94JA0	335C-17		338C-5
45231-89L00	336A-11		335F-17		338D-5
	336B-11		335K-17	48553-88L00	338A-4
	336D-11		335L-17		338B-4
	336E-11	45425-94J01	335A-20		338C-4
	336G-11		335B-20		338D-4
	336H-11		335D-20	48572-94J00	338A-8
	336J-11		335E-20		338B-8
45241-89L00	336A-12		335G-20		338C-8
	336B-12		335H-20		338D-8
	336D-12		335J-20	48582-97E00	338A-13
	336E-12	45710-89L00	336A-24-1		338B-13
	336G-12		336B-24-1		338C-13
	336H-12		336D-24-1		338D-13
45247-99J00	336J-12		336E-24-1	48583-95E00	338A-6
	336A-14		336G-24-1		338B-6
	336B-14		336H-24-1		338C-6
	336D-14		336J-24-1		338D-6
	336E-14	45710-89L10	336A-24-2	48664-87D00	338A-9
	336G-14		336B-24-2		338A-15
	336H-14		336D-24-2		338B-9
	336J-14		336E-24-2		338B-15
45250-89L03	336A-15		336G-24-2		338C-9
	336B-15		336H-24-2		338C-15
	336D-15		336J-24-2		338D-9
	336E-15	45722-94J11	336A-25		338D-15
	336G-15		336B-25	48681-87J11	338A-3
	336H-15		336D-25		338B-3
	336J-15		336E-25		338C-3
45261-89L00	335A-13		336G-25		338D-3
	335B-13		336H-25	48864-89LA0	338A-2
	335D-13		336J-25		338B-2
	335E-13	48000-89LA0	338A-1		338C-2
	335G-13		338B-1		338D-2
	335H-13		338C-1		
	335J-13		338D-1		

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	50000		336C-20-1		220D-1-2
			336F-25-1		220E-1-2
			336K-20-1		220F-1-2
			336L-25-1		220G-1-2
			338A-19-1		220H-1-2
			338B-19-1		220J-1-2
			338C-19-1		220K-1-2
			338D-19-1		220L-1-2
			407A-6	57100-90L40	220A-1-1
51110-89L02	401A-1	55321-87J10	335C-20-2		220B-1-1
51211-89L00	401A-2		335F-20-2		220C-1-1
52110-89L00-0EP	405A-3-1		335K-20-2		220D-1-1
52110-89L10-0EP	405A-3-2		335L-20-2		220E-1-1
52113-89L00	405A-5		336C-20-2		220F-1-1
52131-89L00-0EP	405A-16		336F-25-2		220G-1-1
54112-99J01	401A-7		336K-20-2		220H-1-1
54113-99J00	401A-8		336L-25-2		220J-1-1
54125-99J00	401A-10		338A-19-2		220K-1-1
54127-89L00	401A-9		338B-19-2		220L-1-1
54130-89L00	401A-11		338C-19-2	57100-90L50	220A-1-3
54137-89L00	401A-12		338D-19-2		220B-1-3
54144-89L10	410A-17		407A-23		220C-1-3
	410B-17		410F-17	55331-99J10	220D-1-3
	410C-17		410G-17	55332-99J10	220E-1-3
	410D-17		410H-17	56120-99J40-0EP	220F-1-3
	410E-17		410J-17	56130-99J30	220G-1-3
	410F-17		410K-17		220H-1-3
	410G-17		410L-17		220J-1-3
	410H-17		410A-18		220K-1-3
54145-89L00	410A-18		410B-18		220L-1-3
	410C-18		410D-18	57311-99J10	220A-8
	410E-18		410F-18		220B-8
	410G-18		410H-18		220C-8
	410I-18		410J-18		220D-8
	410K-18		410L-18		220E-8
	410L-18		405A-10		220F-8
	405A-11		405A-11		220G-8
54151-99J00	405A-12		405A-12		220H-8
54167-99J01	405A-14		405A-14		220J-8
54211-99J01-0EP	405A-13		405A-13		220K-8
54213-93901	407A-1		407A-1		220L-8
54221-99J01-0EP	111A-7		111A-7		220A-9
55100-99J40-0EP	335C-20-1		335C-20-1		220B-9
55321-87J00	335F-20-1		335F-20-1		220C-9
	335K-20-1		335K-20-1		220D-9
	335L-20-1		335L-20-1		220E-9
					220F-9
					220G-9
					220H-9
					220J-9

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
57521-99J10	220K-9		220D-20		420K-12
	220L-9		220E-20		420L-12
	220A-10		220F-20		
	220B-10		220G-20		
	220C-10		220H-20		
57610-99JL0	220D-10		220J-20	60000	
	220E-10		220K-20		
	220F-10		220L-20		
	220G-10	58100-89L00-019	407A-15-1		
	220H-10	58100-89L20-019	407A-15-2		
	220J-10	58100-89L30-019	407A-15-3	61112-89L10	410A-4
	220K-10	58100-89L40-019	407A-15-4		410B-4
	220L-10	58100-89L50-019	407A-15-5		410C-4
	220A-14	58100-90L40-019	407A-15-6		410D-4
	220B-14	58100-90L50-019	407A-15-7		410E-4
	220C-14	58100-90L60-019	407A-15-8		410F-4
	220D-14	58120-89L00	407A-16		410G-4
	220E-14	59178-97J00	407A-8		410H-4
	220F-14	59262-94J00	175A-13		410J-4
	220G-14	59441-94J00	220A-17		410K-4
	220H-14		220B-17	61124-89L20	410L-4
	220J-14		220C-17		410B-13
	220K-14		220D-17		410E-13
	220L-14		220E-17		410J-13
	220A-15		220F-17		513A-21
57621-99J11	220B-15		220G-17	61124-89L30	513B-21
	220C-15		220H-17		513C-21
	220D-15		220J-17		513D-21
	220E-15		220K-17		410C-13
	220F-15		220L-17		410K-13
	220G-15	59441-99J00	220A-18	61124-89L40	410A-13
	220H-15		220B-18		410D-13
	220J-15		220C-18		410F-13
	220K-15		220D-18		410G-13
	220L-15		220E-18		410H-13
57631-93901	220A-19		220F-18	61134-89L00	410L-13
	220B-19		220G-18		410A-5
	220C-19		220H-18		410B-5
	220D-19		220J-18		410C-5
	220E-19		220K-18		410D-5
	220F-19		220L-18	61435-89L00	410E-5
	220G-19	59800-89L00	420A-12		410F-5
	220H-19		420B-12		410G-5
	220J-19		420C-12		410H-5
	220K-19		420D-12		410J-5
57632-94J00 57632-98501	220L-19		420E-12	61151-91J11	410K-5
	407A-17		420F-12		410L-5
	220A-20		420G-12		146A-43
	220B-20		420H-12		410A-14
	220C-20		420J-12		410B-14

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	410C-14	61435-99J10	420A-8		420L-10
	410D-14		420B-8	61471-89L00	420A-11
	410E-14		420C-8		420B-11
	410F-14	61443-99J00	420A-5		420C-11
	410G-14		420B-5		420D-11
	410H-14		420C-5		420E-11
	410J-14		420D-5		420F-11
	410K-14		420E-5		420G-11
	410L-14		420F-5		420H-11
61400-89L10-0EP	420A-1		420G-5		420J-11
	420B-1		420H-5		420K-11
	420C-1		420J-5		420L-11
	420D-1		420K-5	61472-94J00	167H-13
	420E-1		420L-5	61472-94J10	167A-13
	420F-1	61446-89L00	420A-9		167B-13
	420G-1		420B-9		167C-13
	420H-1		420C-9		167D-13
	420J-1		420D-9		167E-13
	420K-1		420E-9		167F-13
	420L-1		420F-9		167G-13
61412-89L00	410A-9		420G-9		167J-13
	410B-9		420H-9		167K-13
	410C-9		420J-9		167L-13
	410D-9		420K-9	61493-94J00	167A-15
	410E-9		420L-9		167B-15
	410F-9	61447-94J00	420C-14		167C-15
	410G-9		420F-14		167D-15
	410H-9		420K-14		167E-15
	410J-9		420L-14		167F-15
	410K-9	61453-99J00	420A-6		167G-15
	410L-9		420B-6		167H-15
61433-89L01	420A-2		420C-6		167J-15
	420B-2		420D-6		167K-15
	420C-2		420E-6		167L-15
	420D-2		420F-6	61494-94J00	167A-16
	420E-2		420G-6		167B-16
	420F-2		420H-6		167C-16
	420G-2		420J-6		167D-16
	420H-2		420K-6		167E-16
	420J-2		420L-6		167F-16
	420K-2	61458-89L00	420A-10		167G-16
	420L-2		420B-10		167H-16
61435-89L00	420G-8		420C-10		167J-16
	420H-8		420D-10		167K-16
	420J-8		420E-10		167L-16
	420K-8		420F-10	61610-90L00	410A-10
	420L-8		420G-10		410B-10
61435-94J30	420D-8		420H-10		410C-10
	420E-8		420J-10		410D-10
	420F-8		420K-10		410E-10

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
61616-93EL0	410F-10	61827-89L00	410A-15	63121-99J00-0EP	444E-4
	410G-10		410B-15		444F-4
	410H-10		410C-15		444A-5
	410J-10		410D-15		444B-5
	410K-10		410E-15		444C-5
	410L-10		410F-15		444D-5
	410A-11		410G-15		444E-5
	410B-11		410H-15		444F-5
	410C-11		410J-15		444A-23
	410D-11		410K-15		444B-23
61622-90L00	410E-11	61831-89L00-0EP	410L-15	63131-99J11-0EP	444C-23
	410F-11		410A-6		444D-23
	410G-11		410B-6		444E-23
	410H-11		410C-6		444F-23
	410J-11		410D-6		444A-24
	410K-11		410E-6		444B-24
	410L-11		410F-6		444C-24
	420A-4		410G-6		444D-24
	420B-4		410H-6		444E-24
	420C-4		410J-6		444F-24
61810-89L00-RB4	420D-4	63111-89L00-0EP	410K-6	63133-89L00	444A-25
	420E-4		410L-6		444B-25
	420F-4		444A-1		444C-25
	420G-4		444B-1		444D-25
	420H-4		444C-1		444E-25
	420J-4		444D-1		444B-25
	420K-4		444E-1	63210-89L10	444A-6
	420L-4		444F-1		444B-6
	410A-1	63114-99J01	444A-22		444C-6
	410B-1		444B-22		444D-6
	410D-1		444C-22		444E-6
61810-89L10-RB4	410E-1		444D-22	63215-93110	444B-6
	410G-1		444E-22		444A-31
	410H-1		444F-22		444B-31
	410J-1	63115-99J00	444A-3		444C-31
	410C-1		444B-3		444D-31
	410F-1		444C-3		444E-31
	410K-1		444D-3	63220-89L00	444F-31
	410L-1		444E-3		444A-7
	410A-2		444F-3		444B-7
61820-89L00-RB4	410B-2	63115-99J10	444A-2		444C-7
	410D-2		444B-2		444D-7
	410E-2		444C-2		444E-7
	410F-2		444D-2		444F-7
	410G-2		444E-2	63225-93200	444A-9
	410H-2		444F-2		444B-9
	410J-2	63116-99J00	444A-4		444C-9
	410L-2		444B-4		444D-9
	410C-2		444C-4		444E-9
	410K-2		444D-4		444F-9

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
63225-98601	444A-8	65770-89L00	583A-10	67200-94J20	450A-1
	444B-8		432A-11		450C-1
	444C-8		583A-11		450D-1
	444D-8		432A-12		508A-1
	444E-8		583A-12		508B-1
	444F-8		444A-26		508C-1
	444A-10	65793-89L00	444B-26	67211-93J00	508D-1
	444B-10		444C-26		544A-27
	444C-10		444D-26		544B-27
	444D-10		444E-26		544C-27
	444E-10		444F-26		544D-27
63241-986B0	444F-10		432A-4		544E-27
	444A-11	65831-95D00	583A-5		544F-27
	444B-11		583A-6		544G-27
	444C-11		432A-5		544H-27
	444D-11		432A-6		544J-27
	444E-11		583A-7	67130-89L02	450A-13
	444F-11		513A-1		450B-14
	444A-12		513B-1		450C-13
63244-94J00	444B-12		513C-1		450D-13
	444C-12	67140-95600	513D-1		450E-14
	444D-12		515A-1		508A-13
	444E-12		515B-1		508B-13
	444F-12		515C-1		508C-13
	444A-14		515D-1	67214-92E00	508D-13
	444B-14		515E-1		450A-14
	444C-14		515F-1		450C-14
	444D-14		515G-1		450D-14
	444E-14		515H-1		508A-14
63610-89L00	444F-14		515J-1		508B-14
	444A-15	67200-93J13	544A-1		508C-14
	444B-15		544B-1		508D-14
	444C-15		544C-1	67220-95630	450A-15
	444D-15		544D-1		450B-16
	444E-15		544E-1		450C-15
	444F-15		544F-1		450D-15
	432A-1		544G-1		450E-16
65000-89L10	583A-1		544H-1		508A-15
	583A-2		544J-1		508B-15
	432A-2		545A-1		508C-15
	432A-3		545B-1	67221-92E00	508D-15
	583A-3		545C-1		545A-8
	583A-8		545D-1		545B-8
	432A-8		545E-1		545C-8
	432A-13		545F-1		545D-8
	432A-7		545G-1		545E-8
65700-87J15	583A-4		545H-1		545F-8
	432A-9	67200-93J50	545J-1		545G-8
	583A-9		450B-1		545H-8
	432A-10		450E-1		545J-8

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67222-92E00	545A-2		545F-16		450B-19
	545B-2		545G-16		450C-18
	545C-2		545H-16		450D-18
	545D-2		545J-16		450E-19
	545E-2	67227-92E00	545A-24		508A-18
67223-92E00	545F-2		545B-24		508B-18
	545G-2		545C-24		508C-18
	545H-2		545D-24		508D-18
	545J-2		545E-24		545A-42
	545A-3		545F-24		545B-42
67223-92E00	545B-3		545G-24		545C-42
	545C-3		545H-24		545D-42
	545D-3		545J-24		545E-42
	545E-3	67228-92E00	545A-18		545F-42
	545F-3		545B-18		545G-42
67223-99E10	545G-3		545C-18		545H-42
	545H-3		545D-18		545J-42
	545J-3		545E-18	67232-95620	545A-28
	450A-16		545F-18		545B-28
	450B-17		545G-18		545C-28
67224-92E00	450C-16		545H-18		545D-28
	450D-16		545J-18		545E-28
	450E-17	67229-95600	450A-17		545F-28
	508A-16		450B-18		545G-28
	508B-16		450C-17		545H-28
67224-92E00	508C-16		450D-17		545J-28
	508D-16		450E-18	67233-92E00	545A-26
	545A-9		508A-17		545B-26
	545B-9		508B-17		545C-26
	545C-9		508C-17		545D-26
67226-92E00	545D-9		508D-17		545E-26
	545E-9	67230-92E00	545A-20		545F-26
	545F-9		545B-20		545G-26
	545G-9		545C-20		545H-26
	545H-9		545D-20		545J-26
67226-92E00	545J-9		545E-20	67234-92E00	545A-22
	545A-15		545F-20		545B-22
	545B-15		545G-20		545C-22
	545C-15		545H-20		545D-22
	545D-15		545J-20		545E-22
67226-92E10	545E-15	67231-92E00	545A-41		545F-22
	545F-15		545B-41		545G-22
	545G-15		545C-41		545H-22
	545H-15		545D-41		545J-22
	545J-15		545E-41	67235-92E00	545A-27
67226-92E10	545A-16		545F-41		545B-27
	545B-16		545G-41		545C-27
	545C-16		545H-41		545D-27
	545D-16		545J-41		545E-27
	545E-16	67232-95600	450A-18		545F-27

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67236-92E00	545G-27		545C-45		508C-21
	545H-27		545D-45	67244-95600	508D-21
	545J-27		545E-45		450A-22
	545A-32		545F-45		450B-23
	545B-32		545G-45		450C-22
67240-92E00	545C-32		545H-45		450D-22
	545D-32		545J-45		450E-23
	545E-32		545A-17		508A-22
	545F-32		545B-17		508B-22
	545G-32		545C-17		508C-22
67237-92E01	545H-32		545D-17		508D-22
	545J-32		545E-17	67245-92E00	545A-23
	545A-33		545F-17		545B-23
	545B-33		545G-17		545C-23
	545C-33		545H-17		545D-23
67241-92E10	545D-33		545J-17		545E-23
	545E-33		545A-43		545F-23
	545F-33		545B-43		545G-23
	545G-33		545C-43		545H-23
	545H-33		545D-43		545J-23
67238-87D00	545J-33		545E-43	67245-95600	450A-23
	450A-19		545F-43		450B-24
	450B-20		545G-43		450C-23
	450C-19		545H-43		450D-23
	450D-19		545J-43		450E-24
67238-92E00	450E-20	67241-99E10	450A-20		508A-23
	508A-19		450B-21		508B-23
	508B-19		450C-20		508C-23
	508C-19		450D-20		508D-23
	508D-19		450E-21	67246-92E00	545A-36
67239-92E00	545A-34		508A-20		545B-36
	545B-34		508B-20		545C-36
	545C-34		508C-20		545D-36
	545D-34		508D-20		545E-36
	545E-34	67243-92E00	545A-44		545F-36
67239-92E00	545F-34		545B-44		545G-36
	545G-34		545C-44		545H-36
	545H-34		545D-44		545J-36
	545J-34		545E-44	67251-93J00	544A-12
	545A-35		545F-44		544B-12
67243-95600	545B-35		545G-44		544C-12
	545C-35		545H-44		544D-12
	545D-35		545J-44		544E-12
	545E-35		450A-21		544F-12
	545F-35		450B-22		544G-12
67239-92E10	545G-35		450C-21		544H-12
	545H-35		450D-21		544J-12
	545J-35		450E-22	67251-99E20	450A-24
	545A-45		508A-21		450B-25
	545B-45		508B-21		450C-24

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	450D-24		508D-26		450E-31
	450E-25		545A-40		508A-30
	508A-24		545B-40		508B-30
	508B-24		545C-40		508C-30
	508C-24		545D-40		508D-30
67252-92E10	508D-24		545E-40	67259-87D00	450A-31
	545A-39		545F-40		450B-32
	545B-39		545G-40		450C-31
	545C-39		545H-40		450D-31
	545D-39		545J-40		450E-32
	545E-39	67255-99E10	450A-27		508A-31
	545F-39		450B-28		508B-31
	545G-39		450C-27		508C-31
	545H-39		450D-27		508D-31
	545J-39		450E-28	67261-93J00	544A-2
67252-95600	450A-25		508A-27		544B-2
	450B-26		508B-27		544C-2
	450C-25		508C-27		544D-2
	450D-25		508D-27		544E-2
	450E-26	67256-95600	450A-28		544F-2
	508A-25		450B-29		544G-2
	508B-25		450C-28		544H-2
	508C-25		450D-28	67261-99E10	544J-2
	508D-25		450E-29		450A-32
67253-92E00	544A-15		508A-28		450B-33
	544B-15		508B-28		450C-32
	544C-15		508C-28		450D-32
	544D-15		508D-28		450E-33
	544E-15	67257-92E00	544A-11		508A-32
	544F-15		544B-11		508B-32
	544G-15		544C-11		508C-32
	544H-15		544D-11	67263-93J00	508D-32
67253-92E10	544J-15		544E-11		544A-3
	545A-38		544F-11		544B-3
	545B-38		544G-11		544C-3
	545C-38		544H-11		544D-3
	545D-38		544J-11		544E-3
	545E-38	67257-99E10	450A-29		544F-3
	545F-38		450B-30		544G-3
	545G-38		450C-29		544H-3
	545H-38		450D-29		544J-3
67253-95600	545J-38		450E-30	67264-95600	450A-34
	450A-26		508A-29		450B-35
	450B-27		508B-29		450C-34
	450C-26		508C-29		450D-34
	450D-26		508D-29		450E-35
	450E-27	67258-99E00	450A-30		508A-34
	508A-26		450B-31		508B-34
	508B-26		450C-30		508C-34
	508C-26		450D-30		508D-34

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67267-93J00	450A-35		544F-22		450B-53
	450B-36		544G-22		450C-39
	450C-35		544H-22		450D-39
	450D-35		544J-22		450E-53
	450E-36	67274-92E00	544A-24		508A-39
	508A-35		544B-24	67286-92E00	508B-39
	508B-35		544C-24		508C-39
	508C-35		544D-24		508D-39
	508D-35		544E-24		545A-19
67269-92E00	545A-29		544F-24		545B-19
	545B-29		544G-24		545C-19
	545C-29	67275-95600	544H-24		545D-19
	545D-29		544J-24		545E-19
	545E-29		450A-37		545F-19
	545F-29		450B-38		545G-19
	545G-29		450C-37		545H-19
	545H-29		450D-37	67287-92E00	545J-19
	545J-29		450E-38		544A-20
67271-92E00	544A-26		508A-37		544B-20
	544B-26		508B-37		544C-20
	544C-26		508C-37		544D-20
	544D-26		508D-37		544E-20
	544E-26		544A-21		544F-20
	544F-26		544B-21		544G-20
	544G-26		544C-21		544H-20
	544H-26		544D-21		544J-20
67273-92E00	544J-26		544E-21	67288-92E00	545A-4
	544A-23		544F-21		545B-4
	544B-23		544G-21		545C-4
	544C-23		544H-21		545D-4
	544D-23		544J-21		545E-4
	544E-23	67281-93J00	544A-17		545F-4
	544F-23		544B-17		545G-4
	544G-23		544C-17		545H-4
	544H-23		544D-17		545J-4
	544J-23		544E-17	67288-92E10	545A-6
67273-95600	450A-36		544F-17		545B-6
	450B-37		544G-17		545C-6
	450C-36		544H-17		545D-6
	450D-36		544J-17		545E-6
	450E-37	67282-94L00	450A-38		545F-6
	508A-36		450B-52		545G-6
	508B-36		450C-38		545H-6
	508C-36		450D-38		545J-6
	508D-36		450E-52	67288-92E20	544A-7
	544A-22		508A-38		544B-7
	544B-22		508B-38		544C-7
	544C-22		508C-38		544D-7
	544D-22		508D-38		544E-7
	544E-22	67284-94L00	450A-39		544F-7

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67288-92E30	544G-7	67294-92E00	545C-5	67296-88D10	544H-5
	544H-7		545D-5		544J-5
	544J-7		545E-5		544A-6
	544A-14		545F-5		544B-6
	544B-14		545G-5		544C-6
67288-92E40	544C-14	67294-95600	545H-5	67296-92E30	544D-6
	544D-14		545J-5		544E-6
	544E-14		545A-10		544F-6
	544F-14		545B-10		544G-6
	544G-14		545C-10		544H-6
67291-92E00	544H-14	67296-92E60	545D-10	67296-92E60	544J-6
	544J-14		545E-10		545A-13
	544A-10		545F-10		545A-30
	544B-10		545G-10		545B-13
	544C-10		545H-10		545B-30
67291-92E10	544D-10	67296-95610	545J-10	67296-95610	545C-13
	544E-10		450A-41		545C-30
	544F-10		450B-40		545D-13
	544G-10		450C-41		545D-30
	544H-10		450D-41		545E-13
67292-94300	544J-10	67296-92E11	450E-40	67296-92E20	545E-30
	545A-7		508A-41		545F-13
	545B-7		508B-41		545F-30
	545C-7		508C-41		545G-13
	545D-7		508D-41		545G-30
67292-94300	545E-7	67296-92E10	515A-2	67296-94300	545H-13
	545F-7		515B-2		545H-30
	545G-7		515C-2		545J-13
	545H-7		515D-2		545J-30
	545J-7		515E-2		450A-42
67292-94300	545A-37	67296-92E10	515F-2	67296-94300	450B-41
	545B-37		515G-2		450C-42
	545C-37		515H-2		450D-42
	545D-37		515J-2		450E-41
	545E-37		544A-8		508A-42
67292-94300	545F-37	67296-92E10	544B-8	67296-94300	508B-42
	545G-37		544C-8		508C-42
	545H-37		544D-8		508D-42
	545J-37		544E-8		450B-15
	450A-40		544F-8		450E-15
67292-94300	450B-39	67296-92E10	544G-8	67296-94300	545A-12
	450C-40		544H-8		545B-12
	450D-40		544J-8		545C-12
	450E-39		544A-5		545D-12
	508A-40		544B-5		545E-12
67292-94300	508B-40	67296-92E10	544C-5	67296-94300	545F-12
	508C-40		544D-5		545G-12
	508D-40		544E-5		545H-12
	545A-5		544F-5		545J-12
	545B-5		544G-5		545A-14

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67296-94310	545B-14	67296-94310	508B-43	67320-93J00	450C-46
	545C-14		508C-43		450D-46
	545D-14		508D-43		450E-45
	545E-14		450A-33		508A-46
	545F-14		450B-34		508B-46
67296-92E30	545G-14	67296-95600	450C-33	67320-93J10	508C-46
	545H-14		450D-33		508D-46
	545J-14		450E-34		515A-4-1
	544A-18		508A-33		515B-4-1
	544B-18		508B-33		515C-4-1
67296-92E60	544C-18	67296-95610	508C-33	67320-93J20	515D-4-1
	544D-18		508D-33		515E-4-1
	544E-18		450A-44		515F-4-1
	544F-18		450B-43		515G-4-1
	544G-18		450C-44		515H-4-1
67296-92E70	544H-18	67296-95621	450D-44	67320-93J40	515J-4-1
	544J-18		450E-43		515A-4-2
	544A-13		508A-44		515B-4-2
	544B-13		508B-44		515C-4-2
	544C-13		508C-44		515D-4-2
67296-92E70	544D-13	67296-95621	508D-44	67320-93J40	515E-4-2
	544E-13		450A-45		515F-4-2
	544F-13		450B-44		515G-4-2
	544G-13		450C-45		515H-4-2
	544H-13		450D-45		515J-4-2
67296-92E70	544J-13	67296-95621	450E-44	67320-93J40	515A-4-3
	544A-9		508A-45		515B-4-3
	544A-28		508B-45		515C-4-3
	544B-9		508C-45		515D-4-3
	544B-28		508D-45		515E-4-3
67296-92E70	544C-9	67296-95621	544A-25	67320-93J40	515F-4-3
	544C-28		544B-25		515G-4-3
	544D-9		544C-25		515H-4-3
	544D-28		544D-25		515J-4-3
	544E-9		544E-25		515A-4-4
67296-92E70	544E-28	67296-95621	544F-25	67320-93J40	515B-4-4
	544F-9		544G-25		515C-4-4
	544F-28		544H-25		515D-4-4
	544G-9		544J-25		515E-4-4
	544G-28		515A-3		515F-4-4
67296-94300	544H-9	67296-95621	515B-3	67320-93J40	515G-4-4
	544H-28		515C-3		515H-4-4
	544J-9		515D-3		515J-4-4
	544J-28		515E-3		515A-4-5
	450A-43		515F-3		515B-4-5
67296-94300	450B-42	67297-95600	515G-3	67297-95600	515C-4-5
	450C-43		515H-3		515D-4-5
	450D-43		515J-3		515E-4-5
	450E-42		450A-46		515F-4-5
	508A-43		450B-45		515G-4-5

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67320-93J50	515H-4-5		166D-11		442D-5
	515J-4-5		166E-11		442E-5
	515A-4-6		206B-18		575A-5
	515B-4-6		206C-18		575B-5
	515C-4-6		206E-18		575C-5
67320-93J60	515D-4-6		206J-18	67728-99E00	575D-5
	515E-4-6		206K-18		442A-6
	515F-4-6		513A-23		442B-6
	515G-4-6		513B-23		442C-6
	515H-4-6		513C-23		442D-6
67320-93J70	515J-4-6	67500-93J00	513D-23		442E-6
	515A-4-7		544A-29		575A-6
	515B-4-7		544B-29		575B-6
	515C-4-7		544C-29		575C-6
	515D-4-7		544D-29		575D-6
67320-93J80	515E-4-7		544E-29	68110-89L00	420A-14
	515F-4-7		544F-29		420B-14
	515G-4-7		544G-29		420C-15
	515H-4-7		544H-29		420D-14
	515J-4-7		544J-29		420E-14
67320-93J90	515A-4-8	67701-99J02	442A-2		420F-15
	515B-4-8		442B-2		420G-14
	515C-4-8		442C-2		420H-14
	515D-4-8		442D-2		420J-14
	515E-4-8		442E-2		420K-15
67320-93J00	515F-4-8		575A-2		420L-15
	515G-4-8		575B-2	68111-89L00	420A-7
	515H-4-8		575C-2		420B-7
	515J-4-8		575D-2		420C-7
	515A-4-9	67721-93E10	442A-3		420D-7
67320-93J10	515B-4-9		442B-3		420E-7
	515C-4-9		442C-3		420F-7
	515D-4-9		442D-3		420G-7
	515E-4-9		442E-3		420H-7
	515F-4-9		575A-3		420J-7
67320-93J20	515G-4-9		575B-3		420K-7
	515H-4-9		575C-3		420L-7
	515J-4-9		575D-3	69711-93E10	167A-12
	206B-21	67725-96J00	442A-4		167B-12
	206C-21		442B-4		167C-12
67320-93J30	206E-21		442C-4		167D-12
	206J-21		442D-4		167E-12
	206K-21		442E-4		167F-12
	513A-22		575A-4		167G-12
	513B-22		575B-4		167H-12
67320-93J40	513C-22		575C-4		167J-12
	513D-22		575D-4		167K-12
	166A-11	67726-99E00	442A-5		167L-12
	166B-11		442B-5	69911-91J00	335H-24
	166C-11		442C-5	69911-91J40	335A-24

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	335B-24		420K-13		166B-9
	335C-27		420L-13		166C-9
	335D-24				166D-9
	335E-24				166E-9
	335F-27				175A-8
	335G-24				206A-17
	335J-24				206B-9
	335K-27				206B-15
	335L-27				206C-9
					206C-15
					206D-17
					206E-9
					206E-15
					206F-17
					206G-17
					206H-17
					206J-9
					206J-15
					206K-9
					206K-15
					206L-17
					322A-20
					322A-21
					322B-15
					322B-16
					322C-15
					322C-16
					322D-20
					322D-21
					322E-15
					322E-16
					322F-20
					322F-21
					322G-20
					322G-21
					322H-20
					322H-21
					322J-15
					322J-16
					322K-15
					322K-16
					322L-20
					322L-21
					322M-15
					322M-16
					322N-15
					322N-16
					322O-15
					322O-16
					322P-15
					322P-16
					322Q-15
					322Q-16
					322R-15
					322R-16
					322S-15
					322S-16
					322T-15
					322T-16
					322U-15
					322U-16
					322V-15
					322V-16
					322W-15
					322W-16
					322X-15
					322X-16
					322Y-15
					322Y-16
					322Z-15
					322Z-16
					323A-15
					323A-16
					323B-15
					323B-16
					323C-15
					323C-16
					323D-15
					323D-16
					323E-15
					323E-16
					323F-15
					323F-16
					323G-15
					323G-16
					323H-15
					323H-16
					323I-15
					323I-16
					323J-15
					323J-16
					323K-15
					323K-16
					323L-15
					323L-16
					323M-15
					323M-16
					323N-15
					323N-16
					323O-15
					323O-16
					323P-15
					323P-16
					323Q-15
					323Q-16
					323R-15
					323R-16
					323S-15
					323S-16
					323T-15
					323T-16
					323U-15
					323U-16
					323V-15
					323V-16
					323W-15
					323W-16
					323X-15
					323X-16
					323Y-15
					323Y-16
					323Z-15
					323Z-16
					324A-15
					324A-16
					324B-15
					324B-16
					324C-15
					324C-16
					324D-15
					324D-16
					324E-15
					324E-16
					324F-15
					324F-16
					324G-15
					324G-16
					324H-15
					324H-16
					324I-15
					324I-16
					324J-15
					324J-16
					324K-15
					324K-16
					324L-15
					324L-16
					324M-15
					324M-16
					324N-15
					324N-16
					324O-15
					324O-16
					324P-15
					324P-16
					324Q-15
					324Q-16
					324R-15
					324R-16
					324S-15
					324S-16
					324T-15
					324T-16
					324U-15
					324U-16
					324V-15
					324V-16
					324W-15
					324W-16
					324X-15
					324X-16
					324Y-15
					324Y-16
					324Z-15
					324Z-16
					325A-15
					325A-16
					325B-15
					325B-16
					325C-15
					325C-16
					325D-15
					325D-16
					325E-15
					325E-16
					325F-15
					325F-16
					325G-15
					325G-16
					325H-15
					325H-16
					325I-15
					325I-16
					325J-15
					325J-16
					325K-15
					325K-16
					325L-15
					325L-16
					325M-15
					325M-16
					325N-15
					325N-16
					325O-15
					325O-16
					325P-15
					325P-16
					325Q-15
					325Q-16
					325R-15
					325R-16
					325S-15
					325S-16
					325T-15
					325T-16
					325U-15
					325U-16
					325V-15
					325V-16
					325W-15
					325W-16
					325X-15
					325X-16
					325Y-15
					325Y-16
					325Z-15
					325Z-16
					326A-15
					326A-16
					326B-15
					326B-16
					326C-15
					326C-16
					326D-15
					326D-16
					326E-15
					326E-16
					326F-15
					326F-16
					326G-15
					326G-16
					326H-15
					326H-16
					326I-15
					326I-16
					326J-15
					326J-16
					326K-15
					326K-16
					326L-15
					326L-16
					326M-15
					326M-16
					326N-15
					326N-16
					326O-15
					326O-16
					326P-15
					326P-16
					326Q-15
					326Q-16
					326R-15
					326R-16
					326S-15
					326S-16
					326T-15
					326T-16
					326U-15
					326U-16
					326V-15
					326V-16
					326W-15
					326W-16
					326X-15
					326X-16
					326Y-15
					326Y-16
					326Z-15
					326Z-16
					327A-15
					327A-16
					327B-15
					327B-16
					327C-15
					327C-16
					327D-15
					327D-16
					327E-15
					327E-16
					327F-15
					327F-16
					327G-15
					327G-16
					327H-15
					327H-16
					327I-15
					327I-16
					327J-15
					327J-16
					327K-15
					327K-16
					327L-15
					327L-16
					327M-15
					327M-16
					327N-15
					327N-16
					327O-15
					327O-16
					327P-15
					327P-16
					327Q-15
					327Q-16
					327R-15
					327R-16
					327S-15
					327S-16
					327T-15
					327T-16
					327U-15
					327U-16
					327V-15
					327V-16
					327W-15
					327W-16
					327X-15
					327X-16
					327Y-15
					327Y-16
					327Z-15
					327Z-16
					328A-15
					328A-16
					328B-15
					328B-16
					328C-15
					328C-16
					328D-15
					328D-16
					328E-15

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	166C-10		163K-7		206D-18
	166D-10		163L-9		206E-16
	166E-10		167A-11		206F-18
	303A-10		167B-11		206G-18
	303B-10		167C-11		206H-18
	303C-10		167D-11		206J-16
	303D-10		167E-11		206K-16
	303E-10		167F-11		206L-18
	310A-8		167G-11	01550-06307	167A-9
	310B-8		167H-11		167B-9
	310C-8		167J-11		167C-9
	310D-8		167K-11		167D-9
	310E-8		167L-11		167E-9
	310F-8		175A-7		167F-9
	310G-8		310A-7		167G-9
	310H-8		310B-7		167H-9
	310J-8		310C-7		167J-9
	310K-8		310D-7		167K-9
	310L-8		310E-7		167L-9
	334A-9		310F-7		310A-12
	334B-8		310G-7		310B-12
	334C-8		310H-7		310C-12
	334D-9		310J-7		310D-12
	334E-8		310K-7		310E-12
	334F-8		310L-7		310F-12
	334G-9		334A-15		310G-12
	334H-9		334B-14		310H-12
	334J-8		334C-14		310J-12
	334K-8		334D-15		310K-12
	334L-8		334E-14		310L-12
	513A-35		334F-14	01550-06357	113A-2
	513B-35		334G-15		120A-14
	513C-35		334H-15	01550-06507	144A-9
	513D-35		334J-14	01550-08207	111A-9
	561A-8		334K-14		113A-7
	561B-8		334L-14		301A-22
	561C-8		553A-6		553A-5
	561D-8		553B-6		553B-5
	111A-15		553C-6		553C-5
	146A-21		553D-6		553D-5
	162A-3		561A-9	01550-08307	301A-23
	163A-9		561B-9	01560-08307	401A-15
	163B-7		561C-9	01560-08757	113A-3
	163C-7		561D-9	01580-08407	126A-3
	163D-9	01550-06257	120A-13		126B-3
	163E-7		146A-11		126C-3
	163F-9		146A-22		126D-3
	163G-9		206A-18		126E-3
	163H-9		206B-16		126F-3
	163J-7		206C-16		126G-3

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	126H-3		420B-3		335B-9
	126J-3		420C-3		335D-9
	126K-3		420D-3		335E-9
	126L-3		420E-3		335G-9
	120A-15		420F-3		335H-9
02122-04127	175A-14		420G-3		335J-9
02122-0630A	410A-16		420H-3	09100-08232	336A-23
02142-06167	410B-16		420J-3		336B-23
	410C-16		420K-3		336C-13
	410D-16		420L-3		336D-23
	410E-16	03542-06209	146A-23		336E-23
	410F-16	04211-09149	120A-12		336F-13
	410G-16	04211-11129	111A-12		336G-23
	410H-16		113A-4		336H-23
	410J-16	04221-05109	126A-4		336J-23
	410K-16		126B-4		336K-13
	410L-16		126C-4		336L-13
02142-06207	206A-19		126D-4		450A-48
	206B-17		126E-4		450B-47
	206C-17		126F-4		450C-48
	206D-19		126G-4		450D-48
	206E-17		126H-4		450E-47
	206F-19		126J-4		508A-48
	206G-19		126K-4		508B-48
	206H-19		126L-4		508C-48
	206J-17	08110-60020	220A-2		508D-48
	206K-17		220B-2	09100-08311	335A-15
	206L-19		220C-2		335B-15
03112-06303	502A-32		220D-2		335C-24
	502B-32		220E-2		335D-15
	502C-32		220F-2		335E-15
	502D-32		220G-2		335F-24
	502E-32		220H-2		335G-15
03121-0516A	530A-22		220J-2		335H-15
	530B-22		220K-2		335J-15
	530C-22		220L-2		335K-24
	530D-22	08110-60050	407A-11		335L-24
	530E-22	08316-10087	301A-24	09103-06237	432A-14
03142-04169	160A-12	08322-0106A	303A-11	09103-06267	120A-7
	160B-12		303B-11	09103-06281	111A-8
	160C-12		303C-11		335C-21
	160D-12		303D-11		335F-21
	160E-12	08341-31039	120A-9		335K-21
	160F-12		120A-10		335L-21
	160G-12		303A-7		336C-21
	160H-12		303B-7		336F-26
	160J-12		303C-7		336K-21
	160K-12		303D-7		336L-26
	160L-12		303E-7		338A-20
03542-05169	420A-3	09100-06178	335A-9		338B-20

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09108-06141	338C-20		126K-9	09116-08137	401A-13
	338D-20		126L-9	09116-08150	338A-21
	407A-7		146A-12		338B-21
	160A-14		327A-4		338C-21
	160B-14		327B-8		338D-21
	160C-14	09116-06225	327C-4	09116-08151	401A-3
	160D-14		327D-8		405A-6
	160E-14		336A-35		405A-17
	160F-14		336B-32		407A-5
	160G-14		336C-19		444A-16
09108-08286	160H-14		336D-35		444B-16
	160J-14		336E-32		444C-16
	160K-14		336F-22		444D-16
	160L-14		336G-35		444E-16
	336B-29		336H-35		444F-16
	336C-16		336J-32	09116-08154	405A-15
	336E-29		336K-19	09116-08155	444A-28
	336J-29		336L-22		444B-28
	336K-16		444A-27		444C-28
	513A-24		444B-27		444D-28
09111-10067	513B-24		444C-27		444E-28
	513C-24		444D-27		444F-28
	513D-24		444E-27	09119-08L01	111A-4
	336A-26		444F-27	09119-08L02	111A-3
	336B-26		513A-25	09125-05042	444A-29
	336D-26		513B-25		444B-29
	336E-26		513C-25		444C-29
	336G-26		513D-25		444D-29
	336H-26	09116-06227	407A-14		444E-29
	336J-26	09116-06229	220A-24		444F-29
09116-06196	310A-3		220B-24		545A-21
	310B-3		220C-24		545B-21
	310C-3		220D-24		545C-21
	310D-3		220E-24		545D-21
	310E-3		220F-24		545E-21
	310F-3		220G-24		545F-21
	310G-3		220H-24		545G-21
	310H-3		220J-24		545H-21
	310J-3		220K-24		545J-21
	310K-3		220L-24	09125-05046	327B-5
09116-06202	310L-3	09116-06234	206A-9		327D-5
	126A-7		206D-9	09125-05135	544A-30
	126B-7		206F-9		544B-30
	126C-7		206G-9		544C-30
	126D-7		206H-9		544D-30
	126E-7		206L-9		544E-30
	126F-7	09116-08128	335C-18		544F-30
	126G-9		335F-18		544G-30
	126H-9		335K-18		544H-30
	126J-9		335L-18		544J-30

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09125-06063	335C-12		410B-3	09140-10031	401A-14
	335F-12		410C-3	09140-14008	303A-5
	335K-12		410D-3		303B-5
	335L-12		410E-3		303C-5
	450A-49		410F-3		303D-5
09126-05003	450B-48		410G-3		303E-5
	450C-49		410H-3	09141-12005	407A-18
	450D-49		410J-3	09148-06008	444A-13
	450E-48		410K-3		444B-13
	508A-49		410L-3		444C-13
	508B-49	09140-05005	327B-7		444D-13
	508C-49		327D-7		444E-13
	508D-49		544A-32		444F-13
	545A-25		544B-32	09159-08059	336B-30
	545B-25		544C-32		336C-17
09126-06006	545C-25		544D-32		336E-30
	545D-25		544E-32		336J-30
	545E-25		544F-32		336K-17
	545F-25		544G-32		513A-26
	545G-25		544H-32		513B-26
	545H-25	09140-06020	544J-32		513C-26
	545J-25		450A-50		513D-26
	444A-17		450B-49	09159-08L02	336A-36
	444B-17		450C-50		336D-36
	444C-17		450D-50		336F-23
	444D-17		450E-49		336G-36
	444E-17		508A-50		336H-36
	444F-17		508B-50		336L-23
	340A-8	09136-05041	508C-50	09159-22006	335A-8
	340B-8		508D-50		335B-8
	340C-8		545A-31		335C-13
	340D-8		545B-31		335D-8
	444A-18		545C-31		335E-8
	444B-18		545D-31		335F-13
	444C-18		545E-31		335G-8
	444D-18		545F-31		335H-8
	444E-18		545G-31		335J-8
	444F-18		545H-31		335K-13
09136-06168	410A-8		545J-31		335L-13
	410B-8	09140-08023-XC0	335A-16		513A-27
	410C-8		335B-16		513B-27
	410D-8		335C-25		513C-27
	410E-8		335D-16		513D-27
	410F-8		335E-16	09160-05024	544A-19
	410G-8		335F-25		544B-19
	410H-8		335G-16		544C-19
	410J-8		335H-16		544D-19
	410K-8		335J-16		544E-19
	410L-8		335K-25		544F-19
	410A-3		335L-25		544G-19
09136-06169					

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	220B-6		336D-8		126F-6
	220C-6		336E-5		126G-8
	220D-6		336E-8		126H-8
	220E-6		336F-5		126J-8
	220F-6		336F-8		126K-8
	220G-6		336G-5		126L-8
	220H-6		336G-8		146A-13
	220J-6		336H-5		327A-5
	220K-6		336H-8		327B-9
	220L-6		336J-5		327C-5
09160-25040	220A-12-4		336J-8	09169-06063	327D-9
	220B-12-4		336K-5		310A-5
	220C-12-4		336K-8		310B-5
	220D-12-4		336L-5		310C-5
	220E-12-4		336L-8		310D-5
	220F-12-4	09161-04012	410A-12		310E-5
	220G-12-4		410B-12		310F-5
	220H-12-4		410C-12		310G-5
	220J-12-4		410D-12		310H-5
	220K-12-4		410E-12		310J-5
09160-25041	220L-12-4		410F-12		310K-5
	220A-12-5		410G-12	09180-06186	310L-5
	220B-12-5		410H-12		206A-13
	220C-12-5		410J-12		206D-13
	220D-12-5		410K-12		206F-13
	220E-12-5		410L-12	09180-06362	206G-13
	220F-12-5	09161-08019	336A-37		206H-13
	220G-12-5		336D-37		206L-13
	220H-12-5		336F-24		206A-14
	220J-12-5		336G-37		206B-12
	220K-12-5		336H-37		206C-12
09160-25042	220L-12-5	09163-06001	336L-24		206D-14
	220A-12-6		444A-19		206E-12
	220B-12-6		444B-19		206F-14
	220C-12-6		444C-19		206G-14
	220D-12-6		444D-19		206H-14
	220E-12-6		444E-19		206J-12
	220F-12-6		444F-19		206K-12
	220G-12-6	09164-14008	206A-12		206L-14
	220H-12-6		206D-12	09180-06366	335A-11
	220J-12-6		206F-12		335B-11
	220K-12-6		206G-12		335D-11
	220L-12-6		206H-12		335E-11
09160-27012	336A-5		206L-12		335G-11
	336A-8	09168-12017	405A-8		335H-11
	336B-5	09169-06062	126A-6		335J-11
	336B-8		126B-6	09181-15241	220A-13
	336C-5		126C-6		220B-13
	336C-8		126D-6		220C-13
	336D-5		126E-6		220D-13

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	220E-13		220L-5-1		336H-18
	220F-13	09181-25160	220A-12-1		336J-18
	220G-13		220B-12-1	09200-06061	336A-16
	220H-13		220C-12-1		336B-16
	220J-13		220D-12-1		336D-16
	220K-13		220E-12-1		336E-16
09181-20244	220L-13		220F-12-1		336G-16
	220A-5-5		220G-12-1		336H-16
	220B-5-5		220H-12-1		336J-16
	220C-5-5		220J-12-1	09202-04008	160A-17
	220D-5-5		220K-12-1		160B-17
	220E-5-5		220L-12-1		160C-17
	220F-5-5	09181-25162	220A-12-2		160D-17
	220G-5-5		220B-12-2		160E-17
	220H-5-5		220C-12-2		160F-17
	220J-5-5		220D-12-2		160G-17
09181-20246	220K-5-5		220E-12-2		160H-17
	220L-5-5		220F-12-2		160J-17
	220A-5-6		220G-12-2		160K-17
	220B-5-6		220H-12-2		160L-17
	220C-5-6		220J-12-2	09202-04025	220A-16
	220D-5-6		220K-12-2		220B-16
	220E-5-6	09181-25164	220L-12-2		220C-16
	220F-5-6		220A-12-3		220D-16
	220G-5-6		220B-12-3		220E-16
	220H-5-6		220C-12-3		220F-16
	220J-5-6		220D-12-3		220G-16
	220K-5-6		220E-12-3		220H-16
	220L-5-6		220F-12-3		220J-16
09181-20248	220A-5-7		220G-12-3		220K-16
	220B-5-7		220H-12-3		220L-16
	220C-5-7		220J-12-3	09202-06023	401A-4
	220D-5-7		220K-12-3		405A-7
	220E-5-7		220L-12-3		407A-4
	220F-5-7	09181-25181	220A-12-7	09204-01002	206A-8
	220G-5-7		220B-12-7		206B-8
	220H-5-7		220C-12-7		206C-8
	220J-5-7		220D-12-7		206D-8
	220K-5-7		220E-12-7		206E-8
	220L-5-7		220F-12-7		206F-8
09181-20251	220A-5-1		220G-12-7		206G-8
	220B-5-1		220H-12-7		206H-8
	220C-5-1		220J-12-7		206J-8
	220D-5-1		220K-12-7		206K-8
	220E-5-1		220L-12-7		206L-8
	220F-5-1	09200-05014	336A-18		336A-13
	220G-5-1		336B-18		336B-13
	220H-5-1		336D-18		336D-13
	220J-5-1		336E-18		336E-13
	220K-5-1		336G-18		336G-13

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	336H-13		410H-19		336B-6
	336J-13		410J-19		336C-6
	513A-19		410K-19		336D-6
	513B-19		410L-19		336E-6
	513C-19	09260-12003	206A-15		336F-6
	513D-19		206B-13		336G-6
09204-02004	407A-20		206C-13		336H-6
09205-02004	210A-4		206D-15		336J-6
09205-03004	335C-19		206E-13		336K-6
	335F-19		206F-15		336L-6
	335K-19		206G-15	09283-25096	121A-2
	335L-19		206H-15		121B-2
09205-06021	335A-6		206J-13		121C-2
	335B-6		206K-13		121D-2
	335C-3		206L-15		121E-2
	335D-6	09262-25003	407A-3		121F-2
	335E-6	09263-17L03	407A-2		121G-2
	335F-3	09263-20L04	220A-7		121H-2
	335G-6		220B-7		121J-2
	335H-6		220C-7		121K-2
	335J-6		220D-7		121L-2
	335K-3		220E-7	09283-32039	116A-9
	335L-3		220F-7	09289-05012	121A-14
09229-04005	410A-20		220G-7		121B-14
	410B-20		220H-7		121C-14
	410C-20		220J-7		121D-14
	410D-20		220K-7		121E-14
	410E-20		220L-7		121F-14
	410F-20	09280-06012	210A-9		121G-14
	410G-20	09280-09008	175A-11		121H-14
	410H-20	09280-09012	210A-10		121J-14
	410J-20	09280-13004	175A-4		121K-14
	410K-20	09280-17003	111A-11		121L-14
	410L-20	09280-22019	111A-6	09289-06L02	210A-11
09248-08001	407A-9	09280-26005	146A-39	09289-17L02	407A-13
09248-12009	405A-9	09280-54001	175A-5	09306-22006	335A-14
09250-12006	444A-30	09280-57002	407A-12		335B-14
	444B-30	09282-12L04	401A-5		335D-14
	444C-30	09282-13L01	220A-22		335E-14
	444D-30		220B-22		335G-14
	444E-30		220C-22		335H-14
	444F-30		220D-22		335J-14
09251-05006	146A-14		220E-22	09320-08051	310A-6
09251-09007	410A-19		220F-22		310B-6
	410B-19		220G-22		310C-6
	410C-19		220H-22		310D-6
	410D-19		220J-22		310E-6
	410E-19		220K-22		310F-6
	410F-19		220L-22		310G-6
	410G-19	09282-27002	336A-6		310H-6

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	310J-6		410E-21		163G-7
	310K-6		410F-21		163H-7
	310L-6		410G-21		163L-7
09320-08062	144A-7		410H-21		167C-17
09320-09052	126A-10		410J-21		167F-17
	126B-10		410K-21	09403-12415	167K-17
	126C-10	09385-06012	410L-21		167L-17
	126D-10		166A-13		167A-14
	126E-10		166B-13		167B-14
	126F-10		166C-13		167C-14
	126G-12		166D-13		167D-14
	126H-12		166E-13		167E-14
	126J-12		206B-20		167F-14
	126K-12		206C-20		167G-14
	126L-12		206E-20		167H-14
09320-11017	146A-15		206J-20		167J-14
	410A-7		206K-20		167K-14
	410B-7		513A-31		167L-14
	410C-7		513B-31	09407-08401	530A-8
	410D-7		513C-31		530A-24
	410E-7		513D-31		530B-8
	410F-7	09401-08412	146A-18		530B-24
	410G-7	09401-08413	162A-6		530C-8
	410H-7	09401-10412	146A-19		530C-24
	410J-7	09401-11423	146A-34		530D-8
	410K-7		146A-40		530D-24
	410L-7	09401-11425	144A-8		530E-8
09320-13022	405A-18	09401-12413	111A-17		530E-24
09321-08022	146A-16		401A-16	09407-14403	322A-2
09352-50823-600	146A-17	09401-13423	146A-41		322D-2
09380-12002	338A-22	09401-13424	401A-18		322F-2
	338B-22	09403-07308	410C-22		322G-2
	338C-22		410F-22		322H-2
	338D-22		410K-22		322L-2
09380-15001	220A-3		410L-22		553A-15
	220B-3	09403-08404	322A-16		553B-15
	220C-3		322B-11		553C-15
	220D-3		322C-11		553D-15
	220E-3		322D-16		561A-16
	220F-3		322E-11		561B-16
	220G-3		322F-16		561C-16
	220H-3		322G-16		561D-16
	220J-3		322H-16	09407-14407	303A-8
	220K-3		322J-11		303B-8
	220L-3		322K-11		303C-8
09381-16001	116A-4		322L-16		303D-8
09385-04003	410A-21	09403-11320	146A-42		303E-8
	410B-21	09403-12406	163A-7		322A-3
	410C-21		163D-7		322A-10
	410D-21		163F-7		322B-6

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	322C-6		322D-17		322L-19
	322D-3		322E-12	09420-03009	160A-16
	322D-10		322F-17		160B-16
	322E-6		322G-17		160C-16
	322F-3		322H-17		160D-16
	322F-10		322J-12		160E-16
	322G-3		322L-17		160F-16
	322G-10	09408-00024	322C-12		160G-16
	322H-3		322K-12		160H-16
	322H-10	09408-00070	162A-9		160J-16
	322J-6	09408-00159	310A-10		160K-16
	322K-6		310B-10		160L-16
	322L-3		310C-10	09440-09041	206A-16
	322L-10		310D-10		206B-14
	338A-23		310E-10		206C-14
	338B-23		310F-10		206D-16
	338C-23		310G-10		206E-14
	338D-23		310H-10		206F-16
	502A-16		310J-10		206G-16
	502A-29		310K-10		206H-16
	502B-16		310L-10		206J-14
	502B-29	09408-00184	553A-8		206K-14
	502C-16		553B-8		206L-16
	502C-29		553C-8	09440-12027	444A-20
	502D-16		553D-8		444B-20
	502D-29		561A-11		444C-20
	502E-16		561B-11		444D-20
	502E-29		561C-11		444E-20
	513A-32		561D-11		444F-20
	513B-32	09408-00252	322A-18	09440-18002	175A-6
	513C-32		322D-18	09441-17001	335A-21
	513D-32		322F-18		335B-21
	553A-7		322G-18		335D-21
	553A-16		322H-18		335E-21
	553B-7		322L-18		335G-21
	553B-16	09408-00296	322B-13		335H-21
	553C-7		322C-13		335J-21
	553C-16		322E-13	09471-12028	502A-27
	553D-7		322J-13		502A-35-1
	553D-16		322K-13		502B-27
	561A-18	09408-00297	322A-19		502B-35-1
	561A-22		322B-14		502C-27
	561B-18		322C-14		502C-35-1
	561B-22		322D-19		502D-27
	561C-18		322E-14		502D-35-1
	561C-22		322F-19		502E-27
	561D-18		322G-19		502E-35-1
	561D-22		322H-19	09471-12103	502A-21
09408-00008	322A-17		322J-14		502A-24
	322B-12		322K-14		502A-39

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	502B-21		546D-2		
	502B-24		546E-2		
	502B-39		546F-2		
	502C-21	09481-30501	322A-7		
	502C-24		322B-4		
	502C-39		322C-4		
	502D-21		322D-7		
	502D-24		322E-4		
	502D-39		322F-7		
	502E-21		322G-7		
	502E-24		322H-7		
	502E-39		322J-4		
09481-05501	502A-19		322K-4		
	502B-19		322L-7		
	502C-19		513A-14		
	502D-19		513B-14		
	502E-19		513C-14		
	503A-7		513D-14		
	503A-17	09482-00L04	111A-18		
	503B-7				
	503B-17				
	503C-7				
	503C-17				
	503D-7				
	503D-17				
	503E-7				
	503E-17				
09481-10501	322A-6				
	322B-3				
	322C-3				
	322D-6				
	322E-3				
	322F-6				
	322G-6				
	322H-6				
	322J-3				
	322K-3				
	322L-6				
	450A-53				
	450B-55				
	450C-53				
	450D-53				
	450E-55				
	513A-13				
	513B-13				
	513C-13				
	513D-13				
	546A-2				
	546B-2				
	546C-2				

SUZUKI DF9.9B/15A/20A PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION

Technical Readiness Group, Quality Administration Department

300 Takatsuka, Minami, Hamamatsu, Japan

Reprint Prohibited

SUZUKI MOTOR CORPORATION