

SUZUKI

PARTS CATALOGUE

DF9. 9B/15A/20A

DF9.9B/BR

DF9.9BT

DF15A/AR

DF15AT/ATH

DF20A/AR

DF20AT/ATH



OUTBOARD MOTOR

P01/P40

2015-8

1ST EDITION

PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF9.9B/15A/20A production start 2015.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E. NO.	: Engine number	OS	: Over size
F. NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	W/	: with
LH(PORT)	: Left hand side	S, L	: Transom type
RH(STBD)	: Right hand side	SUS	: Stainless steel
~123456	: Up to E. NO. 02002F-123456		
123456~	: From E. NO. 02002F-123456		

12 x 34 x 5.6..... Figures in the description column

| | | show the dimensions of parts.

ID OD T(or W, L)

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual.
When assembling, use "SUZUKI SERVICE MANUAL".

6. SPECIFICATION CODE

This catalogue contains the parts for the model designed for the following spec.:

spec. code :	DF9.9B : P1	DF9.9BR : P1
	DF15A : P1	DF15AR : P1
	DF20A : P1, P40	DF20AR : P1

7. MODEL NAME AND ENGINE NUMBER

MODEL	DESTINATION	TYPE	TRANSOM	ENGINE NO.
DF9.9B	P01	00995F	S, L, X	00995F-610001~
DF9.9BR	P01	00995F	S, L, X	00995F-610001~
DF9.9BT	P01	00995F	S, L, X	00995F-610001~
DF15A	P01	01504F	S, L, X	01504F-610001~
DF15AR	P01	01504F	S, L, X	01504F-610001~
DF15AT	P01	01504F	S, L, X	01504F-610001~
DF15ATH	P01	01504F	S, L, X	01504F-610001~
DF20A	P01, P40	02002F	S, L, X	02002F-610001~
DF20AR	P01	02002F	S, L, X	02002F-610001~
DF20AT	P01	02002F	S, L, X	02002F-610001~
DF20ATH	P01	02002F	S, L, X	02002F-610001~

MILLIMETER → INCH CONVERSION CHART


	0	1	2	3	4	5	6	7	8	9
00	.000	.039	.079	.118	.157	.197	.236	.276	.315	.354
10	.394	.433	.472	.512	.551	.591	.630	.669	.709	.748
20	.787	.827	.866	.906	.945	.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.535
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.214	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.031	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

How to read

	0	1	2	3	4
00	...	...	...	...	...
10	...	...	...	...	...
20	...	...	...	0.906	...
30	...	...	...	...	...


23 millimeters equal 0.906 inch

FIG.111A




DC90A_P01_016_111A
TURBINE HEAD

FIG.113A




DC90A_P01_016_113A
TURBINE BODY

FIG.116A




DC90A_P01_016_116A
TURBINE SET

FIG.120A




DC90A_P01_016_120A
TURBINE SET

FIG.121A




DC90A_P01_016_121A
TURBINE SET

FIG.121B




DC90A_P01_016_121B
TURBINE SET

FIG.121C




DC90A_P01_016_121C
TURBINE SET

FIG.121D




DC90A_P01_016_121D
TURBINE SET

FIG. 121E




DC9M_P01_01E_021E
CAM3D.NET

FIG. 121F




DC9M_P01_01E_021F
CAM3D.NET

FIG. 121G




DC9M_P01_01E_021G
CAM3D.NET

FIG. 121H




DC9M_P01_01E_021H
CAM3D.NET

FIG. 121J




DC9M_P01_01E_021J
CAM3D.NET

FIG. 121K




DC9M_P01_01E_021K
CAM3D.NET

FIG. 121L




DC9M_P01_01E_021L
CAM3D.NET

FIG. 121M




DC9M_P01_01E_021M
CAM3D.NET

FIG. 126A




DC60A_R11_016_026A
PIELET MARKING

FIG. 126B




DC60A_R11_016_026B
PIELET MARKING

FIG. 126C




DC60A_R11_016_026C
PIELET MARKING

FIG. 126D




DC60A_R11_016_026D
PIELET MARKING

FIG. 126E




DC60A_R11_016_026E
PIELET MARKING

FIG. 126F




DC60A_R11_016_026F
PIELET MARKING

FIG. 126G




DC60A_R11_016_026G
PIELET MARKING

FIG. 126H




DC60A_R11_016_026H
PIELET MARKING

FIG.146D




DC604_P01_016_H4D
FUEL PUMP

FIG.146E




DC604_P01_016_H4E
FUEL PUMP

FIG.146F




DC604_P01_016_H4F
FUEL PUMP

FIG.146G




DC604_P01_016_H4G
FUEL PUMP

FIG.146H



DC604_P01_016_H4H
FUEL PUMP

FIG.146J



DC604_P01_016_H4J
FUEL PUMP

FIG.146K






FIG.146M




DC904_P01_016_146M
WATER PUMP

FIG.160A




DC904_P01_016_160A
WATER PUMP

FIG.160B




DC904_P01_016_160B
WATER PUMP

FIG.160C




DC904_P01_016_160C
WATER PUMP

FIG.160D




DC904_P01_016_160D
WATER PUMP

FIG.160E




DC904_P01_016_160E
WATER PUMP

FIG.160F




DC904_P01_016_160F
WATER PUMP

FIG.160G




DC904_P01_016_160G
WATER PUMP

FIG.160H




DC904_P01_016_H6H
WATER PUMP

FIG.160J




DC904_P01_016_H6J
WATER PUMP

FIG.160K




DC904_P01_016_H6K
WATER PUMP

FIG.160L




DC904_P01_016_H6L
WATER PUMP

FIG.160M




DC904_P01_016_H6M
WATER PUMP

FIG.162A




DC904_P01_016_H6A
THERMOSTAT

FIG.163A




DC904_P01_016_H6A
THROTTLE BODY

FIG.163B




DC904_P01_016_H6B
THROTTLE BODY

FIG. 163C




DC6M_P11_016_163C
THROTTLE BODY

FIG. 163D




DC6M_P11_016_163D
THROTTLE BODY

FIG. 163E




DC6M_P11_016_163E
THROTTLE BODY

FIG. 163F




DC6M_P11_016_163F
THROTTLE BODY

FIG. 163G




DC6M_P11_016_163G
THROTTLE BODY

FIG. 163H




DC6M_P11_016_163H
THROTTLE BODY

FIG. 163J




DC6M_P11_016_163J
THROTTLE BODY

FIG. 163K




DC6M_P11_016_163K
THROTTLE BODY

FIG. 163L




DC604_P01_016_163L
THROTTLE CONTROL

FIG. 163M




DC604_P01_016_163M
THROTTLE CONTROL

FIG. 166A




DC604_P01_016_166A
THROTTLE CONTROL

FIG. 166B




DC604_P01_016_166B
THROTTLE CONTROL

FIG. 166C




DC604_P01_016_166C
THROTTLE CONTROL

FIG. 166D




DC604_P01_016_166D
THROTTLE CONTROL

FIG. 166E




DC604_P01_016_166E
THROTTLE CONTROL

FIG. 166F




DC604_P01_016_166F
THROTTLE CONTROL

FIG.167A




DCRM_P01_016_167A
RECCE STARTER

FIG.167B




DCRM_P01_016_167B
RECCE STARTER

FIG.167C




DCRM_P01_016_167C
RECCE STARTER

FIG.167D




DCRM_P01_016_167D
RECCE STARTER

FIG.167E




DCRM_P01_016_167E
RECCE STARTER

FIG.167F




DCRM_P01_016_167F
RECCE STARTER

FIG.167G




DCRM_P01_016_167G
RECCE STARTER

FIG.167H




DCRM_P01_016_167H
RECCE STARTER

FIG.167J




DC904_R01_016_167J
BECUL STARTER

FIG.167K




DC904_R01_016_167K
BECUL STARTER

FIG.167L




DC904_R01_016_167L
BECUL STARTER

FIG.167M




DC904_R01_016_167M
BECUL STARTER

FIG.175A




DC904_R01_016_175A
OLE PUMP

FIG.206A




DC904_R01_016_206A
CLUTCH ROD

FIG.206B




DC904_R01_016_206B
CLUTCH ROD

FIG.206C




DC904_R01_016_206C
CLUTCH ROD

FIG.206D




DC04_R01_016_206D
(CLUTCH RED)

FIG.206E




DC04_R01_016_206E
(CLUTCH RED)

FIG.206F




DC04_R01_016_206F
(CLUTCH RED)

FIG.206G




DC04_R01_016_206G
(CLUTCH RED)

FIG.206H




DC04_R01_016_206H
(CLUTCH RED)

FIG.206J




DC04_R01_016_206J
(CLUTCH RED)

FIG.206K




DC04_R01_016_206K
(CLUTCH RED)

FIG.206L




DC04_R01_016_206L
(CLUTCH RED)

FIG.220G




DC604_P01_016_203G
TRANSMISSION

FIG.220H




DC604_P01_016_203H
TRANSMISSION

FIG.220U




DC604_P01_016_203U
TRANSMISSION

FIG.220K




DC604_P01_016_203K
TRANSMISSION

FIG.220L




DC604_P01_016_203L
TRANSMISSION

FIG.220M




DC604_P01_016_203M
TRANSMISSION

FIG.301A




DC604_P01_016_301A
STARTING MOTOR

FIG.303A




DC604_P01_016_303A
MAGNETO

FIG.303B




DC604_P01_016_303B
MAGNETO

FIG.303C




DC604_P01_016_303C
MAGNETO

FIG.303D




DC604_P01_016_303D
MAGNETO

FIG.303E




DC604_P01_016_303E
MAGNETO

FIG.310A




DC604_P01_016_310A
RELECTROSERVIZIONE COIL

FIG.310B




DC604_P01_016_310B
RELECTROSERVIZIONE COIL

FIG.310C




DC604_P01_016_310C
RELECTROSERVIZIONE COIL

FIG.310D




DC604_P01_016_310D
RELECTROSERVIZIONE COIL

FIG.310E




DCRM_P01_016_310E
REC.TEDESCA/AVION.COR

FIG.310F




DCRM_P01_016_310F
REC.TEDESCA/AVION.COR

FIG.310G




DCRM_P01_016_310G
REC.TEDESCA/AVION.COR

FIG.310H




DCRM_P01_016_310H
REC.TEDESCA/AVION.COR

FIG.310J




DCRM_P01_016_310J
REC.TEDESCA/AVION.COR

FIG.310K




DCRM_P01_016_310K
REC.TEDESCA/AVION.COR

FIG.310L




DCRM_P01_016_310L
REC.TEDESCA/AVION.COR

FIG.310M




DCRM_P01_016_310M
REC.TEDESCA/AVION.COR

FIG.322A




DC6M_R11_016_3204
HARNESS

FIG.322B




DC6M_R11_016_3202
HARNESS

FIG.322C




DC6M_R11_016_3201
HARNESS

FIG.322D




DC6M_R11_016_3203
HARNESS

FIG.322E




DC6M_R11_016_3237
HARNESS

FIG.322F




DC6M_R11_016_3237
HARNESS

FIG.322G




DC6M_R11_016_3232
HARNESS

FIG.322H




DC6M_R11_016_3233
HARNESS

FIG.322J




DC604_R01_016_322J
UNASSEMBLED

FIG.322K




DC604_R01_016_322K
UNASSEMBLED

FIG.322L




DC604_R01_016_322L
UNASSEMBLED

FIG.322M




DC604_R01_016_322M
UNASSEMBLED

FIG.327A




DC604_R01_016_327A
PTT SWITCH

FIG.327B




DC604_R01_016_327B
PTT SWITCH

FIG.327C




DC604_R01_016_327C
PTT SWITCH

FIG.327D




DC604_R01_016_327D
PTT SWITCH

FIG.327E




DC904_P01_016_207E
PTT SWITCH

FIG.334A




DC904_P01_016_204A
SENSOR SWITCH

FIG.334B




DC904_P01_016_204G
SENSOR SWITCH

FIG.334C




DC904_P01_016_204C
SENSOR SWITCH

FIG.334D




DC904_P01_016_204D
SENSOR SWITCH

FIG.334E




DC904_P01_016_204E
SENSOR SWITCH

FIG.334F




DC904_P01_016_204F
SENSOR SWITCH

FIG.334G




DC904_P01_016_204G
SENSOR SWITCH

FIG.334H




DC04_R11_016_334H
SENSOR/ SWITCH

FIG.334J




DC04_R11_016_334J
SENSOR/ SWITCH

FIG.334K




DC04_R11_016_334K
SENSOR/ SWITCH

FIG.334L




DC04_R11_016_334L
SENSOR/ SWITCH

FIG.334M




DC04_R11_016_334M
SENSOR/ SWITCH

FIG.335A




DC04_R11_016_335A
CLAMP BRACKET

FIG.335B




DC04_R11_016_335B
CLAMP BRACKET

FIG.335C




DC04_R11_016_335C
CLAMP BRACKET

FIG.335D



DCRM_R01_016_335D
CLAMP BRACKET

FIG.335E



DCRM_R01_016_335E
CLAMP BRACKET

FIG.335F






FIG.335M




DC04_R11_016_335M
CLAMP BRACKET

FIG.336A




DC04_R11_016_336A
SWIVEL BRACKET

FIG.336B




DC04_R11_016_336B
SWIVEL BRACKET

FIG.336C




DC04_R11_016_336C
SWIVEL BRACKET

FIG.336D




DC04_R11_016_336D
SWIVEL BRACKET

FIG.336E




DC04_R11_016_336E
SWIVEL BRACKET

FIG.336F



DC04_R11_016_336F
SWIVEL BRACKET

FIG.336G



DC04_R11_016_336G
SWIVEL BRACKET

FIG.336H


DC604_R11_016_28M7
CAMERA BRACKET

FIG.336J


DC604_R11_016_28M7
CAMERA BRACKET

FIG.336K


DC604_R11_016_28M7
CAMERA BRACKET

FIG.336L


DC604_R11_016_28M7
CAMERA BRACKET

FIG.336M


DC604_R11_016_28M7
CAMERA BRACKET

FIG.338A


DC604_R11_016_28M4
TILT CYLINDER

FIG.338B


DC604_R11_016_28M7
TILT CYLINDER

FIG.338C




DC604_R11_016_28M7
TILT CYLINDER

FIG.338D




DC904_P01_016_38D
PIT C-000329

FIG.338E




DC904_P01_016_38E
PIT C-000329

FIG.340A




DC904_P01_016_34A
PIT 407232

FIG.340B




DC904_P01_016_34B
PIT 407232

FIG.340C




DC904_P01_016_34C
PIT 407232

FIG.340D




DC904_P01_016_34D
PIT 407232

FIG.340E




DC904_P01_016_34E
PIT 407232

FIG.401A




DC904_P01_016_401A
ENGINE HOUSING

FIG.405A




DC90A_P01_016_405A
SEE COVER

FIG.407A




DC90A_P01_016_407A
SEE COVER

FIG.410A




DC90A_P01_016_410A
SEE COVER

FIG.410B




DC90A_P01_016_410B
SEE COVER

FIG.410C




DC90A_P01_016_410C
SEE COVER

FIG.410D




DC90A_P01_016_410D
SEE COVER

FIG.410E




DC90A_P01_016_410E
SEE COVER

FIG.410F




DC90A_P01_016_410F
SEE COVER

FIG.410G




DC90A_P01_016_410G
SEE COVER

FIG.410H




DC90A_P01_016_410H
SEE COVER

FIG.410J




DC90A_P01_016_410J
SEE COVER

FIG.410K




DC90A_P01_016_410K
SEE COVER

FIG.410L




DC90A_P01_016_410L
SEE COVER

FIG.410M




DC90A_P01_016_410M
SEE COVER

FIG.420A



DC90A_P01_016_420A
ENGINE COVER

FIG.420B



DC90A_P01_016_420B
ENGINE COVER

FIG.420C


DC90A, P11, 016, 435C
ENGINE COVER

FIG.420D


DC90A, P11, 016, 435D
ENGINE COVER

FIG.420E


DC90A, P11, 016, 435E
ENGINE COVER

FIG.420F


DC90A, P11, 016, 435F
ENGINE COVER

FIG.420G


DC90A, P11, 016, 435G
ENGINE COVER

FIG.420H


DC90A, P11, 016, 435H
ENGINE COVER

FIG.420J


DC90A, P11, 016, 435J
ENGINE COVER

FIG.420K




DC90A, P11, 016, 435K
ENGINE COVER

FIG.420L




DC90A_P01_016_400
ENGINE COVER

FIG.420M




DC90A_P01_016_400M
ENGINE COVER

FIG.432A




DC90A_P01_016_400M
E.C.E. 140V

FIG.442A




DC90A_P01_016_440A
BRAGLIPW

FIG.442B




DC90A_P01_016_440B
BRAGLIPW

FIG.442C




DC90A_P01_016_440C
BRAGLIPW

FIG.442D




DC90A_P01_016_440D
BRAGLIPW

FIG.442E




DC90A_P01_016_440E
BRAGLIPW

FIG.442F




DC004_P01_016_442F
TILLAGE HANDLE

FIG.444A




DC004_P01_016_444A
TILLAGE HANDLE

FIG.444B




DC004_P01_016_444B
TILLAGE HANDLE

FIG.444C




DC004_P01_016_444C
TILLAGE HANDLE

FIG.444D




DC004_P01_016_444D
TILLAGE HANDLE

FIG.444E




DC004_P01_016_444E
TILLAGE HANDLE

FIG.444F




DC004_P01_016_444F
TILLAGE HANDLE

FIG.450A




DC004_P01_016_450A
REMOTE CONTROL

FIG.450B




DCRM_P01_016_450B
REMOTE CONTROL

FIG.450C




DCRM_P01_016_450C
REMOTE CONTROL

FIG.450D




DCRM_P01_016_450D
REMOTE CONTROL

FIG.450E




DCRM_P01_016_450E
REMOTE CONTROL

FIG.501F




DCRM_P01_016_501F
REMOTE CONTROL

FIG.501A




DCRM_P01_016_501A
OPT.46174H

FIG.501B




DCRM_P01_016_501B
OPT.46174H

FIG.501C




DCRM_P01_016_501C
OPT.46174H

FIG.501D




DC604_P01_016.810
OPT-AMT222

FIG.501E




DC604_P01_016.81E
OPT-AMT222

FIG.501F




DC604_P01_016.81F
OPT-AMT222

FIG.508A




DC604_P01_016.80A
OPT-AMT222

FIG.508B




DC604_P01_016.80B
OPT-AMT222

FIG.508C




DC604_P01_016.80C
OPT-AMT222

FIG.508D





DC604_P01_016.80D
OPT-AMT222

FIG.513A





DC604_P01_016.81A
OPT-AMT222

FIG.515F





DC04_R11_016_015C
OPT.FEMCCH CABLE

FIG.515G





DC04_R11_016_015C
OPT.FEMCCH CABLE

FIG.515H





DC04_R11_016_015I
OPT.FEMCCH CABLE

FIG.515J




DC04_R11_016_015I
OPT.FEMCCH CABLE

FIG.515K




DC04_R11_016_015K
OPT.FEMCCH CABLE

FIG.530A




DC04_R11_016_030A
OPT.SWITCH

FIG.530B




DC04_R11_016_030B
OPT.SWITCH

FIG.530C




DC04_R11_016_030C
OPT.SWITCH

FIG.530D




DC04_R01_016_830
OPT. REMOTE CONTROL ASSY SINGLE (1)

FIG.530E




DC04_R01_016_830F
OPT. REMOTE CONTROL ASSY SINGLE (1)

FIG.530F




DC04_R01_016_830F
OPT. REMOTE CONTROL ASSY SINGLE (1)

FIG.544A




DC04_R01_016_844
OPT. REMOTE CONTROL ASSY SINGLE (1)

FIG.544B




DC04_R01_016_844
OPT. REMOTE CONTROL ASSY SINGLE (1)

FIG.544C




DC04_R01_016_844C
OPT. REMOTE CONTROL ASSY SINGLE (1)

FIG.544D




DC04_R01_016_844D
OPT. REMOTE CONTROL ASSY SINGLE (1)

FIG.544E




DC04_R01_016_844E
OPT. REMOTE CONTROL ASSY SINGLE (1)

FIG.544F




DCRM_P01_016_844C
OPT-PARAMETRIC CONTROL ASSY SINGLE (1)

FIG.544G




DCRM_P01_016_844C
OPT-PARAMETRIC CONTROL ASSY SINGLE (1)

FIG.544H




DCRM_P01_016_844C
OPT-PARAMETRIC CONTROL ASSY SINGLE (1)

FIG.544J




DCRM_P01_016_844C
OPT-PARAMETRIC CONTROL ASSY SINGLE (1)

FIG.544K




DCRM_P01_016_844C
OPT-PARAMETRIC CONTROL ASSY SINGLE (1)

FIG.545A




DCRM_P01_016_844B
OPT-PARAMETRIC CONTROL ASSY SINGLE (2)

FIG.545B




DCRM_P01_016_844B
OPT-PARAMETRIC CONTROL ASSY SINGLE (2)

FIG.545C




DCRM_P01_016_844C
OPT-PARAMETRIC CONTROL ASSY SINGLE (2)

FIG.545D




DCRM_P01_016_840
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545E




DCRM_P01_016_840
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545F




DCRM_P01_016_840
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545G




DCRM_P01_016_840
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545H




DCRM_P01_016_841
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545J




DCRM_P01_016_841
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545K




DCRM_P01_016_841
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.546A




DCRM_P01_016_846
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.546B




DC00A_P01_016_846Z
OPT. PARACORD CABLE (ELECTRIC STARTER)

FIG.546C




DC00A_P01_016_846Z
OPT. PARACORD CABLE (ELECTRIC STARTER)

FIG.546D




DC00A_P01_016_846Z
OPT. PARACORD CABLE (ELECTRIC STARTER)

FIG.546E




DC00A_P01_016_846Z
OPT. PARACORD CABLE (ELECTRIC STARTER)

FIG.546F




DC00A_P01_016_846Z
OPT. PARACORD CABLE (ELECTRIC STARTER)

FIG.553A




DC00A_P01_016_853A
OPT. ELECTRICAL (MANUAL STARTER)

FIG.553B




DC00A_P01_016_853B
OPT. ELECTRICAL (MANUAL STARTER)

FIG.553C




DC00A_P01_016_853C
OPT. ELECTRICAL (MANUAL STARTER)

FIG.553D




DC90A_P01_016,820
OPT.ELECTRICAL (MANUAL STARTER)

FIG.561A




DC90A_P01_016,810
OPT.STARTING MOTOR (MANUAL STARTER)

FIG.561B




DC90A_P01_016,810
OPT.STARTING MOTOR (MANUAL STARTER)

FIG.561C




DC90A_P01_016,810
OPT.STARTING MOTOR (MANUAL STARTER)

FIG.561D




DC90A_P01_016,810
OPT.STARTING MOTOR (MANUAL STARTER)

FIG.575A




DC90A_P01_016,554
OPT.30A4G.LIN

FIG.575B




DC90A_P01_016,554
OPT.30A4G.LIN

FIG.575C




DC90A_P01_016,554
OPT.30A4G.LIN

FIG.575D




DC90A_P01_016_052D
OPT:ALL TO IN

FIG.583A




DC90A_P01_016_053A
OPT:ALL TO IN

FIG.600A




DC90A_P01_016_050A
OPT:ALL TO FUNCTION GAUGE

FIG.600B




DC90A_P01_016_050B
OPT:ALL TO FUNCTION GAUGE

FIG.600C




DC90A_P01_016_050C
OPT:ALL TO FUNCTION GAUGE

FIG.600D




DC90A_P01_016_050D
OPT:ALL TO FUNCTION GAUGE

FIG.600E



DC90A_P01_016_050E
OPT:ALL TO FUNCTION GAUGE

FIG.600F



DC90A_P01_016_050F
OPT:ALL TO FUNCTION GAUGE

FIG.111A

FIG.111A (1-B-2) CYLINDER HEAD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11110-89L01	HEAD, CYLINDER	1	
2	11141-89L00	GASKET, CYLINDER HEAD	1	
3	09119-08L02	BOLT (8X72)	6	
4	09119-08L01	BOLT (8X77)	2	
5	11261-93J00	COVER, PROTECTION ANODE	1	
6	09280-22019	O RING (D:1.9,ID:21.8)	1	
7	55321-87J01	ANODE, PROTECTION	1	
8	09103-06319	BOLT (6X14)	1	
9	01550-08207	BOLT	1	
10	11382-93E00	CAP, OIL FILLER	1	
11	09280-17003	O RING (D:3.1,ID:16.8)	1	
12	04211-11129	PIN	2	
13	11170-89L00	COVER, CYLINDER HEAD	1	
14	11162-89L00	GASKET, CYLINDER HEAD COVER	1	
15	01550-06207	BOLT	6	
16	11174-89L00	HOSE, BREATHER	1	
17	09401-12413	CLIP	2	
18	09482-00L04	SPARK PLUG (CPR6EA-9)	2	NGK
19	11115-93E00-001	GUIDE, VALVE (OS:0.3)	4	OPT




FIG.113A




FIG.113A (1-B-3) CYLINDER BLOCK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11300-89L02	BLOCK ASSY, CYLINDER	1	
2	01550-06357	.BOLT	6	
3	01560-08757	.BOLT	4	
4	04211-11129	.PIN	2	
5	16440-11D00	REGULATOR ASSY, ENGINE	1	
6	11291-91B50	HOOK, ENGINE	1	OPT
7	01550-08207	BOLT	1	OPT

FIG.116A




FIG.116A (1-B-4) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12111-89L00-0B0	PISTON	2	
2	12140-89L10	RING SET, PISTON	2	
3	12151-89L00	PIN, PISTON	2	
4	09381-16001	SNAP RING	4	
5	12160-89L11	CONNROD ASSY	2	
6	12163-89L02	.BOLT, CONNROD	4	
7	12220-89L00	CRANKSHAFT	1	
8	12341-89L10	BEARING, CRANKSHAFT	4	
9	09283-32039	OIL SEAL (32X44X6.5)	2	
10	12100-89L10-050	PISTON SET (OS:0.50)	2	OPT
11	12140-89L10-050	.RING SET, PISTON	2	OPT



FIG.120A




FIG.120A (1-B-5) TIMING BELT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12631-89L10	PULLEY, CRANKSHAFT (NT:17)	1	
2	12635-89L00	GUIDE, TIMING BELT	1	
3	12636-89L00	GUIDE, TIMING BELT (LOWER)	1	
4	12637-89L00	NUT, TIMING PULLEY	1	
5	12638-89L00	WASHER, PULLEY NUT LOCK	1	
6	12741-89L00	PULLEY, CAMSHAFT (NT:34)	1	
7	09103-06267	BOLT (6X18)	1	
8	09160-06171	WASHER (6.5X24X4)	1	
9	08341-31039	KEY	1	
10	08341-31039	KEY	1	
11	12625-89L01	BASE, STATOR	1	
12	04211-09149	PIN	2	
13	01550-06257	BOLT	2	
14	01550-06357	BOLT	2	
15	02122-04127	SCREW	3	
16	12761-93EL0	BELT, TIMING	1	
17	12744-89L00	PLATE, SENSING	1	

DF20A_P01_016_121A
CAMSHAFT



DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1-1	12700-89L01	CAMSHAFT ASSY	1	W/MANUAL STARTER
1-2	12700-89L21	CAMSHAFT ASSY	1	W/ELECTRIC STARTER
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121B




FIG.121B (1-B-7) CAMSHAFT (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121C




FIG.121C (1-B-8) CAMSHAFT (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121D




FIG.121D (1-B-9) CAMSHAFT (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12700-89L01	CAMSHAFT ASSY	1	W/MANUAL STARTER
1-2	12700-89L21	CAMSHAFT ASSY	1	W/ELECTRIC STARTER
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121E




FIG.121E (1-B-10) CAMSHAFT (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121F




FIG.121F (1-B-11) CAMSHAFT (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121G




FIG.121G (1-B-12) CAMSHAFT (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121H




FIG.121H (1-B-13) CAMSHAFT (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12700-89L01	CAMSHAFT ASSY	1	W/MANUAL STARTER
1-2	12700-89L21	CAMSHAFT ASSY	1	W/ELECTRIC STARTER
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121J




FIG.121J (1-B-14) CAMSHAFT (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12700-89L01	CAMSHAFT ASSY	1	W/MANUAL STARTER
1-2	12700-89L21	CAMSHAFT ASSY	1	W/ELECTRIC STARTER
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121K




FIG.121K (1-B-15) CAMSHAFT (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121L




FIG.121L (1-C-2) CAMSHAFT (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121M




FIG.121M (1-C-3) CAMSHAFT (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.126A




FIG.126A (1-C-4) INLET MANIFOLD (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06202	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L10	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126B




FIG.126B (1-C-5) INLET MANIFOLD (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06202	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L10	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126C




FIG.126C (1-C-6) INLET MANIFOLD (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06202	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L10	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126D




FIG.126D (1-C-7) INLET MANIFOLD (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06202	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L00	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	

FIG.126E




FIG.126E (1-C-8) INLET MANIFOLD (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06202	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L00	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126F




FIG.126F (1-C-9) INLET MANIFOLD (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06202	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L00	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126G




FIG.126G (1-C-10) INLET MANIFOLD (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06202	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L00	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126H




FIG.126H (1-C-11) INLET MANIFOLD (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06202	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	
13	61494-89L10	LABEL, OIL & CLEARANCE	1	

FIG.126J




FIG.126J (1-C-12) INLET MANIFOLD (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06202	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	
13	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126K




FIG.126K (1-C-13) INLET MANIFOLD (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06202	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	
13	61494-89L10	LABEL, OIL & CLEARANCE	1	

FIG.126L




FIG.126L (1-C-14) INLET MANIFOLD (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06202	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	
13	61494-89L10	LABEL, OIL & CLEARANCE	1	

FIG.126M




FIG.126M (1-C-15) INLET MANIFOLD (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06202	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	
13	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.144A





FIG.144A (1-D-2) FUEL INJECTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-89L00	HOSE, FUEL(PUMP TO DLVY)	1	
2	15710-50M00	INJECTOR ASSY, FUEL	2	
3	15716-65DT0	.GROMMET SET, FUEL INJECTOR	2	
4	15734-89L00	SPACER, DELIVERY PIPE	1	
5	15735-89L00	INSULATOR, DELIVERY PIPE	1	
6	15751-89L00	PIPE, DELIVERY	1	
7	09320-08062	CUSHION	2	
8	09401-11425	CLIP	2	
9	01550-06507	BOLT	2	



FIG.146A




DF20A_P01_016_146A
FUEL PUMP

FIG.146A (1-D-3) FUEL PUMP (DF9.9B P01)


REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L01	CHAMBER, EVAPORATION	1	
7	15770-89L01	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-06257	BOLT	2	
12	09116-06202	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-06167	BOLT	2	
21	01550-06207	BOLT	2	
22	01550-06257	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	

DF20A_P01_016




DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	



DF20A_P01_016


REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L01	CHAMBER, EVAPORATION	1	
7	15770-89L01	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-06257	BOLT	2	
12	09116-06202	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-06167	BOLT	2	
21	01550-06207	BOLT	2	
22	01550-06257	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	



DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146C




DF20A_P01_016_146C
FUEL PUMP

FIG.146C (1-D-7) FUEL PUMP (DF9.9BT P01)


REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L01	CHAMBER, EVAPORATION	1	
7	15770-89L01	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-06257	BOLT	2	
12	09116-06202	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-06167	BOLT	2	
21	01550-06207	BOLT	2	
22	01550-06257	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	

DF20A_P01_016




DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	



DF20A_P01_016


REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L01	CHAMBER, EVAPORATION	1	
7	15770-89L01	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-06257	BOLT	2	
12	09116-06202	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-06167	BOLT	2	
21	01550-06207	BOLT	2	
22	01550-06257	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	



DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146E




DF20A_P01_016_146E
FUEL PUMP

FIG.146E (1-D-11) FUEL PUMP (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L01	CHAMBER, EVAPORATION	1	
7	15770-89L01	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-06257	BOLT	2	
12	09116-06202	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-06167	BOLT	2	
21	01550-06207	BOLT	2	
22	01550-06257	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	

DF20A_P01_016



DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4, ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146F






FIG.146F (1-D-13) FUEL PUMP (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L01	CHAMBER, EVAPORATION	1	
7	15770-89L01	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-06257	BOLT	2	
12	09116-06202	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-06167	BOLT	2	
21	01550-06207	BOLT	2	
22	01550-06257	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	




DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	



DF20A_P01_016


REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L01	CHAMBER, EVAPORATION	1	
7	15770-89L01	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-06257	BOLT	2	
12	09116-06202	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-06167	BOLT	2	
21	01550-06207	BOLT	2	
22	01550-06257	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	



DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146H



DF20A_P01_016_146H
FUEL PUMP

FIG.146H (1-E-3) FUEL PUMP (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L01	CHAMBER, EVAPORATION	1	
7	15770-89L01	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-06257	BOLT	2	
12	09116-06202	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-06167	BOLT	2	
21	01550-06207	BOLT	2	
22	01550-06257	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	


DF20A_P01_016

DF20A_P01_016_146H
FUEL PUMP




DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	



DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L01	CHAMBER, EVAPORATION	1	
7	15770-89L01	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-06257	BOLT	2	
12	09116-06202	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-06167	BOLT	2	
21	01550-06207	BOLT	2	
22	01550-06257	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L10	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	




DF20A_P01_016_146J
FUEL PUMP

FIG.146J (1-E-6) FUEL PUMP (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146K




DF20A_P01_016_146K
FUEL PUMP

FIG.146K (1-E-7) FUEL PUMP (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L01	CHAMBER, EVAPORATION	1	
7	15770-89L01	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-06257	BOLT	2	
12	09116-06202	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-06167	BOLT	2	
21	01550-06207	BOLT	2	
22	01550-06257	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	


DF20A_P01_016



DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146L




DF20A_P01_016_146L
FUEL PUMP

FIG.146L (1-E-9) FUEL PUMP (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L01	CHAMBER, EVAPORATION	1	
7	15770-89L01	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-06257	BOLT	2	
12	09116-06202	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-06167	BOLT	2	
21	01550-06207	BOLT	2	
22	01550-06257	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	

DF20A_P01_016


DF20A_P01_016_146L
FUEL PUMP



DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146M




DF20A_P01_016_146M
FUEL PUMP

FIG.146M (1-E-11) FUEL PUMP (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L01	CHAMBER, EVAPORATION	1	
7	15770-89L01	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-06257	BOLT	2	
12	09116-06202	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-06167	BOLT	2	
21	01550-06207	BOLT	2	
22	01550-06257	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	

DF20A_P01_016

DF20A_P01_016_146M
FUEL PUMP



DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.160A




FIG.160A (1-E-13) WATER PUMP (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160B





FIG.160B (1-E-14) WATER PUMP (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT



REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160D





FIG.160D (1-F-2) WATER PUMP (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT



DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160F (1-F-4) WATER PUMP (DF15AT P01)




FIG.160G




FIG.160G (1-F-5) WATER PUMP (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160H




FIG.160H (1-F-6) WATER PUMP (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160J




FIG.160J (1-F-7) WATER PUMP (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J10	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J10	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J11	KIT, WATER PUMP REPAIR	1	OPT

FIG.160K




FIG.160K (1-F-8) WATER PUMP (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160L




FIG.160L (1-F-9) WATER PUMP (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160M




FIG.160M (1-F-10) WATER PUMP (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.162A




FIG.162A (1-F-11) THERMOSTAT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17670-91J00	THERMOSTAT (50C)	1	
2	17680-89L00	COVER, THERMOSTAT	1	
3	01550-06207	BOLT	3	
4	17712-89L10	HOSE, WATER (COOLER TO HOUSING)	1	
5	17712-89L00	HOSE, WATER (HOUSING TO COOLER)	1	
6	09401-08413	CLIP	4	
7	17685-89L00	SEAL, THERMOSTAT COVER	1	
8	18498-94J20	PROTECTOR,FUEL HOSE (L:320)	1	L:320->50
9	09408-00070	CLAMP	1	

FIG.163A




FIG.163A (1-F-12) THROTTLE BODY (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L01	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-06127	BOLT	1	
9	01550-06207	BOLT	2	

FIG.163B




FIG.163B (1-F-13) THROTTLE BODY (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L11	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-06207	BOLT	2	

FIG.163C




FIG.163C (1-F-14) THROTTLE BODY (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L11	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-06207	BOLT	2	

FIG.163D




FIG.163D (1-F-15) THROTTLE BODY (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L01	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-06127	BOLT	1	
9	01550-06207	BOLT	2	

FIG.163E




FIG.163E (1-G-2) THROTTLE BODY (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L11	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-06207	BOLT	2	

FIG.163F




FIG.163F (1-G-3) THROTTLE BODY (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L11	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-06207	BOLT	2	



FIG.163G




FIG.163G (1-G-4) THROTTLE BODY (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L01	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-06127	BOLT	1	
9	01550-06207	BOLT	2	

FIG.163H




FIG.163H (1-G-5) THROTTLE BODY (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L01	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-06127	BOLT	1	
9	01550-06207	BOLT	2	

FIG.163J




FIG.163J (1-G-6) THROTTLE BODY (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L01	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-06127	BOLT	1	
9	01550-06207	BOLT	2	

FIG.163K




FIG.163K (1-G-7) THROTTLE BODY (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L11	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-06207	BOLT	2	



FIG.163L




FIG.163L (1-G-8) THROTTLE BODY (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L11	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-06207	BOLT	2	

FIG.163M




FIG.163M (1-G-9) THROTTLE BODY (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L01	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-06127	BOLT	1	
9	01550-06207	BOLT	2	

FIG.166A




FIG.166A (1-G-10) THROTTLE CONTROL (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-06127	BOLT	1	
10	01550-06167	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	



FIG.166B

FIG.166B (1-G-11) THROTTLE CONTROL (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-06127	BOLT	1	
10	01550-06167	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	




FIG.166C




FIG.166C (1-G-12) THROTTLE CONTROL (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-06127	BOLT	1	
10	01550-06167	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	



FIG.166D

FIG.166D (1-G-13) THROTTLE CONTROL (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-06127	BOLT	1	
10	01550-06167	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	




FIG.166E

FIG.166E (1-G-14) THROTTLE CONTROL (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-06127	BOLT	1	
10	01550-06167	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	




FIG.166F

FIG.166F (1-G-15) THROTTLE CONTROL (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-06127	BOLT	1	
10	01550-06167	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	




FIG.167A




FIG.167A (1-H-2) RECOIL STARTER (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	

FIG.167B




FIG.167B (1-H-3) RECOIL STARTER (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	

FIG.167C




FIG.167C (1-H-4) RECOIL STARTER (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	09403-12406	CLAMP	1	

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	

FIG.167E




FIG.167E (1-H-6) RECOIL STARTER (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	

FIG.167F




FIG.167F (1-H-7) RECOIL STARTER (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	09403-12406	CLAMP	1	

FIG.167G




FIG.167G (1-H-8) RECOIL STARTER (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	09403-12406	CLAMP	1	

FIG.167H




FIG.167H (1-H-9) RECOIL STARTER (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	

FIG.167J




FIG.167J (1-H-10) RECOIL STARTER (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	

FIG.167K




FIG.167K (1-H-11) RECOIL STARTER (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	09403-12406	CLAMP	1	

FIG.167M




FIG.167M (1-H-13) RECOIL STARTER (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-06307	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-06207	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	09403-12406	CLAMP	1	

FIG.175A




FIG.175A (1-H-14) OIL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	16400-89L00	PUMP ASSY, OIL	1	
2	16510-45H10	FILTER, ENGINE OIL	1	
3	16512-99J00	CAP, OIL FILTER	1	
4	09280-13004	O RING (D:1.9,ID:13)	1	
5	09280-54001	O RING (D:2.4,ID:52.6)	1	
6	09440-18002	SPRING	1	
7	01550-06207	BOLT	3	
8	01550-06127	BOLT	1	
9	16910-89L01	GAUGE, OIL LEVEL	1	
10	16930-89L00	GUIDE, OIL LEVEL GAUGE	1	
11	09280-09008	O RING (D:2.1,ID:8.8)	1	
12	16431-89L00	BLOCK, OIL GALLERY	1	
13	59262-94J00	PIN, OIL PUMP	1	
14	02122-0630A	SCREW	3	

FIG.206A




FIG.206A (1-H-15) CLUTCH ROD (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.5)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-06127	BOLT	1	
18	01550-06257	BOLT	1	
19	02142-06207	SCREW	2	



FIG.206B




FIG.206B (1-I-2) CLUTCH ROD (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-06127	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-06127	BOLT	1	
16	01550-06257	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-06167	BOLT	2	

FIG.206C




FIG.206C (1-I-3) CLUTCH ROD (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-06127	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-06127	BOLT	1	
16	01550-06257	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-06167	BOLT	2	

FIG.206D




FIG.206D (1-I-4) CLUTCH ROD (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.5)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-06127	BOLT	1	
18	01550-06257	BOLT	1	
19	02142-06207	SCREW	2	



FIG.206E




FIG.206E (1-I-5) CLUTCH ROD (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-06127	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-06127	BOLT	1	
16	01550-06257	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-06167	BOLT	2	

FIG.206F




FIG.206F (1-I-6) CLUTCH ROD (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-06127	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-06127	BOLT	1	
16	01550-06257	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-06167	BOLT	2	

FIG.206G




FIG.206G (1-I-7) CLUTCH ROD (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.5)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-06127	BOLT	1	
18	01550-06257	BOLT	1	
19	02142-06207	SCREW	2	



FIG.206H




FIG.206H (1-I-8) CLUTCH ROD (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.5)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-06127	BOLT	1	
18	01550-06257	BOLT	1	
19	02142-06207	SCREW	2	



FIG.206J




FIG.206J (1-I-9) CLUTCH ROD (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.5)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-06127	BOLT	1	
18	01550-06257	BOLT	1	
19	02142-06207	SCREW	2	



FIG.206K




FIG.206K (1-I-10) CLUTCH ROD (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-06127	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-06127	BOLT	1	
16	01550-06257	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-06167	BOLT	2	

FIG.206L




FIG.206L (1-1-11) CLUTCH ROD (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-06127	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-06127	BOLT	1	
16	01550-06257	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-06167	BOLT	2	

FIG.206M




FIG.206M (1-I-12) CLUTCH ROD (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.5)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-06127	BOLT	1	
18	01550-06257	BOLT	1	
19	02142-06207	SCREW	2	



FIG.210A





FIG.210A (1-I-13) SHIFT ROD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	23311-95J00	CONNECTOR, CLUTCH ROD	1	
2-1	25111-99J01	ROD, SHIFT (S & L)	1	W/TRANSOM(S) W/TRANSOM(L)
2-2	25111-99J10	ROD, SHIFT (X)	1	W/TRANSOM(X)
3	25311-99J00	CAM, SHIFT	1	
4	09205-02004	SPRING PIN (2.5X12)	2	
5	25211-99JL0	GUIDE, SHIFT ROD	1	
6	25215-99J00	STOPPER, SHIFT ROD GUIDE	1	
7	29141-93J00	NUT, CLUTCH ROD (M6)	1	
8	09160-06082	WASHER (6.5X13X1.0)	1	
9	09280-06012	O RING (D:1.7,ID:5.8)	2	
10	09280-09012	O RING (D:2.3,ID:9)	1	
11	09289-06L02	DUST SEAL (5X17X3.5)	1	

FIG.220A



DF20A_P01_016_220A
TRANSMISSION

FIG.220A (1-I-14) TRANSMISSION (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_016

FIG.220A




FIG.220A (1-I-15) TRANSMISSION (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.220B




FIG.220B (1-J-2) TRANSMISSION (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

FIG.220B





FIG.220B (1-J-3) TRANSMISSION (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.220C



DF20A_P01_016_220C
TRANSMISSION

FIG.220C (1-J-4) TRANSMISSION (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17053	WASHER (T:1.1)	1	REV
11-2	09160-17054	WASHER (T:1.2)	1	REV
11-3	09160-17055	WASHER (T:1.3)	1	REV
11-4	09160-17056	WASHER (T:1.4)	1	REV
11-5	09160-17057	WASHER (T:1.5)	1	REV
11-6	09160-17058	WASHER (T:1.6)	1	REV
11-7	09160-17059	WASHER (T:1.7)	1	REV
11-8	09160-17060	WASHER (T:1.8)	1	REV
11-9	09160-17061	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_016

FIG.220C




FIG.220C (1-J-5) TRANSMISSION (DF9.9BT P01)


REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

The diagram is an exploded view of a mechanical assembly. The central component is a long shaft (1). At the top, there is a seal (2) and a ring (3). To the right, a housing (21) is shown with a cover (23) and a pin (24). Below the shaft, there are several seals (4, 5, 6, 7, 8, 9, 10, 11, 12, 13) and a spring (17). A directional arrow labeled 'FWD' is shown at the bottom left.

FIG.220D (1-J-6) TRANSMISSION (DF15A P01)

DF20A_P01_016

FIG.220D



DF20A_P01_016_220D
TRANSMISSION

FIG.220D (1-J-7) TRANSMISSION (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

DF20A_P01_016

Exploded view diagram of a mechanical assembly, likely a pump or motor, showing various components labeled with numbers 1 through 24. The diagram includes a central shaft assembly (1) with a long shaft (14) and a gear (10) at the end. Other components include a housing (23), a cover (21), and various seals and washers (2, 3, 4, 5, 6, 7, 8, 9, 11, 12, 13, 15, 16, 17, 18, 19, 20, 22, 24). A small arrow points to the right, indicating the direction of assembly.

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

FIG.220E




FIG.220E (1-J-9) TRANSMISSION (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

The diagram is an exploded view of a mechanical assembly. The central component is a long shaft (1). At the top, there is a seal assembly consisting of a seal (2) and a ring (3). Below the shaft, there are several more seals (4, 5, 6, 7, 8, 9, 10, 11, 12, 13) and a gear (14). To the right, there is a housing assembly (21) with a cover (23) and a seal (22). A bolt (24) is shown near the housing. At the bottom left, there is a drive mechanism (14) with a gear (10) and a shaft (17). A warning symbol 'FWD' is visible at the bottom left.


FIG.220F (1-J-10) TRANSMISSION (DF15AT P01)

DF20A_P01_016

Exploded view diagram of a mechanical assembly, likely a pump or motor, showing various components labeled with numbers 1 through 24. The diagram includes a central shaft assembly (1) with a long shaft (14) and a gear (10) at the bottom. Other components include a housing (21) with a cover (23), a pin (24), and various seals and washers (2, 3, 4, 5, 6, 7, 8, 9, 11, 12, 13, 15, 16, 17, 18, 19, 20, 22). A small arrow points to the right at the bottom left.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.220G



DF20A_P01_016_220G
TRANSMISSION

FIG.220G (1-J-12) TRANSMISSION (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17053	WASHER (T:1.1)	1	REV
11-2	09160-17054	WASHER (T:1.2)	1	REV
11-3	09160-17055	WASHER (T:1.3)	1	REV
11-4	09160-17056	WASHER (T:1.4)	1	REV
11-5	09160-17057	WASHER (T:1.5)	1	REV
11-6	09160-17058	WASHER (T:1.6)	1	REV
11-7	09160-17059	WASHER (T:1.7)	1	REV
11-8	09160-17060	WASHER (T:1.8)	1	REV
11-9	09160-17061	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_016

FIG.220G





FIG.220G (1-J-13) TRANSMISSION (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.220H



DF20A_P01_016_220H
TRANSMISSION

FIG.220H (1-J-14) TRANSMISSION (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_016

FIG.220H





FIG.220H (1-J-15) TRANSMISSION (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.220J



DF20A_P01_016_220J
TRANSMISSION

FIG.220J (1-K-2) TRANSMISSION (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_016

FIG.220J





FIG.220J (1-K-3) TRANSMISSION (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.220K



DF20A_P01_016_220K
TRANSMISSION

FIG.220K (1-K-4) TRANSMISSION (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_016

FIG.220K





FIG.220K (1-K-5) TRANSMISSION (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.220L



DF20A_P01_016_220L
TRANSMISSION

FIG.220L (1-K-6) TRANSMISSION (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17053	WASHER (T:1.1)	1	REV
11-2	09160-17054	WASHER (T:1.2)	1	REV
11-3	09160-17055	WASHER (T:1.3)	1	REV
11-4	09160-17056	WASHER (T:1.4)	1	REV
11-5	09160-17057	WASHER (T:1.5)	1	REV
11-6	09160-17058	WASHER (T:1.6)	1	REV
11-7	09160-17059	WASHER (T:1.7)	1	REV
11-8	09160-17060	WASHER (T:1.8)	1	REV
11-9	09160-17061	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_016

FIG.220L





FIG.220L (1-K-7) TRANSMISSION (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.220M




DF20A_P01_016_220M
TRANSMISSION

FIG.220M (1-K-8) TRANSMISSION (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20L04	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17053	WASHER (T:1.1)	1	REV
11-2	09160-17054	WASHER (T:1.2)	1	REV
11-3	09160-17055	WASHER (T:1.3)	1	REV
11-4	09160-17056	WASHER (T:1.4)	1	REV
11-5	09160-17057	WASHER (T:1.5)	1	REV
11-6	09160-17058	WASHER (T:1.6)	1	REV
11-7	09160-17059	WASHER (T:1.7)	1	REV
11-8	09160-17060	WASHER (T:1.8)	1	REV
11-9	09160-17061	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

DF20A_P01_016

FIG.220M



DF20A_P01_016_220M
TRANSMISSION

FIG.220M (1-K-9) TRANSMISSION (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

DF20A_P01_016

FIG.301A




FIG.301A (1-K-10) STARTING MOTOR (ELECTRIC STARTER)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-94J22	STARTING MOTOR	1	
2	31131-94J00	.BRUSH SET, PLUS	1	
3	31135-90J00	.SPRING	4	
4	31151-94J01	.CASE, GEAR	1	
5	31152-90J00	.PLATE, CENTER	1	
6	31153-90J00	.BRACKET, PLANET GEAR	1	
7	31171-96J00	.COVER KIT, DUST	1	
8	31173-94J01	.HOLDER ASSY, BRUSH	1	
9	31191-96J00	.LEVER, SHIFT	1	
10	31220-94J00	.SWITCH, MAGNET	1	
11	31310-90J00	.ARMATURE	1	
12	31320-94J00	.PINION	1	
13	31341-94J00	.SHAFT, PINION	1	
14	31343-90J00	.INTERNAL GEAR	1	
15	31344-90J00	.GEAR, PLANETARY	3	
16	31360-93J01	.WASHER SET	1	
17	31170-94J00	.COVER ASSY, STATER MOTOR REAR	1	
18	31912-89L00	BAND, STARTING MOTOR	1	
19	31918-94J00	DAMPER, LOWER	1	
20	38860-76F01	RELAY, STARTING MOTOR	1	
21	38915-90J00	HOLDER, RELAY	1	
22	01550-08207	BOLT	2	LOWER
23	01550-08307	BOLT	2	
24	08316-10087	NUT	1	

FIG.303A

FIG.303A (1-K-11) MAGNETO (MANUAL STARTER) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-89L10	COIL, STATOR & PULSER	1	
2	01547-0630A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L10	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	7	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	
11	08322-0106A	WASHER	3	
12	36615-96300	TERMINAL, RESIN	2	




FIG.303B




FIG.303B (1-K-12) MAGNETO (MANUAL STARTER) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-89L10	COIL, STATOR & PULSER	1	
2	01547-0630A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L10	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	7	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	
11	08322-0106A	WASHER	3	
12	36615-96300	TERMINAL, RESIN	2	



FIG.303C

FIG.303C (1-K-13) MAGNETO (MANUAL STARTER) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-89L10	COIL, STATOR & PULSER	1	
2	01547-0630A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L10	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	7	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	
11	08322-0106A	WASHER	3	
12	36615-96300	TERMINAL, RESIN	2	




FIG.303D

FIG.303D (1-K-14) MAGNETO (MANUAL STARTER) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-89L10	COIL, STATOR & PULSER	1	
2	01547-0630A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L10	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	7	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	
11	08322-0106A	WASHER	3	
12	36615-96300	TERMINAL, RESIN	2	




FIG.303E




FIG.303E (1-K-15) MAGNETO (ELECTRIC STARTER)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-89L00	COIL, STATOR & PULSER	1	
2	01547-0625A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L00	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	7	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	

FIG.310A




FIG.310A (1-L-2) RECTIFIER/IGNITION COIL (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	W/ELECTRIC STARTER
8	01550-06167	BOLT	1	W/ELECTRIC STARTER
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13-1	33920-89LC0	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
13-2	33920-89LD0	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
16	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
17	09160-06168	WASHER (6X14X1)	1	

FIG.310B




FIG.310B (1-L-3) RECTIFIER/IGNITION COIL (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13	33920-89LC0	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	

FIG.310C




FIG.310C (1-L-4) RECTIFIER/IGNITION COIL (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13	33920-89LC0	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	

FIG.310D




FIG.310D (1-L-5) RECTIFIER/IGNITION COIL (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	W/ELECTRIC STARTER
8	01550-06167	BOLT	1	W/ELECTRIC STARTER
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13-1	33920-89L80	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
13-2	33920-89L90	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
16	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
17	09160-06168	WASHER (6X14X1)	1	

FIG.310E




FIG.310E (1-L-6) RECTIFIER/IGNITION COIL (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13	33920-89L80	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	

FIG.310F

FIG.310F (1-L-7) RECTIFIER/IGNITION COIL (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13	33920-89L80	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310G

FIG.310G (1-L-8) RECTIFIER/IGNITION COIL (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13	33920-89L80	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310H




FIG.310H (1-L-9) RECTIFIER/IGNITION COIL (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	W/ELECTRIC STARTER
8	01550-06167	BOLT	1	W/ELECTRIC STARTER
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13-1	33920-89LA0	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
13-2	33920-89LB0	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
16	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
17	09160-06168	WASHER (6X14X1)	1	

FIG.310J




FIG.310J (1-L-10) RECTIFIER/IGNITION COIL (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	W/ELECTRIC STARTER
8	01550-06167	BOLT	1	W/ELECTRIC STARTER
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13-1	33920-89LE0	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
13-2	33920-89LF0	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
16	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
17	09160-06168	WASHER (6X14X1)	1	

FIG.310K

FIG.310K (1-L-11) RECTIFIER/IGNITION COIL (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13	33920-89LA0	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310L

FIG.310L (1-L-12) RECTIFIER/IGNITION COIL (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13	33920-89LA0	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310M

FIG.310M (1-L-13) RECTIFIER/IGNITION COIL (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L00	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-06307	BOLT	2	
13	33920-89LA0	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.322A

FIG.322A (1-L-14) HARNESS (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	W/ELECTRIC STARTER
2	09407-14403	CLAMP (L:125)	1	W/ELECTRIC STARTER
3	09407-14407	CLAMP (L:145)	1	W/ELECTRIC STARTER
4	01547-06167	BOLT	2	W/ELECTRIC STARTER
5-1	36610-89L04	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
5-2	36610-89L14	HARNESS ASSY, WIRING	1	W/MANUAL STARTER
6	09481-10501	.FUSE (10A)	1	W/ELECTRIC STARTER
7	09481-30501	.FUSE (30A)	1	W/ELECTRIC STARTER
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10	09407-14407	CLAMP (L:145)	4	
11	32916-89L00	COVER, CONNECTOR	1	W/ELECTRIC STARTER
12	36617-89L10	BRACKET, HARNESS	1	W/ELECTRIC STARTER
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L01	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-06127	BOLT	2	
21	01550-06127	BOLT	1	




FIG.322B




FIG.322B (1-L-15) HARNESS (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89L23	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	4	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L01	BRACKET, HARNESS	1	
10	36617-91J00	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00008	CLIP (ID:20)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-06127	BOLT	2	
16	01550-06127	BOLT	1	
17-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
17-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

FIG.322C




FIG.322C (2-B-2) HARNESS (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89L52	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	2	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L30	BRACKET, HARNESS	1	
10	36617-89L20	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00024	CLIP (ID:23)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-06127	BOLT	4	
16	01550-06127	BOLT	1	
17	36617-89L40	BRACKET, HARNESS	1	
18	36991-91J00	CLAMP, EMERGENCY SWITCH LEAD	1	
19-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
19-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

FIG.322D




FIG.322D (2-B-3) HARNESS (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	W/ELECTRIC STARTER
2	09407-14403	CLAMP (L:125)	1	W/ELECTRIC STARTER
3	09407-14407	CLAMP (L:145)	1	W/ELECTRIC STARTER
4	01547-06167	BOLT	2	W/ELECTRIC STARTER
5-1	36610-89L04	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
5-2	36610-89L14	HARNESS ASSY, WIRING	1	W/MANUAL STARTER
6	09481-10501	.FUSE (10A)	1	W/ELECTRIC STARTER
7	09481-30501	.FUSE (30A)	1	W/ELECTRIC STARTER
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10	09407-14407	CLAMP (L:145)	4	
11	32916-89L00	COVER, CONNECTOR	1	W/ELECTRIC STARTER
12	36617-89L10	BRACKET, HARNESS	1	W/ELECTRIC STARTER
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L01	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-06127	BOLT	2	
21	01550-06127	BOLT	1	

FIG.322E




FIG.322E (2-B-4) HARNESS (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89L23	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	4	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L01	BRACKET, HARNESS	1	
10	36617-91J00	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00008	CLIP (ID:20)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-06127	BOLT	2	
16	01550-06127	BOLT	1	
17-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
17-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

FIG.322F




FIG.322F (2-B-5) HARNESS (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89L52	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	2	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L30	BRACKET, HARNESS	1	
10	36617-89L20	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00024	CLIP (ID:23)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-06127	BOLT	4	
16	01550-06127	BOLT	1	
17	36617-89L40	BRACKET, HARNESS	1	
18	36991-91J00	CLAMP, EMERGENCY SWITCH LEAD	1	
19-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
19-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

FIG.322G




FIG.322G (2-B-6) HARNESS (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	09407-14403	CLAMP (L:125)	1	
3	09407-14407	CLAMP (L:145)	1	
4	01547-06167	BOLT	2	
5	36610-89L42	HARNESS ASSY, WIRING	1	
6	09481-10501	.FUSE (10A)	1	
7	09481-30501	.FUSE (30A)	1	
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10	09407-14407	CLAMP (L:145)	2	
11	32916-89L00	COVER, CONNECTOR	1	
12	36617-89L10	BRACKET, HARNESS	1	
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L30	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-06127	BOLT	4	
21	01550-06127	BOLT	1	
22	36617-89L40	BRACKET, HARNESS	1	
23	36991-91J00	CLAMP, EMERGENCY SWITCH LEAD	1	

FIG.322H

FIG.322H (2-B-7) HARNESS (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	W/ELECTRIC STARTER
2	09407-14403	CLAMP (L:125)	1	W/ELECTRIC STARTER
3	09407-14407	CLAMP (L:145)	1	W/ELECTRIC STARTER
4	01547-06167	BOLT	2	W/ELECTRIC STARTER
5-1	36610-89L04	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
5-2	36610-89L14	HARNESS ASSY, WIRING	1	W/MANUAL STARTER
6	09481-10501	.FUSE (10A)	1	W/ELECTRIC STARTER
7	09481-30501	.FUSE (30A)	1	W/ELECTRIC STARTER
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10	09407-14407	CLAMP (L:145)	4	
11	32916-89L00	COVER, CONNECTOR	1	W/ELECTRIC STARTER
12	36617-89L10	BRACKET, HARNESS	1	W/ELECTRIC STARTER
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L01	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-06127	BOLT	2	
21	01550-06127	BOLT	1	




FIG.322J

FIG.322J (2-B-8) HARNESS (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	W/ELECTRIC STARTER
2	09407-14403	CLAMP (L:125)	1	W/ELECTRIC STARTER
3	09407-14407	CLAMP (L:145)	1	W/ELECTRIC STARTER
4	01547-06167	BOLT	2	W/ELECTRIC STARTER
5-1	36610-89L04	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
5-2	36610-89L14	HARNESS ASSY, WIRING	1	W/MANUAL STARTER
6	09481-10501	.FUSE (10A)	1	W/ELECTRIC STARTER
7	09481-30501	.FUSE (30A)	1	W/ELECTRIC STARTER
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10	09407-14407	CLAMP (L:145)	4	
11	32916-89L00	COVER, CONNECTOR	1	W/ELECTRIC STARTER
12	36617-89L10	BRACKET, HARNESS	1	W/ELECTRIC STARTER
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L01	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-06127	BOLT	2	
21	01550-06127	BOLT	1	





FIG.322K



DF20A_P01_016_322K
HARNESS

FIG.322K (2-B-9) HARNESS (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89L23	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	4	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L01	BRACKET, HARNESS	1	
10	36617-91J00	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00008	CLIP (ID:20)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-06127	BOLT	2	
16	01550-06127	BOLT	1	
17-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
17-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

DF20A_P01_016

FIG.322L




FIG.322L (2-B-10) HARNESS (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89L52	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	2	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L30	BRACKET, HARNESS	1	
10	36617-89L20	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00024	CLIP (ID:23)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-06127	BOLT	4	
16	01550-06127	BOLT	1	
17	36617-89L40	BRACKET, HARNESS	1	
18	36991-91J00	CLAMP, EMERGENCY SWITCH LEAD	1	
19-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
19-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

FIG.322M




FIG.322M (2-B-11) HARNESS (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	09407-14403	CLAMP (L:125)	1	
3	09407-14407	CLAMP (L:145)	1	
4	01547-06167	BOLT	2	
5	36610-89L42	HARNESS ASSY, WIRING	1	
6	09481-10501	.FUSE (10A)	1	
7	09481-30501	.FUSE (30A)	1	
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10	09407-14407	CLAMP (L:145)	2	
11	32916-89L00	COVER, CONNECTOR	1	
12	36617-89L10	BRACKET, HARNESS	1	
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L30	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-06127	BOLT	4	
21	01550-06127	BOLT	1	
22	36617-89L40	BRACKET, HARNESS	1	
23	36991-91J00	CLAMP, EMERGENCY SWITCH LEAD	1	

FIG.327A




FIG.327A (2-B-12) PTT SWITCH (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J20	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-99E04	SWITCH ASSY, PTT	1	
4	09116-06202	BOLT (6X25)	2	
5	09169-06062	WASHER	2	

FIG.327B




FIG.327B (2-B-13) PTT SWITCH (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J20	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-99E04	SWITCH ASSY, PTT	1	
4	09116-06202	BOLT (6X25)	2	
5	09169-06062	WASHER	2	

FIG.327C




FIG.327C (2-B-14) PTT SWITCH (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J20	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-94JA2	SWITCH ASSY, PTT	1	
4	37852-94JA0	PLATE, PTT SWITCH	1	
5	09125-05046	SCREW (5X12)	2	
6	29103-93J00	BOLT, PTT SW BRACKET (6X12)	2	
7	09140-05005	NUT	2	
8	09116-06202	BOLT (6X25)	2	
9	09169-06062	WASHER	2	
10	37851-89L00	HOLDER, PTT SWITCH	1	

FIG.327D




FIG.327D (2-B-15) PTT SWITCH (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J20	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-99E04	SWITCH ASSY, PTT	1	
4	09116-06202	BOLT (6X25)	2	
5	09169-06062	WASHER	2	

FIG.327E




FIG.327E (2-C-2) PTT SWITCH (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J20	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-94JA2	SWITCH ASSY, PTT	1	
4	37852-94JA0	PLATE, PTT SWITCH	1	
5	09125-05046	SCREW (5X12)	2	
6	29103-93J00	BOLT, PTT SW BRACKET (6X12)	2	
7	09140-05005	NUT	2	
8	09116-06202	BOLT (6X25)	2	
9	09169-06062	WASHER	2	
10	37851-89L00	HOLDER, PTT SWITCH	1	

FIG.334A




FIG.334A (2-C-3) SENSOR/SWITCH (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L01	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	37163-89L00	PLUG, STARTING SWITCH HOLE	1	W/MANUAL STARTER
7	37721-89L00	SWITCH ASSY, NEUTRAL	1	
8	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
9	01550-06167	BOLT	1	
10	36616-89L03	HOLDER, CONNECTOR	1	
11	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
12	13650-52G00	SENSOR, INLET AIR TEMP	1	
13	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
14	18590-58M00	SENSOR, MAP	1	
15	01550-06207	BOLT	1	

FIG.334B




FIG.334B (2-C-4) SENSOR/SWITCH (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-06167	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-06207	BOLT	1	

FIG.334C




FIG.334C (2-C-5) SENSOR/SWITCH (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-06167	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-06207	BOLT	1	

FIG.334D




FIG.334D (2-C-6) SENSOR/SWITCH (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L01	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	37163-89L00	PLUG, STARTING SWITCH HOLE	1	W/MANUAL STARTER
7	37721-89L00	SWITCH ASSY, NEUTRAL	1	
8	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
9	01550-06167	BOLT	1	
10	36616-89L03	HOLDER, CONNECTOR	1	
11	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
12	13650-52G00	SENSOR, INLET AIR TEMP	1	
13	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
14	18590-58M00	SENSOR, MAP	1	
15	01550-06207	BOLT	1	

FIG.334E




FIG.334E (2-C-7) SENSOR/SWITCH (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-06167	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-06207	BOLT	1	

FIG.334F




FIG.334F (2-C-8) SENSOR/SWITCH (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-06167	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-06207	BOLT	1	

FIG.334G




FIG.334G (2-C-9) SENSOR/SWITCH (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L01	SWITCH ASSY, STARTER MOTOR	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-06167	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-06207	BOLT	1	

FIG.334H




FIG.334H (2-C-10) SENSOR/SWITCH (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L01	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	37163-89L00	PLUG, STARTING SWITCH HOLE	1	W/MANUAL STARTER
7	37721-89L00	SWITCH ASSY, NEUTRAL	1	
8	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
9	01550-06167	BOLT	1	
10	36616-89L03	HOLDER, CONNECTOR	1	
11	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
12	13650-52G00	SENSOR, INLET AIR TEMP	1	
13	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
14	18590-58M00	SENSOR, MAP	1	
15	01550-06207	BOLT	1	

FIG.334J




FIG.334J (2-C-11) SENSOR/SWITCH (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L01	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	37163-89L00	PLUG, STARTING SWITCH HOLE	1	W/MANUAL STARTER
7	37721-89L00	SWITCH ASSY, NEUTRAL	1	
8	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
9	01550-06167	BOLT	1	
10	36616-89L03	HOLDER, CONNECTOR	1	
11	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
12	13650-52G00	SENSOR, INLET AIR TEMP	1	
13	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
14	18590-58M00	SENSOR, MAP	1	
15	01550-06207	BOLT	1	

FIG.334K




FIG.334K (2-C-12) SENSOR/SWITCH (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-06167	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-06207	BOLT	1	

FIG.334L




FIG.334L (2-C-13) SENSOR/SWITCH (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-06167	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-06207	BOLT	1	

FIG.334M





FIG.334M (2-C-14) SENSOR/SWITCH (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L01	SWITCH ASSY, STARTER MOTOR	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-06167	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-06207	BOLT	1	

FIG.335A




DF20A_P01_016_335A
CLAMP BRACKET

FIG.335A (2-C-15) CLAMP BRACKET (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-90L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

DF20A_P01_016

FIG.335B



DF20A_P01_016_335B
CLAMP BRACKET

FIG.335B (2-D-2) CLAMP BRACKET (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-89L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

DF20A_P01_016

FIG.335C





FIG.335C (2-D-3) CLAMP BRACKET (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89LA0-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89LA0-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	09205-06021	SPRING PIN (6X25)	2	
4	41211-95J00	SCREW, CLAMP	2	
5	41212-91J00	HANDLE, CLAMP	2	
6	41213-94J01	PLATE, CLAMP	2	
7	41130-94JA1	SHAFT, CLAMP BRKT	1	
8	41135-93J11	WASHER, CLAMP BRKT SHAFT	1	
9	36894-87D00	LEAD, SWIVEL TO CLAMP	1	
10	36894-87D00	LEAD, PWR TILT TO CLAMP PORT	1	
11	36895-87D01	LEAD, PWR TILT TO CLAMP STBD	1	
12	09125-06063	SCREW (6X10)	5	
13	09159-22006	NUT	1	
14	41221-94JA0	KNOB, TILT STOPPER	1	
15	41222-94JA0	PIN, TILT STOPPER	1	
16	41226-94JA0	BUSH, TILT STOPPER	1	
17	45421-94JA0	PIN, TILT LOCK	2	
18	09116-08128	BOLT (8X40)	2	
19	09205-03004	SPRING PIN (3X20)	1	
20-1	55321-87J01	ANODE, PROTECTION	2	
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
21	09103-06319	BOLT (6X14)	2	
22	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
23	09160-08081	WASHER (8.5X23X1.5)	2	
24	09100-08311	BOLT (8X90)	2	
25	09140-08023-XC0	NUT	2	
26	09160-08170	WASHER (8.5X16X2)	2	
27	69911-91J50	MARK, CLAMP BRACKET	1	
28	41210-89LA0	SCREW SET, CLAMP	1	OPT

FIG.335D




DF20A_P01_016_335D
CLAMP BRACKET

FIG.335D (2-D-4) CLAMP BRACKET (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-90L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

DF20A_P01_016

FIG.335E



DF20A_P01_016_335E
CLAMP BRACKET

FIG.335E (2-D-5) CLAMP BRACKET (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-89L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

DF20A_P01_016

FIG.335F




FIG.335F (2-D-6) CLAMP BRACKET (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89LA0-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89LA0-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	09205-06021	SPRING PIN (6X25)	2	
4	41211-95J00	SCREW, CLAMP	2	
5	41212-91J00	HANDLE, CLAMP	2	
6	41213-94J01	PLATE, CLAMP	2	
7	41130-94JA1	SHAFT, CLAMP BRKT	1	
8	41135-93J11	WASHER, CLAMP BRKT SHAFT	1	
9	36894-87D00	LEAD, SWIVEL TO CLAMP	1	
10	36894-87D00	LEAD, PWR TILT TO CLAMP PORT	1	
11	36895-87D01	LEAD, PWR TILT TO CLAMP STBD	1	
12	09125-06063	SCREW (6X10)	5	
13	09159-22006	NUT	1	
14	41221-94JA0	KNOB, TILT STOPPER	1	
15	41222-94JA0	PIN, TILT STOPPER	1	
16	41226-94JA0	BUSH, TILT STOPPER	1	
17	45421-94JA0	PIN, TILT LOCK	2	
18	09116-08128	BOLT (8X40)	2	
19	09205-03004	SPRING PIN (3X20)	1	
20-1	55321-87J01	ANODE, PROTECTION	2	
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
21	09103-06319	BOLT (6X14)	2	
22	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
23	09160-08081	WASHER (8.5X23X1.5)	2	
24	09100-08311	BOLT (8X90)	2	
25	09140-08023-XC0	NUT	2	
26	09160-08170	WASHER (8.5X16X2)	2	
27	69911-91J50	MARK, CLAMP BRACKET	1	
28	41210-89LA0	SCREW SET, CLAMP	1	OPT

FIG.335G




FIG.335G (2-D-7) CLAMP BRACKET (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89LA0-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89LA0-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	09205-06021	SPRING PIN (6X25)	2	
4	41211-95J00	SCREW, CLAMP	2	
5	41212-91J00	HANDLE, CLAMP	2	
6	41213-94J01	PLATE, CLAMP	2	
7	41130-94JA1	SHAFT, CLAMP BRKT	1	
8	41135-93J11	WASHER, CLAMP BRKT SHAFT	1	
9	36894-87D00	LEAD, SWIVEL TO CLAMP	1	
10	36894-87D00	LEAD, PWR TILT TO CLAMP PORT	1	
11	36895-87D01	LEAD, PWR TILT TO CLAMP STBD	1	
12	09125-06063	SCREW (6X10)	5	
13	09159-22006	NUT	1	
14	41221-94JA0	KNOB, TILT STOPPER	1	
15	41222-94JA0	PIN, TILT STOPPER	1	
16	41226-94JA0	BUSH, TILT STOPPER	1	
17	45421-94JA0	PIN, TILT LOCK	2	
18	09116-08128	BOLT (8X40)	2	
19	09205-03004	SPRING PIN (3X20)	1	
20-1	55321-87J01	ANODE, PROTECTION	2	
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
21	09103-06319	BOLT (6X14)	2	
22	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
23	09160-08081	WASHER (8.5X23X1.5)	2	
24	09100-08311	BOLT (8X90)	2	
25	09140-08023-XC0	NUT	2	
26	09160-08170	WASHER (8.5X16X2)	2	
27	69911-91J50	MARK, CLAMP BRACKET	1	
28	41210-89LA0	SCREW SET, CLAMP	1	OPT

FIG.335H





FIG.335H (2-D-8) CLAMP BRACKET (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-90L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

FIG.335J




DF20A_P01_016_335J
CLAMP BRACKET

FIG.335J (2-D-9) CLAMP BRACKET (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-90L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

DF20A_P01_016

FIG.335K



DF20A_P01_016_335K
CLAMP BRACKET

FIG.335K (2-D-10) CLAMP BRACKET (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-89L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

DF20A_P01_016

FIG.335L




FIG.335L (2-D-11) CLAMP BRACKET (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89LA0-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89LA0-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	09205-06021	SPRING PIN (6X25)	2	
4	41211-95J00	SCREW, CLAMP	2	
5	41212-91J00	HANDLE, CLAMP	2	
6	41213-94J01	PLATE, CLAMP	2	
7	41130-94JA1	SHAFT, CLAMP BRKT	1	
8	41135-93J11	WASHER, CLAMP BRKT SHAFT	1	
9	36894-87D00	LEAD, SWIVEL TO CLAMP	1	
10	36894-87D00	LEAD, PWR TILT TO CLAMP PORT	1	
11	36895-87D01	LEAD, PWR TILT TO CLAMP STBD	1	
12	09125-06063	SCREW (6X10)	5	
13	09159-22006	NUT	1	
14	41221-94JA0	KNOB, TILT STOPPER	1	
15	41222-94JA0	PIN, TILT STOPPER	1	
16	41226-94JA0	BUSH, TILT STOPPER	1	
17	45421-94JA0	PIN, TILT LOCK	2	
18	09116-08128	BOLT (8X40)	2	
19	09205-03004	SPRING PIN (3X20)	1	
20-1	55321-87J01	ANODE, PROTECTION	2	
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
21	09103-06319	BOLT (6X14)	2	
22	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
23	09160-08081	WASHER (8.5X23X1.5)	2	
24	09100-08311	BOLT (8X90)	2	
25	09140-08023-XC0	NUT	2	
26	09160-08170	WASHER (8.5X16X2)	2	
27	69911-91J50	MARK, CLAMP BRACKET	1	
28	41210-89LA0	SCREW SET, CLAMP	1	OPT

FIG.335M





FIG.335M (2-D-12) CLAMP BRACKET (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89LA0-0EP	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89LA0-0EP	BRACKET, CLAMP PORT (BLACK)	1	
3	09205-06021	SPRING PIN (6X25)	2	
4	41211-95J00	SCREW, CLAMP	2	
5	41212-91J00	HANDLE, CLAMP	2	
6	41213-94J01	PLATE, CLAMP	2	
7	41130-94JA1	SHAFT, CLAMP BRKT	1	
8	41135-93J11	WASHER, CLAMP BRKT SHAFT	1	
9	36894-87D00	LEAD, SWIVEL TO CLAMP	1	
10	36894-87D00	LEAD, PWR TILT TO CLAMP PORT	1	
11	36895-87D01	LEAD, PWR TILT TO CLAMP STBD	1	
12	09125-06063	SCREW (6X10)	5	
13	09159-22006	NUT	1	
14	41221-94JA0	KNOB, TILT STOPPER	1	
15	41222-94JA0	PIN, TILT STOPPER	1	
16	41226-94JA0	BUSH, TILT STOPPER	1	
17	45421-94JA0	PIN, TILT LOCK	2	
18	09116-08128	BOLT (8X40)	2	
19	09205-03004	SPRING PIN (3X20)	1	
20-1	55321-87J01	ANODE, PROTECTION	2	
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
21	09103-06319	BOLT (6X14)	2	
22	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
23	09160-08081	WASHER (8.5X23X1.5)	2	
24	09100-08311	BOLT (8X90)	2	
25	09140-08023-XC0	NUT	2	
26	09160-08170	WASHER (8.5X16X2)	2	
27	69911-91J50	MARK, CLAMP BRACKET	1	
28	41210-89LA0	SCREW SET, CLAMP	1	OPT

FIG.336A




DF20A_P01_016_336A
SWIVEL BRACKET

FIG.336A (2-D-13) SWIVEL BRACKET (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43411-89L00	LEVER, STEERING ADJUSTER	1	
28	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
29	43420-89L00	PLATE, STRG ADJ FRICTION	1	

DF20A_P01_016

FIG.336A




DF20A_P01_016_336A
SWIVEL BRACKET

FIG.336A (2-D-14) SWIVEL BRACKET (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	43425-89L00	PLATE, STRG ADJ UPPER	1	
31	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
32	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
33	43516-89J00	WASHER, STEERING ADJUSTER	2	
34	43517-89L00	SPACER, STEERING ADJUSTER	1	
35	09116-06225	BOLT (6X15)	4	
36	09159-08L02	NUT	1	
37	09161-08019	WASHER (8.2X18X1.2)	1	

DF20A_P01_016

DF20A_P01_016_336B
SWIVEL BRACKET



DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	W/TRANSOM(X)
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
28	09160-08082	WASHER (8.5X16X1.2)	2	
29	09108-08286	STUD BOLT	2	

FIG.336B




FIG.336B (2-E-2) SWIVEL BRACKET (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	09159-08059	NUT	2	
31	43759-89L00	HOLDER, DRAIN HOSE	1	
32	09116-06225	BOLT (6X15)	1	

FIG.336C




FIG.336C (2-E-3) SWIVEL BRACKET (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE	3	W/TRANSOM(S)
1-2	22511-99011	NIPPLE	4	W/TRANSOM(L) W/TRANSOM(X)
2-1	43111-89LB0-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89LA0-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-94JA0	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	43411-939L0	PLATE, STEERING ADJUSTER	1	
10	43412-93900	COVER, STEERING ADJUSTER	1	
11	29440-93J00	SPRING, STEERING ADJUSTER	1	
12	09160-08082	WASHER (8.5X16X1.2)	1	
13	09100-08232	BOLT (8X30)	1	
14	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
15	09160-08082	WASHER (8.5X16X1.2)	2	
16	09108-08286	STUD BOLT	2	
17	09159-08059	NUT	2	
18	43759-89L00	HOLDER, DRAIN HOSE	1	
19	09116-06225	BOLT (6X15)	1	
20-1	55321-87J01	ANODE, PROTECTION	1	W/TRANSOM(L) W/TRANSOM(X)
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT W/TRANSOM(L) W/TRANSOM(X)
21	09103-06319	BOLT (6X14)	1	W/TRANSOM(L) W/TRANSOM(X)

FIG.336D





FIG.336D (2-E-4) SWIVEL BRACKET (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43411-89L00	LEVER, STEERING ADJUSTER	1	
28	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
29	43420-89L00	PLATE, STRG ADJ FRICTION	1	

FIG.336E



DF20A_P01_016_336E
SWIVEL BRACKET

FIG.336E (2-E-6) SWIVEL BRACKET (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
28	09160-08082	WASHER (8.5X16X1.2)	2	
29	09108-08286	STUD BOLT	2	

DF20A_P01_016

FIG.336E




FIG.336E (2-E-7) SWIVEL BRACKET (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	09159-08059	NUT	2	
31	43759-89L00	HOLDER, DRAIN HOSE	1	
32	09116-06225	BOLT (6X15)	1	

FIG.336F




FIG.336F (2-E-8) SWIVEL BRACKET (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE	3	W/TRANSOM(S)
1-2	22511-99011	NIPPLE	4	W/TRANSOM(L) W/TRANSOM(X)
2-1	43111-89LB0-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89LA0-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-94JA0	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	43411-939L0	PLATE, STEERING ADJUSTER	1	
10	43412-93900	COVER, STEERING ADJUSTER	1	
11	29440-93J00	SPRING, STEERING ADJUSTER	1	
12	09160-08082	WASHER (8.5X16X1.2)	1	
13	09100-08232	BOLT (8X30)	1	
14	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
15	09160-08082	WASHER (8.5X16X1.2)	2	
16	09108-08286	STUD BOLT	2	
17	09159-08059	NUT	2	
18	43759-89L00	HOLDER, DRAIN HOSE	1	
19	09116-06225	BOLT (6X15)	1	
20-1	55321-87J01	ANODE, PROTECTION	1	W/TRANSOM(L) W/TRANSOM(X)
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT W/TRANSOM(L) W/TRANSOM(X)
21	09103-06319	BOLT (6X14)	1	W/TRANSOM(L) W/TRANSOM(X)

FIG.336G




FIG.336G (2-E-9) SWIVEL BRACKET (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE	3	W/TRANSOM(S)
1-2	22511-99011	NIPPLE	4	W/TRANSOM(L) W/TRANSOM(X)
2-1	43111-89LB0-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89LA0-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-94JA0	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	43411-939L0	PLATE, STRG ADJUSTER	1	
10	43412-93900	COVER, STEERING ADJUSTER	1	
11	29440-93J00	SPRING, STEERING ADJUSTER	1	
12	09160-08082	WASHER (8.5X16X1.2)	1	
13	09100-08232	BOLT (8X30)	1	
14	43411-89LA0	LEVER, STEERING ADJUSTER	1	
15	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
16	43420-89L00	PLATE, STRG ADJ FRICTION	1	
17	43425-89L00	PLATE, STRG ADJ UPPER	1	
18	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
19	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
20	43516-89J00	WASHER, STEERING ADJUSTER	2	
21	43517-89L00	SPACER, STEERING ADJUSTER	1	
22	09116-06225	BOLT (6X15)	4	
23	09159-08L02	NUT	1	
24	09161-08019	WASHER (8.2X18X1.2)	1	

FIG.336G




FIG.336G (2-E-10) SWIVEL BRACKET (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25-1	55321-87J01	ANODE, PROTECTION	1	W/TRANSOM(L) W/TRANSOM(X)
25-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT W/TRANSOM(L) W/TRANSOM(X)
26	09103-06319	BOLT (6X14)	1	W/TRANSOM(L) W/TRANSOM(X)

FIG.336H





FIG.336H (2-E-11) SWIVEL BRACKET (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43411-89L00	LEVER, STEERING ADJUSTER	1	
28	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
29	43420-89L00	PLATE, STRG ADJ FRICTION	1	

FIG.336H



DF20A_P01_016_336H
SWIVEL BRACKET

FIG.336H (2-E-12) SWIVEL BRACKET (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	43425-89L00	PLATE, STRG ADJ UPPER	1	
31	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
32	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
33	43516-89J00	WASHER, STEERING ADJUSTER	2	
34	43517-89L00	SPACER, STEERING ADJUSTER	1	
35	09116-06225	BOLT (6X15)	4	
36	09159-08L02	NUT	1	
37	09161-08019	WASHER (8.2X18X1.2)	1	

DF20A_P01_016

FIG.336J





FIG.336J (2-E-13) SWIVEL BRACKET (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43411-89L00	LEVER, STEERING ADJUSTER	1	
28	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
29	43420-89L00	PLATE, STRG ADJ FRICTION	1	

FIG.336K




DF20A_P01_016_336K
SWIVEL BRACKET

FIG.336K (2-E-15) SWIVEL BRACKET (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
28	09160-08082	WASHER (8.5X16X1.2)	2	
29	09108-08286	STUD BOLT	2	

DF20A_P01_016

FIG.336K



DF20A_P01_016_336K
SWIVEL BRACKET

FIG.336K (2-F-2) SWIVEL BRACKET (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	09159-08059	NUT	2	
31	43759-89L00	HOLDER, DRAIN HOSE	1	
32	09116-06225	BOLT (6X15)	1	

DF20A_P01_016

FIG.336L




FIG.336L (2-F-3) SWIVEL BRACKET (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE	3	W/TRANSOM(S)
1-2	22511-99011	NIPPLE	4	W/TRANSOM(L) W/TRANSOM(X)
2-1	43111-89LB0-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89LA0-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-94JA0	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	43411-939L0	PLATE, STEERING ADJUSTER	1	
10	43412-93900	COVER, STEERING ADJUSTER	1	
11	29440-93J00	SPRING, STEERING ADJUSTER	1	
12	09160-08082	WASHER (8.5X16X1.2)	1	
13	09100-08232	BOLT (8X30)	1	
14	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
15	09160-08082	WASHER (8.5X16X1.2)	2	
16	09108-08286	STUD BOLT	2	
17	09159-08059	NUT	2	
18	43759-89L00	HOLDER, DRAIN HOSE	1	
19	09116-06225	BOLT (6X15)	1	
20-1	55321-87J01	ANODE, PROTECTION	1	W/TRANSOM(L) W/TRANSOM(X)
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT W/TRANSOM(L) W/TRANSOM(X)
21	09103-06319	BOLT (6X14)	1	W/TRANSOM(L) W/TRANSOM(X)

FIG.336M




FIG.336M (2-F-4) SWIVEL BRACKET (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE	3	W/TRANSOM(S)
1-2	22511-99011	NIPPLE	4	W/TRANSOM(L) W/TRANSOM(X)
2-1	43111-89LB0-0EP	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89LA0-0EP	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-94JA0	BUSH, STEERING	2	
4-1	43750-99J60-0EP	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-0EP	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	43411-939L0	PLATE, STRG ADJUSTER	1	
10	43412-93900	COVER, STEERING ADJUSTER	1	
11	29440-93J00	SPRING, STEERING ADJUSTER	1	
12	09160-08082	WASHER (8.5X16X1.2)	1	
13	09100-08232	BOLT (8X30)	1	
14	43411-89LA0	LEVER, STEERING ADJUSTER	1	
15	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
16	43420-89L00	PLATE, STRG ADJ FRICTION	1	
17	43425-89L00	PLATE, STRG ADJ UPPER	1	
18	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
19	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
20	43516-89J00	WASHER, STEERING ADJUSTER	2	
21	43517-89L00	SPACER, STEERING ADJUSTER	1	
22	09116-06225	BOLT (6X15)	4	
23	09159-08L02	NUT	1	
24	09161-08019	WASHER (8.2X18X1.2)	1	

FIG.336M




FIG.336M (2-F-5) SWIVEL BRACKET (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25-1	55321-87J01	ANODE, PROTECTION	1	W/TRANSOM(L) W/TRANSOM(X)
25-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT W/TRANSOM(L) W/TRANSOM(X)
26	09103-06319	BOLT (6X14)	1	W/TRANSOM(L) W/TRANSOM(X)



FIG.338A





FIG.338A (2-F-6) TILT CYLINDER (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-89LA0	POWER TILT ASSY	1	
2	48864-89LA0	.MANUAL VALVE	1	
3	48681-87J11	.CIRCLIP	1	
4	48553-88L00	.SEAL WASHER	1	
5	48510-94600	.PUMP ASSY, GEAR	1	
6	48583-95E00	.JOINT, DRIVE	1	
7	31123-89J10	.O RING	1	
8	48572-94J00	.CAP	1	
9	48664-87D00	.O RING	1	
10	31193-94J00	.BAND	1	
11	31192-94J01	.SCREW	1	
12	31281-94J01	.BOLT	2	
13	48582-97E00	.FILTER	1	
14	38100-89LA0	.MOTOR ASSY, PTT	1	
15	48664-87D00	.O RING	2	
16	48121-94JA0	SHAFT, TILT CYL LOWER	1	
17	48321-97E01	SHAFT, TILT CYL UPPER	1	
18	48325-97E00	BUSH	4	
19-1	55321-87J01	ANODE	1	
19-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
20	09103-06319	BOLT (6X14)	1	
21	09116-08150	BOLT (8X27)	2	
22	09380-12002	SNAP RING	2	
23	09407-14407	CLAMP (L:145)	3	

FIG.338B




DF20A_P01_016_338B
TILT CYLINDER

FIG.338B (2-F-7) TILT CYLINDER (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-89LA0	POWER TILT ASSY	1	
2	48864-89LA0	.MANUAL VALVE	1	
3	48681-87J11	.CIRCLIP	1	
4	48553-88L00	.SEAL WASHER	1	
5	48510-94600	.PUMP ASSY, GEAR	1	
6	48583-95E00	.JOINT, DRIVE	1	
7	31123-89J10	.O RING	1	
8	48572-94J00	.CAP	1	
9	48664-87D00	.O RING	1	
10	31193-94J00	.BAND	1	
11	31192-94J01	.SCREW	1	
12	31281-94J01	.BOLT	2	
13	48582-97E00	.FILTER	1	
14	38100-89LA0	.MOTOR ASSY, PTT	1	
15	48664-87D00	.O RING	2	
16	48121-94JA0	SHAFT, TILT CYL LOWER	1	
17	48321-97E01	SHAFT, TILT CYL UPPER	1	
18	48325-97E00	BUSH	4	
19-1	55321-87J01	ANODE	1	
19-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
20	09103-06319	BOLT (6X14)	1	
21	09116-08150	BOLT (8X27)	2	
22	09380-12002	SNAP RING	2	
23	09407-14407	CLAMP (L:145)	3	

DF20A_P01_016

FIG.338C




DF20A_P01_016_338C
TILT CYLINDER

FIG.338C (2-F-8) TILT CYLINDER (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-89LA0	POWER TILT ASSY	1	
2	48864-89LA0	.MANUAL VALVE	1	
3	48681-87J11	.CIRCLIP	1	
4	48553-88L00	.SEAL WASHER	1	
5	48510-94600	.PUMP ASSY, GEAR	1	
6	48583-95E00	.JOINT, DRIVE	1	
7	31123-89J10	.O RING	1	
8	48572-94J00	.CAP	1	
9	48664-87D00	.O RING	1	
10	31193-94J00	.BAND	1	
11	31192-94J01	.SCREW	1	
12	31281-94J01	.BOLT	2	
13	48582-97E00	.FILTER	1	
14	38100-89LA0	.MOTOR ASSY, PTT	1	
15	48664-87D00	.O RING	2	
16	48121-94JA0	SHAFT, TILT CYL LOWER	1	
17	48321-97E01	SHAFT, TILT CYL UPPER	1	
18	48325-97E00	BUSH	4	
19-1	55321-87J01	ANODE	1	
19-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
20	09103-06319	BOLT (6X14)	1	
21	09116-08150	BOLT (8X27)	2	
22	09380-12002	SNAP RING	2	
23	09407-14407	CLAMP (L:145)	3	

DF20A_P01_016

FIG.338D



DF20A_P01_016_338D
TILT CYLINDER

FIG.338D (2-F-9) TILT CYLINDER (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-89LA0	POWER TILT ASSY	1	
2	48864-89LA0	.MANUAL VALVE	1	
3	48681-87J11	.CIRCLIP	1	
4	48553-88L00	.SEAL WASHER	1	
5	48510-94600	.PUMP ASSY, GEAR	1	
6	48583-95E00	.JOINT, DRIVE	1	
7	31123-89J10	.O RING	1	
8	48572-94J00	.CAP	1	
9	48664-87D00	.O RING	1	
10	31193-94J00	.BAND	1	
11	31192-94J01	.SCREW	1	
12	31281-94J01	.BOLT	2	
13	48582-97E00	.FILTER	1	
14	38100-89LA0	.MOTOR ASSY, PTT	1	
15	48664-87D00	.O RING	2	
16	48121-94JA0	SHAFT, TILT CYL LOWER	1	
17	48321-97E01	SHAFT, TILT CYL UPPER	1	
18	48325-97E00	BUSH	4	
19-1	55321-87J01	ANODE	1	
19-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
20	09103-06319	BOLT (6X14)	1	
21	09116-08150	BOLT (8X27)	2	
22	09380-12002	SNAP RING	2	
23	09407-14407	CLAMP (L:145)	3	

DF20A_P01_016

FIG.338E




FIG.338E (2-F-10) TILT CYLINDER (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-89LA0	POWER TILT ASSY	1	
2	48864-89LA0	.MANUAL VALVE	1	
3	48681-87J11	.CIRCLIP	1	
4	48553-88L00	.SEAL WASHER	1	
5	48510-94600	.PUMP ASSY, GEAR	1	
6	48583-95E00	.JOINT, DRIVE	1	
7	31123-89J10	.O RING	1	
8	48572-94J00	.CAP	1	
9	48664-87D00	.O RING	1	
10	31193-94J00	.BAND	1	
11	31192-94J01	.SCREW	1	
12	31281-94J01	.BOLT	2	
13	48582-97E00	.FILTER	1	
14	38100-89LA0	.MOTOR ASSY, PTT	1	
15	48664-87D00	.O RING	2	
16	48121-94JA0	SHAFT, TILT CYL LOWER	1	
17	48321-97E01	SHAFT, TILT CYL UPPER	1	
18	48325-97E00	BUSH	4	
19-1	55321-87J01	ANODE	1	
19-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
20	09103-06319	BOLT (6X14)	1	
21	09116-08150	BOLT (8X27)	2	
22	09380-12002	SNAP RING	2	
23	09407-14407	CLAMP (L:145)	3	

FIG.340A




FIG.340A (2-F-11) PTT MOTOR (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-89LA0	MOTOR ASSY, PTT	1	
2	31174-89LA0	.BRACKET	1	
3	31136-94J00	..BRAKER	1	
4	31133-94900	..BRUSH	1	
5	31123-94J01	..O RING	1	
6	33799-97E00	..SEAL, OIL	1	
7	31135-94900	..SPRING	2	
8	09136-05041	..SCREW (5X20)	2	
9	31311-94J00	..ARMATURE	1	

FIG.340B




FIG.340B (2-F-12) PTT MOTOR (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-89LA0	MOTOR ASSY, PTT	1	
2	31174-89LA0	.BRACKET	1	
3	31136-94J00	..BRAKER	1	
4	31133-94900	..BRUSH	1	
5	31123-94J01	..O RING	1	
6	33799-97E00	..SEAL, OIL	1	
7	31135-94900	..SPRING	2	
8	09136-05041	..SCREW (5X20)	2	
9	31311-94J00	..ARMATURE	1	

FIG.340C




FIG.340C (2-F-13) PTT MOTOR (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-89LA0	MOTOR ASSY, PTT	1	
2	31174-89LA0	.BRACKET	1	
3	31136-94J00	..BRAKER	1	
4	31133-94900	..BRUSH	1	
5	31123-94J01	..O RING	1	
6	33799-97E00	..SEAL, OIL	1	
7	31135-94900	..SPRING	2	
8	09136-05041	..SCREW (5X20)	2	
9	31311-94J00	..ARMATURE	1	

FIG.340D




FIG.340D (2-F-14) PTT MOTOR (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-89LA0	MOTOR ASSY, PTT	1	
2	31174-89LA0	.BRACKET	1	
3	31136-94J00	..BRAKER	1	
4	31133-94900	..BRUSH	1	
5	31123-94J01	..O RING	1	
6	33799-97E00	..SEAL, OIL	1	
7	31135-94900	..SPRING	2	
8	09136-05041	..SCREW (5X20)	2	
9	31311-94J00	..ARMATURE	1	

FIG.340E




FIG.340E (2-F-15) PTT MOTOR (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-89LA0	MOTOR ASSY, PTT	1	
2	31174-89LA0	.BRACKET	1	
3	31136-94J00	..BRAKER	1	
4	31133-94900	..BRUSH	1	
5	31123-94J01	..O RING	1	
6	33799-97E00	..SEAL, OIL	1	
7	31135-94900	..SPRING	2	
8	09136-05041	..SCREW (5X20)	2	
9	31311-94J00	..ARMATURE	1	

FIG.401A




FIG.401A (2-G-2) ENGINE HOLDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51110-89L02	HOLDER, ENGINE	1	
2	51211-89L00	GASKET, ENGINE HOLDER	1	
3	09116-08151	BOLT (8X30)	3	
4	09202-06039	PIN (6X10)	2	
5	09282-12L04	OIL SEAL (12X25X7)	1	
6	16515-89L10	HOSE, OIL	1	
7	54112-99J01	BOLT, UPR MOUNT (L:123)	2	
8	54113-99JM0	WASHER, UPPER MOUNT BOLT	2	
9	54127-89L00	MOUNT, UPRER SIDE	1	
10	54125-99J00	STOPPER, UPR REVERSE THRUST	2	
11	54130-89L00	MOUNT, UPPER	2	
12	54137-89L00	COVER, UPPER MOUNT	2	
13	09116-08137	BOLT (8X22)	4	
14	09140-10031	NUT	2	
15	01560-08307	BOLT	7	
16	09401-12413	CLIP	1	
17	16520-99J00	STRAINER, OIL	1	
18	09401-13424	CLIP	1	

FIG.405A




FIG.405A (2-G-3) DRIVE SHAFT HOUSING

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17913-93J00	PLUG, WATER	1	
2	17914-93J00	GASKET, WATER PLUG	1	
3-1	52110-89L00-0EP	HOUSING, DRIVE SHAFT (S) (BLACK)	1	W/TRANSOM(S)
3-2	52110-89L10-0EP	HOUSING, DRIVE SHAFT (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
4	43112-99E00	.PIPE, EXHAUST	1	
5	52113-89L00	GASKET, DRIVE SHAFT HOUSING	1	
6	09116-08151	BOLT (8X30)	6	
7	09202-06039	PIN (6X10)	2	
8	09168-12017	GASKET (12X17X1)	1	
9	09248-12009	PLUG (12X18.65)	1	
10	54151-99J00	MOUNT, LOWER THRUST	1	
11	54167-99J01	MOUNT, LOWER SIDE	2	
12	54211-99J01-0EP	COVER, LWR MOUNT STBD (BLACK)	1	
13	54221-99J01-0EP	COVER, LWR MOUNT PORT (BLACK)	1	
14	54213-93901	PIN, KNOCK	2	
15	09116-08154	BOLT (8X40)	2	
16	52131-89L00-0EP	CASE, EXTENSION (BLACK)	1	W/TRANSOM(X)
17	09116-08151	BOLT (8X30)	4	W/TRANSOM(X)
18	09320-13022	BUSH	1	W/TRANSOM(X)

FIG.407A




FIG.407A (2-G-4) GEAR CASE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55100-99J40-0EP	CASE, GEAR (BLACK)	1	
2	09263-17L03	.BEARING (17X24X27.5)	1	
3	09262-25003	.BEARING (25X52X15)	1	
4	09202-06039	PIN (6X10)	2	
5	09116-08151	BOLT (8X30)	4	
6	55321-87J01	ANODE, PROTECTION	1	
7	09103-06319	BOLT (6X14)	1	
8	59178-97J00	GASKET, DRAIN PLUG	2	
9	09248-08001	PLUG (8X7.5)	2	
10	56120-99J41-0EP	HOUSING, PROPELLER SHAFT (BLACK)	1	
11	08110-60050	.BEARING	1	
12	09280-57002	.O RING (D:3.5,ID:65.2)	1	
13	09289-17L02	.OIL SEAL (17X30X6)	2	
14	09116-06227	BOLT (6X20)	2	
15-1	58100-89L00-019	PROPELLER, 3X9-1/4X7 (M701) (BLACK)	1	
15-2	58100-89L20-019	PROPELLER, 3X9-1/4X9 (M930) (BLACK)	1	
15-3	58100-89L60-019	PROPELLER, 3X9-1/4X10 (M1001) (BLACK)	1	
15-4	58100-89L40-019	PROPELLER, 3X9-1/4X11 (M1101) (BLACK)	1	
15-5	58100-89L50-019	PROPELLER, 3X9-1/4X12 (M1201) (BLACK)	1	
15-6	58100-90L40-019	PROPELLER, 3X9-1/4X8 (M821) (BLACK)	1	
15-7	58100-90L50-019	PROPELLER, 3X9-1/4X9 (M911) (BLACK)	1	
15-8	58100-90L60-019	PROPELLER, 3X9-1/4X10 (M1011) (BLACK)	1	
16	58120-89L00	.BUSH, PROPELLER	1	

FIG.407A




FIG.407A (2-G-5) GEAR CASE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	57632-94J00	STOPPER, PROPELLER BUSH	1	
18	09141-12005	NUT	1	
19	09160-12066	WASHER (12.5X22X2.5)	1	
20	09204-02004	PIN	1	
21	55331-99J10	CORE, EXHAUST SEAL	1	
22	55332-99J10	RUBBER, EXHAUST SEAL	1	
23	55321-87J11	ANODE (MAGNESIUM)	1	OPT

FIG.410A




FIG.410A (2-G-6) SIDE COVER (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L00-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410B




FIG.410B (2-G-7) SIDE COVER (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L00-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L20	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410C




FIG.410C (2-G-8) SIDE COVER (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L10-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L10-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L30	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	09403-07308	CLAMP	2	
23	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410D




FIG.410D (2-G-9) SIDE COVER (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L00-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410E




FIG.410E (2-G-10) SIDE COVER (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L00-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L20	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410F




FIG.410F (2-G-11) SIDE COVER (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L10-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L10-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L30	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	09403-07308	CLAMP	2	
23	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410G




FIG.410G (2-G-12) SIDE COVER (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L10-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	09403-07308	CLAMP	2	
23	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410H




FIG.410H (2-G-13) SIDE COVER (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L00-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410J




FIG.410J (2-G-14) SIDE COVER (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L00-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410K




FIG.410K (2-G-15) SIDE COVER (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L00-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L20	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410L




FIG.410L (2-H-2) SIDE COVER (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L10-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L10-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L30	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	09403-07308	CLAMP	2	
23	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410M




FIG.410M (2-H-3) SIDE COVER (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L10-RB4	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-RB4	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-0EP	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-06167	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	09403-07308	CLAMP	2	
23	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.420A




FIG.420A (2-H-4) ENGINE COVER (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-99J10	MARK, EMBLEM REAR (9.9)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L30	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L01	TOOL ASSY	1	
13	99011-89L30-055	MANUAL, OWNER'S	1	
14	68110-89L00	COVER, WEATHER	1	OPT

FIG.420B




FIG.420B (2-H-5) ENGINE COVER (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-99J10	MARK, EMBLEM REAR (9.9)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L30	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L01	TOOL ASSY	1	
13	99011-89L30-055	MANUAL, OWNER'S	1	
14	68110-89L00	COVER, WEATHER	1	OPT

FIG.420C




FIG.420C (2-H-6) ENGINE COVER (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-99J10	MARK, EMBLEM REAR (9.9)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L30	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L01	TOOL ASSY	1	
13	99011-89L30-055	MANUAL, OWNER'S	1	
14	61447-94J00	MARK, EMBLEM POWER TILT	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.420D




FIG.420D (2-H-7) ENGINE COVER (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-94J30	MARK, EMBLEM REAR (15)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L30	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L01	TOOL ASSY	1	
13	99011-89L30-055	MANUAL, OWNER'S	1	
14	68110-89L00	COVER, WEATHER	1	OPT

FIG.420E




FIG.420E (2-H-8) ENGINE COVER (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-94J30	MARK, EMBLEM REAR (15)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L30	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L01	TOOL ASSY	1	
13	99011-89L30-055	MANUAL, OWNER'S	1	
14	68110-89L00	COVER, WEATHER	1	OPT

FIG.420F




FIG.420F (2-H-9) ENGINE COVER (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-94J30	MARK, EMBLEM REAR (15)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L30	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L01	TOOL ASSY	1	
13	99011-89L30-055	MANUAL, OWNER'S	1	
14	61447-94J00	MARK, EMBLEM POWER TILT	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.420G




FIG.420G (2-H-10) ENGINE COVER (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-94J30	MARK, EMBLEM REAR (15)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L30	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L01	TOOL ASSY	1	
13	99011-89L30-055	MANUAL, OWNER'S	1	
14	61447-94J00	MARK, EMBLEM POWER TILT	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.420H




FIG.420H (2-H-11) ENGINE COVER (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-89L00	MARK, EMBLEM REAR (20)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L30	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L01	TOOL ASSY	1	
13	99011-89L30-055	MANUAL, OWNER'S	1	
14	68110-89L00	COVER, WEATHER	1	OPT

FIG.420J




FIG.420J (2-H-12) ENGINE COVER (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-89L00	MARK, EMBLEM REAR (20)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L30	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L01	TOOL ASSY	1	
13	99011-89L30-055	MANUAL, OWNER'S	1	
14	68110-89L00	COVER, WEATHER	1	OPT

FIG.420K




FIG.420K (2-H-13) ENGINE COVER (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-89L00	MARK, EMBLEM REAR (20)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L30	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L01	TOOL ASSY	1	
13	99011-89L30-055	MANUAL, OWNER'S	1	
14	68110-89L00	COVER, WEATHER	1	OPT

FIG.420L




FIG.420L (2-H-14) ENGINE COVER (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-89L00	MARK, EMBLEM REAR (20)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L30	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L01	TOOL ASSY	1	
13	99011-89L30-055	MANUAL, OWNER'S	1	
14	61447-94J00	MARK, EMBLEM POWER TILT	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.420M




FIG.420M (2-H-15) ENGINE COVER (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L10-0EP	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61443-99J00	STRIPE, ENGINE COVER STBD	1	
6	61453-99J00	STRIPE, ENGINE COVER PORT	1	
7	68111-89L00	EMBLEM (S)	1	
8	61435-89L00	MARK, EMBLEM REAR (20)	1	
9	61446-89L00	DECAL, EFI	1	
10	61458-89L30	LABEL, ENGINE COVER	1	
11	61471-89L00	DECAL, LEAN BURN	1	
12	59800-89L01	TOOL ASSY	1	
13	99011-89L30-055	MANUAL, OWNER'S	1	
14	61447-94J00	MARK, EMBLEM POWER TILT	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.432A




FIG.432A (2-I-2) FUEL TANK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65000-89L10	TANK ASSY, FUEL (12L)	1	
2	65520-99100	.CAP ASSY, FUEL TANK	1	
3	65561-95D00	.GASKET, TANK CAP	1	
4	65831-95D00	.FILTER, OUTLET	1	
5	65890-99100	.OUTLET	1	
6	65892-95D00	.O RING	1	
7	65740-95D01	.PLUG, FUEL CONNECTOR	1	
8	65700-89L30	HOSE, FUEL	1	
9	65750-87JL0	.SOCKET, FUEL HOSE	1	
10	65750-955L0	.SOCKET, FUEL HOSE	1	
11	65770-89L00	.PUMP, SQUEEZE	1	
12	65781-98500	.CLIP	4	
13	65720-986L0	PLUG, FUEL CONNECTOR	1	
14	09103-06237	BOLT (6X12.5)	1	
15	09160-06085	WASHER (6.5X15X1)	1	

FIG.442A




FIG.442A (2-I-3) DRAG LINK (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.442B




FIG.442B (2-I-4) DRAG LINK (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.442C




FIG.442C (2-I-5) DRAG LINK (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.442D




FIG.442D (2-I-6) DRAG LINK (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.442E




FIG.442E (2-I-7) DRAG LINK (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.442F




FIG.442F (2-I-8) DRAG LINK (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.444A




FIG.444A (2-I-9) TILLER HANDLE (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-0EP	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-0EP	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L11	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06015	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-0EP	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L01	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444B




FIG.444B (2-I-10) TILLER HANDLE (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-0EP	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-0EP	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L11	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06015	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-0EP	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L01	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444C




FIG.444C (2-I-11) TILLER HANDLE (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-0EP	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-0EP	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L11	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06015	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-0EP	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L01	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444D




FIG.444D (2-I-12) TILLER HANDLE (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-0EP	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-0EP	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L11	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06015	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-0EP	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L01	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444E




FIG.444E (2-I-13) TILLER HANDLE (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-0EP	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-0EP	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L11	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06015	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-0EP	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L01	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444F





FIG.444F (2-I-14) TILLER HANDLE (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-0EP	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-0EP	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L11	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06015	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-0EP	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L01	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.450A




DF20A_P01_016_450A
REMOTE CONTROL

FIG.450A (2-I-15) REMOTE CONTROL (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY	1	
		SWITCH LOCK		
9	37826-92J00	..NUT	1	
10	37859-90J00	..SPACER	1	
11	37864-94J10	..CAP, PTT SW	1	
12	38500-93J00	..BUZZER ASSY, WARNING	1	
13	67212-95600	..WASHER	1	
14	67214-92E00	..SCREW (5X10)	1	
15	67220-95630	..PLATE ASSY	1	
16	67223-99E10	..KNOB, BRAKE ADJUST	1	
17	67229-95600	..ROLLER	1	
18	67232-95600	..BUSH	1	
19	67238-87D00	..GEAR, DRIVE	1	

DF20A_P01_016

FIG.450A




DF20A_P01_016_450A
REMOTE CONTROL

FIG.450A (2-J-2) REMOTE CONTROL (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	
52	36620-94J01	WIRE ASSY,REMOTE CONTROL	1	
53	09481-10501	.FUSE (10A)	1	

DF20A_P01_016

FIG.450B



DF20A_P01_016_450B
REMOTE CONTROL

FIG.450B (2-J-3) REMOTE CONTROL (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J50	REMOTE CONTROL ASSY	1	
2	36646-93J01	..WIRE ASSY, PTT SW ADAPTER	1	
3	36628-92E00	..GROMMET, WIRE HARNESS	1	
4	37110-93J11	..SWITCH ASSY, IGNITION	1	
5-1	37141-99E00	..KEY (931)	2	
5-2	37141-99E10	..KEY (932)	2	
5-3	37141-99E20	..KEY (933)	2	
5-4	37141-99E30	..KEY (934)	2	
5-5	37141-99E40	..KEY (935)	2	
5-6	37141-99E50	..KEY (936)	2	
5-7	37141-99E60	..KEY (937)	2	
5-8	37141-99E70	..KEY (938)	2	
5-9	37141-99E80	..KEY (939)	2	
5-10	37141-99E90	..KEY (940)	2	
5-11	37141-99EA0	..KEY (941)	2	
5-12	37141-99EB0	..KEY (942)	2	
6	37143-99E00	..CAP, KEY	2	
7	37149-93J00	..CAP CYLINDER BODY	1	
8	37721-93J91	..SWITCH, NEUTRAL	1	
9	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE	1	
11	37826-92J00	..NUT	1	
12	37850-90J05	..SWITCH ASSY, PTT	1	
13	38500-93J90	..BUZZER	1	
14	67212-95600	..WASHER	1	
15	67296-92E11	..SCREW, NEUTRAL SW	2	
16	67220-95630	..PLATE ASSY	1	
17	67223-99E10	..KNOB, BRAKE ADJ	1	
18	67229-95600	..ROLLER	1	
19	67232-95600	..BUSH	1	
20	67238-87D00	..GEAR, DRIVE	1	
21	67241-99E10	..LEVER, FREE THROTTLE	1	


DF20A_P01_016

This exploded perspective view illustrates the assembly of a vehicle interior component, possibly a center console or gear shifter area. The main housing (1) is shown with various mounting points and internal structures. Key components include:

- Electrical Components:** A multi-pin connector (2) is connected to a cable (3) that leads to a control unit (13). A coiled spring cable (10) is also shown. Other electrical parts include a switch (4), a connector (7), and a cable (9).
- Mechanical Components:** A large gear or pulley (16) is mounted on a shaft (20). A bracket (21) is shown with a pin (22). A lever (23) is connected to a shaft (24). A bracket (25) is shown with a pin (26). A bracket (27) is shown with a pin (28).
- Fasteners and Hardware:** Numerous screws (e.g., 32, 34, 35, 36, 37, 38, 39), bolts (e.g., 17, 19, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39), and washers (e.g., 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39) are shown.
- Other Components:** A bracket (33) is shown with a pin (34). A bracket (35) is shown with a pin (36). A bracket (37) is shown with a pin (38). A bracket (39) is shown with a pin (40). A bracket (41) is shown with a pin (42). A bracket (43) is shown with a pin (44). A bracket (45) is shown with a pin (46). A bracket (47) is shown with a pin (48). A bracket (49) is shown with a pin (50). A bracket (51) is shown with a pin (52). A bracket (53) is shown with a pin (54). A bracket (55) is shown with a pin (56).

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
22	67243-95600	.BUSH	1	
23	67244-95600	.WASHER, WAVE	1	
24	67245-95600	.DRUM, FREE THROTTLE	1	
25	67251-99E20	.LEVER, HANDLE	1	
26	67252-95600	.BUSH	2	
27	67253-95600	.WASHER	1	
28	67255-99E10	.ARM, LOCK	1	
29	67256-95600	.HOLDER, NEUT LOCK	1	
30	67257-99E10	.CAP, LEVER	1	
31	67258-99E00	.BRACKET, LOCK ARM	1	
32	67259-87D00	.SPRING, NEUTRAL ARM	1	
33	67261-99E10	.GRIP	1	
34	67296-94310	.SCREW	1	
35	67264-95600	.WASHER	1	
36	67267-93J00	.COVER, WIRE	1	
37	67273-95600	.SPACER	1	
38	67275-95600	.END, CABLE	2	
39	67292-94300	.E RING	3	
40	67294-95600	.SPACER	3	
41	67296-90J00	.SCREW	5	
42	67296-94300	.SCREW	2	
43	67296-95600	.SCREW	3	
44	67296-95610	.SCREW	2	
45	67297-95600	.WASHER	2	
46	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
47	09100-08232	.BOLT (8X30)	1	
48	09126-05003	.SCREW (5X12)	2	
49	09140-06020	.NUT	3	
50	09160-06104	.WASHER (6.5X24X2)	3	
51	37859-90J00	.SPACER	1	
52	67282-94L00	.DECAL, REMOCON SIDE	1	
53	67284-94L00	.MARK, HANDLE LEVER	1	
54	36620-93J02	WIRE ASSY, REMOTE CONTROL	1	
55	09481-10501	.FUSE (10A)	1	

FIG.450C




DF20A_P01_016_450C
REMOTE CONTROL

FIG.450C (2-J-5) REMOTE CONTROL (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SWITCH LOCK	1	
9	37826-92J00	..NUT	1	
10	37859-90J00	..SPACER	1	
11	37864-94J10	..CAP, PTT SW	1	
12	38500-93J00	..BUZZER ASSY, WARNING	1	
13	67212-95600	..WASHER	1	
14	67214-92E00	..SCREW (5X10)	1	
15	67220-95630	..PLATE ASSY	1	
16	67223-99E10	..KNOB, BRAKE ADJUST	1	
17	67229-95600	..ROLLER	1	
18	67232-95600	..BUSH	1	
19	67238-87D00	..GEAR, DRIVE	1	

DF20A_P01_016

FIG.450C




DF20A_P01_016_450C
REMOTE CONTROL

FIG.450C (2-J-6) REMOTE CONTROL (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	
52	36620-94J01	.WIRE ASSY,REMOTE CONTROL	1	
53	09481-10501	.FUSE (10A)	1	

DF20A_P01_016

FIG.450D




DF20A_P01_016_450D
REMOTE CONTROL

FIG.450D (2-J-7) REMOTE CONTROL (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J50	REMOTE CONTROL ASSY	1	
2	36646-93J01	..WIRE ASSY, PTT SW ADAPTER	1	
3	36628-92E00	..GROMMET, WIRE HARNESS	1	
4	37110-93J11	..SWITCH ASSY, IGNITION	1	
5-1	37141-99E00	..KEY (931)	2	
5-2	37141-99E10	..KEY (932)	2	
5-3	37141-99E20	..KEY (933)	2	
5-4	37141-99E30	..KEY (934)	2	
5-5	37141-99E40	..KEY (935)	2	
5-6	37141-99E50	..KEY (936)	2	
5-7	37141-99E60	..KEY (937)	2	
5-8	37141-99E70	..KEY (938)	2	
5-9	37141-99E80	..KEY (939)	2	
5-10	37141-99E90	..KEY (940)	2	
5-11	37141-99EA0	..KEY (941)	2	
5-12	37141-99EB0	..KEY (942)	2	
6	37143-99E00	..CAP, KEY	2	
7	37149-93J00	..CAP CYLINDER BODY	1	
8	37721-93J91	..SWITCH, NEUTRAL	1	
9	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE	1	
11	37826-92J00	..NUT	1	
12	37850-90J05	..SWITCH ASSY, PTT	1	
13	38500-93J90	..BUZZER	1	
14	67212-95600	..WASHER	1	
15	67296-92E11	..SCREW, NEUTRAL SW	2	
16	67220-95630	..PLATE ASSY	1	
17	67223-99E10	..KNOB, BRAKE ADJ	1	
18	67229-95600	..ROLLER	1	
19	67232-95600	..BUSH	1	
20	67238-87D00	..GEAR, DRIVE	1	
21	67241-99E10	..LEVER, FREE THROTTLE	1	

DF20A_P01_016

FIG.450D




DF20A_P01_016_450D
REMOTE CONTROL

FIG.450D (2-J-8) REMOTE CONTROL (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	67243-95600	.BUSH	1	
23	67244-95600	.WASHER, WAVE	1	
24	67245-95600	.DRUM, FREE THROTTLE	1	
25	67251-99E20	.LEVER, HANDLE	1	
26	67252-95600	.BUSH	2	
27	67253-95600	.WASHER	1	
28	67255-99E10	.ARM, LOCK	1	
29	67256-95600	.HOLDER, NEUT LOCK	1	
30	67257-99E10	.CAP, LEVER	1	
31	67258-99E00	.BRACKET, LOCK ARM	1	
32	67259-87D00	.SPRING, NEUTRAL ARM	1	
33	67261-99E10	.GRIP	1	
34	67296-94310	.SCREW	1	
35	67264-95600	.WASHER	1	
36	67267-93J00	.COVER, WIRE	1	
37	67273-95600	.SPACER	1	
38	67275-95600	.END, CABLE	2	
39	67292-94300	.E RING	3	
40	67294-95600	.SPACER	3	
41	67296-90J00	.SCREW	5	
42	67296-94300	.SCREW	2	
43	67296-95600	.SCREW	3	
44	67296-95610	.SCREW	2	
45	67297-95600	.WASHER	2	
46	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
47	09100-08232	.BOLT (8X30)	1	
48	09126-05003	.SCREW (5X12)	2	
49	09140-06020	.NUT	3	
50	09160-06104	.WASHER (6.5X24X2)	3	
51	37859-90J00	.SPACER	1	
52	67282-94L00	.DECAL, REMOCON SIDE	1	
53	67284-94L00	.MARK, HANDLE LEVER	1	
54	36620-93J02	WIRE ASSY, REMOTE CONTROL	1	
55	09481-10501	.FUSE (10A)	1	

DF20A_P01_016

FIG.450E




DF20A_P01_016_450E
REMOTE CONTROL

FIG.450E (2-J-9) REMOTE CONTROL (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY	1	
9	37826-92J00	SWITCH LOCK	1	
10	37859-90J00	..NUT	1	
11	37864-94J10	..SPACER	1	
12	38500-93J00	..CAP, PTT SW	1	
13	67212-95600	..BUZZER ASSY, WARNING	1	
14	67214-92E00	..WASHER	1	
15	67220-95630	..SCREW (5X10)	1	
16	67223-99E10	..PLATE ASSY	1	
17	67229-95600	..KNOB, BRAKE ADJUST	1	
18	67232-95600	..ROLLER	1	
19	67238-87D00	..BUSH	1	
		..GEAR, DRIVE	1	

DF20A_P01_016

FIG.450E




DF20A_P01_016_450E
REMOTE CONTROL

FIG.450E (2-J-10) REMOTE CONTROL (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	
52	36620-94J01	.WIRE ASSY,REMOTE CONTROL	1	
53	09481-10501	.FUSE (10A)	1	

DF20A_P01_016

FIG.450F




DF20A_P01_016_450F
REMOTE CONTROL

FIG.450F (2-J-11) REMOTE CONTROL (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J50	REMOTE CONTROL ASSY	1	
2	36646-93J01	..WIRE ASSY, PTT SW ADAPTER	1	
3	36628-92E00	..GROMMET, WIRE HARNESS	1	
4	37110-93J11	..SWITCH ASSY, IGNITION	1	
5-1	37141-99E00	..KEY (931)	2	
5-2	37141-99E10	..KEY (932)	2	
5-3	37141-99E20	..KEY (933)	2	
5-4	37141-99E30	..KEY (934)	2	
5-5	37141-99E40	..KEY (935)	2	
5-6	37141-99E50	..KEY (936)	2	
5-7	37141-99E60	..KEY (937)	2	
5-8	37141-99E70	..KEY (938)	2	
5-9	37141-99E80	..KEY (939)	2	
5-10	37141-99E90	..KEY (940)	2	
5-11	37141-99EA0	..KEY (941)	2	
5-12	37141-99EB0	..KEY (942)	2	
6	37143-99E00	..CAP, KEY	2	
7	37149-93J00	..CAP CYLINDER BODY	1	
8	37721-93J91	..SWITCH, NEUTRAL	1	
9	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE	1	
11	37826-92J00	..NUT	1	
12	37850-90J05	..SWITCH ASSY, PTT	1	
13	38500-93J90	..BUZZER	1	
14	67212-95600	..WASHER	1	
15	67296-92E11	..SCREW, NEUTRAL SW	2	
16	67220-95630	..PLATE ASSY	1	
17	67223-99E10	..KNOB, BRAKE ADJ	1	
18	67229-95600	..ROLLER	1	
19	67232-95600	..BUSH	1	
20	67238-87D00	..GEAR, DRIVE	1	
21	67241-99E10	..LEVER, FREE THROTTLE	1	

DF20A_P01_016

FIG.450F



DF20A_P01_016_450F
REMOTE CONTROL

FIG.450F (2-J-12) REMOTE CONTROL (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	67243-95600	.BUSH	1	
23	67244-95600	.WASHER, WAVE	1	
24	67245-95600	.DRUM, FREE THROTTLE	1	
25	67251-99E20	.LEVER, HANDLE	1	
26	67252-95600	.BUSH	2	
27	67253-95600	.WASHER	1	
28	67255-99E10	.ARM, LOCK	1	
29	67256-95600	.HOLDER, NEUT LOCK	1	
30	67257-99E10	.CAP, LEVER	1	
31	67258-99E00	.BRACKET, LOCK ARM	1	
32	67259-87D00	.SPRING, NEUTRAL ARM	1	
33	67261-99E10	.GRIP	1	
34	67296-94310	.SCREW	1	
35	67264-95600	.WASHER	1	
36	67267-93J00	.COVER, WIRE	1	
37	67273-95600	.SPACER	1	
38	67275-95600	.END, CABLE	2	
39	67292-94300	.E RING	3	
40	67294-95600	.SPACER	3	
41	67296-90J00	.SCREW	5	
42	67296-94300	.SCREW	2	
43	67296-95600	.SCREW	3	
44	67296-95610	.SCREW	2	
45	67297-95600	.WASHER	2	
46	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
47	09100-08232	.BOLT (8X30)	1	
48	09126-05003	.SCREW (5X12)	2	
49	09140-06020	.NUT	3	
50	09160-06104	.WASHER (6.5X24X2)	3	
51	37859-90J00	.SPACER	1	
52	67282-94L00	.DECAL, REMOCON SIDE	1	
53	67284-94L00	.MARK, HANDLE LEVER	1	
54	36620-93J02	WIRE ASSY, REMOTE CONTROL	1	
55	09481-10501	.FUSE (10A)	1	

DF20A_P01_016

FIG.501A




FIG.501A (2-J-13) OPT:METER (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36682-92E00	WIRE, TRIM METER	1	
2-1	36663-98J00	HARNESS, ACTIVE HUB POWER	1	2.5M
2-2	36663-98J10	HARNESS, ACTIVE HUB POWER	1	6M
3	09481-05501	.FUSE (5A)	1	
4-1	34500-93J01	METER ASSY, HOUR	1	BLACK
4-2	34500-93J12	METER ASSY, HOUR	1	WHITE
5	09471-12103	.BULB (12V,3W,T6.5)	1	
6	36615-96300	.TERMINAL	4	
7-1	34600-93J01	METER ASSY, VOLTAGE	1	BLACK
7-2	34600-93J12	METER ASSY, VOLTAGE	1	WHITE
8	09471-12103	.BULB (12V,3W,T6.5)	1	
9	36615-96300	.TERMINAL	4	
10-1	34100-93J21	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
10-2	34100-93J32	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
10-3	34100-93J41	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
10-4	34100-93J52	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
11	09471-12028	.BULB (12V,3.4W)	1	
12	34191-92E00	.TUBE	1	
13	09407-14407	.CLAMP (L:145)	2	
14	36615-96300	.TERMINAL, RESIN	2	
15	34190-95500	SENDER ASSY, SPEEDOMETER	1	
16	03112-0630B	.SCREW	2	
17	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
18-1	34200-93J21	TACHOMETER ASSY	1	BLACK
18-2	34200-93J33	TACHOMETER ASSY	1	WHITE
19-1	09471-12028	.BULB (12V,3.4W)	1	
20-1	34300-93J01	GAUGE ASSY, FUEL	1	BLACK
20-2	34300-93J12	GAUGE ASSY, FUEL	1	WHITE
21	34310-92E00	.LEAD, FUEL GAUGE	1	
22	34360-92E00	ADAPTER, FUEL GAUGE	1	
23	09471-12103	.BULB (12V,3W,T6.5)	1	
24	36615-96300	.TERMINAL	5	

FIG.501B





FIG.501B (2-J-14) OPT:METER (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36682-92E00	WIRE, TRIM METER	1	
2-1	36663-98J00	HARNESS, ACTIVE HUB POWER	1	2.5M
2-2	36663-98J10	HARNESS, ACTIVE HUB POWER	1	6M
3	09481-05501	.FUSE (5A)	1	
4-1	34500-93J01	METER ASSY, HOUR	1	BLACK
4-2	34500-93J12	METER ASSY, HOUR	1	WHITE
5	09471-12103	.BULB (12V,3W,T6.5)	1	
6	36615-96300	.TERMINAL	4	
7-1	34600-93J01	METER ASSY, VOLTAGE	1	BLACK
7-2	34600-93J12	METER ASSY, VOLTAGE	1	WHITE
8	09471-12103	.BULB (12V,3W,T6.5)	1	
9	36615-96300	.TERMINAL	4	
10-1	34100-93J21	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
10-2	34100-93J32	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
10-3	34100-93J41	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
10-4	34100-93J52	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
11	09471-12028	.BULB (12V,3.4W)	1	
12	34191-92E00	.TUBE	1	
13	09407-14407	.CLAMP (L:145)	2	
14	36615-96300	.TERMINAL, RESIN	2	
15	34190-95500	SENDER ASSY, SPEEDOMETER	1	
16	03112-0630B	.SCREW	2	
17	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
18-1	34200-93J21	TACHOMETER ASSY	1	BLACK
18-2	34200-93J33	TACHOMETER ASSY	1	WHITE
19-1	09471-12028	.BULB (12V,3.4W)	1	
20-1	34300-93J01	GAUGE ASSY, FUEL	1	BLACK
20-2	34300-93J12	GAUGE ASSY, FUEL	1	WHITE
21	34310-92E00	.LEAD, FUEL GAUGE	1	
22	34360-92E00	ADAPTER, FUEL GAUGE	1	
23	09471-12103	.BULB (12V,3W,T6.5)	1	
24	36615-96300	.TERMINAL	5	

FIG.501C



DF20A_P01_016_501C
OPT:METER

FIG.501C (2-J-15) OPT:METER (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36682-92E00	WIRE, TRIM METER	1	
2-1	36663-98J00	HARNESS, ACTIVE HUB POWER	1	2.5M
2-2	36663-98J10	HARNESS, ACTIVE HUB POWER	1	6M
3	09481-05501	.FUSE (5A)	1	
4-1	34500-93J01	METER ASSY, HOUR	1	BLACK
4-2	34500-93J12	METER ASSY, HOUR	1	WHITE
5	09471-12103	.BULB (12V,3W,T6.5)	1	
6	36615-96300	.TERMINAL	4	
7-1	34600-93J01	METER ASSY, VOLTAGE	1	BLACK
7-2	34600-93J12	METER ASSY, VOLTAGE	1	WHITE
8	09471-12103	.BULB (12V,3W,T6.5)	1	
9	36615-96300	.TERMINAL	4	
10-1	34100-93J21	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
10-2	34100-93J32	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
10-3	34100-93J41	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
10-4	34100-93J52	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
11	09471-12028	.BULB (12V,3.4W)	1	
12	34191-92E00	.TUBE	1	
13	09407-14407	.CLAMP (L:145)	2	
14	36615-96300	.TERMINAL, RESIN	2	
15	34190-95500	SENDER ASSY, SPEEDOMETER	1	
16	03112-0630B	.SCREW	2	
17	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
18-1	34200-93J21	TACHOMETER ASSY	1	BLACK
18-2	34200-93J33	TACHOMETER ASSY	1	WHITE
19-1	09471-12028	.BULB (12V,3.4W)	1	
20-1	34300-93J01	GAUGE ASSY, FUEL	1	BLACK
20-2	34300-93J12	GAUGE ASSY, FUEL	1	WHITE
21	34310-92E00	.LEAD, FUEL GAUGE	1	
22	34360-92E00	ADAPTER, FUEL GAUGE	1	
23	09471-12103	.BULB (12V,3W,T6.5)	1	
24	36615-96300	.TERMINAL	5	

DF20A_P01_016

FIG.501D





FIG.501D (2-K-2) OPT:METER (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36682-92E00	WIRE, TRIM METER	1	
2-1	36663-98J00	HARNESS, ACTIVE HUB POWER	1	2.5M
2-2	36663-98J10	HARNESS, ACTIVE HUB POWER	1	6M
3	09481-05501	.FUSE (5A)	1	
4-1	34500-93J01	METER ASSY, HOUR	1	BLACK
4-2	34500-93J12	METER ASSY, HOUR	1	WHITE
5	09471-12103	.BULB (12V,3W,T6.5)	1	
6	36615-96300	.TERMINAL	4	
7-1	34600-93J01	METER ASSY, VOLTAGE	1	BLACK
7-2	34600-93J12	METER ASSY, VOLTAGE	1	WHITE
8	09471-12103	.BULB (12V,3W,T6.5)	1	
9	36615-96300	.TERMINAL	4	
10-1	34100-93J21	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
10-2	34100-93J32	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
10-3	34100-93J41	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
10-4	34100-93J52	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
11	09471-12028	.BULB (12V,3.4W)	1	
12	34191-92E00	.TUBE	1	
13	09407-14407	.CLAMP (L:145)	2	
14	36615-96300	.TERMINAL, RESIN	2	
15	34190-95500	SENDER ASSY, SPEEDOMETER	1	
16	03112-0630B	.SCREW	2	
17	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
18-1	34200-93J21	TACHOMETER ASSY	1	BLACK
18-2	34200-93J33	TACHOMETER ASSY	1	WHITE
19-1	09471-12028	.BULB (12V,3.4W)	1	
20-1	34300-93J01	GAUGE ASSY, FUEL	1	BLACK
20-2	34300-93J12	GAUGE ASSY, FUEL	1	WHITE
21	34310-92E00	.LEAD, FUEL GAUGE	1	
22	34360-92E00	ADAPTER, FUEL GAUGE	1	
23	09471-12103	.BULB (12V,3W,T6.5)	1	
24	36615-96300	.TERMINAL	5	

FIG.501E




DF20A_P01_016_501E
OPT:METER

FIG.501E (2-K-3) OPT:METER (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36682-92E00	WIRE, TRIM METER	1	
2-1	36663-98J00	HARNESS, ACTIVE HUB POWER	1	2.5M
2-2	36663-98J10	HARNESS, ACTIVE HUB POWER	1	6M
3	09481-05501	.FUSE (5A)	1	
4-1	34500-93J01	METER ASSY, HOUR	1	BLACK
4-2	34500-93J12	METER ASSY, HOUR	1	WHITE
5	09471-12103	.BULB (12V,3W,T6.5)	1	
6	36615-96300	.TERMINAL	4	
7-1	34600-93J01	METER ASSY, VOLTAGE	1	BLACK
7-2	34600-93J12	METER ASSY, VOLTAGE	1	WHITE
8	09471-12103	.BULB (12V,3W,T6.5)	1	
9	36615-96300	.TERMINAL	4	
10-1	34100-93J21	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
10-2	34100-93J32	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
10-3	34100-93J41	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
10-4	34100-93J52	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
11	09471-12028	.BULB (12V,3.4W)	1	
12	34191-92E00	.TUBE	1	
13	09407-14407	.CLAMP (L:145)	2	
14	36615-96300	.TERMINAL, RESIN	2	
15	34190-95500	SENDER ASSY, SPEEDOMETER	1	
16	03112-0630B	.SCREW	2	
17	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
18-1	34200-93J21	TACHOMETER ASSY	1	BLACK
18-2	34200-93J33	TACHOMETER ASSY	1	WHITE
19-1	09471-12028	.BULB (12V,3.4W)	1	
20-1	34300-93J01	GAUGE ASSY, FUEL	1	BLACK
20-2	34300-93J12	GAUGE ASSY, FUEL	1	WHITE
21	34310-92E00	.LEAD, FUEL GAUGE	1	
22	34360-92E00	ADAPTER, FUEL GAUGE	1	
23	09471-12103	.BULB (12V,3W,T6.5)	1	
24	36615-96300	.TERMINAL	5	

DF20A_P01_016

FIG.501F



DF20A_P01_016_501F
OPT:METER

FIG.501F (2-K-4) OPT:METER (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36682-92E00	WIRE, TRIM METER	1	
2-1	36663-98J00	HARNESS, ACTIVE HUB POWER	1	2.5M
2-2	36663-98J10	HARNESS, ACTIVE HUB POWER	1	6M
3	09481-05501	.FUSE (5A)	1	
4-1	34500-93J01	METER ASSY, HOUR	1	BLACK
4-2	34500-93J12	METER ASSY, HOUR	1	WHITE
5	09471-12103	.BULB (12V,3W,T6.5)	1	
6	36615-96300	.TERMINAL	4	
7-1	34600-93J01	METER ASSY, VOLTAGE	1	BLACK
7-2	34600-93J12	METER ASSY, VOLTAGE	1	WHITE
8	09471-12103	.BULB (12V,3W,T6.5)	1	
9	36615-96300	.TERMINAL	4	
10-1	34100-93J21	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
10-2	34100-93J32	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
10-3	34100-93J41	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
10-4	34100-93J52	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
11	09471-12028	.BULB (12V,3.4W)	1	
12	34191-92E00	.TUBE	1	
13	09407-14407	.CLAMP (L:145)	2	
14	36615-96300	.TERMINAL, RESIN	2	
15	34190-95500	SENDER ASSY, SPEEDOMETER	1	
16	03112-0630B	.SCREW	2	
17	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
18-1	34200-93J21	TACHOMETER ASSY	1	BLACK
18-2	34200-93J33	TACHOMETER ASSY	1	WHITE
19-1	09471-12028	.BULB (12V,3.4W)	1	
20-1	34300-93J01	GAUGE ASSY, FUEL	1	BLACK
20-2	34300-93J12	GAUGE ASSY, FUEL	1	WHITE
21	34310-92E00	.LEAD, FUEL GAUGE	1	
22	34360-92E00	ADAPTER, FUEL GAUGE	1	
23	09471-12103	.BULB (12V,3W,T6.5)	1	
24	36615-96300	.TERMINAL	5	

DF20A_P01_016

FIG.508A




FIG.508A (2-K-5) OPT:REMOTE CONTROL (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY	1	
9	37826-92J00	SWITCH LOCK	1	
10	37859-90J00	..NUT	1	
11	37864-94J10	..SPACER	1	
12	38500-93J00	..CAP, PTT SW	1	
13	67212-95600	..BUZZER ASSY, WARNING	1	
14	67214-92E00	..WASHER	1	
15	67220-95630	..SCREW (5X10)	1	
16	67223-99E10	..PLATE ASSY	1	
17	67229-95600	..KNOB, BRAKE ADJUST	1	
18	67232-95600	..ROLLER	1	
19	67238-87D00	..BUSH	1	
		..GEAR, DRIVE	1	

FIG.508A




FIG.508A (2-K-6) OPT:REMOTE CONTROL (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	

FIG.508B




FIG.508B (2-K-7) OPT:REMOTE CONTROL (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY	1	
9	37826-92J00	SWITCH LOCK	1	
10	37859-90J00	..NUT	1	
11	37864-94J10	..SPACER	1	
12	38500-93J00	..CAP, PTT SW	1	
13	67212-95600	..BUZZER ASSY, WARNING	1	
14	67214-92E00	..WASHER	1	
15	67220-95630	..SCREW (5X10)	1	
16	67223-99E10	..PLATE ASSY	1	
17	67229-95600	..KNOB, BRAKE ADJUST	1	
18	67232-95600	..ROLLER	1	
19	67238-87D00	..BUSH	1	
		..GEAR, DRIVE	1	

FIG.508B




FIG.508B (2-K-8) OPT:REMOTE CONTROL (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	

FIG.508C




FIG.508C (2-K-9) OPT:REMOTE CONTROL (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY	1	
9	37826-92J00	SWITCH LOCK	1	
10	37859-90J00	..NUT	1	
11	37864-94J10	..SPACER	1	
12	38500-93J00	..CAP, PTT SW	1	
13	67212-95600	..BUZZER ASSY, WARNING	1	
14	67214-92E00	..WASHER	1	
15	67220-95630	..SCREW (5X10)	1	
16	67223-99E10	..PLATE ASSY	1	
17	67229-95600	..KNOB, BRAKE ADJUST	1	
18	67232-95600	..ROLLER	1	
19	67238-87D00	..BUSH	1	
		..GEAR, DRIVE	1	

FIG.508C




FIG.508C (2-K-10) OPT:REMOTE CONTROL (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	

FIG.508D




FIG.508D (2-K-11) OPT:REMOTE CONTROL (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY	1	
9	37826-92J00	SWITCH LOCK	1	
10	37859-90J00	..NUT	1	
11	37864-94J10	..SPACER	1	
12	38500-93J00	..CAP, PTT SW	1	
13	67212-95600	..BUZZER ASSY, WARNING	1	
14	67214-92E00	..WASHER	1	
15	67220-95630	..SCREW (5X10)	1	
16	67223-99E10	..PLATE ASSY	1	
17	67229-95600	..KNOB, BRAKE ADJUST	1	
18	67232-95600	..ROLLER	1	
19	67238-87D00	..BUSH	1	
		..GEAR, DRIVE	1	

FIG.508D




FIG.508D (2-K-12) OPT:REMOTE CONTROL (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J00	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	

FIG.513A




FIG.513A (2-K-13) OPT:REMOTE CONTROL PARTS (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67130-89L03	PARTS SET, R/CON	1	
2	13513-89L10	.ROD,THROTTLE	1	
3	19120-99J11	.LEVER, THROTTLE CONTROL	1	
4	19122-99J00	.LEVER, INTERLINK THROTTLE NO.2	1	
5	19131-89L00	.CONNECTOR	2	
6	19148-89L10	.LEVER, INTERLINK THROTTLE NO.1	1	
7	19150-89L00	.BRACKET, THROTTLE LEVER	1	
8	19185-99J00	.SPRING, THROTTLE LEVER	1	
9	21110-89L10	.LEVER, CLUTCH	1	
10	23115-89L10	.LINK, CLUTCH LEVER	1	
11	36610-89L23	.HARNESS ASSY, WIRING	1	
12	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
13	09481-10501	..FUSE (10A)	1	
14	09481-30501	..FUSE (30A)	1	
15	37163-89L00	.PLUG, STARTING SWITCH HOLE	1	
16	41130-89L00	.SHAFT, CLAMP BRACKET	1	
17	43755-99J00	.ATTACHMENT, STEERING BRACKET	1	
18	43759-89L00	.HOLDER, DRAIN HOSE	1	
19	09204-01002	.PIN	2	
20	09160-08082	.WASHER (8.5X16X1.2)	2	
21	61124-89L20	.GROMMET, R/CON CABLE	1	
22	67340-89L00	.HOLDER,, R/CON CABLE	1	
23	67467-89J01	.CONNECTOR	2	
24	09108-08286	.STUD BOLT	2	
25	09116-06225	.BOLT (6X15)	1	
26	09159-08059	.NUT	2	
27	09159-22006	.NUT	1	

FIG.513A





FIG.513A (2-K-14) OPT:REMOTE CONTROL PARTS (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09160-05029	.WASHER (5.5X12X0.8)	2	
29	09160-06046	.WASHER (6.5X20X1.5)	2	
30	09160-06055	.WASHER (7X12X1)	2	
31	09385-06012	.CLIP	2	
32	09407-14407	.CLAMP (L:145)	12	
33	01547-06167	.BOLT	2	
34	01550-06127	.BOLT	2	
35	01550-06167	.BOLT	2	

FIG.513B



DF20A_P01_016_513B
OPT:REMOTE CONTROL PARTS

FIG.513B (2-K-15) OPT:REMOTE CONTROL PARTS (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67130-89L03	PARTS SET, R/CON	1	
2	13513-89L10	.ROD,THROTTLE	1	
3	19120-99J11	.LEVER, THROTTLE CONTROL	1	
4	19122-99J00	.LEVER, INTERLINK THROTTLE NO.2	1	
5	19131-89L00	.CONNECTOR	2	
6	19148-89L10	.LEVER, INTERLINK THROTTLE NO.1	1	
7	19150-89L00	.BRACKET, THROTTLE LEVER	1	
8	19185-99J00	.SPRING, THROTTLE LEVER	1	
9	21110-89L10	.LEVER, CLUTCH	1	
10	23115-89L10	.LINK, CLUTCH LEVER	1	
11	36610-89L23	.HARNESS ASSY, WIRING	1	
12	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
13	09481-10501	..FUSE (10A)	1	
14	09481-30501	..FUSE (30A)	1	
15	37163-89L00	.PLUG, STARTING SWITCH HOLE	1	
16	41130-89L00	.SHAFT, CLAMP BRACKET	1	
17	43755-99J00	.ATTACHMENT, STEERING BRACKET	1	
18	43759-89L00	.HOLDER, DRAIN HOSE	1	
19	09204-01002	.PIN	2	
20	09160-08082	.WASHER (8.5X16X1.2)	2	
21	61124-89L20	.GROMMET, R/CON CABLE	1	
22	67340-89L00	.HOLDER,, R/CON CABLE	1	
23	67467-89J01	.CONNECTOR	2	
24	09108-08286	.STUD BOLT	2	
25	09116-06225	.BOLT (6X15)	1	
26	09159-08059	.NUT	2	
27	09159-22006	.NUT	1	

DF20A_P01_016

FIG.513B





FIG.513B (2-L-2) OPT:REMOTE CONTROL PARTS (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09160-05029	.WASHER (5.5X12X0.8)	2	
29	09160-06046	.WASHER (6.5X20X1.5)	2	
30	09160-06055	.WASHER (7X12X1)	2	
31	09385-06012	.CLIP	2	
32	09407-14407	.CLAMP (L:145)	12	
33	01547-06167	.BOLT	2	
34	01550-06127	.BOLT	2	
35	01550-06167	.BOLT	2	

FIG.513C



DF20A_P01_016_513C
OPT:REMOTE CONTROL PARTS

FIG.513C (2-L-3) OPT:REMOTE CONTROL PARTS (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67130-89L03	PARTS SET, R/CON	1	
2	13513-89L10	.ROD,THROTTLE	1	
3	19120-99J11	.LEVER, THROTTLE CONTROL	1	
4	19122-99J00	.LEVER, INTERLINK THROTTLE NO.2	1	
5	19131-89L00	.CONNECTOR	2	
6	19148-89L10	.LEVER, INTERLINK THROTTLE NO.1	1	
7	19150-89L00	.BRACKET, THROTTLE LEVER	1	
8	19185-99J00	.SPRING, THROTTLE LEVER	1	
9	21110-89L10	.LEVER, CLUTCH	1	
10	23115-89L10	.LINK, CLUTCH LEVER	1	
11	36610-89L23	.HARNESS ASSY, WIRING	1	
12	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
13	09481-10501	..FUSE (10A)	1	
14	09481-30501	..FUSE (30A)	1	
15	37163-89L00	.PLUG, STARTING SWITCH HOLE	1	
16	41130-89L00	.SHAFT, CLAMP BRACKET	1	
17	43755-99J00	.ATTACHMENT, STEERING BRACKET	1	
18	43759-89L00	.HOLDER, DRAIN HOSE	1	
19	09204-01002	.PIN	2	
20	09160-08082	.WASHER (8.5X16X1.2)	2	
21	61124-89L20	.GROMMET, R/CON CABLE	1	
22	67340-89L00	.HOLDER,, R/CON CABLE	1	
23	67467-89J01	.CONNECTOR	2	
24	09108-08286	.STUD BOLT	2	
25	09116-06225	.BOLT (6X15)	1	
26	09159-08059	.NUT	2	
27	09159-22006	.NUT	1	

DF20A_P01_016

FIG.513C




FIG.513C (2-L-4) OPT:REMOTE CONTROL PARTS (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09160-05029	.WASHER (5.5X12X0.8)	2	
29	09160-06046	.WASHER (6.5X20X1.5)	2	
30	09160-06055	.WASHER (7X12X1)	2	
31	09385-06012	.CLIP	2	
32	09407-14407	.CLAMP (L:145)	12	
33	01547-06167	.BOLT	2	
34	01550-06127	.BOLT	2	
35	01550-06167	.BOLT	2	

FIG.513D




FIG.513D (2-L-5) OPT:REMOTE CONTROL PARTS (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67130-89L03	PARTS SET, R/CON	1	
2	13513-89L10	.ROD,THROTTLE	1	
3	19120-99J11	.LEVER, THROTTLE CONTROL	1	
4	19122-99J00	.LEVER, INTERLINK THROTTLE NO.2	1	
5	19131-89L00	.CONNECTOR	2	
6	19148-89L10	.LEVER, INTERLINK THROTTLE NO.1	1	
7	19150-89L00	.BRACKET, THROTTLE LEVER	1	
8	19185-99J00	.SPRING, THROTTLE LEVER	1	
9	21110-89L10	.LEVER, CLUTCH	1	
10	23115-89L10	.LINK, CLUTCH LEVER	1	
11	36610-89L23	.HARNESS ASSY, WIRING	1	
12	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
13	09481-10501	..FUSE (10A)	1	
14	09481-30501	..FUSE (30A)	1	
15	37163-89L00	.PLUG, STARTING SWITCH HOLE	1	
16	41130-89L00	.SHAFT, CLAMP BRACKET	1	
17	43755-99J00	.ATTACHMENT, STEERING BRACKET	1	
18	43759-89L00	.HOLDER, DRAIN HOSE	1	
19	09204-01002	.PIN	2	
20	09160-08082	.WASHER (8.5X16X1.2)	2	
21	61124-89L20	.GROMMET, R/CON CABLE	1	
22	67340-89L00	.HOLDER,, R/CON CABLE	1	
23	67467-89J01	.CONNECTOR	2	
24	09108-08286	.STUD BOLT	2	
25	09116-06225	.BOLT (6X15)	1	
26	09159-08059	.NUT	2	
27	09159-22006	.NUT	1	

FIG.513D




FIG.513D (2-L-6) OPT:REMOTE CONTROL PARTS (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09160-05029	.WASHER (5.5X12X0.8)	2	
29	09160-06046	.WASHER (6.5X20X1.5)	2	
30	09160-06055	.WASHER (7X12X1)	2	
31	09385-06012	.CLIP	2	
32	09407-14407	.CLAMP (L:145)	12	
33	01547-06167	.BOLT	2	
34	01550-06127	.BOLT	2	
35	01550-06167	.BOLT	2	

FIG.515A





FIG.515A (2-L-7) OPT:REMOCON CABLE (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515B





FIG.515B (2-L-8) OPT:REMOCON CABLE (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515C





FIG.515C (2-L-9) OPT:REMOCON CABLE (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515D





FIG.515D (2-L-10) OPT:REMOCON CABLE (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515E





FIG.515E (2-L-11) OPT:REMOCON CABLE (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515F





FIG.515F (2-L-12) OPT:REMOCON CABLE (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515G





FIG.515G (2-L-13) OPT:REMOCON CABLE (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515H





FIG.515H (2-L-14) OPT:REMOCON CABLE (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515J





FIG.515J (2-L-15) OPT:REMOCON CABLE (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515K






FIG.515K (3-B-2) OPT:REMOCON CABLE (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.530A




DF20A_P01_016_530A
OPT:SWITCH

FIG.530A (3-B-3) OPT:SWITCH (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	..SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	..PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER ASSY, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
11	37823-92E01	..PLATE	1	
12	37826-92J00	..NUT	1	
13	37825-99E00	..PANEL, EMERGENCY SW	1	
14	03122-05165	..SCREW	4	
15	37210-93J00	PANEL ASSY, LIGHTING SW	1	
16	37212-93J00	..PANEL, LIGHTING SW	1	

DF20A_P01_016

FIG.530A




DF20A_P01_016_530A
OPT:SWITCH

FIG.530A (3-B-4) OPT:SWITCH (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	37100-96J24	PANEL ASSY, ENGINE SW	1	
18	37110-93J01	..SWITCH ASSY, IGNITION	1	
19-1	37141-99E00	..KEY (931)	2	
19-2	37141-99E10	..KEY (932)	2	
19-3	37141-99E20	..KEY (933)	2	
19-4	37141-99E30	..KEY (934)	2	
19-5	37141-99E40	..KEY (935)	2	
19-6	37141-99E50	..KEY (936)	2	
19-7	37141-99E60	..KEY (937)	2	
19-8	37141-99E70	..KEY (938)	2	
19-9	37141-99E80	..KEY (939)	2	
19-10	37141-99E90	..KEY (940)	2	
19-11	37141-99EA0	..KEY (941)	2	
19-12	37141-99EB0	..KEY (942)	2	
20	37143-99E00	..CAP, KEY	1	
21	37149-93J00	..CAP, CYLINDER BODY	1	
22	37139-99E20	..PANEL, IGNITION SWITCH	1	
23	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
24	37823-92E01	..PLATE ASSY, EMERGENCY	1	
25	37826-92J00	..NUT	1	
26	03121-0516A	..SCREW	4	
27	38500-93J90	..BUZZER ASSY, WARNING	1	
28	09407-08401	..CLAMP (L:80)	1	

DF20A_P01_016

FIG.530B




DF20A_P01_016_530B
OPT:SWITCH

FIG.530B (3-B-5) OPT:SWITCH (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	.SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	.PANEL, IGNITION SW	1	
7	38500-93J90	.BUZZER ASSY, WARNING	1	
8	09407-08401	.CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J04	.SWITCH ASSY, EMERGENCY	1	
11	37823-92E01	..PLATE	1	
12	37826-92J00	..NUT	1	
13	37825-99E00	.PANEL, EMERGENCY SW	1	
14	03122-05165	.SCREW	4	
15	37210-93J00	PANEL ASSY, LIGHTING SW	1	
16	37212-93J00	.PANEL, LIGHTING SW	1	

DF20A_P01_016

FIG.530B




DF20A_P01_016_530B
OPT:SWITCH

FIG.530B (3-B-6) OPT:SWITCH (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	37100-96J24	PANEL ASSY, ENGINE SW	1	
18	37110-93J01	..SWITCH ASSY, IGNITION	1	
19-1	37141-99E00	..KEY (931)	2	
19-2	37141-99E10	..KEY (932)	2	
19-3	37141-99E20	..KEY (933)	2	
19-4	37141-99E30	..KEY (934)	2	
19-5	37141-99E40	..KEY (935)	2	
19-6	37141-99E50	..KEY (936)	2	
19-7	37141-99E60	..KEY (937)	2	
19-8	37141-99E70	..KEY (938)	2	
19-9	37141-99E80	..KEY (939)	2	
19-10	37141-99E90	..KEY (940)	2	
19-11	37141-99EA0	..KEY (941)	2	
19-12	37141-99EB0	..KEY (942)	2	
20	37143-99E00	..CAP, KEY	1	
21	37149-93J00	..CAP, CYLINDER BODY	1	
22	37139-99E20	..PANEL, IGNITION SWITCH	1	
23	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
24	37823-92E01	..PLATE ASSY, EMERGENCY	1	
25	37826-92J00	..NUT	1	
26	03121-0516A	..SCREW	4	
27	38500-93J90	..BUZZER ASSY, WARNING	1	
28	09407-08401	..CLAMP (L:80)	1	

DF20A_P01_016

FIG.530C




DF20A_P01_016_530C
OPT:SWITCH

FIG.530C (3-B-7) OPT:SWITCH (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	..SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	..PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER ASSY, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
11	37823-92E01	..PLATE	1	
12	37826-92J00	..NUT	1	
13	37825-99E00	..PANEL, EMERGENCY SW	1	
14	03122-05165	..SCREW	4	
15	37210-93J00	PANEL ASSY, LIGHTING SW	1	
16	37212-93J00	..PANEL, LIGHTING SW	1	

DF20A_P01_016

FIG.530C




DF20A_P01_016_530C
OPT:SWITCH

FIG.530C (3-B-8) OPT:SWITCH (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	37100-96J24	PANEL ASSY, ENGINE SW	1	
18	37110-93J01	..SWITCH ASSY, IGNITION	1	
19-1	37141-99E00	..KEY (931)	2	
19-2	37141-99E10	..KEY (932)	2	
19-3	37141-99E20	..KEY (933)	2	
19-4	37141-99E30	..KEY (934)	2	
19-5	37141-99E40	..KEY (935)	2	
19-6	37141-99E50	..KEY (936)	2	
19-7	37141-99E60	..KEY (937)	2	
19-8	37141-99E70	..KEY (938)	2	
19-9	37141-99E80	..KEY (939)	2	
19-10	37141-99E90	..KEY (940)	2	
19-11	37141-99EA0	..KEY (941)	2	
19-12	37141-99EB0	..KEY (942)	2	
20	37143-99E00	..CAP, KEY	1	
21	37149-93J00	..CAP, CYLINDER BODY	1	
22	37139-99E20	..PANEL, IGNITION SWITCH	1	
23	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
24	37823-92E01	..PLATE ASSY, EMERGENCY	1	
25	37826-92J00	..NUT	1	
26	03121-0516A	..SCREW	4	
27	38500-93J90	..BUZZER ASSY, WARNING	1	
28	09407-08401	..CLAMP (L:80)	1	

DF20A_P01_016

FIG.530D




DF20A_P01_016_530D
OPT:SWITCH

FIG.530D (3-B-9) OPT:SWITCH (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	..SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	..PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER ASSY, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
11	37823-92E01	..PLATE	1	
12	37826-92J00	..NUT	1	
13	37825-99E00	..PANEL, EMERGENCY SW	1	
14	03122-05165	..SCREW	4	
15	37210-93J00	PANEL ASSY, LIGHTING SW	1	
16	37212-93J00	..PANEL, LIGHTING SW	1	

DF20A_P01_016

FIG.530D




DF20A_P01_016_530D
OPT:SWITCH

FIG.530D (3-B-10) OPT:SWITCH (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	37100-96J24	PANEL ASSY, ENGINE SW	1	
18	37110-93J01	..SWITCH ASSY, IGNITION	1	
19-1	37141-99E00	..KEY (931)	2	
19-2	37141-99E10	..KEY (932)	2	
19-3	37141-99E20	..KEY (933)	2	
19-4	37141-99E30	..KEY (934)	2	
19-5	37141-99E40	..KEY (935)	2	
19-6	37141-99E50	..KEY (936)	2	
19-7	37141-99E60	..KEY (937)	2	
19-8	37141-99E70	..KEY (938)	2	
19-9	37141-99E80	..KEY (939)	2	
19-10	37141-99E90	..KEY (940)	2	
19-11	37141-99EA0	..KEY (941)	2	
19-12	37141-99EB0	..KEY (942)	2	
20	37143-99E00	..CAP, KEY	1	
21	37149-93J00	..CAP, CYLINDER BODY	1	
22	37139-99E20	..PANEL, IGNITION SWITCH	1	
23	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
24	37823-92E01	..PLATE ASSY, EMERGENCY	1	
25	37826-92J00	..NUT	1	
26	03121-0516A	..SCREW	4	
27	38500-93J90	..BUZZER ASSY, WARNING	1	
28	09407-08401	..CLAMP (L:80)	1	

DF20A_P01_016

FIG.530E




DF20A_P01_016_530E
OPT:SWITCH

FIG.530E (3-B-11) OPT:SWITCH (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	..SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	..PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER ASSY, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
11	37823-92E01	..PLATE	1	
12	37826-92J00	..NUT	1	
13	37825-99E00	..PANEL, EMERGENCY SW	1	
14	03122-05165	..SCREW	4	
15	37210-93J00	PANEL ASSY, LIGHTING SW	1	
16	37212-93J00	..PANEL, LIGHTING SW	1	

DF20A_P01_016

FIG.530E




DF20A_P01_016_530E
OPT:SWITCH

FIG.530E (3-B-12) OPT:SWITCH (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	37100-96J24	PANEL ASSY, ENGINE SW	1	
18	37110-93J01	..SWITCH ASSY, IGNITION	1	
19-1	37141-99E00	..KEY (931)	2	
19-2	37141-99E10	..KEY (932)	2	
19-3	37141-99E20	..KEY (933)	2	
19-4	37141-99E30	..KEY (934)	2	
19-5	37141-99E40	..KEY (935)	2	
19-6	37141-99E50	..KEY (936)	2	
19-7	37141-99E60	..KEY (937)	2	
19-8	37141-99E70	..KEY (938)	2	
19-9	37141-99E80	..KEY (939)	2	
19-10	37141-99E90	..KEY (940)	2	
19-11	37141-99EA0	..KEY (941)	2	
19-12	37141-99EB0	..KEY (942)	2	
20	37143-99E00	..CAP, KEY	1	
21	37149-93J00	..CAP, CYLINDER BODY	1	
22	37139-99E20	..PANEL, IGNITION SWITCH	1	
23	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
24	37823-92E01	..PLATE ASSY, EMERGENCY	1	
25	37826-92J00	..NUT	1	
26	03121-0516A	..SCREW	4	
27	38500-93J90	..BUZZER ASSY, WARNING	1	
28	09407-08401	..CLAMP (L:80)	1	

DF20A_P01_016

FIG.530F




DF20A_P01_016_530F
OPT:SWITCH

FIG.530F (3-B-13) OPT:SWITCH (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	.SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	.PANEL, IGNITION SW	1	
7	38500-93J90	.BUZZER ASSY, WARNING	1	
8	09407-08401	.CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J04	.SWITCH ASSY, EMERGENCY	1	
11	37823-92E01	..PLATE	1	
12	37826-92J00	..NUT	1	
13	37825-99E00	.PANEL, EMERGENCY SW	1	
14	03122-05165	.SCREW	4	
15	37210-93J00	PANEL ASSY, LIGHTING SW	1	
16	37212-93J00	.PANEL, LIGHTING SW	1	

DF20A_P01_016

FIG.530F



DF20A_P01_016_530F
OPT:SWITCH

FIG.530F (3-B-14) OPT:SWITCH (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	37100-96J24	PANEL ASSY, ENGINE SW	1	
18	37110-93J01	..SWITCH ASSY, IGNITION	1	
19-1	37141-99E00	..KEY (931)	2	
19-2	37141-99E10	..KEY (932)	2	
19-3	37141-99E20	..KEY (933)	2	
19-4	37141-99E30	..KEY (934)	2	
19-5	37141-99E40	..KEY (935)	2	
19-6	37141-99E50	..KEY (936)	2	
19-7	37141-99E60	..KEY (937)	2	
19-8	37141-99E70	..KEY (938)	2	
19-9	37141-99E80	..KEY (939)	2	
19-10	37141-99E90	..KEY (940)	2	
19-11	37141-99EA0	..KEY (941)	2	
19-12	37141-99EB0	..KEY (942)	2	
20	37143-99E00	..CAP, KEY	1	
21	37149-93J00	..CAP, CYLINDER BODY	1	
22	37139-99E20	..PANEL, IGNITION SWITCH	1	
23	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
24	37823-92E01	..PLATE ASSY, EMERGENCY	1	
25	37826-92J00	..NUT	1	
26	03121-0516A	..SCREW	4	
27	38500-93J90	..BUZZER ASSY, WARNING	1	
28	09407-08401	..CLAMP (L:80)	1	

DF20A_P01_016

FIG.544A




FIG.544A (3-B-15) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544B




FIG.544B (3-C-2) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544C




FIG.544C (3-C-3) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544D




FIG.544D (3-C-4) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544E




FIG.544E (3-C-5) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544F




FIG.544F (3-C-6) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544G




FIG.544G (3-C-7) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544H




FIG.544H (3-C-8) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544J




FIG.544J (3-C-9) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544K




FIG.544K (3-C-10) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.545A




FIG.545A (3-C-11) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545A




FIG.545A (3-C-12) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

This exploded view diagram illustrates the assembly of a mechanical device. The components are numbered as follows:

- 1**: Main housing or frame.
- 2**: A bracket or support arm.
- 3**: A small pin or fastener.
- 4**: A small washer or spacer.
- 5**: A small pin or fastener.
- 6**: A small washer or spacer.
- 7**: A small pin or fastener.
- 8**: A small pin or fastener.
- 9**: A small pin or fastener.
- 10**: A small pin or fastener.
- 11**: A cable or wire.
- 12**: A small pin or fastener.
- 13**: A small pin or fastener.
- 14**: A small pin or fastener.
- 15**: A small pin or fastener.
- 16**: A small pin or fastener.
- 17**: A small pin or fastener.
- 18**: A small pin or fastener.
- 19**: A small pin or fastener.
- 20**: A small pin or fastener.
- 21**: A small pin or fastener.
- 22**: A circular component, possibly a lens or filter.
- 23**: A small pin or fastener.
- 24**: A small pin or fastener.
- 25**: A small pin or fastener.
- 26**: A small pin or fastener.
- 27**: A small pin or fastener.
- 28**: A small pin or fastener.
- 29**: A small pin or fastener.
- 30**: A small pin or fastener.
- 31**: A small pin or fastener.
- 32**: A small pin or fastener.
- 33**: A small pin or fastener.
- 34**: A small pin or fastener.
- 35**: A small pin or fastener.
- 36**: A small pin or fastener.
- 37**: A small pin or fastener.
- 38**: A small pin or fastener.
- 39**: A small pin or fastener.
- 40**: A small pin or fastener.
- 41**: A small pin or fastener.
- 42**: A small pin or fastener.
- 43**: A small pin or fastener.
- 44**: A small pin or fastener.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545B




FIG.545B (3-C-14) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

This exploded view diagram illustrates the assembly of a mechanical device, likely a pump or motor component. The parts are numbered as follows:

- 1**: Main housing or casing.
- 2**: A bracket or support arm.
- 3**: A small pin or clip.
- 4**: A small washer or spacer.
- 5**: A small pin or clip.
- 6**: A small washer or spacer.
- 7**: A small pin or clip.
- 8**: A small pin or clip.
- 9**: A small pin or clip.
- 10**: A small pin or clip.
- 11**: A long cable or hose.
- 12**: A small pin or clip.
- 13**: A small pin or clip.
- 14**: A small pin or clip.
- 15**: A small pin or clip.
- 16**: A small pin or clip.
- 17**: A small pin or clip.
- 18**: A small pin or clip.
- 19**: A small pin or clip.
- 20**: A small pin or clip.
- 21**: A small pin or clip.
- 22**: A circular component, possibly a filter or cap.
- 23**: A small pin or clip.
- 24**: A small pin or clip.
- 25**: A small pin or clip.
- 26**: A small pin or clip.
- 27**: A small pin or clip.
- 28**: A small pin or clip.
- 29**: A small pin or clip.
- 30**: A small pin or clip.
- 31**: A small pin or clip.
- 32**: A small pin or clip.
- 33**: A small pin or clip.
- 34**: A small pin or clip.
- 35**: A small pin or clip.
- 36**: A small pin or clip.
- 37**: A small pin or clip.
- 38**: A small pin or clip.
- 39**: A small pin or clip.
- 40**: A small pin or clip.
- 41**: A small pin or clip.
- 42**: A small pin or clip.
- 43**: A small pin or clip.
- 44**: A small pin or clip.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545C




FIG.545C (3-D-2) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545D




FIG.545D (3-D-3) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545D




FIG.545D (3-D-4) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545E




FIG.545E (3-D-5) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545E




FIG.545E (3-D-6) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545F




FIG.545F (3-D-7) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545F




FIG.545F (3-D-8) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545G





FIG.545G (3-D-9) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545G



DF20A_P01_016_545G
OPT:REMOTE CONTROL ASSY SINGLE (2)

FIG.545G (3-D-10) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

DF20A_P01_016

This exploded view diagram illustrates the assembly of a mechanical device. The components are numbered as follows:

- 1**: Main housing or frame.
- 2**: A bracket or support arm.
- 3**: A small pin or clip.
- 4**: A small washer or spacer.
- 5**: A small pin or clip.
- 6**: A small pin or clip.
- 7**: A small pin or clip.
- 8**: A small pin or clip.
- 9**: A small pin or clip.
- 10**: A small pin or clip.
- 11**: A cable or wire.
- 12**: A small pin or clip.
- 13**: A small pin or clip.
- 14**: A small pin or clip.
- 15**: A small pin or clip.
- 16**: A small pin or clip.
- 17**: A small pin or clip.
- 18**: A small pin or clip.
- 19**: A small pin or clip.
- 20**: A small pin or clip.
- 21**: A small pin or clip.
- 22**: A circular component, possibly a lens or filter.
- 23**: A small pin or clip.
- 24**: A small pin or clip.
- 25**: A small pin or clip.
- 26**: A small pin or clip.
- 27**: A small pin or clip.
- 28**: A small pin or clip.
- 29**: A small pin or clip.
- 30**: A small pin or clip.
- 31**: A small pin or clip.
- 32**: A small pin or clip.
- 33**: A small pin or clip.
- 34**: A small pin or clip.
- 35**: A small pin or clip.
- 36**: A small pin or clip.
- 37**: A small pin or clip.
- 38**: A small pin or clip.
- 39**: A small pin or clip.
- 40**: A small pin or clip.
- 41**: A small pin or clip.
- 42**: A small pin or clip.
- 43**: A small pin or clip.
- 44**: A small pin or clip.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545H




FIG.545H (3-D-12) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545J




FIG.545J (3-D-13) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545J




FIG.545J (3-D-14) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545K




FIG.545K (3-D-15) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545K




FIG.545K (3-E-2) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.546A

FIG.546A (3-E-3) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	





FIG.546B

FIG.546B (3-E-4) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	





FIG.546C





FIG.546C (3-E-5) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF15ATH P01

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.546D

FIG.546D (3-E-6) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	





FIG.546E

FIG.546E (3-E-7) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	





FIG.546F

FIG.546F (3-E-8) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF20ATH P01

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	





FIG.553A




FIG.553A (3-E-9) OPT:ELECTRICAL (MANUAL STARTER) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-89L00	KIT,BATTERY CHARGING	1	
2	32801-89L00	..RECTIFIER & REGULATOR SET	1	
3	32800-94J11	..RECTIFIER/REGULATOR ASSY	1	
4	32815-89L10	..BRACKET, RECTIFIER	1	
5	01550-08207	..BOLT	2	
6	01550-06207	..BOLT	2	
7	09407-14407	..CLAMP (L:145)	3	
8	09408-00184	..CLAMP	1	
9	39600-89L00	..RECEPTACLE SET	1	
10	36740-94J00	..CASE ASSY, FUSE	1	
11	37801-98300	..LEAD RECEPTACLE GROUND	1	
12	39601-95D00	..RECEPTACLE ASSY, LIGHTING	1	
13	36634-93910	...CAP	1	
14	39602-93900	..PLUG, RECEPTACLE	1	
15	09407-14403	..CLAMP (L:125)	2	
16	09407-14407	..CLAMP (L:145)	3	
17	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.553B




FIG.553B (3-E-10) OPT:ELECTRICAL (MANUAL STARTER) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-89L00	KIT,BATTERY CHARGING	1	
2	32801-89L00	..RECTIFIER & REGULATOR SET	1	
3	32800-94J11	..RECTIFIER/REGULATOR ASSY	1	
4	32815-89L10	..BRACKET, RECTIFIER	1	
5	01550-08207	..BOLT	2	
6	01550-06207	..BOLT	2	
7	09407-14407	..CLAMP (L:145)	3	
8	09408-00184	..CLAMP	1	
9	39600-89L00	..RECEPTACLE SET	1	
10	36740-94J00	..CASE ASSY, FUSE	1	
11	37801-98300	..LEAD RECEPTACLE GROUND	1	
12	39601-95D00	..RECEPTACLE ASSY, LIGHTING	1	
13	36634-93910	...CAP	1	
14	39602-93900	..PLUG, RECEPTACLE	1	
15	09407-14403	..CLAMP (L:125)	2	
16	09407-14407	..CLAMP (L:145)	3	
17	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.553C




FIG.553C (3-E-11) OPT:ELECTRICAL (MANUAL STARTER) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-89L00	KIT,BATTERY CHARGING	1	
2	32801-89L00	..RECTIFIER & REGULATOR SET	1	
3	32800-94J11	..RECTIFIER/REGULATOR ASSY	1	
4	32815-89L10	..BRACKET, RECTIFIER	1	
5	01550-08207	..BOLT	2	
6	01550-06207	..BOLT	2	
7	09407-14407	..CLAMP (L:145)	3	
8	09408-00184	..CLAMP	1	
9	39600-89L00	..RECEPTACLE SET	1	
10	36740-94J00	..CASE ASSY, FUSE	1	
11	37801-98300	..LEAD RECEPTACLE GROUND	1	
12	39601-95D00	..RECEPTACLE ASSY, LIGHTING	1	
13	36634-93910	...CAP	1	
14	39602-93900	..PLUG, RECEPTACLE	1	
15	09407-14403	..CLAMP (L:125)	2	
16	09407-14407	..CLAMP (L:145)	3	
17	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.553D




FIG.553D (3-E-12) OPT:ELECTRICAL (MANUAL STARTER) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-89L00	KIT,BATTERY CHARGING	1	
2	32801-89L00	..RECTIFIER & REGULATOR SET	1	
3	32800-94J11	..RECTIFIER/REGULATOR ASSY	1	
4	32815-89L10	..BRACKET, RECTIFIER	1	
5	01550-08207	..BOLT	2	
6	01550-06207	..BOLT	2	
7	09407-14407	..CLAMP (L:145)	3	
8	09408-00184	..CLAMP	1	
9	39600-89L00	..RECEPTACLE SET	1	
10	36740-94J00	..CASE ASSY, FUSE	1	
11	37801-98300	..LEAD RECEPTACLE GROUND	1	
12	39601-95D00	..RECEPTACLE ASSY, LIGHTING	1	
13	36634-93910	...CAP	1	
14	39602-93900	..PLUG, RECEPTACLE	1	
15	09407-14403	..CLAMP (L:125)	2	
16	09407-14407	..CLAMP (L:145)	3	
17	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.561A




FIG.561A (3-E-13) OPT:STARTING MOTOR (MANUAL STARTER) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L04	STARTER SET, ELECTRIC	1	
2	31101-89L00	..MOTOR SET, STARTING	1	
3	31100-94J22	..MOTOR ASSY, STARTING	1	
4	32102-89L00	..FLYWHEEL, MAGNETO	1	
5	32120-89L00	..COIL, STATOR & PULSER	1	
6	32800-89L00	..RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	..BRACKET, RECTIFIER	1	
8	01550-06167	..BOLT	1	
9	01550-06207	..BOLT	2	
10	01547-0625A	..BOLT	3	
11	09408-00184	..CLAMP	1	
12	33800-89L01	..CABLE SET, STARTER	1	
13	33810-89L02	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L01	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19	36610-89L04	..HARNESS ASSY, WIRING	1	
20	38860-76F01	..RELAY ASSY	1	
21	38915-90J00	..HOLDER, RELAY	1	
22	09407-14407	..CLAMP (L:145)	11	
23	12700-89L21	..CAMSHAFT ASSY	1	
24	33920-89LC0	UNIT, ENGINE CONTROL	1	

FIG.561B




FIG.561B (3-E-14) OPT:STARTING MOTOR (MANUAL STARTER) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L04	STARTER SET, ELECTRIC	1	
2	31101-89L00	..MOTOR SET, STARTING	1	
3	31100-94J22	..MOTOR ASSY, STARTING	1	
4	32102-89L00	..FLYWHEEL, MAGNETO	1	
5	32120-89L00	..COIL, STATOR & PULSER	1	
6	32800-89L00	..RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	..BRACKET, RECTIFIER	1	
8	01550-06167	..BOLT	1	
9	01550-06207	..BOLT	2	
10	01547-0625A	..BOLT	3	
11	09408-00184	..CLAMP	1	
12	33800-89L01	..CABLE SET, STARTER	1	
13	33810-89L02	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L01	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19	36610-89L04	..HARNESS ASSY, WIRING	1	
20	38860-76F01	..RELAY ASSY	1	
21	38915-90J00	..HOLDER, RELAY	1	
22	09407-14407	..CLAMP (L:145)	11	
23	12700-89L21	..CAMSHAFT ASSY	1	
24	33920-89L80	UNIT, ENGINE CONTROL	1	

FIG.561C




FIG.561C (3-E-15) OPT:STARTING MOTOR (MANUAL STARTER) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L04	STARTER SET, ELECTRIC	1	
2	31101-89L00	.MOTOR SET, STARTING	1	
3	31100-94J22	..MOTOR ASSY, STARTING	1	
4	32102-89L00	..FLYWHEEL, MAGNETO	1	
5	32120-89L00	..COIL, STATOR & PULSER	1	
6	32800-89L00	..RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	..BRACKET, RECTIFIER	1	
8	01550-06167	..BOLT	1	
9	01550-06207	..BOLT	2	
10	01547-0625A	..BOLT	3	
11	09408-00184	..CLAMP	1	
12	33800-89L01	..CABLE SET, STARTER	1	
13	33810-89L02	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L01	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19	36610-89L04	..HARNESS ASSY, WIRING	1	
20	38860-76F01	..RELAY ASSY	1	
21	38915-90J00	..HOLDER, RELAY	1	
22	09407-14407	..CLAMP (L:145)	11	
23	12700-89L21	..CAMSHAFT ASSY	1	
24	33920-89LA0	UNIT, ENGINE CONTROL	1	

FIG.561D




FIG.561D (3-F-2) OPT:STARTING MOTOR (MANUAL STARTER) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L04	STARTER SET, ELECTRIC	1	
2	31101-89L00	..MOTOR SET, STARTING	1	
3	31100-94J22	..MOTOR ASSY, STARTING	1	
4	32102-89L00	..FLYWHEEL, MAGNETO	1	
5	32120-89L00	..COIL, STATOR & PULSER	1	
6	32800-89L00	..RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	..BRACKET, RECTIFIER	1	
8	01550-06167	..BOLT	1	
9	01550-06207	..BOLT	2	
10	01547-0625A	..BOLT	3	
11	09408-00184	..CLAMP	1	
12	33800-89L01	..CABLE SET, STARTER	1	
13	33810-89L02	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L01	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19	36610-89L04	..HARNESS ASSY, WIRING	1	
20	38860-76F01	..RELAY ASSY	1	
21	38915-90J00	..HOLDER, RELAY	1	
22	09407-14407	..CLAMP (L:145)	11	
23	12700-89L21	..CAMSHAFT ASSY	1	
24	33920-89LE0	UNIT, ENGINE CONTROL	1	

FIG.575A




FIG.575A (3-F-3) OPT:DRAG LINK (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.575B




FIG.575B (3-F-4) OPT:DRAG LINK (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.575C




FIG.575C (3-F-5) OPT:DRAG LINK (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.575D





FIG.575D (3-F-6) OPT:DRAG LINK (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	



DF20A_P01_016_583A
OPT:FUEL TANK



DF20A_P01_016

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	65000-95D01	TANK ASSY, FUEL (25L)	1	
2	65520-95D01	.CAP, FUEL TANK	1	
3	65561-95D00	.GASKET, TANK CAP	1	
4	65740-95D01	.PLUG, FUEL CONNECTOR	1	
5	65831-95D00	.FILTER, OUTLET	1	
6	65890-95D00	.OUTLET ASSY	1	
7	65892-95D00	.O RING	1	
8	65700-87J15	HOSE, FUEL	1	
9	65750-87JL0	.SOCKET, FUEL HOSE	1	
10	65750-955L0	.SOCKET, FUEL HOSE	1	
11	65770-90J11	.PUMP, SQUEEZE	1	
12	65781-98500	.CLIP	4	

FIG.600A



DF20A_P01_016_600A
OPT:MULTI FUNCTION GAUGE

FIG.600A (3-F-8) OPT:MULTI FUNCTION GAUGE (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L00	KIT, SINGLE GAUGE MECH	1	
2	34011-96L00	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L10	..ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36663-98J10	..WIRE, GAUGE POWER	1	
10	09481-05501	..FUSE (5A)	1	
11	36001-88L00	SET, WIRE	1	
12	36662-88L10	..WIRE, 2 EXTENSION	1	
13	36663-88L00	..HARNESS ASSY, NETWORK POWER	1	
14	36664-88L00	..CONNECTOR, BRANCH	1	
15	36665-88L00	..UNIT, RESISTOR FEMALE	1	
16	36665-88L10	..UNIT, RESISTOR MALE	1	
17	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
18	36662-88L10	WIRE, 2 EXTENSION	1	
19	36662-88L20	WIRE, 6 EXTENSION	1	
20	36662-88L30	WIRE, 15 EXTENSION	1	
21	36662-88L00	WIRE, 25 EXTENSION	1	
22	39950-88L01	MODULE ASSY, GPS RECEIVER	1	
23	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
24	36665-88L00	UNIT, RESISTOR FEMALE	1	
25	36665-88L10	UNIT, RESISTOR MALE	1	
26	36660-89L01	SET, ENG TO INTERFACE WIRE	1	
27	29404-93J10	..CLAMP	1	
28	09407-14407	..CLAMP (L:145)	4	
29	36990-87D00	TERMINAL & SLEEVE SET	1	

DF20A_P01_016

FIG.600B







FIG.600B (3-F-9) OPT:MULTI FUNCTION GAUGE (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L00	KIT, SINGLE GAUGE MECH	1	
2	34011-96L00	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L10	..ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36663-98J10	..WIRE, GAUGE POWER	1	
10	09481-05501	..FUSE (5A)	1	
11	36001-88L00	SET, WIRE	1	
12	36662-88L10	..WIRE, 2 EXTENSION	1	
13	36663-88L00	..HARNESS ASSY, NETWORK POWER	1	
14	36664-88L00	..CONNECTOR, BRANCH	1	
15	36665-88L00	..UNIT, RESISTOR FEMALE	1	
16	36665-88L10	..UNIT, RESISTOR MALE	1	
17	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
18	36662-88L10	WIRE, 2 EXTENSION	1	
19	36662-88L20	WIRE, 6 EXTENSION	1	
20	36662-88L30	WIRE, 15 EXTENSION	1	
21	36662-88L00	WIRE, 25 EXTENSION	1	
22	39950-88L01	MODULE ASSY, GPS RECEIVER	1	
23	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
24	36665-88L00	UNIT, RESISTOR FEMALE	1	
25	36665-88L10	UNIT, RESISTOR MALE	1	
26	36660-89L01	SET, ENG TO INTERFACE WIRE	1	
27	29404-93J10	..CLAMP	1	
28	09407-14407	..CLAMP (L:145)	4	
29	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.600C



DF20A_P01_016_600C
OPT:MULTI FUNCTION GAUGE

FIG.600C (3-F-10) OPT:MULTI FUNCTION GAUGE (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L00	KIT, SINGLE GAUGE MECH	1	
2	34011-96L00	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L10	..ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36663-98J10	..WIRE, GAUGE POWER	1	
10	09481-05501	..FUSE (5A)	1	
11	36001-88L00	SET, WIRE	1	
12	36662-88L10	..WIRE, 2 EXTENSION	1	
13	36663-88L00	..HARNESS ASSY, NETWORK POWER	1	
14	36664-88L00	..CONNECTOR, BRANCH	1	
15	36665-88L00	..UNIT, RESISTOR FEMALE	1	
16	36665-88L10	..UNIT, RESISTOR MALE	1	
17	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
18	36662-88L10	WIRE, 2 EXTENSION	1	
19	36662-88L20	WIRE, 6 EXTENSION	1	
20	36662-88L30	WIRE, 15 EXTENSION	1	
21	36662-88L00	WIRE, 25 EXTENSION	1	
22	39950-88L01	MODULE ASSY, GPS RECEIVER	1	
23	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
24	36665-88L00	UNIT, RESISTOR FEMALE	1	
25	36665-88L10	UNIT, RESISTOR MALE	1	
26	36660-89L01	SET, ENG TO INTERFACE WIRE	1	
27	29404-93J10	..CLAMP	1	
28	09407-14407	..CLAMP (L:145)	4	
29	36990-87D00	TERMINAL & SLEEVE SET	1	

DF20A_P01_016

FIG.600D







FIG.600D (3-F-11) OPT:MULTI FUNCTION GAUGE (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L00	KIT, SINGLE GAUGE MECH	1	
2	34011-96L00	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L10	..ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36663-98J10	..WIRE, GAUGE POWER	1	
10	09481-05501	..FUSE (5A)	1	
11	36001-88L00	SET, WIRE	1	
12	36662-88L10	..WIRE, 2 EXTENSION	1	
13	36663-88L00	..HARNESS ASSY, NETWORK POWER	1	
14	36664-88L00	..CONNECTOR, BRANCH	1	
15	36665-88L00	..UNIT, RESISTOR FEMALE	1	
16	36665-88L10	..UNIT, RESISTOR MALE	1	
17	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
18	36662-88L10	WIRE, 2 EXTENSION	1	
19	36662-88L20	WIRE, 6 EXTENSION	1	
20	36662-88L30	WIRE, 15 EXTENSION	1	
21	36662-88L00	WIRE, 25 EXTENSION	1	
22	39950-88L01	MODULE ASSY, GPS RECEIVER	1	
23	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
24	36665-88L00	UNIT, RESISTOR FEMALE	1	
25	36665-88L10	UNIT, RESISTOR MALE	1	
26	36660-89L01	SET, ENG TO INTERFACE WIRE	1	
27	29404-93J10	..CLAMP	1	
28	09407-14407	..CLAMP (L:145)	4	
29	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.600E





DF20A_P01_016_600E
OPT:MULTI FUNCTION GAUGE

FIG.600E (3-F-12) OPT:MULTI FUNCTION GAUGE (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L00	KIT, SINGLE GAUGE MECH	1	
2	34011-96L00	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L10	..ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36663-98J10	..WIRE, GAUGE POWER	1	
10	09481-05501	..FUSE (5A)	1	
11	36001-88L00	SET, WIRE	1	
12	36662-88L10	..WIRE, 2 EXTENSION	1	
13	36663-88L00	..HARNESS ASSY, NETWORK POWER	1	
14	36664-88L00	..CONNECTOR, BRANCH	1	
15	36665-88L00	..UNIT, RESISTOR FEMALE	1	
16	36665-88L10	..UNIT, RESISTOR MALE	1	
17	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
18	36662-88L10	WIRE, 2 EXTENSION	1	
19	36662-88L20	WIRE, 6 EXTENSION	1	
20	36662-88L30	WIRE, 15 EXTENSION	1	
21	36662-88L00	WIRE, 25 EXTENSION	1	
22	39950-88L01	MODULE ASSY, GPS RECEIVER	1	
23	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
24	36665-88L00	UNIT, RESISTOR FEMALE	1	
25	36665-88L10	UNIT, RESISTOR MALE	1	
26	36660-89L01	SET, ENG TO INTERFACE WIRE	1	
27	29404-93J10	..CLAMP	1	
28	09407-14407	..CLAMP (L:145)	4	
29	36990-87D00	TERMINAL & SLEEVE SET	1	

DF20A_P01_016

FIG.600F



DF20A_P01_016.600F
OPT:MULTI FUNCTION GAUGE

FIG.600F (3-F-13) OPT:MULTI FUNCTION GAUGE (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L00	KIT, SINGLE GAUGE MECH	1	
2	34011-96L00	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L10	..ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36663-98J10	..WIRE, GAUGE POWER	1	
10	09481-05501	..FUSE (5A)	1	
11	36001-88L00	SET, WIRE	1	
12	36662-88L10	..WIRE, 2 EXTENSION	1	
13	36663-88L00	..HARNESS ASSY, NETWORK POWER	1	
14	36664-88L00	..CONNECTOR, BRANCH	1	
15	36665-88L00	..UNIT, RESISTOR FEMALE	1	
16	36665-88L10	..UNIT, RESISTOR MALE	1	
17	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
18	36662-88L10	WIRE, 2 EXTENSION	1	
19	36662-88L20	WIRE, 6 EXTENSION	1	
20	36662-88L30	WIRE, 15 EXTENSION	1	
21	36662-88L00	WIRE, 25 EXTENSION	1	
22	39950-88L01	MODULE ASSY, GPS RECEIVER	1	
23	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
24	36665-88L00	UNIT, RESISTOR FEMALE	1	
25	36665-88L10	UNIT, RESISTOR MALE	1	
26	36660-89L01	SET, ENG TO INTERFACE WIRE	1	
27	29404-93J10	..CLAMP	1	
28	09407-14407	..CLAMP (L:145)	4	
29	36990-87D00	TERMINAL & SLEEVE SET	1	

DF20A_P01_016

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
10000		12741-89L00	120A-6		121M-6
		12744-89L00	120A-17	12891-94J00	121A-7
		12761-93EL0	120A-16		121B-7
		12840-93E01	121A-3		121C-7
			121B-3		121D-7
11110-89L01	111A-1		121C-3		121E-7
11115-93E00-001	111A-19		121D-3		121F-7
11141-89L00	111A-2		121E-3		121G-7
11162-89L00	111A-14		121F-3		121H-7
11170-89L00	111A-13		121G-3		121J-7
11174-89L00	111A-16		121H-3		121K-7
11261-93J00	111A-5		121J-3		121L-7
11291-91B50	113A-6		121K-3		121M-7
11300-89L02	113A-1		121L-3	12911-94J01	121A-8
11382-93E00	111A-10		121M-3		121B-8
12100-89L10-050	116A-10	12842-49201	121A-4		121C-8
12111-89L00-0B0	116A-1		121B-4		121D-8
12140-89L10	116A-2		121C-4		121E-8
12140-89L10-050	116A-11		121D-4		121F-8
12151-89L00	116A-3		121E-4		121G-8
12160-89L11	116A-5		121F-4		121H-8
12163-89L02	116A-6		121G-4		121J-8
12220-89L00	116A-7		121H-4		121K-8
12341-89L10	116A-8		121J-4		121L-8
12625-89L01	120A-11		121K-4		121M-8
12631-89L10	120A-1		121L-4	12915-94J50	121A-9
12635-89L00	120A-2		121M-4		121B-9
12636-89L00	120A-3	12843-27A00	121A-5		121C-9
12637-89L00	120A-4		121B-5		121D-9
12638-89L00	120A-5		121C-5		121E-9
12700-89L01	121A-1-1		121D-5		121F-9
	121D-1-1		121E-5		121G-9
	121H-1-1		121F-5		121H-9
	121J-1-1		121G-5		121J-9
12700-89L21	121A-1-2		121H-5		121K-9
	121B-1		121J-5		121L-9
	121C-1		121K-5		121M-9
	121D-1-2		121L-5	12921-89L00	121A-10
	121E-1		121M-5		121B-10
	121F-1	12861-89L00	121A-6		121C-10
	121G-1		121B-6		121D-10
	121H-1-2		121C-6		121E-10
	121J-1-2		121D-6		121F-10
	121K-1		121E-6		121G-10
	121L-1		121F-6		121H-10
	121M-1		121G-6		121J-10
	561A-23		121H-6		121K-10
	561B-23		121J-6		121L-10
	561C-23		121K-6		121M-10
	561D-23		121L-6	12931-78G00	121A-11

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	121B-11		126D-8		163F-2
	121C-11		126E-8		163G-2
	121D-11		126F-8		163H-2
	121E-11		126G-8		163J-2
	121F-11		126H-10		163K-2
	121G-11		126J-10		163L-2
	121H-11		126K-10	13421-89L00	163M-2
	121J-11		126L-10		163A-5
	121K-11		126M-10		163B-5
	121L-11	13119-89L00	126A-2		163C-5
	121M-11		126B-2		163D-5
12932-24400	121A-12		126C-2		163E-5
	121B-12		126D-2		163F-5
	121C-12		126E-2		163G-5
	121D-12		126F-2		163H-5
	121E-12		126G-2		163J-5
	121F-12		126H-2		163K-5
	121G-12		126J-2		163L-5
	121H-12		126K-2		163M-5
	121J-12		126L-2	13425-33G00	163A-3
	121K-12		126M-2		163B-3
	121L-12	13300-89L01	163A-1		163C-3
	121M-12		163D-1		163D-3
12933-71C00	121A-13		163G-1		163E-3
	121B-13		163H-1		163F-3
	121C-13		163J-1		163G-3
	121D-13		163M-1		163H-3
	121E-13	13300-89L11	163B-1		163J-3
	121F-13		163C-1		163K-3
	121G-13		163E-1		163L-3
	121H-13		163F-1		163M-3
	121J-13		163K-1	13513-89L10	166A-1
	121K-13		163L-1		166B-1
	121L-13	13326-89L00	163A-4		166C-1
	121M-13		163B-4		166D-1
13111-89L00	126A-1		163C-4		166E-1
	126B-1		163D-4		166F-1
	126C-1		163E-4		513A-2
	126D-1		163F-4		513B-2
	126E-1		163G-4		513C-2
	126F-1		163H-4		513D-2
	126G-1		163J-4	13640-32G20	334A-1
	126H-1		163K-4		334B-1
	126J-1		163L-4		334C-1
	126K-1		163M-4		334D-1
	126L-1	13420-16HA0	163A-2		334E-1
	126M-1		163B-2		334F-1
13116-94J00	126A-8		163C-2		334G-1
	126B-8		163D-2		334H-1
	126C-8		163E-2		334J-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
13650-52G00	334K-1		126G-5		146J-25
	334L-1		126H-5		146K-25
	334M-1		126J-5		146L-25
	334A-12		126K-5		146M-25
	334B-11		126L-5	15192-89L00	146A-26
	334C-11	13820-89L00	126M-5		146B-26
	334D-12		126D-9		146C-26
	334E-11		126E-9		146D-26
	334F-11		126F-9		146E-26
	334G-11		126G-9		146F-26
	334H-12	13820-89L10	126A-9		146G-26
	334J-12		126B-9		146H-26
	334K-11		126C-9		146J-26
	334L-11	13831-89L00	126A-11		146K-26
	334M-11		126B-11		146L-26
13655-89L01	334A-13		126C-11		146M-26
	334B-12		126D-11	15192-89L10	146A-27
	334C-12		126E-11		146B-27
	334D-13		126F-11		146C-27
	334E-12		126G-11		146D-27
	334F-12		126H-11		146E-27
	334G-12		126J-11		146F-27
	334H-13		126K-11		146G-27
	334J-13		126L-11		146H-27
	334K-12		126M-11		146J-27
	334L-12	13832-89L00	126H-7		146K-27
13684-89L00	334M-12		126J-7		146L-27
	146A-1		126K-7		146M-27
	146B-1		126L-7	15192-89L20	146A-28
	146C-1		126M-7		146B-28
	146D-1	15100-89L10	146J-24		146C-28
	146E-1		146A-24		146D-28
	146F-1	15100-89L20	146B-24		146E-28
	146G-1		146C-24		146F-28
	146H-1		146D-24		146G-28
	146J-1		146E-24		146H-28
	146K-1		146F-24		146J-28
	146L-1		146G-24		146K-28
	146M-1		146H-24		146L-28
	126H-6		146K-24		146M-28
13710-89L00	126J-6		146L-24	15192-89L30	146A-29
	126K-6		146M-24		146B-29
	126L-6	15191-89L00	146A-25		146C-29
	126M-6		146B-25		146D-29
	126A-5		146C-25		146E-29
13811-89L00	126B-5		146D-25		146F-29
	126C-5		146E-25		146G-29
	126D-5		146F-25		146H-29
	126E-5		146G-25		146J-29
	126F-5		146H-25		146K-29

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
15192-89L40	146L-29	15211-91J00-130	163A-6		146C-35
	146M-29		163B-6		146D-35
	146A-30		163C-6		146E-35
	146B-30		163D-6		146F-35
	146C-30		163E-6		146G-35
	146D-30		163F-6		146H-35
	146E-30		163G-6		146J-35
	146F-30		163H-6		146K-35
	146G-30		163J-6		146L-35
	146H-30		163K-6		146M-35
	146J-30		163L-6	15421-89L01	146A-36
	146K-30		163M-6		146B-36
	146L-30	15217-89L00	146A-3		146C-36
	146M-30		146B-3		146D-36
	146A-31		146C-3		146E-36
15193-89L00	146B-31		146D-3		146F-36
	146C-31		146E-3		146G-36
	146D-31		146H-3		146J-36
	146E-31		146G-3		146K-36
	146F-31		146H-3		146L-36
	146G-31		146J-3		146M-36
	146H-31		146K-3		146N-36
	146J-31		146L-3	15422-89L00	146A-37
	146K-31		146M-3		146B-37
	146L-31		146A-4		146C-37
15194-89L00	146M-31	15218-89L00	146B-4		146D-37
	146A-32		146C-4		146E-37
	146B-32		146D-4		146F-37
	146C-32		146E-4		146G-37
	146D-32		146F-4		146H-37
	146E-32		146G-4		146J-37
	146F-32		146H-4		146K-37
	146G-32		146J-4		146L-37
	146H-32		146K-4		146M-37
	146J-32		146L-4	15600-89L00	146A-5
15200-89L10	146K-32	15410-87L00	146M-4		146B-5
	146L-32		146A-33		146C-5
	146M-32		146B-33		146D-5
	146A-2		146C-33		146E-5
	146B-2		146D-33		146F-5
	146C-2		146E-33		146G-5
	146D-2		146F-33		146H-5
	146E-2		146G-33		146J-5
	146F-2		146H-33		146K-5
	146G-2		146J-33		146L-5
	146H-2		146K-33		146M-5
	146J-2		146L-33	15629-89L00	146A-8
	146K-2		146M-33		146B-8
	146L-2	15419-87J00	146A-35		146C-8
	146M-2		146B-35		146D-8

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
15676-89L00	146E-8	15770-89L01	146A-7	17413-94J00	160F-1
	146F-8		146B-7		160G-1
	146G-8		146C-7		160H-1
	146H-8		146D-7		160J-1
	146J-8		146E-7		160K-1
	146K-8		146F-7		160L-1
	146L-8		146G-7		160M-1
	146M-8		146H-7		160A-2
	146A-44		146J-7		160B-2
	146B-44		146K-7		160C-2
	146C-44	15790-89L00	146L-7		160D-2
	146D-44		146M-7		160E-2
	146E-44		146A-9		160F-2
	146F-44		146B-9		160G-2
	146G-44		146C-9		160H-2
	146H-44		146D-9		160K-2
	146J-44		146E-9		160L-2
	146K-44		146F-9		160M-2
15681-89L00 15685-89L00	146L-44	16400-89L00	146G-9	17413-94J10	160J-2
	146M-44		146H-9	17461-939M0	160A-3
	144A-1		146J-9		160B-3
	146A-38		146K-9		160C-3
15690-89L01	146B-38		146L-9		160D-3
	146C-38		146M-9		160E-3
	146D-38		175A-1		160F-3
	146E-38		175A-12		160G-3
	146F-38		113A-5		160H-3
	146G-38		175A-2		160J-3
	146H-38		16512-99J00		160K-3
	146J-38		16515-89L10		160L-3
	146K-38	16431-89L00	16520-99J00		160M-3
	146L-38		16910-89L01	17471-99J00	160A-4
	146M-38		16930-89L00		160B-4
	146A-6		17400-99J01		160C-4
	146B-6				160D-4
	146C-6				160E-4
	146D-6				160F-4
	146E-6				160G-4
15710-50M00 15716-65DT0 15734-89L00 15735-89L00 15751-89L00	146F-6	16440-11D00	160H-4		160H-4
	146G-6		160I-4		160K-4
	146H-6		160J-4		160L-4
	146J-6		160K-4		160M-4
	146K-6		160L-4		160J-4
	146L-6		160M-4		160A-5
	146M-6		160N-4		160B-5
	144A-2		160O-4		160C-5
15716-65DT0 15734-89L00 15735-89L00 15751-89L00	144A-3	16440-11D00	160P-4		160D-5
	144A-4		160Q-4		160E-5
	144A-5		160R-4		160F-5
	144A-6		160S-4		160G-5
			160T-4		160H-5

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
17473-94J00	160H-5	17563-94J00	160K-7-3	17632-99J30	160M-10
	160J-5		160L-7-3		160A-11
	160K-5		160M-7-3		160B-11
	160L-5		160A-8		160C-11
	160M-5		160B-8		160D-11
	160A-6		160C-8		160E-11
	160B-6		160D-8		160F-11
	160C-6		160E-8		160G-11
	160D-6		160F-8		160H-11
	160E-6		160G-8		160J-11
	160F-6		160H-8		160K-11
	160G-6		160J-8		160L-11
	160H-6		160K-8		160M-11
	160J-6		160L-8		162A-1
	160K-6		160M-8		162A-2
	160L-6		160A-9		162A-7
17561-99J00	160M-6	17564-99J00	160B-9	17670-91J00	162A-5
	160A-7-1		160C-9		162A-4
	160B-7-1		160D-9		162A-1
	160C-7-1		160E-9		162A-2
	160D-7-1		160F-9		162A-3
	160E-7-1		160G-9		162A-4
	160F-7-1		160H-9		162A-5
	160G-7-1		160J-9		162A-6
	160H-7-1		160K-9		162A-7
	160J-7-1		160L-9		162A-8
	160K-7-1		160M-9		162A-9
	160L-7-1		160A-18		162A-10
	160M-7-1		160B-18		162A-11
	160A-7-2		160C-18		162A-12
	160B-7-2		160D-18		162A-13
	160C-7-2		160E-18		162A-14
17561-99J10	160D-7-2	17565-99J00	160F-18	18100-94JN0	162A-15
	160E-7-2		160G-18		162A-16
	160F-7-2		160H-18		162A-17
	160G-7-2		160J-18		162A-18
	160H-7-2		160K-18		162A-19
	160I-7-2		160L-18		162A-20
	160J-7-2		160M-18		162A-21
	160K-7-2		160A-10		162A-22
	160L-7-2		160B-10		162A-23
	160M-7-2		160C-10		162A-24
	160A-7-3		160D-10		162A-25
	160B-7-3		160E-10		162A-26
	160C-7-3		160F-10		162A-27
	160D-7-3		160G-10		162A-28
	160E-7-3		160H-10		162A-29
	160F-7-3		160J-10		162A-30
17561-99J20	160G-7-3	17631-99J20	160K-10	18121-94JL0	162A-31
	160H-7-3		160L-10		162A-32
	160J-7-3				162A-33
	160K-7-3				162A-34
	160L-7-3				162A-35

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
18130-93E01	167G-2	18280-93E00	167J-6	19120-99J11	334K-13
	167H-2		167K-6		334L-13
	167J-2		167L-6		334M-13
	167K-2		167M-6		166A-2
	167L-2		167A-7		166B-2
	167M-2		167B-7		166C-2
	167A-3		167C-7		166D-2
	167B-3		167D-7		166E-2
	167C-3		167E-7		166F-2
	167D-3		167F-7		513A-3
18132-89L00	167E-3	18290-94J01	167G-7	19122-99J00	513B-3
	167F-3		167H-7		513C-3
	167G-3		167J-7		513D-3
	167H-3		167K-7		166A-3
	167J-3		167L-7		166B-3
	167K-3		167M-7		166C-3
	167L-3		167A-10		166D-3
	167M-3		167B-10		166E-3
	167A-5		167C-10		166F-3
	167B-5		167D-10		513A-4
18142-93E00	167C-5	18498-87JC0	167E-10	19131-89L00	513B-4
	167D-5		167F-10		513C-4
	167E-5		167G-10		513D-4
	167F-5		167H-10		166A-4
	167G-5		167J-10		166B-4
	167H-5		167K-10		166C-4
	167J-5		167L-10		166D-4
	167K-5		167M-10		166E-4
	167L-5		146A-10		166F-4
	167M-5		146B-10		513A-5
18210-95L00	167A-4	18590-58M00	146C-10	19148-89L10	513B-5
	167B-4		146D-10		513C-5
	167C-4		146E-10		513D-5
	167D-4		146F-10		166A-5
	167E-4		146G-10		166B-5
	167F-4		146H-10		166C-5
	167G-4		146J-10		166D-5
	167H-4		146K-10		166E-5
	167J-4		146L-10		166F-5
	167K-4		146M-10		513A-6
18122-89L00	167L-4	23111-89L00	162A-8	23111-89L00	513B-6
	167M-4		334A-14		513C-6
	167A-6		334B-13		513D-6
	167B-6		334C-13		166A-6
	167C-6		334D-14		166B-6
	167D-6		334E-13		166C-6
	167E-6		334F-13		166D-6
	167F-6		334G-13		166E-6
	167G-6		334H-14		166F-6
	167H-6		334J-14		513A-7

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
19185-99J00	513B-7	21131-94J00	206C-3	23111-89L10	206F-5-1
	513C-7		206D-3		206G-5-1
	513D-7		206H-3		206H-5-1
	166A-7		206F-3		206J-5-1
	166B-7		206G-3		206K-5-1
	166C-7		206H-3		206L-5-1
	166D-7		206J-3		206M-5-1
	166E-7		206K-3		206A-5-2
	166F-7		206L-3		206B-5-2
	513A-8		206M-3		206C-5-2
20000	513B-8	21210-89L01	444A-36	23115-89L00	206D-5-2
	513C-8		444B-36		206E-5-2
	513D-8		444C-36		206F-5-2
			444D-36		206G-5-2
			444E-36		206H-5-2
			444F-36		206J-5-2
			206A-4		206K-5-2
			206B-4		206L-5-2
			206C-4		206M-5-2
			206D-4		206A-6
21110-89L10	206B-1	22511-99011	206E-4	23115-89L10	206D-6
	206C-1		206F-4		206G-6
	206E-1		206G-4		206H-6
	206F-1		206H-4		206J-6
	206K-1		206J-4		206M-6
	206L-1		206K-4		206B-6
	513A-9		206L-4		206C-6
	513B-9		206M-4		206E-6
	513C-9		336A-1		206F-6
	513D-9		336B-1		206K-6
21111-89L00	206A-1	23211-89L00	336C-1-1	23211-89L00	206L-6
	206D-1		336C-1-2		513A-10
	206G-1		336D-1		513B-10
	206H-1		336E-1		513C-10
	206J-1		336F-1-1		513D-10
	206M-1		336F-1-2		206A-7
	206A-2		336G-1-1		206B-7
	206B-2		336G-1-2		206C-7
	206C-2		336H-1		206D-7
	206D-2		336J-1		206E-7
21122-89L00	206E-2	23111-89L00	336K-1	23311-95J00	206F-7
	206F-2		336L-1-1		206G-7
	206G-2		336L-1-2		206H-7
	206H-2		336M-1-1		206J-7
	206J-2		336M-1-2		206K-7
	206K-2		206A-5-1		206L-7
	206L-2		206B-5-1		206M-7
	206M-2		206C-5-1		210A-1
	206A-3		206D-5-1		25111-99J01
	206B-3		206E-5-1		25111-99J10

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
25211-99JL0	210A-5		336H-21	31151-94J01	301A-4
25215-99J00	210A-6		336J-21	31152-90J00	301A-5
25311-99J00	210A-3		336K-21	31153-90J00	301A-6
29103-93J00	327C-6		336L-11	31170-94J00	301A-17
	327E-6		336M-11	31171-96J00	301A-7
29141-93J00	160A-13	30000		31173-94J01	301A-8
	160B-13			31174-89LA0	340A-2
	160C-13				340B-2
	160D-13				340C-2
	160E-13				340D-2
	160F-13				340E-2
	160G-13	31000-89L04	561A-1	31191-96J00	301A-9
	160H-13		561B-1	31192-94J01	338A-11
	160J-13		561C-1		338B-11
	160K-13		561D-1		338C-11
	160L-13	31100-94J22	301A-1		338D-11
	160M-13		561A-3		338E-11
	210A-7		561B-3	31193-94J00	338A-10
	335A-12		561C-3		338B-10
	335B-12		561D-3		338B-10
	335D-12	31101-89L00	561A-2		338C-10
	335E-12		561B-2		338D-10
	335H-12		561C-2		338E-10
	335J-12	31123-89J10	561D-2	31220-94J00	301A-10
	335K-12		338A-7	31281-94J01	338A-12
	335A-18		338B-7		338B-12
29162-93J10	335B-18		338C-7		338C-12
	335C-22		338D-7		338D-12
	335D-18		338E-7		338E-12
	335E-18	31123-94J01	340A-5	31310-90J00	301A-11
	335F-22		340B-5	31311-94J00	340A-9
	335G-22		340C-5		340B-9
	335H-18		340D-5		340C-9
	335J-18	31131-94J00	340E-5		340D-9
	335K-18	31133-94900	301A-2		340E-9
	335L-22		340A-4	31320-94J00	301A-12
	335M-22		340B-4	31341-94J00	301A-13
29404-93J10	600A-27		340C-4	31343-90J00	301A-14
	600B-27		340D-4	31344-90J00	301A-15
	600C-27		340E-4	31360-93J01	301A-16
	600D-27	31135-90J00	301A-3	31912-89L00	301A-18
	600E-27	31135-94900	340A-7	31918-94J00	301A-19
	600F-27		340B-7	32000-89L00	553A-1
29440-93J00	336A-21		340C-7		553B-1
	336B-21		340D-7		553C-1
	336C-11		340E-7		553D-1
	336D-21	31136-94J00	340A-3	32102-89L00	303E-4
	336E-21		340B-3		561A-4
	336F-11		340C-3		561B-4
	336G-11		340D-3		561C-4
			340E-3		561D-4

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
32102-89L10	303A-4		561B-7		310C-9
	303B-4		561C-7		310D-9
	303C-4		561D-7		310E-9
	303D-4	32815-89L10	553A-4		310F-9
32120-89L00	303E-1		553B-4		310G-9
	561A-5		553C-4		310H-9
	561B-5		553D-4		310J-9
	561C-5	32890-89L01	310A-4		310K-9
	561D-5		310B-4		310L-9
32120-89L10	303A-1		310C-4		310M-9
	303B-1		310D-4	33634-96J00	322A-13
	303C-1		310E-4		322B-8
32800-89L00	303D-1		310F-4		322C-8
	310A-1		310G-4		322D-13
	310B-1		310H-4		322E-8
	310C-1		310J-4		322F-8
	310D-1		310K-4		322G-13
	310E-1		310L-4		322H-13
	310F-1		310M-4		322J-13
	310G-1	32916-89L00	322A-11		322K-8
	310H-1		322B-7		322L-8
	310J-1		322C-7		322M-13
	310K-1		322D-11	33799-97E00	340A-6
	310L-1		322E-7		340B-6
	310M-1		322F-7		340C-6
	561A-6		322G-11		340D-6
	561B-6		322H-11		340E-6
	561C-6		322J-11	33800-89L01	561A-12
	561D-6		322K-7		561B-12
32800-94J11	553A-3		322L-7		561C-12
	553B-3		322M-11		561D-12
	553C-3	33220-84M10	303A-9	33810-89L02	322A-1
	553D-3		303B-9		322B-1
32801-89L00	553A-2		303C-9		322C-1
	553B-2		303D-9		322D-1
	553C-2		303E-9		322E-1
	553D-2	33410-89L10	310A-11		322F-1
32815-89L00	310A-2		310B-11		322G-1
	310B-2		310C-11		322H-1
	310C-2		310D-11		322J-1
	310D-2		310E-11		322K-1
	310E-2		310F-11		322L-1
	310F-2		310G-11		322M-1
	310G-2		310H-11		561A-13
	310H-2		310J-11		561B-13
	310J-2		310K-11		561C-13
	310K-2		310L-11		561D-13
	310L-2		310M-11	33833-91J00	444A-21
	310M-2	33500-07H00	310A-9		444B-21
	561A-7		310B-9		444C-21

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
33920-89L80	444D-21	34100-93J32	501D-10-1	34193-96L00	501F-12
	444E-21		501E-10-1		600A-4
	444F-21		501F-10-1		600B-4
	310D-13-1		501A-10-2		600C-4
33920-89L90	310E-13	34100-93J41	501B-10-2	34200-93J21	600D-4
	310F-13		501C-10-2		600E-4
	310G-13		501D-10-2		600F-4
	561B-24		501E-10-2		501A-18-1
33920-89LA0	310D-13-2	34100-93J52	501F-10-2	34200-93J33	501B-18-1
	310H-13-1		501A-10-3		501C-18-1
	310K-13		501B-10-3		501D-18-1
	310L-13		501C-10-3		501E-18-1
33920-89LB0	310M-13	34100-93J52	501D-10-3	34211-96L00	501F-18-1
	561C-24		501E-10-3		501A-18-2
	310H-13-2		501F-10-3		501B-18-2
	33920-89LC0		501A-10-4		501C-18-2
33920-89LD0	310A-13-1	34112-96L00	501B-10-4	34300-93J01	501D-18-2
	310B-13		501C-10-4		501E-18-2
	310C-13		501D-10-4		501F-18-2
	561A-24		501E-10-4	34300-93J12	600A-5
33920-89LE0	310J-13-1	34190-87D00	501F-10-4		600B-5
	561D-24		600A-3		600C-5
	310J-13-2		600B-3		600D-5
	310A-14		600C-3		600E-5
33920-89LF0	310B-14	34190-88L00	600D-3	34310-92E00	600F-5
	310C-14		600E-3		501A-20-1
	310D-14		600F-3		501B-20-1
	310E-14		501A-17		501C-20-1
34000-96L00	310F-14	34190-95500	501B-17	34360-92E00	501D-20-1
	310G-14		501C-17		501E-20-1
	310H-14		501D-17		501F-20-1
	310J-14		501E-17	34500-93J01	501A-20-2
34011-96L00	310K-14	34191-92E00	501F-17		501B-20-2
	310L-14		600A-17		501C-20-2
	310M-14		600B-17		501D-20-2
	600A-1		600C-17	34367-89L00	501E-20-2
34000-96L00	600B-1	34190-92E00	600D-17		501F-20-2
	600C-1		600E-17		501A-21
	600D-1		600F-17		501B-21
	600E-1		501A-15		501C-21
34011-96L00	600F-1	34190-92E00	501B-15		501D-21
	600A-2		501C-15		501E-21
	600B-2		501D-15		501F-21
	600C-2		501E-15		501A-22
34100-93J21	600D-2		501F-15		501B-22
	600E-2		501A-12		501C-22
	600F-2		501B-12		501D-22
	501A-10-1		501C-12		501E-22
34100-93J21	501B-10-1		501D-12		501F-22
	501C-10-1		501E-12		501A-4-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
34500-93J12	501B-4-1	36610-89L04	334D-4	36610-89L14	501B-24
	501C-4-1		334E-4		501C-6
	501D-4-1		334F-4		501C-9
	501E-4-1		334G-4		501C-14
34600-93J01	501F-4-1	36610-89L23	334H-4	36616-89L03	501C-24
	501A-4-2		334J-4		501D-6
	501B-4-2		334K-4		501D-9
	501C-4-2		334L-4		501D-14
34600-93J12	501D-4-2	36610-89L42	334M-4	36615-96300	501D-24
	501E-4-2		322A-5-1		501E-6
	501F-4-2		322D-5-1		501E-9
	501A-7-1		322H-5-1		501E-14
34825-96L00	501B-7-1	36610-89L52	322J-5-1	36617-89L10	501E-24
	501C-7-1		561A-19		501F-6
	501D-7-1		561B-19		501F-9
	501E-7-1		561C-19		501F-14
36001-88L00	501F-7-1	36610-89L01	561D-19	36617-89L10	501F-24
	501A-7-2		322A-5-2		600A-8
	501B-7-2		322D-5-2		600B-8
	501C-7-2		322H-5-2		600C-8
36360-99J10	501D-7-2	36610-89L23	322J-5-2	36617-89L10	600D-8
	501E-7-2		322B-2		600E-8
	501F-7-2		322E-2		600F-8
	600A-6		322K-2		334A-10
36001-88L00	600B-6	36610-89L42	513A-11	36617-89L10	334B-9
	600C-6		513B-11		334C-9
	600D-6		513C-11		334D-10
	600E-6		513D-11		334E-9
36001-88L00	600F-6	36610-89L52	322G-5	36617-89L10	334F-9
	600A-11		322M-5		334G-9
	600B-11		322C-2		334H-10
	600C-11		322F-2		334J-10
36360-99J10	600D-11	36615-96300	322L-2	36617-89L10	334K-9
	600E-11		303A-12		334L-9
	600F-11		303B-12		334M-9
	334A-3		303C-12		322A-14
36367-89L00	334B-3	36617-89L10	303D-12	36617-89L10	322B-9
	334C-3		322A-9		322D-14
	334D-3		322D-9		322E-9
	334E-3		322G-9		322H-14
36367-89L00	334F-3	36617-89L10	322H-9	36617-89L10	322J-14
	334G-3		322J-9		322K-9
	334H-3		322M-9		322A-12
	334J-3		501A-6		322D-12
36367-89L00	334K-3	36617-89L10	501A-9	36617-89L10	322G-12
	334L-3		501A-14		322H-12
	334M-3		501A-24		322J-12
	334A-4		501B-6		322M-12
36367-89L00	334B-4	36617-89L10	501B-9	36617-89L10	561A-14
	334C-4		501B-14		561B-14

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
36617-89L20	561C-14		322C-19-2		600A-18
	561D-14		322E-17-2		600B-12
	322C-10		322F-19-2		600B-18
	322F-10		322K-17-2		600C-12
	322L-10		322L-19-2		600C-18
36617-89L30	322C-9	36620-94J01	450A-52		600D-12
	322F-9		450C-52		600D-18
	322G-14		450E-52		600E-12
	322L-9		546A-1		600E-18
	322M-14		546B-1		600F-12
36617-89L40	322C-17		546C-1		600F-18
	322F-17		546D-1	36662-88L20	600A-19
	322G-22		546E-1		600B-19
	322L-17		546F-1		600C-19
	322M-22	36628-92E00	450A-2		600D-19
36617-91J00	322A-15		450B-3		600E-19
	322B-10		450C-2		600F-19
	322D-15		450D-3	36662-88L30	600A-20
	322E-10		450E-2		600B-20
	322G-15		450F-3		600C-20
36618-43410	322H-15		508A-2		600D-20
	322J-15		508B-2		600E-20
	322K-10		508C-2		600F-20
	322M-15		508D-2	36663-88L00	600A-13
	322A-8	36634-93910	553A-13		600A-23
36618-43410	322B-5		553B-13		600B-13
	322C-5		553C-13		600B-23
	322D-8		553D-13		600C-13
	322E-5	36646-93J01	450B-2		600C-23
	322F-5		450D-2		600D-13
36618-43410	322G-8		450F-2		600D-23
	322H-8	36660-89L01	600A-26		600E-13
	322J-8		600B-26		600E-23
	322K-5		600C-26		600F-13
	322L-5		600D-26		600F-23
36620-93J02	322M-8		600E-26	36663-98J00	501A-2-1
	513A-12		600F-26		501B-2-1
	513B-12	36661-96L10	600A-7		501C-2-1
	513C-12		600B-7		501D-2-1
	513D-12		600C-7		501E-2-1
36620-93J02	450B-54		600D-7		501F-2-1
	450D-54		600E-7	36663-98J10	501A-2-2
	450F-54		600F-7		501B-2-2
	322B-17-1	36662-88L00	600A-21		501C-2-2
	322C-19-1		600B-21		501D-2-2
36620-93J10	322E-17-1		600C-21		501E-2-2
	322F-19-1		600D-21		501F-2-2
	322K-17-1		600E-21		600A-9
	322L-19-1		600F-21		600B-9
	322B-17-2	36662-88L10	600A-12		600C-9

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
36664-88L00	600D-9		544H-16		530F-17
	600E-9		544J-16	37110-93J01	530A-2
	600F-9		544K-16		530A-18
	600A-14	36894-87D00	335C-9		530B-2
	600B-14		335C-10		530B-18
36665-88L00	600C-14		335F-9		530C-2
	600D-14		335F-10		530C-18
	600E-14		335G-9		530D-2
	600F-14		335G-10		530D-18
	600A-15		335L-9		530E-2
36665-88L00	600A-24		335L-10		530E-18
	600B-15		335M-9		530F-2
	600B-24		335M-10		530F-18
	600C-15	36895-87D01	335C-11	37110-93J11	450B-4
	600C-24		335F-11		450D-4
36665-88L10	600D-15		335G-11		450F-4
	600D-24		335L-11	37110-94J02	450A-3
	600E-15		335M-11		450C-3
	600E-24	36990-87D00	546A-3		450E-3
	600F-15		546B-3		508A-3
36665-88L10	600F-24		546C-3		508B-3
	600A-16		546D-3		508C-3
	600A-25		546E-3		508D-3
	600B-16		546F-3	37139-99E00	530A-6
	600B-25		553A-17		530B-6
36665-88L10	600C-16		553B-17		530C-6
	600C-25		553C-17		530D-6
	600D-16		553D-17		530E-6
	600D-25		600A-29		530F-6
	600E-16		600B-29	37139-99E20	530A-22
36665-88L10	600E-25		600C-29		530B-22
	600F-16		600D-29		530C-22
	600F-25		600E-29		530D-22
	501A-1		600F-29		530E-22
	501B-1	36991-91J00	322C-18		530F-22
36665-88L10	501C-1		322F-18	37141-99E00	450A-4-1
	501D-1		322G-23		450B-5-1
	501E-1		322L-18		450C-4-1
	501F-1		322M-23		450D-5-1
	553A-10	37100-96J00	530A-1		450E-4-1
36670-94J00	553B-10		530B-1		450F-5-1
	553C-10		530C-1		508A-4-1
	553D-10		530D-1		508B-4-1
	544A-16		530E-1		508C-4-1
	544B-16		530F-1		508D-4-1
36890-93J00	544C-16	37100-96J24	530A-17		530A-3-1
	544D-16		530B-17		530A-19-1
	544E-16		530C-17		530B-3-1
	544F-16		530D-17		530B-19-1
	544G-16		530E-17		530C-3-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	530C-19-1	37141-99E30	530F-19-3		450F-5-6
	530D-3-1		450A-4-4		508A-4-6
	530D-19-1		450B-5-4		508B-4-6
	530E-3-1		450C-4-4		508C-4-6
	530E-19-1		450D-5-4		508D-4-6
37141-99E10	530F-3-1		450E-4-4		530A-3-6
	530F-19-1		450F-5-4		530A-19-6
	450A-4-2		508A-4-4		530B-3-6
	450B-5-2		508B-4-4		530B-19-6
	450C-4-2		508C-4-4		530C-3-6
	450D-5-2		508D-4-4		530C-19-6
	450E-4-2		530A-3-4		530D-3-6
	450F-5-2		530A-19-4		530D-19-6
	508A-4-2		530B-3-4		530E-3-6
	508B-4-2		530B-19-4		530E-19-6
	508C-4-2		530C-3-4		530F-3-6
	508D-4-2		530C-19-4	37141-99E60	530F-19-6
	530A-3-2		530D-3-4		450A-4-7
	530A-19-2		530D-19-4		450B-5-7
	530B-3-2		530E-3-4		450C-4-7
	530B-19-2		530E-19-4		450D-5-7
	530C-3-2	37141-99E40	530F-3-4		450E-4-7
	530C-19-2		530F-19-4		450F-5-7
	530D-3-2		450A-4-5		508A-4-7
	530D-19-2		450B-5-5		508B-4-7
	530E-3-2		450C-4-5		508C-4-7
	530E-19-2		450D-5-5		508D-4-7
	530F-3-2		450E-4-5		530A-3-7
	530F-19-2		450F-5-5		530A-19-7
37141-99E20	450A-4-3		508A-4-5		530B-3-7
	450B-5-3		508B-4-5		530B-19-7
	450C-4-3		508C-4-5		530C-3-7
	450D-5-3		508D-4-5		530C-19-7
	450E-4-3		530A-3-5		530D-3-7
	450F-5-3		530A-19-5		530D-19-7
	508A-4-3		530B-3-5		530E-3-7
	508B-4-3		530B-19-5		530E-19-7
	508C-4-3		530C-3-5		530F-3-7
	508D-4-3		530C-19-5		530F-19-7
	530A-3-3		530D-3-5	37141-99E70	450A-4-8
	530A-19-3		530D-19-5		450B-5-8
	530B-3-3		530E-3-5		450C-4-8
	530B-19-3		530E-19-5		450D-5-8
	530C-3-3		530F-3-5		450E-4-8
	530C-19-3		530F-19-5		450F-5-8
	530D-3-3	37141-99E50	450A-4-6		508A-4-8
	530D-19-3		450B-5-6		508B-4-8
	530E-3-3		450C-4-6		508C-4-8
	530E-19-3		450D-5-6		508D-4-8
	530F-3-3		450E-4-6		530A-3-8

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	530A-19-8		530D-19-10		450B-6
	530B-3-8		530E-3-10		450C-5
	530B-19-8		530E-19-10		450D-6
	530C-3-8		530F-3-10		450E-5
	530C-19-8		530F-19-10		450F-6
	530D-3-8	37141-99EA0	450A-4-11		508A-5
	530D-19-8		450B-5-11		508B-5
	530E-3-8		450C-4-11		508C-5
	530E-19-8		450D-5-11		508D-5
	530F-3-8		450E-4-11		530A-4
	530F-19-8		450F-5-11		530A-20
37141-99E80	450A-4-9		508A-4-11		530B-4
	450B-5-9		508B-4-11		530B-20
	450C-4-9		508C-4-11		530C-4
	450D-5-9		508D-4-11		530C-20
	450E-4-9		530A-3-11		530D-4
	450F-5-9		530A-19-11		530D-20
	508A-4-9		530B-3-11		530E-4
	508B-4-9		530B-19-11		530E-20
	508C-4-9		530C-3-11		530F-4
	508D-4-9		530C-19-11		530F-20
	530A-3-9		530D-3-11	37149-93J00	450A-6
	530A-19-9		530D-19-11		450B-7
	530B-3-9		530E-3-11		450C-6
	530B-19-9		530E-19-11		450D-7
	530C-3-9		530F-3-11		450E-6
	530C-19-9		530F-19-11		450F-7
	530D-3-9	37141-99EB0	450A-4-12		508A-6
	530D-19-9		450B-5-12		508B-6
	530E-3-9		450C-4-12		508C-6
	530E-19-9		450D-5-12		508D-6
	530F-3-9		450E-4-12		530A-5
37141-99E90	530F-19-9		450F-5-12		530A-21
	450A-4-10		508A-4-12		530B-5
	450B-5-10		508B-4-12		530B-21
	450C-4-10		508C-4-12		530C-5
	450D-5-10		508D-4-12		530C-21
	450E-4-10		530A-3-12		530D-5
	450F-5-10		530A-19-12		530D-21
	508A-4-10		530B-3-12		530E-5
	508B-4-10		530B-19-12		530E-21
	508C-4-10		530C-3-12		530F-5
	508D-4-10		530C-19-12		530F-21
	530A-3-10		530D-3-12	37161-89L01	334A-5
	530A-19-10		530D-19-12		334D-5
	530B-3-10		530E-3-12		334G-5
	530B-19-10		530E-19-12		334H-5
	530C-3-10		530F-3-12		334J-5
	530C-19-10		530F-19-12		334M-5
	530D-3-10	37143-99E00	450A-5		561A-15

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
37163-89L00	561B-15	37725-89L01	545G-11	37820-93J04	450A-7
	561C-15		545H-11		450B-9
	561D-15		545J-11		450C-7
	334A-6		545K-11		450D-9
	334B-5		334A-11		450E-7
	334C-5		334B-10		450F-9
	334D-6		334C-10		508A-7
	334E-5		334D-11		508B-7
	334F-5		334E-10		508C-7
	334H-6		334F-10		508D-7
	334J-6		334G-10		530A-10
	334K-5		334H-11		530A-23
	334L-5		334J-11		530B-10
	513A-15		334K-10		530B-23
	513B-15		334L-10		530C-10
37210-93J00	513C-15	37726-89L00	334M-10		530C-23
	513D-15		334A-8		530D-10
	530A-15		334B-7		530D-23
	530B-15		334C-7		530E-10
	530C-15		334D-8		530E-23
37212-93J00	530D-15		334E-7	37823-92E01	530F-10
	530E-15		334F-7		530F-23
	530F-15		334G-7		450A-8
	530A-16		334H-8		450B-10
	530B-16		334J-8		450C-8
37721-89L00	530C-16	37801-98300	334K-7		450D-10
	530D-16		334L-7		450E-8
	530E-16		334M-7		450F-10
	530F-16		553A-11		508A-8
	334A-7		553B-11		508B-8
	334B-6	37803-93J04	553C-11		508C-8
	334C-6		553D-11		508D-8
	334D-7		530A-9		530A-11
	334E-6		530B-9		530A-24
	334F-6		530C-9		530B-11
	334G-6	37820-80002	530D-9		530B-24
	334H-7		530E-9		530C-11
	334J-7		530F-9		530C-24
	334K-6		334A-2		530D-11
	334L-6		334B-2		530D-24
37721-93J91	334M-6		334C-2		530E-11
	450B-8		334D-2		530E-24
	450D-8		334E-2		530F-11
	450F-8		334F-2		530F-24
	545A-11		334G-2		444A-33
37721-95500	545B-11		334H-2	37823-97J00	444B-33
	545C-11		334J-2		444C-33
	545D-11		334K-2		444D-33
	545E-11		334L-2		444E-33
	545F-11		334M-2		444F-33

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
37825-99E00	530A-13		544B-4	38415-89L00	327A-2
	530B-13		544C-4		327B-2
	530C-13		544D-4		327C-2
	530D-13		544E-4		327D-2
	530E-13		544F-4		327E-2
37826-92J00	530F-13		544G-4	38500-93J00	450A-12
	450A-9		544H-4		450C-12
	450B-11		544J-4		450E-12
	450C-9		544K-4		508A-12
	450D-11		327C-3		508B-12
	450E-9	37850-94JA2	327E-3	38500-93J90	508C-12
	450F-11		327A-3		508D-12
	508A-9		327B-3		450B-13
	508B-9		327D-3		450D-13
	508C-9		327C-10		450F-13
	508D-9	37851-89L00	327E-10		530A-7
	530A-12		327C-4		530A-27
	530A-25		327E-4		530B-7
	530B-12		450A-10		530B-27
	530B-25		450B-51		530C-7
	530C-12		450C-10		530C-27
	530C-25		450D-51		530D-7
	530D-12		450E-10		530D-27
	530D-25		450F-51		530E-7
	530E-12		508A-10		530E-27
37826-97J00	530E-25	37864-94J10	508B-10	38860-76F01	530F-7
	530F-12		508C-10		530F-27
	530F-25		508D-10		301A-20
	444A-34		450A-11		310A-15
	444B-34		450C-11		310B-15
	444C-34		450E-11		310C-15
	444D-34		508A-11		310D-15
	444E-34		508B-11		310E-15
	444F-34		508C-11		310F-15
	444A-32		508D-11		310G-15
37830-89L01	444B-32	38100-89LA0	338A-14		310H-15
	444C-32		338B-14		310J-15
	444D-32		338C-14		310K-15
	444E-32		338D-14		310L-15
	444F-32		338E-14		310M-15
37835-95D00	444A-35		340A-1		561A-20
	444B-35		340B-1		561B-20
	444C-35		340C-1		561C-20
	444D-35		340D-1		561D-20
	444E-35		340E-1		301A-21
	444F-35	38410-93J20	327A-1		310A-16
	450B-12		327B-1		310B-16
	450D-12		327C-1		310C-16
	450F-12		327D-1		310D-16
	544A-4		327E-1		310E-16

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	310F-16		335E-2		335J-25
	310G-16		335H-2		335K-25
	310H-16		335J-2	41211-95J00	335C-4
	310J-16		335K-2		335F-4
	310K-16	41121-89LA0-0EP	335C-2		335G-4
	310L-16		335F-2		335L-4
	310M-16		335G-2	41211-99JL0	335M-4
	561A-21		335L-2		335A-3
	561B-21		335M-2		335B-3
	561C-21	41130-89L00	335B-7		335D-3
39600-89L00	561D-21		335E-7		335E-3
	553A-9		335K-7		335H-3
	553B-9		513A-16		335J-3
	553C-9		513B-16		335K-3
	553D-9		513C-16	41212-91J00	335A-4
39601-95D00	553A-12		513D-16		335B-4
	553B-12	41130-90L00	335A-7		335C-5
	553C-12		335D-7		335D-4
	553D-12		335H-7		335E-4
39602-93900	553A-14		335J-7		335F-5
	553B-14	41130-94JA1	335C-7		335G-5
	553C-14		335F-7		335H-4
	553D-14		335G-7		335J-4
39950-88L01	600A-22		335L-7		335K-4
	600B-22		335M-7		335L-5
	600C-22	41135-93J11	335C-8		335M-5
	600D-22		335F-8	41213-94J01	335A-5
	600E-22		335G-8		335B-5
	600F-22		335L-8		335C-6
			335M-8		335D-5
		41161-94400	442A-1		335E-5
			442B-1		335F-6
			442C-1		335G-6
			442D-1		335H-5
			442E-1		335J-5
41111-89L00-0EP	335A-1		442F-1		335K-5
	335B-1		575A-1		335L-6
	335D-1		575B-1		335M-6
	335E-1		575C-1	41221-94JA0	335C-14
	335H-1		575D-1		335F-14
	335J-1	41210-89LA0	335C-28		335G-14
41111-89LA0-0EP	335K-1		335F-28		335L-14
	335C-1		335G-28		335M-14
	335F-1		335L-28	41222-94JA0	335C-15
	335G-1		335M-28		335F-15
	335L-1	41210-99JL1	335A-25		335G-15
	335M-1		335B-25		335L-15
41121-89L00-0EP	335A-2		335D-25		335M-15
	335B-2		335E-25	41225-89L00	336A-9
	335D-2		335H-25		336B-9

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	336D-9		336J-27		336M-18
	336E-9	43411-89LA0	336G-14	43515-88L00	336A-32
	336H-9		336M-14		336D-32
	336J-9	43411-939L0	336A-19		336G-19
	336K-9		336B-19		336H-32
41226-94JA0	335C-16		336C-9		336J-32
	335F-16		336D-19		336M-19
	335G-16		336E-19	43516-89J00	336A-33
	335L-16		336F-9		336D-33
	335M-16		336G-9		336G-20
43111-89L00-0EP	336A-2-1		336H-19		336H-33
	336B-2-1		336J-19		336J-33
	336D-2-1		336K-19		336M-20
	336E-2-1		336L-9	43517-89L00	336A-34
	336H-2-1		336M-9		336D-34
	336J-2-1	43412-93900	336A-20		336G-21
43111-89L11-0EP	336K-2-1		336B-20		336H-34
	336A-2-2		336C-10		336J-34
	336B-2-2		336D-20		336M-21
	336D-2-2		336E-20	43711-94JA0	336C-3
	336E-2-2		336F-10		336F-3
	336H-2-2		336G-10		336G-3
	336J-2-2		336H-20		336L-3
	336K-2-2		336J-20		336M-3
43111-89LA0-0EP	336C-2-2		336K-20	43711-99J00	336A-3
	336F-2-2		336L-10		336B-3
	336G-2-2		336M-10		336D-3
	336L-2-2	43415-89L00	336A-28		336E-3
	336M-2-2		336D-28		336H-3
43111-89LB0-0EP	336C-2-1		336G-15		336J-3
	336F-2-1		336H-28		336K-3
	336G-2-1		336J-28	43750-99J60-0EP	336A-4-1
	336L-2-1		336M-15		336B-4-1
	336M-2-1	43420-89L00	336A-29		336C-4-1
43112-99E00	405A-4		336D-29		336D-4-1
43211-87JL0	336A-7		336G-16		336E-4-1
	336B-7		336H-29		336F-4-1
	336C-7		336J-29		336G-4-1
	336D-7		336M-16		336H-4-1
	336E-7	43425-89L00	336A-30		336J-4-1
	336F-7		336D-30		336K-4-1
	336G-7		336G-17		336L-4-1
	336H-7		336H-30		336M-4-1
	336J-7		336J-30	43750-99J70-0EP	336A-4-2
	336K-7		336M-17		336B-4-2
	336L-7	43512-89L00	336A-31		336C-4-2
	336M-7		336D-31		336D-4-2
43411-89L00	336A-27		336G-18		336E-4-2
	336D-27		336H-31		336F-4-2
	336H-27		336J-31		336G-4-2

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	336H-4-2		336H-14	45710-89L10	336A-24-2
	336J-4-2		336J-14		336B-24-2
	336K-4-2	45250-89L03	336K-14		336D-24-2
	336L-4-2		336A-15		336E-24-2
	336M-4-2		336B-15		336H-24-2
43755-99J00	336B-27		336D-15		336J-24-2
	336C-14		336E-15	45722-94J11	336K-24-2
	336E-27		336H-15		336A-25
	336F-14		336J-15		336B-25
	336K-27		336K-15		336D-25
	336L-14	45261-89L00	335A-13		336E-25
	513A-17		335B-13		336H-25
	513B-17		335D-13		336J-25
	513C-17		335E-13		336K-25
	513D-17		335H-13	48000-89LA0	338A-1
43759-89L00	336B-31		335J-13		338B-1
	336C-18		335K-13		338C-1
	336E-31	45269-89L00	335A-23		338D-1
	336F-18		335B-23		338E-1
	336K-31		335D-23	48121-94JA0	338A-16
	336L-18		335E-23		338B-16
	513A-18		335H-23		338C-16
	513B-18		335J-23		338D-16
	513C-18		335K-23		338E-16
	513D-18	45420-89L00	335A-19	48321-97E01	338A-17
45212-89L00	336A-10		335B-19		338B-17
	336B-10		335D-19		338C-17
	336D-10		335E-19		338D-17
	336E-10		335H-19		338E-17
	336H-10		335J-19	48325-97E00	338A-18
	336J-10		335K-19		338B-18
45231-89L00	336K-10	45421-94JA0	335C-17		338C-18
	336A-11		335F-17		338D-18
	336B-11		335G-17		338E-18
	336D-11		335L-17	48510-94600	338A-5
	336E-11		335M-17		338B-5
	336H-11	45425-94J01	335A-20		338C-5
	336J-11		335B-20		338D-5
	336K-11		335D-20		338E-5
45241-89L00	336A-12		335E-20	48553-88L00	338A-4
	336B-12		335H-20		338B-4
	336D-12		335J-20		338C-4
	336E-12		335K-20		338D-4
	336H-12	45710-89L00	336A-24-1		338E-4
	336J-12		336B-24-1	48572-94J00	338A-8
	336K-12		336D-24-1		338B-8
45247-99J00	336A-14		336E-24-1		338C-8
	336B-14		336H-24-1		338D-8
	336D-14		336J-24-1		338E-8
	336E-14		336K-24-1	48582-97E00	338A-13

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	338B-13		410D-17		336F-20-2
	338C-13		410E-17		336G-25-2
	338D-13		410F-17		336L-20-2
	338E-13		410G-17		336M-25-2
48583-95E00	338A-6		410H-17		338A-19-2
	338B-6		410J-17		338B-19-2
	338C-6		410K-17		338C-19-2
	338D-6		410L-17		338D-19-2
	338E-6		410M-17		338E-19-2
48664-87D00	338A-9	54145-89L01	410A-18		407A-23
	338A-15		410B-18	55331-99J10	407A-21
	338B-9		410C-18	55332-99J10	407A-22
	338B-15		410D-18	56120-99J41-0EP	407A-10
	338C-9		410E-18	56130-99J30	220A-21
	338C-15		410F-18		220B-21
	338D-9		410G-18		220C-21
	338D-15		410H-18		220D-21
	338E-9		410J-18		220E-21
	338E-15		410K-18		220F-21
48681-87J11	338A-3		410L-18		220G-21
	338B-3		410M-18		220H-21
	338C-3	54151-99J00	405A-10		220J-21
	338D-3	54167-99J01	405A-11		220K-21
	338E-3	54211-99J01-0EP	405A-12		220L-21
48864-89LA0	338A-2	54213-93901	405A-14		220M-21
	338B-2	54221-99J01-0EP	405A-13	56132-99J10	220A-23
	338C-2	55100-99J40-0EP	407A-1		220B-23
	338D-2	55321-87J01	111A-7		220C-23
	338E-2		335C-20-1		220D-23
			335F-20-1		220E-23
			335G-20-1		220F-23
			335L-20-1		220G-23
			335M-20-1		220H-23
			336C-20-1		220J-23
			336F-20-1		220K-23
51110-89L02	401A-1		336G-25-1		220L-23
51211-89L00	401A-2		336L-20-1		220M-23
52110-89L00-0EP	405A-3-1		336M-25-1	57100-90L30	220A-1-2
52110-89L10-0EP	405A-3-2		338A-19-1		220B-1-2
52113-89L00	405A-5		338B-19-1		220C-1-2
52131-89L00-0EP	405A-16		338C-19-1		220D-1-2
54112-99J01	401A-7		338D-19-1		220E-1-2
54113-99J00	401A-8		338E-19-1		220F-1-2
54125-99J00	401A-10		407A-6		220G-1-2
54127-89L00	401A-9	55321-87J11	335C-20-2		220H-1-2
54130-89L00	401A-11		335F-20-2		220J-1-2
54137-89L00	401A-12		335G-20-2		220K-1-2
54144-89L11	410A-17		335L-20-2		220L-1-2
	410B-17		335M-20-2		220M-1-2
	410C-17		336C-20-2	57100-90L40	220A-1-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	220B-1-1		220D-10		220E-20
	220C-1-1		220E-10		220F-20
	220D-1-1		220F-10		220G-20
	220E-1-1		220G-10		220H-20
	220F-1-1		220H-10		220J-20
	220G-1-1		220J-10		220K-20
	220H-1-1		220K-10		220L-20
	220J-1-1		220L-10		220M-20
	220K-1-1		220M-10	58100-89L00-019	407A-15-1
	220L-1-1	57610-99JL0	220A-14	58100-89L20-019	407A-15-2
57100-90L50	220M-1-1		220B-14	58100-89L40-019	407A-15-4
	220A-1-3		220C-14	58100-89L50-019	407A-15-5
	220B-1-3		220D-14	58100-89L60-019	407A-15-3
	220C-1-3		220E-14	58100-90L40-019	407A-15-6
	220D-1-3		220F-14	58100-90L50-019	407A-15-7
	220E-1-3		220G-14	58100-90L60-019	407A-15-8
	220F-1-3		220H-14	58120-89L00	407A-16
	220G-1-3		220J-14	59178-97J00	407A-8
	220H-1-3		220K-14	59262-94J00	175A-13
	220J-1-3		220L-14	59441-94J00	220A-17
	220K-1-3		220M-14		220B-17
	220L-1-3	57621-99J11	220A-15		220C-17
57311-99J10	220M-1-3		220B-15		220D-17
	220A-8		220C-15		220E-17
	220B-8		220D-15		220F-17
	220C-8		220E-15		220G-17
	220D-8		220F-15		220H-17
	220E-8		220G-15		220J-17
	220F-8		220H-15		220K-17
	220G-8		220J-15		220L-17
	220H-8		220K-15		220M-17
	220J-8		220L-15	59441-99J00	220A-18
	220K-8		220M-15		220B-18
	220L-8	57631-93901	220A-19		220C-18
	220M-8		220B-19		220D-18
57510-99J11	220A-9		220C-19		220E-18
	220B-9		220D-19		220F-18
	220C-9		220E-19		220G-18
	220D-9		220F-19		220H-18
	220E-9		220G-19		220J-18
	220F-9		220H-19		220K-18
	220G-9		220J-19		220L-18
	220H-9		220K-19		220M-18
	220J-9		220L-19	59800-89L01	420A-12
	220K-9		220M-19		420B-12
	220L-9	57632-94J00	407A-17		420C-12
57521-99J10	220M-9	57632-98501	220A-20		420D-12
	220A-10		220B-20		420E-12
	220B-10		220C-20		420F-12
	220C-10		220D-20		420G-12

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	420H-12	61151-91J11	146A-43		420C-2
	420J-12		146B-43		420D-2
	420K-12		146C-43		420E-2
	420L-12		146D-43		420F-2
	420M-12		146E-43		420G-2
			146F-43		420H-2
			146G-43		420J-2
			146H-43		420K-2
			146J-43		420L-2
			146K-43		420M-2
			146L-43	61435-89L00	420H-8
61112-89L10	410A-4		146M-43		420J-8
	410B-4		410A-14		420K-8
	410C-4		410B-14		420L-8
	410D-4		410C-14		420M-8
	410E-4		410D-14	61435-94J30	420D-8
	410F-4		410E-14		420E-8
	410G-4		410F-14		420F-8
	410H-4		410G-14		420G-8
	410J-4		410H-14	61435-99J10	420A-8
	410K-4		410J-14		420B-8
	410L-4		410K-14		420C-8
61124-89L20	410M-4		410L-14	61443-99J00	420A-5
	410B-13		410M-14		420B-5
	410E-13		420A-1		420C-5
	410K-13	61400-89L10-0EP	420B-1		420D-5
	513A-21		420C-1		420E-5
	513B-21		420D-1		420F-5
	513C-21		420E-1		420G-5
	513D-21		420F-1		420H-5
61124-89L30	410C-13		420G-1		420J-5
	410F-13		420H-1		420K-5
	410L-13		420J-1		420L-5
61124-89L40	410A-13		420K-1		420M-5
	410D-13		420L-1	61446-89L00	420A-9
	410G-13		420M-1		420B-9
	410H-13		410A-9		420C-9
	410J-13	61412-89L00	410B-9		420D-9
	410M-13		410C-9		420E-9
61134-89L00	410A-5		410D-9		420F-9
	410B-5		410E-9		420G-9
	410C-5		410F-9		420H-9
	410D-5		410G-9		420J-9
	410E-5		410H-9		420K-9
	410F-5		410J-9		420L-9
	410G-5		410K-9		420M-9
	410H-5		410L-9	61447-94J00	420C-14
	410J-5		410M-9		420F-14
	410K-5	61433-89L01	420A-2		420G-14
	410L-5		420B-2		420L-14
	410M-5				

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
61453-99J00	420M-14	126B-12	410E-1	61810-89L10-RB4	410C-1
	420A-6	126C-12	410H-1		410F-1
	420B-6	126D-12	410J-1		410G-1
	420C-6	126E-12	410K-1		410L-1
	420D-6	126F-12	410M-1		410A-2
61458-89L30	420E-6	126G-12	410B-2	61820-89L00-RB4	410D-2
	420F-6	126H-13	410E-2		410E-2
	420G-6	126J-13	410G-2		410H-2
	420H-6	126K-13	410J-2		410K-2
	420J-6	126L-13	410M-2		410C-2
	420K-6	126M-13	410F-2		410L-2
	420L-6	410A-10	410A-15		410B-15
	420M-6	410B-10	410C-15		410D-15
	420A-10	410C-10	410E-15		410F-15
	420B-10	410D-10	410G-15		410H-15
61471-89L00	420C-10	410E-10	410J-15	61827-89L00	410K-15
	420D-10	410F-10	410L-15		410M-15
	420E-10	410G-10	410A-6		410B-6
	420F-10	410H-10	410C-6		410D-6
	420G-10	410J-10	410E-6		410F-6
	420H-10	410K-10	410G-6		410H-6
	420J-10	410L-10	410J-6		410K-6
	420K-10	410M-10	410L-6		410M-6
	420L-10	410A-11	410A-1		410B-1
	420M-10	410B-11	410D-1		410E-1
61472-97J00	420A-11	410C-11	410E-1	61810-89L00-RB4	410D-1
	420B-11	410D-11	410A-1		410B-1
	420C-11	410E-11	410C-1		410D-1
	420D-11	410F-11	410E-1		410G-1
	420E-11	410G-11	410F-1		410H-1
	420F-11	410H-11	410J-1		410K-1
	420G-11	410J-11	410L-1		410M-1
	420H-11	410K-11	410A-1		410B-1
	420J-11	410L-11	410C-1		410D-1
	420K-11	410M-11	410E-1		410F-1
61494-89L10	420L-11	420A-4	410G-1	61811-89L00-0EP	410H-1
	420M-11	420B-4	410J-1		410K-1
	167A-13	420C-4	410L-1		410M-1
	167B-13	420D-4	410A-1		410B-1
	167C-13	420E-4	410C-1		410D-1
	167D-13	420F-4	410E-1		410F-1
	167E-13	420G-4	410G-1		410H-1
	167F-13	420H-4	410J-1		410K-1
	167G-13	420J-4	410L-1		410M-1
	167H-13	420K-4	410A-1		410B-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
63114-99J01	444F-1	444B-6	444D-14	63610-89L10	444E-14
	444A-22	444C-6	444F-14		444A-15
	444B-22	444D-6	444B-15		444C-15
	444C-22	444E-6	444D-15		444E-15
	444D-22	444F-6	444F-15		432A-1
63115-99J00	444E-22	444A-31	65000-89L10	63220-89L00	65000-95D01
	444F-22	444B-31	65000-95D01		65520-95D01
	444A-3	444C-31	65520-99100		65561-95D00
	444B-3	444D-31	65561-95D00		583A-1
	444C-3	444E-31	583A-2		583A-2
63115-99J10	444D-3	444F-31	583A-3	63225-93200	583A-8
	444E-3	444A-7	583A-8		65700-87J15
	444F-3	444B-7	65700-89L30		65720-986L0
	444A-2	444C-7	65720-986L0		65740-95D01
	444B-2	444D-7	65740-95D01		583A-4
63116-99J00	444C-2	444E-7	583A-9	63225-98601	583A-10
	444D-2	444F-7	583A-10		65770-89L00
	444E-2	444A-9	65770-90J11		65781-98500
	444F-2	444B-9	65781-98500		583A-12
	444A-4	444C-9	65793-89L00		444A-26
63121-99J00-0EP	444B-4	444D-9	444B-26	63240-94J10	444C-26
	444C-4	444E-9	444D-26		444E-26
	444D-4	444F-9	444F-26		432A-4
	444E-4	444A-8	583A-5		583A-6
	444F-4	444B-8	583A-6		583A-7
63122-99J00	444A-5	444C-8	65890-95D00	63241-986B0	65890-99100
	444B-5	444D-8	65892-95D00		65892-95D00
	444C-5	444E-8	583A-12		583A-1
	444D-5	444F-8	583A-12		513A-1
	444E-5	444A-10	444B-26		513B-1
63131-99J11-0EP	444F-5	444B-10	444C-26	63244-94J00	444D-26
	444A-23	444C-10	444E-26		513C-1
	444B-23	444D-10	513D-1		515A-1
	444C-23	444E-10	515B-1		515C-1
	444D-23	444F-10	515D-1		515E-1
63133-89L00	444E-23	444A-11	515F-1	63610-89L00	444B-14
	444F-23	444B-11	444C-14		444D-14
	444A-24	444C-11	444E-12		444F-12
	444B-24	444D-11	444A-14		444B-14
	444C-24	444E-11	444C-14		444D-14
63210-89L11	444D-24	444F-11	444E-12	63210-89L11	444F-12
	444E-24	444A-12	444A-14		444B-14
	444F-24	444B-12	444C-14		444D-14
	444A-25	444C-12	444E-12		444F-12
	444B-25	444D-12	444A-14		444B-14

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67200-93J13	515G-1	67214-92E00	508A-13	67223-99E10	545K-3
	515H-1		508B-13		450A-16
	515J-1		508C-13		450B-17
	515K-1		508D-13		450C-16
	544A-1		450A-14		450D-17
	544B-1		450C-14		450E-16
	544C-1		450E-14		450F-17
	544D-1		508A-14		508A-16
	544E-1		508B-14		508B-16
	544F-1		508C-14		508C-16
67200-93J50	544G-1	67220-95630	508D-14	67224-92E00	508D-16
	544H-1		450A-15		545A-9
	544J-1		450B-16		545B-9
	544K-1		450C-15		545C-9
	545A-1		450D-16		545D-9
	545B-1		450E-15		545E-9
	545C-1		450F-16		545F-9
	545D-1		508A-15		545G-9
	545E-1		508B-15		545H-9
	545F-1		508C-15		545J-9
67200-94J20	545G-1	67221-92E00	508D-15	67226-92E00	545K-9
	545H-1		545A-8		545A-15
	545J-1		545B-8		545B-15
	545K-1		545C-8		545C-15
	450B-1		545D-8		545D-15
	450D-1		545E-8		545E-15
	450F-1		545F-8		545F-15
	450A-1		545G-8		545G-15
	450C-1		545H-8		545H-15
	450E-1		545J-8		545J-15
67211-93J00	508A-1	67222-92E00	545K-8	67226-92E10	545K-15
	508B-1		545A-2		545A-16
	508C-1		545B-2		545B-16
	508D-1		545C-2		545C-16
	544A-27		545D-2		545D-16
	544B-27		545E-2		545E-16
	544C-27		545F-2		545F-16
	544D-27		545G-2		545G-16
	544E-27		545H-2		545H-16
	544F-27		545J-2		545J-16
67212-95600	544G-27	67223-92E00	545K-2	67227-92E00	545K-16
	544H-27		545A-3		545A-24
	544J-27		545B-3		545B-24
	544K-27		545C-3		545C-24
	450A-13		545D-3		545D-24
	450B-14		545E-3		545E-24
	450C-13		545F-3		545F-24
	450D-14		545G-3		545G-24
	450E-13		545H-3		545H-24
	450F-14		545J-3		545J-24

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67228-92E00	545K-24	67232-95620	508D-18	67237-92E01	545K-27
	545A-18		545A-42		545A-32
	545B-18		545B-42		545B-32
	545C-18		545C-42		545C-32
	545D-18		545D-42		545D-32
	545E-18		545E-42		545E-32
	545F-18		545F-42		545F-32
	545G-18		545G-42		545G-32
	545H-18		545H-42		545H-32
	545J-18		545J-42		545J-32
67230-92E00	545K-17	67233-92E00	545K-42	67238-87D00	545K-33
	450A-17		545A-28		545A-33
	450B-18		545B-28		545B-33
	450C-17		545C-28		545C-33
	450D-18		545D-28		545D-33
	450E-17		545E-28		545E-33
	450F-18		545F-28		545F-33
	508A-17		545G-28		545G-33
	508B-17		545H-28		545H-33
	508C-17		545J-28		545J-33
67231-92E00	508D-17	67234-92E00	545K-28	67238-92E00	545K-33
	545A-20		545A-26		450A-19
	545B-20		545B-26		450B-20
	545C-20		545C-26		450C-19
	545D-20		545D-26		450D-20
	545E-20		545E-26		450E-19
	545F-20		545F-26		450F-20
	545G-20		545G-26		508A-19
	545H-20		545H-26		508B-19
	545J-20		545J-26		508C-19
67232-95600	545K-20	67235-92E00	545K-26	67239-92E00	508D-19
	545A-41		545A-22		545A-34
	545B-41		545B-22		545B-34
	545C-41		545C-22		545C-34
	545D-41		545D-22		545D-34
	545E-41		545E-22		545E-34
	545F-41		545F-22		545F-34
	545G-41		545G-22		545G-34
	545H-41		545H-22		545H-34
	545J-41		545J-22		545J-34
67232-95600	545K-41	67235-92E00	545K-22	67239-92E00	545K-34
	450A-18		545A-27		545A-35
	450B-19		545B-27		545B-35
	450C-18		545C-27		545C-35
	450D-19		545D-27		545D-35
	450E-18		545E-27		545E-35
	450F-19		545F-27		545F-35
	508A-18		545G-27		545G-35
	508B-18		545H-27		545H-35
	508C-18		545J-27		545J-35

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67239-92E10	545K-35	67243-95600	545K-44	67251-93J00	545K-36
	545A-45		450A-21		544A-12
	545B-45		450B-22		544B-12
	545C-45		450C-21		544C-12
	545D-45		450D-22		544D-12
-----	545E-45	-----	450E-21	-----	544E-12
	545F-45		450F-22		544F-12
	545G-45		508A-21		544G-12
	545H-45		508B-21		544H-12
	545J-45		508C-21		544J-12
67240-92E00	545K-45	67244-95600	508D-21	67251-99E20	544K-12
	545A-17		450A-22		450A-24
	545B-17		450B-23		450B-25
	545C-17		450C-22		450C-24
	545D-17		450D-23		450D-25
-----	545E-17	-----	450E-22	-----	450E-24
	545F-17		450F-23		450F-25
	545G-17		508A-22		508A-24
	545H-17		508B-22		508B-24
	545J-17		508C-22		508C-24
67241-92E10	545K-17	67245-92E00	508D-22	67252-92E10	508D-24
	545A-43		545A-23		545A-39
	545B-43		545B-23		545B-39
	545C-43		545C-23		545C-39
	545D-43		545D-23		545D-39
-----	545E-43	-----	545E-23	-----	545E-39
	545F-43		545F-23		545F-39
	545G-43		545G-23		545G-39
	545H-43		545H-23		545H-39
	545J-43		545J-23		545J-39
67241-99E10	545K-43	67245-95600	545K-23	67252-95600	545K-39
	450A-20		450A-23		450A-25
	450B-21		450B-24		450B-26
	450C-20		450C-23		450C-25
	450D-21		450D-24		450D-26
-----	450E-20	-----	450E-23	-----	450E-25
	450F-21		450F-24		450F-26
	508A-20		508A-23		508A-25
	508B-20		508B-23		508B-25
	508C-20		508C-23		508C-25
67243-92E00	508D-20	67246-92E00	508D-23	67253-92E00	508D-25
	545A-44		545A-36		544A-15
	545B-44		545B-36		544B-15
	545C-44		545C-36		544C-15
	545D-44		545D-36		544D-15
-----	545E-44	-----	545E-36	-----	544E-15
	545F-44		545F-36		544F-15
	545G-44		545G-36		544G-15
	545H-44		545H-36		544H-15
	545J-44		545J-36		544J-15

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67253-92E10	544K-15	67257-92E00	508D-28	67261-99E10	544K-2
	545A-38		544A-11		450A-32
	545B-38		544B-11		450B-33
	545C-38		544C-11		450C-32
	545D-38		544D-11		450D-33
-----	545E-38	-----	544E-11	-----	450E-32
	545F-38		544F-11		450F-33
	545G-38		544G-11		508A-32
	545H-38		544H-11		508B-32
	545J-38		544J-11		508C-32
67253-95600	545K-38	67257-99E10	544K-11	67263-93J00	508D-32
	450A-26		450A-29		544A-3
	450B-27		450B-30		544B-3
	450C-26		450C-29		544C-3
	450D-27		450D-30		544D-3
-----	450E-26	-----	450E-29	-----	544E-3
	450F-27		450F-30		544F-3
	508A-26		508A-29		544G-3
	508B-26		508B-29		544H-3
	508C-26		508C-29		544J-3
67258-99E00	508D-26	67258-99E00	508D-29	67264-95600	544K-3
	545A-40		450A-30		450A-34
	545B-40		450B-31		450B-35
	545C-40		450C-30		450C-34
	545D-40		450D-31		450D-35
-----	545E-40	-----	450E-30	-----	450E-34
	545F-40		450F-31		450F-35
	545G-40		508A-30		508A-34
	545H-40		508B-30		508B-34
	545J-40		508C-30		508C-34
67255-99E10	545K-40	67259-87D00	508D-30	67267-93J00	508D-34
	450A-27		450A-31		450A-35
	450B-28		450B-32		450B-36
	450C-27		450C-31		450C-35
	450D-28		450D-32		450D-36
-----	450E-27	-----	450E-31	-----	450E-35
	450F-28		450F-32		450F-36
	508A-27		508A-31		508A-35
	508B-27		508B-31		508B-35
	508C-27		508C-31		508C-35
67256-95600	508D-27	67261-93J00	508D-31	67269-92E00	508D-35
	450A-28		544A-2		545A-29
	450B-29		544B-2		545B-29
	450C-28		544C-2		545C-29
	450D-29		544D-2		545D-29
-----	450E-28	-----	544E-2	-----	545E-29
	450F-29		544F-2		545F-29
	508A-28		544G-2		545G-29
	508B-28		544H-2		545H-29
	508C-28		544J-2		545J-29

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67271-92E00	545K-29	67275-95600	544K-24	67286-92E00	508D-39
	544A-26		450A-37		545A-19
	544B-26		450B-38		545B-19
	544C-26		450C-37		545C-19
	544D-26		450D-38		545D-19
67273-92E00	544E-26	67281-93J00	450E-37	67287-92E00	545E-19
	544F-26		450F-38		545F-19
	544G-26		508A-37		545G-19
	544H-26		508B-37		545H-19
	544J-26		508C-37		545J-19
	544K-26		508D-37		545K-19
	544A-23		544A-21		544A-20
	544B-23		544B-21		544B-20
	544C-23		544C-21		544C-20
	544D-23		544D-21		544D-20
67273-95600	544E-23	67282-94L00	544E-21	67288-92E10	544E-20
	544F-23		544F-21		544F-20
	544G-23		544G-21		544G-20
	544H-23		544H-21		544H-20
	544J-23		544J-21		544J-20
	544K-23		544K-21		544K-20
	450A-36		544A-17		545A-4
	450B-37		544B-17		545B-4
	450C-36		544C-17		545C-4
	450D-37		544D-17		545D-4
67274-92E00	450E-36	67284-94L00	544E-17	67288-92E20	545E-4
	450F-37		544F-17		545F-4
	508A-36		544G-17		545G-4
	508B-36		544H-17		545H-4
	508C-36		544J-17		545J-4
	508D-36		544K-17		545K-4
	544A-22		450A-38		545A-6
	544B-22		450B-52		545B-6
	544C-22		450C-38		545C-6
	544D-22		450D-52		545D-6
67274-92E00	544E-22	67284-94L00	450E-38	67288-92E20	545E-6
	544F-22		450F-52		545F-6
	544G-22		508A-38		545G-6
	544H-22		508B-38		545H-6
	544J-22		508C-38		545J-6
	544K-22		508D-38		545K-6
	544A-24		450A-39		544A-7
	544B-24		450B-53		544B-7
	544C-24		450C-39		544C-7
	544D-24		450D-53		544D-7
67274-92E00	544E-24	67284-94L00	450E-39	67288-92E20	544E-7
	544F-24		450F-53		544F-7
	544G-24		508A-39		544G-7
	544H-24		508B-39		544H-7
	544J-24		508C-39		544J-7

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67288-92E30	544K-7	67294-92E00	508D-40	67295-92E10	544K-8
	544A-14		545A-5		544A-5
	544B-14		545B-5		544B-5
	544C-14		545C-5		544C-5
	544D-14		545D-5		544D-5
67288-92E40	544E-14	67294-92E00	545E-5	67296-88D10	544E-5
	544F-14		545F-5		544F-5
	544G-14		545G-5		544G-5
	544H-14		545H-5		544H-5
	544J-14		545J-5		544J-5
	544K-14		545K-5		544K-5
	544A-10		545A-10		544A-6
	544B-10		545B-10		544B-6
	544C-10		545C-10		544C-6
	544D-10		545D-10		544D-6
67291-92E00	544E-10	67294-95600	545E-10	67296-88D10	544E-6
	544F-10		545F-10		544F-6
	544G-10		545G-10		544G-6
	544H-10		545H-10		544H-6
	544J-10		545J-10		544J-6
	544K-10		545K-10		544K-6
	545A-7		450A-41		545A-13
	545B-7		450B-40		545A-30
	545C-7		450C-41		545B-13
	545D-7		450D-40		545B-30
67291-92E10	545E-7	67294-95600	450E-41	67296-88D10	545C-13
	545F-7		450F-40		545C-30
	545G-7		508A-41		545D-13
	545H-7		508B-41		545D-30
	545J-7		508C-41		545E-13
	545K-7		508D-41		545E-30
	545A-37		515A-2		545F-13
	545B-37		515B-2		545F-30
	545C-37		515C-2		545G-13
	545D-37		515D-2		545G-30
67292-94300	545E-37	67295-92E00	515E-2	67296-90J00	545H-13
	545F-37		515F-2		545H-30
	545G-37		515G-2		545J-13
	545H-37		515H-2		545J-30
	545J-37		515J-2		545K-13
	545K-37		515K-2		545K-30
	450A-40		544A-8		450A-42
	450B-39		544B-8		450B-41
	450C-40		544C-8		450C-42
	450D-39		544D-8		450D-41
67292-94300	450E-40	67295-92E00	544E-8	67296-90J00	450E-42
	450F-39		544F-8		450F-41
	508A-40		544G-8		508A-42
	508B-40		544H-8		508B-42
	508C-40		544J-8		508C-42

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67296-92E11	508D-42		544D-9		508A-45
	450B-15		544D-28		508B-45
	450D-15		544E-9		508C-45
	450F-15		544E-28		508D-45
	545A-12		544F-9		544A-25
	545B-12		544F-28		544B-25
	545C-12		544G-9		544C-25
	545D-12		544G-28		544D-25
	545E-12		544H-9		544E-25
	545F-12		544H-28		544F-25
	545G-12		544J-9		544G-25
	545H-12		544J-28		544H-25
	545J-12		544K-9		544J-25
	545K-12		544K-28		544K-25
	545A-14		450A-43		515A-3
67296-92E20	545B-14	67296-94300	450B-42	67296-95621	515B-3
	545C-14		450C-43		515C-3
	545D-14		450D-42		515D-3
	545E-14		450E-43		515E-3
	545F-14		450F-42		515F-3
	545G-14		508A-43		515G-3
	545H-14		508B-43		515H-3
	545J-14		508C-43		515J-3
	545K-14		508D-43		515K-3
	544A-18		450A-33		450A-46
67296-92E30	544B-18	67296-94310	450B-34	67297-95600	450B-45
	544C-18		450C-33		450C-46
	544D-18		450D-34		450D-45
	544E-18		450E-33		450E-46
	544F-18		450F-34		450F-45
	544G-18		508A-33		508A-46
	544H-18		508B-33		508B-46
	544J-18		508C-33		508C-46
	544K-18		508D-33		508D-46
	544A-13		450A-44		515A-4-1
67296-92E60	544B-13	67296-95600	450B-43	67320-93J00	515B-4-1
	544C-13		450C-44		515C-4-1
	544D-13		450D-43		515D-4-1
	544E-13		450E-44		515E-4-1
	544F-13		450F-43		515F-4-1
	544G-13		508A-44		515G-4-1
	544H-13		508B-44		515H-4-1
	544J-13		508C-44		515J-4-1
	544K-13		508D-44		515K-4-1
	544A-9		450A-45		515A-4-2
67296-92E70	544A-28	67296-95610	450B-44	67320-93J10	515B-4-2
	544B-9		450C-45		515C-4-2
	544B-28		450D-44		515D-4-2
	544C-9		450E-45		515E-4-2
	544C-28		450F-44		515F-4-2

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	515G-4-2		515G-4-7	67500-93J00	544A-29
	515H-4-2		515H-4-7		544B-29
	515J-4-2		515J-4-7		544C-29
	515K-4-2		515K-4-7		544D-29
67320-93J20	515A-4-3	67320-93J70	515A-4-8		544E-29
	515B-4-3		515B-4-8		544F-29
	515C-4-3		515C-4-8		544G-29
	515D-4-3		515D-4-8		544H-29
	515E-4-3		515E-4-8		544J-29
	515F-4-3		515F-4-8		544K-29
	515G-4-3		515G-4-8	67701-99J02	442A-2
	515H-4-3		515H-4-8		442B-2
	515J-4-3		515J-4-8		442C-2
	515K-4-3		515K-4-8		442D-2
67320-93J30	515A-4-4	67320-93J80	515A-4-9		442E-2
	515B-4-4		515B-4-9		442F-2
	515C-4-4		515C-4-9		575A-2
	515D-4-4		515D-4-9		575B-2
	515E-4-4		515E-4-9		575C-2
	515F-4-4		515F-4-9		575D-2
	515G-4-4		515G-4-9	67721-93E10	442A-3
	515H-4-4		515H-4-9		442B-3
	515J-4-4		515J-4-9		442C-3
	515K-4-4		515K-4-9		442D-3
67320-93J40	515A-4-5	67340-89L00	206B-21		442E-3
	515B-4-5		206C-21		442F-3
	515C-4-5		206E-21		575A-3
	515D-4-5		206F-21		575B-3
	515E-4-5		206K-21		575C-3
	515F-4-5		206L-21		575D-3
	515G-4-5		513A-22	67725-96J00	442A-4
	515H-4-5		513B-22		442B-4
	515J-4-5		513C-22		442C-4
	515K-4-5		513D-22		442D-4
67320-93J50	515A-4-6	67467-89J01	166A-11		442E-4
	515B-4-6		166B-11		442F-4
	515C-4-6		166C-11		575A-4
	515D-4-6		166D-11		575B-4
	515E-4-6		166E-11		575C-4
	515F-4-6		166F-11		575D-4
	515G-4-6		206B-18	67726-99E00	442A-5
	515H-4-6		206C-18		442B-5
	515J-4-6		206E-18		442C-5
	515K-4-6		206F-18		442D-5
67320-93J60	515A-4-7		206K-18		442E-5
	515B-4-7		206L-18		442F-5
	515C-4-7		513A-23		575A-5
	515D-4-7		513B-23		575B-5
	515E-4-7		513C-23		575C-5
	515F-4-7		513D-23		575D-5

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67728-99E00	442A-6		335E-24		420J-13
	442B-6		335F-27		420K-13
	442C-6		335G-27		420L-13
	442D-6		335H-24		420M-13
	442E-6		335J-24		
-----	442F-6		335K-24		
	575A-6		335L-27		
	575B-6		335M-27		
	575C-6				
	575D-6				
68110-89L00	420A-14			01547-06167	206B-22
	420B-14				206C-22
	420C-15				206E-22
	420D-14				206F-22
	420E-14				206K-22
-----	420F-15				206L-22
	420G-15				322A-4
	420H-14				322D-4
	420J-14				322G-4
	420K-14				322H-4
-----	420L-15				322J-4
	420M-15				322M-4
	420A-7				513A-33
	420B-7				513B-33
	420C-7				513C-33
-----	420D-7				513D-33
	420E-7				561A-17
	420F-7				561B-17
	420G-7				561C-17
	420H-7				561D-17
-----	420J-7				303E-2
	420K-7				561A-10
	420L-7				561B-10
	420M-7				561C-10
	167A-12				561D-10
-----	167B-12				303A-2
	167C-12				303B-2
	167D-12				303C-2
	167E-12				303D-2
	167F-12				303A-3
-----	167G-12				303B-3
	167H-12				303C-3
	167J-12				303D-3
	167K-12				303E-3
	167L-12				163A-8
-----	167M-12				163D-8
	335A-24				163G-8
	335B-24				163H-8
	335C-27				163J-8
	335D-24				163M-8

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	166A-9		513B-34		513A-35
	166B-9		513C-34		513B-35
	166C-9		513D-34		513C-35
	166D-9		146A-20		513D-35
	166E-9		146B-20		561A-8
	166F-9		146C-20		561B-8
	175A-8		146D-20		561C-8
	206A-17		146E-20		561D-8
	206B-9		146F-20		111A-15
	206B-15		146G-20		146A-21
	206C-9		146H-20		146B-21
	206C-15		146J-20		146C-21
	206D-17		146K-20		146D-21
	206E-9		146L-20		146E-21
	206E-15		146M-20		146F-21
	206F-9		166A-10		146G-21
	206F-15		166B-10		146H-21
	206G-17		166C-10		146J-21
	206H-17		166D-10		146K-21
	206J-17		166E-10		146L-21
	206K-9		166F-10		146M-21
	206K-15		303A-10		162A-3
	206L-9		303B-10		163A-9
	206L-15		303C-10		163B-7
	206M-17		303D-10		163C-7
	322A-20		303E-10		163D-9
	322A-21		310A-8		163E-7
	322B-15		310B-8		163F-7
	322B-16		310C-8		163G-9
	322C-15		310D-8		163H-9
	322C-16		310E-8		163J-9
	322D-20		310F-8		163K-7
	322D-21		310G-8		163L-7
	322E-15		310H-8		163M-9
	322E-16		310J-8		167A-11
	322F-15		310K-8		167B-11
	322F-16		310L-8		167C-11
	322G-20		310M-8		167D-11
	322G-21		334A-9		167E-11
	322H-20		334B-8		167F-11
	322H-21		334C-8		167G-11
	322J-20		334D-9		167H-11
	322J-21		334E-8		167J-11
	322K-15		334F-8		167K-11
	322K-16		334G-8		167L-11
	322L-15		334H-9		167M-11
	322L-16		334J-9		175A-7
	322M-20		334K-8		310A-7
	322M-21		334L-8		310B-7
	513A-34		334M-8		310C-7

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	310D-7		146L-11	01550-08307	301A-23
	310E-7		146L-22	01560-08307	401A-15
	310F-7		146M-11	01560-08757	113A-3
	310G-7		146M-22	01580-08407	126A-3
	310H-7		206A-18		126B-3
	310J-7		206B-16		126C-3
	310K-7		206C-16		126D-3
	310L-7		206D-18		126E-3
	310M-7		206E-16		126F-3
	334A-15		206F-16		126G-3
	334B-14		206G-18		126H-3
	334C-14		206H-18		126J-3
	334D-15		206J-18		126K-3
	334E-14		206K-16		126L-3
	334F-14		206L-16		126M-3
	334G-14		206M-18	02122-04127	120A-15
	334H-15	01550-06307	167A-9	02122-0630A	175A-14
	334J-15		167B-9	02142-06167	410A-16
	334K-14		167C-9		410B-16
	334L-14		167D-9		410C-16
	334M-14		167E-9		410D-16
	553A-6		167F-9		410E-16
	553B-6		167G-9		410F-16
	553C-6		167H-9		410G-16
	553D-6		167J-9		410H-16
	561A-9		167K-9		410J-16
	561B-9		167L-9		410K-16
	561C-9		167M-9		410L-16
	561D-9		310A-12		410M-16
01550-06257	120A-13		310B-12	02142-06207	206A-19
	146A-11		310C-12		206B-17
	146A-22		310D-12		206C-17
	146B-11		310E-12		206D-19
	146B-22		310F-12		206E-17
	146C-11		310G-12		206F-17
	146C-22		310H-12		206G-19
	146D-11		310J-12		206H-19
	146D-22		310K-12		206J-19
	146E-11		310L-12		206K-17
	146E-22		310M-12		206L-17
	146F-11	01550-06357	113A-2		206M-19
	146F-22		120A-14	03112-0630B	501A-16
	146G-11	01550-06507	144A-9		501B-16
	146G-22	01550-08207	111A-9		501C-16
	146H-11		113A-7		501D-16
	146H-22		301A-22		501E-16
	146J-11		553A-5		501F-16
	146J-22		553B-5	03121-0516A	530A-26
	146K-11		553C-5		530B-26
	146K-22		553D-5		530C-26

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	530D-26		126C-4		336J-23
	530E-26		126D-4		336K-23
	530F-26		126E-4		336L-13
03122-05165	530A-14		126F-4		336M-13
	530B-14		126G-4		450A-48
	530C-14		126H-4		450B-47
	530D-14		126J-4		450C-48
	530E-14		126K-4		450D-47
	530F-14		126L-4		450E-48
03142-04169	160A-12		126M-4		450F-47
	160B-12	08110-60020	220A-2		508A-48
	160C-12		220B-2		508B-48
	160D-12		220C-2		508C-48
	160E-12		220D-2		508D-48
	160F-12		220E-2	09100-08311	335A-15
	160G-12		220F-2		335B-15
	160H-12		220G-2		335C-24
	160J-12		220H-2		335D-15
	160K-12		220J-2		335E-15
	160L-12		220K-2		335F-24
03542-05169	160M-12		220L-2		335G-24
	420A-3		220M-2		335H-15
	420B-3	08110-60050	407A-11		335J-15
	420C-3	08316-10087	301A-24		335K-15
	420D-3	08322-0106A	303A-11		335L-24
	420E-3		303B-11		335M-24
	420F-3		303C-11	09103-06237	432A-14
	420G-3		303D-11	09103-06267	120A-7
	420H-3	08341-31039	120A-9	09103-06319	111A-8
	420J-3		120A-10		335C-21
	420K-3		303A-7		335F-21
	420L-3		303B-7		335G-21
03542-06209	420M-3		303C-7		335L-21
	146A-23		303D-7		335M-21
	146B-23		303E-7		336C-21
	146C-23	09100-06178	335A-9		336F-21
	146D-23		335B-9		336G-26
	146E-23		335D-9		336L-21
	146F-23		335E-9		336M-26
	146G-23		335H-9		338A-20
	146H-23		335J-9		338B-20
	146J-23		335K-9		338C-20
	146K-23	09100-08232	336A-23		338D-20
	146L-23		336B-23		338E-20
	146M-23		336C-13		407A-7
04211-09149	120A-12		336D-23	09108-06141	160A-14
04211-11129	111A-12		336E-23		160B-14
	113A-4		336F-13		160C-14
04221-05109	126A-4		336G-13		160D-14
	126B-4		336H-23		160E-14

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	160F-14		146C-12	09116-06234	206A-9
	160G-14		146D-12		206D-9
	160H-14		146E-12		206G-9
	160J-14		146F-12		206H-9
	160K-14		146G-12		206J-9
	160L-14		146H-12		206M-9
09108-08286	160M-14		146J-12	09116-08128	335C-18
	336B-29		146K-12		335F-18
	336C-16		146L-12		335G-18
	336E-29		146M-12		335L-18
	336F-16		327A-4		335M-18
	336K-29		327B-4	09116-08137	401A-13
	336L-16		327C-8	09116-08150	338A-21
	513A-24		327D-4		338B-21
	513B-24		327E-8		338C-21
09111-10067	513C-24	09116-06225	336A-35		338D-21
	513D-24		336B-32		338E-21
	336A-26		336C-19	09116-08151	401A-3
	336B-26		336D-35		405A-6
	336D-26		336E-32		405A-17
	336E-26		336F-19		407A-5
	336H-26		336G-22		444A-16
	336J-26		336H-35		444B-16
	336K-26		336J-35		444C-16
09116-06196	310A-3		336K-32		444D-16
	310B-3		336L-19		444E-16
	310C-3		336M-22		444F-16
	310D-3		444A-27	09116-08154	405A-15
	310E-3		444B-27	09116-08155	444A-28
	310F-3		444C-27		444B-28
	310G-3		444D-27		444C-28
	310H-3		444E-27		444D-28
	310J-3		444F-27		444E-28
	310K-3		513A-25		444F-28
	310L-3		513B-25	09119-08L01	111A-4
09116-06202	310M-3		513C-25	09119-08L02	111A-3
	126A-7	09116-06227	513D-25	09125-05042	444A-29
	126B-7	09116-06229	407A-14		444B-29
	126C-7		220A-24		444C-29
	126D-7		220B-24		444D-29
	126E-7		220C-24		444E-29
	126F-7		220D-24		444F-29
	126G-7		220E-24		545A-21
	126H-9		220F-24		545B-21
	126J-9		220G-24		545C-21
	126K-9		220H-24		545D-21
	126L-9		220J-24		545E-21
	126M-9		220K-24		545F-21
	146A-12		220L-24		545G-21
	146B-12		220M-24		545H-21

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	545J-21		444A-18		508C-50
09125-05046	545K-21		444B-18		508D-50
	327C-5		444C-18		545A-31
	327E-5		444D-18		545B-31
09125-05135	544A-30		444E-18		545C-31
	544B-30		444F-18		545D-31
	544C-30	09136-06168	410A-8		545E-31
	544D-30		410B-8		545F-31
	544E-30		410C-8		545G-31
	544F-30		410D-8		545H-31
	544G-30		410E-8		545J-31
	544H-30		410F-8		545K-31
	544J-30		410G-8	09140-08023-XC0	335A-16
	544K-30		410H-8		335B-16
09125-06063	335C-12		410J-8		335C-25
	335F-12		410K-8		335D-16
	335G-12		410L-8		335E-16
	335L-12		410M-8		335F-25
	335M-12	09136-06169	410A-3		335G-25
09126-05003	450A-49		410B-3		335H-16
	450B-48		410C-3		335J-16
	450C-49		410D-3		335K-16
	450D-48		410E-3		335L-25
	450E-49		410F-3		335M-25
	450F-48		410G-3	09140-10031	401A-14
	508A-49		410H-3	09140-14008	303A-5
	508B-49		410J-3		303B-5
	508C-49		410K-3		303C-5
	508D-49		410L-3		303D-5
09126-06006	545A-25		410M-3		303E-5
	545B-25	09140-05005	327C-7	09141-12005	407A-18
	545C-25		327E-7	09148-06008	444A-13
	545D-25		544A-32		444B-13
	545E-25		544B-32		444C-13
	545F-25		544C-32		444D-13
	545G-25		544D-32		444E-13
	545H-25		544E-32		444F-13
	545J-25		544F-32	09159-08059	336B-30
	545K-25		544G-32		336C-17
09126-06015	444A-17		544H-32		336E-30
	444B-17		544J-32		336F-17
	444C-17		544K-32		336K-30
	444D-17	09140-06020	450A-50		336L-17
	444E-17		450B-49		513A-26
	444F-17		450C-50		513B-26
09136-05041	340A-8		450D-49		513C-26
	340B-8		450E-50		513D-26
	340C-8		450F-49	09159-08L02	336A-36
	340D-8		508A-50		336D-36
	340E-8		508B-50		336G-23

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09159-22006	336H-36		166B-8		335A-10
	336J-36		166C-8		335B-10
	336M-23		166D-8		335D-10
	335A-8		166E-8		335E-10
	335B-8		166F-8		335H-10
	335C-13		206A-10		335J-10
	335D-8		206B-10		335K-10
	335E-8		206C-10		336A-17
	335F-13		206D-10		336B-17
	335G-13		206E-10		336D-17
	335H-8		206F-10		336E-17
	335J-8		206G-10		336H-17
	335K-8		206H-10		336J-17
	335L-13		206J-10		336K-17
	335M-13		206K-10	09160-06085	432A-15
	513A-27		206L-10	09160-06094	206A-11
	513B-27		206M-10		206D-11
	513C-27		513A-29		206G-11
	513D-27		513B-29		206H-11
	544A-19		513C-29		206J-11
09160-05024	544B-19		513D-29		206M-11
	544C-19	09160-06055	166A-12	09160-06104	450A-51
	544D-19		166B-12		450B-50
	544E-19		166C-12		450C-51
	544F-19		166D-12		450D-50
	544G-19		166E-12		450E-51
	544H-19		166F-12		450F-50
	544J-19		206B-19		508A-51
	544K-19		206C-19		508B-51
	206B-11		206E-19		508C-51
09160-05029	206C-11		206F-19		508D-51
	206E-11		206K-19	09160-06168	310A-17
	206F-11		206L-19		310B-17
	206K-11		513A-30		310C-17
	206L-11		513B-30		310D-17
	513A-28		513C-30		310E-17
	513B-28		513D-30		310F-17
	513C-28	09160-06082	160A-15		310G-17
	513D-28		160B-15		310H-17
	544A-31		160C-15		310J-17
	544B-31		160D-15		310K-17
	544C-31		160E-15		310L-17
	544D-31		160F-15		310M-17
	544E-31		160G-15	09160-06171	120A-8
	544F-31		160H-15	09160-08081	335A-17
	544G-31		160J-15		335B-17
	544H-31		160K-15		335C-23
	544J-31		160L-15		335D-17
	544K-31		160M-15		335E-17
	166A-8		210A-8		335F-23

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	335G-23		220H-11-1		220J-11-6
	335H-17		220J-11-1		220K-11-6
	335J-17		220K-11-1	09160-17042	220A-11-8
	335K-17	09160-17025	220A-11-3		220B-11-8
	335L-23		220B-11-3		220D-11-8
09160-08082	335M-23		220D-11-3		220E-11-8
	336A-22		220E-11-3		220H-11-8
	336B-22		220H-11-3		220J-11-8
	336B-28		220J-11-3		220K-11-8
	336C-12		220K-11-3	09160-17053	220C-11-1
	336C-15	09160-17026	220A-11-5		220F-11-1
	336D-22		220B-11-5		220G-11-1
	336E-22		220D-11-5		220L-11-1
	336E-28		220E-11-5		220M-11-1
	336F-12		220H-11-5	09160-17054	220C-11-2
	336F-15		220J-11-5		220F-11-2
	336G-12		220K-11-5		220G-11-2
	336H-22	09160-17027	220A-11-7		220L-11-2
	336J-22		220B-11-7		220M-11-2
	336K-22		220D-11-7	09160-17055	220C-11-3
	336K-28		220E-11-7		220F-11-3
	336L-12		220H-11-7		220G-11-3
	336L-15		220J-11-7		220L-11-3
	336M-12		220K-11-7		220M-11-3
	513A-20	09160-17028	220A-11-9	09160-17056	220C-11-4
	513B-20		220B-11-9		220F-11-4
	513C-20		220D-11-9		220G-11-4
	513D-20		220E-11-9		220L-11-4
09160-08170	335A-22		220H-11-9		220M-11-4
	335B-22		220J-11-9	09160-17057	220C-11-5
	335C-26		220K-11-9		220F-11-5
	335D-22	09160-17039	220A-11-2		220G-11-5
	335E-22		220B-11-2		220L-11-5
	335F-26		220D-11-2		220M-11-5
	335G-26		220E-11-2	09160-17058	220C-11-6
	335H-22		220H-11-2		220F-11-6
	335J-22		220J-11-2		220G-11-6
	335K-22		220K-11-2		220L-11-6
	335L-26	09160-17040	220A-11-4		220M-11-6
	335M-26		220B-11-4	09160-17059	220C-11-7
09160-12066	407A-19		220D-11-4		220F-11-7
09160-15057	303A-6		220E-11-4		220G-11-7
	303B-6		220H-11-4		220L-11-7
	303C-6		220J-11-4		220M-11-7
	303D-6		220K-11-4	09160-17060	220C-11-8
	303E-6	09160-17041	220A-11-6		220F-11-8
09160-17024	220A-11-1		220B-11-6		220G-11-8
	220B-11-1		220D-11-6		220L-11-8
	220D-11-1		220E-11-6		220M-11-8
	220E-11-1		220H-11-6	09160-17061	220C-11-9

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09160-20027	220F-11-9	09160-21009	220L-5-4	09160-27012	336A-5
	220G-11-9		220M-5-4		336A-8
	220L-11-9		220A-6		336B-5
	220M-11-9		220B-6		336B-8
	220A-4		220C-6		336C-5
	220B-4		220D-6		336C-8
	220C-4		220E-6		336D-5
	220D-4		220F-6		336D-8
	220E-4		220G-6		336E-5
	220F-4		220H-6		336E-8
	220G-4		220J-6		336F-5
	220H-4		220K-6		336F-8
	220J-4		220L-6		336G-5
	220K-4		220M-6		336G-8
	220L-4	09160-25040	220A-12-4		336H-5
09160-20042	220M-4		220B-12-4		336H-8
	220A-5-2		220C-12-4		336J-5
	220B-5-2		220D-12-4		336J-8
	220C-5-2		220E-12-4		336K-5
	220D-5-2		220F-12-4	09161-04012	336K-8
	220E-5-2	09160-25041	220G-12-4		336L-5
	220F-5-2		220H-12-4		336L-8
	220G-5-2		220J-12-4		336M-5
	220H-5-2		220K-12-4		336M-8
	220J-5-2	09160-25043	220L-12-4		410A-12
	220K-5-2		220M-12-4		410B-12
	220L-5-2		220A-12-5		410C-12
	220M-5-2		220B-12-5		410D-12
	220A-5-3		220C-12-5		410E-12
	220B-5-3		220D-12-5		410F-12
	220C-5-3		220E-12-5		410G-12
	220D-5-3		220F-12-5		410H-12
	220E-5-3		220G-12-5		410J-12
	220F-5-3		220H-12-5		410K-12
	220G-5-3	09160-25042	220J-12-5	09161-08019	410L-12
	220H-5-3		220K-12-5		410M-12
	220J-5-3		220L-12-5		336A-37
	220K-5-3		220M-12-5		336D-37
	220L-5-3		220A-12-6		336G-24
09160-20044	220M-5-3		220B-12-6	09163-06001	336H-37
	220A-5-4		220C-12-6		336J-37
	220B-5-4		220D-12-6		336M-24
	220C-5-4		220E-12-6		444A-19
	220D-5-4		220F-12-6		444B-19
	220E-5-4		220G-12-6		444C-19
	220F-5-4		220H-12-6		444D-19
	220G-5-4		220J-12-6		444E-19
	220H-5-4		220K-12-6		444F-19
	220J-5-4	09164-14008	220L-12-6		206A-12
	220K-5-4		220M-12-6		206D-12

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	206G-12	09180-06362	206J-13		220F-5-6
	206H-12		206M-13		220G-5-6
	206J-12		206A-14		220H-5-6
	206M-12		206B-12		220J-5-6
	405A-8		206C-12		220K-5-6
09168-12017	126A-6		206D-14	09181-20248	220L-5-6
09169-06062	126B-6		206E-12		220M-5-6
	126C-6		206F-12		220A-5-7
	126D-6		206G-14		220B-5-7
	126E-6		206H-14		220C-5-7
	126F-6		206J-14		220D-5-7
	126G-6		206K-12		220E-5-7
	126H-8		206L-12		220F-5-7
	126J-8		206M-14		220G-5-7
	126K-8	09180-06366	335A-11		220H-5-7
	126L-8		335B-11		220J-5-7
	126M-8		335D-11		220K-5-7
	146A-13		335E-11		220L-5-7
	146B-13		335H-11		220M-5-7
	146C-13	09181-15241	335J-11	09181-20251	220A-5-1
	146D-13		335K-11		220B-5-1
	146E-13		220A-13		220C-5-1
	146F-13		220B-13		220D-5-1
	146G-13		220C-13		220E-5-1
	146H-13		220D-13		220F-5-1
	146J-13		220E-13		220G-5-1
	146K-13		220F-13		220H-5-1
	146L-13		220G-13		220J-5-1
	146M-13		220H-13		220K-5-1
	327A-5	09181-20244	220J-13	09181-25160	220L-5-1
	327B-5		220K-13		220M-5-1
	327C-9		220L-13		220A-12-1
	327D-5		220M-13		220B-12-1
	327E-9		220A-5-5		220C-12-1
09169-06063	310A-5		220B-5-5		220D-12-1
	310B-5		220C-5-5		220E-12-1
	310C-5		220D-5-5		220F-12-1
	310D-5		220E-5-5		220G-12-1
	310E-5		220F-5-5		220H-12-1
	310F-5		220G-5-5	09181-25162	220J-12-1
	310G-5		220H-5-5		220K-12-1
	310H-5		220J-5-5		220L-12-1
	310J-5		220K-5-5		220M-12-1
	310K-5		220L-5-5		220A-12-2
	310L-5	09181-20246	220M-5-5		220B-12-2
	310M-5		220A-5-6		220C-12-2
	206A-13		220B-5-6		220D-12-2
	206D-13		220C-5-6		220E-12-2
	206G-13		220D-5-6		220F-12-2
09180-06186	206H-13		220E-5-6		220G-12-2

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09181-25164	220H-12-2	09202-04025	160H-17	09205-06021	335A-6
	220J-12-2		160J-17		335B-6
	220K-12-2		160K-17		335C-3
	220L-12-2		160L-17		335D-6
	220M-12-2		160M-17		335E-6
	220A-12-3		220A-16		335F-3
	220B-12-3		220B-16		335G-3
	220C-12-3		220C-16		335H-6
	220D-12-3		220D-16		335J-6
	220E-12-3		220E-16		335K-6
09181-25181	220F-12-3	09202-06039	220F-16	09229-04005	335L-3
	220G-12-3		220G-16		335M-3
	220H-12-3		220H-16		410A-20
	220J-12-3		220J-16		410B-20
	220K-12-3		220K-16		410C-20
	220L-12-3		220L-16		410D-20
	220M-12-3		220M-16		410E-20
	220A-12-7		401A-4		410F-20
	220B-12-7		405A-7		410G-20
	220C-12-7		407A-4		410H-20
09200-05014	220D-12-7	09204-01002	206A-8	09248-08001	410J-20
	220E-12-7		206B-8		410K-20
	220F-12-7		206C-8		410L-20
	220G-12-7		206D-8		410M-20
	220H-12-7		206E-8		407A-9
	220J-12-7		206F-8		405A-9
	220K-12-7		206G-8		444A-30
	220L-12-7		206H-8		444B-30
	220M-12-7		206J-8		444C-30
	336A-18		206K-8		444D-30
09200-06061	336B-18	09251-05006	206L-8	09251-05006	444E-30
	336D-18		206M-8		444F-30
	336E-18		336A-13		146A-14
	336H-18		336B-13		146B-14
	336J-18		336D-13		146C-14
	336K-18		336E-13		146D-14
	336A-16		336H-13		146E-14
	336B-16		336J-13		146F-14
	336D-16		336K-13		146G-14
	336E-16		513A-19		146H-14
09202-04008	336H-16	09204-02004	513B-19	09251-09007	146J-14
	336J-16		513C-19		146K-14
	336K-16		513D-19		146L-14
	160A-17		407A-20		146M-14
	160B-17	09205-02004	210A-4		410A-19
	160C-17		335C-19		410B-19
	160D-17		335F-19		410C-19
	160E-17		335G-19		410D-19
	160F-17		335L-19		410E-19
	160G-17		335M-19		410F-19

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09260-12003	410G-19	09280-54001	175A-5	09289-06L02	121L-14
	410H-19		407A-12		121M-14
	410J-19		401A-5		210A-11
	410K-19		09282-12L04		407A-13
	410L-19		09282-13L01		09306-22006
	410M-19		220B-22		335A-14
	206A-15		220C-22		335B-14
	206B-13		220D-22		335D-14
	206C-13		220E-22		335E-14
	206D-15		220F-22		335H-14
09262-25003	206E-13	09282-27002	220G-22	09320-08051	335J-14
	206F-13		220H-22		335K-14
	206G-15		220J-22		310A-6
	206H-15		220K-22		310B-6
	206J-15		220L-22		310C-6
	206K-13		220M-22		310D-6
	206L-13		336A-6		310E-6
	206M-15		336B-6		310F-6
	407A-3		336C-6		310G-6
	407A-2		336D-6		310H-6
09263-20L04	220A-7	09283-25096	336E-6	09320-08062	310J-6
	220B-7		336F-6		310K-6
	220C-7		336G-6		310L-6
	220D-7		336H-6		310M-6
	220E-7		336J-6		144A-7
	220F-7		336K-6		126A-10
	220G-7		336L-6		126B-10
	220H-7		336M-6		126C-10
	220J-7		121A-2		126D-10
	220K-7		121B-2		126E-10
09280-06012	220L-7	09283-32039	121C-2	09289-05012	126F-10
	220M-7		121D-2		126G-10
	210A-9		121E-2		126H-12
	175A-11		121F-2		126J-12
	210A-10		121G-2		126K-12
	175A-4		121H-2		126L-12
	111A-11		121J-2		126M-12
	111A-6		121K-2		146A-15
	146A-39		121L-2		146B-15
	146B-39		121M-2		146C-15
09280-26005	146C-39	09320-11017	116A-9	09320-11017	146D-15
	146D-39		121A-14		146E-15
	146E-39		121B-14		146F-15
	146F-39		121C-14		146G-15
	146G-39		121D-14		146H-15
	146H-39		121E-14		146J-15
	146I-39		121F-14		146K-15
	146J-39		121G-14		146L-15
	146K-39		121H-14		146M-15
	146L-39		121J-14		410A-7

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	410C-7		220L-3		146G-19
	410D-7		220M-3		146H-19
	410E-7	09381-16001	116A-4		146J-19
	410F-7	09385-04003	410A-21		146K-19
	410G-7		410B-21		146L-19
	410H-7		410C-21		146M-19
	410J-7		410D-21	09401-11423	146A-34
	410K-7		410E-21		146A-40
	410L-7		410F-21		146B-34
	410M-7		410G-21		146B-40
09320-13022	405A-18		410H-21		146C-34
09321-08022	146A-16		410J-21		146C-40
	146B-16		410K-21		146D-34
	146C-16		410L-21		146D-40
	146D-16		410M-21		146E-34
	146E-16	09385-06012	166A-13		146E-40
	146F-16		166B-13		146F-34
	146G-16		166C-13		146F-40
	146H-16		166D-13		146G-34
	146J-16		166E-13		146G-40
	146K-16		166F-13		146H-34
	146L-16		206B-20		146H-40
09352-50823-600	146M-16		206C-20		146J-34
	146A-17		206E-20		146J-40
	146B-17		206F-20		146K-34
	146C-17		206K-20		146K-40
	146D-17		206L-20		146L-34
	146E-17		513A-31		146L-40
	146F-17		513B-31		146M-34
	146G-17		513C-31		146M-40
	146H-17		513D-31	09401-11425	144A-8
	146J-17	09401-08412	146A-18	09401-12413	111A-17
	146K-17		146B-18		401A-16
	146L-17		146C-18	09401-13423	146A-41
	146M-17		146D-18		146B-41
09380-12002	338A-22		146E-18		146C-41
	338B-22		146F-18		146D-41
	338C-22		146G-18		146E-41
	338D-22		146H-18		146F-41
	338E-22		146J-18		146G-41
09380-15001	220A-3		146K-18		146H-41
	220B-3		146L-18		146J-41
	220C-3		146M-18		146K-41
	220D-3	09401-08413	162A-6		146L-41
	220E-3	09401-10412	146A-19		146M-41
	220F-3		146B-19	09401-13424	401A-18
	220G-3		146C-19	09403-07308	410C-22
	220H-3		146D-19		410F-22
	220J-3		146E-19		410G-22
	220K-3		146F-19		410L-22

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	410M-22		530B-8		338D-23
09403-08404	322A-16		530B-28		338E-23
	322B-11		530C-8		501A-13
	322C-11		530C-28		501B-13
	322D-16		530D-8		501C-13
	322E-11		530D-28		501D-13
	322F-11		530E-8		501E-13
	322G-16		530E-28		501F-13
	322H-16		530F-8		513A-32
	322J-16		530F-28		513B-32
	322K-11	09407-14403	322A-2		513C-32
	322L-11		322D-2		513D-32
09403-11320	322M-16		322G-2		553A-7
	146A-42		322H-2		553A-16
	146B-42		322J-2		553B-7
	146C-42		322M-2		553B-16
	146D-42		553A-15		553C-7
	146E-42		553B-15		553C-16
	146F-42		553C-15		553D-7
	146G-42		553D-15		553D-16
	146H-42		561A-16		561A-18
	146J-42		561B-16		561A-22
	146K-42		561C-16		561B-18
	146L-42		561D-16		561B-22
	146M-42	09407-14407	303A-8		561C-18
09403-12406	163A-7		303B-8		561C-22
	163D-7		303C-8		561D-18
	163G-7		303D-8		561D-22
	163H-7		303E-8		600A-28
	163J-7		322A-3		600B-28
	163M-7		322A-10		600C-28
	167C-15		322B-6		600D-28
	167F-15		322C-6		600E-28
	167G-15		322D-3		600F-28
	167L-15		322D-10	09408-00008	322A-17
09403-12415	167M-15		322E-6		322B-12
	167A-14		322F-6		322D-17
	167B-14		322G-3		322E-12
	167C-14		322G-10		322G-17
	167D-14		322H-3		322H-17
	167E-14		322H-10		322J-17
	167F-14		322J-3		322K-12
	167G-14		322J-10		322M-17
	167H-14		322K-6	09408-00024	322C-12
	167J-14		322L-6		322F-12
	167K-14		322M-3		322L-12
	167L-14		322M-10	09408-00070	162A-9
	167M-14		338A-23	09408-00159	310A-10
09407-08401	530A-8		338B-23		310B-10
	530A-28		338C-23		310C-10

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	310D-10		160K-16		501D-5
	310E-10		160L-16		501D-8
	310F-10		160M-16		501D-23
	310G-10	09440-09041	206A-16		501E-5
	310H-10		206B-14		501E-8
	310J-10		206C-14		501E-23
	310K-10		206D-16		501F-5
	310L-10		206E-14		501F-8
	310M-10		206F-14		501F-23
09408-00184	553A-8		206G-16	09481-05501	501A-3
	553B-8		206H-16		501B-3
	553C-8		206J-16		501C-3
	553D-8		206K-14		501D-3
	561A-11		206L-14		501E-3
	561B-11		206M-16		501F-3
	561C-11	09440-12027	444A-20		600A-10
	561D-11		444B-20		600B-10
09408-00252	322A-18		444C-20		600C-10
	322D-18		444D-20		600D-10
	322G-18		444E-20		600E-10
	322H-18		444F-20		600F-10
	322J-18	09440-18002	175A-6	09481-10501	322A-6
	322M-18	09441-17001	335A-21		322B-3
	322B-13		335B-21		322C-3
	322C-13		335D-21		322D-6
	322E-13		335E-21		322E-3
	322F-13		335H-21		322F-3
	322K-13		335J-21		322G-6
	322L-13		335K-21		322H-6
09408-00296	322A-19	09471-12028	501A-11		322J-6
	322B-14		501A-19-1		322K-3
	322C-14		501B-11		322L-3
	322D-19		501B-19-1		322M-6
	322E-14		501C-11		450A-53
	322F-14		501C-19-1		450B-55
	322G-19		501D-11		450C-53
	322H-19		501D-19-1		450D-55
	322J-19		501E-11		450E-53
	322K-14		501E-19-1		450F-55
	322L-14		501F-11		513A-13
	322M-19		501F-19-1		513B-13
09420-03009	160A-16	09471-12103	501A-5		513C-13
	160B-16		501A-8		513D-13
	160C-16		501A-23		546A-2
	160D-16		501B-5		546B-2
	160E-16		501B-8		546C-2
	160F-16		501B-23		546D-2
	160G-16		501C-5		546E-2
	160H-16		501C-8		546F-2
	160J-16		501C-23	09481-30501	322A-7

[illegible]

SUZUKI DF9.9B/15A/20A PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION

Technical Readiness Group, Quality Administration Department

300 Takatsuka, Minami, Hamamatsu, Japan

Reprint Prohibited

SUZUKI MOTOR CORPORATION