SUZUKI

PARTS CATALOGUE

DF100A/115A/140A

DF100AT
DF115AT/AZ
DF115AST
DF140AT/AZ

SUZUKI Way of Life!

OUTBOARD MOTOR

E11/E40/E03

2018-7

1ST EDITION

PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF100A/115A/140A production start 2018.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E.NO.	: Engine number	OS	: Over size
F.NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	W/	: With
LH(PORT)	: Left hand side	L,X	: Transom type
RH(STBD)	: Right hand side	SUS	: Stainless steel
～123456	: Up to E.NO.14002F-123456	PTT	: Power trim and tilt
123456～	: From E.NO.14002F-123456		

12 x 34 x 5.6····· Figures in the description column show the dimensions of parts.
ID OD T(or W,L)

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual. When assembling, use "SUZUKI SERVICE MANUAL".

6. MODEL NAME AND ENGINE NUMBER

MODEL	DESTINATION	TYPE	TRANSOM	COLOR	ENGINE No.
DF100AT	E11	10003F	L,X	YAY	10003F-910001～
DF115AT	E11,E40	11503F	L,X	YAY,Y5S	11503F-910001～
DF115AZ	E11,E40	11503Z	L,X	YAY,Y5S	11503Z-910001～
DF115AST	E03	11504F	L,X	YKV	11504F-910001～
DF140AT	E11,E40	14003F	L,X	YAY,Y5S	14003F-910001～
DF140AZ	E11,E40	14003Z	L,X	YAY,Y5S	14003Z-910001～

PREFACE

Quand il devient nécessarie de remplacer des pièces sur SUZUKI MOTEURS HORSBOARD toujours utiliser les PIECES D'ORIGINE SUZUKI qui ont été soumises à des contriles de qualité sévères leur garantissant qualité et performance impeccables.

Ce catalogue de pièces détachées couvre la liste de toutes les pièces de rechange pour SUZUKI DF100A/115A/140A production start 2018.

INSTRUCTIONS POUR UTILISER LE CATALOGUE

1. DIMENSIONS

Les dimensions des pièces dans ce catalogue sont indiquées en unités de millimètres.

2. ABREVIATIONS

Les abréviations utilisées dans ce catalogue sont les suivantes:

AR	: Comme requis	NT	: Nombre de dents
ASSY	: Assemblage	OPT	: Sur option
E.NO.	: Numéro du moteur	OS	: Sur-dimensionné
F.NO.	: Numéro du chfssis	T	: Epaisseur
ID	: Diamètre intérieur	US	: Sous-dimensionné
OD	: Diamètre extérieur	W	: Largeur
L	: Longueur		
LH(PORT)	: Côté gauche		
RH(STBD)	: Côte droit		
～123456	: Jusqu'à E.NO.14002F-123456		
123456～	: Depuis E.NO.14002F-123456		

12 x 34 x 5.6…… Les chiffres dans la colonne remarques montrent les dimensions des pieces comme suit.

ID OD T(or W,L)

→12345-56781 (Nº de pieces) : indique que le numéro des pièces a été ehangé en 12345-56781 et que les nouvelles pièces sont interchange-ables avec les anciennes, mais que celles-cine sont pas interchangeables avec les nouvelles.

←12345-56781 (Nº de pieces) : indique que les anciennes et nouvelles pièces sont interchangeables les unes avec les autres et sont utilisables chacune.

3. PIECES INTERNES DE L'ASSEMBLAGE

Les numéros de pièces qui comportent un point (.) avant la désignation de pièce détachée indique la pièce interne se rapportant à l'assemblage.

4. AVIS DE MODIFICATION

Un bulletin de pièces détachées vous sera envoyé à tout moment opportun quand des changements de pièces ont lieu, y compris les modifications de pièces interchangeables entre les nouvelles et anciennes pièces.

5. A NOTER

5-1. Il existe certaines pièces différentes de celles de rechange pour les modèles de production vu des rainsons administratives et dont l'usage est commun avec celles d'autres modèles.

5-2. Concernant les durites en caoutchouc et les tuyaux en vinyle, ne pas manquer de les couper à la bonne longueur comme indiqué dans le catalogue des pièces détachées ou selon ce qui est utile pour le véhicule affecté.

5-3. Noter que les dessins à la page d'illustration servent à titre de référence pour les numéros de pièces détachées, et non pas comme référence pour l'assemblage. Pour cette dernière opération, se reporter au "MANUEL D'ENTRETIEN SUZUKI".

6. NOM DU MODELE / NUMERO DE SERIE DU MOTEUR

MODELE	DESTINATION	TYPE	HOUTEUR DE BARRE D'ARCASSE	COULEUR	Nº DELA MOTEUR
DF100AT	E11	10003F	L,X	YAY	10003F-910001～
DF115AT	E11,E40	11503F	L,X	YAY,Y5S	11503F-910001～
DF115AZ	E11,E40	11503Z	L,X	YAY,Y5S	11503Z-910001～
DF115AST	E03	11504F	L,X	YKV	11504F-910001～
DF140AT	E11,E40	14003F	L,X	YAY,Y5S	14003F-910001～
DF140AZ	E11,E40	14003Z	L,X	YAY,Y5S	14003Z-910001～

MILLIMETER → INCH CONVERSION CHART
TABLEAU DE CONVERSION DE MILLIMETRES → POUCES

	0	1	2	3	4	5	6	7	8	9
00	.000	.039	.079	.118	.157	.197	.236	.276	.315	.354
10	.394	.433	.472	.512	.551	.591	.630	.669	.709	.748
20	.787	.827	.866	.906	.945	.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.535
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.214	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.031	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

How to read
Mode de lecture


	0	1	2	3	4
00	…	…	…	…	…
10	…	…	…	…	…
20	…	…	…	0.906	…
30	…	…	…	…	…

23 millimeters equal 0.906 in
23 millimètres égalent 0.906 pouce

Contents are subject to change without notice or obligation.


Les matières traitées sont susceptibles d'être modifiées sans préavis obligation de notre part.

FIG.111A




DF140A_E11_010_111A
CYLINDER HEAD

FIG.113A




DF140A_E11_010_113A
CYLINDER BLOCK

FIG.116A




DF140A_E11_010_116A
CRANKSHAFT

FIG.119A




DF140A_E11_010_119A
TIMING CHAIN

FIG.121A




DF140A_E11_010_121A
CAMSHAFT

FIG.122A




DF140A_E11_010_122A
INTAKE MANIFOLD

FIG.134A




DF140A_E11_010_134A
SILENCER

FIG.134B




DF140A_E11_010_134B
SILENCER

FIG.136A




DF140A_E11_010_136A
RING GEAR COVER

FIG.143A




DF140A_E11_010_143A
FUEL VAPOR SEPARATOR

FIG.143B




DF140A_E11_010_143B
FUEL VAPOR SEPARATOR

FIG.144A




DF140A_E11_010_144A
FUEL INJECTOR

FIG.144B




DF140A_E11_010_144B
FUEL INJECTOR

FIG.146A




DF140A_E11_010_146A
FUEL PUMP

FIG.160A




DF140A_E11_010_160A
WATER PUMP

FIG.160B




DF140A_E11_010_160B
WATER PUMP

FIG.162A




DF140A_E11_012_162A
THERMOSTAT

FIG.162B




DF140A_E11_012_162B
THERMOSTAT

FIG.163A




DF140A_E11_012_163A
THROTTLE BODY

FIG.175A




DF140A_E11_012_175A
OIL PUMP

FIG.180A




DF140A_E11_012_180A
OIL PAN

FIG.180B




DF140A_E11_012_180B
OIL PAN

FIG.204A




DF140A_E11_012_204A
CLUTCH SHAFT

FIG.210A




DF140A_E11_012_210A
SHIFT ROD

FIG.210B




DF140A_E11_018_210B
SHIFT ROD

FIG.220A




DF140A_E11_018_220A
TRANSMISSION

FIG.220B




DF140A_E11_018_220B
TRANSMISSION

FIG.220C




DF140A_E11_018_220C
TRANSMISSION

FIG.301A




DF140A_E11_018_301A
STARTING MOTOR

FIG.303A




DF140A_E11_018_303A
MAGNETO

FIG.307A




DF140A_E11_018_307A
IGNITION COIL

FIG.311A




DF140A_E11_018_311A
RECTIFIER

FIG.315A




DF140A_E11_018_315A
SENSOR

FIG.315B




DF140A_E11_018_315B
SENSOR

FIG.322A




DF140A_E11_018_322A
HARNESS

FIG.322B




DF140A_E11_018_322B
HARNESS

FIG.322C




DF140A_E11_018_322C
HARNESS

FIG.326A




DF140A_E11_018_326A
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326B




DF140A_E11_018_326B
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326C




DF140A_E11_018_326C
PTT SWITCH/ENGINE CONTROL UNIT

FIG.331A




DF140A_E11_018_331A
KEY-LESS START

FIG.331B




DF140A_E11_018_331B
KEY-LESS START

FIG.335A




DF140A_E11_018_335A
CLAMP BRACKET

FIG.335B




DF140A_E11_018_335B
CLAMP BRACKET

FIG.335C




DF140A_E11_018_335C
CLAMP BRACKET

FIG.335D




DF140A_E11_018_335D
CLAMP BRACKET

FIG.335E




DF140A_E11_018_335E
CLAMP BRACKET

FIG.335F




DF140A_E11_018_335F
CLAMP BRACKET

FIG.336A




DF140A_E11_018_336A
SWIVEL BRACKET

FIG.336B




DF140A_E11_018_336B
SWIVEL BRACKET

FIG.336C




DF140A_E11_018_336C
SWIVEL BRACKET

FIG.336D




DF140A_E11_018_336D
SWIVEL BRACKET

FIG.337A




DF140A_E11_018_337A
TRIM CYLINDER

FIG.337B




DF140A_E11_018_337B
TRIM CYLINDER

FIG.337C




DF140A_E11_018_337C
TRIM CYLINDER

FIG.337D




DF140A_E11_018_337D
TRIM CYLINDER

FIG.340A




DF140A_E11_018_340A
PTT MOTOR

FIG.340B




DF140A_E11_018_340B
PTT MOTOR

FIG.401A




DF140A_E11_018_401A
ENGINE HOLDER

FIG.401B




DF140A_E11_018_401B
ENGINE HOLDER

FIG.405A




DF140A_E11_018_405A
DRIVE SHAFT HOUSING

FIG.405B




DF140A_E11_018_405B
DRIVE SHAFT HOUSING

FIG.407A




DF140A_E11_018_407A
GEAR CASE

FIG.407B




DF140A_E11_018_407B
GEAR CASE

FIG.407C




DF140A_E11_012_407C
GEAR CASE

FIG.407D




DF140A_E11_012_407D
GEAR CASE

FIG.407E




DF140A_E11_012_407E
GEAR CASE

FIG.407F




DF140A_E11_012_407F
GEAR CASE

FIG.410A




DF140A_E11_012_410A
SIDE COVER

FIG.410B




DF140A_E11_012_410B
SIDE COVER

FIG.410C




DF140A_E11_012_410C
SIDE COVER

FIG.420A




DF140A_E11_012_420A
ENGINE COVER

FIG.420B




DF140A_E11_012_420B
ENGINE COVER

FIG.420C




DF140A_E11_012_420C
ENGINE COVER

FIG.420D




DF140A_E11_012_420D
ENGINE COVER

FIG.420E




DF140A_E11_012_420E
ENGINE COVER

FIG.420F




DF140A_E11_012_420F
ENGINE COVER

FIG.432A




DF140A_E11_012_432A
FUEL TANK

FIG.442A




DF140A_E11_012_442A
DRAG LINK

FIG.460A




DF140A_E11_012_460A
METER

FIG.460B




DF140A_E11_018_460B
METER

FIG.475A




DF140A_E11_018_475A
SQUEEZE PUMP

FIG.475B




DF140A_E11_018_475B
SQUEEZE PUMP

FIG.501A




DF140A_E11_018_501A
OPT:METER

FIG.501B




DF140A_E11_018_501B
OPT:METER

FIG.501C




DF140A_E11_018_501C
OPT:METER

FIG.507A




DF140A_E11_018_507A
OPT:WATER PRESSURE GAUGE SUB KIT

FIG.508A




DF140A_E11_018_508A
OPT:REMOTE CONTROL

FIG.508B




DF140A_E11_018_508B
OPT:REMOTE CONTROL

FIG.509A




DF140A_E11_018_509A
OPT:REMOTE CONTROL (1)

FIG.510A




DF140A_E11_018_510A
OPT:REMOTE CONTROL (2)

FIG.517A




DF140A_E11_018_517A
OPT:CONCEALED REMOCON (1)

FIG.518A




DF140A_E11_018_518A
OPT:CONCEALED REMOCON (2)

FIG.521A




DF140A_E11_018_521A
OPT:HARNESS

FIG.530A




DF140A_E11_018_530A
OPT:SWITCH

FIG.535A




DF140A_E11_018_535A
OPT:KEY LESS START

FIG.541A




DF140A_E11_018_541A
OPT:REMOTE CONTROL ASSY DUAL (1)

FIG.542A




DF140A_E11_018_542A
OPT:REMOTE CONTROL ASSY DUAL (2)

FIG.544A




DF140A_E11_018_544A
OPT:REMOTE CONTROL ASSY SINGLE (1)

FIG.545A




DF140A_E11_018_545A
OPT:REMOTE CONTROL ASSY SINGLE (2)

FIG.570A




DF140A_E11_018_570A
OPT:TILLER HANDLE

FIG.585A




DF140A_E11_018_585A
OPT:GASKET SET

FIG.601A



DF140A_E11_018_601A
OPT:MULTI FUNCTION GAUGE (1)

FIG.602A



DF140A_E11_018_602A
OPT:MULTI FUNCTION GAUGE (2)

FIG.111A




FIG.111A (1-B-2) CYLINDER HEAD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-90J11	HEAD, CYLINDER	1	
2	09103-06266	.BOLT (6X40)	21	
3	09206-08001	.PIN (8X11)	18	
4	11115-85FA1-001	GUIDE, VALVE (OS:0.3)	16	OPT
5	11261-93J00	COVER, PROTECTION ANODE	2	
6	09280-22019	O RING (D:1.9,ID:21.8)	2	
7	55321-87J01	ANODE, PROTECTION	2	
8	09103-06281	BOLT (6X14)	2	
9	01550-08207	BOLT	2	
10	11117-89J00	BOLT, CYLINDER HEAD	10	
11	11141-92J01	GASKET, CYLINDER HEAD	1	
12	09116-08125	BOLT (8X50)	8	
13	04211-13189	PIN	2	
14	11170-90J11	COVER, CYLINDER HEAD	1	
15	11173-90J00	PLATE, BREATHER	1	
16	11179-90J00	GASKET, SPARK PLUG HOLE	4	
17	11189-90J00	GASKET, CYLINDER HEAD COVER	1	
18	11382-93J00	CAP, OIL FILLER	1	
19	18498-90J21	PROTECTOR, BREATHER HOSE	1	
20	09280-26006	O RING (D:3.1,ID:26.4)	1	
21	09355-13207-00B	HOSE (13X20X2000)	1	L:2000->660
22	09401-20409	CLIP	2	
23	01547-06257	BOLT	11	
24	01547-06557	BOLT	4	
25	02112-0612A	SCREW	7	
26	09482-00427	SPARK PLUG (BKR6E)	4	NGK

FIG.113A




FIG.113A (1-B-3) CYLINDER BLOCK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11291-90J10	HOOK, ENGINE	1	
2	01550-1230C	BOLT	2	
3	11300-92J40	BLOCK, CYLINDER	1	
4	11117-90J10	.BOLT, CRANKCASE	10	
5	11216-90J10	.GASKET, OIL GALLERY PLUG	3	
6	09248-18011	.PLUG (18X8)	2	
7	09248-18014	.PLUG (18X8)	1	
8	11330-90J00	.COVER, CRANKCASE WTR JKT	1	
9	11332-90J00	.O RING, WTR JKT COVER	1	
10	09206-13019	.PIN (10.4X13X16)	5	
11	01550-06207	.BOLT	8	
12	01550-08407	.BOLT	10	
13	11112-90J00	.PLUG, OIL VENTURI	1	
14	09246-05006	PLUG (1/8PT,H:8)	1	
15	11261-93J00	COVER, PROTECTION ANODE	1	
16	09280-22019	O RING (D:1.9,ID:21.8)	1	
17	55321-87J01	ANODE, PROTECTION	1	
18	09103-06281	BOLT (6X14)	1	
19	01550-08207	BOLT	1	

FIG.116A




FIG.116A (1-B-4) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12111-92J00	PISTON	4	
2	12140-92J10	RING SET, PISTON	4	
3	12151-86FA0	PIN, PISTON	4	
4	09381-21002	SNAP RING	8	
5	12160-92J10	CONNROD ASSY	4	
6	12163-35F00	.BOLT, CONNROD	8	
7	04221-04089	.PIN	8	
8-1	12100-92841-0A0	BEARING SET, CONNROD (GREEN)	4	
8-2	12100-92840-025	BEARING SET, CONNROD (US:0.25)	4	OPT
9	12220-92J00	CRANKSHAFT (NT:29)	1	
10	09202-05027	.PIN (5X8.8)	1	
11-1	12340-85FB3-0A0	BEARING SET, CRANKSHAFT	5	GREEN
11-2	12340-85FB3-0B0	BEARING SET, CRANKSHAFT	5	BLACK
11-3	12340-85FB3-0C0	BEARING SET, CRANKSHAFT	5	NON
11-4	12340-85FB3-0D0	BEARING SET, CRANKSHAFT	5	YELLOW
11-5	12340-85FB3-0E0	BEARING SET, CRANKSHAFT	5	BLUE
11-6	12300-85854-0AA	BEARING SET, CRANKSHAFT	5	OPT
		(US:0.25)		RED/GREEN
11-7	12300-85854-0BA	BEARING SET, CRANKSHAFT	5	OPT
		(US:0.25)		RED/BLACK
11-8	12300-85854-0CA	BEARING SET, CRANKSHAFT	5	OPT
		(US:0.25)		RED
11-9	12300-85854-0DA	BEARING SET, CRANKSHAFT	5	OPT
		(US:0.25)		RED/YELLOW
11-10	12300-85854-0EA	BEARING SET, CRANKSHAFT	5	OPT
		(US:0.25)		RED/BLUE
12-1	12300-85830	BEARING SET, CRANK THRUST	1	
12-2	12300-85830-012	BEARING SET, CRANK THRUST	1	OPT
		(OS:0.12)		
13	09283-52006	OIL SEAL (52X70X10)	1	
14	12100-92J10-050	PISTON SET (OS:0.50)	4	OPT
15	12140-92J10-050	.RING SET, PISTON (OS:0.50)	4	OPT

FIG.119A




FIG.119A (1-B-5) TIMING CHAIN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12732-90J00	GEAR, DRIVEN (NT:18)	1	
2	12741-90J01	SPROCKET, CAM SHAFT TIMING (NT:29)	2	
3	09103-12049	BOLT (12X25)	2	
4	12733-90J00	PLUG, DRIVEN GEAR	1	
5	04221-05109	PIN	2	
6	09262-35068	BEARING (35X62X14)	1	UPPER
7	09280-22022	O RING (D:1.9,ID:21.8)	1	
8	08331-41269	CIRCLIP	1	
9	12761-90J00	CHAIN, TIMING	1	
10	12771-90J00	GUIDE, TIMING CHAIN	1	
11	12810-90J00	TENSIONER, TIMING CHAIN	1	
12	12813-73G00	.PAD, TIMING CHAIN TENSIONER	1	
13	12812-90J00	SPACER, TIMING CHAIN TENSIONER	1	
14	12831-90J02	ADJUSTER, TENSIONER	1	
15	01421-0616A	STUD BOLT	1	
16	01550-0616A	BOLT	2	
17	01550-0620A	BOLT	1	
18	01550-0835A	BOLT	1	
19	08316-1006A	NUT	1	

FIG.121A




FIG.121A (1-B-6) CAMSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12711-92J00	CAMSHAFT, INTAKE	1	
2	12720-92J10	CAMSHAFT, EXHAUST	1	
3	12891-69G00	TAPPET	16	
4-1	12892-69G10-218	SHIM, TAPPET (T:2.175)	AR	
4-2	12892-69G10-220	SHIM, TAPPET (T:2.200)	AR	
4-3	12892-69G10-223	SHIM, TAPPET (T:2.225)	AR	
4-4	12892-69G10-225	SHIM, TAPPET (T:2.250)	AR	
4-5	12892-69G10-228	SHIM, TAPPET (T:2.275)	AR	
4-6	12892-69G10-230	SHIM, TAPPET (T:2.300)	AR	
4-7	12892-69G10-233	SHIM, TAPPET (T:2.325)	AR	
4-8	12892-69G10-235	SHIM, TAPPET (T:2.350)	AR	
4-9	12892-69G10-238	SHIM, TAPPET (T:2.375)	AR	
4-10	12892-69G10-240	SHIM, TAPPET (T:2.400)	AR	
4-11	12892-69G10-243	SHIM, TAPPET (T:2.425)	AR	
4-12	12892-69G10-245	SHIM, TAPPET (T:2.450)	AR	
4-13	12892-69G10-248	SHIM, TAPPET (T:2.475)	AR	
4-14	12892-69G10-250	SHIM, TAPPET (T:2.500)	AR	
4-15	12892-69G10-253	SHIM, TAPPET (T:2.525)	AR	
4-16	12892-69G10-255	SHIM, TAPPET (T:2.550)	AR	
4-17	12892-69G10-258	SHIM, TAPPET (T:2.575)	AR	
4-18	12892-69G10-260	SHIM, TAPPET (T:2.600)	AR	
4-19	12892-69G10-263	SHIM, TAPPET (T:2.625)	AR	
4-20	12892-69G10-265	SHIM, TAPPET (T:2.650)	AR	
4-21	12892-69G10-268	SHIM, TAPPET (T:2.675)	AR	
4-22	12892-69G10-270	SHIM, TAPPET (T:2.700)	AR	
4-23	12892-69G10-273	SHIM, TAPPET (T:2.725)	AR	
4-24	12892-69G10-275	SHIM, TAPPET (T:2.750)	AR	
4-25	12892-69G10-278	SHIM, TAPPET (T:2.775)	AR	
4-26	12892-69G10-280	SHIM, TAPPET (T:2.800)	AR	
4-27	12892-69G10-283	SHIM, TAPPET (T:2.825)	AR	
4-28	12892-69G10-285	SHIM, TAPPET (T:2.850)	AR	
4-29	12892-69G10-288	SHIM, TAPPET (T:2.875)	AR	
4-30	12892-69G10-290	SHIM, TAPPET (T:2.900)	AR	
4-31	12892-69G10-293	SHIM, TAPPET (T:2.925)	AR	

FIG.121A




FIG.121A (1-B-7) CAMSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
4-32	12892-69G10-295	SHIM, TAPPET (T:2.950)	AR	
4-33	12892-69G10-298	SHIM, TAPPET (T:2.975)	AR	
4-34	12892-69G10-300	SHIM, TAPPET (T:3.000)	AR	
5	12911-86FA2	VALVE, INTAKE	8	
6	12915-86F51	VALVE, EXHAUST	8	
7	12921-90J01	SPRING, VALVE	16	
8	12931-90J00	RETAINER, VALVE SPRING	16	
9	12932-85FA0	COTTER, VALVE	32	
10	12933-86510	SEAT, VALVE SPRING	16	
11	09289-06003	OIL SEAL (6X12.8X10.2)	16	

FIG.122A




FIG.122A (1-B-8) INTAKE MANIFOLD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-90J11	MANIFOLD, INTAKE	1	
2	13119-90J00	GASKET, INTAKE MANIFOLD	1	
3	18134-77E00	GASKET, IAC VALVE	1	
4	18137-77E00	VALVE, IAC	1	
5	18141-90J00	HOSE, IAC	1	
6	09329-12004	CUSHION	1	
7	01421-08357	STUD BOLT	1	
8	01421-08507	STUD BOLT	1	
9	01550-06207	BOLT	2	
10	01550-08407	BOLT	8	
11	01550-08757	BOLT	1	
12	04211-11129	PIN	2	
13	08316-10087	NUT	2	
14	18148-90J00	FILTER, IAC HOSE	1	

DF140A_E11_019_122A
INTAKE MANIFOLD

FIG.134A




FIG.134A (1-B-9) SILENCER (DF100AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13710-99E00	ARRESTER, FLAME	1	
2	13810-90J01	SILENCER	1	
3	13820-90J00	HOLDER, FLAME ARRESTER	1	
4	13840-90J00	DUCT, SILENCER	1	
5	13851-90J00	GROMMET, SILENCER	1	
6	09169-06075	WASHER	5	
7	09320-09039	CUSHION	5	
8	09116-06215	BOLT (6X30)	5	

DF100AT E11

FIG.134B




FIG.134B (1-B-10) SILENCER (DF115AT)(DF115AZ)(DF140AT)(DF140AZ)(DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13710-99E00	ARRESTER, FLAME	1	
2	13810-90J01	SILENCER	1	
3	13813-92J00	HOLDER, FLAME ARRESTER	1	
4	13840-90J00	DUCT, SILENCER	1	
5	13851-90J00	GROMMET, SILENCER	1	
6	09169-06075	WASHER	5	
7	09320-09039	CUSHION	5	
8	09116-06215	BOLT (6X30)	5	

DF115AT E11
DF115AT E40
DF115AZ E11
DF115AZ E40
DF140AT E11
DF140AT E40
DF140AZ E11
DF140AZ E40
DF115AST E03

FIG.136A

FIG.136A (1-B-11) RING GEAR COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11510-90J00	COVER, RING GEAR	1	
2	11512-99E00	CUSHION, RING GEAR COVER	2	
3	01550-06207	BOLT	1	
4	69711-93E10	LABEL, S.I.G.P.	1	
5	61494-90J01	LABEL, OIL	1	




FIG.143A




FIG.143A (1-B-12) FUEL VAPOR SEPARATOR (E11)(E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15600-92J20	SEPARATOR ASSY, FUEL VAPOR	1	
2	13370-88L00	.VALVE ASSY, NEEDLE	1	
3	15200-92J00	.PUMP ASSY, FUEL	1	
4	15626-92J00	.SEAL	1	
5	15628-99E00	.SCREW (L:15)	5	
6	15629-99E10	.SCREW, DRAIN	1	
7	15641-88L00	.SPACER	1	
8	15642-88L00	.FILTER ASSY	1	
9	15650-99E00	.FLOAT	1	
10	15654-88L00	.PIN	1	
11	15683-87J00	.HOSE, DRAIN (L:120)	1	
12	15760-88L00	.REGULATOR ASSY	1	
13	15644-88L00	.O RING	1	
14	15645-88L00	.HOLDER, REGULATOR	1	
15	02112-0408A	.SCREW	1	
16	15648-92J00	.RING	1	
17	15643-88L10	.JOINT	1	
18	15641-88L31	.BUSH	1	
19	15641-88L51	.BUSH	1	
20	15642-88L10	.FILTER	1	
21	15612-88L00	.COVER	1	
22	15613-88L00	.O RING	1	
23	15614-88L00	.SCREW	3	
24	02142-0408B	.SCREW	1	
25	15613-92J00	.GASKET	1	

DF140A_E11_019_143A
FUEL VAPOR SEPARATOR

FIG.143A




FIG.143A (1-B-13) FUEL VAPOR SEPARATOR (E11)(E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
26	09116-06217	BOLT (6X30)	3	
27	09169-06090	WASHER	3	
28	09320-08076	GROMMET	1	
29	15691-92J00	CUSHION	3	
30	09352-50003-680	HOSE (5X8.2X680)	1	
31	09401-08412	CLIP	1	
32	18498-88L01	PROTECTOR, EVAP HOSE (L:610)	1	
33	09403-13408	CLAMP	2	
34	09408-00302	CLAMP	1	
35	01550-06127	BOLT	2	

DF100AT E11
DF115AT E11
DF115AZ E11
DF140AT E11
DF140AZ E11
DF115AST E03

DF140A_E11_019_143A
FUEL VAPOR SEPARATOR

FIG.143B




FIG.143B (1-B-14) FUEL VAPOR SEPARATOR (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15600-92J30	SEPARATOR ASSY, FUEL VAPOR	1	
2	13370-88L10	.VALVE ASSY, NEEDLE	1	
3	15200-92J10	.PUMP ASSY, FUEL	1	
4	15626-92J10	.SEAL	1	
5	15628-99E00	.SCREW (L:15)	5	
6	15629-99E10	.SCREW, DRAIN	1	
7	15641-88L10	.SPACER	1	
8	15642-88L00	.FILTER ASSY	1	
9	15650-99E00	.FLOAT	1	
10	15654-88L00	.PIN	1	
11	15683-87J00	.HOSE, DRAIN (L:120)	1	
12	15760-88L00	.REGULATOR ASSY	1	
13	15644-88L10	.O RING	1	
14	15645-88L00	.HOLDER, REGULATOR	1	
15	13614-89J00	.SCREW	1	
16	13614-93J00	.SCREW	1	
17	15643-88L10	.JOINT	1	
18	15641-88L31	.BUSH	1	
19	15641-88L51	.BUSH	1	
20	15642-88L10	.FILTER	1	
21	15612-88L00	.COVER	1	
22	15613-88L00	.O RING	1	
23	15614-88L00	.SCREW	3	
24	15648-92J00	.RING	1	
25	15613-92J00	.GASKET	1	
26	09116-06217	BOLT (6X30)	3	
27	09169-06090	WASHER	3	

DF140A_E11_019_143B
FUEL VAPOR SEPARATOR

FIG.143B




FIG.143B (1-B-15) FUEL VAPOR SEPARATOR (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09320-08076	GROMMET	1	
29	15691-92J00	CUSHION	3	
30	09352-50003-680	HOSE (5X8.2X680)	1	
31	09401-08412	CLIP	1	
32	18498-88L01	PROTECTOR, EVAP HOSE (L:610)	1	
33	09403-13408	CLAMP	2	
34	09408-00302	CLAMP	1	
35	01550-06127	BOLT	2	

DF115AT E40
DF115AZ E40
DF140AT E40
DF140AZ E40

DF140A_E11_019_143B
FUEL VAPOR SEPARATOR

FIG.144A




FIG.144A (1-C-2) FUEL INJECTOR (E11)(E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-92J00	HOSE, FUEL (SEPARATOR TO DLVY)	1	
2	15710-82K50	INJECTOR, FUEL	4	
3	15716-65DT0	.GROMMET SET	4	
4	15735-58B00	INSULATOR, DELIVERY PIPE	2	
5	15751-92J00	PIPE, DELIVERY	1	
6	18498-87J41	PROTECTOR	1	
7	09168-12013	GASKET (11.8X22X1.2)	3	
8	09320-08062	CUSHION	4	
9	09360-12008	UNION	1	
10	09363-08004	UNION	1	
11	09401-11425	CLIP	2	
12	01421-08407	STUD BOLT	2	
13	01550-12167	BOLT	1	
14	08316-10087	NUT	2	

DF100AT E11
DF115AT E11
DF115AZ E11
DF140AT E11
DF140AZ E11
DF115AST E03

FIG.144B




FIG.144B (1-C-3) FUEL INJECTOR (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-92J00	HOSE, FUEL (SEPARATOR TO DLVY)	1	
2	15710-82K50	INJECTOR, FUEL	4	
3	15716-65DT0	.GROMMET SET	4	
4	15735-58B00	INSULATOR, DELIVERY PIPE	2	
5	15751-92J00	PIPE, DELIVERY	1	
6	18498-87J41	PROTECTOR	1	
7	15762-90J00	GASKET, UNION	3	
8	09320-08062	CUSHION	4	
9	09360-12013	UNION	1	
10	15830-90J00	JOINT, FUEL MAIN	1	
11	09401-11425	CLIP	2	
12	01421-08407	STUD BOLT	2	
13	09247-12013	PLUG (12X16)	1	
14	08316-10087	NUT	2	

DF115AT E40
DF115AZ E40
DF140AT E40
DF140AZ E40

FIG.146A




FIG.146A (1-C-4) FUEL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-90J11	PUMP, FUEL	1	
2	15190-92J10	HOSE, FUEL (JOINT TO FILTER)	1	
3	09343-70503-600	HOSE (7X12X600)	1	L:600->60 FILTER TO PUMP
4	15410-92J00	FILTER, FUEL	1	
5	15412-92J00	.FILTER, FUEL	1	
6	15411-92J00	.CAP, FUEL FILTER	1	
7	15413-92J00	.CASE, FUEL FILTER	1	
8	15415-92J00	.SEAL, FUEL FILTER	1	
9	09408-00050	CLIP	1	
10	15421-92J00	BRACKET, FUEL FILTER	1	
11	18498-96J21	PROTECTOR, FUEL HOSE (370)	2	
12	18498-89J51	PROTECTOR, FUEL HOSE (200)	1	
13	09280-26005	O RING (D:2.4,ID:26.2)	1	
14	15192-92J00	HOSE, FUEL (PUMP TO SEPARATOR)	1	
15	09401-11423	CLIP	5	
16	01550-08167	BOLT	1	
17	01550-06257	BOLT	2	
18	08316-10087	NUT	1	
19	15419-92J00	CAP, JOINT	1	

DF140A_E11_019_146A
FUEL PUMP

FIG.160A




FIG.160A (1-C-5) WATER PUMP (E11)(E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-92J00	CASE, WATER PUMP	1	
2	17461-90J01	IMPELLER, WATER PUMP	1	
3	17471-92J00	PANEL, PUMP CASE UNDER	1	
4	17472-87E10	GASKET, PUMP CASE PANEL	1	
5-1	17561-90J03	TUBE, WATER (L)	1	W/TRANSOM(L)
5-2	17561-90J13	TUBE, WATER (X)	1	W/TRANSOM(X)
6	17562-90J00	BUSH, WATER TUBE UPPER	1	
7	17563-87D00	BUSH, WATER TUBE LOWER	1	
8	17564-87D00	BUSH, WATER PUMP CASE	1	
9	17631-90J00	FILTER, WATER PORT SIDE	1	
10	17632-90J00	FILTER, WATER STBD SIDE	1	
11	17635-90J00	PLUG, SUB WATER TUBE	1	
12	09116-08131	BOLT (8X45)	4	
13	09125-05046	SCREW (5X12)	2	
14	09161-16008	WASHER (15.8X26X1)	2	
15	09202-06031	PIN (6X12)	2	
16	09420-05009	KEY	1	
17	09132-04034	SCREW (4X18)	2	
18	17413-92J01	SLEEVE, WATER PUMP CASE	1	
19	17416-92J10	SEALING, WATER PUMP CASE	1	
20	17612-90J00	SPACER, WATER TUBE	1	W/TRANSOM(X)
21	17400-92J21	KIT, WATER PUMP REPAIR	1	OPT

DF140A_E11_019_160A
WATER PUMP

FIG.160A




FIG.160A (1-C-6) WATER PUMP (E11)(E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	17500-90J10	KIT, WATER SUB TUBE	1	OPT
23	17520-90J00	.TUBE, WATER SUB	1	OPT
24	17563-87D00	.BUSH, WATER TUBE LOWER	1	OPT
25	17635-87E00	.FILTER, WATER SUB	1	OPT
26	55332-87D01	.RUBBER, EXHAUST SEAL	1	OPT
27	55333-87D02	.PLATE, EXHAUST SEAL	1	OPT
28	09125-06063	.SCREW (6X10)	1	OPT

DF100AT E11
DF115AT E11
DF115AZ E11
DF140AT E11
DF140AZ E11
DF115AST E03

FIG.160B




FIG.160B (1-C-7) WATER PUMP (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-92J00	CASE, WATER PUMP	1	
2	17461-90J01	IMPELLER, WATER PUMP	1	
3	17471-92J10	PANEL, PUMP CASE UNDER	1	
4	17472-87E10	GASKET, PUMP CASE PANEL	1	
5-1	17561-90J03	TUBE, WATER (L)	1	W/TRANSOM(L)
5-2	17561-90J13	TUBE, WATER (X)	1	W/TRANSOM(X)
6	17562-90J00	BUSH, WATER TUBE UPPER	1	
7	17563-87D00	BUSH, WATER TUBE LOWER	1	
8	17564-87D00	BUSH, WATER PUMP CASE	1	
9	17631-90J00	FILTER, WATER PORT SIDE	1	
10	17632-90J00	FILTER, WATER STBD SIDE	1	
11	17635-90J00	PLUG, SUB WATER TUBE	1	
12	09116-08131	BOLT (8X45)	4	
13	09125-05046	SCREW (5X12)	2	
14	09161-16008	WASHER (15.8X26X1)	2	
15	09202-06031	PIN (6X12)	2	
16	09420-05009	KEY	1	
17	09132-04034	SCREW (4X18)	2	
18	17413-92J11	SLEEVE, WATER PUMP CASE	1	
19	17416-92J10	SEALING, WATER PUMP CASE	1	
20	17612-90J00	SPACER, WATER TUBE	1	W/TRANSOM(X)

DF140A_E11_019_160B
WATER PUMP

FIG.160B




FIG.160B (1-C-8) WATER PUMP (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21	17400-92J10	KIT, WATER PUMP REPAIR	1	OPT
22	17500-90J10	KIT, WATER SUB TUBE	1	OPT
23	17520-90J00	.TUBE, WATER SUB	1	OPT
24	17563-87D00	.BUSH, WATER TUBE LOWER	1	OPT
25	17635-87E00	.FILTER, WATER SUB	1	OPT
26	55332-87D01	.RUBBER, EXHAUST SEAL	1	OPT
27	55333-87D02	.PLATE, EXHAUST SEAL	1	OPT
28	09125-06063	.SCREW (6X10)	1	OPT

DF115AT E40
DF115AZ E40
DF140AT E40
DF140AZ E40

FIG.162A




FIG.162A (1-C-9) THERMOSTAT (DF100AT)(DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11196-90J00	HOSE, WATER RETURN	1	
2	17611-90J00-YAY	COVER, WATER PRESS VALVE (BLACK)	1	
3	17660-90J00	VALVE, WATER PRESSURE	1	
4-1	17670-90J20	THERMOSTAT (50sC)	1	
4-2	17670-90J10	THERMOSTAT (71sC)	1	OPT
5	17680-90J00	COVER, THERMOSTAT	1	
6	17711-90J00	3 WAY, WATER HOSE	1	
7	09116-06121	BOLT (6X25)	2	
8	09280-26006	O RING (D:3.1,ID:26.4)	1	
9	09352-11153-600	HOSE (11X15X600)	1	L:600->50 HOLDER TO 3 WAY
10	09352-50903-600	HOSE (5X9X600)	1	L:600->180 3WAY TO SEPARATOR
11	09352-50903-600	HOSE (5X9X600)	1	L:600->440 3WAY TO CRKC LOWER
12	09352-50903-600	HOSE (5X9X600)	1	L:600->450 3WAY TO THERMO
13	09352-50903-600	HOSE (5X9X600)	1	L:600->580 SEPARATOR TO HLDR
14	09352-50903-00B	HOSE (5X9X2000)	1	L:2000->610 3WAY TO IND
15	17712-92J00	HOSE, WATER	1	CRKC UPPER TO 3WAY
16	09367-06002	JOINT, 3 WAY	1	
17	09401-08413	CLIP	11	
18	09401-14409	CLIP	2	
19	09401-31407	CLIP	2	
20	09408-00024	CLIP (ID:23)	1	
21	01550-06257	BOLT	3	

DF100AT E11
DF115AST E03

DF140A_E11_019_162A
THERMOSTAT

FIG.162B




FIG.162B (1-C-10) THERMOSTAT (DF115AT)(DF115AZ)(DF140AT)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11196-90J00	HOSE, WATER RETURN	1	
2-1	17611-90J00-YAY	COVER, WATER PRESS VALVE (BLACK)	1	
2-2	17611-90J00-Y5S	COVER, WATER PRESS VALVE (WHITE)	1	
3	17660-90J00	VALVE, WATER PRESSURE	1	
4-1	17670-90J20	THERMOSTAT (50sC)	1	
4-2	17670-90J10	THERMOSTAT (71sC)	1	OPT
5	17680-90J00	COVER, THERMOSTAT	1	
6	17711-90J00	3 WAY, WATER HOSE	1	
7	09116-06121	BOLT (6X25)	2	
8	09280-26006	O RING (D:3.1,ID:26.4)	1	
9	09352-11153-600	HOSE (11X15X600)	1	L:600->50 HOLDER TO 3 WAY
10	09352-50903-600	HOSE (5X9X600)	1	L:600->180 3WAY TO SEPARATOR
11	09352-50903-600	HOSE (5X9X600)	1	L:600->440 3WAY TO CRKC LOWER
12	09352-50903-600	HOSE (5X9X600)	1	L:600->450 3WAY TO THERMO
13	09352-50903-600	HOSE (5X9X600)	1	L:600->580 SEPARATOR TO HLDR
14	09352-50903-00B	HOSE (5X9X2000)	1	L:2000->610 3WAY TO IND
15	17712-92J00	HOSE, WATER	1	CRKC UPPER TO 3WAY
16	09367-06002	JOINT, 3 WAY	1	
17	09401-08413	CLIP	11	

DF140A_E11_019_162B
THERMOSTAT

FIG.162B




FIG.162B (1-C-11) THERMOSTAT (DF115AT)(DF115AZ)(DF140AT)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
18	09401-14409	CLIP	2	
19	09401-31407	CLIP	2	
20	09408-00024	CLIP (ID:23)	1	
21	01550-06257	BOLT	3	

DF115AT E11
DF115AT E40
DF115AZ E11
DF115AZ E40
DF140AT E11
DF140AT E40
DF140AZ E11
DF140AZ E40

DF140A_E11_019_162B
THERMOSTAT

FIG.163A




FIG.163A (1-C-12) THROTTLE BODY

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-92J11	BODY ASSY, THROTTLE	1	
2	13421-90J01	GASKET, THROTTLE BODY	1	
3	01550-08557	BOLT	4	
4	13510-90J00	ROD, THROTTLE	1	
5	09205-02006	.SPRING PIN (2X12)	1	
6	19115-90J00	HOLDER, THROTTLE LEVER	1	
7	19121-90J00	LEVER, THROTTLE NO.1	1	
8	19130-92J00	ROD, THROTTLE NO.2	1	
9	19131-95502	CONNECTOR, THROTTLE ROD	1	
10	19140-92J00	LEVER, THROTTLE NO.2	1	
11	67473-89J00	PIN, REMOCON CONNECTOR	1	
12	09119-05010	PIVOT	1	
13	09140-05005	NUT	1	
14	09160-06046	WASHER (6.5X20X1.5)	2	
15	09180-06186	SPACER (6.2X12.6X21)	1	
16	01550-06167	BOLT	3	
17	01550-06357	BOLT	1	

FIG.175A




FIG.175A (1-C-13) OIL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12632-92J12	GEAR, OIL PUMP DRIVE (NT:41)	1	
2	16113-92J11	GEAR, OIL PUMP DRIVEN (NT:20)	1	
3	16400-90J00	PUMP ASSY, OIL	1	
4	16440-99E00	VALVE, OIL RELIEF	1	
5	16520-90J00	STRAINER, OIL PUMP	1	
6	09168-16002	GASKET (16X22X2)	1	
7	09181-12158	SHIM (12X20X0.5)	1	
8	09261-05006	PIN (5X18)	1	
9	09280-22020	O RING (D:2.4,ID:21.8)	2	
10	01547-0625A	BOLT	1	
11	01547-0635A	BOLT	2	
12	01550-0616A	BOLT	3	
13	08331-3112A	CIRCLIP	1	
14	16510-61A31	FILTER, OIL	1	

FIG.180A




FIG.180A (1-C-14) OIL PAN (DF100AT)(DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11489-90J00	GASKET, OIL PAN	1	
2	11501-90J04-YAY	PAN, OIL (BLACK)	1	
3	17913-99E12	PLUG, WATER	1	
4	43112-99E00	PIPE, EXHAUST	1	
5	61150-99E00	COVER, WATER INDICATOR	1	
6	09280-09005	.O RING (D:1.9,ID:8.6)	1	
7	61155-99E01	TUBE, WATER INDICATOR	1	
8	09116-08128	BOLT (8X40)	3	
9	09116-10129	BOLT (10X160)	8	
10	09168-12012	GASKET (12.5X20X2.5)	1	
11	09248-12009	PLUG (12X18.65)	1	OIL DRAIN
12	09280-13005	O RING (D:3.5,ID:12.8)	1	
13	16910-90J10	GAUGE, OIL LEVEL	1	
14	16930-90J01	GUIDE, OIL LEVEL	1	
15	09280-09008	O RING (D:2.1,ID:8.8)	1	
16	01550-06127	BOLT	1	

DF100AT E11
DF115AST E03

FIG.180B




FIG.180B (1-C-15) OIL PAN (DF115AT)(DF115AZ)(DF140AT)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11489-90J00	GASKET, OIL PAN	1	
2-1	11501-90J04-YAY	PAN, OIL (BLACK)	1	
2-2	11501-90J04-Y5S	PAN, OIL (WHITE)	1	
3	17913-99E12	PLUG, WATER	1	
4	43112-99E00	PIPE, EXHAUST	1	
5	61150-99E00	COVER, WATER INDICATOR	1	
6	09280-09005	.O RING (D:1.9,ID:8.6)	1	
7	61155-99E01	TUBE, WATER INDICATOR	1	
8	09116-08128	BOLT (8X40)	3	
9	09116-10129	BOLT (10X160)	8	
10	09168-12012	GASKET (12.5X20X2.5)	1	
11	09248-12009	PLUG (12X18.65)	1	OIL DRAIN
12	09280-13005	O RING (D:3.5,ID:12.8)	1	
13	16910-90J10	GAUGE, OIL LEVEL	1	
14	16930-90J01	GUIDE, OIL LEVEL	1	
15	09280-09008	O RING (D:2.1,ID:8.8)	1	
16	01550-06127	BOLT	1	

DF115AT E11
DF115AT E40
DF115AZ E11
DF115AZ E40
DF140AT E11
DF140AT E40
DF140AZ E11
DF140AZ E40

FIG.204A




FIG.204A (1-D-2) CLUTCH SHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-92J00	LEVER, CLUTCH	1	
2	21151-92J00	HOLDER, CLUTCH LEVER	1	
3	21210-92J00	SHAFT, CLUTCH	1	
4	21230-92J01	ARM, CLUTCH SHAFT	1	
5	22511-99011	NIPPLE, GREASE	1	
6-1	23111-90J02	ROD, CLUTCH (L)	1	W/TRANSOM(L)
6-2	23111-90J12	ROD, CLUTCH (X)	1	W/TRANSOM(X)
7	23115-92J00	LINK, CLUTCH LEVER	1	
8	09160-06094	WASHER (6.5X15X1.0)	2	
9	09204-01006	PIN	2	
10	09248-12011	PLUG (12X9)	1	
11	09306-06004	BUSH	2	
12	09306-10001	BUSH	2	
13	09383-08004	E RING	1	
14	01550-06307	BOLT	2	
15	11118-95J00	PLUG, NOTCH SPRING	1	
16	21131-93J00	BUSH, CLUTCH LEVER	1	
17	09205-10006	SPRING PIN (10.2X10)	1	
18	09260-10005	BALL	1	
19	09403-13408	CLAMP	1	
20	09440-07071	SPRING	1	
21	01550-06127	BOLT	1	

FIG.210A




FIG.210A (1-D-3) SHIFT ROD (DF100AT)(DF115AT)(DF140AT)(DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	25131-92J00	YOKE, SHIFTER	1	
2	25141-92J01	HOUSING, SHIFT ROD GUIDE	1	
3	25222-90J00	COVER, SFT GUIDE HSG OIL SEAL	1	
4	25232-90J00	MAGNET, GEAR CASE	2	
5	25321-92J10	SLIDER, SHIFT HORIZONTAL	1	
6-1	25111-92J00	ROD ASSY, SHIFT (L)	1	W/TRANSOM(L)
6-2	25111-92J10	ROD ASSY, SHIFT (X)	1	W/TRANSOM(X)
7	41226-97E00	BUSH	1	
8	29116-93J00	BOLT (6X20)	2	
9	09205-04014	SPRING PIN (4X14)	2	
10	09280-69001	O RING (D:3.1,ID:68.5)	1	
11	09283-10011	OIL SEAL (10X22X8)	2	

DF100AT E11
DF115AT E11
DF115AT E40
DF140AT E11
DF140AT E40
DF115AST E03

FIG.210B




FIG.210B (1-D-4) SHIFT ROD (DF115AZ)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	25131-92J00	YOKE, SHIFTER	1	
2	25141-92J01	HOUSING, SHIFT ROD GUIDE	1	
3	25222-90J00	COVER, SFT GUIDE HSG OIL SEAL	1	
4	25232-90J00	MAGNET, GEAR CASE	2	
5	25321-92J20	SLIDER, SHIFT HORIZONTAL	1	
6-1	25111-92J00	ROD ASSY, SHIFT (L)	1	W/TRANSOM(L)
6-2	25111-92J10	ROD ASSY, SHIFT (X)	1	W/TRANSOM(X)
7	41226-97E00	BUSH	1	
8	29116-93J00	BOLT (6X20)	2	
9	09205-04014	SPRING PIN (4X14)	2	
10	09280-69001	O RING (D:3.1,ID:68.5)	1	
11	09283-10011	OIL SEAL (10X22X8)	2	

DF115AZ E11
DF115AZ E40
DF140AZ E11
DF140AZ E40

FIG.220A




FIG.220A (1-D-5) TRANSMISSION (DF100AT)(DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57110-92J60	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-2	57110-92J70	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	57133-90J02	COLLAR, DRIVE SHAFT	1	
3	09265-25046	BEARING (25X52X19.25)	1	
4	57300-92861	PINION/GEAR SET (NT:25)	1	
5	09140-14024	NUT	1	
6	57500-87873	SHIM SET, DRIVE SHAFT	1	
7-1	09181-40186	.SHIM (T:0.50)	1	
7-2	09181-41002	.SHIM (T:0.55)	1	
7-3	09181-41003	.SHIM (T:0.60)	1	
7-4	09181-41004	.SHIM (T:0.65)	1	
7-5	09181-41005	.SHIM (T:0.70)	1	
7-6	09181-41006	.SHIM (T:0.75)	1	
7-7	09181-40190	.SHIM (T:0.80)	1	
7-8	09181-41008	.SHIM (T:0.85)	1	
7-9	09181-41009	.SHIM (T:0.90)	1	
7-10	09181-41010	.SHIM (T:0.95)	1	
7-11	09181-40195	.SHIM (T:1.00)	1	
7-12	09181-41012	.SHIM (T:1.05)	1	
7-13	09181-41013	.SHIM (T:1.10)	1	
7-14	09181-41014	.SHIM (T:1.15)	1	
8	57500-87861	SHIM SET, PROP SHAFT REV	1	
9-1	08211-30382	.WASHER (T:1.5)	1	
9-2	09160-30036	.WASHER (T:1.7)	1	
9-3	09160-30037	.WASHER (T:1.9)	1	
9-4	09160-30038	.WASHER (T:2.1)	1	
9-5	09160-30039	.WASHER (T:2.3)	1	
9-6	09160-30041	.WASHER (T:2.4)	1	
9-7	09160-30042	.WASHER (T:2.6)	1	

FIG.220A




FIG.220A (1-D-6) TRANSMISSION (DF100AT)(DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
9-8	09160-30043	.WASHER (T:2.7)	1	
9-9	09160-30044	.WASHER (T:2.8)	1	
10	09160-70002	WASHER (70X95X5.25)	1	FWD GEAR
11-1	09181-45003	SHIM (T:1.0)	1	REV GEAR
11-2	09181-45004	SHIM (T:1.1)	1	REV GEAR
11-3	09181-45005	SHIM (T:1.2)	1	REV GEAR
11-4	09181-45006	SHIM (T:1.3)	1	REV GEAR
11-5	09181-45007	SHIM (T:1.4)	1	REV GEAR
11-6	09181-45008	SHIM (T:1.5)	1	REV GEAR
11-7	09181-45009	SHIM (T:1.6)	1	REV GEAR
12	57500-92813	SHIM SET, FWD GEAR	1	FWD GEAR
13-1	09181-70001	.SHIM (T:0.70)	1	FWD GEAR
13-2	09181-70002	.SHIM (T:0.80)	1	FWD GEAR
13-3	09181-70003	.SHIM (T:0.90)	1	FWD GEAR
13-4	09181-70004	.SHIM (T:1.00)	1	FWD GEAR
13-5	09181-70006	.SHIM (T:0.60)	1	FWD GEAR
13-6	09181-70009	.SHIM (T:0.65)	1	FWD GEAR
13-7	09181-70010	.SHIM (T:0.75)	1	FWD GEAR
13-8	09181-70011	.SHIM (T:0.85)	1	FWD GEAR
13-9	09181-70012	.SHIM (T:0.95)	1	FWD GEAR
13-10	09181-70008	.SHIM (T:0.55)	1	FWD GEAR
14	09269-70001	BEARING (70X95X4)	1	
15	57610-92J20	SHAFT ASSY, PROPELLER	1	
16	57621-92J20	SHIFTER, CLUTCH DOG	1	
17	09202-07002	PIN (7X48)	1	
18	57631-92J00	PIN, CONNECTOR	1	
19	09440-09040	SPRING	1	
20	06111-07004	BALL	2	NO.1
21	06111-11004	BALL	2	NO.2

FIG.220A




FIG.220A (1-D-7) TRANSMISSION (DF100AT)(DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	09440-49004	SPRING	1	
23	57616-90J00	SPACER, CLUTCH DOG FWD	1	
24	56120-92J01-YAY	HOUSING, PROP SFT BRG (BLACK)	1	
25	56123-92J00	.WASHER, OIL SEAL PROTECTOR	1	
26	09263-30051	.BEARING (30X37X26)	1	
27	09280-97001	.O RING (D:3.5,ID:95)	1	
28	09282-30007	.OIL SEAL (30X50X6)	2	
29	08113-62090	.BEARING	1	
30	09387-52001	.RING SET	1	
31	09116-08122	BOLT (8X30)	2	
32	56130-90J00	HOUSING, DRIVESHAFT BRG	1	
33	09280-46004	.O RING (D:3.5,ID:45.7)	1	
34	09282-24004	.OIL SEAL (24X40X7)	2	
35	09117-08110	BOLT (8X25)	4	
36	56140-92J00	HOUSING, FWD GEAR BRG	1	
37	09206-09012	.PIN (7.4X9X10)	1	
38	09263-50001	.BEARING (50X62X25)	1	

DF100AT E11
DF115AST E03

FIG.220B




FIG.220B (1-D-8) TRANSMISSION (DF115AT)(DF140AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57110-92J60	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-2	57110-92J70	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	57133-90J02	COLLAR, DRIVE SHAFT	1	
3	09265-25046	BEARING (25X52X19.25)	1	
4	57300-92861	PINION/GEAR SET (NT:25)	1	
5	09140-14024	NUT	1	
6	57500-87873	SHIM SET, DRIVE SHAFT	1	
7-1	09181-40186	.SHIM (T:0.50)	1	
7-2	09181-41002	.SHIM (T:0.55)	1	
7-3	09181-41003	.SHIM (T:0.60)	1	
7-4	09181-41004	.SHIM (T:0.65)	1	
7-5	09181-41005	.SHIM (T:0.70)	1	
7-6	09181-41006	.SHIM (T:0.75)	1	
7-7	09181-40190	.SHIM (T:0.80)	1	
7-8	09181-41008	.SHIM (T:0.85)	1	
7-9	09181-41009	.SHIM (T:0.90)	1	
7-10	09181-41010	.SHIM (T:0.95)	1	
7-11	09181-40195	.SHIM (T:1.00)	1	
7-12	09181-41012	.SHIM (T:1.05)	1	
7-13	09181-41013	.SHIM (T:1.10)	1	
7-14	09181-41014	.SHIM (T:1.15)	1	
8	57500-87861	SHIM SET, PROP SHAFT REV	1	
9-1	08211-30382	.WASHER (T:1.5)	1	
9-2	09160-30036	.WASHER (T:1.7)	1	
9-3	09160-30037	.WASHER (T:1.9)	1	
9-4	09160-30038	.WASHER (T:2.1)	1	
9-5	09160-30039	.WASHER (T:2.3)	1	

FIG.220B




FIG.220B (1-D-9) TRANSMISSION (DF115AT)(DF140AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
9-6	09160-30041	.WASHER (T:2.4)	1	
9-7	09160-30042	.WASHER (T:2.6)	1	
9-8	09160-30043	.WASHER (T:2.7)	1	
9-9	09160-30044	.WASHER (T:2.8)	1	
10	09160-70002	WASHER (70X95X5.25)	1	FWD GEAR
11-1	09181-45003	SHIM (T:1.0)	1	REV GEAR
11-2	09181-45004	SHIM (T:1.1)	1	REV GEAR
11-3	09181-45005	SHIM (T:1.2)	1	REV GEAR
11-4	09181-45006	SHIM (T:1.3)	1	REV GEAR
11-5	09181-45007	SHIM (T:1.4)	1	REV GEAR
11-6	09181-45008	SHIM (T:1.5)	1	REV GEAR
11-7	09181-45009	SHIM (T:1.6)	1	REV GEAR
12	57500-92813	SHIM SET, FWD GEAR	1	FWD GEAR
13-1	09181-70001	.SHIM (T:0.70)	1	FWD GEAR
13-2	09181-70002	.SHIM (T:0.80)	1	FWD GEAR
13-3	09181-70003	.SHIM (T:0.90)	1	FWD GEAR
13-4	09181-70004	.SHIM (T:1.00)	1	FWD GEAR
13-5	09181-70006	.SHIM (T:0.60)	1	FWD GEAR
13-6	09181-70009	.SHIM (T:0.65)	1	FWD GEAR
13-7	09181-70010	.SHIM (T:0.75)	1	FWD GEAR
13-8	09181-70011	.SHIM (T:0.85)	1	FWD GEAR
13-9	09181-70012	.SHIM (T:0.95)	1	FWD GEAR
13-10	09181-70008	.SHIM (T:0.55)	1	FWD GEAR
14	09269-70001	BEARING (70X95X4)	1	
15	57610-92J20	SHAFT ASSY, PROPELLER	1	
16	57621-92J20	SHIFTER, CLUTCH DOG	1	
17	09202-07002	PIN (7X48)	1	

FIG.220B




FIG.220B (1-D-10) TRANSMISSION (DF115AT)(DF140AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
18	57631-92J00	PIN, CONNECTOR	1	
19	09440-09040	SPRING	1	
20	06111-07004	BALL	2	NO.1
21	06111-11004	BALL	2	NO.2
22	09440-49004	SPRING	1	
23	57616-90J00	SPACER, CLUTCH DOG FWD	1	
24-1	56120-92J01-YAY	HOUSING, PROP SFT BRG (BLACK)	1	
24-2	56120-92J01-Y5S	HOUSING, PROP SFT BRG (WHITE)	1	
25	56123-92J00	.WASHER, OIL SEAL PROTECTOR	1	
26	09263-30051	.BEARING (30X37X26)	1	
27	09280-97001	.O RING (D:3.5,ID:95)	1	
28	09282-30007	.OIL SEAL (30X50X6)	2	
29	08113-62090	.BEARING	1	
30	09387-52001	.RING SET	1	
31	09116-08122	BOLT (8X30)	2	
32	56130-90J00	HOUSING, DRIVESHAFT BRG	1	
33	09280-46004	.O RING (D:3.5,ID:45.7)	1	
34	09282-24004	.OIL SEAL (24X40X7)	2	
35	09117-08110	BOLT (8X25)	4	
36	56140-92J00	HOUSING, FWD GEAR BRG	1	
37	09206-09012	.PIN (7.4X9X10)	1	
38	09263-50001	.BEARING (50X62X25)	1	

DF115AT E11
DF115AT E40
DF140AT E11
DF140AT E40

FIG.220C




FIG.220C (1-D-11) TRANSMISSION (DF115AZ)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	56120-92J12-YAY	HOUSING, PROP SFT BRG (BLACK)	1	
1-2	56120-92J12-Y5S	HOUSING, PROP SFT BRG (WHITE)	1	
2	56123-92J00	.WASHER, OIL SEAL PROTECTOR	1	
3	09263-30051	.BEARING (30X37X26)	1	
4	09263-50001	.BEARING (50X62X25)	1	
5	09280-97001	.O RING (D:3.5,ID:95)	1	
6	09282-30007	.OIL SEAL (30X50X6)	2	
7	09387-52001	.RING SET	1	
8	56130-90J00	HOUSING, DRIVE SHAFT BRG	1	
9	09280-46004	.O RING (D:3.5,ID:45.7)	1	
10	09282-24004	.OIL SEAL (24X40X7)	2	
11	56140-92J30	HOUSING, REV GEAR BRG	1	
12	09206-09012	.PIN (7.4X9X10)	1	
13	09263-45004	.BEARING (45X52X16)	1	
14	09116-08122	BOLT (8X30)	2	
15	09117-08110	BOLT (8X25)	4	
16-1	57110-92J60	SHAFT, DRIVE (L)	1	W/TRANSOM(L)
16-2	57110-92J70	SHAFT, DRIVE (X)	1	W/TRANSOM(X)
17	57133-90J02	COLLAR, DRIVE SHAFT	1	
18	09265-25046	BEARING (25X52X19.25)	1	
19	57300-92871	PINION/GEAR SET (NT:25)	1	
20	09140-14024	NUT	1	
21	57500-87873	SHIM SET, DRIVE SHAFT	1	
22-1	09181-40186	.SHIM (T:0.50)	1	
22-2	09181-41002	.SHIM (T:0.55)	1	
22-3	09181-41003	.SHIM (T:0.60)	1	
22-4	09181-41004	.SHIM (T:0.65)	1	

FIG.220C




FIG.220C (1-D-12) TRANSMISSION (DF115AZ)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22-5	09181-41005	.SHIM (T:0.70)	1	
22-6	09181-41006	.SHIM (T:0.75)	1	
22-7	09181-40190	.SHIM (T:0.80)	1	
22-8	09181-41008	.SHIM (T:0.85)	1	
22-9	09181-41009	.SHIM (T:0.90)	1	
22-10	09181-41010	.SHIM (T:0.95)	1	
22-11	09181-40195	.SHIM (T:1.00)	1	
22-12	09181-41012	.SHIM (T:1.05)	1	
22-13	09181-41013	.SHIM (T:1.10)	1	
22-14	09181-41014	.SHIM (T:1.15)	1	
23-1	09160-35015	WASHER (T:0.60)	1	PROP SAFT REV
23-2	09160-35014	WASHER (T:0.70)	1	PROP SAFT REV
23-3	09160-35013	WASHER (T:0.80)	1	PROP SAFT REV
23-4	09160-35006	WASHER (T:0.90)	1	PROP SAFT REV
23-5	09160-35008	WASHER (T:0.95)	1	PROP SAFT REV
23-6	09160-35002	WASHER (T:1.00)	1	PROP SAFT REV
23-7	09160-35009	WASHER (T:1.05)	1	PROP SAFT REV
23-8	09160-35003	WASHER (T:1.10)	1	PROP SAFT REV
23-9	09160-35010	WASHER (T:1.15)	1	PROP SAFT REV
24	09160-60011	WASHER (60X85X3)	1	REV GEAR
25-1	09160-60008	WASHER (T:0.8)	1	REV GEAR
25-2	09160-60009	WASHER (T:0.9)	1	REV GEAR
25-3	09160-60003	WASHER (T:1.0)	1	REV GEAR
25-4	09160-60004	WASHER (T:1.1)	1	REV GEAR
25-5	09160-60005	WASHER (T:1.2)	1	REV GEAR
25-6	09160-60006	WASHER (T:1.3)	1	REV GEAR
25-7	09160-60007	WASHER (T:1.4)	1	REV GEAR

FIG.220C




FIG.220C (1-D-13) TRANSMISSION (DF115AZ)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
26	09160-70005	WASHER (70X95X2)	1	FWD GEAR
27	57500-92813	SHIM SET, FWD GEAR	1	FWD GEAR
28-1	09181-70006	.SHIM (T:0.60)	1	FWD GEAR
28-2	09181-70009	.SHIM (T:0.65)	1	FWD GEAR
28-3	09181-70001	.SHIM (T:0.70)	1	FWD GEAR
28-4	09181-70010	.SHIM (T:0.75)	1	FWD GEAR
28-5	09181-70002	.SHIM (T:0.80)	1	FWD GEAR
28-6	09181-70011	.SHIM (T:0.85)	1	FWD GEAR
28-7	09181-70003	.SHIM (T:0.90)	1	FWD GEAR
28-8	09181-70012	.SHIM (T:0.95)	1	FWD GEAR
28-9	09181-70004	.SHIM (T:1.00)	1	FWD GEAR
28-10	09181-70008	.SHIM (T:0.55)	1	FWD GEAR
29	09269-60001	BEARING (60X85X3)	1	REV
30	09269-70001	BEARING (70X95X4)	1	FWD
31	57610-92J31	SHAFT, PROPELLER	1	
32	57621-92J20	SHIFTER, CLUTCH DOG	1	
33	57631-92J00	PIN, CONNECTOR	1	
34	09440-09040	SPRING	1	
35	06111-07004	BALL	2	NO.1
36	06111-11004	BALL	2	NO.2
37	09202-07002	PIN (7X48)	1	
38	09440-49004	SPRING	1	
39	57616-92J00	SPACER, CLUTCH DOG FWD	1	
40	09160-30055	WASHER (30X47X6)	1	PROP SAFT REV
41	09160-30056	WASHER (32X47X3)	1	PROP SAFT REV
42	09269-30014	BEARING (30X47X2)	1	PROP SAFT REV

DF115AZ E11
DF115AZ E40
DF140AZ E11
DF140AZ E40

FIG.301A




FIG.301A (1-D-14) STARTING MOTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-92J00	STARTING MOTOR	1	
2	31150-92J00	.HOUSING, FRONT	1	
3	31170-92J00	.HOUSING, REAR	1	
4	31173-92J00	.HOLDER ASSY, BRUSH	1	
5	31191-92J00	.LEVER, SHIFT	1	
6	31192-92J00	.SCREW SET	1	
7	31220-92J00	.SWITCH ASSY	1	
8	31261-75F10	.BOLT	2	
9	31311-63J00	.ARMATURE	1	
10	31340-92J00	.CLUTCH SET, STARTING MOTOR	1	
11	31312-92J00	..SET, PINION STOPPER	1	
12	31320-92J00	..PINION	1	
13	31341-92J00	..SHAFT, PINION	1	
14	31343-63J00	..INTERNAL GEAR	1	
15	31344-63J00	..PLANETARY GEAR	3	
16	31912-90J00	BAND, STARTING MOTOR	1	
17	31918-92J01	DAMPER, LOWER	1	
18	01550-08207	BOLT	2	
19	01550-10507	BOLT	2	
20	04211-13149	PIN	2	

FIG.303A




FIG.303A (1-D-15) MAGNETO

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32102-92J20	FLYWHEEL	1	
2	32120-92J00	COIL, BATTERY CHARGING	1	
3	32160-92J00	COIL, IGNITION TIMING	1	
4	33220-64L10	SENSOR, CAM POSITION	1	
5	33833-91J00	TUBE	1	L:250->100
6	09103-06231	BOLT (6X35)	4	
7	09103-16004	BOLT (16X50)	1	
8	09160-16048	WASHER (16.5X60X7)	1	
9	01547-06167	BOLT	1	
10	09106-05030	BOLT (5X10)	2	
11	08341-31059	KEY	1	

DF140A_E11_019_303A
MAGNETO

FIG.307A




FIG.307A (1-E-2) IGNITION COIL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33410-90J00	COIL ASSY, IGNITION NO.1	1	
2	33710-90J00	.CORD, HIGH TENSION	1	NO.1
3	33740-90J00	.CORD, HIGH TENSION	1	NO.4
4	33420-90J00	COIL ASSY, IGNITION NO.2	1	
5	33720-90J00	.CORD, HIGH TENSION	1	NO.2
6	33730-90J00	.CORD, HIGH TENSION	1	NO.3
7	09408-00035	CLIP	2	
8	01550-06257	BOLT	4	
9	08322-01067	WASHER	4	

FIG.311A




FIG.311A (1-E-3) RECTIFIER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11261-87E10	COVER, PROTECTION ANODE	2	
2	11265-87E10	GASKET, PROTECTION COVER	2	
3-1	55321-87J01	ANODE, PROTECTION	2	
3-2	55321-87J11	ANODE (MAGNESIUM)	1	OPT
4	09103-06281	BOLT (6X14)	2	
5	14151-90J00	GASKET, RECTIFIER	1	
6	32800-92J00	RECTIFIER	1	
7	32890-92J00	HOLDER, ELECTRIC PARTS	1	
8	09160-06054	WASHER (6.5X22X1.6)	1	
9	09320-10008	CUSHION	2	
10	09320-12011	CUSHION	1	
11	09329-01007	CUSHION	1	
12	29404-93J10	CLAMP	1	
13	01550-06167	BOLT	1	
14	01550-06207	BOLT	4	
15	01550-06307	BOLT	9	
16	01550-06127	BOLT	1	

FIG.315A




FIG.315A (1-E-4) SENSOR (DF100AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13650-52G00	SENSOR, INLET AIR TEMP	1	
2	13655-87J00	GROMMET, AIR TEMP SENSOR	1	
3	18590-68H00	SENSOR, PRESSURE	1	
4	34830-87J20	SENSOR ASSY, EXHAUST TEMP	2	
5	34840-98J03	SENDER ASSY, TRIM	1	
6	18213-98J30	SENSOR, OXYGEN	1	
7	34841-92J00	LEVER, TRIM SENSOR	1	
8	34842-92J01	CAM, TRIM SENSOR UPPER	1	
9	34843-87L00	CAM, TRIM SENSOR LOWER	1	
10	34846-87L00	WASHER, TRIM SENSOR	1	
11	37820-99E02	SWITCH, OIL PRESSURE	1	
12	34845-92J00	BRACKET, TRIM SENSOR	1	
13	02162-05207	SCREW	2	
14	09103-06093	BOLT (6X20)	1	
15	09125-05046	SCREW (5X12)	1	
16	09407-10404	CLAMP (L:100)	1	
17	09407-14407	CLAMP (L:145)	2	
18	09407-18402	CLAMP (L:165)	1	

DF100AT E11

FIG.315B




FIG.315B (1-E-5) SENSOR (DF115AT)(DF115AZ)(DF140AT)(DF140AZ)(DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13650-52G00	SENSOR, INLET AIR TEMP	1	
2	13655-87J00	GROMMET, AIR TEMP SENSOR	1	
3	18590-68H00	SENSOR, PRESSURE	1	
4	34830-87J20	SENSOR ASSY, EXHAUST TEMP	2	
5	18640-78G00	SENSOR ASSY, KNOCK	1	
6	34840-98J03	SENDER ASSY, TRIM	1	
7	18213-98J30	SENSOR, OXYGEN	1	
8	34841-92J00	LEVER, TRIM SENSOR	1	
9	34842-92J01	CAM, TRIM SENSOR UPPER	1	
10	34843-87L00	CAM, TRIM SENSOR LOWER	1	
11	34846-87L00	WASHER, TRIM SENSOR	1	
12	37820-99E02	SWITCH, OIL PRESSURE	1	
13	34845-92J00	BRACKET, TRIM SENSOR	1	
14	02162-05207	SCREW	2	
15	09103-06093	BOLT (6X20)	1	
16	09125-05046	SCREW (5X12)	1	
17	09407-10404	CLAMP (L:100)	1	
18	09407-11401	CLAMP (L:95)	1	
19	09407-14407	CLAMP (L:145)	2	
20	09407-18402	CLAMP (L:165)	1	

DF115AT E11
DF115AT E40
DF115AZ E11
DF115AZ E40
DF140AT E11
DF140AT E40
DF140AZ E11
DF140AZ E40
DF115AST E03

FIG.322A




FIG.322A (1-E-6) HARNESS (DF100AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-90J20	CABLE, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3	36610-92J70	HARNESS ASSY, WIRING	1	
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	38860-76F01	.RELAY ASSY	2	
6	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
7	36721-98L00	.O RING, UPPER COVER	1	
8	36737-98L00	.PULLER, FUSE	1	
9	36738-98L00	.COVER, FUSE CASE UPPER	1	
10	09320-08021	.CUSHION	2	
11	09481-15504	.FUSE (15A)	3	
12	09481-30504	.FUSE (30A)	3	
13	09481-60403	.FUSE (60A)	3	
14	36612-96J00	CAP, TERMINAL	1	
15	36616-90J10	HOLDER, REMOCON CONNECTOR	1	
16	36617-93J10	BRACKET, HARNESS	1	
17	09408-00111	CLAMP	1	
18	02142-06167	SCREW	2	
19	08310-00067	NUT	1	
20	08321-01067	WASHER	1	
21	09407-10404	CLAMP (L:100)	2	
22-1	36625-93J00	LEAD, BATTERY	1	
22-2	36625-93J10	LEAD, BATTERY	1	OPT
23	09481-15501	.FUSE (15A)	1	

DF100AT E11

FIG.322B




FIG.322B (1-E-7) HARNESS (DF115AT)(DF115AZ)(DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-90J20	CABLE, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3	36610-92J60	HARNESS ASSY, WIRING	1	
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	38860-76F01	.RELAY ASSY	2	
6	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
7	36721-98L00	.O RING, UPPER COVER	1	
8	36737-98L00	.PULLER, FUSE	1	
9	36738-98L00	.COVER, FUSE CASE UPPER	1	
10	09320-08021	.CUSHION	2	
11	09481-15504	.FUSE (15A)	3	
12	09481-30504	.FUSE (30A)	3	
13	09481-60403	.FUSE (60A)	3	
14	36612-96J00	CAP, TERMINAL	1	
15	36616-90J10	HOLDER, REMOCON CONNECTOR	1	
16	36617-93J10	BRACKET, HARNESS	1	
17	09408-00111	CLAMP	1	
18	02142-06167	SCREW	2	
19	08310-00067	NUT	1	
20	08321-01067	WASHER	1	
21	09407-10404	CLAMP (L:100)	2	
22-1	36625-93J00	LEAD, BATTERY	1	
22-2	36625-93J10	LEAD, BATTERY	1	OPT
23	09481-15501	.FUSE (15A)	1	

DF115AT E11
DF115AT E40
DF115AZ E11
DF115AZ E40
DF115AST E03

DF140A_E11_019_322B
HARNESS

FIG.322C




FIG.322C (1-E-8) HARNESS (DF140AT)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-90J20	CABLE, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3	36610-92J50	HARNESS ASSY, WIRING	1	
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	33926-78A80	.RESISTOR, TERMINAL	1	
6	38860-76F01	.RELAY ASSY	2	
7	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
8	36721-98L00	.O RING, UPPER COVER	1	
9	36737-98L00	.PULLER, FUSE	1	
10	36738-98L00	.COVER, FUSE CASE UPPER	1	
11	09320-08021	.CUSHION	2	
12	09481-15504	.FUSE (15A)	3	
13	09481-30504	.FUSE (30A)	3	
14	09481-60403	.FUSE (60A)	3	
15	36612-96J00	CAP, TERMINAL	1	
16	36616-90J10	HOLDER, REMOCON CONNECTOR	1	
17	36617-93J10	BRACKET, HARNESS	1	
18	09408-00111	CLAMP	1	
19	02142-06167	SCREW	2	
20	08310-00067	NUT	1	
21	08321-01067	WASHER	1	
22	09407-10404	CLAMP (L:100)	2	
23-1	36625-93J00	LEAD, BATTERY	1	
23-2	36625-93J10	LEAD, BATTERY	1	OPT
24	09481-15501	.FUSE (15A)	1	

DF140AT E11
DF140AT E40
DF140AZ E11
DF140AZ E40

DF140A_E11_019_322C
HARNESS

FIG.326A




FIG.326A (1-E-9) PTT SWITCH/ENGINE CONTROL UNIT (DF100AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37850-92J00	SWITCH ASSY, PTT	1	
2	37856-92J00	.TAPE, PTT SWITCH	1	
3	37857-92J00	BUSH, PTT SWITCH	1	
4	38410-93J21	RELAY, PTT	1	
5	38415-93J20	HOLDER, PTT RELAY	1	
6	33920-92JR1	UNIT, ENGINE CONTROL	1	
7	33925-92J00	CUSHION, ENGINE CONTROL UNIT	1	
8	37721-93J00	SWITCH ASSY, NEUTRAL	1	
9	37726-90J10	BRACKET, NEUTRAL SWITCH	1	
10	09137-04004	SCREW (4X16)	2	
11	09403-06316	CLIP	1	

DF100AT E11

FIG.326B




FIG.326B (1-E-10) PTT SWITCH/ENGINE CONTROL UNIT (DF115AT)(DF115AZ)(DF115AS

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37850-92J00	SWITCH ASSY, PTT	1	
2	37856-92J00	.TAPE, PTT SWITCH	1	
3	37857-92J00	BUSH, PTT SWITCH	1	
4	38410-93J21	RELAY, PTT	1	
5	38415-93J20	HOLDER, PTT RELAY	1	
6	33920-92JQ1	UNIT, ENGINE CONTROL	1	
7	33925-92J00	CUSHION, ENGINE CONTROL UNIT	1	
8	37721-93J00	SWITCH ASSY, NEUTRAL	1	
9	37726-90J10	BRACKET, NEUTRAL SWITCH	1	
10	09137-04004	SCREW (4X16)	2	
11	09403-06316	CLIP	1	

DF115AT E11
DF115AT E40
DF115AZ E11
DF115AZ E40
DF115AST E03

FIG.326C




FIG.326C (1-E-11) PTT SWITCH/ENGINE CONTROL UNIT (DF140AT)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37850-92J00	SWITCH ASSY, PTT	1	
2	37856-92J00	.TAPE, PTT SWITCH	1	
3	37857-92J00	BUSH, PTT SWITCH	1	
4	38410-93J21	RELAY, PTT	1	
5	38415-93J20	HOLDER, PTT RELAY	1	
6	33920-92JP1	UNIT, ENGINE CONTROL	1	
7	33925-92J00	CUSHION, ENGINE CONTROL UNIT	1	
8	37721-93J00	SWITCH ASSY, NEUTRAL	1	
9	37726-90J10	BRACKET, NEUTRAL SWITCH	1	
10	09137-04004	SCREW (4X16)	2	
11	09403-06316	CLIP	1	

DF140AT E11
DF140AT E40
DF140AZ E11
DF140AZ E40

FIG.331A




FIG.331A (1-E-12) KEY LESS START (DF100AT E11)(DF115AT E11)(DF140AT E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32851-93J00	CUSHION, KLS CONTROLLER	1	
2	32980-38F00	HOLDER, KLS CONTROLLER	1	
3	36623-96L10	HARNESS ASSY, KLS CONT	1	
4	36615-96300	.TERMINAL	1	
5	36662-96L10	HARNESSASSY, KLS CAN	1	L:6500+2000
6	37117-96L00	DECAL, KLS	2	
7-1	37171-96L02	CONTROLLER ASSY, KLS 433MHZ	1	
7-2	37171-96L12	CONTROLLER ASSY, KLS 315MHZ	1	
8-1	37172-96L01	REMOCON ASSY, KLS 433MHZ	2	
8-2	37172-96L10	REMOCON ASSY, KLS 315MHZ	2	
9	37173-96L10	HOLDER, KLS PARTS	1	
10	38500-93J90	BUZZER ASSY	1	
11	38860-96L01	RELAY ASSY, KLS	1	
12	09407-14407	CLAMP (L:145)	1	

NOTE: USE FREQUENCY ASSIGNED ON YOUR MARKET.
FOR DETAILES, PLEASE MAKE SURE OF SUZUKI DEALERS.

DF100AT E11
DF115AT E11
DF140AT E11

FIG.331B




FIG.331B (1-E-13) KEY LESS START (DF115AST E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32851-93J00	CUSHION, KLS CONTROLLER	1	
2	32980-38F00	HOLDER, KLS CONTROLLER	1	
3	36623-96L10	HARNESS ASSY, KLS CONT	1	
4	36615-96300	.TERMINAL	1	
5	36662-96L10	HARNESSASSY, KLS CAN	1	L:6500+2000
6	37117-96L00	DECAL, KLS	2	
7-1	37171-96L02	CONTROLLER ASSY, KLS 433MHZ	1	
7-2	37171-96L12	CONTROLLER ASSY, KLS 315MHZ	1	
8-1	37172-96L01	REMOCON ASSY, KLS 433MHZ	2	
8-2	37172-96L10	REMOCON ASSY, KLS 315MHZ	2	
9	37173-96L10	HOLDER, KLS PARTS	1	
10	38500-93J90	BUZZER ASSY	1	
11	38860-96L01	RELAY ASSY, KLS	1	
12	09407-14407	CLAMP (L:145)	1	

NOTE: USE FREQUENCY ASSIGNED ON YOUR MARKET.
FOR DETAILES, PLEASE MAKE SURE OF SUZUKI DEALERS.

DF115AST E03

FIG.335A




FIG.335A (1-E-14) CLAMP BRACKET (DF100AT E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-90J13-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-90J21-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	41130-92J30	SHAFT, CLAMP BRACKET	1	
4	55320-94900	ZINC, PROTECTION	1	
5	09116-06121	.BOLT (6X25)	2	
6-1	09100-12091	BOLT (12X115)	4	
6-2	09100-12090	BOLT (12X150)	1	OPT
7	09159-12014	NUT	4	
8	09159-22006	NUT	1	
9	09160-12128	WASHER (12.5X35X3)	4	
10	09160-12110	WASHER (12.5X22X3)	4	
11	41135-92J00	WASHER, SHAFT	1	
12	09106-10065	BOLT (10X20)	2	
13	09160-10082	WASHER (10.5X19X2)	2	
14	09116-08137	BOLT (8X22)	1	
15	29103-93J00	BOLT, PTT CABLE CLAMP	1	
16	09403-13408	CLAMP	1	
17	45421-90J00	PIN, TILT LOCK	1	OPT
18	09159-14020	NUT	2	OPT
19	55321-94910	ANODE (MAGNESIUM)	1	OPT

DF100AT E11

FIG.335B




FIG.335B (1-E-15) CLAMP BRACKET (DF115AT E11)(DF115AZ E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-90J13-YAY	BRACKET, CLAMP STBD (BLACK)	1	
1-2	41111-90J13-Y5S	BRACKET, CLAMP STBD (WHITE)	1	
2-1	41121-90J21-YAY	BRACKET, CLAMP PORT (BLACK)	1	
2-2	41121-90J21-Y5S	BRACKET, CLAMP PORT (WHITE)	1	
3	41130-92J30	SHAFT, CLAMP BRACKET	1	
4	55320-94900	ZINC, PROTECTION	1	
5	09116-06121	.BOLT (6X25)	2	
6-1	09100-12091	BOLT (12X115)	4	
6-2	09100-12090	BOLT (12X150)	1	OPT
7	09159-12014	NUT	4	
8	09159-22006	NUT	1	
9	09160-12128	WASHER (12.5X35X3)	4	
10	09160-12110	WASHER (12.5X22X3)	4	
11	41135-92J00	WASHER, SHAFT	1	
12	09106-10065	BOLT (10X20)	2	
13	09160-10082	WASHER (10.5X19X2)	2	
14	09116-08137	BOLT (8X22)	1	
15	29103-93J00	BOLT, PTT CABLE CLAMP	1	
16	09403-13408	CLAMP	1	
17	45421-90J00	PIN, TILT LOCK	1	OPT
18	09159-14020	NUT	2	OPT
19	55321-94910	ANODE (MAGNESIUM)	1	OPT

DF115AT E11
DF115AZ E11

FIG.335C




FIG.335C (1-F-2) CLAMP BRACKET (DF115AT E40)(DF115AZ E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-90J13-YAY	BRACKET, CLAMP STBD (BLACK)	1	
1-2	41111-90J13-Y5S	BRACKET, CLAMP STBD (WHITE)	1	
2-1	41121-90J21-YAY	BRACKET, CLAMP PORT (BLACK)	1	
2-2	41121-90J21-Y5S	BRACKET, CLAMP PORT (WHITE)	1	
3	41130-92J30	SHAFT, CLAMP BRACKET	1	
4	55320-94900	ZINC, PROTECTION	1	
5	09116-06121	.BOLT (6X25)	2	
6	09100-12091	BOLT (12X115)	4	
7	09159-12014	NUT	4	
8	09159-22006	NUT	1	
9	09160-12128	WASHER (12.5X35X3)	4	
10	09160-12110	WASHER (12.5X22X3)	4	
11	41135-92J00	WASHER, SHAFT	1	
12	09106-10065	BOLT (10X20)	2	
13	09160-10082	WASHER (10.5X19X2)	2	
14	09116-08137	BOLT (8X22)	1	
15	29103-93J00	BOLT, PTT CABLE CLAMP	1	
16	09403-13408	CLAMP	1	

DF115AT E40
DF115AZ E40

DF140A_E11_019_335C
CLAMP BRACKET

FIG.335D




FIG.335D (1-F-3) CLAMP BRACKET (DF140AT E11)(DF140AZ E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-92J03-YAY	BRACKET, CLAMP STBD (BLACK)	1	
1-2	41111-92J03-Y5S	BRACKET, CLAMP STBD (WHITE)	1	
2-1	41121-92J21-YAY	BRACKET, CLAMP PORT (BLACK)	1	
2-2	41121-92J21-Y5S	BRACKET, CLAMP PORT (WHITE)	1	
3	41130-92J30	SHAFT, CLAMP BRACKET	1	
4	41135-92J00	WASHER, CLAMP BRACKET SHAFT	1	
5	55320-94900	ZINC, PROTECTION	1	
6	09116-06121	.BOLT (6X25)	2	
7-1	09100-12091	BOLT (12X115)	4	
7-2	09100-12090	BOLT (12X150)	1	OPT
8	29103-93J00	BOLT (6X12)	1	
9	09159-12014	NUT	4	
10	09159-22006	NUT	1	
11	09160-12128	WASHER (12.5X35X3)	4	
12	09160-12110	WASHER (12.5X22X3)	4	
13	09106-10065	BOLT (10X20)	2	
14	09160-10082	WASHER (10.5X19X2)	2	
15	45421-87D03	PIN, TILT LOCK	1	
16	09159-14020	NUT	2	
17	09403-13408	CLAMP	1	
18	09116-08137	BOLT (8X22)	1	
19	55321-94910	ANODE (MAGNESIUM)	1	OPT

DF140AT E11
DF140AZ E11

FIG.335E




FIG.335E (1-F-4) CLAMP BRACKET (DF140AT E40)(DF140AZ E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-92J03-YAY	BRACKET, CLAMP STBD (BLACK)	1	
1-2	41111-92J03-Y5S	BRACKET, CLAMP STBD (WHITE)	1	
2-1	41121-92J21-YAY	BRACKET, CLAMP PORT (BLACK)	1	
2-2	41121-92J21-Y5S	BRACKET, CLAMP PORT (WHITE)	1	
3	41130-92J30	SHAFT, CLAMP BRACKET	1	
4	41135-92J00	WASHER, CLAMP BRACKET SHAFT	1	
5	55320-94900	ZINC, PROTECTION	1	
6	09116-06121	.BOLT (6X25)	2	
7	09100-12091	BOLT (12X115)	4	
8	29103-93J00	BOLT (6X12)	1	
9	09159-12014	NUT	4	
10	09159-22006	NUT	1	
11	09160-12128	WASHER (12.5X35X3)	4	
12	09160-12110	WASHER (12.5X22X3)	4	
13	09106-10065	BOLT (10X20)	2	
14	09160-10082	WASHER (10.5X19X2)	2	
15	45421-87D03	PIN, TILT LOCK	1	
16	09159-14020	NUT	2	
17	09403-13408	CLAMP	1	
18	09116-08137	BOLT (8X22)	1	

DF140AT E40
DF140AZ E40

FIG.335F




FIG.335F (1-F-5) CLAMP BRACKET (DF115AST E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-92J03-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-92J21-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	41130-92J30	SHAFT, CLAMP BRACKET	1	
4	41135-92J00	WASHER, CLAMP BRACKET SHAFT	1	
5	55320-94900	ZINC, PROTECTION	1	
6	09116-06121	.BOLT (6X25)	2	
7-1	09100-12091	BOLT (12X115)	4	
7-2	09100-12090	BOLT (12X150)	1	OPT
8	29103-93J00	BOLT (6X12)	1	
9	09159-12014	NUT	4	
10	09159-22006	NUT	1	
11	09160-12128	WASHER (12.5X35X3)	4	
12	09160-12110	WASHER (12.5X22X3)	4	
13	09106-10065	BOLT (10X20)	2	
14	09160-10082	WASHER (10.5X19X2)	2	
15	45421-87D03	PIN, TILT LOCK	1	
16	09159-14020	NUT	2	
17	09403-13408	CLAMP	1	
18	09116-08137	BOLT (8X22)	1	
19	55321-94910	ANODE (MAGNESIUM)	1	OPT

DF115AST E03

FIG.336A




FIG.336A (1-F-6) SWIVEL BRACKET (DF100AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE, GREASE	5	W/TRANSOM(L)
1-2	22511-99011	NIPPLE, GREASE	4	W/TRANSOM(X)
2	36894-95201	LEAD (CLAMP TO SWIVEL)	1	
3	36894-87D00	LEAD (SWIVEL TO MOUNT BRKT)	1	
4-1	43111-90J40-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L)
4-2	43111-90J50-YAY	BRACKET, SWIVEL (UL) (BLACK)	1	W/TRANSOM(X)
5	43211-93J00	BUSH, CLAMP SHAFT SWIVEL	2	
6	43711-97E10	BUSH, STEERING	2	
7-1	43750-90J61-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L)
7-2	43750-90J71-YAY	BRACKET, STEERING (X) (BLACK)	1	W/TRANSOM(X)
8	09125-05050	SCREW (5X8)	3	
9	09125-06063	SCREW (6X10)	2	
10	09160-39001	WASHER (39.5X64X1)	2	
11	09169-28003	WASHER	2	
12	09181-39001	SHIM (39.5X64X0.3)	4	
13	09250-10001	CAP (OD:14)	2	
14	09282-39001	OIL SEAL (39X51X5)	1	
15	09380-38003	CIRCLIP	1	
16	29404-93J10	CLAMP	2	
17	41220-95E13	LEVER, TILT LOCK	1	
18	41221-95E40	LEVER, TILT LOCK PORT	1	
19	41224-95E01	BUSH, TILT STOPPER ROD	2	
20	41225-94400	RUBBER, TILT LOCK LEVER	1	
21	41228-90J00	SPRING, TILT LOCK LEVER	1	
22	41230-95E00	LINK, TILT LOCK LEVER	1	
23	41233-95E10	BRACKET, TILT LOCK SPRING	1	
24	09125-06063	SCREW (6X10)	1	
25	09140-10032	NUT	1	
26	09160-06082	WASHER (6.5X13X1.0)	1	
27	09204-01006	PIN	1	

DF140A_E11_019_336A
SWIVEL BRACKET

FIG.336A




FIG.336A (1-F-7) SWIVEL BRACKET (DF100AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09440-19028	SPRING	1	
29	55127-87D00	UNION, SPEEDOMETER HOSE	1	
30	09355-40805-00B	HOSE (4X8X2000)	1	L:2000->1000
31	09407-10404	CLAMP (L:100)	2	

DF100AT E11

FIG.336B




FIG.336B (1-F-8) SWIVEL BRACKET (DF115AT)(DF115AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE, GREASE	5	W/TRANSOM(L)
1-2	22511-99011	NIPPLE, GREASE	4	W/TRANSOM(X)
2	36894-95201	LEAD (CLAMP TO SWIVEL)	1	
3	36894-87D00	LEAD (SWIVEL TO MOUNT BRKT)	1	
4-1	43111-90J40-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L)
4-2	43111-90J40-Y5S	BRACKET, SWIVEL (L) (WHITE)	1	W/TRANSOM(L)
4-3	43111-90J50-YAY	BRACKET, SWIVEL (UL) (BLACK)	1	W/TRANSOM(X)
4-4	43111-90J50-Y5S	BRACKET, SWIVEL (UL) (WHITE)	1	W/TRANSOM(X)
5	43211-93J00	BUSH, CLAMP SHAFT SWIVEL	2	
6	43711-97E10	BUSH, STEERING	2	
7-1	43750-90J61-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L)
7-2	43750-90J61-Y5S	BRACKET, STEERING (L) (WHITE)	1	W/TRANSOM(L)
7-3	43750-90J71-YAY	BRACKET, STEERING (X) (BLACK)	1	W/TRANSOM(X)
7-4	43750-90J71-Y5S	BRACKET, STEERING (X) (WHITE)	1	W/TRANSOM(X)
8	09125-05050	SCREW (5X8)	3	
9	09125-06063	SCREW (6X10)	2	
10	09160-39001	WASHER (39.5X64X1)	2	
11	09169-28003	WASHER	2	
12	09181-39001	SHIM (39.5X64X0.3)	4	
13	09250-10001	CAP (OD:14)	2	
14	09282-39001	OIL SEAL (39X51X5)	1	
15	09380-38003	CIRCLIP	1	
16	29404-93J10	CLAMP	2	
17	41220-95E13	LEVER, TILT LOCK	1	
18	41221-95E40	LEVER, TILT LOCK PORT	1	
19	41224-95E01	BUSH, TILT STOPPER ROD	2	
20	41225-94400	RUBBER, TILT LOCK LEVER	1	

FIG.336B




FIG.336B (1-F-9) SWIVEL BRACKET (DF115AT)(DF115AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21	41228-90J00	SPRING, TILT LOCK LEVER	1	
22	41230-95E00	LINK, TILT LOCK LEVER	1	
23	41233-95E10	BRACKET, TILT LOCK SPRING	1	
24	09125-06063	SCREW (6X10)	1	
25	09140-10032	NUT	1	
26	09160-06082	WASHER (6.5X13X1.0)	1	
27	09204-01006	PIN	1	
28	09440-19028	SPRING	1	
29	55127-87D00	UNION, SPEEDOMETER HOSE	1	
30	09355-40805-00B	HOSE (4X8X2000)	1	L:2000->1000
31	09407-10404	CLAMP (L:100)	2	

DF115AT E11
DF115AT E40
DF115AZ E11
DF115AZ E40

FIG.336C




FIG.336C (1-F-10) SWIVEL BRACKET (DF140AT)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE, GREASE	4	
2	36894-95201	LEAD (CLAMP TO SWIVEL)	1	
3	36894-87D00	LEAD (SWIVEL TO MOUNT BRKT)	1	
4-1	43111-92J80-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L)
4-2	43111-92J80-Y5S	BRACKET, SWIVEL (L) (WHITE)	1	W/TRANSOM(L)
4-3	43111-92J90-YAY	BRACKET, SWIVEL (UL) (BLACK)	1	W/TRANSOM(X)
4-4	43111-92J90-Y5S	BRACKET, SWIVEL (UL) (WHITE)	1	W/TRANSOM(X)
5	43211-93J00	BUSH, CLAMP SHAFT SWIVEL	2	
6	43711-97E10	BUSH, STEERING	2	
7-1	43750-90J61-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L)
7-2	43750-90J61-Y5S	BRACKET, STEERING (L) (WHITE)	1	W/TRANSOM(L)
7-3	43750-90J71-YAY	BRACKET, STEERING (X) (BLACK)	1	W/TRANSOM(X)
7-4	43750-90J71-Y5S	BRACKET, STEERING (X) (WHITE)	1	W/TRANSOM(X)
8	09125-05050	SCREW (5X8)	3	
9	09125-06063	SCREW (6X10)	2	
10	09160-39001	WASHER (39.5X64X1)	2	
11	09169-28003	WASHER	2	
12	09181-39001	SHIM (39.5X64X0.3)	4	
13	09250-10001	CAP (OD:14)	2	
14	09282-39001	OIL SEAL (39X51X5)	1	
15	09380-38003	CIRCLIP	1	
16	29404-93J10	CLAMP	2	
17	41220-95E13	LEVER, TILT LOCK	1	
18	41221-95E40	LEVER, TILT LOCK PORT	1	
19	41224-95E01	BUSH, TILT STOPPER ROD	2	
20	41225-94400	RUBBER, TILT LOCK LEVER	1	
21	41228-90J00	SPRING, TILT LOCK LEVER	1	

FIG.336C




FIG.336C (1-F-11) SWIVEL BRACKET (DF140AT)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	41230-95E00	LINK, TILT LOCK LEVER	1	
23	41233-95E10	BRACKET, TILT LOCK SPRING	1	
24	09125-06063	SCREW (6X10)	1	
25	09140-10032	NUT	1	
26	09160-06082	WASHER (6.5X13X1.0)	1	
27	09204-01006	PIN	1	
28	09440-19028	SPRING	1	
29	55127-87D00	UNION, SPEEDOMETER HOSE	1	
30	09355-40805-00B	HOSE (4X8X2000)	1	L:2000->1000
31	09407-10404	CLAMP (L:100)	2	

DF140AT E11
DF140AT E40
DF140AZ E11
DF140AZ E40

FIG.336D




FIG.336D (1-F-12) SWIVEL BRACKET (DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE, GREASE	4	
2	36894-95201	LEAD (CLAMP TO SWIVEL)	1	
3	36894-87D00	LEAD (SWIVEL TO MOUNT BRKT)	1	
4-1	43111-92J80-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L)
4-2	43111-92J90-YAY	BRACKET, SWIVEL (UL) (BLACK)	1	W/TRANSOM(X)
5	43211-93J00	BUSH, CLAMP SHAFT SWIVEL	2	
6	43711-97E10	BUSH, STEERING	2	
7-1	43750-90J61-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L)
7-2	43750-90J71-YAY	BRACKET, STEERING (X) (BLACK)	1	W/TRANSOM(X)
8	09125-05050	SCREW (5X8)	3	
9	09125-06063	SCREW (6X10)	2	
10	09160-39001	WASHER (39.5X64X1)	2	
11	09169-28003	WASHER	2	
12	09181-39001	SHIM (39.5X64X0.3)	4	
13	09250-10001	CAP (OD:14)	2	
14	09282-39001	OIL SEAL (39X51X5)	1	
15	09380-38003	CIRCLIP	1	
16	29404-93J10	CLAMP	2	
17	41220-95E13	LEVER, TILT LOCK	1	
18	41221-95E40	LEVER, TILT LOCK PORT	1	
19	41224-95E01	BUSH, TILT STOPPER ROD	2	
20	41225-94400	RUBBER, TILT LOCK LEVER	1	
21	41228-90J00	SPRING, TILT LOCK LEVER	1	
22	41230-95E00	LINK, TILT LOCK LEVER	1	
23	41233-95E10	BRACKET, TILT LOCK SPRING	1	
24	09125-06063	SCREW (6X10)	1	
25	09140-10032	NUT	1	
26	09160-06082	WASHER (6.5X13X1.0)	1	
27	09204-01006	PIN	1	
28	09440-19028	SPRING	1	

FIG.336D




FIG.336D (1-F-13) SWIVEL BRACKET (DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	55127-87D00	UNION, SPEEDOMETER HOSE	1	
30	09355-40805-00B	HOSE (4X8X2000)	1	L:2000->1000
31	09407-10404	CLAMP (L:100)	2	

DF115AST E03

FIG.337A




FIG.337A (1-F-14) TRIM CYLINDER (DF100AT)(DF115AT E11)(DF115AZ E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-90J39	TRIM ASSY, POWER WITH TILT	1	
2	38100-92J13	.MOTOR ASSY, PTT	1	
3	48400-90J03	.MANIFOLD ASSY	1	
4	48611-90J00	.JOINT, METAL	1	
5	48571-87L01	.TANK, RESERVOIR	1	
6	48572-87J10	.PLUG	1	
7	48557-90J00	.O RING	1	
8	48862-87J20	.BOLT	4	
9	48502-90J13	.PUMP ASSY	1	
10	48583-95E00	..JOINT, DRIVE	1	
11	48582-95E01	..FILTER	1	
12	48585-95E00	..O RING	1	
13	48864-93J01	.VALVE, MANUAL	1	
14	48588-90J00	.O RING SET	1	
15	48862-92J20	.BOLT, PUMP NO.1	1	
16	48862-92J30	.BOLT, PUMP NO.2	1	
17	48862-90J21	.BOLT	1	
18	31281-92J10	.BOLT	4	
19	48121-90J00	SHAFT, TILT CYL LOWER	1	
20	48321-90J00	SHAFT, TILT CYL UPPER	1	
21	48326-95E00	BUSH	4	
22	09116-10179	BOLT (10X35)	2	
23	09380-22015	CIRCLIP	2	
24	55321-87J01	ANODE, PROTECTION	1	
25	09103-06281	BOLT (6X14)	1	
26	36895-87D10	LEAD, PTT TO ANODE	1	
27	09125-05050	SCREW (5X8)	1	
28	55321-87J11	ANODE (MAGNESIUM)	1	OPT

DF100AT E11
DF115AT E11
DF115AZ E11

DF140A_E11_019_337A
TRIM CYLINDER

FIG.337B




FIG.337B (1-F-15) TRIM CYLINDER (DF115AT E40)(DF115AZ E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-90J39	TRIM ASSY, POWER WITH TILT	1	
2	38100-92J13	.MOTOR ASSY, PTT	1	
3	48400-90J03	.MANIFOLD ASSY	1	
4	48611-90J00	.JOINT, METAL	1	
5	48571-87L01	.TANK, RESERVOIR	1	
6	48572-87J10	.PLUG	1	
7	48557-90J00	.O RING	1	
8	48862-87J20	.BOLT	4	
9	48502-90J13	.PUMP ASSY	1	
10	48583-95E00	..JOINT, DRIVE	1	
11	48582-95E01	..FILTER	1	
12	48585-95E00	..O RING	1	
13	48864-93J01	.VALVE, MANUAL	1	
14	48588-90J00	.O RING SET	1	
15	48862-92J20	.BOLT, PUMP NO.1	1	
16	48862-92J30	.BOLT, PUMP NO.2	1	
17	48862-90J21	.BOLT	1	
18	31281-92J10	.BOLT	4	
19	48121-90J00	SHAFT, TILT CYL LOWER	1	
20	48321-90J00	SHAFT, TILT CYL UPPER	1	
21	48326-95E00	BUSH	4	
22	09116-10179	BOLT (10X35)	2	
23	09380-22015	CIRCLIP	2	
24	55321-87J01	ANODE, PROTECTION	1	
25	09103-06281	BOLT (6X14)	1	
26	36895-87D10	LEAD, PTT TO ANODE	1	
27	09125-05050	SCREW (5X8)	1	

DF115AT E40
DF115AZ E40

FIG.337C




FIG.337C (1-G-2) TRIM CYLINDER (DF140AT E11)(DF140AZ E11)(DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-96J13	TRIM ASSY, POWER WITH TILT	1	
2	29404-93J10	.CLAMP	1	
3	31281-92J10	.BOLT	4	
4	38100-96J12	.MOTOR ASSY, PTT	1	
5	48502-96J05	.PUMP ASSY	1	
6	48503-96J04	.MANIFOLD SUB ASSY	1	
7	48401-96J02	..PISTON ASSY	1	
8	48601-94900	..PISTON / RAM ASSY	2	
9	48627-95E00	..O RING SET	3	
10	48630-96J03	..HEAD, TRIM CYLINDER	2	
11	48633-94900	..O RING SET (2PCS)	2	
12	48641-96J03	..MANIFOLD, PTT	1	
13	48650-94900	..PISTON, FREE	1	
14	48405-93J00	...O RING SET	1	
15	48615-97E00	...RING SET, PISTON	1	
16	48570-95E01	.RESERVOIR	1	
17	48572-95E00	..CAP	1	
18	48583-95E00	.JOINT, DRIVE	1	
19	48585-95E00	.O RING	1	
20	48588-94900	.O RING SET (6PCS)	1	
21	48861-92J01	.BOLT, RESERVOIR	3	
22	48862-92J20	.BOLT, PUMP NO.1	1	
23	48862-92J30	.BOLT, PUMP NO.2	2	
24	48121-92J00	SHAFT, TILT CYLINDER LOWER	1	
25	48311-96J20	PAD, TRIM CYLINDER RAM	2	
26	48321-87D03	SHAFT, TILT CYLINDER UPPER	1	
27	48326-95E00	BUSH, TILT CYLINDER LOWER	2	

FIG.337C




FIG.337C (1-G-3) TRIM CYLINDER (DF140AT E11)(DF140AZ E11)(DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09116-10179	BOLT (10X35)	2	
29	09140-10031	NUT	2	
30	09162-10005	LOCK WASHER	2	
31	09306-17001	BUSH	2	
32	09380-17009	CIRCLIP	2	
33	36894-87D00	LEAD, PTT TO ANODE (L:165)	1	
34	09125-06063	SCREW (6X10)	1	
35	36895-87D10	LEAD, PTT TO ANODE (L:310)	1	
36	09125-05050	SCREW (5X8)	1	
37	55321-87J11	ANODE (MAGNESIUM)	1	OPT

DF140AT E11
DF140AZ E11
DF115AST E03

FIG.337D




FIG.337D (1-G-4) TRIM CYLINDER (DF140AT E40)(DF140AZ E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-96J13	TRIM ASSY, POWER WITH TILT	1	
2	29404-93J10	.CLAMP	1	
3	31281-92J10	.BOLT	4	
4	38100-96J12	.MOTOR ASSY, PTT	1	
5	48502-96J05	.PUMP ASSY	1	
6	48503-96J04	.MANIFOLD SUB ASSY	1	
7	48401-96J02	..PISTON ASSY	1	
8	48601-94900	..PISTON / RAM ASSY	2	
9	48627-95E00	..O RING SET	3	
10	48630-96J03	..HEAD, TRIM CYLINDER	2	
11	48633-94900	..O RING SET (2PCS)	2	
12	48641-96J03	..MANIFOLD, PTT	1	
13	48650-94900	..PISTON, FREE	1	
14	48405-93J00	...O RING SET	1	
15	48615-97E00	...RING SET, PISTON	1	
16	48570-95E01	.RESERVOIR	1	
17	48572-95E00	..CAP	1	
18	48583-95E00	.JOINT, DRIVE	1	
19	48585-95E00	.O RING	1	
20	48588-94900	.O RING SET (6PCS)	1	
21	48861-92J01	.BOLT, RESERVOIR	3	
22	48862-92J20	.BOLT, PUMP NO.1	1	
23	48862-92J30	.BOLT, PUMP NO.2	2	
24	48121-92J00	SHAFT, TILT CYLINDER LOWER	1	
25	48311-96J20	PAD, TRIM CYLINDER RAM	2	
26	48321-87D03	SHAFT, TILT CYLINDER UPPER	1	
27	48326-95E00	BUSH, TILT CYLINDER LOWER	2	
28	09116-10179	BOLT (10X35)	2	
29	09140-10031	NUT	2	

FIG.337D





FIG.337D (1-G-5) TRIM CYLINDER (DF140AT E40)(DF140AZ E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	09162-10005	LOCK WASHER	2	
31	09306-17001	BUSH	2	
32	09380-17009	CIRCLIP	2	
33	36894-87D00	LEAD, PTT TO ANODE (L:165)	1	
34	09125-06063	SCREW (6X10)	1	
35	36895-87D10	LEAD, PTT TO ANODE (L:310)	1	
36	09125-05050	SCREW (5X8)	1	

DF140AT E40
DF140AZ E40

FIG.340A



DF140A_E11_019_340A
PTT MOTOR

FIG.340A (1-G-6) PTT MOTOR (DF100AT)(DF115AT)(DF115AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-92J13	MOTOR ASSY, PTT	1	
2	31311-94900	.ARMATURE	1	
3	31173-94920	.HOLDER, BRUSH	1	
4	31123-94910	..O RING	1	
5	31133-90J10	..BRUSH SET	1	
6	31133-94910	...BRUSH	1	
7	31136-90J20	..BREAKER ASSY	1	
8	31135-94900	..SPRING	2	
9	33799-97E00	..OIL SEAL	1	
10	31111-94900	.SCREW	2	

DF100AT E11
DF115AT E11
DF115AT E40
DF115AZ E11
DF115AZ E40

FIG.340B




FIG.340B (1-G-7) PTT MOTOR (DF140AT)(DF140AZ)(DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-96J12	MOTOR ASSY, PTT	1	
2	31111-94900	.SCREW, YOKE	3	
3	31173-94920	.HOLDER, BRUSH	1	
4	31123-94910	..O RING	1	
5	31133-90J10	..BRUSH SET, PLUS	1	
6	31133-94910	...BRUSH, PLUS	1	
7	31135-94900	..SPRING	2	
8	31136-90J20	..BREAKER	1	
9	33799-97E00	..OIL SEAL	1	
10	31311-94900	.ARMATURE	1	
11	48502-96J05	PUMP ASSY	1	
12	48582-95E01	.FILTER	1	
13	48864-96J10	.VALVE, MANUAL	1	

DF140AT E11
DF140AT E40
DF140AZ E11
DF140AZ E40
DF115AST E03

DF140A_E11_019_340B
PTT MOTOR

FIG.401A




FIG.401A (1-G-8) ENGINE HOLDER (DF100AT)(DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51110-90851-YAY	HOLDER SET, ENGINE (BLACK)	1	
2	09262-17019	.BEARING (17X35X8)	1	
3	09282-24003	.OIL SEAL (24X36X6)	2	
4	09283-32044	.OIL SEAL (32X47X6)	1	
5	09289-18001	.OIL SEAL (18X30X8)	1	
6	08331-41359	.CIRCLIP	1	
7	09262-35069	.BEARING (35X62X16)	1	
8	51115-90J00	UNION, WATER RETURN	1	
9	51211-90J22	GASKET, ENGINE HOLDER	1	
10	09116-08160	BOLT (8X70)	4	
11	09116-08128	BOLT (8X40)	4	
12	09206-08001	PIN (8X11)	2	
13	09280-26006	O RING (D:3.1,ID:26.4)	1	
14	01550-06257	BOLT	1	
15	29117-93J10	BOLT (8X45)	1	
16	09160-08059	WASHER (8.5X18X1.6)	1	
17	04211-11129	PIN	3	
18	51122-90J00	COVER, MOUNT CASE	1	
19	51123-90J01	GASKET, MOUNT CASE COVER	1	
20	01550-0825A	BOLT	4	
21	54123-90J01	PLATE, UPPER MOUNT	1	
22	54112-90J21	BOLT, UPPER MOUNT	2	
23	54130-90J40	MOUNT, UPPER	2	
24	09159-12014	NUT	2	
25	54114-90J10	WASHER, UPPER MOUNT	2	
26	54125-90J10	MOUNT, UPPER THRUST	1	
27	54148-90J11	COVER, UPPER MOUNT	2	
28	09116-10181	BOLT (10X44)	4	
29	09159-12014	NUT	2	
30	09160-12110	WASHER (12.5X22X3)	2	

DF100AT E11
DF115AST E03

FIG.401B




FIG.401B (1-G-9) ENGINE HOLDER (DF115AT)(DF115AZ)(DF140AT)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	51110-90851-YAY	HOLDER SET, ENGINE (BLACK)	1	
1-2	51110-90851-Y5S	HOLDER SET, ENGINE (WHITE)	1	
2	09262-17019	.BEARING (17X35X8)	1	
3	09282-24003	.OIL SEAL (24X36X6)	2	
4	09283-32044	.OIL SEAL (32X47X6)	1	
5	09289-18001	.OIL SEAL (18X30X8)	1	
6	08331-41359	.CIRCLIP	1	
7	09262-35069	.BEARING (35X62X16)	1	
8	51115-90J00	UNION, WATER RETURN	1	
9	51211-90J22	GASKET, ENGINE HOLDER	1	
10	09116-08160	BOLT (8X70)	4	
11	09116-08128	BOLT (8X40)	4	
12	09206-08001	PIN (8X11)	2	
13	09280-26006	O RING (D:3.1,ID:26.4)	1	
14	01550-06257	BOLT	1	
15	29117-93J10	BOLT (8X45)	1	
16	09160-08059	WASHER (8.5X18X1.6)	1	
17	04211-11129	PIN	3	
18	51122-90J00	COVER, MOUNT CASE	1	
19	51123-90J01	GASKET, MOUNT CASE COVER	1	
20	01550-0825A	BOLT	4	
21	54123-90J01	PLATE, UPPER MOUNT	1	
22	54112-90J21	BOLT, UPPER MOUNT	2	

DF140A_E11_019_401B
ENGINE HOLDER

FIG.401B




FIG.401B (1-G-10) ENGINE HOLDER (DF115AT)(DF115AZ)(DF140AT)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23	54130-90J40	MOUNT, UPPER	2	
24	09159-12014	NUT	2	
25	54114-90J10	WASHER, UPPER MOUNT	2	
26	54125-90J10	MOUNT, UPPER THRUST	1	
27	54148-90J11	COVER, UPPER MOUNT	2	
28	09116-10181	BOLT (10X44)	4	
29	09159-12014	NUT	2	
30	09160-12110	WASHER (12.5X22X3)	2	

DF115AT E11
DF115AT E40
DF115AZ E11
DF115AZ E40
DF140AT E11
DF140AT E40
DF140AZ E11
DF140AZ E40

DF140A_E11_019_401B
ENGINE HOLDER

FIG.405A




FIG.405A (1-G-11) DRIVE SHAFT HOUSING (DF100AT)(DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-90J02-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	W/TRANSOM(L)
1-2	52111-90J12-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	W/TRANSOM(X)
2	09116-10181	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4	09387-45001	RING	1	W/TRANSOM(X)
5	57130-92J01	BUSH, DRIVE SHAFT	1	W/TRANSOM(X)
6	09125-06063	SCREW (6X10)	1	
7	36895-87D10	LEAD (SWIVEL TO HSG)	1	
8	54121-87D01	DAMPER, REVERSE STOPPER LOWER	2	
9	54160-90J20	MOUNT, LOWER	2	
10	54166-90J11	BOLT (12X231)	2	
11	09159-12014	NUT	2	
12	09160-12112	WASHER (12X40X3)	2	
13	54114-90J10	WASHER, LOWER MOUNT	2	
14	54151-90J00	MOUNT, LOWER THRUST	1	
15	54211-90J01-YAY	BRACKET, LOWER MOUNT (BLACK)	1	
16	54221-90J02-YAY	COVER, LOWER MOUNT (BLACK)	2	
17	09116-10181	BOLT (10X44)	6	
18	09160-12113	WASHER (12.5X30X2.5)	2	

DF100AT E11
DF115AST E03

FIG.405B




FIG.405B (1-G-12) DRIVE SHAFT HOUSING (DF115AT)(DF115AZ)(DF140AT)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-90J02-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	W/TRANSOM(L)
1-2	52111-90J02-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	W/TRANSOM(L)
1-3	52111-90J12-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	W/TRANSOM(X)
1-4	52111-90J12-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	W/TRANSOM(X)
2	09116-10181	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4	09387-45001	RING	1	W/TRANSOM(X)
5	57130-92J01	BUSH, DRIVE SHAFT	1	W/TRANSOM(X)
6	09125-06063	SCREW (6X10)	1	
7	36895-87D10	LEAD (SWIVEL TO HSG)	1	
8	54121-87D01	DAMPER, REVERSE STOPPER LOWER	2	
9	54160-90J20	MOUNT, LOWER	2	
10	54166-90J11	BOLT (12X231)	2	
11	09159-12014	NUT	2	
12	09160-12112	WASHER (12X40X3)	2	
13	54114-90J10	WASHER, LOWER MOUNT	2	
14	54151-90J00	MOUNT, LOWER THRUST	1	
15-1	54211-90J01-YAY	BRACKET, LOWER MOUNT (BLACK)	1	
15-2	54211-90J01-Y5S	BRACKET, LOWER MOUNT (WHITE)	1	
16-1	54221-90J02-YAY	COVER, LOWER MOUNT (BLACK)	2	
16-2	54221-90J02-Y5S	COVER, LOWER MOUNT (WHITE)	2	
17	09116-10181	BOLT (10X44)	6	
18	09160-12113	WASHER (12.5X30X2.5)	2	

DF115AT E11
DF115AT E40
DF115AZ E11
DF115AZ E40
DF140AT E11
DF140AT E40
DF140AZ E11
DF140AZ E40

FIG.407A




FIG.407A (1-G-13) GEAR CASE (DF100AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55110-90J15-YAY	CASE, GEAR (BLACK)	1	
2	09263-28016	.BEARING (28.6X38X31.8)	1	
3	55125-90J01	TAB, TRIM	1	
4	09367-05003	UNION	1	
5	55321-90J01	ANODE, GEAR CASE	1	
6	55332-87D11	RUBBER, EXHAUST SEAL	1	
7	55333-87D10	PLATE, EXHAUST SEAL	1	
8	09100-06131	BOLT (6X12)	1	
9	09116-08137	BOLT (8X22)	1	
10	09116-10150	BOLT (10X55)	6	
11	09117-10039	BOLT (10X80)	1	
12	09160-06085	WASHER (6.5X15X1)	1	
13	09168-10022	GASKET (10X17X1.5)	2	
14	09202-08006	PIN (8X12)	2	
15	09248-10008	PLUG (10X7.5)	2	
16-1	09355-40805-600	HOSE (4X8X600)	1	TRANSOM (L) L:600->50
16-2	09355-40805-600	HOSE (4X8X600)	1	TRANSOM (X) L:600->100
17	09362-09008	UNION	1	
18	09407-10404	CLAMP (L:100)	2	
19-1	58100-90JA0-019	PROPELLER (3X14X17)	1	
19-2	58100-90JB0-019	PROPELLER (3X14X19)	1	
19-3	58100-90JC0-019	PROPELLER (3X14X21)	1	
19-4	58100-90JD0-019	PROPELLER (3X14X23)	1	
19-5	58100-90JE0-019	PROPELLER (3X13.5X15)	1	
20	58105-90J00	.BUSH	1	

FIG.407A




FIG.407A (1-G-14) GEAR CASE (DF100AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21-1	58200-92J40	PROPELLER (3X13.875X15)	1	OPT
21-2	58200-92J50	PROPELLER (3X13.875X17)	1	OPT
21-3	58200-92J60	PROPELLER (3X13.875X19)	1	OPT
21-4	58200-92J70	PROPELLER (3X13.875X21)	1	OPT
21-5	58200-92J80	PROPELLER (3X13.875X23)	1	OPT
21-6	58200-92J90	PROPELLER (3X13.875X25)	1	OPT
22	58105-90J00	.BUSH, PROPELLER	1	OPT
23	57633-90J02	SPACER, PROPELLER NUT	1	
24	57635-92J01	STOPPER, PROPELLER BUSH	1	
25	09141-18005	NUT	1	
26	09160-18028	WASHER (18.5X31X1)	1	
27	09204-03003	PIN	1	
28	55116-87E00	PLUG	1	OPT
29	57630-90J00	KIT, PROPELLER NUT	1	OPT
30	25700-92J00	SEALING KIT, GEAR CASE	1	OPT
				NOT ILLUSTRATED

DF100AT E11

FIG.407B




FIG.407B (1-G-15) GEAR CASE (DF115AT E11)(DF140AT E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-90J15-YAY	CASE, GEAR (BLACK)	1	
1-2	55110-90J15-Y5S	CASE, GEAR (WHITE)	1	
2	09263-28016	.BEARING (28.6X38X31.8)	1	
3	55125-90J01	TAB, TRIM	1	
4	09367-05003	UNION	1	
5	55321-90J01	ANODE, GEAR CASE	1	
6	55332-87D11	RUBBER, EXHAUST SEAL	1	
7	55333-87D10	PLATE, EXHAUST SEAL	1	
8	09100-06131	BOLT (6X12)	1	
9	09116-08137	BOLT (8X22)	1	
10	09116-10150	BOLT (10X55)	6	
11	09117-10039	BOLT (10X80)	1	
12	09160-06085	WASHER (6.5X15X1)	1	
13	09168-10022	GASKET (10X17X1.5)	2	
14	09202-08006	PIN (8X12)	2	
15	09248-10008	PLUG (10X7.5)	2	
16-1	09355-40805-600	HOSE (4X8X600)	1	TRANSOM (L) L:600->50
16-2	09355-40805-600	HOSE (4X8X600)	1	TRANSOM (X) L:600->100
17	09362-09008	UNION	1	
18	09407-10404	CLAMP (L:100)	2	
19-1	58100-90JA0-019	PROPELLER (3X14X17)	1	
19-2	58100-90JB0-019	PROPELLER (3X14X19)	1	
19-3	58100-90JC0-019	PROPELLER (3X14X21)	1	
19-4	58100-90JD0-019	PROPELLER (3X14X23)	1	
19-5	58100-90JE0-019	PROPELLER (3X13.5X15)	1	
20	58105-90J00	.BUSH	1	

FIG.407B




FIG.407B (1-H-2) GEAR CASE (DF115AT E11)(DF140AT E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21-1	58200-92J40	PROPELLER (3X13.875X15)	1	OPT
21-2	58200-92J50	PROPELLER (3X13.875X17)	1	OPT
21-3	58200-92J60	PROPELLER (3X13.875X19)	1	OPT
21-4	58200-92J70	PROPELLER (3X13.875X21)	1	OPT
21-5	58200-92J80	PROPELLER (3X13.875X23)	1	OPT
21-6	58200-92J90	PROPELLER (3X13.875X25)	1	OPT
22	58105-90J00	.BUSH, PROPELLER	1	OPT
23	57633-90J02	SPACER, PROPELLER NUT	1	
24	57635-92J01	STOPPER, PROPELLER BUSH	1	
25	09141-18005	NUT	1	
26	09160-18028	WASHER (18.5X31X1)	1	
27	09204-03003	PIN	1	
28	55116-87E00	PLUG	1	OPT
29	57630-90J00	KIT, PROPELLER NUT	1	OPT
30	25700-92J00	SEALING KIT, GEAR CASE	1	OPT
				NOT ILLUSTRATED

DF115AT E11
DF140AT E11

FIG.407C




FIG.407C (1-H-3) GEAR CASE (DF115AT E40)(DF140AT E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-90J15-YAY	CASE, GEAR (BLACK)	1	
1-2	55110-90J15-Y5S	CASE, GEAR (WHITE)	1	
2	09263-28016	.BEARING (28.6X38X31.8)	1	
3	55125-90J01	TAB, TRIM	1	
4	09367-05003	UNION	1	
5	55321-90J01	ANODE, GEAR CASE	1	
6	55332-87D11	RUBBER, EXHAUST SEAL	1	
7	55333-87D10	PLATE, EXHAUST SEAL	1	
8	09100-06131	BOLT (6X12)	1	
9	09116-08137	BOLT (8X22)	1	
10	09116-10150	BOLT (10X55)	6	
11	09117-10039	BOLT (10X80)	1	
12	09160-06085	WASHER (6.5X15X1)	1	
13	09168-10022	GASKET (10X17X1.5)	2	
14	09202-08006	PIN (8X12)	2	
15	09248-10008	PLUG (10X7.5)	2	
16-1	09355-40805-600	HOSE (4X8X600)	1	TRANSOM (L) L:600->50
16-2	09355-40805-600	HOSE (4X8X600)	1	TRANSOM (X) L:600->100
17	09362-09008	UNION	1	
18	09407-10404	CLAMP (L:100)	2	
19-1	58100-90JA0-019	PROPELLER (3X14X17)	1	
19-2	58100-90JB0-019	PROPELLER (3X14X19)	1	
19-3	58100-90JC0-019	PROPELLER (3X14X21)	1	
19-4	58100-90JD0-019	PROPELLER (3X14X23)	1	
19-5	58100-90JE0-019	PROPELLER (3X13.5X15)	1	
20	58105-90J00	.BUSH	1	

FIG.407C




FIG.407C (1-H-4) GEAR CASE (DF115AT E40)(DF140AT E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21	57633-90J02	SPACER, PROPELLER NUT	1	
22	57635-92J01	STOPPER, PROPELLER BUSH	1	
23	09141-18005	NUT	1	
24	09160-18028	WASHER (18.5X31X1)	1	
25	09204-03003	PIN	1	
26	25700-92J00	SEALING KIT, GEAR CASE	1	OPT
				NOT ILLUSTRATED

DF115AT E40
DF140AT E40

FIG.407D




FIG.407D (1-H-5) GEAR CASE (DF115AZ E11)(DF140AZ E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-92J00-YAY	CASE, GEAR (BLACK)	1	
1-2	55110-92J00-Y5S	CASE, GEAR (WHITE)	1	
2	09263-28016	.BEARING (28.6X38X31.8)	1	
3-1	55125-92J00-YAY	TAB, TRIM (BLACK)	1	
3-2	55125-92J00-Y5S	TAB, TRIM (WHITE)	1	
4	09367-05003	UNION	1	
5	55321-90J01	ANODE, GEAR CASE	1	
6	55332-87D11	RUBBER, EXHAUST SEAL	1	
7	55333-87D10	PLATE, EXHAUST SEAL	1	
8	09100-06131	BOLT (6X12)	1	
9	09116-08137	BOLT (8X22)	1	
10	09116-10150	BOLT (10X55)	6	
11	09117-10039	BOLT (10X80)	1	
12	09160-06085	WASHER (6.5X15X1)	1	
13	09168-10022	GASKET (10X17X1.5)	2	
14	09202-08006	PIN (8X12)	2	
15	09248-10008	PLUG (10X7.5)	2	
16-1	09355-40805-600	HOSE (4X8X600)	1	TRANSOM (L) L:600->50
16-2	09355-40805-600	HOSE (4X8X600)	1	TRANSOM (X) L:600->100
17	09362-09008	UNION	1	
18	09407-10404	CLAMP (L:100)	2	
19-1	58200-92JA0	PROPELLER (3X13.875X17)	1	OPT
19-2	58200-92JB0	PROPELLER (3X13.875X19)	1	OPT
19-3	58200-92JC0	PROPELLER (3X13.875X21)	1	OPT
19-4	58200-92JD0	PROPELLER (3X13.875X23)	1	OPT
20	58105-90J00	.BUSH	1	OPT

FIG.407D




FIG.407D (1-H-6) GEAR CASE (DF115AZ E11)(DF140AZ E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21	57633-90J02	SPACER, PROPELLER	1	
22	57635-92J01	STOPPER, PROPELLER BUSH	1	
23	09141-18005	NUT	1	
24	09160-18028	WASHER (18.5X31X1)	1	
25	09204-03003	PIN	1	
26	55116-87E00	PLUG	1	OPT
27	57630-90J00	KIT, PROPELLER NUT	1	OPT
28	25700-92J00	SEALING KIT, GEAR CASE	1	OPT
				NOT ILLUSTRATED

DF115AZ E11
DF140AZ E11

FIG.407E




FIG.407E (1-H-7) GEAR CASE (DF115AZ E40)(DF140AZ E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-92J00-YAY	CASE, GEAR (BLACK)	1	
1-2	55110-92J00-Y5S	CASE, GEAR (WHITE)	1	
2	09263-28016	.BEARING (28.6X38X31.8)	1	
3-1	55125-92J00-YAY	TAB, TRIM (BLACK)	1	
3-2	55125-92J00-Y5S	TAB, TRIM (WHITE)	1	
4	09367-05003	UNION	1	
5	55321-90J01	ANODE, GEAR CASE	1	
6	55332-87D11	RUBBER, EXHAUST SEAL	1	
7	55333-87D10	PLATE, EXHAUST SEAL	1	
8	09100-06131	BOLT (6X12)	1	
9	09116-08137	BOLT (8X22)	1	
10	09116-10150	BOLT (10X55)	6	
11	09117-10039	BOLT (10X80)	1	
12	09160-06085	WASHER (6.5X15X1)	1	
13	09168-10022	GASKET (10X17X1.5)	2	
14	09202-08006	PIN (8X12)	2	
15	09248-10008	PLUG (10X7.5)	2	
16-1	09355-40805-600	HOSE (4X8X600)	1	TRANSOM (L) L:600->50
16-2	09355-40805-600	HOSE (4X8X600)	1	TRANSOM (X) L:600->100
17	09362-09008	UNION	1	
18	09407-10404	CLAMP (L:100)	2	
19	57633-90J02	SPACER, PROPELLER	1	
20	57635-92J01	STOPPER, PROPELLER BUSH	1	
21	09141-18005	NUT	1	
22	09160-18028	WASHER (18.5X31X1)	1	
23	09204-03003	PIN	1	
24	25700-92J00	SEALING KIT, GEAR CASE	1	OPT NOT ILLUSTRATED

DF115AZ E40
DF140AZ E40

FIG.407F




FIG.407F (1-H-8) GEAR CASE (DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55110-90J15-YAY	CASE, GEAR (BLACK)	1	
2	09263-28016	.BEARING (28.6X38X31.8)	1	
3	55125-90J01	TAB, TRIM	1	
4	09367-05003	UNION	1	
5	55321-90J01	ANODE, GEAR CASE	1	
6	55332-87D11	RUBBER, EXHAUST SEAL	1	
7	55333-87D10	PLATE, EXHAUST SEAL	1	
8	09100-06131	BOLT (6X12)	1	
9	09116-08137	BOLT (8X22)	1	
10	09116-10150	BOLT (10X55)	6	
11	09117-10039	BOLT (10X80)	1	
12	09160-06085	WASHER (6.5X15X1)	1	
13	09168-10022	GASKET (10X17X1.5)	2	
14	09202-08006	PIN (8X12)	2	
15	09248-10008	PLUG (10X7.5)	2	
16-1	09355-40805-600	HOSE (4X8X600)	1	TRANSOM (L) L:600->50
16-2	09355-40805-600	HOSE (4X8X600)	1	TRANSOM (X) L:600->100
17	09362-09008	UNION	1	
18	09407-10404	CLAMP (L:100)	2	
19	57633-90J02	SPACER, PROPELLER NUT	1	
20	57635-92J01	STOPPER, PROPELLER BUSH	1	
21	09141-18005	NUT	1	
22	09160-18028	WASHER (18.5X31X1)	1	
23	09204-03003	PIN	1	
24	25700-92J00	SEALING KIT, GEAR CASE	1	OPT NOT ILLUSTRATED

DF115AST E03

FIG.410A




FIG.410A (1-H-9) SIDE COVER (DF100AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61134-90J20	SEAL, SIDE COVER	1	
2	61810-90J10-YAY	COVER, SIDE STBD (BLACK)	1	
3	61817-89J00	PLUG, SIDE COVER	1	
4	61820-90J11-YAY	COVER, SIDE PORT (BLACK)	1	
5	61827-90J00	HOLDER, SIDE COVER	1	
6	61831-90J12-YAY	PANEL, FRONT (BLACK)	1	
7	09116-08174	BOLT (8X38)	2	
8	09136-06148	SCREW (6X35)	7	
9	09136-06149	SCREW (6X55)	2	
10	09169-08039	WASHER	2	
11	09320-11013	CUSHION	2	
12	09321-08022	CUSHION	2	
13	09409-05302-5PK	CLIP (BLACK)	2	
14	61633-90J02-YAY	LEVER, HOOK REAR (BLACK)	1	
15	61633-90J02-YAY	LEVER, HOOK REAR (BLACK)	1	
16	61637-90J10	HOOK, ENGINE COVER REAR STBD	1	
17	61638-90J10	HOOK, ENGINE COVER REAR PORT	1	
18	61641-87D00	HOOK, ENGINE COVER FR	1	
19	61645-90J01-YAY	LEVER, HOOK FR (BLACK)	1	
20	09116-06127	BOLT (6X12)	3	
21	09160-13014	WASHER (13.2X25X1)	3	
22	09164-14008	WASHER	3	
23	09307-13006	BUSH	1	FRONT
24	09306-13008	BUSH	2	REAR
25	61124-92J10	GROMMET, REMOCON CABLE	1	
26	09407-25402	CLAMP (L:250)	1	
27	01550-06167	BOLT	2	
28	67341-90J32	HOLDER, REMOCON CABLE	1	
29	67343-90J20	STOPPER, REMOCON CABLE	1	
30	67344-90J00	CUSHION, REMOCON CABLE HLDR	1	

FIG.410A




FIG.410A (1-H-10) SIDE COVER (DF100AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	01580-08257	BOLT	1	
32	09403-20308	CLAMP	1	
33	17917-87L00	CONNECTOR, FLUSH WATER	1	
34	61458-90J00	LABEL, ENGINE COVER	1	
35	67361-90J10	ADAPTER, HOSE (RIGGING)	1	
36	09208-06009	PIN, HOSE ADAPTER (RIGGING)	2	
37	09383-04002	E RING	2	

DF100AT E11

FIG.410B




FIG.410B (1-H-11) SIDE COVER (DF115AT)(DF115AZ)(DF140AT)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61134-90J20	SEAL, SIDE COVER	1	
2-1	61810-90J10-YAY	COVER, SIDE STBD (BLACK)	1	
2-2	61810-90J10-Y5S	COVER, SIDE STBD (WHITE)	1	
3	61817-89J00	PLUG, SIDE COVER	1	
4-1	61820-90J11-YAY	COVER, SIDE PORT (BLACK)	1	
4-2	61820-90J11-Y5S	COVER, SIDE PORT (WHITE)	1	
5	61827-90J00	HOLDER, SIDE COVER	1	
6-1	61831-90J12-YAY	PANEL, FRONT (BLACK)	1	
6-2	61831-90J12-Y5S	PANEL, FRONT (WHITE)	1	
7	09116-08174	BOLT (8X38)	2	
8	09136-06148	SCREW (6X35)	7	
9	09136-06149	SCREW (6X55)	2	
10	09169-08039	WASHER	2	
11	09320-11013	CUSHION	2	
12	09321-08022	CUSHION	2	
13	09409-05302-5PK	CLIP (BLACK)	2	
14-1	61633-90J02-YAY	LEVER, HOOK REAR (BLACK)	1	
14-2	61633-90J02-Y5S	LEVER, HOOK REAR (WHITE)	1	
15-1	61633-90J02-YAY	LEVER, HOOK REAR (BLACK)	1	
15-2	61633-90J02-Y5S	LEVER, HOOK REAR (WHITE)	1	
16	61637-90J10	HOOK, ENGINE COVER REAR STBD	1	
17	61638-90J10	HOOK, ENGINE COVER REAR PORT	1	
18	61641-87D00	HOOK, ENGINE COVER FR	1	

FIG.410B




FIG.410B (1-H-12) SIDE COVER (DF115AT)(DF115AZ)(DF140AT)(DF140AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
19-1	61645-90J01-YAY	LEVER, HOOK FR (BLACK)	1	
19-2	61645-90J01-Y5S	LEVER, HOOK FR (WHITE)	1	
20	09116-06127	BOLT (6X12)	3	
21	09160-13014	WASHER (13.2X25X1)	3	
22	09164-14008	WASHER	3	
23	09307-13006	BUSH	1	FRONT
24	09306-13008	BUSH	2	REAR
25	61124-92J10	GROMMET, REMOCON CABLE	1	
26	09407-25402	CLAMP (L:250)	1	
27	01550-06167	BOLT	2	
28	67341-90J32	HOLDER, REMOCON CABLE	1	
29	67343-90J20	STOPPER, REMOCON CABLE	1	
30	67344-90J00	CUSHION, REMOCON CABLE HLDR	1	
31	01580-08257	BOLT	1	
32	09403-20308	CLAMP	1	
33	17917-87L00	CONNECTOR, FLUSH WATER	1	
34	61458-90J00	LABEL, ENGINE COVER	1	
35	67361-90J10	ADAPTER, HOSE (RIGGING)	1	
36	09208-06009	PIN, HOSE ADAPTER (RIGGING)	2	
37	09383-04002	E RING	2	

DF115AT E11
DF115AT E40
DF115AZ E11
DF115AZ E40
DF140AT E11
DF140AT E40
DF140AZ E11
DF140AZ E40

FIG.410C




FIG.410C (1-H-13) SIDE COVER (DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61134-90J20	SEAL, SIDE COVER	1	
2	61810-90J10-YKV	COVER, SIDE STBD (MAT BLACK)	1	
3	61817-89J00	PLUG, SIDE COVER	1	
4	61820-90J11-YKV	COVER, SIDE PORT (MAT BLACK)	1	
5	61827-90J00	HOLDER, SIDE COVER	1	
6	61831-90J12-YKV	PANEL, FRONT (MAT BLACK)	1	
7	09116-08174	BOLT (8X38)	2	
8	09136-06148	SCREW (6X35)	7	
9	09136-06149	SCREW (6X55)	2	
10	09169-08039	WASHER	2	
11	09320-11013	CUSHION	2	
12	09321-08022	CUSHION	2	
13	09409-05302-5PK	CLIP (BLACK)	2	
14	61633-90J02-YKV	LEVER, HOOK REAR (MAT BLACK)	1	
15	61633-90J02-YKV	LEVER, HOOK REAR (MAT BLACK)	1	
16	61637-90J10	HOOK, ENGINE COVER REAR STBD	1	
17	61638-90J10	HOOK, ENGINE COVER REAR PORT	1	
18	61641-87D00	HOOK, ENGINE COVER FR	1	
19	61645-90J01-YAY	LEVER, HOOK FR (BLACK)	1	
20	09116-06127	BOLT (6X12)	3	
21	09160-13014	WASHER (13.2X25X1)	3	
22	09164-14008	WASHER	3	
23	09307-13006	BUSH	1	FRONT
24	09306-13008	BUSH	2	REAR
25	61124-92J10	GROMMET, REMOCON CABLE	1	
26	09407-25402	CLAMP (L:250)	1	
27	01550-06167	BOLT	2	
28	67341-90J32	HOLDER, REMOCON CABLE	1	
29	67343-90J20	STOPPER, REMOCON CABLE	1	
30	67344-90J00	CUSHION, REMOCON CABLE HLDR	1	

FIG.410C




FIG.410C (1-H-14) SIDE COVER (DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	01580-08257	BOLT	1	
32	09403-20308	CLAMP	1	
33	17917-87L00	CONNECTOR, FLUSH WATER	1	
34	61458-90J00	LABEL, ENGINE COVER	1	
35	67361-90J10	ADAPTER, HOSE (RIGGING)	1	
36	09208-06009	PIN, HOSE ADAPTER (RIGGING)	2	
37	09383-04002	E RING	2	

DF115AST E03

FIG.420A




FIG.420A (1-H-15) ENGINE COVER (DF100AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61401-90810-YAY	COVER SET, ENGINE (BLACK)	1	
2	61621-87D20	.BRACKET, FASTENER FRONT	1	
3	61644-90J20	.BRACKET, FASTENER REAR	2	
4	09229-04025	.RIVET	4	
5	09229-04025	.RIVET	3	
6	61430-92J00-YAY	.HANDLE, TILT UP (BLACK)	1	
7	61438-92J10	.SEAL, TILT UP HANDLE	1	
8	61439-92J10	.SEAL, TILT UP HANDLE	1	
9	61610-93J00	.FASTENER	1	
10	61680-90J01	.FASTENER, REAR STBD	1	
11	61690-90J01	.FASTENER, REAR PORT	1	
12	09329-10024	.CUSHION	2	
13	09329-10023	.CUSHION	2	
14	01550-06127	.BOLT	3	
15	07120-06167	.BOLT	2	
16	08316-10067	.NUT	2	
17	61443-88L20	.STRIPE, ENGINE COVER STBD	1	
18	61453-88L20	.STRIPE, ENGINE COVER PORT	1	
19	77811-63J00-0PG	.EMBLEM, S (CHROME)	1	
20	61112-92J10	.RUBBER, SIDE COVER	1	
21	61432-92J10	.LOUVER, TILT UP HANDLE	1	
22	03542-06169	.SCREW	3	
23	61422-90J40	MARK, EMBLEM FRONT (100)	1	
24	61435-90JA0	MARK, EMBLEM REAR (100)	1	
25	09800-81841	TOOL SET	1	
26	68110-87L01	COVER, WEATHER	1	OPT
27-1	99011-90J90-054	MANUAL, OWNER'S	1	
27-2	99011-90J90-059	MANUAL, OWNER'S	1	

DF100AT E11

FIG.420B




FIG.420B (1-I-2) ENGINE COVER (DF115AT E11)(DF115AZ E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61401-90810-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61401-90820-Y5S	COVER SET, ENGINE (WHITE)	1	
2	61621-87D20	.BRACKET, FASTENER FRONT	1	
3	61644-90J20	.BRACKET, FASTENER REAR	2	
4	09229-04025	.RIVET	4	
5	09229-04025	.RIVET	3	
6-1	61430-92J00-YAY	.HANDLE, TILT UP (BLACK)	1	
6-2	61430-92J00-Y5S	.HANDLE, TILT UP (WHITE)	1	
7	61438-92J10	.SEAL, TILT UP HANDLE	1	
8	61439-92J10	.SEAL, TILT UP HANDLE	1	
9	61610-93J00	.FASTENER	1	
10	61680-90J01	.FASTENER, REAR STBD	1	
11	61690-90J01	.FASTENER, REAR PORT	1	
12	09329-10024	.CUSHION	2	
13	09329-10023	.CUSHION	2	
14	01550-06127	.BOLT	3	
15	07120-06167	.BOLT	2	
16	08316-10067	.NUT	2	
17-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	FOR YAY
17-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	FOR Y5S
18-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	FOR YAY
18-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	FOR Y5S
19	77811-63J00-0PG	.EMBLEM, S (CHROME)	1	
20	61112-92J10	.RUBBER, SIDE COVER	1	
21	61432-92J10	.LOUVER, TILT UP HANDLE	1	
22	03542-06169	.SCREW	3	
23-1	61422-90J50	MARK, EMBLEM FRONT (115)	1	FOR YAY
23-2	61422-90J60	MARK, EMBLEM FRONT (115)	1	FOR Y5S

DF140A_E11_019_420B
ENGINE COVER

FIG.420B




FIG.420B (1-I-3) ENGINE COVER (DF115AT E11)(DF115AZ E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24-1	61435-90JB0	MARK, EMBLEM REAR (115)	1	FOR YAY
24-2	61435-90JC0	MARK, EMBLEM REAR (115)	1	FOR Y5S
25	09800-81841	TOOL SET	1	
26	68110-87L01	COVER, WEATHER	1	OPT
27-1	99011-90J90-054	MANUAL, OWNER'S	1	
27-2	99011-90J90-03B	MANUAL, OWNER'S	1	
27-3	99011-90J90-059	MANUAL, OWNER'S	1	

DF115AT E11
DF115AZ E11

DF140A_E11_019_420B
ENGINE COVER

FIG.420C




FIG.420C (1-I-4) ENGINE COVER (DF115AT E40)(DF115AZ E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61401-90810-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61401-90820-Y5S	COVER SET, ENGINE (WHITE)	1	
2	61621-87D20	.BRACKET, FASTENER FRONT	1	
3	61644-90J20	.BRACKET, FASTENER REAR	2	
4	09229-04025	.RIVET	4	
5	09229-04025	.RIVET	3	
6-1	61430-92J00-YAY	.HANDLE, TILT UP (BLACK)	1	
6-2	61430-92J00-Y5S	.HANDLE, TILT UP (WHITE)	1	
7	61438-92J10	.SEAL, TILT UP HANDLE	1	
8	61439-92J10	.SEAL, TILT UP HANDLE	1	
9	61610-93J00	.FASTENER	1	
10	61680-90J01	.FASTENER, REAR STBD	1	
11	61690-90J01	.FASTENER, REAR PORT	1	
12	09329-10024	.CUSHION	2	
13	09329-10023	.CUSHION	2	
14	01550-06127	.BOLT	3	
15	07120-06167	.BOLT	2	
16	08316-10067	.NUT	2	
17-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	FOR YAY
17-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	FOR Y5S
18-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	FOR YAY
18-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	FOR Y5S
19	77811-63J00-0PG	.EMBLEM, S (CHROME)	1	
20	61112-92J10	.RUBBER, SIDE COVER	1	
21	61432-92J10	.LOUVER, TILT UP HANDLE	1	
22	03542-06169	.SCREW	3	
23-1	61422-90J50	MARK, EMBLEM FRONT (115)	1	FOR YAY
23-2	61422-90J60	MARK, EMBLEM FRONT (115)	1	FOR Y5S

FIG.420C




FIG.420C (1-I-5) ENGINE COVER (DF115AT E40)(DF115AZ E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24-1	61435-90JB0	MARK, EMBLEM REAR (115)	1	FOR YAY
24-2	61435-90JC0	MARK, EMBLEM REAR (115)	1	FOR Y5S
25	09800-81841	TOOL SET	1	
26	68110-87L01	COVER, WEATHER	1	OPT
27	99011-90J90-059	MANUAL, OWNER'S	1	

DF115AT E40
DF115AZ E40

FIG.420D




FIG.420D (1-I-6) ENGINE COVER (DF140AT E11)(DF140AZ E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61401-90810-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61401-90820-Y5S	COVER SET, ENGINE (WHITE)	1	
2	61621-87D20	.BRACKET, FASTENER FRONT	1	
3	61644-90J20	.BRACKET, FASTENER REAR	2	
4	09229-04025	.RIVET	4	
5	09229-04025	.RIVET	3	
6-1	61430-92J00-YAY	.HANDLE, TILT UP (BLACK)	1	
6-2	61430-92J00-Y5S	.HANDLE, TILT UP (WHITE)	1	
7	61438-92J10	.SEAL, TILT UP HANDLE	1	
8	61439-92J10	.SEAL, TILT UP HANDLE	1	
9	61610-93J00	.FASTENER	1	
10	61680-90J01	.FASTENER, REAR STBD	1	
11	61690-90J01	.FASTENER, REAR PORT	1	
12	09329-10024	.CUSHION	2	
13	09329-10023	.CUSHION	2	
14	01550-06127	.BOLT	3	
15	07120-06167	.BOLT	2	
16	08316-10067	.NUT	2	
17-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	FOR YAY
17-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	FOR Y5S
18-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	FOR YAY
18-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	FOR Y5S
19	77811-63J00-0PG	.EMBLEM, S (CHROME)	1	
20	61112-92J10	.RUBBER, SIDE COVER	1	
21	61432-92J10	.LOUVER, TILT UP HANDLE	1	
22	03542-06169	.SCREW	3	
23-1	61422-92J20	MARK, EMBLEM FRONT (140)	1	FOR YAY
23-2	61422-92J30	MARK, EMBLEM FRONT (140)	1	FOR Y5S

FIG.420D




FIG.420D (1-I-7) ENGINE COVER (DF140AT E11)(DF140AZ E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24-1	61435-92J60	MARK, EMBLEM REAR (140)	1	FOR YAY
24-2	61435-92J70	MARK, EMBLEM REAR (140)	1	FOR Y5S
25	09800-81841	TOOL SET	1	
26	68110-87L01	COVER, WEATHER	1	OPT
27-1	99011-90J90-054	MANUAL, OWNER'S	1	
27-2	99011-90J90-03B	MANUAL, OWNER'S	1	
27-3	99011-90J90-059	MANUAL, OWNER'S	1	

DF140AT E11
DF140AZ E11

FIG.420E




FIG.420E (1-I-8) ENGINE COVER (DF140AT E40)(DF140AZ E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61401-90810-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61401-90820-Y5S	COVER SET, ENGINE (WHITE)	1	
2	61621-87D20	.BRACKET, FASTENER FRONT	1	
3	61644-90J20	.BRACKET, FASTENER REAR	2	
4	09229-04025	.RIVET	4	
5	09229-04025	.RIVET	3	
6-1	61430-92J00-YAY	.HANDLE, TILT UP (BLACK)	1	
6-2	61430-92J00-Y5S	.HANDLE, TILT UP (WHITE)	1	
7	61438-92J10	.SEAL, TILT UP HANDLE	1	
8	61439-92J10	.SEAL, TILT UP HANDLE	1	
9	61610-93J00	.FASTENER	1	
10	61680-90J01	.FASTENER, REAR STBD	1	
11	61690-90J01	.FASTENER, REAR PORT	1	
12	09329-10024	.CUSHION	2	
13	09329-10023	.CUSHION	2	
14	01550-06127	.BOLT	3	
15	07120-06167	.BOLT	2	
16	08316-10067	.NUT	2	
17-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	FOR YAY
17-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	FOR Y5S
18-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	FOR YAY
18-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	FOR Y5S
19	77811-63J00-0PG	.EMBLEM, S (CHROME)	1	
20	61112-92J10	.RUBBER, SIDE COVER	1	
21	61432-92J10	.LOUVER, TILT UP HANDLE	1	
22	03542-06169	.SCREW	3	
23-1	61422-92J20	MARK, EMBLEM FRONT (140)	1	FOR YAY
23-2	61422-92J30	MARK, EMBLEM FRONT (140)	1	FOR Y5S

DF140A_E11_019_420E
ENGINE COVER

FIG.420E




FIG.420E (1-I-9) ENGINE COVER (DF140AT E40)(DF140AZ E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24-1	61435-92J60	MARK, EMBLEM REAR (140)	1	FOR YAY
24-2	61435-92J70	MARK, EMBLEM REAR (140)	1	FOR Y5S
25	09800-81841	TOOL SET	1	
26	68110-87L01	COVER, WEATHER	1	OPT
27	99011-90J90-059	MANUAL, OWNER'S	1	

DF140AT E40
DF140AZ E40

FIG.420F




FIG.420F (1-I-10) ENGINE COVER (DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61401-90830-YKV	COVER SET, ENGINE (MAT BLACK)	1	
2	61621-87D20	.BRACKET, FASTENER FRONT	1	
3	61644-90J20	.BRACKET, FASTENER REAR	2	
4	09229-04025	.RIVET	4	
5	09229-04025	.RIVET	3	
6	61430-92J00-YKV	.HANDLE, TILT UP (MAT BLACK)	1	
7	61438-92J10	.SEAL, TILT UP HANDLE	1	
8	61439-92J10	.SEAL, TILT UP HANDLE	1	
9	61610-93J00	.FASTENER	1	
10	61680-90J01	.FASTENER, REAR STBD	1	
11	61690-90J01	.FASTENER, REAR PORT	1	
12	09329-10024	.CUSHION	2	
13	09329-10023	.CUSHION	2	
14	01550-06127	.BOLT	3	
15	07120-06167	.BOLT	2	
16	08316-10067	.NUT	2	
17	61443-92J20	.STRIPE, ENGINE COVER STBD	1	
18	61453-92J20	.STRIPE, ENGINE COVER PORT	1	
19	77811-63J00-0PG	.EMBLEM, S (CHROME)	1	
20	61112-92J10	.RUBBER, SIDE COVER	1	
21	61432-92J20	.LOUVER, TILT UP HANDLE (MAT RED)	1	
22	03542-06169	.SCREW	3	
23	61424-93J00	.MARK, EMBLEM (SS)	1	
24	61435-92J50	.MARK, EMBLEM REAR (115)	1	
25	61444-92J00	.STRIPE, ENGINE COVER UPPER	1	STBD
26	61454-92J00	.STRIPE, ENGINE COVER UPPER	1	PORT
27	61441-92J10	.MARK, SUZUKI	2	

FIG.420F




FIG.420F (1-I-11) ENGINE COVER (DF115AST)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09800-81841	TOOL SET	1	
29	68110-87L01	COVER, WEATHER	1	OPT
30-1	99011-90J90-054	MANUAL, OWNER'S	1	
30-2	99011-90J90-03B	MANUAL, OWNER'S	1	

DF115AST E03

FIG.432A




FIG.432A (1-I-12) FUEL TANK (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65000-94L10	TANK ASSY, FUEL (25L)	1	
2	65520-99100	.CAP ASSY, FUEL TANK	1	
3	65561-95D00	.GASKET, TANK CAP	1	
4	65740-95D01	.PLUG, FUEL CONNECTOR	1	
5	65700-90J21	HOSE, FUEL (TANK TO ENGINE)	1	
6	65750-95500	.SOCKET, FUEL HOSE	1	
7	65770-90J12	.PUMP, SQUEEZE	1	
8	09401-11423	CLIP	1	

DF115AT E40
DF115AZ E40
DF140AT E40
DF140AZ E40

FIG.442A




FIG.442A (1-I-13) DRAG LINK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-90J01	LINK, DRAG	1	
3	67721-99E00	.SPACER	1	
4	67725-99E00	.BOLT, DRAG LINK	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	
7	67467-89J01	CONNECTOR, REMOCON CABLE	2	
8	09385-06012	CLIP	2	
9	09160-06055	WASHER (7X12X1)	2	
10	67600-90J00	KIT, TIE ROD	1	OPT
11	67631-90J00	.BRACKET, TIE ROD	2	OPT
12	67725-99E20	.BOLT	2	OPT
13	67726-99E00	.NUT	2	OPT
14	09100-12081	.BOLT (12X25)	4	OPT
15	09160-12066	.WASHER (12.5X22X2.5)	4	OPT
16	09180-09022	.SPACER (9.6X18X12)	2	OPT

FIG.460A




FIG.460A (1-I-14) METER (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34800-93J02	METER ASSY, TRIM	1	BLACK
1-2	34800-93J13	METER ASSY, TRIM	1	WHITE
2	09471-12108	.BULB (12V1.7W,T6.5)	1	
3-1	34200-93J02	TACHOMETER ASSY, WITH MONITOR	1	BLACK
3-2	34200-93J14	TACHOMETER ASSY, WITH MONITOR	1	WHITE
4	09471-12077	.BULB (12V1.7W,T10,WB121)	1	

DF100AT E11
DF115AT E11
DF115AZ E11
DF140AT E11
DF140AZ E11

FIG.460B




FIG.460B (1-I-15) METER (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34800-93J02	METER ASSY, TRIM	1	BLACK
1-2	34800-93J13	METER ASSY, TRIM	1	WHITE
2	09471-12108	.BULB (12V1.7W,T6.5)	1	
3-1	34200-93J02	TACHOMETER ASSY, WITH MONITOR	1	BLACK
3-2	34200-93J14	TACHOMETER ASSY, WITH MONITOR	1	WHITE
4	09471-12077	.BULB (12V1.7W,T10,WB121)	1	
5-1	34500-93J02	METER ASSY, HOUR	1	BLACK
5-2	34500-93J13	METER ASSY, HOUR	1	WHITE
6	09471-12103	.BULB (12V3W,T6.5)	1	

DF115AT E40
DF115AZ E40
DF140AT E40
DF140AZ E40

FIG.475A

FIG.475A (1-J-2) SQUEEZE PUMP (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65770-90J04	PUMP, SQUEEZE	1	
2	09352-73123-00D	HOSE, FUEL (4M)	1	

DF100AT E11
DF115AT E11
DF115AZ E11
DF140AT E11
DF140AZ E11




FIG.475B

FIG.475B (1-J-3) SQUEEZE PUMP (E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65770-90J04	PUMP, SQUEEZE	1	

DF115AST E03




FIG.501A




FIG.501A (1-J-4) OPT:METER (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34100-93J02	SPEEDOMETER ASSY	1	MAX 130KM/H BLACK
1-2	34100-93J13	SPEEDOMETER ASSY	1	MAX 130KM/H WHITE
1-3	34100-93J22	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
1-4	34100-93J33	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
1-5	34100-93J42	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
1-6	34100-93J53	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
1-7	34100-93J62	SPEEDOMETER ASSY	1	MAX 65KNOTS WHITE
2	09471-12028	.BULB (12V3.4W,T10)	1	
3	34191-92E00	.TUBE	1	
4	09407-14407	.CLAMP (L:145)	2	
5	36615-96300	.TERMINAL, RESIN	2	
6-1	34600-93J02	METER ASSY, VOLTAGE	1	BLACK
6-2	34600-93J13	METER ASSY, VOLTAGE	1	WHITE
7	09471-12103	.BULB (12V3W,T6.5)	1	
8-1	34300-93J02	GAUGE ASSY, FUEL	1	BLACK
8-2	34300-93J13	GAUGE ASSY, FUEL	1	WHITE
9	34310-92E00	.LEAD, FUEL GAUGE	1	
10	34360-92E00	.ADAPTER, FUEL GAUGE	1	
11	09471-12103	.BULB (12V3W,T6.5)	1	
12-1	34500-93J02	METER ASSY, HOUR	1	BLACK
12-2	34500-93J13	METER ASSY, HOUR	1	WHITE
13	09471-12103	.BULB (12V3W,T6.5)	1	

FIG.501A




FIG.501A (1-J-5) OPT:METER (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14-1	34650-93J22	GAUGE ASSY, WATER PRESSURE	1	15PSI BLACK
14-2	34650-93J33	GAUGE ASSY, WATER PRESSURE	1	15PSI WHITE
15	34191-92E00	.TUBE	1	
16	09407-14407	.CLAMP (L:145)	2	
17	09471-12103	.BULB (12V3W,T6.5)	1	
18-1	34200-93J42	TACHOMETER ASSY, WITH MONITOR	1	BLACK
18-2	34200-93J53	TACHOMETER ASSY, WITH MONITOR	1	WHITE
19	09471-12077	.BULB (12V1.7W,T10,WB121)	1	
20	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
21	34190-95500	SENDER ASSY, SPEEDOMETER	1	
22	03112-0630B	.SCREW	2	

DF100AT E11
DF115AT E11
DF115AZ E11
DF140AT E11
DF140AZ E11

FIG.501B




FIG.501B (1-J-6) OPT:METER (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34100-93J02	SPEEDOMETER ASSY	1	MAX 130KM/H BLACK
1-2	34100-93J13	SPEEDOMETER ASSY	1	MAX 130KM/H WHITE
1-3	34100-93J22	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
1-4	34100-93J33	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
1-5	34100-93J42	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
1-6	34100-93J53	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
1-7	34100-93J62	SPEEDOMETER ASSY	1	MAX 65KNOTS WHITE
2	09471-12028	.BULB (12V3.4W,T10)	1	
3	34191-92E00	.TUBE	1	
4	09407-14407	.CLAMP (L:145)	2	
5	36615-96300	.TERMINAL, RESIN	2	
6-1	34600-93J02	METER ASSY, VOLTAGE	1	BLACK
6-2	34600-93J13	METER ASSY, VOLTAGE	1	WHITE
7	09471-12103	.BULB (12V3W,T6.5)	1	
8-1	34300-93J02	GAUGE ASSY, FUEL	1	BLACK
8-2	34300-93J13	GAUGE ASSY, FUEL	1	WHITE
9	34310-92E00	.LEAD, FUEL GAUGE	1	
10	34360-92E00	.ADAPTER, FUEL GAUGE	1	
11	09471-12103	.BULB (12V3W,T6.5)	1	
12-1	34650-93J22	GAUGE ASSY, WATER PRESSURE	1	15PSI BLACK
12-2	34650-93J33	GAUGE ASSY, WATER PRESSURE	1	15PSI WHITE
13	34191-92E00	.TUBE	1	
14	09407-14407	.CLAMP (L:145)	2	
15	09471-12103	.BULB (12V3W,T6.5)	1	

FIG.501B




FIG.501B (1-J-7) OPT:METER (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
16-1	34200-93J42	TACHOMETER ASSY, WITH MONITOR	1	BLACK
16-2	34200-93J53	TACHOMETER ASSY, WITH MONITOR	1	WHITE
17	09471-12077	.BULB (12V1.7W,T10,WB121)	1	
18	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
19	34190-95500	SENDER ASSY, SPEEDOMETER	1	
20	03112-0630B	.SCREW	2	

DF115AT E40
DF115AZ E40
DF140AT E40
DF140AZ E40

FIG.501C




FIG.501C (1-J-8) OPT:METER (E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34800-93J02	METER ASSY, TRIM	1	BLACK
1-2	34800-93J13	METER ASSY, TRIM	1	WHITE
2	09471-12108	.BULB (12V1.7W,T6.5)	1	
3-1	34100-93J02	SPEEDOMETER ASSY	1	MAX 130KM/H BLACK
3-2	34100-93J13	SPEEDOMETER ASSY	1	MAX 130KM/H WHITE
3-3	34100-93J22	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
3-4	34100-93J33	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
3-5	34100-93J42	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
3-6	34100-93J53	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
3-7	34100-93J62	SPEEDOMETER ASSY	1	MAX 65KNOTS WHITE
4	09471-12028	.BULB (12V3.4W,T10)	1	
5	34191-92E00	.TUBE	1	
6	09407-14407	.CLAMP (L:145)	2	
7	36615-96300	.TERMINAL, RESIN	2	
8-1	34600-93J02	METER ASSY, VOLTAGE	1	BLACK
8-2	34600-93J13	METER ASSY, VOLTAGE	1	WHITE
9	09471-12103	.BULB (12V3W,T6.5)	1	
10-1	34300-93J02	GAUGE ASSY, FUEL	1	BLACK
10-2	34300-93J13	GAUGE ASSY, FUEL	1	WHITE
11	34310-92E00	.LEAD, FUEL GAUGE	1	
12	34360-92E00	.ADAPTER, FUEL GAUGE	1	
13	09471-12103	.BULB (12V3W,T6.5)	1	
14-1	34500-93J02	METER ASSY, HOUR	1	BLACK
14-2	34500-93J13	METER ASSY, HOUR	1	WHITE
15	09471-12103	.BULB (12V3W,T6.5)	1	
16-1	34650-93J22	GAUGE ASSY, WATER PRESSURE	1	15PSI BLACK
16-2	34650-93J33	GAUGE ASSY, WATER PRESSURE	1	15PSI WHITE
17	34191-92E00	.TUBE	1	
18	09407-14407	.CLAMP (L:145)	2	
19	09471-12103	.BULB (12V3W,T6.5)	1	

DF140A_E11_019_501C
OPT:METER

FIG.501C




FIG.501C (1-J-9) OPT:METER (E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20-1	34200-93J02	TACHOMETER ASSY, WITH MONITOR	1	BLACK
20-2	34200-93J14	TACHOMETER ASSY, WITH MONITOR	1	WHITE
21	09471-12077	.BULB (12V1.7W,T10,WB121)	1	
22-1	34200-93J42	TACHOMETER ASSY, WITH MONITOR	1	BLACK
22-2	34200-93J53	TACHOMETER ASSY, WITH MONITOR	1	WHITE
23	09471-12077	.BULB (12V1.7W,T10,WB121)	1	
24	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
25	34190-95500	SENDER ASSY, SPEEDOMETER	1	
26	03112-0630B	.SCREW	2	

DF115AST E03

FIG.507A




FIG.507A (1-J-10) OPT:WATER PRESSURE GAUGE SUB KIT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34660-90J02	WATER PRESS GAUGE SUB KIT	1	
2	09352-50903-600	.HOSE (5X9X600)	1	L:600->160
3	09352-50903-600	.HOSE (5X9X600)	1	L:600->210
4	09367-06006	.3 WAY	1	
5	09401-08413	.CLIP	4	
6	18498-99EA1	.PROTECTOR (L:80)	1	
7	09407-25402	.CLAMP (L:250)	1	
8	17917-87L00	CONNECTOR, FLUSH WATER	1	

FIG.508A




FIG.508A (1-J-11) OPT:REMOTE CONTROL (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J51	REMOTE CONTROL ASSY	1	
2	36646-93J01	.WIRE ASSY, PTT SW ADAPTER	1	
3	36628-92E00	.GROMMET, WIRE HARNESS	1	
4	37110-93J11	.SWITCH ASSY, IGNITION	1	
5-1	37141-99E00	..KEY (931)	2	
5-2	37141-99E10	..KEY (932)	2	
5-3	37141-99E20	..KEY (933)	2	
5-4	37141-99E30	..KEY (934)	2	
5-5	37141-99E40	..KEY (935)	2	
5-6	37141-99E50	..KEY (936)	2	
5-7	37141-99E60	..KEY (937)	2	
5-8	37141-99E70	..KEY (938)	2	
5-9	37141-99E80	..KEY (939)	2	
5-10	37141-99E90	..KEY (940)	2	
5-11	37141-99EA0	..KEY (941)	2	
5-12	37141-99EB0	..KEY (942)	2	
6	37143-99E00	..CAP, KEY	2	
7	37149-93J00	..CAP CYLINDER BODY	1	
8	37721-93J91	.SWITCH, NEUTRAL	1	
9	37820-93J04	.SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE	1	
11	37826-92J00	..NUT	1	
12	37850-90J06	.SWITCH ASSY, PTT	1	
13	38500-93J90	.BUZZER	1	
14	67212-95600	.WASHER	1	
15	67296-92E11	.SCREW, NEUTRAL SW	2	
16	67220-95630	.PLATE ASSY	1	

FIG.508A




FIG.508A (1-J-12) OPT:REMOTE CONTROL (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	67223-99E10	.KNOB, BRAKE ADJ	1	
18	67229-95600	.ROLLER	1	
19	67232-95600	.BUSH	1	
20	67238-87D00	.GEAR, DRIVE	1	
21	67241-99E10	.LEVER, FREE THROTTLE	1	
22	67243-95600	.BUSH	1	
23	67244-95600	.WASHER, WAVE	1	
24	67245-95600	.DRUM, FREE THROTTLE	1	
25	67251-99E20	.LEVER, HANDLE	1	
26	67252-95600	.BUSH	2	
27	67253-95600	.WASHER	1	
28	67255-99E10	.ARM, LOCK	1	
29	67256-95600	.HOLDER, NEUT LOCK	1	
30	67257-99E10	.CAP, LEVER	1	
31	67258-99E00	.BRACKET, LOCK ARM	1	
32	67259-87D00	.SPRING, NEUTRAL ARM	1	
33	67261-99E10	.GRIP	1	
34	67296-94310	.SCREW	1	
35	67264-95600	.WASHER	1	
36	67267-93J00	.COVER, WIRE	1	
37	67273-95600	.SPACER	1	
38	67275-95600	.END, CABLE	2	
39	67292-94300	.E RING	3	
40	67294-95600	.SPACER	3	
41	67296-90J10	.SCREW	5	
42	67296-94300	.SCREW	2	
43	67296-95600	.SCREW	3	

FIG.508A




FIG.508A (1-J-13) OPT:REMOTE CONTROL (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
44	67296-95610	.SCREW	2	
45	67297-95600	.WASHER	2	
46	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
47	09100-08232	.BOLT (8X30)	1	
48	09126-05003	.SCREW (5X12)	2	
49	09140-06020	.NUT	3	
50	09160-06104	.WASHER (6.5X24X2)	3	
51	37859-90J00	.SPACER	1	
52	67282-94L00	.DECAL, REMOCON SIDE	1	
53	67284-94L00	.MARK, HANDLE LEVER	1	
54	67140-95600	KIT, R/CON (NA12S) TWIN	1	
55	67294-95600	.SPACER	3	
56	67296-95621	.SCREW (L:165)	3	

DF115AT E40
DF115AZ E40
DF140AT E40
DF140AZ E40

FIG.508B




FIG.508B (1-J-14) OPT:REMOTE CONTROL (E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	KIT, R/CON (NA12S) TWIN	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	

DF115AST E03

FIG.509A




FIG.509A (1-J-15) OPT:REMOTE CONTROL (1) (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-96L01	REMOTE CONTROL ASSY	1	
2	36646-93J01	.WIRE ASSY, PTT SW ADAPTER	1	
3	36628-92E00	.GROMMET, WIRE HARNESS	1	
4	37110-96L10	.SWITCH ASSY, MAIN	1	
5-1	37141-99E00	..KEY (931)	2	
5-2	37141-99E10	..KEY (932)	2	
5-3	37141-99E20	..KEY (933)	2	
5-4	37141-99E30	..KEY (934)	2	
5-5	37141-99E40	..KEY (935)	2	
5-6	37141-99E50	..KEY (936)	2	
6	37143-96L00	..KNOB, MAIN SWITCH	1	
7	37721-93J91	.SWITCH, NEUTRAL	1	
8	37820-93J04	.SWITCH ASSY, EMERGENCY	1	
9	37823-92E01	..PLATE	1	
10	37826-92J00	..NUT	1	
11	37850-90J06	.SWITCH ASSY, PTT	1	
12	38500-93J90	.BUZZER	1	
13	67212-95600	.WASHER	1	
14	67296-92E11	.SCREW, NEUTRAL SW	2	
15	67220-95630	.PLATE ASSY	1	
16	67223-99E10	.KNOB, BRAKE ADJ	1	
17	67229-95600	.ROLLER	1	
18	67232-95600	.BUSH	1	
19	67238-87D00	.GEAR, DRIVE	1	
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	

FIG.509A




FIG.509A (1-K-2) OPT:REMOTE CONTROL (1) (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	67244-95600	.WASHER, WAVE	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUT LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET, LOCK ARM	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67292-94300	.E RING	3	
39	67294-95600	.SPACER	3	
40	67296-90J10	.SCREW	5	
41	67296-94300	.SCREW	2	
42	67296-95600	.SCREW	3	
43	67296-95610	.SCREW	2	
44	67297-95600	.WASHER	2	
45	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
46	09100-08232	.BOLT (8X30)	1	
47	09126-05003	.SCREW (5X12)	2	

FIG.509A




FIG.509A (1-K-3) OPT:REMOTE CONTROL (1) (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
48	09140-06020	.NUT	3	
49	09160-06104	.WASHER (6.5X24X2)	3	
50	37859-90J00	.SPACER	1	
51	67282-94L00	.DECAL, REMOCON SIDE	1	
52	67284-94L00	.MARK, HANDLE LEVER	1	
53	67285-96L00	.MARK, KLS MAIN SW	1	
54	67140-95600	KIT, R/CON (NA12S) TWIN	1	
55	67294-95600	.SPACER	3	
56	67296-95621	.SCREW (L:165)	3	

DF100AT E11
DF115AT E11
DF115AZ E11
DF140AT E11
DF140AZ E11

FIG.510A




FIG.510A (1-K-4) OPT:REMOTE CONTROL (2) (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J51	REMOTE CONTROL ASSY	1	
2	36646-93J01	.WIRE ASSY, PTT SW ADAPTER	1	
3	36628-92E00	.GROMMET, WIRE HARNESS	1	
4	37110-93J11	.SWITCH ASSY, IGNITION	1	
5-1	37141-99E00	..KEY (931)	2	
5-2	37141-99E10	..KEY (932)	2	
5-3	37141-99E20	..KEY (933)	2	
5-4	37141-99E30	..KEY (934)	2	
5-5	37141-99E40	..KEY (935)	2	
5-6	37141-99E50	..KEY (936)	2	
5-7	37141-99E60	..KEY (937)	2	
5-8	37141-99E70	..KEY (938)	2	
5-9	37141-99E80	..KEY (939)	2	
5-10	37141-99E90	..KEY (940)	2	
5-11	37141-99EA0	..KEY (941)	2	
5-12	37141-99EB0	..KEY (942)	2	
6	37143-99E00	..CAP, KEY	2	
7	37149-93J00	..CAP CYLINDER BODY	1	
8	37721-93J91	.SWITCH, NEUTRAL	1	
9	37820-93J04	.SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE	1	
11	37826-92J00	..NUT	1	
12	37850-90J06	.SWITCH ASSY, PTT	1	
13	38500-93J90	.BUZZER	1	
14	67212-95600	.WASHER	1	
15	67296-92E11	.SCREW, NEUTRAL SW	2	

FIG.510A




FIG.510A (1-K-5) OPT:REMOTE CONTROL (2) (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
16	67220-95630	.PLATE ASSY	1	
17	67223-99E10	.KNOB, BRAKE ADJ	1	
18	67229-95600	.ROLLER	1	
19	67232-95600	.BUSH	1	
20	67238-87D00	.GEAR, DRIVE	1	
21	67241-99E10	.LEVER, FREE THROTTLE	1	
22	67243-95600	.BUSH	1	
23	67244-95600	.WASHER, WAVE	1	
24	67245-95600	.DRUM, FREE THROTTLE	1	
25	67251-99E20	.LEVER, HANDLE	1	
26	67252-95600	.BUSH	2	
27	67253-95600	.WASHER	1	
28	67255-99E10	.ARM, LOCK	1	
29	67256-95600	.HOLDER, NEUT LOCK	1	
30	67257-99E10	.CAP, LEVER	1	
31	67258-99E00	.BRACKET, LOCK ARM	1	
32	67259-87D00	.SPRING, NEUTRAL ARM	1	
33	67261-99E10	.GRIP	1	
34	67296-94310	.SCREW	1	
35	67264-95600	.WASHER	1	
36	67267-93J00	.COVER, WIRE	1	
37	67273-95600	.SPACER	1	
38	67275-95600	.END, CABLE	2	
39	67292-94300	.E RING	3	
40	67294-95600	.SPACER	3	
41	67296-90J10	.SCREW	5	

FIG.510A




FIG.510A (1-K-6) OPT:REMOTE CONTROL (2) (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
42	67296-94300	.SCREW	2	
43	67296-95600	.SCREW	3	
44	67296-95610	.SCREW	2	
45	67297-95600	.WASHER	2	
46	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
47	09100-08232	.BOLT (8X30)	1	
48	09126-05003	.SCREW (5X12)	2	
49	09140-06020	.NUT	3	
50	09160-06104	.WASHER (6.5X24X2)	3	
51	37859-90J00	.SPACER	1	
52	67282-94L00	.DECAL, REMOCON SIDE	1	
53	67284-94L00	.MARK, HANDLE LEVER	1	
54	67140-95600	KIT, R/CON (NA12S) TWIN	1	
55	67294-95600	.SPACER	3	
56	67296-95621	.SCREW (L:165)	3	

DF100AT E11
DF115AT E11
DF115AZ E11
DF140AT E11
DF140AZ E11

FIG.517A




FIG.517A (1-K-7) OPT:CONCEALED REMOCON (1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J33	REMOTE CONTROL ASSY	1	
2	67298-92E50	.SPRING	1	
3	67296-94310	.SCREW	1	
4	67295-92E10	.SCREW (3X12)	2	
5	37850-92E27	.SWITCH ASSY, PTT	1	
6	67288-92E60	.WASHER	1	
7	09125-04021	.SCREW (4X20)	1	
8	67255-92E50	.ARM, NEUTRAL LOCK	1	
9	67251-92E50	.LEVER	1	
10	67261-92E50	.GRIP	1	
11	67256-92E50	.HOLDER, NEUTRAL LOCK	1	
12	67257-92E00	.CAP, LEVER	1	
13	67242-92E50	.SHAFT, FREE ACC	1	
14	67288-92E20	.WASHER	6	
15	67296-88D10	.SCREW (5X16)	4	
16	67288-92E70	.WASHER	1	
17	67296-88D20	.SCREW (6X35)	3	
18	67295-92E50	.SCREW (6X30)	3	
19	67287-92E50	.NUT	3	
20	09160-06104	.WASHER (6.5X24X2)	3	
21	67296-88D30	.SCREW (5X30)	4	
22	67254-92E50	.COVER, LOCK ARM	1	
23	36890-93J00	.WIRING ASSY	1	
24	67275-95600	.END CABLE	2	
25	67273-95600	.SPACER	1	
26	67283-92E50	.DECAL, LEVER	1	
27	67284-92E50	.DECAL, CLUTCH	1	
28	67274-92E50	.BASE	1	
29	67211-92E50	.COVER	1	

DF140A_E11_019_517A
OPT:CONCEALED REMOCON (1)

FIG.518A




FIG.518A (1-K-8) OPT:CONCEALED REMOCON (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J33	REMOTE CONTROL ASSY	1	
2	67222-92E50	.DUEL PLATE	1	
3	67292-94300	.E RING	3	
4	67288-92E10	.WASHER	1	
5	67291-92E00	.SNAP RING	2	
6	67223-92E50	.BRAKE ADJUST	1	
7	67221-92E50	.HOLDER ASSY	1	
8	67224-92E50	.BRAKE SHOE ASSY	1	
9	67225-92E50	.DISC, BRAKE	1	
10	09140-06020	.NUT	2	
11	67294-92E00	.SPACER	1	
12	37721-95500	.SWITCH ASSY, NEUTRAL	1	
13	67296-92E11	.SCREW (3X15)	2	
14	67226-92E10	.BOLT, STOPPER (REAR)	2	
15	67296-92E20	.SCREW (5X25)	2	
16	67240-92E50	.ARM ASSY, THROTTLE	1	
17	67228-92E00	.WASHER	1	
18	67286-92E00	.BOLT (6X18)	3	
19	67230-92E00	.ARM ASSY, SHIFT	1	
20	09125-05042	.SCREW (5X10)	11	
21	67234-92E00	.GEAR CASE	1	
22	67245-92E00	.LEVER ASSY, THROTTLE	1	
23	67227-92E00	.STOPPER	1	
24	67296-88D10	.SCREW (5X16)	2	
25	67225-92E00	.SPRING	1	

DF140A_E11_019_518A
OPT:CONCEALED REMOCON (2)

FIG.518A




FIG.518A (1-K-9) OPT:CONCEALED REMOCON (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
26	09125-04004	.SCREW (4X6)	1	
27	67233-92E00	.SPRING	1	
28	67235-92E00	.PLATE, SHIFT LOCK	1	
29	67239-92E10	.PLATE, SHIFT PIN	1	
30	67236-92E00	.ROLLER	1	
31	67237-92E01	.SPRING	5	
32	67238-92E50	.GEAR, DRIVE	1	
33	67239-92E00	.PIN	1	
34	67246-92E50	.SHAFT, DRIVE	1	
35	67252-92E00	.BUSH	1	
36	67291-92E10	.SNAP RING	1	
37	67253-92E10	.WASHER	1	
38	67252-92E10	.BUSH	1	
39	67253-95600	.WASHER	1	
40	67231-92E00	.GEAR, SHIFT	1	
41	67232-95600	.BUSH	1	
42	67241-92E50	.ROD, FREE ACC	1	
43	67232-92E50	.BUSH	1	

FIG.521A




FIG.521A (1-K-10) OPT:HARNESS

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	L:2000
1-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	L:3000
2	36620-93J30	WIRE ASSY, REMOCON ADAPTER	1	L:2000
3	38500-93J00	BUZZER ASSY, WARNING	1	
4-1	36620-93J02	WIRE ASSY, REMOTE CONTROL	1	
4-2	36620-93J52	WIRE ASSY, REMOTE CONTROL	1	L:3500
4-3	36620-93J62	WIRE ASSY, REMOTE CONTROL	1	L:6500
5	09481-10501	.FUSE (10A)	1	
6	36630-92E00	WIRE ASSY, INSTRUMENT	1	
7	36660-94480	WIRE, MONITOR GAUGE EXT	1	
8	36667-96L20	WIRE, GAUGE EXT	1	

FIG.530A




FIG.530A (1-K-11) OPT:SWITCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	.SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	.PANEL, IGNITION SW	1	
7	38500-93J90	.BUZZER ASSY, WARNING	1	
8	09407-08401	.CLAMP (L:80)	1	
9	37803-93J05	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J10	.SWITCH ASSY, EMERGENCY	1	
11	37823-92E01	..PLATE ASSY, EMERGENCY SW LOCK	1	
12	37826-92J10	..NUT	1	
13	37825-99E10	.PANEL, EMERGENCY SW	1	
14	03122-05165	.SCREW	4	
15	37805-93J00	PANEL ASSY, PTT SW	1	
16	37855-99E00	.PANEL, PTT SW	1	
17	37210-93J00	PANEL ASSY, LIGHTING SW	1	
18	37212-93J00	.PANEL, LIGHTING SW	1	
19	37100-96J25	PANEL ASSY, ENGINE SW	1	
20	37110-93J01	.SWITCH ASSY, IGNITION	1	
21-1	37141-99E00	..KEY (931)	2	
21-2	37141-99E10	..KEY (932)	2	

DF140A_E11_019_530A
OPT:SWITCH

FIG.530A




FIG.530A (1-K-12) OPT:SWITCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21-3	37141-99E20	..KEY (933)	2	
21-4	37141-99E30	..KEY (934)	2	
21-5	37141-99E40	..KEY (935)	2	
21-6	37141-99E50	..KEY (936)	2	
21-7	37141-99E60	..KEY (937)	2	
21-8	37141-99E70	..KEY (938)	2	
21-9	37141-99E80	..KEY (939)	2	
21-10	37141-99E90	..KEY (940)	2	
21-11	37141-99EA0	..KEY (941)	2	
21-12	37141-99EB0	..KEY (942)	2	
22	37143-99E00	..CAP, KEY	1	
23	37149-93J00	..CAP, CYLINDER BODY	1	
24	37820-93J10	.SWITCH ASSY, EMERGENCY	1	
25	37823-92E01	..PLATE ASSY,EMERGENCY SW LOCK	1	
26	37826-92J10	..NUT	1	
27	37139-99E40	.PANEL	1	
28	03121-0516A	.SCREW	4	
29	38500-93J90	.BUZZER ASSY, WARNING	1	
30	09407-08401	.CLAMP (L:80)	1	
31	37100-96J15	PANEL ASSY, DUAL ENGINE SW	1	
32	37110-93J01	.SWITCH ASSY, IGNITION	2	
33-1	37141-99E00	..KEY (931)	4	
33-2	37141-99E10	..KEY (932)	4	
33-3	37141-99E20	..KEY (933)	4	
33-4	37141-99E30	..KEY (934)	4	
33-5	37141-99E40	..KEY (935)	4	
33-6	37141-99E50	..KEY (936)	4	
33-7	37141-99E60	..KEY (937)	4	
33-8	37141-99E70	..KEY (938)	4	
33-9	37141-99E80	..KEY (939)	4	
33-10	37141-99E90	..KEY (940)	4	
33-11	37141-99EA0	..KEY (941)	4	
33-12	37141-99EB0	..KEY (942)	4	
34	37143-99E00	..CAP, KEY	2	

FIG.530A




FIG.530A (1-K-13) OPT:SWITCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	37149-93J00	..CAP, CYLINDER BODY	2	
36	37820-93JA0	.SWITCH ASSY, EMERGENCY	1	
37	37823-92E01	..PLATE ASSY, EMERGENCY SW LOCK	1	
38	37826-92J10	..NUT	1	
39	37139-99E30	.PANEL	1	
40	03121-0516A	.SCREW	4	
41	38500-93J90	.BUZZER ASSY, WARNING	2	
42	09407-08401	.CLAMP (L:80)	1	
43	37860-87L00	PANEL ASSY, TROLLING CONTROL	1	
44	37862-87L00	.PANEL	1	
45	09131-05004	.SCREW (5X16)	4	

DF140A_E11_019_530A
OPT:SWITCH

FIG.535A




FIG.535A (1-K-14) OPT:KEY LESS START (E11)(E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96L11	PANEL ASSY, MAIN SWITCH KLS	1	
2	37110-96L10	.SWITCH ASSY, MAIN	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
4	37143-96L00	..KNOB, MAIN SWITCH	1	
5	37114-96L10	.SHEET, MAIN SWITCH PANEL	1	
6	37139-96L40	.PANEL, MAIN SWITCH	1	
7	37820-93J10	.SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SW LOCK	1	
9	37826-92J10	..NUT	1	
10	38500-93J90	.BUZZER, WARNING	1	
11	09407-08401	.CLAMP (L:80)	1	
12	03122-05165	.SCREW	4	
13	37100-96L21	PANEL ASSY, DUAL ENGINE SWITCH	1	
14	37110-96L10	.SWITCH ASSY, MAIN	2	
15-1	37141-99E00	..KEY (931)	4	
15-2	37141-99E10	..KEY (932)	4	
15-3	37141-99E20	..KEY (933)	4	

DF140A_E11_019_535A
OPT:KEY LESS START

FIG.535A




FIG.535A (1-K-15) OPT:KEY LESS START (E11)(E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
15-4	37141-99E30	..KEY (934)	4	
15-5	37141-99E40	..KEY (935)	4	
15-6	37141-99E50	..KEY (936)	4	
16	37143-96L00	..KNOB, MAIN SWITCH	2	
17	37114-96L00	.SHEET, MAIN SWITCH PANEL	1	
18	37139-96L50	.PANEL, MAIN SWITCH	1	
19	37820-93JA0	.SWITCH ASSY, EMERGENCY	1	
20	37823-92E01	..PLATE ASSY, EMERGENCY SW LOCK	1	
21	37826-92J10	..NUT	1	
22	38500-93J90	.BUZZER, WARNING	2	
23	09407-08401	.CLAMP (L:80)	2	
24	03122-05165	.SCREW	4	
25	37105-96L11	HARNESS SET, KLS CONTROLLER	1	
26	32980-38F00	.HOLDER, KLS CONT	1	
27	36623-96L10	.HARNESS ASSY, KLS CONT	1	
28	36615-96300	..TERMINAL	1	
29	36662-96L10	.HARNESS ASSY, KLS CAN	1	L:6500+2000
30	37173-96L10	.HOLDER, KLS PARTS	1	SMALL TYPE
31	38500-93J90	.BUZZER ASSY, KLS	1	
32	38860-96L01	.RELAY ASSY, KLS	1	
33	32851-93J00	.CUSHION, LEAD WIRE	1	
34	36621-96L00	HARNESS ASSY, KLS DUAL ENG	1	

DF140A_E11_019_535A
OPT:KEY LESS START

FIG.535A




FIG.535A (1-L-2) OPT:KEY LESS START (E11)(E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	36664-96L00	HARNESS ASSY, KLS CAN	1	L:920
36	36663-96L10	WIRE, KLS CAN EXT	1	CONNECTOR:BLUE
37	36663-96L00	WIRE, KLS CAN EXT	1	CONNECTOR:BLACK
38-1	37170-96L14	CONTROLLER SET, KLS 315MHZ	1	
38-2	37170-96L04	CONTROLLER SET, KLS 433MHZ	1	
39	37117-96L00	.DECAL, KLS	2	
40-1	37171-96L12	.CONTROLLER ASSY, KLS 315MHZ	1	
40-2	37171-96L02	.CONTROLLER ASSY, KLS 433MHZ	1	
41-1	37172-96L10	.REMOCON ASSY, KLS 315MHZ	2	
41-2	37172-96L01	.REMOCON ASSY, KLS 433MHZ	2	
42	37173-96L00	HOLDER, KLS PARTS	1	LARGE TYPE

NOTE: USE FREQUENCY ASSIGNED ON YOUR MARKET.
FOR DETAILES, PLEASE MAKE SURE OF SUZUKI DEALERS.

DF100AT E11
DF115AT E11
DF115AZ E11
DF140AT E11
DF140AZ E11
DF115AST E03

DF140A_E11_019_535A
OPT:KEY LESS START

FIG.541A




FIG.541A (1-L-3) OPT:REMOTE CONTROL ASSY DUAL (1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-88L10	REMOTE CONTROL ASSY	1	
2	67261-88L10	.GRIP, REMOCON NO.2	2	
3	67261-88L00	.GRIP, REMOCON NO.1	2	
4	37850-88L10	.SWITCH ASSY, PTT	1	
5	67296-88L00	.SCREW	6	
6	67288-92E20	.WASHER	6	
7	67212-88L10	.COVER, PLUG (DUAL)	1	
8	68111-88L00	.EMBLEM, MARK (S)	1	
9	67257-88L00	.CAP, LEVER	2	
10	67281-88L10	.DECAL (DUAL)	1	
11	67296-92E60	.SCREW	4	
12	67288-92E60	.WASHER	4	
13	67253-92E00	.WASHER	2	
14	67275-95600	.END, CABLE	4	
15	67273-95600	.SPACER	2	
16	67271-88L10	.COVER, REMOCON LEVER LOWER	2	
17	67211-88L10	.COVER (DUAL)	1	
18	36890-88L00	.WIRE ASSY, NEWTRAL & PTT SW	1	
19	67263-88L30	.CAP, GRIP SW HOLE	1	
20	67217-88L00	.GUIDE, WATER PROOF	1	
21	67296-88L10	.SCREW, WATER PROOF GUIDE	2	
22	37850-88L30	.SWITCH ASSY PTT STBD (DUAL)	1	
23	37850-88L20	.SWITCH ASSY PTT PORT (DUAL)	1	
24	67264-88L00	.COVER, LEVER DESIGN	2	
25	67264-88L10	.COVER, LEVER PLATING	2	
26	67251-88L00	.LEVER, HANDLE	2	
27	67500-88L10	KIT, REMOCON SPACER DUAL	1	
28	09125-05135	.SCREW (5X65)	4	
29	09160-05029	.WASHER (5.5X12X0.8)	4	
30	09140-05005	.NUT	4	
31	67273-88L10	.GROMMET, REMOCON (DUAL)	1	

FIG.542A




FIG.542A (1-L-4) OPT:REMOTE CONTROL ASSY DUAL (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-88L10	REMOTE CONTROL ASSY	1	
2	67222-92E00	.DUAL PLATE	2	
3	67223-92E00	.BRAKE ADJUST	2	
4	67288-92E00	.WASHER	2	
5	67292-94300	.E RING	8	
6	67272-88L00	.GOM SEAL, WATERPROOF	2	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	2	
9	67224-92E00	.BRAKE ARM ASSY	2	
10	09140-06020	.NUT	4	
11	37721-92E10	.SWITCH ASSY, NEUTRAL	1	
12	67236-92E00	.ROLLER	2	
13	67296-88D10	.SCREW	4	
14	67296-92E20	.SCREW	4	
15	67226-92E00	.BOLT, STOPPER FRONT	2	
16	67226-92E10	.BOLT, STOPPER REAR	2	
17	67240-92E00	.ARM ASSY, THROTTLE	2	
18	67228-92E00	.WASHER	2	
19	67286-92E00	.BOLT	6	
20	67230-88L00	.ARM ASSY, SHIFT	2	
21	09125-05042	.SCREW (5X10)	18	
22	67234-88L00	.CASE, GEAR	2	
23	67245-92E00	.LEVER ASSY, THROTTLE	2	
24	67227-92E00	.STOPPER	2	
25	09126-06006	.SCREW (6X20)	4	
26	67233-92E00	.SPRING	2	
27	67235-92E00	.PLATE, SHIFT LOCK	2	
28	67237-92E01	.SPRING	10	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	67238-88L00	.GEAR, DRIVE	2	
32	67231-88L00	.GEAR, SHIFT	2	
33	67232-88L00	.BUSH, SHIFT GEAR	2	
34	67241-88L00	.ROD, FREE ACCEL	2	

DF140A_E11_019_542A
OPT:REMOTE CONTROL ASSY DUAL (2)

FIG.542A




FIG.542A (1-L-5) OPT:REMOTE CONTROL ASSY DUAL (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	2	
36	67246-88L00	.SHAFT, REMOCON DRIVE	2	
37	67291-92E10	.SNAP RING	2	
38	67243-92E00	.CAP, HOLE	2	
39	67252-88L00	.BUSH, REMOCON DRIVE SHAFT	2	
40	67253-88L00	.WASHER	2	
41	67239-92E10	.PLATE, SHIFT PIN	2	
42	67274-88L10	.FLANGE, COVER BASE (DUAL)	2	
43	67287-92E10	.NUT	1	
44	67296-95610	.SCREW	4	
45	67296-92E30	.SCREW	4	
46	67296-92E80	.SCREW	3	
47	09160-05024	.WASHER (5.5X16X1.5)	4	
48	67287-92E00	.NUT	4	
49	67273-88L10	.GROMMET, REMOCON (DUAL)	1	

FIG.544A




FIG.544A (1-L-6) OPT:REMOTE CONTROL ASSY SINGLE (1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-88L00	REMOTE CONTROL ASSY, SINGLE	1	
2	67261-88L10	.GRIP, REMOCON NO.2	1	
3	67261-88L00	.GRIP, REMOCON NO.1	1	
4	37850-88L00	.SWITCH ASSY, PTT	1	
5	67296-88L00	.SCREW	3	
6	67288-92E20	.WASHER	3	
7	67212-88L00	.COVER, PLUG (SINGLE)	1	
8	68111-88L00	.EMBLEM, MARK (S)	1	
9	67257-88L00	.CAP, LEVER	1	
10	67281-88L00	.DECAL (SINGLE)	1	
11	67296-92E60	.SCREW	2	
12	67288-92E60	.WASHER	2	
13	67253-92E00	.WASHER	1	
14	67275-95600	.END, CABLE	2	
15	67273-95600	.SPACER	1	
16	67271-88L10	.COVER, REMOCON LEVER LOWER	1	
17	67211-88L00	.COVER (SINGLE)	1	
18	67264-88L00	.COVER, LEVER DESIGN	1	
19	67264-88L10	.COVER, LEVER PLATING	1	
20	67251-88L00	.LEVER, HANDLE	1	
21	67500-88L00	KIT, REMOCON SPACER SINGLE	1	
22	09125-05135	.SCREW (5X65)	4	
23	09160-05029	.WASHER (5.5X12X0.8)	4	
24	09140-05005	.NUT	4	
25	67273-88L00	.GROMMET, REMOCON (SINGLE)	1	

FIG.545A




FIG.545A (1-L-7) OPT:REMOTE CONTROL ASSY SINGLE (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-88L00	REMOTE CONTROL ASSY	1	
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67272-88L00	.GOM SEAL, WATERPROOF	1	
7	67291-92E00	.SNAP RING	1	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	09140-06020	.NUT	2	
11	37721-88L00	.SWITCH ASSY, NEUTRAL	1	
12	67236-92E00	.ROLLER	1	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT	3	
20	67230-88L00	.ARM ASSY, SHIFT	1	
21	09125-05042	.SCREW (5X10)	10	
22	67234-88L00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67237-92E01	.SPRING	5	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	67238-88L00	.GEAR, DRIVE	1	
32	67231-88L00	.GEAR, SHIFT	1	
33	67232-88L00	.BUSH, SHIFT GEAR	1	
34	67241-88L00	.ROD, FREE ACCEL	1	

DF140A_E11_019_545A
OPT:REMOTE CONTROL ASSY SINGLE (2)

FIG.545A




FIG.545A (1-L-8) OPT:REMOTE CONTROL ASSY SINGLE (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-88L00	.SHIFT, REMOCON DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67243-92E00	.CAP, HOLE	1	
39	67252-88L00	.BUSH, REMOCON DRIVE SHAFT	1	
40	67253-88L00	.WASHER	1	
41	67239-92E10	.PLATE, SHIFT PIN	1	
42	67274-88L00	.FLANGE, COVER BASE (SINGLE)	2	
43	67296-95610	.SCREW	4	
44	67296-92E30	.SCREW	4	
45	09160-05024	.WASHER (5.5X16X1.5)	4	
46	67287-92E00	.NUT	4	
47	67273-88L00	.GROMMET, REMOCON (SINGLE)	1	

FIG.570A




FIG.570A (1-L-9) OPT:TILLER HANDLE (DF100AT)(DF115AT)(DF115AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63002-90J35-YAY	KIT TILLER HANDLE (BLACK)	1	
2	21110-88L00	.LEVER, SHIFT	1	
3	23230-90J20	.CABLE, SHIFT	1	
4	36620-87L00	.WIRE ASSY, HARNESS	1	
5	37110-87L01	.SWITCH ASSY, IGNITION	1	
6-1	37141-99E00	..KEY (931)	1	
6-2	37141-99E10	..KEY (932)	1	
6-3	37141-99E20	..KEY (933)	1	
6-4	37141-99E30	..KEY (934)	1	
6-5	37141-99E40	..KEY (935)	1	
6-6	37141-99E50	..KEY (936)	1	
6-7	37141-99E60	..KEY (937)	1	
6-8	37141-99E70	..KEY (938)	1	
6-9	37141-99E80	..KEY (939)	1	
6-10	37141-99E90	..KEY (940)	1	
6-11	37141-99EA0	..KEY (941)	1	
6-12	37141-99EB0	..KEY (942)	1	
7	37143-99E00	..CAP, KEY	1	
8	37149-93J00	..CAP, CYLINDER BODY	1	
9	37820-87L10	.SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE, LOCK	1	
11	37826-92J10	..NUT	1	
12	38500-93J90	.BUZZER	1	
13	37850-87L01	.SWITCH ASSY, PTT	1	
14	37852-87J00	.PLATE, TRIM SWITCH	1	
15	63121-88L10	.COVER, UNDER	1	

DF140A_E11_019_570A
OPT:TILLER HANDLE

FIG.570A




FIG.570A (1-L-10) OPT:TILLER HANDLE (DF100AT)(DF115AT)(DF115AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
16	63210-88L00	.GRIP, HANDLE	1	
17	63221-88L00	.SHAFT, THROTTLE	1	
18	63223-92D00	.STOPPER, HANDLE ROD	1	
19	63225-88L00	.BUSH, HANDLE ROD	1	
20	63227-93200	.PIN, HANDLE ROD	1	
21	63235-88L00	.PLATE, THROTTLE SHAFT	1	
22	63246-88L00	.STOPPER THROTTLE ADJ	1	
23	63250-88L00	.ARM ASSY, THROTTLE	1	
24	63251-87J00	.BOLT, SHIFT GEAR ASSY	4	
25	63260-88L00	.GEAR ASSY, SHIFT	1	
26	63272-87J00	..PLATE, BALL GUIDE	1	
27	63273-87J00	..BALL	1	
28	63262-87J00	.BUSH, SHIFT LEVER	1	
29	63271-87J00	.PLATE, LOCK	1	
30	63248-99J00	.PLATE, THROTTLE ADJ NOTCH	1	
31	63261-87J00	.BUSH, SHIFT GEAR	1	
32	63274-87J00	.E RING	1	
33	63610-87J00	.CABLE, THROTTLE	1	
34	37853-88L90	.GROMMET, PTT SWITCH LEAD	1	
35	63626-88L00	.GROMMET, WIRE HARNESS	1	
36	67292-87J00	.E RING	2	
37	09126-06015	.SCREW (6X23)	1	
38	09163-06001	.LOCK WASHER	1	
39	09440-12027	.SPRING	1	
40	21112-88L00	.BOLT SHIFT LEVER	1	
41	09125-05047	.SCREW (5X14)	6	

FIG.570A




FIG.570A (1-L-11) OPT:TILLER HANDLE (DF100AT)(DF115AT)(DF115AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
42	63611-88L00	.BOLT CLAMP BRACKET	3	
43	63612-87J00	.BRACKET, CLAMP	1	
44	34200-87L00	.TACHOMETER ASSY, WITH MONITOR	1	
45	36617-88L90	.CLAMP PLATE, MAIN HARNESS	1	
46	37112-88L91	.LABEL, IGNITION SWITCH	1	
47	37835-91J00-YAY	.LABEL, STOP (BLACK)	1	
48	37851-88L90	.BASE, PTT SWITCH	1	
49	37852-88L90	.HARNESS, GUIDE	1	
50	37861-87L11	.SWITCH, TROLLING CONTROL	1	
51	37864-88L91	.LABEL, TROLL MODE	1	
52	63244-99J00	.KNOB, THROTTLE ADJ	1	
53	63245-99J00	.BUSH, THROTTLE ADJ	1	
54	63612-88L10	.BRACKET, CLAMP SHIFT	1	
55	09260-10006	.BALL	1	
56	19140-92J10	.LEVER, THROTTLE	1	
57	21131-88L01	.MARK, CLUTCH SHIFT	1	
58	43761-90J10-YAY	.BRACKET, TILLER HANDLE (BLACK)	1	
59	43762-88L00	.BOLT TILLER HANDLE PIVOT	1	
60	43768-88L00	.SPACER, TILLER HANDLE	1	
61	09116-08137	.BOLT (8X22)	1	
62	09159-12014	.NUT	1	
63	09160-12066	.WASHER (12.5X22X2.5)	2	
64	09160-12124	.WASHER (12.5X32X1.5)	1	
65	63115-88L01	.BUSH, TILLER HANDLE	2	
66	09164-13010	.WASHER	1	

FIG.570A




FIG.570A (1-L-12) OPT:TILLER HANDLE (DF100AT)(DF115AT)(DF115AZ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
67	63215-93110	.MARK, HANDLE GRIP	1	
68	43769-90J00	.BOLT (12X50)	2	
69	63132-88L00	.STOPPER, TILLER HANDLE	1	
70	63251-88L90	.BOLT	2	
71	37855-88L90	.SCREW, THROTTLE GRIP	1	
72	37854-88L90	.WASHER, THROTTLE GRIP	1	
73	63258-88L00	.WASHER	1	
74	09440-06037	.SPRING	1	
75	03522-05169	.SCREW	3	
76	63247-99J00	.PLATE,THROTTLE ADJ KNOB	1	
77	63111-88L00-YAY	.HOUSING, TILLER HANDLE (BLACK)	1	
78	43770-90J00	.DAMPER ASSY, STEERING	1	
79	43778-90J00	..NUT, ROD	4	
80	43779-90J00	..WASHER, ROD	5	
81	67725-90J00	..BOLT, DRAG LINK PLATE	2	
82	43781-90J00	..SPACER/WASHER SET	1	
83	67734-90J00	..BUSH, DRAG LINK	3	
84	67725-90J10	..BOLT, DRAG LINK	1	
85	67725-90J20	..BOLT, DRAG LINK	1	
86	67726-90J00	..NUT, DRAG LINK	2	
87	29162-93J20	.WASHER LOCK	2	
88	09160-12066	.WASHER (12.5X22X2.5)	2	
89	09407-14403	.CLAMP (L:125)	1	

DF100AT E11
DF115AT E11
DF115AT E40
DF115AZ E11
DF115AZ E40

FIG.585A




FIG.585A (1-L-13) OPT:GASKET SET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11400-92862	GASKET SET	1	
2	11141-92J01	.GASKET, CYLINDER HEAD	1	
3	11189-90J00	.GASKET, CYLINDER HEAD COVER	1	
4	11265-87E10	.GASKET, PROTECTION COVER	2	
5	11489-90J00	.GASKET, OIL PAN	1	
6	13119-90J00	.GASKET, INTAKE MANIFOLD	1	
7	13421-90J01	.GASKET, THROTTLE BODY	1	
8	14151-90J00	.GASKET, RECTIFIER	1	
9	17472-87E10	.GASKET, PUMP CASE PANEL	1	
10	51211-90J22	.GASKET, ENGINE HOLDER	1	

FIG.601A




FIG.601A (1-L-14) OPT:MULTI FUNCTION GAUGE (1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L43	KIT, SINGLE GAUGE MECH	1	
2	34011-96L13	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L30	.ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	34000-96L53	KIT, DUAL GAUGE MECH	1	
10	34011-96L13	.SET, MULTI GAUGE	2	
11	34112-96L00	..NUT, GAUGE	2	
12	34193-96L00	..BEZEL, GAUGE	2	
13	34211-96L00	..COVER, GAUGE	2	
14	34825-96L00	..PACKING, GAUGE	2	
15	36661-96L30	.ADAPTER, GAUGE	2	
16	36615-96300	..TERMINAL	10	
17	36662-88L10	.WIRE, 2 EXTENSION	2	
18	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
19	36664-88L00	.CONNECTOR, BRANCH	2	
20	36665-87L10	.ADAPTER, AUGE FOR MULT	1	
21	36665-88L00	.UNIT, RESISTOR FEMALE	1	
22	36665-88L10	.UNIT, RESISTOR MALE	1	

FIG.602A




FIG.602A (1-L-15) OPT:MULTI FUNCTION GAUGE (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36001-88L00	SET, WIRE	1	
2	36662-88L10	.WIRE, 2 EXTENSION	1	
3	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
4	36664-88L00	.CONNECTOR, BRANCH	1	
5	36665-88L00	.UNIT, RESISTOR FEMALE	1	
6	36665-88L10	.UNIT, RESISTOR MALE	1	
7	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
8	36662-88L10	WIRE, 2 EXTENSION	1	
9	36662-88L20	WIRE, 6 EXTENSION	1	
10	36662-88L30	WIRE, 15 EXTENSION	1	
11	36662-88L00	WIRE, 25 EXTENSION	1	
12	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
13	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
14	36665-88L00	UNIT, RESISTOR FEMALE	1	
15	36665-88L10	UNIT, RESISTOR MALE	1	
16	36664-88L00	CONNECTOR, BRANCH	1	
17	36667-96L11	WIRE, DUAL GAUGE ADAPTER	1	
18	36990-87D00	TERMINAL SET, WITH SLEEVE	1	
19	36682-92E00	WIRE, TRIM GAUGE EXT (L:6500)	2	
20	09407-10404	CLAMP (L:100)	2	

DF140A_E11_019_602A
OPT:MULTI FUNCTION GAUGE (2)

PART NO.	FIG.NO.-REF.NO.
10000	
11100-90J11	111A-1
11112-90J00	113A-13
11115-85FA1-001	111A-4
11117-89J00	111A-10
11117-90J10	113A-4
11118-95J00	204A-15
11141-92J01	111A-11
	585A-2
11170-90J11	111A-14
11173-90J00	111A-15
11179-90J00	111A-16
11189-90J00	111A-17
	585A-3
11196-90J00	162A-1
	162B-1
11216-90J10	113A-5
11261-87E10	311A-1
11261-93J00	111A-5
	113A-15
11265-87E10	311A-2
	585A-4
11291-90J10	113A-1
11300-92J40	113A-3
11330-90J00	113A-8
11332-90J00	113A-9
11382-93J00	111A-18
11400-92862	585A-1
11489-90J00	180A-1
	180B-1
	585A-5
11501-90J04-Y5S	180B-2-2
11501-90J04-YAY	180A-2
	180B-2-1
11510-90J00	136A-1
11512-99E00	136A-2
12100-92840-025	116A-8-2
12100-92841-0A0	116A-8-1
12100-92J10-050	116A-14
12111-92J00	116A-1
12140-92J10	116A-2
12140-92J10-050	116A-15
12151-86FA0	116A-3
12160-92J10	116A-5
12163-35F00	116A-6
12220-92J00	116A-9
12300-85830	116A-12-1
12300-85830-012	116A-12-2
12300-85854-0AA	116A-11-6
12300-85854-0BA	116A-11-7
12300-85854-0CA	116A-11-8
12300-85854-0DA	116A-11-9
12300-85854-0EA	116A-11-10
12340-85FB3-0A0	116A-11-1
12340-85FB3-0B0	116A-11-2
12340-85FB3-0C0	116A-11-3
12340-85FB3-0D0	116A-11-4
12340-85FB3-0E0	116A-11-5
12632-92J12	175A-1
12711-92J00	121A-1
12720-92J10	121A-2
12732-90J00	119A-1
12733-90J00	119A-4
12741-90J01	119A-2
12761-90J00	119A-9
12771-90J00	119A-10
12810-90J00	119A-11
12812-90J00	119A-13
12813-73G00	119A-12
12831-90J02	119A-14
12891-69G00	121A-3
12892-69G10-218	121A-4-1
12892-69G10-220	121A-4-2
12892-69G10-223	121A-4-3
12892-69G10-225	121A-4-4
12892-69G10-228	121A-4-5
12892-69G10-230	121A-4-6
12892-69G10-233	121A-4-7
12892-69G10-235	121A-4-8
12892-69G10-238	121A-4-9
12892-69G10-240	121A-4-10
12892-69G10-243	121A-4-11
12892-69G10-245	121A-4-12
12892-69G10-248	121A-4-13
12892-69G10-250	121A-4-14
12892-69G10-253	121A-4-15
12892-69G10-255	121A-4-16
12892-69G10-258	121A-4-17
12892-69G10-260	121A-4-18
12892-69G10-263	121A-4-19
12892-69G10-265	121A-4-20
12892-69G10-268	121A-4-21
12892-69G10-270	121A-4-22
12892-69G10-273	121A-4-23
12892-69G10-275	121A-4-24
12892-69G10-278	121A-4-25
12892-69G10-280	121A-4-26
12892-69G10-283	121A-4-27
12892-69G10-285	121A-4-28
12892-69G10-288	121A-4-29
12892-69G10-290	121A-4-30
12892-69G10-293	121A-4-31
12892-69G10-295	121A-4-32
12892-69G10-298	121A-4-33
12892-69G10-300	121A-4-34
12911-86FA2	121A-5
12915-86F51	121A-6
12921-90J01	121A-7
12931-90J00	121A-8
12932-85FA0	121A-9
12933-86510	121A-10
13110-90J11	122A-1
13119-90J00	122A-2
	585A-6
13300-92J11	163A-1
13370-88L00	143A-2
13370-88L10	143B-2
13421-90J01	163A-2
	585A-7
13510-90J00	163A-4
13614-89J00	143B-15
13614-93J00	143B-16
13650-52G00	315A-1
	315B-1
13655-87J00	315A-2
	315B-2
13710-99E00	134A-1
	134B-1
13810-90J01	134A-2
	134B-2
13813-92J00	134B-3
13820-90J00	134A-3
13840-90J00	134A-4
	134B-4
13851-90J00	134A-5
	134B-5
14151-90J00	311A-5
	585A-8
15100-90J11	146A-1
15190-92J10	146A-2
15192-92J00	146A-14
15200-92J00	143A-3
15200-92J10	143B-3
15410-92J00	146A-4
15411-92J00	146A-6
15412-92J00	146A-5
15413-92J00	146A-7
15415-92J00	146A-8
15419-92J00	146A-19
15421-92J00	146A-10
15600-92J20	143A-1
15600-92J30	143B-1
15612-88L00	143A-21
	143B-21
15613-88L00	143A-22
	143B-22
15613-92J00	143A-25
	143B-25
15614-88L00	143A-23
	143B-23
15626-92J00	143A-4
15626-92J10	143B-4
15628-99E00	143A-5
	143B-5
15629-99E10	143A-6
	143B-6
15641-88L00	143A-7
15641-88L10	143B-7
15641-88L31	143A-18
	143B-18
15641-88L51	143A-19
	143B-19
15642-88L00	143A-8
	143B-8
15642-88L10	143A-20
	143B-20
15643-88L10	143A-17
	143B-17
15644-88L00	143A-13
15644-88L10	143B-13
15645-88L00	143A-14
	143B-14
15648-92J00	143A-16
	143B-24
15650-99E00	143A-9
	143B-9
15654-88L00	143A-10
	143B-10
15681-92J00	144A-1
	144B-1
15683-87J00	143A-11
	143B-11
15691-92J00	143A-29
	143B-29
15710-82K50	144A-2
	144B-2
15716-65DT0	144A-3
	144B-3
15735-58B00	144A-4
	144B-4
15751-92J00	144A-5
	144B-5
15760-88L00	143A-12
	143B-12
15762-90J00	144B-7
15830-90J00	144B-10
16113-92J11	175A-2
16400-90J00	175A-3
16440-99E00	175A-4
16510-61A31	175A-14
16520-90J00	175A-5
16910-90J10	180A-13
	180B-13
16930-90J01	180A-14
	180B-14
17400-92J10	160B-21
17400-92J21	160A-21
17410-92J00	160A-1
	160B-1
17413-92J01	160A-18
17413-92J11	160B-18
17416-92J10	160A-19
	160B-19
17461-90J01	160A-2
	160B-2
17471-92J00	160A-3
17471-92J10	160B-3
17472-87E10	160A-4
	160B-4
	585A-9
17500-90J10	160A-22
	160B-22
17520-90J00	160A-23
	160B-23
17561-90J03	160A-5-1
	160B-5-1
17561-90J13	160A-5-2
	160B-5-2
17562-90J00	160A-6
	160B-6
17563-87D00	160A-7
	160A-24
	160B-7
	160B-24
17564-87D00	160A-8
	160B-8
17611-90J00-Y5S	162B-2-2
17611-90J00-YAY	162A-2
	162B-2-1
17612-90J00	160A-20
	160B-20
17631-90J00	160A-9
	160B-9
17632-90J00	160A-10
	160B-10
17635-87E00	160A-25
	160B-25
17635-90J00	160A-11
	160B-11
17660-90J00	162A-3
	162B-3
17670-90J10	162A-4-2
	162B-4-2
17670-90J20	162A-4-1
	162B-4-1
17680-90J00	162A-5
	162B-5
17711-90J00	162A-6
	162B-6
17712-92J00	162A-15
	162B-15
17913-99E12	180A-3
	180B-3
17917-87L00	410A-33
	410B-33
	410C-33
	507A-8
18134-77E00	122A-3
18137-77E00	122A-4
18141-90J00	122A-5
18148-90J00	122A-14
18213-98J30	315A-6
	315B-7
18498-87J41	144A-6
	144B-6
18498-88L01	143A-32
	143B-32
18498-89J51	146A-12
18498-90J21	111A-19
18498-96J21	146A-11
18498-99EA1	507A-6
18590-68H00	315A-3
	315B-3
18640-78G00	315B-5
19115-90J00	163A-6
19121-90J00	163A-7

PART NO.	FIG.NO.-REF.NO.
19130-92J00	163A-8
19131-95502	163A-9
19140-92J00	163A-10
19140-92J10	570A-56
20000	
21110-88L00	570A-2
21110-92J00	204A-1
21112-88L00	570A-40
21131-88L01	570A-57
21131-93J00	204A-16
21151-92J00	204A-2
21210-92J00	204A-3
21230-92J01	204A-4
22511-99011	204A-5
	336A-1-1
	336A-1-2
	336B-1-1
	336B-1-2
	336C-1
	336D-1
23111-90J02	204A-6-1
23111-90J12	204A-6-2
23115-92J00	204A-7
23230-90J20	570A-3
25111-92J00	210A-6-1
	210B-6-1
25111-92J10	210A-6-2
	210B-6-2
25131-92J00	210A-1
	210B-1
25141-92J01	210A-2
	210B-2
25222-90J00	210A-3
	210B-3
25232-90J00	210A-4
	210B-4
25321-92J10	210A-5
25321-92J20	210B-5
25700-92J00	407A-30
	407B-30
	407C-26
	407D-28
	407E-24
	407F-24
29103-93J00	335A-15
29116-93J00	210A-8
	210B-8
29117-93J10	401A-15
	401B-15
29162-93J20	570A-87
29404-93J10	311A-12
	336A-16
	336B-16
	336C-16
	336D-16
	337C-2
	337D-2
30000	
31100-92J00	301A-1
31111-94900	340A-10
	340B-2
31123-94910	340A-4
	340B-4
31133-90J10	340A-5
	340B-5
31133-94910	340A-6
	340B-6
31135-94900	340A-8
	340B-7
31136-90J20	340A-7
	340B-8
31150-92J00	301A-2
31170-92J00	301A-3
31173-92J00	301A-4
31173-94920	340A-3
	340B-3
31191-92J00	301A-5
31192-92J00	301A-6
31220-92J00	301A-7
31261-75F10	301A-8
31281-92J10	337A-18
	337B-18
	337C-3
	335B-15
	335C-15
	335D-8
	335E-8
	335F-8
31312-92J00	301A-11
31320-92J00	301A-12
31340-92J00	301A-10
31341-92J00	301A-13
31343-63J00	301A-14
31344-63J00	301A-15
31912-90J00	301A-16
31918-92J01	301A-17
32102-92J20	303A-1
32120-92J00	303A-2
32160-92J00	303A-3
32800-92J00	311A-6
32851-93J00	331A-1
	331B-1
	535A-33
32890-92J00	311A-7
32980-38F00	331A-2
	331B-2
	535A-26
33220-64L10	303A-4
33410-90J00	307A-1
33420-90J00	307A-4
33634-96J00	322A-4
	322B-4
	322C-4
33710-90J00	307A-2
33720-90J00	307A-5
33730-90J00	307A-6
33740-90J00	307A-3
33799-97E00	340A-9
	340B-9
33810-90J20	322A-1
	322B-1
	322C-1
33833-91J00	303A-5
33920-92JP1	326C-6
33920-92JQ1	326B-6
33920-92JR1	326A-6
33925-92J00	326A-7
	326B-7
	326C-7
33926-78A80	322C-5
34000-96L43	601A-1
34000-96L53	601A-9
34011-96L13	601A-2
	601A-10

PART NO.	FIG.NO.-REF.NO.
34100-93J02	501A-1-1
	501B-1-1
	501C-3-1
34100-93J13	501A-1-2
	501B-1-2
	501C-3-2
34100-93J22	501A-1-3
	501B-1-3
	501C-3-3
34100-93J33	501A-1-4
	501B-1-4
	501C-3-4
34100-93J42	501A-1-5
	501B-1-5
	501C-3-5
34100-93J53	501A-1-6
	501B-1-6
	501C-3-6
34100-93J62	501A-1-7
	501B-1-7
	501C-3-7
34112-96L00	601A-3
	601A-11
34190-87D00	501A-20
	501B-18
	501C-24
34190-88L00	602A-7
34190-95500	501A-21
	501B-19
	501C-25
34191-92E00	501A-3
	501A-15
	501B-3
	501B-13
	501C-5
	501C-17
34193-96L00	601A-4
	601A-12
34200-87L00	570A-44
34200-93J02	460A-3-1
	460B-3-1
	501C-20-1
34200-93J14	460A-3-2
	460B-3-2
	501C-20-2
34200-93J42	501A-18-1
	501B-16-1
	501C-22-1
34200-93J53	501A-18-2
	501B-16-2
	501C-22-2
34211-96L00	601A-5
	601A-13
34300-93J02	501A-8-1
	501B-8-1
	501C-10-1
34300-93J13	501A-8-2
	501B-8-2
	501C-10-2
34310-92E00	501A-9
	501B-9
	501C-11
34360-92E00	501A-10
	501B-10
	501C-12
34500-93J02	460B-5-1
	501A-12-1
	501C-14-1
34500-93J13	460B-5-2
	501A-12-2
	501C-14-2
34600-93J02	501A-6-1
	501B-6-1
	501C-8-1
34600-93J13	501A-6-2
	501B-6-2
	501C-8-2
34650-93J22	501A-14-1
	501B-12-1
	501C-16-1
34650-93J33	501A-14-2
	501B-12-2
	501C-16-2
34660-90J02	507A-1
34800-93J02	460A-1-1
	460B-1-1
	501C-1-1
34800-93J13	460A-1-2
	460B-1-2
	501C-1-2
34825-96L00	601A-6
	601A-14
34830-87J20	315A-4
	315B-4
34840-98J03	315A-5
34841-92J00	315A-7
	315B-8
34842-92J01	315A-8
	315B-9
34843-87L00	315A-9
	315B-10
34845-92J00	315A-12
	315B-13
34846-87L00	315A-10
	315B-11
36001-88L00	602A-1
36610-92J50	322C-3
36610-92J60	322B-3
36610-92J70	322A-3
36612-96J00	322A-14
	322B-14
	322C-15
36615-96300	331A-4
	331B-4
	501A-5
	501B-5
	501C-7
	535A-28
	601A-8
	601A-16
36616-90J10	322A-15
	322B-15
	322C-16
36617-88L90	570A-45
36617-93J10	322A-16
	322B-16
	322C-17
36618-43410	322A-6
	322B-6
	322C-7
36620-87L00	570A-4
36620-93J02	521A-4-1
36620-93J10	521A-1-1
36620-93J30	521A-2
36620-93J40	521A-1-2
36620-93J52	521A-4-2
36620-93J62	521A-4-3
36621-96L00	535A-34
36623-96L10	331A-3
	331B-3
	535A-27
36625-93J00	322A-22-1
	322B-22-1
	322C-23-1
36625-93J10	322A-22-2
	322B-22-2
	322C-23-2
36628-92E00	508A-3
	509A-3

PART NO.	FIG.NO.-REF.NO.
	510A-3
36630-92E00	521A-6
36646-93J01	508A-2
	509A-2
	510A-2
36660-94480	521A-7
36661-96L30	601A-7
	601A-15
36662-88L00	602A-11
36662-88L10	601A-17
	602A-2
	602A-8
36662-88L20	602A-9
36662-88L30	602A-10
36662-96L10	331A-5
	331B-5
	535A-29
36663-88L00	601A-18
	602A-3
	602A-13
36663-96L00	535A-37
36663-96L10	535A-36
36664-88L00	601A-19
	602A-4
	602A-16
36664-96L00	535A-35
36665-87L10	601A-20
36665-88L00	601A-21
	602A-5
	602A-14
36665-88L10	601A-22
	602A-6
	602A-15
36667-96L11	602A-17
36667-96L20	521A-8
36682-92E00	602A-19
36721-98L00	322A-7
	322B-7
	322C-8
36737-98L00	322A-8
	322B-8
	322C-9
36738-98L00	322A-9
	322B-9
	322C-10
36890-88L00	541A-18
36890-93J00	517A-23
36894-87D00	336A-3
	336B-3
	336C-3
	336D-3
	337C-33
	337D-33
36894-95201	336A-2
	336B-2
	336C-2
	336D-2
36895-87D10	337A-26
	337B-26
	337C-35
	337D-35
	405A-7
	405B-7
36990-87D00	602A-18
37100-96J00	530A-1
37100-96J15	530A-31
37100-96J25	530A-19
37100-96L11	535A-1
37100-96L21	535A-13
37105-96L11	535A-25
37110-87L01	570A-5
37110-93J01	530A-2
	530A-20
	530A-32
37110-93J11	508A-4
	510A-4
37110-96L10	509A-4
	535A-2
	535A-14
37112-88L91	570A-46
37114-96L00	535A-17
37114-96L10	535A-5
37117-96L00	331A-6
	331B-6
	535A-39
37139-96L40	535A-6
37139-96L50	535A-18
37139-99E00	530A-6
37139-99E30	530A-39
37139-99E40	530A-27
37141-99E00	508A-5-1
	509A-5-1
	510A-5-1
	530A-3-1
	530A-21-1
	530A-33-1
	535A-3-1
	535A-15-1
	570A-6-1
37141-99E10	508A-5-2
	509A-5-2
	510A-5-2
	530A-3-2
	530A-21-2
	530A-33-2
	535A-3-2
	535A-15-2
	570A-6-2
37141-99E20	508A-5-3
	509A-5-3
	510A-5-3
	530A-3-3
	530A-21-3
	530A-33-3
	535A-3-3
	535A-15-3
	570A-6-3
37141-99E30	508A-5-4
	509A-5-4
	510A-5-4
	530A-3-4
	530A-21-4
	530A-33-4
	535A-3-4
	535A-15-4
	570A-6-4
37141-99E40	508A-5-5
	509A-5-5
	510A-5-5
	530A-3-5
	530A-21-5
	530A-33-5
	535A-3-5
	535A-15-5
	570A-6-5
37141-99E50	508A-5-6
	509A-5-6
	510A-5-6
	530A-3-6
	530A-21-6
	530A-33-6
	535A-3-6
	535A-15-6
	570A-6-6
37141-99E60	508A-5-7
	510A-5-7
	530A-3-7
	530A-21-7
	530A-33-7
	570A-6-7

PART NO.	FIG.NO.-REF.NO.
37141-99E70	508A-5-8
	510A-5-8
	530A-3-8
	530A-21-8
	530A-33-8
	570A-6-8
37141-99E80	508A-5-9
	510A-5-9
	530A-3-9
	530A-21-9
	530A-33-9
	570A-6-9
37141-99E90	508A-5-10
	510A-5-10
	530A-3-10
	530A-21-10
	530A-33-10
	570A-6-10
37141-99EA0	508A-5-11
	510A-5-11
	530A-3-11
	530A-21-11
	530A-33-11
	570A-6-11
37141-99EB0	508A-5-12
	510A-5-12
	530A-3-12
	530A-21-12
	530A-33-12
	570A-6-12
37143-96L00	509A-6
	535A-4
	535A-16
37143-99E00	508A-6
	510A-6
	530A-4
	530A-22
	530A-34
	570A-7
37149-93J00	508A-7
	510A-7
	530A-5
	530A-23
	530A-35
	570A-8
37170-96L04	535A-38-2
37170-96L14	535A-38-1
37171-96L02	331A-7-1
	331B-7-1
	535A-40-2
37171-96L12	331A-7-2
	331B-7-2
	535A-40-1
37172-96L01	331A-8-1
	331B-8-1
	535A-41-2
37172-96L10	331A-8-2
	331B-8-2
	535A-41-1
37173-96L00	535A-42
37173-96L10	331A-9
	331B-9
	535A-30
37210-93J00	530A-17
37212-93J00	530A-18
37721-88L00	545A-11
37721-92E10	542A-11
37721-93J00	326A-8
	326B-8
	326C-8
37721-93J91	508A-8
	509A-7
	510A-8
37721-95500	518A-12
37726-90J10	326A-9
	326B-9
	326C-9
37803-93J05	530A-9
37805-93J00	530A-15
37820-87L10	570A-9
37820-93J04	508A-9
	509A-8
	510A-9
37820-93J10	530A-10
	530A-24
	535A-7
37820-93JA0	530A-36
	535A-19
37820-99E02	315A-11
	315B-12
37823-92E01	508A-10
	509A-9
	510A-10
	530A-11
	530A-25
	530A-37
	535A-8
	535A-20
	570A-10
37825-99E10	530A-13
37826-92J00	508A-11
	509A-10
	510A-11
37826-92J10	530A-12
	530A-26
	530A-38
	535A-9
	535A-21
	570A-11
37835-91J00-YAY	570A-47
37850-87L01	570A-13
37850-88L00	544A-4
37850-88L10	541A-4
37850-88L20	541A-23
37850-88L30	541A-22
37850-90J06	508A-12
	509A-11
	510A-12
37850-92E27	517A-5
37850-92J00	326A-1
	326B-1
	326C-1
37851-88L90	570A-48
37852-87J00	570A-14
37852-88L90	570A-49
37853-88L90	570A-34
37854-88L90	570A-72
37855-88L90	570A-71
37855-99E00	530A-16
37856-92J00	326A-2
	326B-2
	326C-2
37857-92J00	326A-3
	326B-3
	326C-3
37859-90J00	508A-51
	509A-50
	510A-51
37860-87L00	530A-43
37861-87L11	570A-50
37862-87L00	530A-44
37864-88L91	570A-51
38100-92J13	337A-2
	337B-2
	340A-1
38100-96J12	337C-4
	337D-4
	340B-1
38410-93J21	326A-4
	326B-4

PART NO.	FIG.NO.-REF.NO.
	326C-4
38415-93J20	326A-5
	326B-5
	326C-5
38500-93J00	521A-3
38500-93J90	331A-10
	331B-10
	508A-13
	509A-12
	510A-13
	530A-7
	530A-29
	530A-41
	535A-10
	535A-22
	535A-31
	570A-12
38860-76F01	322A-5
	322B-5
	322C-6
38860-96L01	331A-11
	331B-11
	535A-32
39950-88L02	602A-12
40000	
41111-90J13-Y5S	335B-1-2
	335C-1-2
41111-90J13-YAY	335A-1
	335B-1-1
	335C-1-1
41111-92J03-Y5S	335D-1-2
	335E-1-2
41111-92J03-YAY	335D-1-1
	335E-1-1
	335F-1
41121-90J21-Y5S	335B-2-2
	335C-2-2
41121-90J21-YAY	335A-2
	335B-2-1
	335C-2-1
41121-92J21-Y5S	335D-2-2
	335E-2-2
41121-92J21-YAY	335D-2-1
	335E-2-1
	335F-2
41130-92J30	335A-3
	335B-3
	335C-3
	335D-3
	335E-3
	335F-3
41135-92J00	335A-11
	335B-11
	335C-11
	335D-4
	335E-4
	335F-4
41161-94400	442A-1
41220-95E13	336A-17
	336B-17
	336C-17
	336D-17
41221-95E40	336A-18
	336B-18
	336C-18
	336D-18
41224-95E01	336A-19
	336B-19
	336C-19
	336D-19
41225-94400	336A-20
	336B-20
	336C-20
	336D-20
41226-97E00	210A-7
	210B-7
41228-90J00	336A-21
	336B-21
	336C-21
	336D-21
41230-95E00	336A-22
	336B-22
	336C-22
	336D-22
41233-95E10	336A-23
	336B-23
	336C-23
	336D-23
43111-90J40-Y5S	336B-4-2
43111-90J40-YAY	336A-4-1
	336B-4-1
43111-90J50-Y5S	336B-4-4
43111-90J50-YAY	336A-4-2
	336B-4-3
43111-92J80-Y5S	336C-4-2
43111-92J80-YAY	336C-4-1
	336D-4-1
43111-92J90-Y5S	336C-4-4
43111-92J90-YAY	336C-4-3
	336D-4-2
43112-99E00	180A-4
	180B-4
43211-93J00	336A-5
	336B-5
	336C-5
	336D-5
43711-97E10	336A-6
	336B-6
	336C-6
	336D-6
43750-90J61-Y5S	336B-7-2
	336C-7-2
43750-90J61-YAY	336A-7-1
	336B-7-1
	336C-7-1
	336D-7-1
43750-90J71-Y5S	336B-7-4
	336C-7-4
43750-90J71-YAY	336A-7-2
	336B-7-3
	336C-7-3
	336D-7-2
43761-90J10-YAY	570A-58
43762-88L00	570A-59
43768-88L00	570A-60
43769-90J00	570A-68
43770-90J00	570A-78
43778-90J00	570A-79
43779-90J00	570A-80
43781-90J00	570A-82
45421-87D03	335D-15
	335E-15
	335F-15
45421-90J00	335A-17
	335B-17
48000-90J39	337A-1
	337B-1
48000-96J13	337C-1
	337D-1
48121-90J00	337A-19
	337B-19
48121-92J00	337C-24
	337D-24
48311-96J20	337C-25
	337D-25

PART NO.	FIG.NO.-REF.NO.
48321-87D03	337C-26
	337D-26
48321-90J00	337A-20
	337B-20
48326-95E00	337A-21
	337B-21
	337C-27
	337D-27
48400-90J03	337A-3
	337B-3
48401-96J02	337C-7
	337D-7
48405-93J00	337C-14
	337D-14
48502-90J13	337A-9
	337B-9
48502-96J05	337C-5
	337D-5
	340B-11
48503-96J04	337C-6
	337D-6
48557-90J00	337A-7
	337B-7
48570-95E01	337C-16
	337D-16
48571-87L01	337A-5
	337B-5
48572-87J10	337A-6
	337B-6
48572-95E00	337C-17
	337D-17
48582-95E01	337A-11
	337B-11
	340B-12
48583-95E00	337A-10
	337B-10
	337C-18
	337D-18
48585-95E00	337A-12
	337B-12
	337C-19
	337D-19
48588-90J00	337A-14
	337B-14
48588-94900	337C-20
	337D-20
48601-94900	337C-8
	337D-8
48611-90J00	337A-4
	337B-4
48615-97E00	337C-15
	337D-15
48627-95E00	337C-9
	337D-9
48630-96J03	337C-10
	337D-10
48633-94900	337C-11
	337D-11
48641-96J03	337C-12
	337D-12
48650-94900	337C-13
	337D-13
48861-92J01	337C-21
	337D-21
48862-87J20	337A-8
	337B-8
48862-90J21	337A-17
	337B-17
48862-92J20	337A-15
	337B-15
	337C-22
	337D-22
48862-92J30	337A-16
	337B-16
	337C-23
	337D-23
48864-93J01	337A-13
	337B-13
48864-96J10	340B-13
50000	
51110-90851-Y5S	401B-1-2
51110-90851-YAY	401A-1
	401B-1-1
51115-90J00	401A-8
	401B-8
51122-90J00	401A-18
	401B-18
51123-90J01	401A-19
	401B-19
51211-90J22	401A-9
	401B-9
52111-90J02-Y5S	405B-1-2
52111-90J02-YAY	405A-1-1
	405B-1-1
52111-90J12-Y5S	405B-1-4
52111-90J12-YAY	405A-1-2
	405B-1-3
54112-90J21	401A-22
	401B-22
54114-90J10	401A-25
	401B-25
	405A-13
	405B-13
54121-87D01	405A-8
	405B-8
54123-90J01	401A-21
	401B-21
54125-90J10	401A-26
	401B-26
54130-90J40	401A-23
	401B-23
54148-90J11	401A-27
	401B-27
54151-90J00	405A-14
	405B-14
54160-90J20	405A-9
	405B-9
54166-90J11	405A-10
	405B-10
54211-90J01-Y5S	405B-15-2
54211-90J01-YAY	405A-15
	405B-15-1
54221-90J02-Y5S	405B-16-2
54221-90J02-YAY	405A-16
	405B-16-1
55110-90J15-Y5S	407B-1-2
	407C-1-2
55110-90J15-YAY	407A-1
	407B-1-1
	407C-1-1
	407F-1
55110-92J00-Y5S	407D-1-2
	407E-1-2
55110-92J00-YAY	407D-1-1
	407E-1-1
55116-87E00	407A-28
	407B-28
	407D-26
55125-90J01	407A-3
	407B-3
	407C-3
	407F-3
55125-92J00-Y5S	407D-3-2
	407E-3-2

PART NO.	FIG.NO.-REF.NO.
55125-92J00-YAY	407D-3-1
	407E-3-1
55127-87D00	336A-29
	336B-29
	336C-29
	336D-29
55320-94900	335A-4
	335B-4
	335C-4
	335D-5
	335E-5
	335F-5
55321-87J01	111A-7
	113A-17
	311A-3-1
	337A-24
	337B-24
55321-87J11	311A-3-2
	337A-28
	337C-37
55321-90J01	407A-5
	407B-5
	407C-5
	407D-5
	407E-5
	407F-5
55321-94910	335A-19
	335B-19
	335D-19
	335F-19
55332-87D01	160A-26
	160B-26
55332-87D11	407A-6
	407B-6
	407C-6
	407D-6
	407E-6
	407F-6
55333-87D02	160A-27
	160B-27
55333-87D10	407A-7
	407B-7
	407C-7
	407D-7
	407E-7
	407F-7
56120-92J01-Y5S	220B-24-2
56120-92J01-YAY	220A-24
	220B-24-1
56120-92J12-Y5S	220C-1-2
56120-92J12-YAY	220C-1-1
56123-92J00	220A-25
	220B-25
	220C-2
56130-90J00	220A-32
	220B-32
	220C-8
56140-92J00	220A-36
	220B-36
56140-92J30	220C-11
57110-92J60	220A-1-1
	220B-1-1
	220C-16-1
57110-92J70	220A-1-2
	220B-1-2
	220C-16-2
57130-92J01	405A-5
	405B-5
57133-90J02	220A-2
	220B-2
	220C-17
57300-92861	220A-4
	220B-4
57300-92871	220C-19
57500-87861	220A-8
	220B-8
57500-87873	220A-6
	220B-6
	220C-21
57500-92813	220A-12
	220B-12
	220C-27
57610-92J20	220A-15
	220B-15
57610-92J31	220C-31
57616-90J00	220A-23
	220B-23
57616-92J00	220C-39
57621-92J20	220A-16
	220B-16
	220C-32
57630-90J00	407A-29
	407B-29
	407D-27
57631-92J00	220A-18
	220B-18
	220C-33
57633-90J02	407A-23
	407B-23
	407C-21
	407D-21
	407E-19
	407F-19
57635-92J01	407A-24
	407B-24
	407C-22
	407D-22
	407E-20
	407F-20
58100-90JA0-019	407A-19-1
	407B-19-1
	407C-19-1
58100-90JB0-019	407A-19-2
	407B-19-2
	407C-19-2
58100-90JC0-019	407A-19-3
	407B-19-3
	407C-19-3
58100-90JD0-019	407A-19-4
	407B-19-4
	407C-19-4
58100-90JE0-019	407A-19-5
	407B-19-5
	407C-19-5
58105-90J00	407A-20
	407A-22
	407B-20
	407B-22
	407C-20
	407D-20
58200-92J40	407A-21-1
	407B-21-1
58200-92J50	407A-21-2
	407B-21-2
58200-92J60	407A-21-3
	407B-21-3
58200-92J70	407A-21-4
	407B-21-4
58200-92J80	407A-21-5
	407B-21-5
58200-92J90	407A-21-6
	407B-21-6
58200-92JA0	407D-19-1
58200-92JB0	407D-19-2
58200-92JC0	407D-19-3
58200-92JD0	407D-19-4

60000

PART NO.	FIG.NO.-REF.NO.
61112-92J10	420A-20
	420B-20
	420C-20
	420D-20
	420E-20
	420F-20
61124-92J10	410A-25
	410B-25
	410C-25
61134-90J20	410A-1
	410B-1
	410C-1
61150-99E00	180A-5
	180B-5
61155-99E01	180A-7
	180B-7
61401-90810-YAY	420A-1
	420B-1-1
	420C-1-1
	420D-1-1
	420E-1-1
61401-90820-Y5S	420B-1-2
	420C-1-2
	420D-1-2
	420E-1-2
61401-90830-YKV	420F-1
61422-90J40	420A-23
61422-90J50	420B-23-1
	420C-23-1
61422-90J60	420B-23-2
	420C-23-2
61422-92J20	420D-23-1
	420E-23-1
61422-92J30	420D-23-2
	420E-23-2
61424-93J00	420F-23
61430-92J00-Y5S	420B-6-2
	420C-6-2
	420D-6-2
	420E-6-2
61430-92J00-YAY	420A-6
	420B-6-1
	420C-6-1
	420D-6-1
	420E-6-1
61430-92J00-YKV	420F-6
61432-92J10	420A-21
	420B-21
	420C-21
	420D-21
	420E-21
	420F-21
61432-92J20	420F-21
61435-90JA0	420A-24
61435-90JB0	420B-24-1
	420C-24-1
61435-90JC0	420B-24-2
	420C-24-2
61435-92J50	420F-24
61435-92J60	420D-24-1
	420E-24-1
61435-92J70	420D-24-2
	420E-24-2
61438-92J10	420A-7
	420B-7
	420C-7
	420D-7
	420E-7
	420F-7
61439-92J10	420A-8
	420B-8
	420C-8
	420D-8
	420E-8
	420F-8
61441-92J10	420F-27
61443-88L20	420A-17
	420B-17-1
	420C-17-1
	420D-17-1
	420E-17-1
61443-88L30	420B-17-2
	420C-17-2
	420D-17-2
	420E-17-2
61443-92J20	420F-17
61444-92J00	420F-25
61453-88L20	420A-18
	420B-18-1
	420C-18-1
	420D-18-1
	420E-18-1
61453-88L30	420B-18-2
	420C-18-2
	420D-18-2
	420E-18-2
61453-92J20	420F-18
61454-92J00	420F-26
61458-90J00	410A-34
	410B-34
	410C-34
61494-90J01	136A-5
61610-93J00	420A-9
	420B-9
	420C-9
	420D-9
	420E-9
	420F-9
61621-87D20	420A-2
	420B-2
	420C-2
	420D-2
	420E-2
	420F-2
61633-90J02-Y5S	410B-14-2
	410B-15-2
61633-90J02-YAY	410A-14
	410A-15
	410B-14-1
	410B-15-1
61633-90J02-YKV	410C-14
	410C-15
61637-90J10	410A-16
	410B-16
	410C-16
61638-90J10	410A-17
	410B-17
	410C-17
61641-87D00	410A-18
	410B-18
	410C-18
61644-90J20	420A-3
	420B-3
	420C-3
	420D-3
	420E-3
	420F-3
61645-90J01-Y5S	410B-19-2
61645-90J01-YAY	410A-19
	410B-19-1
	410C-19
61680-90J01	420A-10
	420B-10
	420C-10
	420D-10
	420E-10

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	420F-10	63272-87J00	570A-26	67223-92E50	518A-6
61690-90J01	420A-11	63273-87J00	570A-27	67223-99E10	508A-17
	420B-11	63274-87J00	570A-32		509A-16
	420C-11	63610-87J00	570A-33		510A-17
	420D-11	63611-88L00	570A-42	67224-92E00	542A-9
	420E-11	63612-87J00	570A-43		545A-9
	420F-11	63612-88L10	570A-54	67224-92E50	518A-8
61810-90J10-Y5S	410B-2-2	63626-88L00	570A-35	67225-92E00	518A-25
61810-90J10-YAY	410A-2	65000-94L10	432A-1	67225-92E50	518A-9
	410B-2-1	65520-99100	432A-2	67226-92E00	542A-15
61810-90J10-YKV	410C-2	65561-95D00	432A-3		545A-15
61817-89J00	410A-3	65700-90J21	432A-5	67226-92E10	518A-14
	410B-3	65740-95D01	432A-4		542A-16
	410C-3	65750-95500	432A-6		545A-16
61820-90J11-Y5S	410B-4-2	65770-90J04	475A-1	67227-92E00	518A-23
61820-90J11-YAY	410A-4		475B-1		542A-24
	410B-4-1	65770-90J12	432A-7		545A-24
61820-90J11-YKV	410C-4	67140-95600	508A-54	67228-92E00	518A-17
61827-90J00	410A-5		508B-1		542A-18
	410B-5		509A-54		545A-18
	410C-5		510A-54	67229-95600	508A-18
61831-90J12-Y5S	410B-6-2	67200-88L00	544A-1		509A-17
61831-90J12-YAY	410A-6		545A-1		510A-18
	410B-6-1	67200-88L10	541A-1	67230-88L00	542A-20
61831-90J12-YKV	410C-6		542A-1		545A-20
63002-90J35-YAY	570A-1	67200-93J33	517A-1	67230-92E00	518A-19
63111-88L00-YAY	570A-77		518A-1	67231-88L00	542A-32
63115-88L01	570A-65	67200-93J51	508A-1		545A-32
63121-88L10	570A-15		510A-1	67231-92E00	518A-40
63132-88L00	570A-69	67200-96L01	509A-1	67232-88L00	542A-33
63210-88L00	570A-16	67211-88L00	544A-17		545A-33
63215-93110	570A-67	67211-88L10	541A-17	67232-92E50	518A-43
63221-88L00	570A-17	67211-92E50	517A-29	67232-95600	508A-19
63223-92D00	570A-18	67212-88L00	544A-7		509A-18
63225-88L00	570A-19	67212-88L10	541A-7		510A-19
63227-93200	570A-20	67212-95600	508A-14		518A-41
63235-88L00	570A-21		509A-13	67233-92E00	518A-27
63244-99J00	570A-52		510A-14		542A-26
63245-99J00	570A-53	67217-88L00	541A-20		545A-26
63246-88L00	570A-22	67220-95630	508A-16	67234-88L00	542A-22
63247-99J00	570A-76		509A-15		545A-22
63248-99J00	570A-30		510A-16	67234-92E00	518A-21
63250-88L00	570A-23	67221-92E00	542A-8	67235-92E00	518A-28
63251-87J00	570A-24		545A-8		542A-27
63251-88L90	570A-70	67221-92E50	518A-7		545A-27
63258-88L00	570A-73	67222-92E00	542A-2	67236-92E00	518A-30
63260-88L00	570A-25		545A-2		542A-12
63261-87J00	570A-31	67222-92E50	518A-2		545A-12
63262-87J00	570A-28	67223-92E00	542A-3	67237-92E01	518A-31
63271-87J00	570A-29		545A-3		542A-28

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	545A-28	67252-95600	508A-26		509A-35
67238-87D00	508A-20		509A-25		510A-36
	509A-19		510A-26	67269-92E00	542A-29
	510A-20	67253-88L00	542A-40		545A-29
67238-88L00	542A-31		545A-40	67271-88L10	541A-16
	545A-31	67253-92E00	541A-13		544A-16
67238-92E50	518A-32		544A-13	67272-88L00	542A-6
67239-92E00	518A-33	67253-92E10	518A-37		545A-6
	542A-35	67253-95600	508A-27	67273-88L00	544A-25
	545A-35		509A-26		545A-47
67239-92E10	518A-29		510A-27	67273-88L10	541A-31
	542A-41		518A-39		542A-49
	545A-41	67254-92E50	517A-22	67273-95600	508A-37
67240-92E00	542A-17	67255-92E50	517A-8		509A-36
	545A-17	67255-99E10	508A-28		510A-37
67240-92E50	518A-16		509A-27		517A-25
67241-88L00	542A-34		510A-28		541A-15
	545A-34	67256-92E50	517A-11		544A-15
67241-92E50	518A-42	67256-95600	508A-29	67274-88L00	545A-42
67241-99E10	508A-21		509A-28	67274-88L10	542A-42
	509A-20		510A-29	67274-92E50	517A-28
	510A-21	67257-88L00	541A-9	67275-95600	508A-38
67242-92E50	517A-13		544A-9		509A-37
67243-92E00	542A-38	67257-92E00	517A-12		510A-38
	545A-38	67257-99E10	508A-30		517A-24
67243-95600	508A-22		509A-29		541A-14
	509A-21		510A-30		544A-14
	510A-22	67258-99E00	508A-31	67281-88L00	544A-10
67244-95600	508A-23		509A-30	67281-88L10	541A-10
	509A-22		510A-31	67282-94L00	508A-52
	510A-23	67259-87D00	508A-32		509A-51
67245-92E00	518A-22		509A-31		510A-52
	542A-23		510A-32	67283-92E50	517A-26
	545A-23	67261-88L00	541A-3	67284-92E50	517A-27
67245-95600	508A-24		544A-3	67284-94L00	508A-53
	509A-23	67261-88L10	541A-2		509A-52
	510A-24		544A-2		510A-53
67246-88L00	542A-36	67261-92E50	517A-10	67285-96L00	509A-53
	545A-36	67261-99E10	508A-33	67286-92E00	518A-18
67246-92E50	518A-34		509A-32		542A-19
67251-88L00	541A-26		510A-33		545A-19
	544A-20	67263-88L30	541A-19	67287-92E00	542A-48
67251-92E50	517A-9	67264-88L00	541A-24		545A-46
67251-99E20	508A-25		544A-18	67287-92E10	542A-43
	509A-24	67264-88L10	541A-25	67287-92E50	517A-19
	510A-25		544A-19	67288-92E00	542A-4
67252-88L00	542A-39	67264-95600	508A-35		545A-4
	545A-39		509A-34	67288-92E10	518A-4
67252-92E00	518A-35		510A-35	67288-92E20	517A-14
67252-92E10	518A-38	67267-93J00	508A-36		541A-6

PART NO.	FIG.NO.-REF.NO.
	544A-6
67288-92E60	517A-6
	541A-12
	544A-12
67288-92E70	517A-16
67291-92E00	518A-5
	542A-7
	545A-7
67291-92E10	518A-36
	542A-37
	545A-37
67292-87J00	570A-36
67292-94300	508A-39
	509A-38
	510A-39
	518A-3
	542A-5
	545A-5
67294-92E00	518A-11
67294-95600	508A-40
	508A-55
	508B-2
	509A-39
	509A-55
	510A-40
	510A-55
67295-92E10	517A-4
67295-92E50	517A-18
67296-88D10	517A-15
	518A-24
	542A-13
	542A-30
	545A-13
	545A-30
67296-88D20	517A-17
67296-88D30	517A-21
67296-88L00	541A-5
	544A-5
67296-88L10	541A-21
67296-90J10	508A-41
	509A-40
	510A-41
67296-92E11	508A-15
	509A-14
	510A-15
	518A-13
67296-92E20	518A-15
	542A-14
	545A-14
67296-92E30	542A-45
	545A-44
67296-92E60	541A-11
	544A-11
67296-92E80	542A-46
67296-94300	508A-42
	509A-41
	510A-42
67296-94310	508A-34
	509A-33
	510A-34
	517A-3
67296-95600	508A-43
	509A-42
	510A-43
67296-95610	508A-44
	509A-43
	510A-44
	542A-44
	545A-43
67296-95621	508A-56
	508B-3
	509A-56
	510A-56
67297-95600	508A-45
	509A-44
	510A-45
67298-92E50	517A-2
67341-90J32	410A-28
	410B-28
	410C-28
67343-90J20	410A-29
	410B-29
	410C-29
67344-90J00	410A-30
	410B-30
	410C-30
67361-90J10	410A-35
	410B-35
	410C-35
67467-89J01	442A-7
67473-89J00	163A-11
67500-88L00	544A-21
67500-88L10	541A-27
67600-90J00	442A-10
67631-90J00	442A-11
67701-90J01	442A-2
67721-99E00	442A-3
67725-90J00	570A-81
67725-90J10	570A-84
67725-90J20	570A-85
67725-99E00	442A-4
67725-99E20	442A-12
67726-90J00	570A-86
67726-99E00	442A-5
	442A-13
67728-99E00	442A-6
67734-90J00	570A-83
68110-87L01	420A-26
	420B-26
	420C-26
	420D-26
	420E-26
	420F-29
68111-88L00	541A-8
	544A-8
69711-93E10	136A-4
70000	
77811-54GB0-0PG	508A-46
	509A-45
	510A-46
77811-63J00-0PG	420A-19
	420B-19
	420C-19
	420D-19
	420E-19
	420F-19
90000	
99011-90J90-03B	420B-27-2
	420D-27-2
	420F-30-2
99011-90J90-054	420A-27-1
	420B-27-1
	420D-27-1
	420F-30-1
99011-90J90-059	420A-27-2
	420B-27-3
	420C-27
	420D-27-3
	420E-27
00000	
01421-0616A	119A-15
01421-08357	122A-7
01421-08407	144A-12
	144B-12
01421-08507	122A-8
01547-06167	303A-9
01547-06257	111A-23
01547-0625A	175A-10
01547-0635A	175A-11
01547-06557	111A-24
01550-06127	143A-35
	143B-35
	180A-16
	180B-16
	204A-21
	311A-16
	420A-14
	420B-14
	420C-14
	420D-14
	420E-14
	420F-14
01550-06167	163A-16
	311A-13
	410A-27
	410B-27
	410C-27
01550-0616A	119A-16
	175A-12
01550-06207	113A-11
	122A-9
	136A-3
	311A-14
01550-0620A	119A-17
01550-06257	146A-17
	162A-21
	162B-21
	307A-8
	401A-14
	401B-14
01550-06307	204A-14
	311A-15
01550-06357	163A-17
01550-08167	146A-16
01550-08207	111A-9
	113A-19
	301A-18
01550-0825A	401A-20
	401B-20
01550-0835A	119A-18
01550-08407	113A-12
	122A-10
01550-08557	163A-3
01550-08757	122A-11
01550-10507	301A-19
01550-12167	144A-13
01550-1230C	113A-2
01580-08257	410A-31
	410B-31
	410C-31
02112-0408A	143A-15
02112-0612A	111A-25
02142-0408B	143A-24
02142-06167	322A-18
	322B-18
	322C-19
02162-05207	315A-13
	315B-14
03112-0630B	501A-22
	501B-20
	501C-26
03121-0516A	530A-28
	530A-40
03122-05165	530A-14
	535A-12
	535A-24
03522-05169	570A-75
03542-06169	420A-22
	420B-22
	420C-22
	420D-22
	420E-22
	420F-22
04211-11129	122A-12
	401A-17
	401B-17
04211-13149	301A-20
04211-13189	111A-13
04221-04089	116A-7
04221-05109	119A-5
06111-07004	220A-20
	220B-20
	220C-35
06111-11004	220A-21
	220B-21
	220C-36
07120-06167	420A-15
	420B-15
	420C-15
	420D-15
	420E-15
	420F-15
08113-62090	220A-29
	220B-29
08211-30382	220A-9-1
	220B-9-1
08310-00067	322A-19
	322B-19
	322C-20
08316-10067	420A-16
	420B-16
	420C-16
	420D-16
	420E-16
	420F-16
08316-1006A	119A-19
08316-10087	122A-13
	144A-14
	144B-14
	146A-18
	322A-2
	322B-2
	322C-2
08321-01067	322A-20
	322B-20
	322C-21
08322-01067	307A-9
08331-3112A	175A-13
08331-41269	119A-8
08331-41359	401A-6
	401B-6
08341-31059	303A-11
09100-06131	407A-8
	407B-8
	407C-8
	407D-8
	407E-8
	407F-8
09100-08232	508A-47
	509A-46

PART NO.	FIG.NO.-REF.NO.
	510A-47
09100-12081	442A-14
09100-12090	335A-6-2
	335B-6-2
	335D-7-2
	335F-7-2
09100-12091	335A-6-1
	335B-6-1
	335C-6
	335D-7-1
	335E-7
	335F-7-1
09103-06093	315A-14
	315B-15
09103-06231	303A-6
09103-06266	111A-2
09103-06281	111A-8
	113A-18
	311A-4
	337A-25
	337B-25
09103-12049	119A-3
09103-16004	303A-7
09106-05030	303A-10
09106-10065	335A-12
	335B-12
	335C-12
	335D-13
	335E-13
	335F-13
09116-06121	162A-7
	162B-7
	335A-5
	335B-5
	335C-5
	335D-6
	335E-6
	335F-6
09116-06127	410A-20
	410B-20
	410C-20
09116-06215	134A-8
	134B-8
09116-06217	143A-26
	143B-26
09116-08122	220A-31
	220B-31
	220C-14
09116-08125	111A-12
09116-08128	180A-8
	180B-8
	401A-11
	401B-11
09116-08131	160A-12
	160B-12
09116-08137	335A-14
	335B-14
	335C-14
	335D-18
	335E-18
	335F-18
	407A-9
	407B-9
	407C-9
	407D-9
	407E-9
	407F-9
	570A-61
09116-08160	401A-10
	401B-10
09116-08174	410A-7
	410B-7
	410C-7
09116-10129	180A-9
	180B-9
09116-10150	407A-10
	407B-10
	407C-10
	407D-10
	407E-10
	407F-10
09116-10179	337A-22
	337B-22
	337C-28
	337D-28
09116-10181	401A-28
	401B-28
	405A-2
	405A-17
	405B-2
	405B-17
09117-08110	220A-35
	220B-35
	220C-15
09117-10039	407A-11
	407B-11
	407C-11
	407D-11
	407E-11
	407F-11
09119-05010	163A-12
09125-04004	518A-26
09125-04021	517A-7
09125-05042	518A-20
	542A-21
	545A-21
09125-05046	160A-13
	160B-13
	315A-15
	315B-16
09125-05047	570A-41
09125-05050	336A-8
	336B-8
	336C-8
	336D-8
	337A-27
	337B-27
	337C-36
	337D-36
09125-05135	541A-28
	544A-22
09125-06063	160A-28
	160B-28
	336A-9
	336A-24
	336B-9
	336B-24
	336C-9
	336C-24
	336D-9
	336D-24
	337C-34
	337D-34
	405A-6
	405B-6
09126-05003	508A-48
	509A-47
	510A-48
09126-06006	542A-25
	545A-25
09126-06015	570A-37
09131-05004	530A-45
09132-04034	160A-17
	160B-17
09136-06148	410A-8
	410B-8
	410C-8
09136-06149	410A-9
	410B-9
	410C-9

PART NO.	FIG.NO.-REF.NO.
09137-04004	326A-10
	326B-10
	326C-10
09140-05005	163A-13
	541A-30
	544A-24
09140-06020	508A-49
	509A-48
	510A-49
	518A-10
	542A-10
	545A-10
09140-10031	337C-29
	337D-29
09140-10032	336A-25
	336B-25
	336C-25
	336D-25
09140-14024	220A-5
	220B-5
	220C-20
09141-18005	407A-25
	407B-25
	407C-23
	407D-23
	407E-21
	407F-21
09159-12014	335A-7
	335B-7
	335C-7
	335D-9
	335E-9
	335F-9
	401A-24
	401A-29
	401B-24
	401B-29
	405A-11
	405B-11
	570A-62
09159-14020	335A-18
	335B-18
	335D-16
	335E-16
	335F-16
09159-22006	335A-8
	335B-8
	335C-8
	335D-10
	335E-10
	335F-10
09160-05024	542A-47
	545A-45
09160-05029	541A-29
	544A-23
09160-06046	163A-14
09160-06054	311A-8
09160-06055	442A-9
09160-06082	336A-26
	336B-26
	336C-26
	336D-26
09160-06085	407A-12
	407B-12
	407C-12
	407D-12
	407E-12
	407F-12
09160-06094	204A-8
09160-06104	508A-50
	509A-49
	510A-50
	517A-20
09160-08059	401A-16
	401B-16
09160-10082	335A-13
	335B-13
	335C-13
	335D-14
	335E-14
	335F-14
09160-12066	442A-15
	570A-63
	570A-88
09160-12110	335A-10
	335B-10
	335C-10
	335D-12
	335E-12
	335F-12
09160-12112	405A-12
	405B-12
09160-12113	405A-18
	405B-18
09160-12124	570A-64
09160-12128	335A-9
	335B-9
	335C-9
09160-13014	410A-21
	410B-21
	410C-21
09160-16048	303A-8
09160-18028	407A-26
	407B-26
	407C-24
	407D-24
	407E-22
	407F-22
09160-30036	220A-9-2
	220B-9-2
09160-30037	220A-9-3
	220B-9-3
09160-30038	220A-9-4
	220B-9-4
09160-30039	220A-9-5
	220B-9-5
09160-30041	220A-9-6
	220B-9-6
09160-30042	220A-9-7
	220B-9-7
09160-30043	220A-9-8
	220B-9-8
09160-30044	220A-9-9
	220B-9-9
09160-30055	220C-40
09160-30056	220C-41
09160-35002	220C-23-6
09160-35003	220C-23-8
09160-35006	220C-23-4
09160-35008	220C-23-5
09160-35009	220C-23-7
09160-35010	220C-23-9
09160-35013	220C-23-3
09160-35014	220C-23-2
09160-35015	220C-23-1
09160-39001	336A-10
	336B-10
	336C-10
	336D-10
09160-60003	220C-25-3
09160-60004	220C-25-4
09160-60005	220C-25-5
09160-60006	220C-25-6
09160-60007	220C-25-7
09160-60008	220C-25-1

PART NO.	FIG.NO.-REF.NO.
09160-60009	220C-25-2
09160-60011	220C-24
09160-70002	220A-10
	220B-10
09160-70005	220C-26
09161-16008	160A-14
	160B-14
09162-10005	337C-30
	337D-30
09163-06001	570A-38
09164-13010	570A-66
09164-14008	410A-22
	410B-22
	410C-22
09168-10022	407A-13
	407B-13
	407C-13
	407D-13
	407E-13
	407F-13
09168-12012	180A-10
	180B-10
09168-12013	144A-7
09168-16002	175A-6
09169-06075	134A-6
	134B-6
09169-06090	143A-27
	143B-27
09169-08039	410A-10
	410B-10
	410C-10
09169-28003	336A-11
	336B-11
	336C-11
	336D-11
09180-06186	163A-15
09180-09022	442A-16
09181-12158	175A-7
09181-39001	336A-12
	336B-12
	336C-12
	336D-12
09181-40186	220A-7-1
	220B-7-1
	220C-22-1
09181-40190	220A-7-7
	220B-7-7
	220C-22-7
09181-40195	220A-7-11
	220B-7-11
09181-41002	220C-22-11
	220A-7-2
	220B-7-2
	220C-22-2
09181-41003	220A-7-3
	220B-7-3
	220C-22-3
09181-41004	220A-7-4
	220B-7-4
	220C-22-4
09181-41005	220A-7-5
	220B-7-5
	220C-22-5
09181-41006	220A-7-6
	220B-7-6
	220C-22-6
09181-41008	220A-7-8
	220B-7-8
	220C-22-8
09181-41009	220A-7-9
	220B-7-9
	220C-22-9
09181-41010	220A-7-10
	220B-7-10
	220C-22-10
09181-41012	220A-7-12
	220B-7-12
	220C-22-12
09181-41013	220A-7-13
	220B-7-13
	220C-22-13
09181-41014	220A-7-14
	220B-7-14
	220C-22-14
09181-45003	220A-11-1
	220B-11-1
09181-45004	220A-11-2
	220B-11-2
09181-45005	220A-11-3
	220B-11-3
09181-45006	220A-11-4
	220B-11-4
09181-45007	220A-11-5
	220B-11-5
09181-45008	220A-11-6
	220B-11-6
09181-45009	220A-11-7
	220B-11-7
09181-70001	220A-13-1
	220B-13-1
09181-70002	220A-13-2
	220B-13-2
	220C-28-5
09181-70003	220A-13-3
	220B-13-3
	220C-28-7
09181-70004	220A-13-4
	220B-13-4
	220C-28-9
09181-70006	220A-13-5
	220B-13-5
	220C-28-1
09181-70008	220A-13-10
	220B-13-10
	220C-28-10
09181-70009	220A-13-6
	220B-13-6
	220C-28-2
09181-70010	220A-13-7
	220B-13-7
	220C-28-4
09181-70011	220A-13-8
	220B-13-8
	220C-28-6
09181-70012	220A-13-9
	220B-13-9
	220C-28-8
09202-05027	116A-10
09202-06031	160A-15
	160B-15
09202-07002	220A-17
	220B-17
	220C-37
09202-08006	405A-3
	405B-3
	407A-14
	407B-14
	407C-14
	407D-14
	407E-14
	407F-14
09204-01006	204A-9
	336A-27
	336B-27
	336C-27
	336D-27
09204-03003	407A-27
	407B-27
	407C-25
	407D-25
	407E-23
	407F-23
09205-02006	163A-5
09205-04014	210A-9
	210B-9
09205-10006	204A-17
09206-08001	111A-3
	401A-12
	401B-12
09206-09012	220A-37
	220B-37
	220C-12
09206-13019	113A-10
09208-06009	410A-36
	410B-36
	410C-36
09229-04025	420A-4
	420A-5
	420B-4
	420B-5
	420C-4
	420C-5
	420D-4
	420D-5
	420E-4
	420E-5
	420F-4
	420F-5
09246-05006	113A-14
09247-12013	144B-13
09248-10008	407A-15
	407B-15
	407C-15
	407D-15
	407E-15
	407F-15
09248-12009	180A-11
	180B-11
09248-12011	204A-10
09248-18011	113A-6
09248-18014	113A-7
09250-10001	336A-13
	336B-13
	336C-13
	336D-13
09260-10005	204A-18
09260-10006	570A-55
09261-05006	175A-8
09262-17019	401A-2
09262-35068	119A-6
09262-35069	401A-7
	401B-7
09263-28016	407A-2
	407B-2
	407C-2
	407D-2
	407E-2
	407F-2
09263-30051	220A-26
	220B-26
	220C-3
09263-45004	220C-13
09263-50001	220A-38
	220B-38
	220C-4
09265-25046	220A-3
	220B-3
	220C-18
09269-30014	220C-42
09269-60001	220C-29
09269-70001	220A-14
	220B-14
	220C-30
09280-09005	180A-6
	180B-6
09280-09008	180A-15
	180B-15
09280-13005	180A-12
	180B-12
09280-22019	111A-6
	113A-16
09280-22020	175A-9
09280-22022	119A-7
09280-26005	146A-13
09280-26006	111A-20
	162A-8
	162B-8
	401A-13
	401B-13
09280-46004	220A-33
	220B-33
	220C-9
09280-69001	210A-10
	210B-10
09280-97001	220A-27
	220B-27
	220C-5
09282-24003	401A-3
	401B-3
09282-24004	220A-34
	220B-34
	220C-10
09282-30007	220A-28
	220B-28
	220C-6
09282-39001	336A-14
	336B-14
	336C-14
	336D-14
09283-10011	210A-11
	210B-11
09283-32044	401A-4
	401B-4
09283-52006	116A-13
09289-06003	121A-11
09289-18001	401A-5
	401B-5
09306-06004	204A-11
09306-10001	204A-12
09306-13008	410A-24
	410B-24
	410C-24
09306-17001	337C-31
	337D-31
09307-13006	410A-23
	410B-23
	410C-23
09320-08021	322A-10
	322B-10
	322C-11
09320-08062	144A-8
	144B-8
09320-08076	143A-28
	143B-28
09320-09039	134A-7
	134B-7
09320-10008	311A-9
09320-11013	410A-11
	410B-11
	410C-11
09320-12011	311A-10
09321-08022	410A-12
	410B-12
	410C-12
09329-01007	311A-11
09329-10023	420A-13
	420B-13
	420C-13

PART NO.	FIG.NO.-REF.NO.
	420D-13
	420E-13
	420F-13
09329-10024	420A-12
	420B-12
	420C-12
	420D-12
	420E-12
	420F-12
09329-12004	122A-6
09343-70503-600	146A-3
09352-11153-600	162A-9
	162B-9
09352-50003-680	143A-30
	143B-30
09352-50903-00B	162A-14
	162B-14
09352-50903-600	162A-10
	162A-11
	162A-12
	162A-13
	162B-10
	162B-11
	162B-12
	162B-13
	507A-2
	507A-3
09352-73123-00D	475A-2
09355-13207-00B	111A-21
09355-40805-00B	336A-30
	336B-30
	336C-30
	336D-30
09355-40805-600	407A-16-1
	407A-16-2
	407B-16-1
	407B-16-2
	407C-16-1
	407C-16-2
	407D-16-1
	407D-16-2
	407E-16-1
	407E-16-2
	407F-16-1
	407F-16-2
09360-12008	144A-9
09360-12013	144B-9
09362-09008	407A-17
	407B-17
	407C-17
	407D-17
	407E-17
	407F-17
09363-08004	144A-10
09367-05003	407A-4
	407B-4
	407C-4
	407D-4
	407E-4
	407F-4
09367-06002	162A-16
	162B-16
09367-06006	507A-4
09380-17009	337C-32
	337D-32
09380-22015	337A-23
	337B-23
09380-38003	336A-15
	336B-15
	336C-15
	336D-15
09381-21002	116A-4
09383-04002	410A-37
	410B-37
	410C-37
09383-08004	204A-13
09385-06012	442A-8
09387-45001	405A-4
	405B-4
09387-52001	220A-30
	220B-30
	220C-7
09401-08412	143A-31
	143B-31
09401-08413	162A-17
	162B-17
	507A-5
09401-11423	146A-15
	432A-8
09401-11425	144A-11
	144B-11
09401-14409	162A-18
	162B-18
09401-20409	111A-22
09401-31407	162A-19
	162B-19
09403-06316	326A-11
	326B-11
	326C-11
09403-13408	143A-33
	143B-33
	204A-19
	335A-16
	335B-16
	335C-16
	335D-17
	335E-17
	335F-17
09403-20308	410A-32
	410B-32
	410C-32
09407-08401	530A-8
	530A-30
	530A-42
	535A-11
	535A-23
09407-10404	315A-16
	315B-17
	322A-21
	322B-21
	322C-22
	336A-31
	336B-31
	336C-31
	336D-31
	407A-18
	407B-18
	407C-18
	407D-18
	407E-18
	407F-18
	602A-20
09407-11401	315B-18
09407-14403	570A-89
09407-14407	315A-17
	315B-19
	331A-12
	331B-12
	501A-4
	501A-16
	501B-4
	501B-14
	501C-6
	501C-18
09407-18402	315A-18
	315B-20
09407-25402	410A-26
	410B-26
	410C-26
	507A-7

PART NO.	FIG.NO.-REF.NO.
09408-00024	162A-20
	162B-20
09408-00035	307A-7
09408-00050	146A-9
09408-00111	322A-17
	322B-17
	322C-18
09408-00302	143A-34
	143B-34
09409-05302-5PK	410A-13
	410B-13
	410C-13
09420-05009	160A-16
	160B-16
09440-06037	570A-74
09440-07071	204A-20
09440-09040	220A-19
	220B-19
	220C-34
09440-12027	570A-39
09440-19028	336A-28
	336B-28
	336C-28
	336D-28
09440-49004	220A-22
	220B-22
	220C-38
09471-12028	501A-2
	501B-2
	501C-4
09471-12077	460A-4
	460B-4
	501A-19
	501B-17
	501C-21
	501C-23
09471-12103	460B-6
	501A-7
	501A-11
	501A-13
	501A-17
	501B-7
	501B-11
	501B-15
	501C-9
	501C-13
	501C-15
	501C-19
09471-12108	460A-2
	460B-2
09481-10501	501C-2
	521A-5
09481-15501	322A-23
	322B-23
	322C-24
09481-15504	322A-11
	322B-11
	322C-12
09481-30504	322A-12
	322B-12
	322C-13
09481-60403	322A-13
	322B-13
	322C-14
09482-00427	111A-26
09800-81841	420A-25
	420B-25
	420C-25
	420D-25
	420E-25
	420F-28

SUZUKI **DF100A/115A/140A** PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved
No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION
Service Material Development Group, Service Engineering Department
300 Takatsuka, Minami, Hamamatsu, Japan

Copyright © SUZUKI MOTOR CORPORATION 2018 All Rights Reserved

SUZUKI MOTOR CORPORATION

PRINTED IN JAPAN

9900B-45413