SUZUKI

PARTS CATALOGUE

DL1050RCM0

(JS1EF12A/JS1EF11A)

DL1050RC
DL1050RQ

SUZUKI

Way of Life!

V-STROM 1050

E21

2019-11

1ST EDITION

PREFACE

When it becomes necessary to replace parts on SUZUKI MOTORCYCLES, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DL1050RCM0, DL1050RQM0.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E.NO.	: Engine number	OS	: Over size
F.NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length		
LH	: Right hand side		
RH	: Right hand side		

～100045 : Up to F.NO.100045

100046～ : From F.NO.100046

12 x 34 x 5.6····· Figures in the description column show the dimensions of parts.

ID OD T(or W,L)

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual. When assembling, use "SUZUKI SERVICE MANUAL".

6. SPECIFICATION CODE

This catalogue contains the parts for the model designed for the following spec.;

spec. code : E21.

7. SERIAL FRAME NUMBER

DL1000RCM0 : JS1EF12AZL7100001～


DL1000RQM0 : JS1EF11AZL7100001～

COLOR CHART
TABLEAU DES COULEURS

COLOR NO. NO DE COULEUR	COLOR DESCRIPTION DESCRIPTION DE COULEUR	COLOR NO. NO DE COULEUR	COLOR DESCRIPTION DESCRIPTION DE COULEUR
019	SLD.BLACK	BD7	QEB,YVB
17U	MET.URBAN GRAY	BTH	YVB,YUD
1ZV	CDY.TEAL BLUEISH GREEN	GWM	1ZV,YKV
291	SLD.BLACK 50% GLOSS	PGZ	MET.MAT FIBROIN GRAY
5NX	GL.SHAIN BLACK	QEB	MET.OORT GRAY NO.3
AA3	YLF,YVB	QQ7	MET.BRONZE
B03	T66,U6B	QRE	GL.BLAZE ORANGE
B1F	QRE,YUH	QSC	SATIN SILVER
B1G	YVB,YUH	T66	LTHR.CRYSTAL GRAY
B1H	T66,U3Z	U3Z	LTHR BLUE
B4F	PGZ,YVB,YUD	U6B	LTHR.BLACK
B4G	PGZ,YVB,YUH	YAP	MET.MAT SHADOW BLACK
B4H	YMD,QEB,YVB	YBA	PRL.SUZUKI DEEP BLUE NO.2
B4J	YBA,YU1	YGS	GL.SHINE BLACK
B4K	QEB,YBA,YU1	YHF	MET.PHANTOM GRAY
B4L	QQ7,YLF,QEB,YVB	YKV	MET.MAT BLACK NO.2
B4M	QEB,YVB,YUH,QRE	YLF	MET.THUNDER GRAY
B4N	YUD,YVB,YGS	YMD	MET.MYSTIC SILVER
B4P	YUH,YVB,YGS	YU1	CHAMPION YELLOW NO.2
B4Q	YKV,QEB,YGS	YUA	MET.MAT STELLAR BLUE
B4X	GL.SHINE BLACK	YUD	SLD.IRON GRAY
B5J	YHF,291	YUH	PRL.BRILLIANT WHITE


COLOR NO. NO DE COULEUR	COLOR DESCRIPTION DESCRIPTION DE COULEUR	COLOR NO. NO DE COULEUR	COLOR DESCRIPTION DESCRIPTION DE COULEUR
YVB	GL.SPARKLE BLACK		

FIG. 101A




DL1100R2CM2_E01_101A
GASKET SET

FIG. 104A




DL1100R2CM2_E01_104A
CYLINDER HEAD (FRONT)

FIG. 104B




DL1100R2CM2_E01_104B
CYLINDER HEAD (FRONT)

FIG. 105A




DL1100R2CM2_E01_105A
CYLINDER HEAD (REAR)

FIG. 107A




DL1100R2CM2_E01_107A
CYLINDER

FIG. 108A




DL1100R2CM2_E01_108A
CRANKCASE

FIG. 109A




DL1100R2CM2_E01_109A
CYLINDER HEAD (FRONT)

FIG. 112A




DL1100R2CM2_E01_112A
CRANKCASE COVER

FIG. 120A




DL1000(P)(M3)_E01_120A
CRANKSHAFT

FIG. 122A




DL1000(P)(M3)_E01_122A
STARTER CLUTCH

FIG. 126A




DL1000(P)(M3)_E01_126A
CAMSHAFT/VALVE

FIG. 127A




DL1000(P)(M3)_E01_127A
CAM CHAIN

FIG. 140A




DL1000(P)(M3)_E01_140A
THROTTLE BODY

FIG. 155A




DL1000(P)(M3)_E01_155A
AIR CLEANER

FIG. 163A




DL1000(P)(M3)_E01_163A
MUFFLER

FIG. 170A




DL1000(P)(M3)_E01_170A
OIL PUMP

FIG.172A




DL1000VFCM3_E01_172A
FUEL PUMP

FIG.178A




DL1000VFCM3_E01_178A
OIL COOLER

FIG.180A




DL1000VFCM3_E01_180A
WATER PUMP

FIG.185A




DL1000VFCM3_E01_185A
RADIATOR

FIG.187A




DL1000VFCM3_E01_187A
RADIATOR HOSE

FIG.189A




DL1000VFCM3_E01_189A
SHROUD

FIG.201A




DL1000VFCM3_E01_201A
CLUTCH

FIG.206A




DL1000VFCM3_E01_206A
TRANSMISSION

FIG.212A




DL1000YRCMJ_E21_212A
GEAR SHIFTING

FIG.301A




DL1000YRCMJ_E21_301A
STARTING MOTOR

FIG.303A




DL1000YRCMJ_E21_303A
MAGNETO

FIG.310A




DL1000YRCMJ_E21_310A
BATTERY

FIG.312A




DL1000YRCMJ_E21_312A
ELECTRICAL

FIG.330A




DL1000YRCMJ_E21_330A
SPEEDOMETER

FIG.330D




DL1000YRCMJ_E21_330D
SPEEDOMETER

FIG.333A




DL1000YRCMJ_E21_333A
HEADLAMP

FIG.334A




DL1000(P2CM2)_E01_334A
TURN SIGNAL LAMP

FIG.334B




DL1000(P2CM2)_E01_334B
TURN SIGNAL LAMP

FIG.339A




DL1000(P2CM2)_E01_339A
REAR COMBINATION LAMP

FIG.339B




DL1000(P2CM2)_E01_339B
REAR COMBINATION LAMP

FIG.350A




DL1000(P2CM2)_E01_350A
WIRING HARNESS

FIG.350B




DL1000(P2CM2)_E01_350B
WIRING HARNESS

FIG.352A




DL1000(P2CM2)_E01_352A
LOCK SET

FIG.352B




DL1000(P2CM2)_E01_352B
LOCK SET

FIG.355A




DL1000RRCM3_E01_355A
HANDLE SWITCH

FIG.355B




DL1000RRCM3_E01_355B
HANDLE SWITCH

FIG.401A




DL1000RRCM3_E01_401A
FRAME

FIG.406A




DL1000RRCM3_E01_406A
HOLDER

FIG.407A




DL1000RRCM3_E01_407A
STAND

FIG.407B




DL1000RRCM3_E01_407B
STAND

FIG.412A




DL1000RRCM3_E01_412A
CARRIER

FIG.415A




DL1000RRCM3_E01_415A
FOOTREST

FIG.420A




DL1000YRCM0_E01_420A
FUEL TANK

FIG.420B




DL1000YRCM0_E01_420B
FUEL TANK

FIG.423A




DL1000YRCM0_E01_423A
FUEL TANK COVER

FIG.423B




DL1000YRCM0_E01_423B
FUEL TANK COVER

FIG.427A




DL1000YRCM0_E01_427A
EMP51911M

FIG.433A




DL1000YRCM0_E01_433A
SIDE COVER

FIG.433B




DL1000YRCM0_E01_433B
SIDE COVER

FIG.444A




DL1000YRCM0_E01_444A
FRONT BRACKET

FIG.445A




DL1000YRCM0_E01_445A
FRAMECOVER

FIG.445B




DL1000YRCM0_E01_445B
FRAMECOVER

FIG.454A




DL1000YRCM0_E01_454A
WINDSCREEN

FIG.454B




DL1000YRCM0_E01_454B
WINDSCREEN

FIG.460A




DL1000YRCM0_E01_460A
FRONT FENDER

FIG.462E




DL1000YRCM0_E01_462E
HANDLEBAR

FIG.462F




DL1000YRCM0_E01_462F
HANDLEBAR

FIG.467A




DL1000YRCM0_E01_467A
HANDLELEVER

FIG.467B




DL1100RFCM0_E01_467B
HANDLE LEVER

FIG.472A




DL1100RFCM0_E01_472A
KNUCKLE COVER

FIG.474A




DL1100RFCM0_E01_474A
REAR FENDER

FIG.474B




DL1100RFCM0_E01_474B
REAR FENDER

FIG.481A




DL1100RFCM0_E01_481A
COWLING(2/2)

FIG.492A




DL1100RFCM0_E01_492A
FRONT BUMPER

FIG.496A




DL1100RFCM0_E01_496A
LABEL

FIG.505A




DL1100RFCM0_E01_505A
SEAT

FIG.505B




DL1100RFCM0_E01_505B
SEAT

FIG.521A




DL1100RFCM0_E01_521A
FRONT FORK DAMPER

FIG.524A




DL1100RFCM0_E01_524A
STEERING STEM

FIG.530A




DL1100RFCM0_E01_530A
FRONT WHEEL

FIG.530B




DL1100RFCM0_E01_530B
FRONT WHEEL

FIG.533A




DL1100RFCM0_E01_533A
HYDRAULIC UNIT

FIG.533B




DL1100RFCM0_E01_533B
HYDRAULIC UNIT

FIG.534A




DL1100RFCM0_E01_534A
BODY ELECTRICAL

FIG.534B




DL1000YRCM0_E01_534B
BODY ELECTRICAL

FIG.535A




DL1000YRCM0_E01_535A
FRONT CALIPER

FIG.536A




DL1000YRCM0_E01_536A
FRONT BRAKE HOSE

FIG.536B




DL1000YRCM0_E01_536B
FRONT BRAKE HOSE

FIG.537A




DL1000YRCM0_E01_537A
FRONT MASTER CYLINDER

FIG.539A




DL1000YRCM0_E01_539A
CLUTCH MASTER CYLINDER

FIG.541A




DL1000YRCM0_E01_541A
REAR SWINGARM

FIG.543A




DL1000YRCM0_E01_543A
REAR CUSHION LEVER

FIG.550A




DL1000(RECM2)_E01_550A
REAR WHEEL

FIG.550B




DL1000(RECM2)_E01_550B
REAR WHEEL

FIG.555A




DL1000(RECM2)_E01_555A
REAR CALIPER

FIG.558A




DL1000(RECM2)_E01_558A
REAR MASTER CYLINDER

FIG.558C




DL1000(RECM2)_E01_558C
REAR MASTER CYLINDER

FIG.970A




DL1000(RECM2)_E01_970A
OPTIONAL

FIG.970C




DL1000(RECM2)_E01_970C
OPTIONAL

FIG.970D




DL1000(RECM2)_E01_970D
OPTIONAL

FIG.970E




DL1000VRCAM2_E01_970E
OPTIONAL

FIG.970F




DL1000VRCAM2_E01_970F
OPTIONAL

FIG.970G




DL1000VRCAM2_E01_970G
OPTIONAL

FIG.970H




DL1000VRCAM2_E01_970H
OPTIONAL

FIG.970J




DL1000VRCAM2_E01_970J
OPTIONAL

FIG.970K




DL1000VRCAM2_E01_970K
OPTIONAL

FIG.970L




DL1000VRCAM2_E01_970L
OPTIONAL

FIG.970M




DL1000VRCAM2_E01_970M
OPTIONAL

FIG.970N



DL1100VRCM2_E01_970N
OPTIONAL

FIG.970P



DL1100VRCM2_E01_970P
OPTIONAL

FIG.101A





FIG.101A (1-B-2) GASKET SET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11401-31850	GASKET SET	1	OPT
2	11141-31J00	.GASKET,CYLINDER HEAD	2	NOT ILLUSTRATED
3	11173-02F00	.GASKET,CYL HEAD COVER NO.1	2	NOT ILLUSTRATED
4	11178-17E00	.GASKET,CYL HEAD COVER NO.2	2	NOT ILLUSTRATED
5	11182-35F10	.GASKET,2ND AIR PASSAGE	2	NOT ILLUSTRATED
6	11241-31J00	.GASKET,CYLINDER FRONT	1	NOT ILLUSTRATED
7	11242-06L00	.GASKET,CYLINDER REAR	1	NOT ILLUSTRATED
8	11482-06G10	.GASKET,CLUTCH COVER	1	NOT ILLUSTRATED
9	11483-02F10	.GASKET,MAGNETO COVER	1	NOT ILLUSTRATED
10	11485-02F10	.GASKET,GEAR SHIFT COVER	1	NOT ILLUSTRATED
11	12837-19B10	.GASKET,TENSIONER ADJUSTER	1	NOT ILLUSTRATED
12	12837-24A10	.GASKET,TENSIONER ADJUSTER	1	NOT ILLUSTRATED
13	14181-31D00	.GASKET,EXH PIPE	2	NOT ILLUSTRATED
14	17435-02F00	.O RING,WATER PUMP CASE	1	NOT ILLUSTRATED
15	09280-33004	.O-RING (D:3.1,ID:32.7)	1	NOT ILLUSTRATED

FIG.104A



FWD

FIG.104A (1-B-3) CYLINDER HEAD (FRONT) (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-31J20	HEAD ASSY,CYLINDER FRONT	1	
2	09206-08001	.PIN (6.2X8X11)	4	
3	09103-06266	.BOLT (6X40)	8	
4	11115-32E70	GUIDE,VALVE (OS:0.3)	4	
5	11141-31J00	GASKET,CYLINDER HEAD	1	
6	04211-13189	PIN	2	
7	09108-08143	BOLT,STUD (L:35)	1	
8	08316-1008B	NUT	1	
9	11117-33H00	BOLT,CYLINDER HEAD,L165 (10X17 5)	4	
10	09108-06096	BOLT,STUD (6X30)	2	
11	08316-1006B	NUT	2	
12	01550-0612B	BOLT	1	
13	09168-06023	GASKET (5.8X13X1.2)	1	
14	09103-06220	BOLT (6X60)	2	
15	09482-00635	PLUG,SPARK (LMAR8BI-9)	2	
16	13101-06L00	PIPE ASSY,INTAKE FRONT	1	
17	09280-55005	.O RING (D:2.4,ID:55.6)	1	
18	02122-0616B	SCREW	2	
19	13826-22H00	CLAMP	1	
20	11171-06L00	COVER,CYLINDER HEAD FRONT	1	
21	11173-02F00	GASKET,CYL HEAD COVER NO.1	1	
22	11178-17E00	GASKET,CYL HEAD COVER NO.2	1	
23	09106-07021	BOLT (7X17.5)	4	
24	11191-27E00	WASHER,CYL HEAD COVER (L:5.5)	4	
25	01550-1050A	BOLT	1	
26	01550-1070A	BOLT	1	
27	11134-31J10	COVER,CYL HEAD NO.2	1	
28	09106-06075	BOLT (6X12)	2	
29	09280-19005	O RING (D:2.4,ID:19)	1	
30	11182-35F10	GASKET,2ND AIR PASSAGE	1	
31	09206-10016	PIN (8.2X10X13)	1	

FIG.104B




FIG.104B (1-B-4) CYLINDER HEAD (FRONT) (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-31J20	HEAD ASSY,CYLINDER FRONT	1	
2	09206-08001	.PIN (6.2X8X11)	4	
3	09103-06266	.BOLT (6X40)	8	
4	11115-32E70	GUIDE,VALVE (OS:0.3)	4	
5	11141-31J00	GASKET,CYLINDER HEAD	1	
6	04211-13189	PIN	2	
7	09108-08143	BOLT,STUD (L:35)	1	
8	08316-1008B	NUT	1	
9	11117-33H00	BOLT,CYLINDER HEAD,L165 (10X17 5)	4	
10	09108-06096	BOLT,STUD (6X30)	2	
11	08316-1006B	NUT	2	
12	01550-0612B	BOLT	1	
13	09168-06023	GASKET (5.8X13X1.2)	1	
14	09103-06220	BOLT (6X60)	2	
15	09482-00635	PLUG,SPARK (LMAR8BI-9)	2	
16	13101-06L00	PIPE ASSY,INTAKE FRONT	1	
17	09280-55005	.O RING (D:2.4,ID:55.6)	1	
18	02122-0616B	SCREW	2	
19	13826-22H00	CLAMP	1	
20	11171-06L00	COVER,CYLINDER HEAD FRONT	1	
21	11173-02F00	GASKET,CYL HEAD COVER NO.1	1	
22	11178-17E00	GASKET,CYL HEAD COVER NO.2	1	
23	09106-07021	BOLT (7X17.5)	4	
24	11191-27E00	WASHER,CYL HEAD COVER (L:5.5)	4	
25	01550-1085B	BOLT,ENG MTG HEAD FRONT RH	1	
26	09103-10475	BOLT,ENG MTG HEAD FRONT LH	1	
27	11134-31J10	COVER,CYL HEAD NO.2	1	
28	09106-06075	BOLT (6X12)	2	
29	09280-19005	O RING (D:2.4,ID:19)	1	
30	11182-35F10	GASKET,2ND AIR PASSAGE	1	
31	09206-10016	PIN (8.2X10X13)	1	

FIG.105A




FIG.105A (1-B-5) CYLINDER HEAD (REAR)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-31J10	HEAD ASSY,CYLINDER FRONT	1	
2	09206-08001	.PIN (6.2X8X11)	4	
3	09103-06266	.BOLT (6X40)	8	
4	11115-32E70	GUIDE,VALVE (OS:0.3)	4	
5	11141-31J00	GASKET,CYLINDER HEAD	1	
6	04211-13189	PIN	2	
7	09108-08143	BOLT,STUD (L:35)	1	
8	08316-1008B	NUT	1	
9	11117-33H00	BOLT,CYLINDER HEAD,L165 (10X17 5)	4	
10	09103-06220	BOLT (6X60)	2	
11	09108-06096	BOLT,STUD (6X30)	2	
12	08316-1006B	NUT	2	
13	01550-0612B	BOLT	1	
14	09168-06023	GASKET (5.8X13X1.2)	1	
15	09482-00635	PLUG,SPARK (LMAR8BI-9)	2	
16	13102-06L00	PIPE ASSY,INTAKE REAR	1	
17	09280-55005	.O RING (D:2.4,ID:55.6)	1	
18	02122-0616B	SCREW	2	
19	13826-22H00	CLAMP	1	
20	11172-31J10	COVER,CYLINDER HEAD REAR	1	
21	11173-02F00	GASKET,CYL HEAD COVER NO.1	1	
22	11178-17E00	GASKET,CYL HEAD COVER NO.2	1	
23	09106-07021	BOLT (7X17.5)	4	
24	11191-27E00	WASHER,CYL HEAD COVER (L:5.5)	4	
25	11134-31J10	COVER,CYL HEAD NO.2	1	
26	09106-06075	BOLT (6X12)	2	
27	09280-19005	O RING (D:2.4,ID:19)	1	
28	11182-35F10	GASKET,2ND AIR PASSAGE	1	
29	09206-10016	PIN (8.2X10X13)	1	
30	11151-27G00	CAP,ENGINE MOUNTING	1	

DL1050RCM0_E21_105A
CYLNDER HEAD (REAR)






FIG.107A (1-B-6) CYLINDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11211-31J10-0F0	CYLINDER,FRONT	1	
2	11221-31J10-0F0	CYLINDER,REAR	1	
3	11241-31J00	GASKET,CYLINDER FRONT	1	
4	11242-06L00	GASKET,CYLINDER REAR	1	
5	04211-13189	PIN	4	
6	09108-06124	BOLT,STUD (L:20)	1	
7	01421-0620A	BOLT,STUD	5	
8	08316-1006B	NUT	6	

FIG.108A



VIEW B



VIEW A




FIG.108A (1-B-7) CRANKCASE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11306-06840	CRANKCASE SET	1	
2	11319-33E00	PIN,CRANKCASE	2	
3	09106-08142	BOLT (8X110)	2	
4	01547-0630A	BOLT	4	
5	01547-0670A	BOLT	7	
6	01547-0685A	BOLT	1	
7	07120-0890A	BOLT	4	
8	09106-08136	BOLT (8X125)	1	
9	08322-0108A	WASHER,LOCK	1	

FIG.109A




FIG.109A (1-B-8) CYLINDER HEAD (FRONT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	09493-28010	JET AIR (#14)	2	
2	09280-04004	O-RING (D:1.2,ID:4)	1	
3	09280-13007	O-RING (D:1.9,ID:12.5)	1	
4	09493-20014	JET, T/M OIL GALLERY	1	
5	09280-04004	O-RING (D:1.2,ID:4)	2	
6	09106-06075	BOLT (6X12)	2	
7	09280-05007	O-RING (D:1.2,ID:4.7)	2	
8	11390-06G10	JET,PISTON COOLING	2	
9	09168-08016	GASKET (8.2X14X1)	4	
10	01550-0812A	BOLT	4	
11	09168-16002	GASKET (16X22X2)	1	
12	09248-16012	PLUG (16X8)	1	
13	09168-14002	GASKET (13.8X18.8X4.8)	1	
14	09247-14036	PLUG (14X20)	1	
15	09103-12016	BOLT (L:300)	1	
16	09159-12056	NUT	1	
17	09103-10205	BOLT (10X225)	1	
18	09103-10226	BOLT (10X260)	1	
19	08319-3110A	NUT	1	
20	37820-33D10	SWITCH ASSY,OIL PRESSURE	1	
21	37822-33D00	.BOLT,OIL PRESSURE SWITCH	1	

FIG.112A




FIG.112A (1-B-9) CRANKCASE COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11340-06L00	COVER,CLUTCH	1	
2	11971-33210	.LENS,OIL LEVEL CHECK	1	
3	11482-06G10	GASKET,CLUTCH COVER	1	
4	04211-09149	PIN	2	
5	09103-06529	BOLT,CLUTCH COVER (6X30)	9	
6	09103-06538	BOLT,CLUTCH COVER (6X75)	2	
7	11342-06G00	SEPARATOR,OIL	1	
8	02112-0612A	SCREW	4	
9	01550-0610A	BOLT	1	
10	09168-06026	GASKET (6.4X11.5X0.8)	1	
11	11351-31J20	COVER,MAGNETO	1	
12	11483-02F10	GASKET,MAGNETO COVER	1	
13	04211-09149	PIN	1	
14	09103-06530	BOLT,CLUTCH COVER (L:35)	9	
15	09103-06539	BOLT,ENG SPROCKET COVER (6X80)	2	
16	09259-36021	PLUG (36X10)	1	
17	09280-33004	O-RING (D:3.1,ID:32.7)	1	
18	09248-14010	PLUG (L:12)	1	
19	09168-14002	GASKET (13.8X18.8X4.8)	1	
20	11360-31J00	COVER,ENG SPROCKET	1	
21	11362-31J00	.SHEET,SPROCKET COVER	1	
22	09103-06530	BOLT,CLUTCH COVER (L:35)	2	
23	09103-06535	BOLT,START IDLE GEAR CAP (6X60)	1	
24	11381-06G00	COVER,GEAR SHIFT	1	
25	11485-02F10	GASKET,GEAR SHIFT COVER	1	
26	09103-06314	BOLT (6X105)	1	
27	01547-0625A	BOLT	2	
28	01547-0635A	BOLT	2	
29	04211-09149	PIN	2	
30	11971-25D00	PLUG,ENGINE OIL FILLER	1	
31	09280-17003	O RING (D:3.1,ID:16.8)	1	
32	11383-06L00	PROTECTOR,CLUTCH COVER	1	
33	09139-05098	BOLT,CLUTCH COVER PROTECTOR	3	
34	09280-08012	O-RING (D:1.9,ID:7.8)	3	

FIG.120A




FIG.120A (1-B-10) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12220-31J00	CRANKSHAFT	1	
2-1	12229-31J00-0A0	BEARING,CRANKSHAFT	2	
2-2	12229-31J00-0B0	BEARING,CRANKSHAFT	2	
2-3	12229-31J00-0C0	BEARING,CRANKSHAFT	2	
2-4	12229-06L00-0A0	BEARING,CRANKSHAFT	2	
2-5	12229-06L00-0B0	BEARING,CRANKSHAFT	2	
2-6	12229-06L00-0C0	BEARING,CRANKSHAFT	2	
3	12652-38B00	WASHER,CRANK THRUST	1	
4	12160-06G10	CONNECTING ROD ASSY	2	
5	12163-06G00	.BOLT,CONNROD	4	
6	12165-27A50	.PIN,CONNROD	4	
7-1	12164-31J00-0A0	BEARING,CRANK PIN	4	
7-2	12164-31J00-0B0	BEARING,CRANK PIN	4	
7-3	12164-31J00-0C0	BEARING,CRANK PIN	4	
7-4	12164-31J00-0D0	BEARING,CRANK PIN	4	
8	12111-31J10-0F0	PISTON	2	
9	12140-31J00	RING SET,PISTON	2	
10	12151-02F10	PIN,PISTON	2	
11	09381-22002	CIRCLIP	4	
12	21111-02F11	GEAR,PRI DRIVE (NT:31)	1	
13	21112-02F00	GEAR,PRI DRIVE SCISSORS (NT:31)	1	
14	21114-02F00	WASHER,PRI DRIVE	1	
15	08331-31409	CIRCLIP	1	
16	09440-07001	SPRING	3	
17	09140-22012	NUT	1	
18	09164-22007	WASHER (22.2X35X2(3))	1	
19	09420-06001	KEY	1	

FIG.122A




FIG.122A (1-B-11) STARTER CLUTCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12612-06G00	GEAR,STARTER IDLE NO.2 (NT:27)	1	
2	09206-12002	PIN (7X12X50.5)	1	
3	09180-12140	SPACER (12.5X19X17.5)	1	
4	12600-06811	CLUTCH SET,STARTER (NT:72)	1	
5	09106-08106	BOLT (8X20)	6	
6	12600-06G01	LIMITER ASSY,START ID GR NO.1 (NT:44)	1	
7	12618-31G00	BUSH,LIMITER GEAR SHAFT	2	
8	09181-10195	SHIM (10X20X1)	2	

FIG.126A




FIG.126A (1-B-12) CAMSHAFT/VALVE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12701-06L00	CAMSHAFT ASSY,INTAKE FRONT	1	
2	12702-06L00	CAMSHAFT ASSY,EXHAUST FRONT	1	
3	12703-06L00	CAMSHAFT ASSY,INTAKE REAR	1	
4	12704-06L00	CAMSHAFT ASSY,EXHAUST REAR	1	
5	12911-16G00	VALVE,INTAKE	4	
6	12912-49XB0	VALVE,EXHAUST	4	
7	12921-06G00	SPRING,VALVE	8	
8	12931-06G00	RETAINER,VALVE SPRING	8	
9	12933-06G00	SEAT,VALVE SPRING	8	
10	09289-05015	OIL SEAL (5.5X11X8.2)	8	
11	12932-24400	COTTER,VALVE	16	
12	12891-02F10	TAPPET	8	
13-1	12892-41C00-230	SHIM,TAPPET (T:2.30)	8	
13-2	12892-41C00-235	SHIM,TAPPET (T:2.35)	8	
13-3	12892-41C00-240	SHIM,TAPPET (T:2.40)	8	
13-4	12892-41C00-245	SHIM,TAPPET (T:2.45)	8	
13-5	12892-41C00-250	SHIM,TAPPET (T:2.50)	8	
13-6	12892-41C00-255	SHIM,TAPPET (T:2.55)	8	
13-7	12892-41C00-260	SHIM,TAPPET (T:2.60)	8	
13-8	12892-41C00-265	SHIM,TAPPET (T:2.65)	8	
13-9	12892-41C00-270	SHIM,TAPPET (T:2.70)	8	
13-10	12892-41C00-275	SHIM,TAPPET (T:2.75)	8	
13-11	12892-41C00-280	SHIM,TAPPET (T:2.80)	8	
13-12	12892-41C00-285	SHIM,TAPPET (T:2.85)	8	
13-13	12892-41C00-290	SHIM,TAPPET (T:2.90)	8	
13-14	12892-41C00-295	SHIM,TAPPET (T:2.95)	8	
13-15	12892-41C00-300	SHIM,TAPPET (T:3.00)	8	
13-16	12892-41C00-305	SHIM,TAPPET (T:3.05)	8	
13-17	12892-41C00-310	SHIM,TAPPET (T:3.10)	8	
13-18	12892-41C00-315	SHIM,TAPPET (T:3.15)	8	
13-19	12892-41C00-320	SHIM,TAPPET (T:3.20)	8	
13-20	12892-41C00-325	SHIM,TAPPET (T:3.25)	8	
13-21	12892-41C00-330	SHIM,TAPPET (T:3.30)	8	
13-22	12892-41C00-335	SHIM,TAPPET (T:3.35)	8	
13-23	12892-41C00-340	SHIM,TAPPET (T:3.40)	8	




FIG.126A (1-B-13) CAMSHAFT/VALVE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
13-24	12892-41C00-345	SHIM,TAPPET (T:3.45)	8	
13-25	12892-41C00-350	SHIM,TAPPET (T:3.50)	8	
14	12800-41810	SHIM SET,TAPPET (5PCS.EACH)	1	OPT,NOT ILLUSTRATED
15	99000-69471	.CASE,TAPPET SHIM	1	OPT,NOT ILLUSTRATED

FIG.127A




FIG.127A (1-B-14) CAM CHAIN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12760-23F20	CHAIN,CAMSHAFT DRIVE	2	
2	12771-06G00	GUIDE,CAM CHAIN	2	
3	12810-06G00	TENSIONER,CAM CHAIN FR	1	
4	12815-06G00	TENSIONER,CAM CHAIN,REAR	1	
5	07120-0612A	BOLT	2	
6	12832-06L00	ADJUSTER ASSY,TENSIONER FRONT	1	
7	09168-12018	.GASKET (12X21X2)	1	
8	12830-30A01	ADJUSTER ASSY,TENSIONER	1	
9	12832-02A00	.O RING	1	
10	12833-30A01	.SPRING	1	
11	12834-02A00	.PLUG,ADJUSTER	1	
12	12837-19B10	GASKET,TENSIONER ADJUSTER	1	
13	12837-24A10	GASKET,TENSIONER ADJUSTER	1	
14	07130-0625A	BOLT	2	
15	07130-0620B	BOLT	2	
16	12750-31J10	GEAR,CAM CHAIN IDLER NO.2 (NT: 31/41)	2	
17	12755-31J00	SHAFT,IDLER NO.2	2	
18	09421-04004	KEY	1	
19	12716-06G00	SHAFT,IDLER	1	
20	09140-16001	NUT	1	
21	09181-16212	SHIM (16X26X1.5)	1	
22	08112-63030	BEARING	1	
23	09262-25006	BEARING (25X47X8)	1	
24	24741-20A00	RETAINER,COUNTER BEARING RH	1	
25	09126-06011	SCREW (6X12)	1	
26	12731-06G01	SPROCKET,IDLER NO.1 (NT:36)	1	

FIG.140A




FIG.140A (1-B-15) THROTTLE BODY

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13400-06L00	BODY ASSY,THROTTLE	2	
2	13601-11J00	.SCREW,DELIVERY PIPE	4	
3	13602-29G00	.PACKING	4	
4	15710-31J00	.INJECTOR ASSY	2	
5	15717-58B00	..O-RING	2	
6	15722-14J00	.SEAL	2	
7	15731-06L00	.DELIVERY PIPE	2	
8	13683-06L00	HOSE,VACUUM	1	
9	13683-06L10	HOSE,VACUUM	1	

FWD

FIG.155A




FIG.155A (1-B-16) AIR CLEANER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13700-06L00	CLEANER ASSY, AIR	1	
2	13881-06L00	.TUBE,OUTLET FR	1	
3	13741-31J00	.CAP, AIR CLEANER	1	
4	13891-31J00	.TUBE,INLET	1	
5	13780-31J00	.FILTER,AIR CLEANER	1	
6	13746-06L00	.GASKET,AIR CLEANER A	1	
7	13746-06L10	.GASKET,AIR CLEANER B	1	
8	13827-06L00	.CLAMP,OUTLET TUBE	2	
9	03541-0520A	.SCREW	6	
10	13878-10G00	.PLUG	1	
11	09401-14301	.CLIP	1	
12	13882-06L00	.TUBE,OUTLET RR	1	
13	13788-06L00	.FILTER,BRETHER	1	
14	18590-18K00	SENSOR,AIR PRESSURE	2	
15	03541-0520A	SCREW	2	
16	13650-41F10	SENSOR,AIR TEMP	1	
17	13655-41F10	.O-RING	1	
18	03511-0516A	SCREW	1	
19	13738-31J00	SHEET,AIR CLEANER INLET	1	
20	13850-31J00	TUBE,BREATHER	1	
21	09401-22405	CLIP	2	

DL1050RCM0_E21_155A
AIR CLEANER

FIG.163A




FIG.163A (1-C-2) MUFFLER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	14150-06L00	PIPE,EXH RR	1	
2	14160-06L00	PIPE,EXH FR	1	
3	14181-31D00	GASKET,EXH PIPE	2	
4	09106-08178	BOLT (8X25)	2	
5	07130-0825A	BOLT	2	
6	14205-06L00	PIPE,EXH CTR	1	
7	14771-42F50	CONNECTOR,JT	2	
8	09106-08197	BOLT (8X35)	2	
9	09180-08152	SPACER (8.6X12X24.2)	2	
10	09320-12077	CUSHION	2	
11	09116-08176	BOLT,EXH CTR SPRT	2	
12	14310-06L00-H01	BODY,MUFFLER (BLACK,MAROON,SILVER)	1	
13	14459-31J10	CLAMP,MUF CONN	1	
14	09106-08162	BOLT (8X40)	1	
15	14771-18H00	CONNECTOR,MUF	1	
16	09106-08195	BOLT (8X45)	1	
17	09180-08156	SPACER (8.6X12X25.5)	1	
18	09320-12049	CUSHION	1	
19	09160-08162	WASHER (8.5X33X1.6)	1	
20	08316-1008B	NUT	1	
21	14760-06L00	COVER,MUF FR	1	
22	14762-06L00	.SHIELD,MUF COV FR HEAT NO.1	1	
23	14780-06L00	COVER,MUF	1	
24	09320-08066	.CUSHION	1	
25	14784-06L00	.SHIELD,MUF COV HEAT	1	
26	14785-06L00	.SHIELD,MUF COV HEAT NO.2	1	
27	09139-06128	SCREW (6X12)	2	
28	09320-08066	CUSHION	1	
29	14791-06L00	COVER,MUF RR	1	
30	09106-06078	BOLT (6X15)	3	
31	09160-06055	WASHER (7X12X1.0)	3	
32	14795-10FA0	GROMMET	2	
33	09320-04013	CUSHION,MUF COV	1	
34	09321-10018	CUSHION	2	

FIG.163A




FIG.163A (1-C-3) MUFFLER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	18213-04K00	SENSOR,OXYGEN	1	

DL1050RCM0_E21_163A
MUFFLER

FIG.170A





FIG.170A (1-C-4) OIL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	16400-02FB0	PUMP ASSY,ENG OIL	1	
2	07130-0625A	BOLT	3	
3	16331-02F00	GEAR,OIL PUMP DRIVEN (NT:29)	1	
4	09181-10158	SHIM (10X18X0.5)	1	
5	09261-04009	PIN (4X15.8)	1	
6	08331-31109	CIRCLIP	1	
7	16440-24F00	VALVE ASSY,OIL RELIEF (7K)	1	
8	09280-13004	.O RING (D:1.9,ID:13)	1	
9	16520-32E00	STRAINER,ENG OIL	1	
10	16321-02F00	GEAR,ENG OIL PUMP DRIVE (NT:41)	1	
11	09261-06002	PIN (OD:6,L:6)	1	
12	08331-31509	CIRCLIP	1	

FIG.172A



DL1050RCM0_E21_172A
FUELPUMP

FIG.172A (1-C-5) FUEL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-28K00	PUMP ASSY,FUEL	1	
2	15113-05H00	.O-RING	1	
3	15113-17K00	.O-RING	1	
4	15113-35F00	.O-RING	1	
5	15114-17K00	.WIRE,EARTH	1	
6	15115-17K00	.WIRE,LEAD	1	
7	15116-17K00	.COLLAR	1	
8	15310-17K00	.FILTER	1	
9	15420-17K00	.STRAINER	1	
10	15610-17K00	.REGULATOR	1	
11	15113-48H00	..O-RING	1	
12	15201-07L00	O-RING,FUEL PUMP	1	
13	15122-17K00	PLATE,FUEL PUMP INNER	1	
14	15121-28K00	PLATE,FUEL PUMP OUTER	1	
15	07120-0616A	BOLT	5	
16	15810-06L00	HOSE,FUEL	1	
17	34810-06L00	GAUGE ASSY,FUEL LEVEL SENDER	1	
18	34815-06L00	ATTACHMENT,FUEL LEVEL GAUGE	1	

FIG.178A




FIG.178A (1-C-6) OIL COOLER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	16510-07J00	FILTER ASSY,ENGINE OIL (P1.0)	1	
2	16591-06L00	BOLT,OIL COOLER UNION	1	
3	16600-06L00	COOLER ASSY,OIL	1	
4	09181-21002	SHIM (21X31X0.8)	1	
5	09280-60005	O RING (D:2.4,ID:60.5)	1	
6	16461-06L00	HOSE,OIL COOLER WATER INLET	1	
7	16471-06L00	HOSE,OIL COOLER WATER OUTLET	1	
8	09401-16407	CLIP (ID:16.5)	4	

FIG.180A




FIG.180A (1-C-7) WATER PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-06L00	CASE,WATER PUMP	1	
2	17491-16G00	IMPELLER,WATER PUMP	1	
3	17470-02F11	SEAL,MECHANICAL	1	
4	09283-10005	OIL SEAL (10X20X5)	1	
5	17435-02F00	O RING,WATER PUMP CASE	1	
6	09262-10016	BEARING (10X22X5)	2	
7	08332-1108A	E RING	1	
8	09103-06529	BOLT,CLUTCH COVER (6X30)	2	
9	09103-06536	BOLT,MAGNETO COVER (6X65)	3	
10	04211-09149	PIN	1	
11	09352-42704-140	HOSE	1	
12	09404-06429	CLAMP (L:45)	1	

FIG.185A




FIG.185A (1-C-8) RADIATOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17710-06L00	RADIATOR,WATER	1	
2	17800-06L00	FAN ASSY,RADIATOR	1	
3	09320-10051	CUSHION	3	
4	09180-06290	SPACER (6.5X10X12)	3	
5	09118-06097	BOLT (6X25)	3	
6	17711-07L00	BOLT,RADIATOR FAN	3	
7	17802-14F00	NUT,RADIATOR FAN	3	
8	09329-18001	CUSHION	2	
9	17730-08D10	CAP,RADIATOR (1.1)	1	

FIG.187A




FIG.187A (1-C-9) RADIATOR HOSE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17851-06L00	HOSE,RADIATOR INLET	1	
2	17852-06L00	HOSE,RADIATOR OUTLET	1	
3	17853-02F10	HOSE,CONNECTOR INLET	2	
4	17890-06G20	UNION,CONNECTOR HOSE	2	
5	09280-18008	O-RING (D:3.2,ID:17.8)	2	
6	07130-0612A	BOLT	2	
7	17910-31J00	TANK ASSY,RESERVOIR	1	
8	17931-31J00	.CAP,WATER RESERVOIR TANK	1	
9	09111-06085	BOLT (6X12)	1	
10	17982-31J00	HOSE,RSVR TANK OVFL	1	
11	17900-27810	HOSE SET,RSVR TANK INLET	1	
12	09401-24002	CLAMP,WATER HOSE	2	
13	09401-08411	CLIP (ID:8.6)	2	
14	09401-25001	CLAMP,WATER HOSE	2	
15	17662-02F11	CONNECTOR,THERMOSTAT,INLET	1	
16	17663-42E00	CAP,THERMOSTAT CONNECTOR	1	
17	01550-0616A	BOLT	2	
18	17670-06G51	THERMOSTAT,WATER	1	
19	17856-16G10	HOSE,WATER BYPASS	1	
20	09401-29001	CLAMP,WATER HOSE	4	
21	09401-12414	CLAMP	2	
22	13650-49X00	SENSOR,TEMP	1	
23	09168-12017	GASKET (12X17X1)	1	
24	17920-31J00	BRACKET,RSVR TANK	1	
25	01550-0610A	BOLT	2	

FIG.189A




FIG.189A (1-C-10) 2ND AIR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13150-28H10	VALVE ASSY,OIL REED	2	
2	18461-06L00	HOSE,2ND AIR VALVE FR	1	
3	18471-06L00	HOSE,2ND AIR VALVE RR	1	
4	18510-29G31	VALVE ASSY,AIR CUT	1	
5	18531-06G01	COVER,2ND AIR	2	
6	18711-06L00	HOSE,2ND AIR CLNR	1	
7	09401-18101	CLIP	3	
8	09401-15101	CLIP (ID:15.5)	2	
9	09401-17201	CLIP	1	
10	01547-0620A	BOLT	4	

FIG.201A




FIG.201A (1-C-11) CLUTCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21200-31Y20	GEAR ASSY, PRIMARY DRIVEN	1	
2	09160-25074	WASHER (25X52X2.5)	1	
3	09263-35013	BEARING (35X40X39.8)	1	
4	21411-31J10	HUB,CLUTCH SLEEVE	1	
5	21412-31J00	BOLT,CLUTCH SPRING	3	
6	21413-31J00	SPRING,CLUTCH	3	
7	21414-31J00	PLATE,STOPPER	1	
8	21441-31J00	PLATE,CLUTCH DRIVE NO.1 (T:3.8)	6	
9	21442-31J00	PLATE,CLUTCH DRIVE NO.2 (T:3.8)	3	
10	21451-24F00	PLATE,CLUTCH DRIVEN (T:2.0)	5	
11	21452-31J00	PLATE,CLUTCH DRIVEN NO.2 (T:2. 0)	1	
12	21462-31J10	DISC,CLUTCH PRESSURE	1	
13	21471-24F00	SEAT,WAVE WASHER	1	
14	21472-24F00	WASHER,CLUTCH PLATE WAVE	1	
15	09159-24010	NUT	1	
16	09160-25056	WASHER (25X50X2.5)	1	
17	09164-24008	WASHER (24.2X35X2.7)	1	
18	09181-25223	SHIM (25X38X1)	1	
19	23110-27A00	ROD,CLUTCH (L:161)	1	
20	23111-26D00	ROD,CLUTCH PUSH LH (L:132.5)	1	
21	23121-31E00	PIECE,CLUTCH PUSH	1	
22	23160-06G20	CYLINDER,CLUTCH RELEASE	1	
23	23163-06B00	.CUP	1	
24	23164-05A00	.SPRING	1	
25	59121-01A00	.BLEEDER	1	
26	59122-46H00	.CAP,BLEEDER	1	
27	23166-06G10	COVER,DUST	1	
28	04221-08149	PIN	1	
29	07130-0665B	BOLT	1	
30	07130-0670B	BOLT	1	
31	09160-15045	WASHER (15.5X28X1)	1	
32	23171-06G00	SPACER,CL RLSE CYL	1	

FIG.201A




FIG.201A (1-C-12) CLUTCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	09263-15003	BEARING (15X28X2)	1	
34	09283-06008	OIL SEAL (6X34X10.5)	1	
35	21415-31J00	SEAT,CLUTCH SPRING	3	

FIG.206A




FIG.206A (1-C-13) TRANSMISSION

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	24120-06G00	SHAFT,COUNTER (NT:12)	1	
2	24221-02F01	GEAR,2ND DRIVE (NT:15)	1	
3	24231-02F30	GEAR,3RD & 4TH DRIVE (NT:18/22)	1	
4	24251-02F11	GEAR,5TH DRIVE (NT:23)	1	
5	24252-02F10	BUSH,5TH DRIVE GEAR	1	
6	24261-02F20	GEAR,6TH DRIVE (NT:24)	1	
7	24262-02F00	BUSH,6TH DRIVE GEAR	1	
8	09181-22167	SHIM (22X30X1)	1	
9	09262-20139	BEARING (20X47X14)	1	
10	09262-25073	BEARING (25X62X17)	1	
11	09280-17004	O RING (D:1.9,ID:16.6)	1	
12	09380-27001	CIRCLIP	1	
13	24130-02F30	SHAFT,DRIVE	1	
14	24311-06G00	GEAR,1ST DRIVEN (NT:36)	1	
15	09263-22068	BEARING (22X26X11)	1	
16	24321-02F11	GEAR,2ND DRIVEN (NT:29)	1	
17	24322-02F01	BUSH,2ND DRIVEN GEAR	1	
18	24331-02F20	GEAR,3RD DRIVEN (NT:27)	1	
19	24332-17E20	BUSH,3RD DRIVEN GEAR	1	
20	24341-02F30	GEAR,4TH DRIVEN	1	
21	24332-17E20	BUSH,3RD DRIVEN GEAR	1	
22	24351-02F20	GEAR,5TH DRIVEN (NT:25)	1	
23	24361-02F30	GEAR,6TH DRIVEN (NT:24)	1	
24	09160-27008	WASHER (27X36X1)	1	
25	24333-02F00	WASHER,3RD & 4TH DRIVEN	1	
26	24333-02F00	WASHER,3RD & 4TH DRIVEN	1	
27	24333-02F10	WASHER,3RD & 4TH DRIVEN GEAR	1	
28	09181-20251	SHIM (20X34X1)	1	
29	09181-22223	SHIM (22X34X1)	1	
30	09262-20082	BEARING (20X52X15)	1	
31	09262-28053	BEARING (28X68X18)	1	
32	09283-38028	OIL SEAL (38X52X8)	1	
33	09380-27001	CIRCLIP	1	
34	09380-27001	CIRCLIP	1	

FIG.206A




FIG.206A (1-C-14) TRANSMISSION

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	09380-27001	CIRCLIP	1	
36	24741-06G00	RETAINER,DRIVE SHAFT BRG	1	
37	24741-21A00	RETAINER	1	
38	24751-06G00	RETAINER,DRIVE SHAFT OIL SEAL	1	
39	09126-06011	SCREW (6X12)	2	
40	02112-0612A	SCREW	1	
41	07130-0612A	BOLT	2	
42	27511-20A20	SPROCKET,ENGINE (NT:17)	1	
43	27531-31J00	SPACER,ENGINE SPROCKET	1	
44	27600-06G40-120	CHAIN ASSY,DRIVE (RK525SMOZ8)	1	
45	27620-06G40	.JOINT SET,DRIVE CHAIN	1	
46	09159-20004	NUT	1	
47	09160-25009	WASHER (25X41X3)	1	
48	09280-24010	O RING (D:2.4,ID:23.7)	1	

FIG.212A




FIG.212A (1-C-15) GEAR SHIFTING

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	25211-17E02	FORK,GEAR SHIFT	2	
2	25231-35F00	FORK,GEAR SHIFT,NO.3	1	
3	25411-02F20	SHIFT,GEAR SHIFT FORK	1	
4	25411-02F20	SHIFT,GEAR SHIFT FORK	1	
5	24741-21A00	RETAINER	2	
6	25310-31J00	CAM,GEAR SHIFT	1	
7	04221-04089	.PIN	1	
8	25312-42F01	BOLT,GEAR SHIFT CAM PLATE	1	
9	25381-13E30	PLATE,GEAR SHIFT CAM	1	
10	09125-06122	SCREW (6X12)	2	
11	08113-69050	BEARING	1	
12	25350-06G00	STOPPER,SHIFT CAM	1	
13	25355-38F00	SPRING,GEAR SHIFT CAM STOPPER	1	
14	09111-06041	BOLT (6X14.3)	1	
15	08211-06141	WASHER	1	
16	25510-06G10	SHAFT,GEAR SHUFT	1	
17	25512-06G20	PLATE,GEAR SHIFT CAM DRIVE	1	
18	25671-01011	STOPPER,GEAR SHIFT ARM	1	
19	09181-14167	SHIM (14X22X1.0)	3	
20	09283-14005	OIL SEAL (14X22X7.3)	1	
21	09440-17013	SPRING	1	
22	25518-06L00	SPRING,GEAR SHIFT SHAFT RETURN	1	
23	08331-3114A	CIRCLIP	2	
24	25520-16G30	ARM,GEAR SHIFT LINK	1	
25	25526-47000	.COVER,DUST	1	
26	25525-11C00	ROD,GEAR SHIFT LINK (L:90)	1	
27	25600-31J10	LEVER ASSY,GEAR SHIFT	1	
28	25526-47000	.COVER,DUST	1	
29	25652-20C00	.RUBBER,GEAR SHIFT PEDAL	1	
30	25617-03F10	SHAFT,GEAR SHIFT LEVER	1	
31	09140-06025	NUT	1	
32	09160-12011	WASHER (12.5X20X1)	1	
33	01547-0625B	BOLT	1	
34	08310-0006A	NUT	1	
35	08331-3112A	CIRCLIP	1	

FIG.212A




FIG.212A (1-C-16) GEAR SHIFTING

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
36	37730-31J10	SENSOR ASSY,GEAR POSITION	1	
37	31497-45000	CLAMP, POSITION SENSOR LEAD	1	
38	07130-0510A	BOLT	1	
39	09106-05023	BOLT (5X16)	2	

FIG.301A




FIG.301A (1-D-2) STARTING MOTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-06L00	MOTOR ASSY,STARTING	1	
2	31132-45C00	.HOLDER SET,BRUSH	1	
3	31143-38300	.O-RING	1	
4	31150-07F10	.HOUSING ASSY	1	
5	31170-06L00	.FRAME	1	
6	31170-43400	.SHIM SET	1	
7	31172-38300	.BUSHING	1	
8	31173-88C00	.BUSHING	1	
9	31264-44110	.O-RING	2	
10	31281-24B10	.BOLT	2	
11	31156-48B00	.O RING (D:2.1,ID;34.7)	1	
12	08310-00067	.NUT	1	
13	08361-35068	.NUT	1	
14	01547-0625B	BOLT	2	
15	08361-3506A	NUT	1	




FIG.303A (1-D-3) MAGNETO

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32101-06L00	STATOR ASSY,MAGNETO	1	
2	32102-06L00	ROTOR ASSY,MAGNETO	1	
3	32371-13E30	CLAMP,GENERATOR LEAD WIRE	1	
4	09103-14001	BOLT (14X43)	1	
5	09420-04008	KEY (B:4,D:16,H6.5)	1	
6	07130-0512A	BOLT	3	
7	09106-06120	BOLT (6X40)	3	

FIG.310A




FIG.310A (1-D-4) BATTERY

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33620-31J01	BATTERY ASSY (FTZ14S,12V/11.2A H)	1	
2	33652-16G00	PROTECTOR,BATTERY	1	
3	33652-06L10	CUSHION,BATTERY RH	1	
4	33652-06L00	CUSHION,BATTERY LH	1	
5	33652-06L20	CUSHION,BATTERY	1	
6	33652-06L30	CUSHION,BATTERY	1	
7	33652-28C00	PROTECTOR (40X85X3)	1	
8	33652-36000	CUSHION (30X50X3)	1	
9	51553-15D40	CUSHION (50X42X2.0)	2	
10	33810-06L00	WIRE,STARTER MOTOR LEAD	1	
11	33860-06L00	WIRE,BATTERY MINUS LEAD	1	
12	36651-48E00	CLAMP (L:63)	1	

FIG.312A




FIG.312A (1-D-5) ELECTRICAL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31800-06G01	RELAY ASSY,STARTING MOTOR	1	
2	31861-47E00	.COVER	1	
3	09481-30101	.FUSE (30A)	2	
4	44552-24B00	MOLDING,FUEL TANK,REAR	1	
5	09128-06013	SCREW (6X8)	2	
6	32800-31J00	RECTIFIER ASSY	1	
7	08319-3106A	NUT	2	
8	45517-16G20	TAPE (30X40X0.2)	1	
9	09106-06088	BOLT (6X35)	6	
10	09106-06120	BOLT (6X40)	2	
11	09159-06096	NUT	8	
12	33410-06G01	COIL ASSY,IGNITION	1	
13	33410-06L00	COIL ASSY,IGNITION REAR	1	
14	33410-20H01	COIL ASSY,IGNITION	1	
15	33410-26G01	COIL ASSY,IGNITION	1	
16	13412-06L00	SHIELD,IGNITION COIL	1	
17	09180-06195	SPACER (6.4X10X18)	4	
18	09180-06198	SPACER (6.2X12X16)	4	
19	09180-06255	SPACER (6.5X9X3.8)	2	
20	09408-00235	CLAMP	1	
21	33510-31G00	CAP ASSY,SPARK PLUG	2	
22	33510-31G10	CAP ASSY,SPARK PLUG	2	
23	33542-06G00	SEAL,HT CORD RR	1	
24	33542-06G10	SEAL,HT CORD FR	1	
25	33542-38B00	SEAL,HIGH TENSION CORD (SIDE)	2	
26	32910-06L00	HARDWARE,FI CONTROL UNIT	1	
27	33960-25H00	SENSOR ASSY,FUEL CUT	1	
28	33651-37000	PROTECTOR (170X95X3.0)	2	
29	33652-36000	CUSHION (30X50X3)	1	




FIG.330A (1-D-6) SPEEDOMETER (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34100-06L00	SPEEDOMETER ASSY	1	
2	34111-17K00	.CASE ASSY,LOWER	1	
3	34150-06L00	.CASE ASSY,UPPER	1	
4	34183-10C00	.NEEDLE,JET	8	
5	34189-08J01	CUSHION,SPEEDOMETER	3	
6	09160-04026	WASHER (4.5X16X1.2)	1	
7	03541-0416A	SCREW	1	
8	#95643-58J00	SENSOR,AIR TEMP	1	




FIG.330D (1-D-7) SPEEDOMETER (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34100-06LA0	SPEEDOMETER ASSY	1	
2	34111-17K00	.CASE ASSY,LOWER	1	
3	34150-06LA0	.CASE ASSY,UPPER	1	
4	34183-10C00	.NEEDLE,JET	8	
5	34189-08J01	CUSHION,SPEEDOMETER	3	
6	09160-04026	WASHER (4.5X16X1.2)	1	
7	03541-0416A	SCREW	1	
8	#95643-58J00	SENSOR,AIR TEMP	1	

FIG.333A




FIG.333A (1-D-8) HEADLAMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	35100-07L10	HEADLAMP ASSY	1	
2	35529-77R00	.CAP	1	
3	09320-10043	CUSHION (10X20X10)	1	
4	09139-06231	BOLT,HEADLAMP	1	
5	09139-06232	BOLT,HEADLAMP	2	
6	09320-09501	CUSHION (9X18X10)	2	

FIG.334A




FIG.334A (1-D-9) TURNSIGNAL LAMP (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	35601-08JA0	LAMP ASSY,FRONT TURNSIGNAL RH	1	
2	35612-08JA0	.LENS,RH	1	
3	03211-0414B	.SCREW	1	
4	09471-12186	.BULB (12V21W)	1	AMBER
5	35602-08JA0	LAMP ASSY,FRONT TURNSIGNAL LH	1	
6	35632-08JA0	.LENS,LH	1	
7	03211-0414B	.SCREW	1	
8	09471-12186	.BULB (12V21W)	1	AMBER
9	35629-31F40	PLATE,TURNSIGNAL	2	
10	08316-1005A	NUT	2	
11	09404-06429	CLAMP (L:45)	2	
12	35603-08JA0	LAMP ASSY,RR TURNSIGNAL RH	1	
13	35632-08JA0	.LENS,LH	1	
14	03211-0414B	.SCREW	1	
15	09471-12186	.BULB (12V21W)	1	AMBER
16	35604-08JA0	LAMP ASSY,RR TURNSIGNAL LH	1	
17	35612-08JA0	.LENS,RH	1	
18	03211-0414B	.SCREW	1	
19	09471-12186	.BULB (12V21W)	1	AMBER
20	35629-31F40	PLATE,TURNSIGNAL	2	
21	08316-1005A	NUT	2	
22	09404-06429	CLAMP (L:45)	2	
23	38610-06F01	RELAY ASSY,TURNSIGNAL LAMP	1	

FIG.334B




FIG.334B (1-D-10) TURNSIGNAL LAMP (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	35601-06L00	LAMP ASSY,FR TURNSIGNAL RH	1	
2	35690-06L00	CUSHION,TURNSIGNAL	1	
3	09169-06073	WASHER (6.1X17.0X4.8)	1	
4	09404-06429	CLAMP (L:45)	1	
5	08316-1006A	NUT	1	
6	35602-06L00	LAMP ASSY,FR TURNSIGNAL LH	1	
7	35690-06L00	CUSHION,TURNSIGNAL	1	
8	09169-06073	WASHER (6.1X17.0X4.8)	1	
9	09404-06429	CLAMP (L:45)	1	
10	08316-1006A	NUT	1	
11	35603-06L00	LAMP ASSY,RR TURNSIGNAL RH	1	
12	35690-06L00	CUSHION,TURNSIGNAL	1	
13	09169-06073	WASHER (6.1X17.0X4.8)	1	
14	09404-06429	CLAMP (L:45)	1	
15	08316-1006A	NUT	1	
16	35604-06L00	LAMP ASSY,RR TURNSIGNAL LH	1	
17	35690-06L00	CUSHION,TURNSIGNAL	1	
18	09169-06073	WASHER (6.1X17.0X4.8)	1	
19	09404-06429	CLAMP (L:45)	1	
20	08316-1006A	NUT	1	
21	38610-06L00	RELAY ASSY,TURNSIGNAL	1	

FIG.339A




FIG.339A (1-D-11) REAR COMBINATION LAMP (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	35710-31J01	LAMP ASSY,RR COMB	1	
2	09160-05501	WASHER (5.5X20X1.2)	3	
3	03541-0516A	SCREW	3	
4	35910-41GB2	LAMP ASSY,LICENSE	1	
5	35912-41G01	.LENS,LICENSE	1	
6	35913-41G00	.GASKET	1	
7	09471-12140	.BULB (12V5W,BF150-40160A)	1	
8	35917-41G00	.COVER,LICENSE LAMP	1	
9	03211-0416A	.SCREW	2	
10	09180-06263	SPACER (6.5X9X9)	2	
11	09159-06096	NUT	2	

FIG.339B




FIG.339B (1-D-12) REAR COMBINATION LAMP (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	35710-31JA0	LAMP ASSY,REAR COMB	1	
2	09160-05501	WASHER (5.5X20X1.2)	3	
3	03541-0516A	SCREW	3	
4	35910-41GB2	LAMP ASSY,LICENSE	1	
5	35912-41G01	.LENS,LICENSE	1	
6	35913-41G00	.GASKET	1	
7	09471-12140	.BULB (12V5W,BF150-40160A)	1	
8	35917-41G00	.COVER,LICENSE LAMP	1	
9	03211-0416A	.SCREW	2	
10	09180-06263	SPACER (6.5X9X9)	2	
11	09159-06096	NUT	2	

FIG.350A




FIG.350A (1-D-13) WIRING HARNESS (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36610-06L00	HARNESS,WIRING	1	
2	09481-03501	.FUSE (3A)	1	
3	09481-10504	.FUSE (10A)	5	
4	09481-15504	.FUSE (15A)	3	
5	09481-25504	.FUSE (25A)	1	
6	36620-06L00	HARNESS,WIRING NO.2	1	
7	36654-28K00	CAP,OBD CONNECTOR	1	
8	36856-06L00	WIRE,REAR TURNSIGNAL LEAD	1	
9	09404-06429	CLAMP (L:45)	2	
10	09403-10319	CLAMP	1	
11	09407-14407	CLAMP (L:145)	9	
12	09407-19401	CLAMP (L:190)	2	
13	37740-06L00	SWITCH ASSY,STOP LAMP	1	
14	43259-31J00	SPRING,STOP LAMP SWITCH	1	
15	43251-31J00	BRACKET,STOP LAMP SWITCH	1	
16	01550-0612A	BOLT	1	
17	37840-24F01	SWITCH ASSY, SIDE STAND	1	
18	09103-08357	BOLT (8X35)	1	
19	38500-06L00	HORN ASSY	1	
20	38850-31J00	TERMINAL,POWER SOURCE	1	
21	39105-06L00	SOCKET,USB	1	
22	36744-06L00	HOLDER,RELAY	1	
23	38860-06L00	RELAY ASSY	1	

FIG.350B




FIG.350B (1-D-14) WIRING HARNESS (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36610-06LA0	HARNESS,WIRING	1	
2	09481-03501	.FUSE (3A)	1	
3	09481-10504	.FUSE (10A)	6	
4	09481-15504	.FUSE (15A)	2	
5	09481-25504	.FUSE (25A)	1	
6	36620-06LA0	HARNESS,WIRING NO.2	1	
7	36654-28K00	CAP,OBD CONNECTOR	1	
8	36856-06LA0	WIRE,REAR TURNSIGNAL LEAD	1	
9	09404-06429	CLAMP (L:45)	2	
10	09403-10319	CLAMP	1	
11	09407-14407	CLAMP (L:145)	9	
12	09407-19401	CLAMP (L:190)	2	
13	37740-06L00	SWITCH ASSY,STOP LAMP	1	
14	43259-31J00	SPRING,STOP LAMP SWITCH	1	
15	43251-31J00	BRACKET,STOP LAMP SWITCH	1	
16	01550-0612A	BOLT	1	
17	37840-24F01	SWITCH ASSY, SIDE STAND	1	
18	09103-08357	BOLT (8X35)	1	
19	38500-06L00	HORN ASSY	1	
20	39105-06L00	SOCKET,USB	1	
21	36744-06L00	HOLDER,RELAY	1	
22	38860-06L00	RELAY ASSY	1	

FIG.352A




FIG.352A (1-D-15) LOCK SET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37101-06810	LOCK SET	1	
2	37100-06L00	.LOCK ASSY,STEERING	1	
3	37152-17K00	BOLT,STEERING LOCK (8X20)	2	
4	37180-06L00	ANTENNA ASSY,IMMOBILIZER	1	
5	01547-0512B	BOLT	2	
6	37146-13K00	KEY,BLANK	1	OPT

DL1050RCM0_E21_352A
LOCK SET

FIG.352B




FIG.352B (1-D-16) LOCK SET (SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37101-06820	LOCK SET	1	
2	37100-06L00	.LOCK ASSY,STEERING	1	
3	37152-17K00	BOLT,STEERING LOCK (8X20)	2	
4	37180-06L00	ANTENNA ASSY,IMMOBILIZER	1	
5	01547-0512B	BOLT	2	
6	95700-31870	LOCK SET,CASE	3	
7	37146-13K00	KEY,BLANK	1	OPT

NOTE 1:
FOR TOP CASE, SIDE CASE

FIG.355A (1-E-2) HANDLE SWITCH (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37400-06L00	SWITCH ASSY,HANDLE LH	1	
2	36990-06L00	CLAMP,HANDLE SWITCH	3	





FIG.355B (1-E-3) HANDLE SWITCH (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37400-06L10	SWITCH ASSY,HANDLE LH	1	
2	36990-06L00	CLAMP,HANDLE SWITCH	3	






FIG.401A (1-E-4) FRAME

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41100-31J20-YAP	FRAME (BLACK)	1	
2	41200-31J30-YAP	RAIL,SEAT (BLACK)	1	
3	09139-10006	BOLT,SEAT RAIL	4	
4	43580-31J00	COVER,PIVOT RH	1	
5	33652-38A10	.PROTECTOR (20X90X2)	1	
6	63115-37H00	.CUSHION,RR COVER NO.2 (10X10X1)	1	
7	94429-21E00	.CUSHION,PIVOT COVER NO.2	1	
8	43590-31J00	COVER,PIVOT LH	1	
9	33652-38A10	.PROTECTOR (20X90X2)	1	
10	63115-37H00	.CUSHION,RR COVER NO.2 (10X10X1)	1	
11	94429-21E00	.CUSHION,PIVOT COVER NO.2	1	
12	09139-05092	SCREW (5X13)	4	
13	41922-19F20	NUT,CRANK CASE ADJUST CTR	1	
14	41921-16G00	BOLT,CASE LWR & RR HEAD ADJ	1	
15	41922-33E20	NUT,CRANK CASE ADJUST LWR	1	
16	41941-19F01	SPACER,MOUNTING REAR UPPER RH	1	
17	41921-47H00	BOLT,CRANK CASE ADJUST	1	
18	41942-02F00	SPACER,ENG HEAD MTG,RR LH	1	
19	07130-0840B	BOLT	1	
20	07130-0840B	BOLT	1	

FIG.406A




FIG.406A (1-E-5) HOLDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	47414-06L00	HOLDER,BATTERY	1	
2	47415-06L00	HOLDER,ELECTRIC PARTS	1	
3	47416-06L00	BOLT,BATTERY HOLDER	4	
4	47431-06L00	LID,BATTERY HOLDER	1	
5	61544-94500	PAD,OIL FILLER LID	1	CUT AS REQUIRED
6	47912-31J00	SCREW (5X13)	2	
7	09148-06018	NUT	2	
8	09409-06314	CLIP (5.9X20.5)	1	
9	03541-0512B	SCREW	1	
10	03541-0516A	SCREW	3	
11	47410-06L00	BRACKET,RECTIFIER	1	
12	48128-14FA0	CUSHION (10X24X1)	2	
13	01421-0616A	BOLT,STUD	1	
14	01421-0625B	BOLT,STUD	1	
15	08316-1006A	NUT	2	
16	47420-06L00	BRACKET,IGNITION COIL RH	1	
17	01550-0620A	BOLT	2	
18	47420-06L10	BRACKET,IGNITION COIL LH	1	
19	01550-0620A	BOLT	2	
20	01550-0620B	BOLT	1	

FIG.407A




FIG.407A (1-E-6) STAND (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	42310-31J01	STAND,PROP	1	
2	09111-10058	BOLT (10X37.5)	1	
3	42321-03FK0	NUT,PROP STAND	1	
4	09443-14058	SPRING	1	
5	09443-19011	SPRING	1	
6	42330-06L00	BRACKET,PROP STAND	1	
7	01550-1235B	BOLT,PROP STAND BRACKET	2	
8	43111-06L00	PEDAL,BRAKE	1	
9	09160-18022	WASHER (18X24X1.0)	1	
10	09448-41006	SPRING,BRAKE PEDAL	1	
11	08331-3118A	CIRCLIP	1	
12	42100-31J10	STAND,CENTER	1	
13	42241-31J00	SPRING,CENTER STAND	2	
14	42253-31J10	SPACER,CENTER STAND RH	1	
15	42254-31J10	SPACER,CENTER STAND LH	1	
16	42260-06L00	PLATE,CENTER STAND RH	1	
17	42270-31J10	PLATE,CENTER STAND LH	1	
18	42290-31J00	PLATE,CENTER STAND	1	
19	01550-1035B	BOLT	3	
20	01550-1045B	BOLT	3	
21	09321-10046	CUSHION,CENTER STAND	1	

FIG.407B




FIG.407B (1-E-7) STAND (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	42310-31J01	STAND,PROP	1	
2	09111-10058	BOLT (10X37.5)	1	
3	42321-03FK0	NUT,PROP STAND	1	
4	09443-14058	SPRING	1	
5	09443-19011	SPRING	1	
6	42330-31J00	BRACKET,PROP STAND	1	
7	01550-1235B	BOLT,PROP STAND BRACKET	2	
8	43111-06L00	PEDAL,BRAKE	1	
9	09160-18022	WASHER (18X24X1.0)	1	
10	09448-41006	SPRING,BRAKE PEDAL	1	
11	08331-3118A	CIRCLIP	1	

FIG.412A

FIG.412A (1-E-8) CARRIER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	46311-31J11	CARRIER,SPORT	1	
2	09103-08568	BOLT,SPORT CARRIER	4	
3	09169-08053	WASHER,SPORT CARRIER	4	




FIG.415A




FIG.415A (1-E-9) FOOTREST

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	43510-06G01-YAP	BRACKET,FR FOOTREST RH (BLACK)	1	
2	43521-06G01-YAP	BRACKET,FR FOOTREST LH (BLACK)	1	
3	09106-08200	BOLT,FR FOOTREST BRKT (8X23)	4	
4	43501-06L00	FOOTREST ASSY,FRONT RH	1	
5	43576-48B40	.BOLT,BANK SENSOR	1	
6	43551-06L00	.RUBBER,FR FOOTREST	1	
7	43552-06L00	.PLATE,FR FOOTREST RUBBER	1	
8	43530-06L00	.BAR,FRONT FOOTREST RH	1	
9	47512-28K00	.SPACER,FR FOOTREST RUBBER	2	
10	07120-0512A	.BOLT	2	
11	43502-06L00	FOOTREST ASSY,FRONT LH	1	
12	43576-48B40	.BOLT,BANK SENSOR	1	
13	43551-06L00	.RUBBER,FR FOOTREST	1	
14	43552-06L00	.PLATE,FR FOOTREST RUBBER	1	
15	43540-06L00	.BAR,FRONT FOOTREST LH	1	
16	47512-28K00	.SPACER,FR FOOTREST RUBBER	2	
17	07120-0512A	.BOLT	2	
18	09208-08023	PIN,FRONT FOOTREST	2	
19	09448-18037	SPRING,FRONT FOOTREST	2	
20	08332-1106B	E RING	2	
21	43610-34A60	BAR,PILLION FOOTREST RH	1	
22	43612-33G30	RUBBER,PILLION FOOTREST	2	
23	43631-34A01	WASHER,FOOTREST RUBBER	2	
24	43710-34A60	BAR,PILLION FOOTREST LH	1	
25	43811-31J00-YAP	BRKT,PILLION FOOTREST RH (BLACK)	1	
26	43821-31J00-YAP	BRKT,PILLION FOOTREST LH (BLACK)	1	
27	09106-08131	BOLT (8X30)	4	
28	09208-06010	PIN,PILLION FOOTREST	2	
29	08332-1104B	E RING	2	

FIG.420A




FIG.420A (1-E-10) FUEL TANK (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44100-06L00-YVB	TANK ASSY,FUEL (BLACK)	1	
2	44121-06L00	VESSEL,FUEL TANK INNER	1	
3	44200-17840	CAP SET,FUEL TANK FILLER	1	
4	44244-11J00	BOLT,FUEL TANK FILLER CAP	3	
5	44276-21H00	CUSHION,FUEL TANK COVER	2	
6	44530-06G00	BRACKET,FUEL TANK REAR UP	1	
7	44541-31J00	CUSHION,FUEL TANK SIDE	2	
8	44542-06G00	CUSHION,FUEL TANK REAR UPPER	1	
9	44545-06G00	CUSHION,FUEL TANK REAR LOWER	1	
10	44545-06L00	CUSHION,FUEL TANK RR	1	
11	44550-31J00	BRACKET,FUEL TANK REAR	1	
12	44552-24B00	MOLDING,FUEL TANK,REAR	2	
13	01550-0816A	BOLT	2	
14	01550-0835A	BOLT	1	
15	44179-06L00	BRKT,FUEL TANK COVER SIDE RH	1	
16	44183-23H00	CUSHION,TANK SIDE COVER	2	
17	44189-06L00	BRKT,FUEL TANK COVER SIDE LH	1	
18	44523-47H00	NUT (M6)	4	
19	44542-31J00	CUSHION,FUEL TANK COVER BRKT	2	
20	44556-33H10	CUSHION,TANK COVER BRKT NO.1	4	
21	44572-02F01	FASTENER (25X33X0.8)	4	
22	47163-10FA0	CUSHION,SIDE COVER BRACKET (15 X23X4)	4	
23	09103-06285	BOLT (6X12)	4	
24	44423-31J12	HOSE,FUEL TANK DRAIN NO.2	1	
25	44423-31J21	HOSE,FUEL TANK DRAIN NO.1	1	
26	44480-31J00	GUIDE,DRAIN HOSE	1	
27	09367-08005	3 WAY	1	
28	07130-1016B	BOLT	2	

FIG.420B




FIG.420B (1-E-11) FUEL TANK (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	44100-06L10-YU1	TANK ASSY,FUEL (YELLOW)	1	BODY COLOR:YU1
1-2	44100-06L10-YVB	TANK ASSY,FUEL (BLACK)	1	BODY COLOR:YVB
1-3	44100-06L10-YUH	TANK ASSY,FUEL (WHITE)	1	BODY COLOR:B1F
2-1	68110-06L00-B4J	.TAPE SET,FUEL TANK	1	BODY COLOR:YU1
2-2	68110-06L00-AA3	.TAPE SET,FUEL TANK (GRAY,BLAC K)	1	BODY COLOR:YVB
2-3	68110-06L00-B1G	.TAPE SET,FUEL TANK	1	BODY COLOR:B1F
3	44121-06L00	VESSEL,FUEL TANK INNER	1	
4	44200-17840	CAP SET,FUEL TANK FILLER	1	
5	44244-11J00	BOLT,FUEL TANK FILLER CAP	3	
6	44276-21H00	CUSHION,FUEL TANK COVER	2	
7	44530-06G00	BRACKET,FUEL TANK REAR UP	1	
8	44541-31J00	CUSHION,FUEL TANK SIDE	2	
9	44542-06G00	CUSHION,FUEL TANK REAR UPPER	1	
10	44545-06G00	CUSHION,FUEL TANK REAR LOWER	1	
11	44545-06L00	CUSHION,FUEL TANK RR	1	
12	44550-31J00	BRACKET,FUEL TANK REAR	1	
13	44552-24B00	MOLDING,FUEL TANK,REAR	2	
14	01550-0816A	BOLT	2	
15	01550-0835A	BOLT	1	
16	44179-06L00	BRKT,FUEL TANK COVER SIDE RH	1	
17	44183-23H00	CUSHION,TANK SIDE COVER	2	
18	44189-06L00	BRKT,FUEL TANK COVER SIDE LH	1	
19	44523-47H00	NUT (M6)	4	
20	44542-31J00	CUSHION,FUEL TANK COVER BRKT	2	
21	44556-33H10	CUSHION,TANK COVER BRKT NO.1	4	
22	44572-02F01	FASTENER (25X33X0.8)	4	
23	47163-10FA0	CUSHION,SIDE COVER BRACKET (15 X23X4)	4	
24	09103-06285	BOLT (6X12)	4	
25	44423-31J12	HOSE,FUEL TANK DRAIN NO.2	1	
26	44423-31J21	HOSE,FUEL TANK DRAIN NO.1	1	
27	09367-08005	3 WAY	1	




FIG.423A (1-E-12) FUEL TANK COVER (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44277-06L00	CUSHION,FUEL TANK COVER CTR	2	
2	44291-06L00-YKV	COVER,FUEL TANK CTR (BLACK)	1	
3	44295-07L01	RUBBER,FUEL TANK COVER	1	
4	44292-06L00	CUSHION,FUEL TANK REAR	1	
5	68281-47HA0	EMBLEM,S	1	
6	94642-10GA0	CUSHION,WINDSCREEN COVER (15X15X2)	2	
7	09139-06172	SCREW (6X10)	1	
8	09139-06229	SCREW (6X13)	2	
9	44271-06L00	SHEET,HEAT SHIELD RUBBER	1	




FIG.423B (1-E-13) FUEL TANK COVER (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44277-06L00	CUSHION,FUEL TANK COVER CTR	2	
2-1	44291-06L00-YUA	COVER,FUEL TANK CTR (BLUE)	1	BODY COLOR:YU1
2-2	44291-06L00-YKV	COVER,FUEL TANK CTR (BLACK)	1	BODY COLOR:YVB,B1F
3	44295-07L01	RUBBER,FUEL TANK COVER	1	
4	44292-06L00	CUSHION,FUEL TANK REAR	1	
5	68281-47HA0	EMBLEM,S	1	
6	94642-10GA0	CUSHION,WINDSCREEN COVER (15X15X2)	2	
7	09139-06172	SCREW (6X10)	1	
8	09139-06229	SCREW (6X13)	2	
9	44271-06L00	SHEET,HEAT SHIELD RUBBER	1	

FIG.427A




FIG.427A (1-E-14) EVAP SYSTEM

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13685-06L00	JOINT,3 WAY	1	
2	18114-74P00	VALVE,CANISTER PURGE	1	
3	18560-04K01	CANISTER ASSY,CHARCOAL	1	
4	18561-06L00	HOSE,CSTR PURGE NO.1	1	
5	18561-06L10	HOSE,CSTR PURGE NO.2	1	
6	18562-06L00	HOSE,CSTR PURGE NO.3	2	
7	18563-06L10	HOSE,CSTR SURGE NO.2	1	
8	18563-06L20	HOSE,CSTR SURGE NO.1	1	
9	18572-06L00	BRACKET,CANISTER NO.1	1	
10	18572-13K00	CUSHION, CANISTER	1	
11	18573-06L00	BRACKET,CANISTER NO.2	1	
12	18575-06L00	BRACKET,PURGE VALVE	1	
13	18576-06L00	COVER,CANISTER	1	
14	09160-06125	WASHER (6.5X14X1.6)	1	
15	09160-06151	WASHER (6.5X18X1)	2	
16	09160-08114	WASHER (8.5X18X1.6)	2	
17	09320-06016	CUSHION (6.5X14X6)	1	
18	09320-08051	CUSHION (8.4X18X6)	2	
19	09367-06009	JOINT	1	
20	09401-06101	CLIP (ID:6.5)	4	
21	09401-10401	CLIP	1	
22	09401-10409	CLIP (ID:10.5)	2	
23	09401-11413	CLIP (ID:11)	3	
24	07130-0620A	BOLT	1	
25	07130-0660B	BOLT	2	
26	08316-1006A	NUT	1	

FIG.433A




FIG.433A (1-E-15) SIDE COVER (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44572-13G10	FASTENER,RR COMB (33X25)	4	
2-1	94420-06L00-YU1	COVER,SIDE RH (YELLOW)	1	BODY COLOR:YU1
2-2	94420-06L00-YVB	COVER,SIDE RH (BLACK)	1	BODY COLOR:YVB
2-3	94420-06L00-QRE	COVER,SIDE RH (ORANGE)	1	BODY COLOR:B1F
3-1	68271-06L00-B4K	.EMBLEM,SIDE COVER RH	1	BODY COLOR:YU1
3-2	68271-06L00-B4L	.EMBLEM,SIDE COVER RH	1	BODY COLOR:YVB
3-3	68271-06L00-B4M	.EMBLEM,SIDE COVER RH	1	BODY COLOR:B1F
4-1	68275-06L00-B4K	.TAPE,COVER SIDE RH	1	BODY COLOR:YU1
4-2	68275-06L00-B4L	.TAPE,COVER SIDE RH	1	BODY COLOR:YVB
4-3	68275-06L00-B4M	.TAPE,COVER SIDE RH	1	BODY COLOR:B1F
5	94425-06L00	CUSHION,SIDE COVER NO.1	2	
6	94426-06L00	CUSHION,SIDE COVER NO.2	2	
7-1	94430-06L00-YU1	COVER,SIDE LH (YELLOW)	1	BODY COLOR:YU1
7-2	94430-06L00-YVB	COVER,SIDE LH (BLACK)	1	BODY COLOR:YVB
7-3	94430-06L00-QRE	COVER,SIDE LH (ORANGE)	1	BODY COLOR:B1F
8-1	68281-06L00-B4K	.EMBLEM,SIDE COVER LH	1	BODY COLOR:YU1
8-2	68281-06L00-B4L	.EMBLEM,SIDE COVER LH	1	BODY COLOR:YVB
8-3	68281-06L00-B4M	.EMBLEM,SIDE COVER LH	1	BODY COLOR:B1F
9-1	68285-06L00-B4K	.TAPE,COVER SIDE	1	BODY COLOR:YU1
9-2	68285-06L00-B4L	.TAPE,COVER SIDE	1	BODY COLOR:YVB
9-3	68285-06L00-B4M	.TAPE,COVER SIDE	1	BODY COLOR:B1F
10	94441-06L00	COVER,SIDE NO.2 RH	1	
11	94451-06L00	COVER,SIDE NO.2 LH	1	
12	94463-06L00	COVER,SIDE INNER LWR RH	1	
13	94464-06L00	COVER,SIDE INNER LWR LH	1	
14	94471-06L00	COVER,SIDE INNER UPR RH	1	
15	94481-06L00	COVER,SIDE INNER UPR LH	1	
16	09139-05091	SCREW (5X13)	4	
17	09139-06172	SCREW (6X10)	2	
18	09409-06314	CLIP (5.9X20.5)	4	
19	09409-07333	CLIP (D:2.4,ID:23.7)	2	
20	03541-0512B	SCREW	12	

FIG.433B




FIG.433B (1-E-16) SIDE COVER (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44572-13G10	FASTENER,RR COMB (33X25)	4	
2-1	94420-06L10-YVB	COVER,SIDE RH (BLACK)	1	BODY COLOR:YVB
2-2	94420-06L10-YUH	COVER,SIDE RH (WHITE)	1	BODY COLOR:B1G
2-3	94420-06L10-YUD	COVER,SIDE RH (GRAY)	1	BODY COLOR:BTH
3-1	68181-06L00-BD7	.EMBLEM,"SUZUKI" RH (GRAY,BLACK)	1	BODY COLOR:YVB
3-2	68181-06L00-B1G	.EMBLEM,"SUZUKI" RH	1	BODY COLOR:B1G
3-3	68181-06L00-BTH	.EMBLEM,"SUZUKI" RH (BLACK,GRAY)	1	BODY COLOR:BTH
4-1	68271-06L10-B4H	.EMBLEM,SIDE COVER RH	1	BODY COLOR:YVB
4-2	68271-06L10-B4G	.EMBLEM,SIDE COVER RH	1	BODY COLOR:B1G
4-3	68271-06L10-B4F	.EMBLEM,SIDE COVER RH	1	BODY COLOR:BTH
5	94425-06L00	CUSHION,SIDE COVER NO.1	2	
6	94426-06L00	CUSHION,SIDE COVER NO.2	2	
7-1	94430-06L10-YVB	COVER,SIDE LH (BLACK)	1	BODY COLOR:YVB
7-2	94430-06L10-YUH	COVER,SIDE LH (WHITE)	1	BODY COLOR:B1G
7-3	94430-06L10-YUD	COVER,SIDE LH (GRAY)	1	BODY COLOR:BTH
8-1	68191-06L00-BD7	.EMBLEM,"SUZUKI" LH (GRAY,BLACK)	1	BODY COLOR:YVB
8-2	68191-06L00-B1G	.EMBLEM,"SUZUKI" LH	1	BODY COLOR:B1G
8-3	68191-06L00-BTH	.EMBLEM,"SUZUKI" LH (BLACK,GRAY)	1	BODY COLOR:BTH
9-1	68281-06L10-B4H	.EMBLEM,SIDE COVER LH	1	BODY COLOR:YVB
9-2	68281-06L10-B4G	.EMBLEM,SIDE COVER LH	1	BODY COLOR:B1G
9-3	68281-06L10-B4F	.EMBLEM,SIDE COVER LH	1	BODY COLOR:BTH
10	94441-06L00	COVER,SIDE NO.2 RH	1	
11	94451-06L00	COVER,SIDE NO.2 LH	1	
12	94463-06L00	COVER,SIDE INNER LWR RH	1	
13	94464-06L00	COVER,SIDE INNER LWR LH	1	
14	94471-06L00	COVER,SIDE INNER UPR RH	1	
15	94481-06L00	COVER,SIDE INNER UPR LH	1	
16	09139-05091	SCREW (5X13)	4	
17	09139-06172	SCREW (6X10)	2	
18	09409-06314	CLIP (5.9X20.5)	4	
19	09409-07333	CLIP (D:2.4,ID:23.7)	2	

FIG.433B (1-F-2) SIDE COVER (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	03541-0512B	SCREW	12	




FIG.444A




FIG.444A (1-F-3) FRONT BRACKET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	09118-06112	BOLT (6X30)	3	
2	09180-06264	SPACER (6.5X9X10.5)	2	
3	44511-16G00	CUSHION,FUEL TANK,FR	3	
4	44512-16G00	SPACER,FUEL TANK,FR	3	
5	44520-31J01	BRACKET,FUEL TANK FRONT	1	
6	44543-31J01	CUSHION,FRONT SIDE BRKT	2	
7	44560-31J00	BRACKET,FRONT SIDE	2	
8	44561-35F00	SPACER,FUEL TANK	1	
9	01550-0616A	BOLT	1	
10	01550-0695A	BOLT	1	
11	08319-3106A	NUT	1	
12	44160-06L00	BRACKET,FRONT COVER	1	
13	44164-31J01	CUSHION,FUEL TANK COVER BRKT	2	
14	44542-06L00	CUSHION,FR COVER BRKT	1	
15	09116-06009	BOLT (6X20)	2	
16	68241-04X50-300	MOLDING (L:300)	2	CUT AS REQUIRED

FIG.445A




FIG.445A (1-F-4) FRAME COVER (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44173-14J00	CUSHION,FUEL TANK COVER SIDE	2	
2	45148-27J00	CUSHION, SEAT MOUNT	2	
3-1	47111-06L00-YU1	COVER,FRAME FRONT RH (YELLOW)	1	BODY COLOR:YU1
3-2	47111-06L10	COVER,FRAME FRONT RH	1	BODY COLOR:YVB
3-3	47111-06L00-YUH	COVER,FRAME FRONT RH (WHITE)	1	BODY COLOR:B1F
4	47121-06L00	PROTECTOR,FRAME COVER RH	1	BODY COLOR:YU1,B1F
5	47131-06L00	CUSHION,FRAME COVER FR RR	2	
6-1	47211-06L00-YU1	COVER,FRAME FRONT LH (YELLOW)	1	BODY COLOR:YU1
6-2	47211-06L10	COVER,FRAME FRONT LH	1	BODY COLOR:YVB
6-3	47211-06L00-YUH	COVER,FRAME FRONT LH (WHITE)	1	BODY COLOR:B1F
7	47221-06L00	PROTECTOR,FRAME COVER LH	1	BODY COLOR:YU1,B1F
8-1	47310-06L00-YU1	COVER,FRAME RH (YELLOW)	1	BODY COLOR:YU1
8-2	47310-06L00-YVB	COVER,FRAME RH (BLACK)	1	BODY COLOR:YVB
8-3	47310-06L00-QRE	COVER,FRAME RH (ORANGE)	1	BODY COLOR:B1F
9-1	68135-06L00-B4K	.TAPE,FRAME COVER RH	1	BODY COLOR:YU1
9-2	68135-06L00-B4L	.TAPE,FRAME COVER RH	1	BODY COLOR:YVB
9-3	68135-06L00-B4M	.TAPE,FRAME COVER RH	1	BODY COLOR:B1F
10	47312-06L00	CUSHION,FRAME COVER SIDE NO.5	2	
11-1	47350-06L00-YU1	COVER,FRAME LH (YELLOW)	1	BODY COLOR:YU1
11-2	47350-06L00-YVB	COVER,FRAME LH (BLACK)	1	BODY COLOR:YVB
11-3	47350-06L00-QRE	COVER,FRAME LH (ORANGE)	1	BODY COLOR:B1F
12-1	68145-06L00-B4K	.TAPE,FRAME COVER LH	1	BODY COLOR:YU1
12-2	68145-06L00-B4L	.TAPE,FRAME COVER LH	1	BODY COLOR:YVB
12-3	68145-06L00-B4M	.TAPE,FRAME COVER LH	1	BODY COLOR:B1F
13	47510-06L00	BRKT,SIDE CASE UPR RH	1	
14	47811-06L00	.BUSH,SIDE CASE BRKT FR RH	1	
15	47911-06L00	.BUSH,SIDE CASE BRKT RR RH	1	
16	47510-28K00	SPACER,FRAME COVER	2	
17	47610-06L00	BRKT,SIDE CASE UPR LH	1	
18	47812-06L00	.BUSH,SIDE CASE BRKT FR LH	1	
19	47912-06L00	.BUSH,SIDE CASE BRKT RR LH	1	
20-1	47711-06L00-YU1	COVER,FRAME CTR (YELLOW)	1	BODY COLOR:YU1
20-2	47711-06L00-YVB	COVER,FRAME CTR (BLACK)	1	BODY COLOR:YVB
20-3	47711-06L00-QRE	COVER,FRAME CTR (ORANGE)	1	BODY COLOR:B1F
21	47913-06L00	SCREW	10	

FIG.445A




FIG.445A (1-F-5) FRAME COVER (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	94415-40F00	TAPE,ABS UNIT HOLDER	2	
23	94417-24F00	CUSHION,FRAME COVER	2	
24	94479-35F00	CLIP	1	
25	09139-05091	SCREW (5X13)	2	
26	09139-05091	SCREW (5X13)	4	
27	09139-06169	SCREW (6X16)	1	
28	09148-05052	NUT (M5)	2	
29	09320-08029	CUSHION	2	
30	09320-20010	CUSHION (20X32X9)	2	

FIG.445B




FIG.445B (1-F-6) FRAME COVER (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44173-14J00	CUSHION,FUEL TANK COVER SIDE	2	
2	45148-27J00	CUSHION, SEAT MOUNT	2	
3	47111-06L10	COVER,FRAME FRONT RH	1	
4	47131-06L00	CUSHION,FRAME COVER FR RR	2	
5	47211-06L10	COVER,FRAME FRONT LH	1	
6-1	47310-06L10-B4X	COVER,FRAME RH (BLACK)	1	BODY COLOR:YVB
6-2	47310-06L10-5NX	COVER,FRAME RH (BLACK)	1	BODY COLOR:B1G
6-3	47310-06L10-YGS	COVER,FRAME RH (BLACK)	1	BODY COLOR:BTH
7-1	68135-06L10-B4Q	.TAPE,FRAME COVER RH	1	BODY COLOR:YVB
7-2	68135-06L10-B4P	.TAPE,FRAME COVER RH	1	BODY COLOR:B1G
7-3	68135-06L10-B4N	.TAPE,FRAME COVER RH	1	BODY COLOR:BTH
8	47312-06L00	CUSHION,FRAME COVER SIDE NO.5	2	
9-1	47350-06L10-B4X	COVER,FRAME LH (BLACK)	1	BODY COLOR:YVB
9-2	47350-06L10-5NX	COVER,FRAME LH (BLACK)	1	BODY COLOR:B1G
9-3	47350-06L10-YGS	COVER,FRAME LH (BLACK)	1	BODY COLOR:BTH
10-1	68145-06L10-B4Q	.TAPE,FRAME COVER LH	1	BODY COLOR:YVB
10-2	68145-06L10-B4P	.TAPE,FRAME COVER LH	1	BODY COLOR:B1G
10-3	68145-06L10-B4N	.TAPE,FRAME COVER LH	1	BODY COLOR:BTH
11	47510-28K00	SPACER,FRAME COVER	2	
12	47511-06L10	COVER,FRAME REAR RH	1	
13	47611-06L10	COVER,FRAME REAR LH	1	
14	47711-06L10-YGS	COVER,FRAME CENTER (BLACK)	1	
15	47913-06L00	SCREW	8	
16	94415-40F00	TAPE,ABS UNIT HOLDER	2	
17	94417-24F00	CUSHION,FRAME COVER	2	
18	94479-35F00	CLIP	1	
19	09139-05091	SCREW (5X13)	2	
20	09139-05091	SCREW (5X13)	4	
21	09139-06169	SCREW (6X16)	1	
22	09148-05052	NUT (M5)	2	
23	09320-08029	CUSHION	2	
24	09320-20010	CUSHION (20X32X9)	2	

FIG.454A




FIG.454A (1-F-7) WINDSCREEN (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44885-44AA0	CUSHION	1	
2	48411-06L00	WINDSCREEN	1	
3	48416-06L00	CUSHION,WINDSCREEN NO.3	3	
4	09139-06206	SCREW,UNDER COWL (6X20)	4	
5	09320-09016	CUSHION (9X18X9.5)	4	
6	44294-43H00	CUSHION,FUEL TANK COVER	2	
7	48412-06L00	COVER,WINDSCREEN	1	
8	48413-06L00	COVER,LOCK WINDSCREEN	1	
9	09409-06329	CLIP	4	
10	47161-26J00	CUSHION,FRAME COVER	2	
11	48421-06L00	BRACE,WINDSCREEN RH	1	
12	48422-06L00	SLIDER,WINDSCREEN FR RH	1	
13	48423-06L00	SLIDER,WINDSCREEN REAR RH	1	
14	48431-06L00	BRACE,WINDSCREEN LH	1	
15	48432-06L00	SLIDER,WINDSCREEN FR LH	1	
16	48433-06L00	SLIDER,WINDSCREEN REAR LH	1	
17	48441-06L00	ROD,WINDSCREEN BRACE	1	
18	48442-06L00	BOLT,WINDSCREEN BRACE ROD	2	
19	48451-06L00	BRACKET,WINDSCREEN FRONT	2	
20	48452-06L00	NUT,WINDSCREEN	4	
21	48454-06L00	O-RING,WINDSCREEN	4	
22	48461-06L00	BRACKET,WINDSCREEN REAR	2	
23	09106-08167	BOLT (8X20)	4	
24	09409-06329	CLIP	2	
25	48453-06L00	NUT,WINDSCREEN	1	
26	48462-06L00	STOPPER,LOCK SCREEN UPR NO.1	1	
27	48463-06L00	STOPPER,LOCK SCREEN UPR NO.2	1	
28	48464-06L00	STOPPER,LOCK SCREEN LWR	1	
29	48465-06L00	SLIDER,LOCK SCREEN	1	
30	48466-06L00	CUSHION,LOCK SCREEN	1	
31	48467-06L00	SLINDER,LOCK SCREEN LWR	1	
32	48471-06L00	BOLT,WINDSCREEN CTR	1	
33	48472-06L00	LEVER,WINDSCREEN	1	
34	48473-06L00	HINGE,WINDSCREEN LEVER	1	
35	48474-06L00	SPRING,WINDSCREEN	1	

FIG.454A




FIG.454A (1-F-8) WINDSCREEN (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
36	48475-06L00	PLATE,WINDSCREEN	2	
37	09106-06090	BOLT (6X25)	1	
38	09159-05045	NUT	2	
39	02142-0520A	SCREW	2	
40	03541-0512A	SCREW	2	
41	08322-0105A	WASHER	2	

FIG.454B




FIG.454B (1-F-9) WINDSCREEN (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	47122-17K00	CUSHION (8X50X8)	1	
2	48411-06L00	WINDSCREEN	1	
3	48415-06L00	SCREW,WINDSCREEN	4	
4	09320-09016	CUSHION (9X18X9.5)	4	
5	44294-43H00	CUSHION,FUEL TANK COVER	2	
6	48412-06L10	COVER,WINDSCREEN	1	
7	48413-06L10	COVER,LOCK WINDSCREEN	1	
8	09409-06329	CLIP	4	
9	03541-0512A	SCREW	2	
10	47161-26J00	CUSHION,FRAME COVER	2	
11	48421-06L10	BRACE,WINDSCREEN RH	1	
12	48422-06L00	SLIDER,WINDSCREEN FR RH	1	
13	48423-06L10	SLIDER,WINDSCREEN RR RH	1	
14	48431-06L10	BRACE,WINDSCREEN LH	1	
15	48432-06L00	SLIDER,WINDSCREEN FR LH	1	
16	48433-06L10	SLIDER,WINDSCREEN RR LH	1	
17	48441-06L00	ROD,WINDSCREEN BRACE	1	
18	48442-06L00	BOLT,WINDSCREEN BRACE ROD	2	
19	48452-06L00	NUT,WINDSCREEN	4	
20	09106-08167	BOLT (8X20)	4	
21	09169-07007	WASHER	4	
22	09409-06329	CLIP	2	

FIG.460A

FIG.460A (1-F-10) FRONT FENDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	53110-31J00	FENDER,FRONT	1	
2	47915-31J00	SCREW (6X16)	4	
3	35950-13K01	REFLEX REFLECTOR ASSY,FR SIDE	2	
4	09119-06109	BOLT	2	
5	09160-08043	WASHER (8.5X18X1)	2	




FIG.462E




FIG.462E (1-F-11) HANDLEBAR (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	56111-06L00	HANDLEBAR	1	
2	56270-04F20	BALANCER ASSY,HANDLEBAR	2	
3	56500-04F30	MIRROR ASSY,RR VIEW RH	1	
4	56600-04F30	MIRROR ASSY,RR VIEW LH	1	

FIG.462F




FIG.462F (1-F-12) HANDLEBAR (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	56111-06L00	HANDLEBAR	1	
2	56270-04FA0	BALANCER ASSY,HANDLEBAR	2	
3	56500-06L00	MIRROR ASSY,REAR VIEW RH	1	
4	56600-06L00	MIRROR ASSY,REAR VIEW LH	1	

FIG.467A




FIG.467A (1-F-13) HANDLE LEVER (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57100-06L00	GRIP ASSY,THROTTLE	1	
2	57110-06L00	.GRIP,THROTTLE	1	
3	57300-10G40	LEVER ASSY,FRONT BRAKE	1	
4	57431-17H02	.BOLT,LEVER PIVOT	1	
5	08319-2106A	.NUT	1	
6	57460-14J01	SWITCH ASSY,FRONT BRAKE	1	
7	57465-17C00	.SCREW	1	
8	57211-21H01	GRIP LH	1	
9	57500-24F40	LEVER ASSY, CLUTCH	1	
10	57431-17H02	.BOLT,LEVER PIVOT	1	
11	08316-1606B	.NUT	1	
12	57560-02FA0	SWITCH ASSY,CLUTCH	1	

FIG.467B




FIG.467B (1-F-14) HANDLE LEVER (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57100-06L10	GRIP ASSY,THROTTLE	1	
2	57110-06L00	.GRIP,THROTTLE	1	
3	57300-10G32	LEVER ASSY,FR BRAKE	1	
4	57431-17H02	.BOLT,LEVER PIVOT	1	
5	08319-2106A	.NUT	1	
6	57460-14J01	SWITCH ASSY,FRONT BRAKE	1	
7	57465-17C00	.SCREW	1	
8	57211-21H01	GRIP LH	1	
9	57500-24F22	LEVER ASSY,CLUTCH	1	
10	57431-17H02	.BOLT,LEVER PIVOT	1	
11	08316-1606B	.NUT	1	
12	57560-02FA0	SWITCH ASSY,CLUTCH	1	

FIG.472A




FIG.472A (1-F-15) KNUCKLE COVER (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57341-06L00	COVER,KNUCKLE RH	1	
2	57342-06L00	BRACKET,KNUCKLE COVER RH	1	
3	57541-06L00	COVER,KNUCKLE LH	1	
4	57542-06L00	BRACKET,KNUCKLE COVER LH	1	
5	09139-05092	SCREW (5X13)	4	
6	09148-05052	NUT (M5)	4	
7	09321-06026	CUSHION	1	
8	09321-06033	CUSHION	1	

FIG.474A




FIG.474A (1-F-16) REAR FENDER (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33652-20C00	PROTECTOR (50X50X5)	2	CUT AS REQUIRED
2	36920-37H00	PROTECTOR,WIRING HARNESS (10X25X0.13)	2	
3	44281-18K01	CUSHION,FUEL TANK COVER	1	
4	47912-31J00	SCREW (5X13)	3	
5	63111-06L00	FENDER,REAR FRONT	1	
6	63112-06L00	FENDER,REAR REAR	1	
7	63411-06L00	MUDGUARD,REAR FENDER	1	
8	09116-06165	BOLT (6X16)	2	
9	09148-05052	NUT (M5)	2	
10	09321-06026	CUSHION	1	
11	03541-0616B	SCREW	4	
12	08322-0106B	WASHER	2	
13	09811-00173	TOOL BAG	1	
14	09813-00030	SPANNER,OPEN (10X12)	1	
15	09813-00031	OPEN SPANNER (14X17)	1	
16	09814-00015	DRIVER,	1	
17	09814-00016	GRIP,DRIVER	1	
18	09816-00059	SPANNER,HEXAGON (5)	1	
19	09816-00103	SPANNER,HEXAGON (4)	1	

FIG.474B




FIG.474B (1-G-2) REAR FENDER (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33652-20C00	PROTECTOR (50X50X5)	2	CUT AS REQUIRED
2	36920-37H00	PROTECTOR,WIRING HARNESS (10X25X0.13)	2	
3	44281-18K01	CUSHION,FUEL TANK COVER	1	
4	47912-31J00	SCREW (5X13)	3	
5	63111-06L00	FENDER,REAR FRONT	1	
6	63112-06L10	FENDER,REAR REAR	1	
7	63411-06L00	MUDGUARD,REAR FENDER	1	
8	09116-06165	BOLT (6X16)	2	
9	09148-05052	NUT (M5)	2	
10	09321-06026	CUSHION	1	
11	03541-0616B	SCREW	4	
12	08322-0106B	WASHER	2	
13	09811-00173	TOOL BAG	1	
14	09813-00030	SPANNER,OPEN (10X12)	1	
15	09813-00031	OPEN SPANNER (14X17)	1	
16	09814-00015	DRIVER,	1	
17	09814-00016	GRIP,DRIVER	1	
18	09816-00059	SPANNER,HEXAGON (5)	1	
19	09816-00103	SPANNER,HEXAGON (4)	1	

FIG.481A




FIG.481A (1-G-3) COWLING BODY

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	94411-06L00	COWLING,BODY	1	
2	03541-0516A	SCREW	2	
3	63115-37H00	CUSHION,RR COVER NO.2 (10X10X1)	2	
4	94630-06L00-B5J	PANEL,METER FRONT	1	
5	68721-13E00-B5J	.EMBLEM,"SUZUKI"	1	
6	94632-06L00	PANEL,METER REAR	1	
7	94633-06L00	CUSHION,METER PANEL REAR	1	
8	09139-05091	SCREW (5X13)	6	
9	09139-05091	SCREW (5X13)	2	
10	09139-05094	SCREW (5X18)	2	
11	09409-06314	CLIP (5.9X20.5)	2	
12	09409-08326	CLIP (10.5X14.3)	1	
13	94510-06L00	BRACE,COWLING	1	
14	48169-12JA0	CUSHION (8X26X7)	1	
15	01550-0820B	BOLT	2	
16	33652-05G20	CUSHION,REAR LAMP (17X17X12)	1	
17	94413-06L00-YKV	COWLING,BODY CTR (BLACK)	1	
18	94414-06L00	COWLING,BODY CTR LWR	1	
19	94479-35F00	CLIP	4	
20	09139-05091	SCREW (5X13)	1	
21	09148-05038	NUT (M5)	2	
22	09148-05052	NUT (M5)	2	
23	09409-06314	CLIP (5.9X20.5)	6	

FIG.492A





FIG.492A (1-G-4) FRONT BUMPER (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	94210-06L00	BAR,ACCESSORY	1	
2	94230-06L00	BRACKET,ACCESSORY BAR RH	1	
3	94240-06L00	BRACKET,ACCESSORY BAR LH	1	
4	94251-06L00	COVER,UNDER RH	1	
5	94261-06L00	COVER,UNDER LH	1	
6	94272-06L00	SPACER,FR RH	1	
7	94273-06L00	SPACER,FR LH	1	
8	94274-06L00	SPACER,RR RH	1	
9	94275-06L00	SPACER,RR LH	1	
10	09106-08207	BOLT,ACCESSORY BAR UPR	2	
11	09116-06527	BOLT,WITH WASHER	6	
12	09160-08157	WASHER (8.5X28X1.6)	2	
13	09160-08177	WASHER,ACCESSORY BAR LWR	2	
14	09180-08152	SPACER (8.6X12X24.2)	2	
15	09180-08230	SPACER,ACCESSORY BAR LWR	2	
16	09320-12048	CUSHION (12X30X24)	2	
17	09320-12068	CUSHION (12X22X9.5)	2	
18	01550-0830B	BOLT	2	

FIG.496A






FIG.496A (1-G-5) LABEL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	68319-06L00	LABEL,GENERAL WARNING	1	ENGLISH
1-2	68319-06L20	LABEL,GENERAL WARNING	1	GERMAN
1-3	68319-06L30	LABEL,GENERAL WARNING	1	FRENCH
1-4	68319-06L40	LABEL,GENERAL WARNING	1	ITALIAN
1-5	68319-06L50	LABEL,GENERAL WARNING	1	SPANISH
1-6	68319-06L70	LABEL,GENERAL WARNING	1	DUTCH
1-7	68319-06L80	LABEL,GENERAL WARNING	1	PORTUGUESE
1-8	68319-06L90	LABEL,GENERAL WARNING	1	SWEDISH
1-9	68319-06LA0	LABEL,GENERAL WARNING	1	FINNISH
1-10	68319-06LB0	LABEL,GENERAL WARNING	1	NORWEGIAN
1-11	68319-06LP0	LABEL,GENERAL WARNING	1	RUSSIAN
2	68332-06L00	LABEL,TIRE INFORMATION	1	
3-1	68391-06L00	LABEL,CARRIER WARNING	1	
3-2	68391-06L10	LABEL,CARRIER WARNING	1	FOR RUSSIAN
4	68386-14J01	LABEL,BRAKE FLUID INFORMATION	3	FOR RUSSIAN
5	17995-14JP1	LABEL,RADIATOR CAP	1	FOR RUSSIAN
6	11959-06L00	LABEL,GASOLINE	1	
7-1	99011-06L50-01A	MANUAL,OWNER'S	1	ENGLISH
7-2	99011-06L50-01E	MANUAL,OWNER'S	1	ITALIAN
7-3	99011-06L50-01F	MANUAL,OWNER'S	1	FRENCH
7-4	99011-06L50-01H	MANUAL,OWNER'S	1	DUTCH
7-5	99011-06L50-01K	MANUAL,OWNER'S	1	GERMAN
7-6	99011-06L50-01T	MANUAL,OWNER'S	1	DANISH
7-7	99011-06L50-01W	MANUAL,OWNER'S	1	SWEDISH
7-8	99011-06L50-029	MANUAL,OWNER'S	1	SPANISH
7-9	99011-06L50-070	MANUAL,OWNER'S	1	RUSSIAN

FIG.505A




FIG.505A (1-G-6) SEAT (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	45100-06L00-B03	SEAT ASSY	1	
2	45149-31300	.CUSHION,SEAT (40X20X15)	4	
3	45141-06L00	.CUSHION,SEAT HOOK	2	
4	45148-27J00	.CUSHION, SEAT MOUNT	2	
5	45154-06L00	.CUSHION,SEAT MOUNT	1	
6	09320-10056	.CUSHION	2	
7	01550-0616A	.BOLT	4	
8	45452-06L00	.FRAME,SEAT NO.2	1	
9	45451-06L00	.FRAME,SEAT	1	
10	45220-04K20	BRACKET,SEAT SUPPORT	1	
11	45288-14F00	GUIDE,SEAT LOCK CABLE	1	
12	95700-14F00	LOCK ASSY,SEAT	1	
13	45289-11F00	PLATE,SEAT LOCK ASSY	1	
14	45280-06L00	CABLE,SEAT LOCK	1	
15	45300-06L00-B03	SEAT ASSY,PILLION	1	
16	09321-10012	.CUSHION	4	
17	45290-17K00	.STRIKER, SEAT LOCK	1	
18	08316-1006A	.NUT	2	
19	08316-1006A	NUT	2	
20	09139-06193	SCREW (6X20)	2	
21	45121-06L00	BRIDGE,SEAT	1	
22	09321-10012	CUSHION	1	
23	01550-0616A	BOLT	4	

FIG.505B




FIG.505B (1-G-7) SEAT (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	45100-06L10-B1H	SEAT ASSY	1	
1-2	45100-06L10-B03	SEAT ASSY	1	
2	45149-31300	.CUSHION,SEAT (40X20X15)	4	
3	45141-06L00	.CUSHION,SEAT HOOK	2	
4	45154-06L00	.CUSHION,SEAT MOUNT	1	
5	01550-0616A	.BOLT	4	
6	09320-10056	.CUSHION	2	
7	45256-06L00	.SHEET,HEAT SHIELD	1	
8	45452-06L00	.FRAME,SEAT NO.2	1	
9	45451-06L00	.FRAME,SEAT	1	
10	45220-04K20	BRACKET,SEAT SUPPORT	1	
11	45288-14F00	GUIDE,SEAT LOCK CABLE	1	
12	95700-14F00	LOCK ASSY,SEAT	1	
13	45289-11F00	PLATE,SEAT LOCK ASSY	1	
14	45280-06L00	CABLE,SEAT LOCK	1	
15-1	45300-06L10-B1H	SEAT ASSY,PILLION	1	
15-2	45300-06L10-B03	SEAT ASSY,PILLION	1	
16	09321-10012	.CUSHION	4	
17	45290-17K00	.STRIKER, SEAT LOCK	1	
18	08316-1006A	.NUT	2	
19	09180-06314	.SPACER (6.5X12X21)	4	
20	45321-06L00	.PLATE,SEAT	1	
21	45312-06L00	.SPACER,SEAT NO.1	1	
22	45313-06L00	.SPACER,SEAT NO.2	1	
23	01550-0620A	.BOLT	1	
24	01550-0635A	.BOLT	4	
25	08316-1006A	NUT	2	
26	09139-06193	SCREW (6X20)	2	
27	45121-06L00	BRIDGE,SEAT	1	
28	09321-10012	CUSHION	1	
29	01550-0616A	BOLT	4	

FIG.521A




FIG.521A (1-G-8) FRONT FORK DAMPER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51103-06L00	DAMPER ASSY RH	1	
2	51110-31J20	.TUBE,INNER RH	1	
3	51158-14200	.WASHER	1	
4	51153-44G00	.OIL SEAL	1	
5	51156-14200	.RING,STOPPER	1	
6	51173-02FA0	.SEAL,DUST	1	
7	51146-06L00	.CYLINDER	1	
8	51352-13A60	.NUT,ROD	1	
9	51171-31J00	.SPRING	1	
10	51158-40F30	.GUIDE,SPRING	1	
11	51176-48G10	.SPACER,SPRING	1	
12	51131-31J30	.TUBE,OUTER	1	
13	51351-31J30	.CAP	1	
14	62278-14100	..O-RING	1	
15	51112-31J00	.PISTON	1	
16	51152-31J00	.METAL,SLIDE	1	
17	51178-31J00	.SEAT,SPRING	1	
18	51104-06L00	DAMPER ASSY LH	1	
19	51120-31J20	.TUBE,INNER LH	1	
20	51158-14200	.WASHER	1	
21	51153-44G00	.OIL SEAL	1	
22	51156-14200	.RING,STOPPER	1	
23	51173-02FA0	.SEAL,DUST	1	
24	51146-06L00	.CYLINDER	1	
25	51352-13A60	.NUT,ROD	1	
26	51171-31J00	.SPRING	1	
27	51158-40F30	.GUIDE,SPRING	1	
28	51176-48G10	.SPACER,SPRING	1	
29	51131-31J30	.TUBE,OUTER	1	
30	51351-31J30	.CAP	1	
31	62278-14100	..O-RING	1	
32	51112-31J00	.PISTON	1	
33	51152-31J00	.METAL,SLIDE	1	
34	51178-31J00	.SEAT,SPRING	1	
35	51166-24F60	BOLT	4	

FIG.524A




FIG.524A (1-G-9) STEERING STEM

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51410-31J10-QSC	BRACKET,UNDER (SILVER)	1	
2	51644-12C00	.SEAL,STEERING LOWER (30.1X56X4)	1	
3	09267-30010	.BEARING (30X55X17)	1	
4	51166-40H20	BOLT (8X40)	4	
5	51310-06L00-QSC	BRACKET,UPPER (SILVER)	1	
6	51166-40H20	BOLT (8X40)	4	
7	51166-40H20	BOLT (8X40)	2	
8	51321-06L00	BOLT,HANDLE HOLDER LOWER	2	
9	51353-06L00	NUT	1	
10	51354-17H00	WASHER	2	
11	51355-16G00	WASHER	2	
12	51356-24F50	WASHER	1	
13	51331-06L00-QSC	HOLDER,HANDLE UPPER (SILVER)	1	
14	51332-06L00-QSC	HOLDER,HANDLE LOWER (SILVER)	2	
15	56245-31J00	RUBBER,HANDLE HOLDER	4	
16	08319-3110A	NUT	2	
17	09267-30010	BEARING (30X55X17)	1	
18	51643-41G00	COVER,STEERING UPPER	1	
19	51631-33E00	NUT,STEERING STEM	2	
20	51644-12C00	SEAL,STEERING LOWER (30.1X56X4)	1	
21	51641-33E00	WASHER,STEERING STEM	1	
22	09250-06015	CAP (OD:10.5)	4	

FIG.530A




FIG.530A (1-G-10) FRONT WHEEL (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	54111-31J00-019	WHEEL,FRONT (19M/CXMT2.50,BLACK)	1	
2	54731-33E20	SPACER,FR HUB BEARING	1	
3	09262-25167	BEARING (25X52X15)	2	
4	09285-32004	OIL SEAL (32X52X7)	2	
5	54711-31J00	AXLE,FR	1	
6	54751-41G10	SPACER, FRONT AXLE RH	1	
7	54162-27G10	RING,SPEED SENSOR FR	1	
8	07130-0512A	BOLT	3	
9	59210-31J10	DISC,FRONT BRAKE	2	
10	09106-08208	BOLT,DISC	10	
11	55110-06L00	TIRE,FRONT	1	
12	#43130-24A00	VALVE ASSY,WHEEL RIM (TR412)	1	
13	54712-47H00	NUT,FRONT AXLE	1	
14-1	55411-22H00	BALANCER,WHEEL NO.1 (10G)	AR	
14-2	55412-22H00	BALANCER,WHEEL NO.2 (20G)	AR	
14-3	55413-22H00	BALANCER,WHEEL NO.3 (30G)	AR	

FIG.530B




FIG.530B (1-G-11) FRONT WHEEL (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	54111-31J10	HUB,FRONT	1	
2	54731-33E20	SPACER,FR HUB BEARING	1	
3	09262-25167	BEARING (25X52X15)	2	
4	09285-32004	OIL SEAL (32X52X7)	2	
5-1	55311-31J10	RIM,FR WHEEL (19M/CXMT2.50)	1	GOLD BODY COLOR:YU1
5-2	55311-31J00	RIM,FR WHEEL (19M/CXMT2.50)	1	BLACK BODY COLOR:YVB,B1F
6	55321-11J00	SPOKE,FRONT WHEEL INNER	16	
7	55322-31J00	SPOKE,FRONT WHEEL OUTER	16	
8	55326-11J00	NIPPLE,WHEEL	32	
9	54162-27G10	RING,SPEED SENSOR FR	1	
10	07130-0512A	BOLT	3	
11	#43130-24A00	VALVE ASSY,WHEEL RIM (TR412)	1	
12	54711-31J00	AXLE,FR	1	
13	54712-47H00	NUT,FRONT AXLE	1	
14	54751-41G10	SPACER, FRONT AXLE RH	1	
15	59210-31J10	DISC,FRONT BRAKE	2	
16	09106-08208	BOLT,DISC	10	
17	55110-06L00	TIRE,FRONT	1	
18	55411-11J00	WEIGHT,WHEEL BALANCE (5GRAM)	1	

FIG.533A




FIG.533A (1-G-12) HYDRAULIC UNIT (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55610-06L10	UNIT ASSY,HYDRAULIC ABS	1	
2	55660-06L10	HOLDER,HYDR UNIT ABS	1	
3	01550-0612A	BOLT	2	
4	55661-10G00	BOLT,HYDR UNIT MTG (6X25)	3	
5	55662-10G00	SPACER,HYDR UNIT MTG (#05)	3	
6	09320-10066	RUBBER	3	

FWD

FIG.533B




FIG.533B (1-G-13) HYDRAULIC UNIT (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55610-06L00	UNIT ASSY,HYDRAULIC ABS	1	
2	55660-06L00	HOLDER,HYDR UNIT ABS	1	
3	01550-0616A	BOLT	3	
4	55661-10G00	BOLT,HYDR UNIT MTG (6X25)	3	
5	55662-10G00	SPACER,HYDR UNIT MTG (#05)	3	
6	09320-10066	RUBBER	3	

FIG.534A




FIG.534A (1-G-14) BODY ELECTRICAL (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55710-06L00	SENSOR,FR WHEEL SPEED	1	
2	65710-06L00	SENSOR,RR WHEEL SPEED	1	
3	01547-0616B	BOLT	2	
4	55731-23H00	CLAMP,ABS SENSOR FR	1	
5	55731-06L00	CLAMP,FR WHEEL SPEED SENSOR	1	
6	09408-00307	CLAMP	1	
7	01547-0616B	BOLT	2	
8	55734-06L00	CLAMP,SENSOR LEAD	5	
9	09407-14407	CLAMP (L:145)	1	

FIG.534B




FIG.534B (1-G-15) BODY ELECTRICAL (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55710-06L00	SENSOR,FR WHEEL SPEED	1	
2	65710-06L00	SENSOR,RR WHEEL SPEED	1	
3	01547-0616B	BOLT	2	
4	55731-23H00	CLAMP,ABS SENSOR FR	1	
5	55731-06L00	CLAMP,FR WHEEL SPEED SENSOR	1	
6	09408-00307	CLAMP	1	
7	01547-0616B	BOLT	2	
8	55750-06L00	SENSOR,INERTIAL	1	
9	01550-0612A	BOLT	2	
10	55734-06L00	CLAMP,SENSOR LEAD	5	
11	09407-14407	CLAMP (L:145)	1	

FIG.535A




FIG.535A (1-G-16) FRONT CALIPER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	59100-31J00-999	CALIPER ASSY,FR RH	1	
2	59100-31810	.PISTON SET	1	
3	59101-47810	..SEAL SET,PISTON	1	
4	59141-41G10	.PIN	2	
5	59151-29G00	.SPRING,PAD	1	
6	59121-18410	.BLEEDER	1	
7	55156-66310	.CAP,BLEEDER PLUG (M10X1)	1	
8	59300-31J00-999	CALIPER ASSY,FR LH	1	
9	59100-31810	.PISTON SET	1	
10	59101-47810	..SEAL SET,PISTON	1	
11	59141-41G10	.PIN	2	
12	59151-29G00	.SPRING,PAD	1	
13	59121-18410	.BLEEDER	1	
14	55156-66310	.CAP,BLEEDER PLUG (M10X1)	1	
15	59100-31820	PAD & SHIM SET	2	
16	59171-31J00	.SHIM	4	
17	59199-06L00	BOLT,CALIPER	4	
18	59151-41G00	PIN,CALIPER	4	

FIG.536A




FIG.536A (1-H-2) FRONT BRAKE HOSE (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	09360-10042	UNION (10X1.25X22)	1	
2	09360-10069	UNION	1	
3	09360-10053	UNION (10X1.25X22)	1	
4	09161-10009	WASHER (10X15X1.5)	7	
5	59200-06L20	HOSE ASSY,FR BK MASTER TO UNIT	1	
6	59240-06L00	HOSE,FR BK CLPR TO CLPR	1	
7	09403-07344	CLAMP	1	
8	09403-06324	CLAMP	2	
9	09403-16412	CLAMP	1	
10	59400-06L20	HOSE ASSY,FR UNIT TO BK CLPR	1	
11	01547-0612B	BOLT	2	
12	01547-0616B	BOLT	1	
13	01547-0625B	BOLT	1	
14	59261-06L00	CLAMP,FR BRAKE HOSE NO.1	1	
15	59260-06L00	GUIDE,FR BRAKE HOSE	1	

FIG.536B




FIG.536B (1-H-3) FRONT BRAKE HOSE (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	09360-10042	UNION (10X1.25X22)	1	
2	09360-10069	UNION	1	
3	09360-10053	UNION (10X1.25X22)	1	
4	09161-10009	WASHER (10X15X1.5)	7	
5	59200-06L00	HOSE ASSY,FR BK MASTER TO UNIT	1	
6	59240-06L00	HOSE,FR BK CLPR TO CLPR	1	
7	09403-07344	CLAMP	1	
8	09403-06324	CLAMP	2	
9	09403-16412	CLAMP	1	
10	59400-06L00	HOSE ASSY,FR UNIT TO BK CLPR	1	
11	01547-0612B	BOLT	2	
12	01547-0616B	BOLT	1	
13	01547-0625B	BOLT	1	
14	59261-06L00	CLAMP,FR BRAKE HOSE NO.1	1	
15	59260-06L00	GUIDE,FR BRAKE HOSE	1	

FIG.537A




FIG.537A (1-H-4) FRONT MASTER CYLINDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	59600-10G30	CYLINDER ASSY,FRONT MASTER	1	
2	59600-45870	.PISTON & CUP SET	1	
3	59666-44300	..BOOT	1	
4	59667-49460	.DIAPHRAGM	1	
5	59668-41C00	.PLATE,DIAPHRAGM	1	
6	59669-10G00	.CAP	1	
7	69689-49300	.SCREW,RESERVOIR CAP	2	
8	59671-32F00	.HOLDER	1	
9	59675-02FA0	.BOLT (6X22)	2	
10	59664-32F00	.PROTECTOR	1	

FIG.539A




FIG.539A (1-H-5) CLUTCH MASTER CYLINDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	59800-32F30	CYLINDER ASSY,CLUTCH MASTER	1	
2	59800-31810	.PISTON & CUP SET	1	
3	59866-23H00	..BOOT	1	
4	59871-23H10	.ROD,PUSH	1	
5	59892-08A00	.BUSH	1	
6	59667-49460	.DIAPHRAGM	1	
7	59668-41C00	.PLATE,DIAPHRAGM	1	
8	59669-10G00	.CAP	1	
9	69689-49300	.SCREW,RESERVOIR CAP	2	
10	59664-32F00	.PROTECTOR	1	
11	59671-32F00	.HOLDER	1	
12	59675-02FA0	.BOLT (6X22)	2	
13	09360-10042	UNION (10X1.25X22)	2	
14	09161-10009	WASHER (10X15X1.5)	4	
15	59900-06L00	HOSE ASSY,CLUTCH	1	
16	59915-31J00	CLAMP,CLUTCH HOSE NO.1	1	
17	59921-06L00	CLAMP,CLUTCH HOSE NO.2	1	
18	01550-0612A	BOLT	2	
19	09403-07331	CLAMP	1	

DL1050RCM0_E21_539A
CLUTCHMASTER CYLINDER

FIG.541A




FIG.541A (1-H-6) REAR SWINGINGARM

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61000-31J20-YAP	SWINGINGARM ASSY,REAR (BLACK)	1	
2	61281-31J00	.SPACER,RR SWGARM PIVOT CTR (2 0.8X27.2X196.7)	1	
3	09263-20070	.BEARING (20X27X30)	1	
4	09263-27013	.BEARING (27X35X35)	2	
5	61251-41G00	SPACER,RR SWGARM PIVOT BEARING	2	
6	61211-31J00	SHAFT,RR SWGARM PIVOT	1	
7	61214-42E10	NUT,RR SWGARM PIVOT BOLT	1	
8	09159-20006	NUT	1	
9	61273-31J00	BUFFER,CHAIN TOUCH DEFENSE	1	
10	09139-06226	SCREW,CHAIN BUFFER (6X17.8)	2	
11	61446-40F00	ADJUSTER,CHAIN LH	1	
12	61445-40F00	ADJUSTER,CHAIN RH	1	
13	09100-08287	BOLT (8X50)	2	
14	08316-1008A	NUT	2	
15	61310-16G00	CASE,CHAIN	1	
16	09139-06225	BOLT,CHAIN CASE (6X12)	2	
17	61124-33E00	PLATE,REAR SWINGINGARM BRKT	1	
18	09125-06060	SCREW (6X12)	1	

FIG.543A




FIG.543A (1-H-7) REAR CUSHION LEVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	62611-31J00	LEVER,REAR CUSHION	2	
2	62317-27C10	SPACER,RR CUSHION LEVER,FR (12 X20X34)	1	
3	62668-42A02	BOLT,CUSHION LEVER,FRONT (12X6 2)	1	
4	09159-12056	NUT	1	
5	62317-44B00	SPACER,RR CUSH LVR,FR	1	
6	62668-42A02	BOLT,CUSHION LEVER,FRONT (12X6 2)	1	
7	09159-12056	NUT	1	
8	62600-31850	ROD SET,RR CUSHION	1	
9	09263-20063	.BEARING (20X27X20)	2	
10	09283-20031	.OIL SEAL (20X27X5)	4	
11	62647-47H00	SPACER,RR CUSHION ROD FR	1	
12	62658-37F10	BOLT,RR CUSHION LEVER UPPER	1	
13	09159-12056	NUT	1	
14	62100-06L00-17U	ABSORBER ASSY,REAR SHOCK (GRAY)	1	
15	09263-17046	BEARING (17X24X32)	1	
16	62317-47H00	SPACER,RR SHOCK ABS LOWER	1	
17	09103-10033	BOLT (10X70)	1	
18	09159-10115	NUT (M10)	2	
19	09103-10428	BOLT (10X58)	1	
20	09160-12037	WASHER (12X34X1)	3	

FIG.550A




FIG.550A (1-H-8) REAR WHEEL (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	64111-31J00-019	WHEEL,RR (17M/CXMT4.00,BLACK)	1	
2	64731-49G00	SPACER,REAR HUB BEARING (20.8X 27.2X124)	1	
3	09262-28052	BEARING (28X52X12)	2	
4	09284-37001	OIL SEAL (37X52X8)	1	
5	69211-06G00	DISC,REAR BRAKE	1	
6	09106-08160	BOLT (8X21)	4	
7	64162-17G00	RING,SPEED SENSOR RR (50T)	1	
8	07130-0512A	BOLT	3	
9	64711-31J00	AXLE,RR	1	
10	64721-17K00	NUT,REAR AXLE	1	
11	09160-25070	WASHER (25.2X42X3.2)	1	
12	64741-35F10	SPACER,REAR AXLE RH	1	
13	64751-47H10	SPACER,REAR AXLE LH	1	
14	64610-35F30	DRUM,RR SPROCKET	1	
15	64733-35F00	RETAINER,REAR SPROCKET DRUM	1	
16	09262-32022	BEARING (32X65X17)	1	
17	09285-39001	OIL SEAL (39X65X7)	1	
18	64651-35F30	ABSORBER,REAR HUB SHOCK	5	
19	64511-35F20	SPROCKET,REAR (NT:41)	1	
20	08319-3110A	NUT	5	
21	65110-06L00	TIRE,REAR	1	
22	#43130-24A00	VALVE ASSY,WHEEL RIM (TR412)	1	
23-1	55411-22H00	BALANCER,WHEEL NO.1 (10G)	AR	
23-2	55412-22H00	BALANCER,WHEEL NO.2 (20G)	AR	
23-3	55413-22H00	BALANCER,WHEEL NO.3 (30G)	AR	

FIG.550B




FIG.550B (1-H-9) REAR WHEEL (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	64111-31J10	HUB,REAR	1	
2-1	65311-31J10	RIM,RR WHEEL (17M/CXMT4.00)	1	GOLD BODY COLOR:YU1
2-2	65311-31J00	RIM,RR WHEEL (17M/CXMT4.00)	1	BLACK BODY COLOR:YVB,B1F
3	65321-31J00	SPOKE,REAR WHEEL INNER	16	
4	65322-31J00	SPOKE,REAR WHEEL OUTER	16	
5	55326-11J00	NIPPLE,WHEEL	32	
6	64651-35F30	ABSORBER,REAR HUB SHOCK	5	
7	64162-17G00	RING,SPEED SENSOR RR (50T)	1	
8	07130-0512A	BOLT	3	
9	64731-49G00	SPACER,REAR HUB BEARING (20.8X 27.2X124)	1	
10	09262-28052	BEARING (28X52X12)	2	
11	09284-37001	OIL SEAL (37X52X8)	1	
12	69211-06G00	DISC,REAR BRAKE	1	
13	09106-08160	BOLT (8X21)	4	
14	64741-35F10	SPACER,REAR AXLE RH	1	
15	64610-35F30	DRUM,RR SPROCKET	1	
16	64711-31J00	AXLE,RR	1	
17	64733-35F00	RETAINER,REAR SPROCKET DRUM	1	
18	64751-47H10	SPACER,REAR AXLE LH	1	
19	64721-17K00	NUT,REAR AXLE	1	
20	09262-32022	BEARING (32X65X17)	1	
21	09285-39001	OIL SEAL (39X65X7)	1	
22	64511-35F20	SPROCKET,REAR (NT:41)	1	
23	08319-3110A	NUT	5	
24	09160-25070	WASHER (25.2X42X3.2)	1	
25	65110-06L00	TIRE,REAR	1	
26	#43130-24A00	VALVE ASSY,WHEEL RIM (TR412)	1	
27	55411-11J00	WEIGHT,WHEEL BALANCE (5GRAM)	1	

FIG.555A




FIG.555A (1-H-10) REAR CALIPER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	69100-31J00-999	CALIPER ASSY,RR	1	
2	69100-44890	.PISTON SET	1	
3	69102-05880	..SEAL SET,PISTON	1	
4	59112-44B00	.BOOT,AXLE	1	
5	69115-44G00	.SPRING,PAD	1	
6	59141-40F00	.PIN,PAD	1	
7	69105-44G00	.PIN,BOLT	1	
8	69116-44G00	.RETAINER	1	
9	59121-18410	.BLEEDER	1	
10	55156-66310	.CAP,BLEEDER PLUG (M10X1)	1	
11	69150-31J00	.BRACKET	1	
12	69182-44G00	.BOLT	1	
13	69185-44G00	.SLEEVE	1	
14	69186-44G00	.BOOT,SLEEVE	1	
15	69101-44890	PAD & SHIM SET	1	
16	69132-44G10	.INSULATOR	2	
17	69133-44G00	.SHIM	2	

FIG.558A




FIG.558A (1-H-11) REAR MASTER CYLINDER (DL1050RC)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	69600-31J00	CYLINDER ASSY,REAR MASTER	1	
2	69600-34830	.PISTON/CUP SET	1	
3	69691-00A00	..BOOT	1	
4	69692-44H00	.YOKE	1	
5	69670-31J00	.ROD,PUSH	1	
6	69693-05A00	.NUT	2	
7	69672-00B20	.CONNECTOR	1	
8	69686-34200	.O-RING	1	
9	69674-00B20	.CIRCLIP	1	
10	09139-06221	SCREW (6X16)	2	
11	69740-06L00	TANK ASSY,RESERVOIR	1	
12	69667-01H00	.DIAPHRAGM	1	
13	69669-18K00	.CAP	1	
14	69689-01H00	.SCREW	2	
15	69668-01H00	.PLATE,DIAPHRAGM	1	
16	69730-06L00	HOSE,RR RESERVOIR TANK	1	
17	09401-12412	CLIP	2	
18	09200-06068	PIN (6X18.2)	1	
19	08322-0106A	WASHER	1	
20	04111-2015A	PIN	1	
21	01547-0612A	BOLT	2	
22	69200-06L00	HOSE ASSY,RR BK MASTER TO UNIT	1	
23	69400-06L00	HOSE ASSY,RR UNIT TO BK CLPR	1	
24	09360-10042	UNION (10X1.25X22)	2	
25	09161-10009	WASHER (10X15X1.5)	4	
26	02142-0616B	SCREW	2	
27	69243-16G00	GUIDE,RR BRAKE HOSE	1	
28	61196-44H00	GUIDE,REAR BRAKE HOSE	1	
29	69641-06L00	COVER,REAR MASTER CYLINDER	1	
30	69273-31J00	CUSHION,REAR BRAKE HOSE	2	
31	69486-31J00	WASHER,REAR BRAKE HOSE GUIDE	2	
32	69750-06L00	BRACKET,RR RSVR TANK	1	
33	09139-06192	SCREW (6X25)	2	

FIG.558C




FIG.558C (1-H-12) REAR MASTER CYLINDER (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	69600-31J00	CYLINDER ASSY,REAR MASTER	1	
2	69600-34830	.PISTON/CUP SET	1	
3	69691-00A00	..BOOT	1	
4	69692-44H00	.YOKE	1	
5	69670-31J00	.ROD,PUSH	1	
6	69693-05A00	.NUT	2	
7	69672-00B20	.CONNECTOR	1	
8	69686-34200	.O-RING	1	
9	69674-00B20	.CIRCLIP	1	
10	09139-06221	SCREW (6X16)	2	
11	69740-06L00	TANK ASSY,RESERVOIR	1	
12	69667-01H00	.DIAPHRAGM	1	
13	69669-18K00	.CAP	1	
14	69689-01H00	.SCREW	2	
15	69668-01H00	.PLATE,DIAPHRAGM	1	
16	69730-06L00	HOSE,RR RESERVOIR TANK	1	
17	09401-12412	CLIP	2	
18	09200-06068	PIN (6X18.2)	1	
19	08322-0106A	WASHER	1	
20	04111-2015A	PIN	1	
21	01547-0612A	BOLT	2	
22	69200-06L20	HOSE ASSY,RR BK MASTER TO UNIT	1	
23	69400-06L20	HOSE ASSY,RR UNIT TO BK CLPR	1	
24	09360-10042	UNION (10X1.25X22)	2	
25	09161-10009	WASHER (10X15X1.5)	4	
26	02142-0616B	SCREW	2	
27	69243-16G00	GUIDE,RR BRAKE HOSE	1	
28	61196-44H00	GUIDE,REAR BRAKE HOSE	1	
29	69641-06L00	COVER,REAR MASTER CYLINDER	1	
30	69273-31J00	CUSHION,REAR BRAKE HOSE	2	
31	69486-31J00	WASHER,REAR BRAKE HOSE GUIDE	2	
32	69750-06L00	BRACKET,RR RSVR TANK	1	
33	09139-06192	SCREW (6X25)	2	

DL1050RCM0_E21_558C
REARMASTER CYLINDER

FIG.970A




FIG.970A (1-H-13) OPTIONAL (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	42100-31830	STAND SET,CENTER	1	
2	42241-31J00	.SPRING,CENTER STAND	2	

FIG.970C

FIG.970C (1-H-14) OPTIONAL (DL1050RQ)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	45100-06L50-B03	SEAT ASSY	1	






FIG.970D




FIG.970D (1-H-15) OPTIONAL (DL1050RQ)(SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48400-06810	WINDSCREEN SET	1	

NOTE 1:
WINDSCREEN SET

FIG.970E




FIG.970E (1-H-16) OPTIONAL (DL1050RQ)(SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	94200-06810	BAR SET,ACCESSORY	1	


NOTE 1:
ACCESSORY BAR SET

FIG.970F

FIG.970F (1-I-2) OPTIONAL (DL1050RQ)(SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	94200-06820	COVER SET,UNDER	1	

NOTE 1:
UNDER COVER SET



FWD

FIG.970G




FIG.970G (1-I-3) OPTIONAL (SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57100-06820	HEATER SET,GRIP	1	

NOTE 1:
GRIP HEATER SET

FIG.970H




FIG.970H (1-I-4) OPTIONAL (DL1050RQ)(SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57300-06810	COVER SET,KNUCKLE	1	

NOTE 1:
KNUCKLE COVER SET

FIG.970J (1-I-5) OPTIONAL (DL1050RQ)(SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	47500-06810	BRACKET SET,SIDE CASE UPR	1	

NOTE 1:
SIDE CASE UPR BRACKET SET






FIG.970K




FIG.970K (1-I-6) OPTIONAL (SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	93300-31830	CASE SET,TOP	1	

NOTE 1:
TOP CASE SET

FIG.970L




FIG.970L (1-I-7) OPTIONAL (SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	93900-31830	PLATE SET,TOP CASE	1	

NOTE 1:
TOP CASE PLATE SET

FIG.970M





FIG.970M (1-I-8) OPTIONAL (SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	93100-31840	CASE SET,SIDE	1	

NOTE 1:
SIDE CASE SET

FIG.970N



DL1050RCM0_E21_970N
OPTIONAL

FIG.970N (1-I-9) OPTIONAL (SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	93700-31840	BRACKET SET,SIDE CASE LWR	1	

NOTE 1:
SIDE CASE LWR BRACKET SET

FIG.970P




FIG.970P (1-I-10) OPTIONAL (DL1050RQ)(SEE NOTE 1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	94400-06830	COWLING SET,UNDER	1	

NOTE 1:
UNDER COWLING SET

PART NO.	FIG.NO.-REF.NO.
10000	
11100-31J10	105A-1
11100-31J20	104A-1
	104B-1
11115-32E70	104A-4
	104B-4
	105A-4
11117-33H00	104A-9
	104B-9
	105A-9
11134-31J10	104A-27
	104B-27
	105A-25
11141-31J00	101A-2
	104A-5
	104B-5
	105A-5
11151-27G00	105A-30
11171-06L00	104A-20
	104B-20
11172-31J10	105A-20
11173-02F00	101A-3
	104A-21
	104B-21
	105A-21
11178-17E00	101A-4
	104A-22
	104B-22
	105A-22
11182-35F10	101A-5
	104A-30
	104B-30
	105A-28
11191-27E00	104A-24
	104B-24
	105A-24
11211-31J10-0F0	107A-1
11221-31J10-0F0	107A-2
11241-31J00	101A-6
	107A-3
11242-06L00	101A-7
	107A-4
11306-06840	108A-1
11319-33E00	108A-2
11340-06L00	112A-1
11342-06G00	112A-7
11351-31J20	112A-11
11360-31J00	112A-20
11362-31J00	112A-21
11381-06G00	112A-24
11383-06L00	112A-32
11390-06G10	109A-8
11401-31850	101A-1
11482-06G10	101A-8
	112A-3
11483-02F10	101A-9
	112A-12
11485-02F10	101A-10
	112A-25
11959-06L00	496A-6
11971-25D00	112A-30
11971-33210	112A-2
12111-31J10-0F0	120A-8
12140-31J00	120A-9
12151-02F10	120A-10
12160-06G10	120A-4
12163-06G00	120A-5
12164-31J00-0A0	120A-7-1
12164-31J00-0B0	120A-7-2
12164-31J00-0C0	120A-7-3
12164-31J00-0D0	120A-7-4
12165-27A50	120A-6
12220-31J00	120A-1
12229-06L00-0A0	120A-2-4
12229-06L00-0B0	120A-2-5
12229-06L00-0C0	120A-2-6
12229-31J00-0A0	120A-2-1
12229-31J00-0B0	120A-2-2
12229-31J00-0C0	120A-2-3
12600-06811	122A-4
12600-06G01	122A-6
12612-06G00	122A-1
12618-31G00	122A-7
12652-38B00	120A-3
12701-06L00	126A-1
12702-06L00	126A-2
12703-06L00	126A-3
12704-06L00	126A-4
12716-06G00	127A-19
12731-06G01	127A-26
12750-31J10	127A-16
12755-31J00	127A-17
12760-23F20	127A-1
12771-06G00	127A-2
12800-41810	126A-14
12810-06G00	127A-3
12815-06G00	127A-4
12830-30A01	127A-8
12832-02A00	127A-9
12832-06L00	127A-6
12833-30A01	127A-10
12834-02A00	127A-11
12837-19B10	101A-11
	127A-12
12837-24A10	101A-12
	127A-13
12891-02F10	126A-12
12892-41C00-230	126A-13-1
12892-41C00-235	126A-13-2
12892-41C00-240	126A-13-3
12892-41C00-245	126A-13-4
12892-41C00-250	126A-13-5
12892-41C00-255	126A-13-6
12892-41C00-260	126A-13-7
12892-41C00-265	126A-13-8
12892-41C00-270	126A-13-9
12892-41C00-275	126A-13-10
12892-41C00-280	126A-13-11
12892-41C00-285	126A-13-12
12892-41C00-290	126A-13-13
12892-41C00-295	126A-13-14
12892-41C00-300	126A-13-15
12892-41C00-305	126A-13-16
12892-41C00-310	126A-13-17
12892-41C00-315	126A-13-18
12892-41C00-320	126A-13-19
12892-41C00-325	126A-13-20
12892-41C00-330	126A-13-21
12892-41C00-335	126A-13-22
12892-41C00-340	126A-13-23
12892-41C00-345	126A-13-24
12892-41C00-350	126A-13-25
12911-16G00	126A-5
12912-49XB0	126A-6
12921-06G00	126A-7
12931-06G00	126A-8
12932-24400	126A-11
12933-06G00	126A-9
13101-06L00	104A-16
	104B-16
13102-06L00	105A-16
13150-28H10	189A-1
13400-06L00	140A-1
13412-06L00	312A-16
13601-11J00	140A-2
13602-29G00	140A-3

PART NO.	FIG.NO.-REF.NO.
13650-41F10	155A-16
13650-49X00	187A-22
13655-41F10	155A-17
13683-06L00	140A-8
13683-06L10	140A-9
13685-06L00	427A-1
13700-06L00	155A-1
13738-31J00	155A-19
13741-31J00	155A-3
13746-06L00	155A-6
13746-06L10	155A-7
13780-31J00	155A-5
13788-06L00	155A-13
13826-22H00	104A-19
	104B-19
	105A-19
13827-06L00	155A-8
13850-31J00	155A-20
13878-10G00	155A-10
13881-06L00	155A-2
13882-06L00	155A-12
13891-31J00	155A-4
14150-06L00	163A-1
14160-06L00	163A-2
14181-31D00	101A-13
	163A-3
14205-06L00	163A-6
14310-06L00-H01	163A-12
14459-31J10	163A-13
14760-06L00	163A-21
14762-06L00	163A-22
14771-18H00	163A-15
14771-42F50	163A-7
14780-06L00	163A-23
14784-06L00	163A-25
14785-06L00	163A-26
14791-06L00	163A-29
14795-10FA0	163A-32
15100-28K00	172A-1
15113-05H00	172A-2
15113-17K00	172A-3
15113-35F00	172A-4
15113-48H00	172A-11
15114-17K00	172A-5
15115-17K00	172A-6
15116-17K00	172A-7
15121-28K00	172A-14
15122-17K00	172A-13
15201-07L00	172A-12
15310-17K00	172A-8
15420-17K00	172A-9
15610-17K00	172A-10
15710-31J00	140A-4
15717-58B00	140A-5
15722-14J00	140A-6
15731-06L00	140A-7
15810-06L00	172A-16
16321-02F00	170A-10
16331-02F00	170A-3
16400-02FB0	170A-1
16440-24F00	170A-7
16461-06L00	178A-6
16471-06L00	178A-7
16510-07J00	178A-1
16520-32E00	170A-9
16591-06L00	178A-2
16600-06L00	178A-3
17410-06L00	180A-1
17435-02F00	101A-14
	180A-5
17470-02F11	180A-3
17491-16G00	180A-2
17662-02F11	187A-15
17663-42E00	187A-16
17670-06G51	187A-18
17710-06L00	185A-1
17711-07L00	185A-6
17730-08D10	185A-9
17800-06L00	185A-2
17802-14F00	185A-7
17851-06L00	187A-1
17852-06L00	187A-2
17853-02F10	187A-3
17856-16G10	187A-19
17890-06G20	187A-4
17900-27810	187A-11
17910-31J00	187A-7
17920-31J00	187A-24
17931-31J00	187A-8
17982-31J00	187A-10
17995-14JP1	496A-5
18114-74P00	427A-2
18213-04K00	163A-35
18461-06L00	189A-2
18471-06L00	189A-3
18510-29G31	189A-4
18531-06G01	189A-5
18560-04K01	427A-3
18561-06L00	427A-4
18561-06L10	427A-5
18562-06L00	427A-6
18563-06L10	427A-7
18563-06L20	427A-8
18572-06L00	427A-9
18572-13K00	427A-10
18573-06L00	427A-11
18575-06L00	427A-12
18576-06L00	427A-13
18590-18K00	155A-14
18711-06L00	189A-6
20000	
21111-02F11	120A-12
21112-02F00	120A-13
21114-02F00	120A-14
21200-31Y20	201A-1
21411-31J10	201A-4
21412-31J00	201A-5
21413-31J00	201A-6
21414-31J00	201A-7
21415-31J00	201A-35
21441-31J00	201A-8
21442-31J00	201A-9
21451-24F00	201A-10
21452-31J00	201A-11
21462-31J10	201A-12
21471-24F00	201A-13
21472-24F00	201A-14
23110-27A00	201A-19
23111-26D00	201A-20
23121-31E00	201A-21
23160-06G20	201A-22
23163-06B00	201A-23
23164-05A00	201A-24
23166-06G10	201A-27
23171-06G00	201A-32
24120-06G00	206A-1
24130-02F30	206A-13
24221-02F01	206A-2
24231-02F30	206A-3
24251-02F11	206A-4
24252-02F10	206A-5
24261-02F20	206A-6
24262-02F00	206A-7
24311-06G00	206A-14
24321-02F11	206A-16
24322-02F01	206A-17

PART NO.	FIG.NO.-REF.NO.
24331-02F20	206A-18
24332-17E20	206A-19
	206A-21
24333-02F00	206A-25
	206A-26
24333-02F10	206A-27
24341-02F30	206A-20
24351-02F20	206A-22
24361-02F30	206A-23
24741-06G00	206A-36
24741-20A00	127A-24
24741-21A00	206A-37
	212A-5
24751-06G00	206A-38
25211-17E02	212A-1
25231-35F00	212A-2
25310-31J00	212A-6
25312-42F01	212A-8
25350-06G00	212A-12
25355-38F00	212A-13
25381-13E30	212A-9
25411-02F20	212A-3
	212A-4
25510-06G10	212A-16
25512-06G20	212A-17
25518-06L00	212A-22
25520-16G30	212A-24
25525-11C00	212A-26
25526-47000	212A-25
	212A-28
25600-31J10	212A-27
25617-03F10	212A-30
25652-20C00	212A-29
25671-01011	212A-18
27511-20A20	206A-42
27531-31J00	206A-43
27600-06G40-120	206A-44
27620-06G40	206A-45
30000	
31100-06L00	301A-1
31132-45C00	301A-2
31143-38300	301A-3
31150-07F10	301A-4
31156-48B00	301A-11
31170-06L00	301A-5
31170-43400	301A-6
31172-38300	301A-7
31173-88C00	301A-8
31264-44110	301A-9
31281-24B10	301A-10
31497-45000	212A-37
31800-06G01	312A-1
31861-47E00	312A-2
32101-06L00	303A-1
32102-06L00	303A-2
32371-13E30	303A-3
32800-31J00	312A-6
32910-06L00	312A-26
33410-06G01	312A-12
33410-06L00	312A-13
33410-20H01	312A-14
33410-26G01	312A-15
33510-31G00	312A-21
33510-31G10	312A-22
33542-06G00	312A-23
33542-06G10	312A-24
33542-38B00	312A-25
33620-31J01	310A-1
33651-37000	312A-28
33652-05G20	481A-16
33652-06L00	310A-4
33652-06L10	310A-3
33652-06L20	310A-5
33652-06L30	310A-6
33652-16G00	310A-2
33652-20C00	474A-1
	474B-1
33652-28C00	310A-7
33652-36000	310A-8
	312A-29
33652-38A10	401A-5
	401A-9
33810-06L00	310A-10
33860-06L00	310A-11
33960-25H00	312A-27
34100-06L00	330A-1
34100-06LA0	330D-1
34111-17K00	330A-2
	330D-2
34150-06L00	330A-3
34150-06LA0	330D-3
34183-10C00	330A-4
	330D-4
34189-08J01	330A-5
	330D-5
34810-06L00	172A-17
34815-06L00	172A-18
35100-07L10	333A-1
35529-77R00	333A-2
35601-06L00	334B-1
35601-08JA0	334A-1
35602-06L00	334B-6
35602-08JA0	334A-5
35603-06L00	334B-11
35603-08JA0	334A-12
35604-06L00	334B-16
35604-08JA0	334A-16
35612-08JA0	334A-2
	334A-17
35629-31F40	334A-9
	334A-20
35632-08JA0	334A-6
	334A-13
35690-06L00	334B-2
	334B-7
	334B-12
	334B-17
35710-31J01	339A-1
35710-31JA0	339B-1
35910-41GB2	339A-4
	339B-4
35912-41G01	339A-5
	339B-5
35913-41G00	339A-6
	339B-6
35917-41G00	339A-8
	339B-8
35950-13K01	460A-3
36610-06L00	350A-1
36610-06LA0	350B-1
36620-06L00	350A-6
36620-06LA0	350B-6
36651-48E00	310A-12
36654-28K00	350A-7
	350B-7
36744-06L00	350A-22
	350B-21
36856-06L00	350A-8
36856-06LA0	350B-8
36920-37H00	474A-2
	474B-2
36990-06L00	355A-2
	355B-2
37100-06L00	352A-2
	352B-2
37101-06810	352A-1
37101-06820	352B-1
37146-13K00	352A-6
	352B-7
37152-17K00	352A-3
	352B-3
37180-06L00	352A-4
	352B-4
37400-06L00	355A-1
37400-06L10	355B-1
37730-31J10	212A-36
37740-06L00	350A-13
	350B-13
37820-33D10	109A-20
37822-33D00	109A-21
37840-24F01	350A-17
	350B-17
38500-06L00	350A-19
	350B-19
38610-06F01	334A-23
38610-06L00	334B-21
38850-31J00	350A-20
38860-06L00	350A-23
	350B-22
39105-06L00	350A-21
	350B-20
40000	
41100-31J20-YAP	401A-1
41200-31J30-YAP	401A-2
41921-16G00	401A-14
41921-47H00	401A-17
41922-19F20	401A-13
41922-33E20	401A-15
41941-19F01	401A-16
41942-02F00	401A-18
42100-31830	970A-1
42100-31J10	407A-12
42241-31J00	407A-13
	970A-2
42253-31J10	407A-14
42254-31J10	407A-15
42260-06L00	407A-16
42270-31J10	407A-17
42290-31J00	407A-18
42310-31J01	407A-1
	407B-1
42321-03FK0	407A-3
	407B-3
42330-06L00	407A-6
42330-31J00	407B-6
43111-06L00	407A-8
	407B-8
43130-24A00	530A-12
	530B-11
	550A-22
	550B-26
43251-31J00	350A-15
	350B-15
43259-31J00	350A-14
	350B-14
43501-06L00	415A-4
43502-06L00	415A-11
43510-06G01-YAP	415A-1
43521-06G01-YAP	415A-2
43530-06L00	415A-8
43540-06L00	415A-15
43551-06L00	415A-6
	415A-13
43552-06L00	415A-7
	415A-14
43576-48B40	415A-5
	415A-12
43580-31J00	401A-4
43590-31J00	401A-8
43610-34A60	415A-21
43612-33G30	415A-22
43631-34A01	415A-23
43710-34A60	415A-24
43811-31J00-YAP	415A-25
43821-31J00-YAP	415A-26
44100-06L00-YVB	420A-1
44100-06L10-YU1	420B-1-1
44100-06L10-YUH	420B-1-3
44100-06L10-YVB	420B-1-2
44121-06L00	420A-2
	420B-3
44160-06L00	444A-12
44164-31J01	444A-13
44173-14J00	445A-1
	445B-1
44179-06L00	420A-15
	420B-16
44183-23H00	420A-16
	420B-17
44189-06L00	420A-17
	420B-18
44200-17840	420A-3
	420B-4
44244-11J00	420A-4
	420B-5
44271-06L00	423A-9
	423B-9
44276-21H00	420A-5
	420B-6
44277-06L00	423A-1
	423B-1
44281-18K01	474A-3
	474B-3
44291-06L00-YKV	423A-2
	423B-2-2
44291-06L00-YUA	423B-2-1
44292-06L00	423A-4
	423B-4
44294-43H00	454A-6
	454B-5
44295-07L01	423A-3
	423B-3
44423-31J12	420A-24
	420B-25
44423-31J21	420A-25
	420B-26
44480-31J00	420A-26
44511-16G00	444A-3
44512-16G00	444A-4
44520-31J01	444A-5
44523-47H00	420A-18
	420B-19
44530-06G00	420A-6
	420B-7
44541-31J00	420A-7
	420B-8
44542-06G00	420A-8
44542-06L00	444A-14
44542-31J00	420A-19
	420B-20
44543-31J01	444A-6
44545-06G00	420A-9
	420B-10
44545-06L00	420A-10
	420B-11
44550-31J00	420A-11

PART NO.	FIG.NO.-REF.NO.
	420B-12
44552-24B00	312A-4
	420A-12
	420B-13
44556-33H10	420A-20
	420B-21
44560-31J00	444A-7
44561-35F00	444A-8
44572-02F01	420A-21
	420B-22
44572-13G10	433A-1
	433B-1
44885-44AA0	454A-1
45100-06L00-B03	505A-1
45100-06L10-B03	505B-1-2
45100-06L10-B1H	505B-1-1
45100-06L50-B03	970C-1
45121-06L00	505A-21
	505B-27
45141-06L00	505A-3
	505B-3
45148-27J00	445A-2
	445B-2
	505A-4
45149-31300	505A-2
	505B-2
45154-06L00	505A-5
	505B-4
45220-04K20	505A-10
	505B-10
45256-06L00	505B-7
45280-06L00	505A-14
	505B-14
45288-14F00	505A-11
	505B-11
45289-11F00	505A-13
	505B-13
45290-17K00	505A-17
	505B-17
45300-06L00-B03	505A-15
45300-06L10-B03	505B-15-2
45300-06L10-B1H	505B-15-1
45312-06L00	505B-21
45313-06L00	505B-22
45321-06L00	505B-20
45451-06L00	505A-9
	505B-9
45452-06L00	505A-8
	505B-8
45517-16G20	312A-8
46311-31J11	412A-1
47111-06L00-YU1	445A-3-1
47111-06L00-YUH	445A-3-3
47111-06L10	445A-3-2
	445B-3
47121-06L00	445A-4
47122-17K00	454B-1
47131-06L00	445A-5
	445B-4
47161-26J00	454A-10
	454B-10
47163-10FA0	420A-22
	420B-23
47211-06L00-YU1	445A-6-1
47211-06L00-YUH	445A-6-3
47211-06L10	445A-6-2
	445B-5
47221-06L00	445A-7
47310-06L00-QRE	445A-8-3
47310-06L00-YU1	445A-8-1
47310-06L00-YVB	445A-8-2
47310-06L10-5NX	445B-6-2
47310-06L10-B4X	445B-6-1
47310-06L10-YGS	445B-6-3
47312-06L00	445A-10
	445B-8
47350-06L00-QRE	445A-11-3
47350-06L00-YU1	445A-11-1
47350-06L00-YVB	445A-11-2
47350-06L10-5NX	445B-9-2
47350-06L10-B4X	445B-9-1
47350-06L10-YGS	445B-9-3
47410-06L00	406A-11
47414-06L00	406A-1
47415-06L00	406A-2
47416-06L00	406A-3
47420-06L00	406A-16
47420-06L10	406A-18
47431-06L00	406A-4
47500-06810	970J-1
47510-06L00	445A-13
47510-28K00	445A-16
	445B-11
47511-06L10	445B-12
47512-28K00	415A-9
	415A-16
47610-06L00	445A-17
47611-06L10	445B-13
47711-06L00-QRE	445A-20-3
47711-06L00-YU1	445A-20-1
47711-06L00-YVB	445A-20-2
47711-06L10-YGS	445B-14
47811-06L00	445A-14
47812-06L00	445A-18
47911-06L00	445A-15
47912-06L00	445A-19
47912-31J00	406A-6
	474A-4
	474B-4
47913-06L00	445A-21
	445B-15
47915-31J00	460A-2
48128-14FA0	406A-12
48169-12JA0	481A-14
48400-06810	970D-1
48411-06L00	454A-2
	454B-2
48412-06L00	454A-7
48412-06L10	454B-6
48413-06L00	454A-8
48413-06L10	454B-7
48415-06L00	454B-3
48416-06L00	454A-3
48421-06L00	454A-11
48421-06L10	454B-11
48422-06L00	454A-12
	454B-12
48423-06L00	454A-13
48423-06L10	454B-13
48431-06L00	454A-14
48431-06L10	454B-14
48432-06L00	454A-15
	454B-15
48433-06L00	454A-16
48433-06L10	454B-16
48441-06L00	454A-17
	454B-17
48442-06L00	454A-18
	454B-18
48451-06L00	454A-19
48452-06L00	454A-20
	454B-19
48453-06L00	454A-25
48454-06L00	454A-21
48461-06L00	454A-22
48462-06L00	454A-26
48463-06L00	454A-27
48464-06L00	454A-28
48465-06L00	454A-29
48466-06L00	454A-30

PART NO.	FIG.NO.-REF.NO.
48467-06L00	454A-31
48471-06L00	454A-32
48472-06L00	454A-33
48473-06L00	454A-34
48474-06L00	454A-35
48475-06L00	454A-36
50000	
51103-06L00	521A-1
51104-06L00	521A-18
51110-31J20	521A-2
51112-31J00	521A-15
	521A-32
51120-31J20	521A-19
51131-31J30	521A-12
	521A-29
51146-06L00	521A-7
	521A-24
51152-31J00	521A-16
	521A-33
51153-44G00	521A-4
	521A-21
51156-14200	521A-5
	521A-22
51158-14200	521A-3
	521A-20
51158-40F30	521A-10
	521A-27
51166-24F60	521A-35
51166-40H20	524A-4
	524A-6
	524A-7
51171-31J00	521A-9
	521A-26
51173-02FA0	521A-6
	521A-23
51176-48G10	521A-11
	521A-28
51178-31J00	521A-17
	521A-34
51310-06L00-QSC	524A-5
51321-06L00	524A-8
51331-06L00-QSC	524A-13
51332-06L00-QSC	524A-14
51351-31J30	521A-13
	521A-30
51352-13A60	521A-8
	521A-25
51353-06L00	524A-9
51354-17H00	524A-10
51355-16G00	524A-11
51356-24F50	524A-12
51410-31J10-QSC	524A-1
51553-15D40	310A-9
51631-33E00	524A-19
51641-33E00	524A-21
51643-41G00	524A-18
51644-12C00	524A-2
	524A-20
53110-31J00	460A-1
54111-31J00-019	530A-1
54111-31J10	530B-1
54162-27G10	530A-7
	530B-9
54711-31J00	530A-5
	530B-12
54712-47H00	530A-13
	530B-13
54731-33E20	530A-2
	530B-2
54751-41G10	530A-6
	530B-14
55110-06L00	530A-11
	530B-17
55156-66310	535A-7
	535A-14
	555A-10
55311-31J00	530B-5-2
55311-31J10	530B-5-1
55321-11J00	530B-6
55322-31J00	530B-7
55326-11J00	530B-8
	550B-5
55411-11J00	530B-18
	550B-27
55411-22H00	530A-14-1
	550A-23-1
55412-22H00	530A-14-2
	550A-23-2
55413-22H00	530A-14-3
	550A-23-3
55610-06L00	533B-1
55610-06L10	533A-1
55660-06L00	533B-2
55660-06L10	533A-2
55661-10G00	533A-4
	533B-4
55662-10G00	533A-5
	533B-5
55710-06L00	534A-1
	534B-1
55731-06L00	534A-5
	534B-5
55731-23H00	534A-4
	534B-4
55734-06L00	534A-8
	534B-10
55750-06L00	534B-8
56111-06L00	462E-1
	462F-1
56245-31J00	524A-15
56270-04F20	462E-2
56270-04FA0	462F-2
56500-04F30	462E-3
56500-06L00	462F-3
56600-04F30	462E-4
56600-06L00	462F-4
57100-06820	970G-1
57100-06L00	467A-1
57100-06L10	467B-1
57110-06L00	467A-2
	467B-2
57211-21H01	467A-8
	467B-8
57300-06810	970H-1
57300-10G32	467B-3
57300-10G40	467A-3
57341-06L00	472A-1
57342-06L00	472A-2
57431-17H02	467A-4
	467A-10
	467B-4
	467B-10
57460-14J01	467A-6
	467B-6
57465-17C00	467A-7
	467B-7
57500-24F22	467B-9
57500-24F40	467A-9
57541-06L00	472A-3
57542-06L00	472A-4
57560-02FA0	467A-12
	467B-12

PART NO.	FIG.NO.-REF.NO.
59100-31810	535A-2
	535A-9
59100-31820	535A-15
59100-31J00-999	535A-1
59101-47810	535A-3
	535A-10
59112-44B00	555A-4
59121-01A00	201A-25
59121-18410	535A-6
	535A-13
	555A-9
59122-46H00	201A-26
59141-40F00	555A-6
59141-41G10	535A-4
	535A-11
59151-29G00	535A-5
	535A-12
59151-41G00	535A-18
59171-31J00	535A-16
59199-06L00	535A-17
59200-06L00	536B-5
59200-06L20	536A-5
59210-31J10	530A-9
	530B-15
59240-06L00	536A-6
	536B-6
59260-06L00	536A-15
	536B-15
59261-06L00	536A-14
	536B-14
59300-31J00-999	535A-8
59400-06L00	536B-10
59400-06L20	536A-10
59600-10G30	537A-1
59600-45870	537A-2
59664-32F00	537A-10
	539A-10
59666-44300	537A-3
59667-49460	537A-4
	539A-6
59668-41C00	537A-5
	539A-7
59669-10G00	537A-6
	539A-8
59671-32F00	537A-8
	539A-11
59675-02FA0	537A-9
	539A-12
59800-31810	539A-2
59800-32F30	539A-1

PART NO.	FIG.NO.-REF.NO.
59866-23H00	539A-3
59871-23H10	539A-4
59892-08A00	539A-5
59900-06L00	539A-15
59915-31J00	539A-16
59921-06L00	539A-17
60000	
61000-31J20-YAP	541A-1
61124-33E00	541A-17
61196-44H00	558A-28
	558C-28
61211-31J00	541A-6
61214-42E10	541A-7
61251-41G00	541A-5
61273-31J00	541A-9
61281-31J00	541A-2
61310-16G00	541A-15
61445-40F00	541A-12
61446-40F00	541A-11
61544-94500	406A-5
62100-06L00-17U	543A-14
62278-14100	521A-14
	521A-31
62317-27C10	543A-2
62317-44B00	543A-5
62317-47H00	543A-16
62600-31850	543A-8
62611-31J00	543A-1
62647-47H00	543A-11
62658-37F10	543A-12
62668-42A02	543A-3
	543A-6
63111-06L00	474A-5
	474B-5
63112-06L00	474A-6
63112-06L10	474B-6
63115-37H00	401A-6
	401A-10
	481A-3
63411-06L00	474A-7
	474B-7
64111-31J00-019	550A-1

PART NO.	FIG.NO.-REF.NO.
64111-31J10	550B-1
64162-17G00	550A-7
	550B-7
64511-35F20	550A-19
	550B-22
64610-35F30	550A-14
	550B-15
64651-35F30	550A-18
	550B-6
64711-31J00	550A-9
	550B-16
64721-17K00	550A-10
	550B-19
64731-49G00	550A-2
	550B-9
64733-35F00	550A-15
	550B-17
64741-35F10	550A-12
	550B-14
64751-47H10	550A-13
	550B-18
65110-06L00	550A-21
	550B-25
65311-31J00	550B-2-2
65311-31J10	550B-2-1
65321-31J00	550B-3
65322-31J00	550B-4
65710-06L00	534A-2
	534B-2
68110-06L00-AA3	420B-2-2
68110-06L00-B1G	420B-2-3
68110-06L00-B4J	420B-2-1
68135-06L00-B4K	445A-9-1
68135-06L00-B4L	445A-9-2
68135-06L00-B4M	445A-9-3
68135-06L10-B4N	445B-7-3
68135-06L10-B4P	445B-7-2
68135-06L10-B4Q	445B-7-1
68145-06L00-B4K	445A-12-1
68145-06L00-B4L	445A-12-2
68145-06L00-B4M	445A-12-3
68145-06L10-B4N	445B-10-3
68145-06L10-B4P	445B-10-2
68145-06L10-B4Q	445B-10-1
68181-06L00-B1G	433B-3-2
68181-06L00-BD7	433B-3-1
68181-06L00-BTH	433B-3-3
68191-06L00-B1G	433B-8-2
68191-06L00-BD7	433B-8-1
68191-06L00-BTH	433B-8-3

PART NO.	FIG.NO.-REF.NO.
68241-04X50-300	444A-16
68271-06L00-B4K	433A-3-1
68271-06L00-B4L	433A-3-2
68271-06L00-B4M	433A-3-3
68271-06L10-B4F	433B-4-3
68271-06L10-B4G	433B-4-2
68271-06L10-B4H	433B-4-1
68275-06L00-B4K	433A-4-1
68275-06L00-B4L	433A-4-2
68275-06L00-B4M	433A-4-3
68281-06L00-B4K	433A-8-1
68281-06L00-B4L	433A-8-2
68281-06L00-B4M	433A-8-3
68281-06L10-B4F	433B-9-3
68281-06L10-B4G	433B-9-2
68281-06L10-B4H	433B-9-1
68281-47HA0	423A-5
	423B-5
68285-06L00-B4K	433A-9-1
68285-06L00-B4L	433A-9-2
68285-06L00-B4M	433A-9-3
68319-06L00	496A-1-1
68319-06L20	496A-1-2
68319-06L30	496A-1-3
68319-06L40	496A-1-4
68319-06L50	496A-1-5
68319-06L70	496A-1-6
68319-06L80	496A-1-7
68319-06L90	496A-1-8
68319-06LA0	496A-1-9
68319-06LB0	496A-1-10
68319-06LP0	496A-1-11
68332-06L00	496A-2
68386-14J01	496A-4
68391-06L00	496A-3-1
68391-06L10	496A-3-2
68721-13E00-B5J	481A-5
69100-31J00-999	555A-1
69100-44890	555A-2
69101-44890	555A-15
69102-05880	555A-3
69105-44G00	555A-7
69115-44G00	555A-5
69116-44G00	555A-8
69132-44G10	555A-16
69133-44G00	555A-17
69150-31J00	555A-11
69182-44G00	555A-12
69185-44G00	555A-13
69186-44G00	555A-14

PART NO.	FIG.NO.-REF.NO.
69200-06L00	558A-22
69200-06L20	558C-22
69211-06G00	550A-5
	550B-12
69243-16G00	558A-27
	558C-27
69273-31J00	558A-30
	558C-30
69400-06L00	558A-23
69400-06L20	558C-23
69486-31J00	558A-31
	558C-31
69600-31J00	558A-1
	558C-1
69600-34830	558A-2
	558C-2
69641-06L00	558A-29
	558C-29
69667-01H00	558A-12
	558C-12
69668-01H00	558A-15
	558C-15
69669-18K00	558A-13
	558C-13
69670-31J00	558A-5
	558C-5
69672-00B20	558A-7
	558C-7
69674-00B20	558A-9
	558C-9
69686-34200	558A-8
	558C-8
69689-01H00	558A-14
	558C-14
69689-49300	537A-7
	539A-9
69691-00A00	558A-3
	558C-3
69692-44H00	558A-4
	558C-4
69693-05A00	558A-6
	558C-6
69730-06L00	558A-16
	558C-16
69740-06L00	558A-11
	558C-11
69750-06L00	558A-32
	558C-32

PART NO.	FIG.NO.-REF.NO.
90000	
93100-31840	970M-1
93300-31830	970K-1
93700-31840	970N-1
93900-31830	970L-1
94200-06810	970E-1
94200-06820	970F-1
94210-06L00	492A-1
94230-06L00	492A-2
94240-06L00	492A-3
94251-06L00	492A-4
94261-06L00	492A-5
94272-06L00	492A-6
94273-06L00	492A-7
94274-06L00	492A-8
94275-06L00	492A-9
94400-06830	970P-1
94411-06L00	481A-1
94413-06L00-YKV	481A-17
94414-06L00	481A-18
94415-40F00	445A-22
	445B-16
94417-24F00	445A-23
	445B-17
94420-06L00-QRE	433A-2-3
94420-06L00-YU1	433A-2-1
94420-06L00-YVB	433A-2-2
94420-06L10-YUD	433B-2-3
94420-06L10-YUH	433B-2-2
94420-06L10-YVB	433B-2-1
94425-06L00	433A-5
	433B-5
94426-06L00	433A-6
	433B-6
94429-21E00	401A-7
	401A-11
94430-06L00-QRE	433A-7-3
94430-06L00-YU1	433A-7-1
94430-06L00-YVB	433A-7-2
94430-06L10-YUD	433B-7-3
94430-06L10-YUH	433B-7-2
94430-06L10-YVB	433B-7-1
94441-06L00	433A-10
	433B-10
94451-06L00	433A-11
	433B-11

PART NO.	FIG.NO.-REF.NO.
94463-06L00	433A-12
	433B-12
94464-06L00	433A-13
	433B-13
94471-06L00	433A-14
	433B-14
94479-35F00	445A-24
	445B-18
	481A-19
94481-06L00	433A-15
	433B-15
94510-06L00	481A-13
94630-06L00-B5J	481A-4
94632-06L00	481A-6
94633-06L00	481A-7
94642-10GA0	423A-6
	423B-6
95643-58J00	330A-8
	330D-8
95700-14F00	505A-12
	505B-12
95700-31870	352B-6
99000-69471	126A-15
99011-06L50-01A	496A-7-1
99011-06L50-01E	496A-7-2
99011-06L50-01F	496A-7-3
99011-06L50-01H	496A-7-4
99011-06L50-01K	496A-7-5
99011-06L50-01T	496A-7-6
99011-06L50-01W	496A-7-7
99011-06L50-029	496A-7-8
99011-06L50-070	496A-7-9
00000	
01421-0616A	406A-13
01421-0620A	107A-7
01421-0625B	406A-14
01547-0512B	352A-5
	352B-5
01547-0612A	558A-21
	558C-21
01547-0612B	536A-11
	536B-11
01547-0616B	534A-3
	534A-7
	534B-3
	534B-7
	536A-12
	536B-12
01547-0620A	189A-10
01547-0625A	112A-27
01547-0625B	212A-33
	301A-14
	536A-13
	536B-13
01547-0630A	108A-4
01547-0635A	112A-28
01547-0670A	108A-5
01547-0685A	108A-6
01550-0610A	112A-9
	187A-25
01550-0612A	350A-16
	350B-16
	533A-3
	534B-9
	539A-18
01550-0612B	104A-12
	104B-12
	105A-13
01550-0616A	187A-17
	444A-9
	505A-7
	505A-23
	505B-5
	505B-29
	533B-3
01550-0620A	406A-17
	406A-19
	505B-23
01550-0620B	406A-20
01550-0635A	505B-24
01550-0695A	444A-10
01550-0812A	109A-10
01550-0816A	420A-13
	420B-14
01550-0820B	481A-15
01550-0830B	492A-18
01550-0835A	420A-14
	420B-15
01550-1035B	407A-19
01550-1045B	407A-20
01550-1050A	104A-25
01550-1070A	104A-26
01550-1085B	104B-25
01550-1235B	407A-7
	407B-7
02112-0612A	112A-8
	206A-40
02122-0616B	104A-18
	104B-18
	105A-18
02142-0520A	454A-39
02142-0616B	558A-26
	558C-26
03211-0414B	334A-3
	334A-7
	334A-14
	334A-18
03211-0416A	339A-9
	339B-9
03511-0516A	155A-18
03541-0416A	330A-7
	330D-7
03541-0512A	454A-40
	454B-9
03541-0512B	406A-9
	433A-20
	433B-20
03541-0516A	339A-3
	339B-3
	406A-10
	481A-2
03541-0520A	155A-9
	155A-15
03541-0616B	474A-11
	474B-11
04111-2015A	558A-20
	558C-20
04211-09149	112A-4
	112A-13
	112A-29
	180A-10
04211-13189	104A-6
	104B-6
	105A-6
	107A-5
04221-04089	212A-7
04221-08149	201A-28
07120-0512A	415A-10
	415A-17
07120-0612A	127A-5
07120-0616A	172A-15
07120-0890A	108A-7
07130-0510A	212A-38

PART NO.	FIG.NO.-REF.NO.
07130-0512A	303A-6
	530A-8
	530B-10
	550A-8
	550B-8
07130-0612A	187A-6
	206A-41
07130-0620A	427A-24
07130-0620B	127A-15
07130-0625A	127A-14
	170A-2
07130-0660B	427A-25
07130-0665B	201A-29
07130-0670B	201A-30
07130-0825A	163A-5
07130-0840B	401A-19
	401A-20
07130-1016B	420A-28
08112-63030	127A-22
08113-69050	212A-11
08211-06141	212A-15
08310-00067	301A-12
08310-0006A	212A-34
08316-1005A	334A-10
	334A-21
08316-1006A	334B-5
	334B-10
	334B-15
	334B-20
	406A-15
	427A-26
	505A-18
	505A-19
	505B-18
	505B-25
08316-1006B	104A-11
	104B-11
	105A-12
	107A-8
08316-1008A	541A-14
08316-1008B	104A-8
	104B-8
	105A-8
	163A-20
08316-1606B	467A-11
	467B-11
08319-2106A	467A-5
	467B-5
08319-3106A	312A-7
	444A-11
08319-3110A	109A-19
	524A-16
	550A-20
	550B-23
08322-0105A	454A-41
08322-0106A	558A-19
	558C-19
08322-0106B	474A-12
	474B-12
08322-0108A	108A-9
08331-31109	170A-6
08331-3112A	212A-35
08331-3114A	212A-23
08331-3118A	407A-11
	407B-11
08331-31409	120A-15
08331-31509	170A-12
08332-1104B	415A-29
08332-1106B	415A-20
08332-1108A	180A-7
08361-35068	301A-13
08361-3506A	301A-15
09100-08287	541A-13
09103-06220	104A-14
	104B-14
	105A-10
09103-06266	104A-3
	104B-3
	105A-3
09103-06285	420A-23
	420B-24
09103-06314	112A-26
09103-06529	112A-5
	180A-8
09103-06530	112A-14
	112A-22
09103-06535	112A-23
09103-06536	180A-9
09103-06538	112A-6
09103-06539	112A-15
09103-08357	350A-18
	350B-18
09103-08568	412A-2
09103-10033	543A-17
09103-10205	109A-17
09103-10226	109A-18
09103-10428	543A-19
09103-10475	104B-26
09103-12016	109A-15
09103-14001	303A-4
09106-05023	212A-39
09106-06075	104A-28
	104B-28
	105A-26
	109A-6
09106-06078	163A-30
09106-06088	312A-9
09106-06090	454A-37
09106-06120	303A-7
	312A-10
09106-07021	104A-23
	104B-23
	105A-23
09106-08106	122A-5
09106-08131	415A-27
09106-08136	108A-8
09106-08142	108A-3
09106-08160	550A-6
	550B-13
09106-08162	163A-14
09106-08167	454A-23
	454B-20
09106-08178	163A-4
09106-08195	163A-16
09106-08197	163A-8
09106-08200	415A-3
09106-08207	492A-10
09106-08208	530A-10
	530B-16
09108-06096	104A-10
	104B-10
	105A-11
09108-06124	107A-6
09108-08143	104A-7
	104B-7
	105A-7
09111-06041	212A-14
09111-06085	187A-9
09111-10058	407A-2
	407B-2
09116-06009	444A-15
09116-06165	474A-8
	474B-8
09116-06527	492A-11
09116-08176	163A-11
09118-06097	185A-5
09118-06112	444A-1
09119-06109	460A-4
09125-06060	541A-18
09125-06122	212A-10

PART NO.	FIG.NO.-REF.NO.
09126-06011	127A-25
	206A-39
09128-06013	312A-5
09139-05091	433A-16
	433B-16
	445A-25
	445A-26
	445B-19
	445B-20
	481A-8
	481A-9
	481A-20
09139-05092	401A-12
	472A-5
09139-05094	481A-10
09139-05098	112A-33
09139-06128	163A-27
09139-06169	445A-27
	445B-21
09139-06172	423A-7
	423B-7
	433A-17
	433B-17
09139-06192	558A-33
	558C-33
09139-06193	505A-20
	505B-26
09139-06206	454A-4
09139-06221	558A-10
	558C-10
09139-06225	541A-16
09139-06226	541A-10
09139-06229	423A-8
	423B-8
09139-06231	333A-4
09139-06232	333A-5
09139-10006	401A-3
09140-06025	212A-31
09140-16001	127A-20
09140-22012	120A-17
09148-05038	481A-21
09148-05052	445A-28
	445B-22
	472A-6
	474A-9
	474B-9
	481A-22
09148-06018	406A-7
09159-05045	454A-38
09159-06096	312A-11
	339A-11
	339B-11
09159-10115	543A-18
09159-12056	109A-16
	543A-4
	543A-7
	543A-13
09159-20004	206A-46
09159-20006	541A-8
09159-24010	201A-15
09160-04026	330A-6
	330D-6
09160-05501	339A-2
	339B-2
09160-06055	163A-31
09160-06125	427A-14
09160-06151	427A-15
09160-08043	460A-5
09160-08114	427A-16
09160-08157	492A-12
09160-08162	163A-19
09160-08177	492A-13
09160-12011	212A-32
09160-12037	543A-20
09160-15045	201A-31
09160-18022	407A-9
	407B-9
09160-25009	206A-47
09160-25056	201A-16
09160-25070	550A-11
	550B-24
09160-25074	201A-2
09160-27008	206A-24
09161-10009	536A-4
	536B-4
	539A-14
	558A-25
	558C-25
09164-22007	120A-18
09164-24008	201A-17
09168-06023	104A-13
	104B-13
	105A-14
09168-06026	112A-10
09168-08016	109A-9
09168-12017	187A-23
09168-12018	127A-7
09168-14002	109A-13
	112A-19
09168-16002	109A-11
09169-06073	334B-3
	334B-8
	334B-13
	334B-18
09169-07007	454B-21
09169-08053	412A-3
09180-06195	312A-17
09180-06198	312A-18
09180-06255	312A-19
09180-06263	339A-10
	339B-10
09180-06264	444A-2
09180-06290	185A-4
09180-06314	505B-19
09180-08152	163A-9
	492A-14
09180-08156	163A-17
09180-08230	492A-15
09180-12140	122A-3
09181-10158	170A-4
09181-10195	122A-8
09181-14167	212A-19
09181-16212	127A-21
09181-20251	206A-28
09181-21002	178A-4
09181-22167	206A-8
09181-22223	206A-29
09181-25223	201A-18
09200-06068	558A-18
	558C-18
09206-08001	104A-2
	104B-2
	105A-2
09206-10016	104A-31
	104B-31
	105A-29
09206-12002	122A-2
09208-06010	415A-28
09208-08023	415A-18
09247-14036	109A-14
09248-14010	112A-18
09248-16012	109A-12
09250-06015	524A-22
09259-36021	112A-16
09261-04009	170A-5
09261-06002	170A-11
09262-10016	180A-6
09262-20082	206A-30
09262-20139	206A-9
09262-25006	127A-23
09262-25073	206A-10
09262-25167	530A-3
	530B-3
09262-28052	550A-3
	550B-10
09262-28053	206A-31
09262-32022	550A-16
	550B-20
09263-15003	201A-33
09263-17046	543A-15
09263-20063	543A-9
09263-20070	541A-3
09263-22068	206A-15
09263-27013	541A-4
09263-35013	201A-3
09267-30010	524A-3
	524A-17
09280-04004	109A-2
	109A-5
09280-05007	109A-7
09280-08012	112A-34
09280-13004	170A-8
09280-13007	109A-3
09280-17003	112A-31
09280-17004	206A-11
09280-18008	187A-5
09280-19005	104A-29
	104B-29
	105A-27
09280-24010	206A-48
09280-33004	101A-15
	112A-17
09280-55005	104A-17
	104B-17
	105A-17
09280-60005	178A-5
09283-06008	201A-34
09283-10005	180A-4
09283-14005	212A-20
09283-20031	543A-10
09283-38028	206A-32
09284-37001	550A-4
	550B-11
09285-32004	530A-4
	530B-4
09285-39001	550A-17
	550B-21
09289-05015	126A-10
09320-04013	163A-33
09320-06016	427A-17
09320-08029	445A-29
	445B-23
09320-08051	427A-18
09320-08066	163A-24
	163A-28
09320-09016	454A-5
	454B-4
09320-09501	333A-6
09320-10043	333A-3
09320-10051	185A-3
09320-10056	505A-6
	505B-6
09320-10066	533A-6
	533B-6
09320-12048	492A-16
09320-12049	163A-18
09320-12068	492A-17
09320-12077	163A-10
09320-20010	445A-30
	445B-24
09321-06026	472A-7
	474A-10
	474B-10
09321-06033	472A-8
09321-10012	505A-16
	505A-22
	505B-16
	505B-28
09321-10018	163A-34
09321-10046	407A-21
09329-18001	185A-8
09352-42704-140	180A-11
09360-10042	536A-1
	536B-1
	539A-13
	558A-24
	558C-24
09360-10053	536A-3
	536B-3
09360-10069	536A-2
	536B-2
09367-06009	427A-19
09367-08005	420A-27
	420B-27
09380-27001	206A-12
	206A-33
	206A-34
	206A-35
09381-22002	120A-11
09401-06101	427A-20
09401-08411	187A-13
09401-10401	427A-21
09401-10409	427A-22
09401-11413	427A-23
09401-12412	558A-17
	558C-17
09401-12414	187A-21
09401-14301	155A-11
09401-15101	189A-8
09401-16407	178A-8
09401-17201	189A-9
09401-18101	189A-7
09401-22405	155A-21
09401-24002	187A-12
09401-25001	187A-14
09401-29001	187A-20
09403-06324	536A-8
	536B-8
09403-07331	539A-19
09403-07344	536A-7
	536B-7
09403-10319	350A-10
	350B-10
09403-16412	536A-9
	536B-9
09404-06429	180A-12
	334A-11
	334A-22
	334B-4
	334B-9
	334B-14
	334B-19
	350A-9
	350B-9
09407-14407	350A-11
	350B-11
	534A-9
	534B-11
09407-19401	350A-12
	350B-12
09408-00235	312A-20
09408-00307	534A-6
	534B-6
09409-06314	406A-8
	433A-18
	433B-18
	481A-11
	481A-23
09409-06329	454A-9
	454A-24

PART NO.	FIG.NO.-REF.NO.
	454B-8
	454B-22
09409-07333	433A-19
	433B-19
09409-08326	481A-12
09420-04008	303A-5
09420-06001	120A-19
09421-04004	127A-18
09440-07001	120A-16
09440-17013	212A-21
09443-14058	407A-4
	407B-4
09443-19011	407A-5
	407B-5
09448-18037	415A-19
09448-41006	407A-10
	407B-10
09471-12140	339A-7
	339B-7
09471-12186	334A-4
	334A-8
	334A-15
	334A-19
09481-03501	350A-2
	350B-2
09481-10504	350A-3
	350B-3
09481-15504	350A-4
	350B-4
09481-25504	350A-5
	350B-5
09481-30101	312A-3
09482-00635	104A-15
	104B-15
	105A-15
09493-20014	109A-4
09493-28010	109A-1
09811-00173	474A-13
	474B-13
09813-00030	474A-14
	474B-14
09813-00031	474A-15
	474B-15
09814-00015	474A-16
	474B-16
09814-00016	474A-17
	474B-17
09816-00059	474A-18
	474B-18
09816-00103	474A-19

PART NO.	FIG.NO.-REF.NO.
	474B-19

PART NO.	FIG.NO.-REF.NO.

PART NO.	FIG.NO.-REF.NO.

SUZUKI **DL1050RCM0** PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved
No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION
Technical Readiness Group, Quality Administration Department
300 Takatsuka, Minami, Hamamatsu, Japan

Reprint Prohibited

SUZUKI MOTOR CORPORATION

PRINTED IN JAPAN

9900B-31684-000