

DF70A/80A/90A /100B

DF70AT/ATH

DF80AT

DF90AT/ATH/AWQH

DF100BT

E11/E40/E03/E01

020 Norge = E01

021 Norge = E11



OUTBOARD MOTOR

2020-8

1ST EDITION

This part catalogue supersedes all the following part catalogue with immediate effect

Model of catalogue	Parts catalogue No.
DF90A_E01/E40_020	9900B-45453-001

This part catalogue supersedes all the following part catalogue with immediate effect

Model of catalogue	Parts catalogue No.
DF90A_E03_020	9900B-45454

PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF70A/80A/90A/100B production start from 2019 to 2020.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E. NO.	: Engine number	OS	: Over size
F. NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	W/	: With
LH(PORT)	: Left hand side	L, X	: Transom type
RH(STBD)	: Right hand side	SUS	: Stainless steel
~123456	: Up to E. NO. 09003F-123456	PTT	: Power trim and tilt
123456~	: From E. NO. 09003F-123456		

12 x 34 x 5.6..... Figures in the description column
| | | show the dimensions of parts.
ID OD T(or W, L)

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual.
When assembling, use "SUZUKI SERVICE MANUAL".

6. MODEL NAME AND ENGINE NUMBER

MODEL	DESTINATION	TYPE	TRANSOM	COLOR	ENGINE No.
DF70AT_020	E01, E40	07003F	L, X	YAY, Y5S	07003F-040001~
DF70AT_020	E03	07003F	L, X	YAY, Y5S	07003F-040001~
DF70AT_021	E11, E40	07003F	L, X	YAY, QTN	07003F-140001~
DF70ATH_020	E01	07003F	L	YAY	07003F-040001~
DF70ATH_020	E40	07003F	L, X	YAY	07003F-040001~
DF70ATH_021	E11	07003F	L	YAY	07003F-140001~
DF80AT_020	E01, E40	08002F	L, X	YAY	08002F-040001~
DF80AT_021	E01, E40	08002F	L, X	YAY	08002F-140001~
DF90AT_020	E01, E40	09003F	L, X	YAY, Y5S	09003F-040001~
DF90AT_020	E03	09003F	L, X	YAY, Y5S	09003F-040001~
DF90AT_021	E11, E40	09003F	L, X	YAY, QTN	09003F-140001~

MODEL	DESTINATION	TYPE	TRANSOM	COLOR	ENGINE No.
DF90ATH_020	E01	09003F	L	YAY	09003F-040001~
DF90ATH_020	E40	09003F	L, X	YAY	09003F-040001~
DF90ATH_021	E11	09003F	L	YAY	09003F-140001~
DF90ATH_021	E40	09003F	L, X	YAY	09003F-140001~
DF90AWQH_021	E40	09003F	L, X	YAY	09003F-140001~
DF100BT_020	E01, E40	10004F	L, X	YAY, Y5S	10004F-040001~
DF100BT_021	E01, E40	10004F	L, X	YAY, QTN	10004F-140001~

Quand il devient nécessaire de remplacer des pièces sur SUZUKI MOTEURS HORSBOARD toujours utiliser les PIÈCES D'ORIGINE SUZUKI qui ont été soumises à des contrôles de qualité sévères leur garantissant qualité et performance impeccables.

Ce catalogue de pièces détachées couvre la liste de toutes les pièces de rechange pour SUZUKI DF70A/80A/90A/100B production start from 2019 to 2020.

INSTRUCTIONS POUR UTILISER LE CATALOGUE

1. DIMENSIONS

Les dimensions des pièces dans ce catalogue sont indiquées en unités de millimètres.

2. ABREVIATIONS

Les abréviations utilisées dans ce catalogue sont les suivantes:

AR	: Comme requis	NT	: Nombre de dents
ASSY	: Assemblage	OPT	: Sur option
E. NO.	: Numéro du moteur	OS	: Sur-dimensionné
F. NO.	: Numéro du chfssis	T	: Epaisseur
ID	: Diamètre intérieur	US	: Sous-dimensionné
OD	: Diamètre extérieur	W	: Largeur

L : Longueur

LH(PORT) : Côte gauche

RH(STBD) : Côte droit

~123456 : Jusqu'à E. NO. 09003F-123456

123456~ : Depuis E. NO. 09003F-123456

12 x 34 x 5.6..... Les chiffres dans la colonne

| | | remarques montrent les dimensions

ID OD T(or W,L) des pieces comme suit.

-12345-56781 (N° de pieces) : indique que le numéro des pièces a été échangé en 12345-56781 et que les nouvelles pièces sont interchangeables avec les anciennes, mais que celles-ci ne sont pas interchangeables avec les nouvelles.

-12345-56781 (N° de pieces) : indique que les anciennes et nouvelles pièces sont interchangeables les unes avec les autres et sont utilisables chacune.

3. PIECES INTERNES DE L'ASSEMBLAGE

Les numéros de pièces qui comportent un point (.) avant la désignation de pièce détachée indique la pièce interne se rapportant à l'assemblage.

4. AVIS DE MODIFICATION

Un bulletin de pièces détachées vous sera envoyé à tout moment opportun quand des changements de pièces ont lieu, y compris les modifications de pièces interchangeables entre les nouvelles et anciennes pièces.

5. A NOTER

5-1. Il existe certaines pièces différentes de celles de rechange pour les modèles de production vu des raisons administratives et dont l'usage est commun avec celles d'autres modèles.

5-2. Concernant les durites en caoutchouc et les tuyaux en vinyle, ne pas manquer de les couper à la bonne longueur comme indiqué dans le catalogue des pièces détachées ou selon ce qui est utile pour le véhicule affecté.

5-3. Noter que les dessins à la page d'illustration servent à titre de référence pour les numéros de pièces détachées, et non pas comme référence pour l'assemblage. Pour cette dernière opération, se reporter au "MANUEL D'ENTRETIEN SUZUKI".

6. NOM DU MODELE / NUMERO DE SERIE DU MOTEUR

MODELE	DESTINATION	TYPE	HOUTEUR DE BARRE D' ARCASSE	COULEUR	N° DELA MOTEUR
DF70AT_020	E01, E40	07003F	L, X	YAY, Y5S	07003F-040001~
DF70AT_020	E03	07003F	L, X	YAY, Y5S	07003F-040001~
DF70AT_021	E11, E40	07003F	L, X	YAY, QTN	07003F-140001~
DF70ATH_020	E01	07003F	L	YAY	07003F-040001~
DF70ATH_020	E40	07003F	L, X	YAY	07003F-040001~
DF70ATH_021	E11	07003F	L	YAY	07003F-140001~
DF80AT_020	E01, E40	08002F	L, X	YAY	08002F-040001~
DF80AT_021	E01, E40	08002F	L, X	YAY	08002F-140001~
DF90AT_020	E01, E40	09003F	L, X	YAY, Y5S	09003F-040001~
DF90AT_020	E03	09003F	L, X	YAY, Y5S	09003F-040001~
DF90AT_021	E11, E40	09003F	L, X	YAY, QTN	09003F-140001~

MODELE	DESTINATION	TYPE	HOUTEUR DE BARRE D' ARCASSE	COULEUR	N° DELA MOTEUR
DF90ATH_020	E01	09003F	L	YAY	09003F-040001~
DF90ATH_020	E40	09003F	L, X	YAY	09003F-040001~
DF90ATH_021	E11	09003F	L	YAY	09003F-140001~
DF90ATH_021	E40	09003F	L, X	YAY	09003F-140001~
DF90AWQH_021	E40	09003F	L, X	YAY	09003F-140001~
DF100BT_020	E01, E40	10004F	L, X	YAY, Y5S	10004F-040001~
DF100BT_021	E01, E40	10004F	L, X	YAY, QTN	10004F-140001~

[illegible][illegible]

MILLIMETER → INCH CONVERSION CHART


	0	1	2	3	4	5	6	7	8	9
00	.000	.039	.079	.118	.157	.197	.236	.276	.315	.354
10	.394	.433	.472	.512	.551	.591	.630	.669	.709	.748
20	.787	.827	.866	.906	.945	.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.535
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.214	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.031	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

How to read

	0	1	2	3	4
00	...	...	...	...	...
10	...	...	...	...	...
20	...	...	...	0.906	...
30	...	...	...	...	...


23 millimeters equal 0.906 inch

FIG.111A




DEFAULET, 121, 111A
TURNED HEAD

FIG.111B




DEFAULET, 121, 111B
TURNED HEAD

FIG.111C




DEFAULET, 121, 111C
TURNED HEAD

FIG.113A




DEFAULET, 121, 113A
TURNED HEAD

FIG.116A




DEFAULET, 121, 116A
CRANKSHAFT

FIG.119A




DEFAULET, 121, 119A
TURNING CHAIN

FIG.121A




DEFAULET, 121, 121A
CRANKSHAFT

FIG.121B




DEFAULET, 121, 121B
CRANKSHAFT

FIG.121C




DEPMLE1/L 02/L 021C
CRANKSHAFT

FIG.122A




DEPMLE1/L 02/L 022A
PISTON AND PIN

FIG.134A




DEPMLE1/L 02/L 034A
VALVE PIN

FIG.136A




DEPMLE1/L 02/L 036A
CRANKSHAFT COVER

FIG.140A




DEPMLE1/L 02/L 140A
CRANKSHAFT COVER

FIG.143A




DEPMLE1/L 02/L 143A
FUEL INJECTION SEPARATOR

FIG.143B



DEPMLE1/L 02/L 143B
FUEL INJECTION SEPARATOR

FIG.144A



DEPMLE1/L 02/L 144A
FUEL INJECTION SEPARATOR

FIG. 144B



DESIGN ET 021 1419
FUEL INJECTOR

FIG. 146A



DF304L E1L 021 146N
FUEL PUMP

FIG. 146B



DFN04E1L 02L 1403
FUEL PUMP

FIG. 146C



DF504, ETL 02L 140C
FUEL PUMP

FIG. 160A



DESIGN ET 021 1004
WATER PUMP

FIG. 160B



DFN04_E11_021_1029
WATER PUMP

FIG. 160C




DFN04_E11_021_180C
WATER PUMP

FIG. 162A




DFN04_E11_021_1624
THERMOSTAT

FIG.163A




DEFAILET L 02L 163A
CLV/CTE/2007

FIG.175A




DEFAILET L 02L 175A
CLV/CTE/2007

FIG.180A




DEFAILET L 02L 180A
CLV/CTE/2007

FIG.204A




DEFAILET L 02L 204A
CLV/CTE/2007

FIG.206A




DEFAILET L 02L 206A
CLV/CTE/2007

FIG.220A




DEFAILET L 02L 220A
CLV/CTE/2007

FIG.301A




DEFAILET L 02L 301A
CLV/CTE/2007

FIG.303A




DEFAILET L 02L 303A
CLV/CTE/2007

FIG.326B




DFRMLE1/L1/L1_3382
PTT SWITCH/ENGINE CONTROL UNIT

FIG.331A




DFRMLE1/L1/L1_3314
NET LOSS START

FIG.335A




DFRMLE1/L1/L1_3354
CLASP BRACKET

FIG.335B




DFRMLE1/L1/L1_3352
CLASP BRACKET

FIG.336A




DFRMLE1/L1/L1_3364
TRUNK BRACKET

FIG.336B




DFRMLE1/L1/L1_3362
TRUNK BRACKET

FIG.336C




DFRMLE1/L1/L1_336C
TRUNK BRACKET

FIG.337A




DFRMLE1/L1/L1_3374
TRUNK CYLINDER

FIG.339A




DFBML E1 L 021 339A
CRACKED SHAFT

FIG.340A




DFBML E1 L 021 340A
FTT 340002

FIG.401A




DFBML E1 L 021 401A
ENGINE 40125

FIG.405A




DFBML E1 L 021 405A
CRACKED SHAFT 4052502

FIG.405B




DFBML E1 L 021 405B
CRACKED SHAFT 4052502

FIG.407A




DFBML E1 L 021 407A
GEAR CASE

FIG.407B




DFBML E1 L 021 407B
GEAR CASE

FIG.407C




DFBML E1 L 021 407C
GEAR CASE

FIG.407D




DEFAILLI L'AZL 407D
SIDE COVER

FIG.407E




DEFAILLI L'AZL 407E
SIDE COVER

FIG.410A




DEFAILLI L'AZL 410A
SIDE COVER

FIG.410B




DEFAILLI L'AZL 410B
SIDE COVER

FIG.410C




DEFAILLI L'AZL 410C
SIDE COVER

FIG.420A




DEFAILLI L'AZL 420A
EXTERNAL COVER

FIG.420B




DEFAILLI L'AZL 420B
EXTERNAL COVER

FIG.420C




DEFAILLI L'AZL 420C
EXTERNAL COVER

FIG.420D




09RM1E71, 021, 420D
ENGINE COVER

FIG.420E




09RM1E71, 021, 420E
ENGINE COVER

FIG.420F




09RM1E71, 021, 420F
ENGINE COVER

FIG.420G




09RM1E71, 021, 420G
ENGINE COVER

FIG.420H




09RM1E71, 021, 420H
ENGINE COVER

FIG.420J




09RM1E71, 021, 420J
ENGINE COVER

FIG.432A




09RM1E71, 021, 432A
FUEL TANK

FIG.442A




09RM1E71, 021, 442A
CRANKCASE

FIG.442B




DEPMLEY L 02L 442B
SQUIGLON

FIG.444A




DEPMLEY L 02L 444A
TELECYMABLE

FIG.444B




DEPMLEY L 02L 444B
TELECYMABLE

FIG.460A




DEPMLEY L 02L 460A
METEG

FIG.475A




DEPMLEY L 02L 475A
SQUEEZE PUMP

FIG.501A




DEPMLEY L 02L 501A
OPTIMETER

FIG.501B




DEPMLEY L 02L 501B
OPTIMETER

FIG.507A




DEPMLEY L 02L 507A
OPTIMETER PRESSURE GAUGE SLOXIT

FIG.508A




DFRML1/L12L S104
OPTI-REMOTE CONTROL

FIG.508B




DFRML1/L12L S102
OPTI-REMOTE CONTROL

FIG.517A




DFRML1/L12L S174
OPTI-CONSIGLED REMCON (1)

FIG.518A




DFRML1/L12L S184
OPTI-CONSIGLED REMCON (2)

FIG.519A




DFRML1/L12L S184
OPTI-REMOTE CONTROL SPACER

FIG.521A




DFRML1/L12L S114
OPTI-HARNISS

FIG.521B




DFRML1/L12L S119
OPTI-HARNISS

FIG.521C




DFRML1/L12L S11C
OPTI-HARNISS

FIG.530A




DFRM1E1L02L804
OPTIC/START

FIG.535A




DFRM1E1L02L804
OPTIC/LESS START

FIG.544A




DFRM1E1L02L804
OPTIC/NOTE CONTROL ASSY SINGLE(1)

FIG.545A




DFRM1E1L02L804
OPTIC/NOTE CONTROL ASSY SINGLE(2)

FIG.570A




DFRM1E1L02L804
OPTIC/LEVER HANDLE

FIG.585A




DFRM1E1L02L804
OPTIC/GARRET SET

FIG.600A




DFRM1E1L02L804
OPTIC/ALL FUNCTION GAUGE

FIG.601A




DFRM1E1L02L804
OPTIC/ALL FUNCTION GAUGE (1)

FIG.602A



DETAILED VIEW 602A
OPTICAL FIBER CABLE ASSEMBLY (3)

FIG.602B



DETAILED VIEW 602B
OPTICAL FIBER CABLE ASSEMBLY (3)

FIG.111A




FIG.111A (1-B-2) CYLINDER HEAD (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-87L11	HEAD ASSY, CYLINDER	1	
2	09103-06266	.BOLT (6X40)	22	
3	09206-08001	.PIN (8X11)	18	
4	11115-73G01-001	GUIDE, VALVE (OS:0.5)	16	OPT
5	11261-93J00	COVER, PROTECTION ANODE	2	
6	09280-22019	O RING (D:1.9,ID:21.8)	2	
7	55321-87J01	ANODE, PROTECTION	2	
8	09103-06281	BOLT (6X14)	2	
9	01550-0820C	BOLT	2	
10	11117-89J00	BOLT, CRANKCASE INSIDE	10	
11	11141-87L00	GASKET, CYLINDER HEAD	1	
12	01550-08407	BOLT	5	
13	04211-13189	PIN (10.4X13X18)	2	
14	11112-96L00	PLUG, OIL VENTURI	1	
15	11382-93J00	CAP, OIL FILLER	1	
16	09280-26006	O RING (D:3.1,ID:26.4)	1	
17	11170-87L11	COVER, CYLINDER HEAD	1	
18	11189-87L00	GASKET, CYLINDER HEAD COVER	1	
19	01550-0625C	BOLT	8	
20	01550-0645C	BOLT	4	
21	11173-87L00	PLATE, BREATHER	1	
22	02112-0612A	SCREW	6	
23	09355-11165-600	HOSE (11X16X600)	1	L:600->260
24	18498-95J01	PROTECTOR, BREATHER HOSE (L:120)	1	
25	09401-15414	CLIP	2	
26	09408-00155	CLAMP	1	
27	11194-87L10	GUARD, FUEL HOSE	1	
28	01550-0620C	BOLT	2	
29	09169-06062	WASHER (6.3X17X1.6)	2	
30	09320-09016	CUSHION	2	

NOTE : (DF70A,DF70ATH,DF80A,DF90A,DF90ATH):020

FIG.111A




FIG.111A (1-B-3) CYLINDER HEAD (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	09482-00446	SPARK PLUG (DCPR6E)	4	NGK

NOTE : (DF70A,DF70ATH,DF80A,DF90A,DF90ATH):020

- DF70A E01
- DF70A E03
- DF70A E40
- DF70ATH E01
- DF70ATH E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E40
- DF90ATH E01
- DF90ATH E40

FIG.111B




FIG.111B (1-B-4) CYLINDER HEAD (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-87L11	HEAD ASSY, CYLINDER	1	
2	09103-06266	.BOLT (6X40)	22	
3	09206-08001	.PIN (8X11)	18	
4	11115-73G01-001	GUIDE, VALVE (OS:0.5)	16	OPT
5	11261-93J00	COVER, PROTECTION ANODE	2	
6	09280-22019	O RING (D:1.9,ID:21.8)	2	
7	55321-87J01	ANODE, PROTECTION	2	
8	09103-06281	BOLT (6X14)	2	
9	01550-0820C	BOLT	2	
10	11117-89J00	BOLT, CRANKCASE INSIDE	10	
11	11141-87L00	GASKET, CYLINDER HEAD	1	
12	01550-08407	BOLT	5	
13	04211-13189	PIN (10.4X13X18)	2	
14	11112-96L00	PLUG, OIL VENTURI	1	
15	11382-93J00	CAP, OIL FILLER	1	
16	09280-26006	O RING (D:3.1,ID:26.4)	1	
17	11170-87L11	COVER, CYLINDER HEAD	1	
18	11189-87L00	GASKET, CYLINDER HEAD COVER	1	
19	01550-0625C	BOLT	8	
20	01550-0645C	BOLT	4	
21	11173-87L00	PLATE, BREATHER	1	
22	02112-0612A	SCREW	6	
23	09355-11165-600	HOSE (11X16X600)	1	L:600->260
24	18498-95J01	PROTECTOR, BREATHER HOSE (L:120)	1	
25	09401-15414	CLIP	2	
26	09408-00155	CLAMP	1	
27	11194-87L20	GUARD, FUEL HOSE	1	
28	01550-0620C	BOLT	3	
29	09169-06062	WASHER (6.3X17X1.6)	3	
30	09320-09016	CUSHION	3	

NOTE : (DF70A,DF70ATH,DF80A,DF90A,DF90ATH):021

FIG.111B




FIG.111B (1-B-5) CYLINDER HEAD (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	09482-00446	SPARK PLUG (DCPR6E)	4	NGK

NOTE : (DF70A,DF70ATH,DF80A,DF90A,DF90ATH):021

- DF70A E11
- DF70A E40
- DF70ATH E11
- DF80A E01
- DF80A E40
- DF90A E11
- DF90A E40
- DF90ATH E11
- DF90ATH E40

FIG.111C




FIG.111C (1-B-6) CYLINDER HEAD (DF90AWQH,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-87L11	HEAD ASSY, CYLINDER	1	
2	09103-06266	.BOLT (6X40)	22	
3	09206-08001	.PIN (8X11)	18	
4	11115-73G01-001	GUIDE, VALVE (OS:0.5)	16	OPT
5	11261-93J00	COVER, PROTECTION ANODE	2	
6	09280-22019	O RING (D:1.9,ID:21.8)	2	
7	55321-87J01	ANODE, PROTECTION	2	
8	09103-06281	BOLT (6X14)	2	
9	01550-0820C	BOLT	2	
10	11117-89J00	BOLT, CRANKCASE INSIDE	10	
11	11141-87L00	GASKET, CYLINDER HEAD	1	
12	01550-08407	BOLT	5	
13	04211-13189	PIN (10.4X13X18)	2	
14	11112-96L00	PLUG, OIL VENTURI	1	
15	11382-93J00	CAP, OIL FILLER	1	
16	09280-26006	O RING (D:3.1,ID:26.4)	1	
17	11170-87L11	COVER, CYLINDER HEAD	1	
18	11189-87L00	GASKET, CYLINDER HEAD COVER	1	
19	01550-0625C	BOLT	8	
20	01550-0645C	BOLT	4	
21	11173-87L00	PLATE, BREATHER	1	
22	02112-0612A	SCREW	6	
23	09355-11165-600	HOSE (11X16X600)	1	L:600->260
24	18498-95J01	PROTECTOR, BREATHER HOSE (L:120)	1	
25	09401-15414	CLIP	2	
26	09408-00155	CLAMP	1	
27	11194-87L20	GUARD, FUEL HOSE	1	
28	01550-0620C	BOLT	3	
29	09169-06062	WASHER (6.3X17X1.6)	3	
30	09320-09016	CUSHION	3	

FIG.111C





FIG.111C (1-B-7) CYLINDER HEAD (DF90AWQH,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	09482-00446	SPARK PLUG (DCPR6E)	4	NGK

DF90AWQH E40
DF100B E01
DF100B E40

DF90A_E11_021_113A
CYLINDER BLOCK



DF90A_E11_021

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11291-87L00	HOOK, ENGINE	1	
2	01550-0820C	BOLT	2	
3	11300-87L11	BLOCK ASSY, CYLINDER	1	
4	11117-90J10	.BOLT, CRANKCASE	10	
5	11216-90J10	.GASKET, OIL GALLERY PLUG	3	
6	09248-18011	.PLUG (18X8)	1	
7	09248-18014	.PLUG (18X8)	2	
8	11118-98J02	.PLUG	1	
9	09206-13019	.PIN (10.4X13X16)	5	
10	01550-08407	.BOLT	10	
11	09401-15414	CLIP	1	
12	11223-87L00	PIPE, BREATHER	1	
13	01550-0612C	BOLT	2	
14	11224-87L00	HOSE, BREATHER NO.2	1	

DF90A_E11_021_116A
CRANKSHAFT



DF90A_E11_021

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12111-87L01	PISTON	4	
2	12140-87L01	RING SET, PISTON	4	
3	12151-54A50	PIN, PISTON	4	
4	09381-18002	CIRCLIP	8	
5	12160-87L10	CONNROD ASSY	4	
6	04221-04089	.PIN (4X11.2)	8	
7-1	12100-69830-0A0	BEARING SET, CONNROD GREEN (T:1.5)	4	GREEN
7-2	12100-69830-0B0	BEARING SET, CONNROD BLACK (T:1.5)	4	BLACK
7-3	12100-69830-0C0	BEARING SET, CONNROD NON (T:1.5)	4	NON
7-4	12100-69830-0D0	BEARING SET, CONNROD YELLOW (T:1.5)	4	YELLOW
7-5	12100-69830-0E0	BEARING SET, CONNROD BLUE (T:1.5)	4	BLUE
7-6	12100-69830-025	BEARING SET, CONNROD RED (US:0.25)	4	RED,OPT
8	12220-87L00	CRANKSHAFT	1	
9-1	12340-57K02-0C0	BEARING SET, CRANK GREEN (T:2)	5	GREEN
9-2	12340-57K02-0D0	BEARING SET, CRANK BLACK (T:2)	5	BLACK
9-3	12340-57K02-0E0	BEARING SET, CRANK NON (T:2)	5	NON
9-4	12340-57K02-0A0	BEARING SET, CRANK PURPLE (T:2)	5	PURPLE
9-5	12340-57K02-0B0	BEARING SET, CRANK BROWN (T:2)	5	BROWN
9-6	12300-57820-0AA	BEARING SET, CRANK RED/PURPLE (US:0.25)	5	RED/PURPLE,OPT
9-7	12300-57820-0BA	BEARING SET, CRANK RED/BROWN (US:0.25)	5	RED/BROWN,OPT
9-8	12300-57820-0CA	BEARING SET, CRANK RED/GREEN (US:0.25)	5	RED/GREEN,OPT
9-9	12300-57820-0DA	BEARING SET, CRANK RED/BLACK (US:0.25)	5	RED/BLACK,OPT
9-10	12300-57820-0EA	BEARING SET, CRANK RED (US:0.25)	5	RED,OPT

FIG.116A




FIG.116A (1-B-10) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
10	12300-78890	BEARING SET, CRANK THRUST (T:2.5)	1	
11	12300-78890-012	BEARING SET, CRANK THRUST (OS:0.125)	1	OPT
12	09283-52006	OIL SEAL (52X70X10)	1	
13	12100-87L02-050	PISTON SET (OS:0.50)	4	OPT
14	12140-87L01-050	.RING SET, PISTON OS (OS:0.5)	4	OPT

FIG.119A




FIG.119A (1-B-11) TIMING CHAIN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12730-87L00	GEAR, DRIVEN (NT:36)	1	
2	09262-32023	BEARING (32X58X13)	1	
3	09262-35070	BEARING (35X62X14)	1	
4	12761-87L00	CHAIN, TIMING	1	
5	12771-87L00	GUIDE, TIMING CHAIN	1	
6	01550-0825A	BOLT	2	
7	12810-87L00	TENSIONER ASSY, TIMING CHAIN	1	
8	12813-73G00	.PAD, TIMING CHAIN TENSIONER	1	
9	01550-0835A	BOLT (8X35)	1	
10	12812-90J00	SPACER, TIMING CHAIN TENSIONER	1	
11	12831-93J01	ADJUSTER ASSY, TENSIONER NO.1	1	
12	01550-0620A	BOLT	2	



FIG.121A




FIG.121A (1-B-12) CAMSHAFT (DF70A,DF70ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12701-87L20	CAMSHAFT, INTK	1	
2	12705-87L00	CAMSHAFT, EXH	1	
3	12741-90J01	SPROCKET, CAMSHAFT TIMING (NT:29)	1	
4	12748-87L00	SPROCKET, EXH CAMSHAFT (NT:29)	1	
5	12749-93J00	BOLT, CAMSHAFT	1	
6	01550-0612A	BOLT (6X12)	3	
7	04221-05109	PIN	2	
8	12891-69J00	TAPPET	16	
9-1	12892-69J00-208	SHIM, TAPPET (T:2.08)	16	
9-2	12892-69J00-210	SHIM, TAPPET (T:2.10)	16	
9-3	12892-69J00-212	SHIM, TAPPET (T:2.12)	16	
9-4	12892-69J00-214	SHIM, TAPPET (T:2.14)	16	
9-5	12892-69J00-216	SHIM, TAPPET (T:2.16)	16	
9-6	12892-69J00-218	SHIM, TAPPET (T:2.18)	16	
9-7	12892-69J00-220	SHIM, TAPPET (T:2.20)	16	
9-8	12892-69J00-222	SHIM, TAPPET (T:2.22)	16	
9-9	12892-69J00-224	SHIM, TAPPET (T:2.24)	16	
9-10	12892-69J00-226	SHIM, TAPPET (T:2.26)	16	
9-11	12892-69J00-228	SHIM, TAPPET (T:2.28)	16	
9-12	12892-69J00-230	SHIM, TAPPET (T:2.30)	16	
9-13	12892-69J00-232	SHIM, TAPPET (T:2.32)	16	
9-14	12892-69J00-234	SHIM, TAPPET (T:2.34)	16	
9-15	12892-69J00-236	SHIM, TAPPET (T:2.36)	16	
9-16	12892-69J00-238	SHIM, TAPPET (T:2.38)	16	
9-17	12892-69J00-240	SHIM, TAPPET (T:2.40)	16	
9-18	12892-69J00-242	SHIM, TAPPET (T:2.42)	16	
9-19	12892-69J00-244	SHIM, TAPPET (T:2.44)	16	
9-20	12892-69J00-246	SHIM, TAPPET (T:2.46)	16	
9-21	12892-69J00-248	SHIM, TAPPET (T:2.48)	16	
9-22	12892-69J00-250	SHIM, TAPPET (T:2.50)	16	
9-23	12892-69J00-252	SHIM, TAPPET (T:2.52)	16	
9-24	12892-69J00-254	SHIM, TAPPET (T:2.54)	16	
9-25	12892-69J00-256	SHIM, TAPPET (T:2.56)	16	
9-26	12892-69J00-258	SHIM, TAPPET (T:2.58)	16	
9-27	12892-69J00-260	SHIM, TAPPET (T:2.60)	16	

FIG.121A




FIG.121A (1-B-13) CAMSHAFT (DF70A,DF70ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
9-28	12892-69J00-262	SHIM, TAPPET (T:2.62)	16	
9-29	12892-69J00-264	SHIM, TAPPET (T:2.64)	16	
9-30	12892-69J00-266	SHIM, TAPPET (T:2.66)	16	
9-31	12892-69J00-268	SHIM, TAPPET (T:2.68)	16	
9-32	12892-69J00-270	SHIM, TAPPET (T:2.70)	16	
9-33	12892-69J00-272	SHIM, TAPPET (T:2.72)	16	
9-34	12892-69J00-274	SHIM, TAPPET (T:2.74)	16	
9-35	12892-69J00-276	SHIM, TAPPET (T:2.76)	16	
9-36	12892-69J00-278	SHIM, TAPPET (T:2.78)	16	
9-37	12892-69J00-280	SHIM, TAPPET (T:2.80)	16	
9-38	12892-69J00-282	SHIM, TAPPET (T:2.82)	16	
9-39	12892-69J00-284	SHIM, TAPPET (T:2.84)	16	
9-40	12892-69J00-286	SHIM, TAPPET (T:2.86)	16	
9-41	12892-69J00-288	SHIM, TAPPET (T:2.88)	16	
9-42	12892-69J00-290	SHIM, TAPPET (T:2.90)	16	
10	12911-87L00	VALVE, INTK	8	
11	12915-87L50	VALVE, EXH	8	
12	12921-87J11	SPRING, VALVE	16	
13	12931-78G00	RETAINER, VALVE SPRING	16	
14	12932-24400	COTTER, VALVE	32	
15	12933-51E00	SEAT, VALVE SPRING	16	
16	09289-05012	OIL SEAL (5.5X11.5X9.3)	16	

DF70A E01
DF70A E03
DF70A E11
DF70A E40
DF70ATH E01
DF70ATH E11
DF70ATH E40



FIG.121B




FIG.121B (1-B-14) CAMSHAFT (DF80A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12701-87L00	CAMSHAFT, INTK	1	
2	12705-87L00	CAMSHAFT, EXH	1	
3	12741-90J01	SPROCKET, CAMSHAFT TIMING (NT:29)	1	
4	12748-87L00	SPROCKET, EXH CAMSHAFT (NT:29)	1	
5	12749-93J00	BOLT, CAMSHAFT	1	
6	01550-0612A	BOLT (6X12)	3	
7	04221-05109	PIN	2	
8	12891-69J00	TAPPET	16	
9-1	12892-69J00-208	SHIM, TAPPET (T:2.08)	16	
9-2	12892-69J00-210	SHIM, TAPPET (T:2.10)	16	
9-3	12892-69J00-212	SHIM, TAPPET (T:2.12)	16	
9-4	12892-69J00-214	SHIM, TAPPET (T:2.14)	16	
9-5	12892-69J00-216	SHIM, TAPPET (T:2.16)	16	
9-6	12892-69J00-218	SHIM, TAPPET (T:2.18)	16	
9-7	12892-69J00-220	SHIM, TAPPET (T:2.20)	16	
9-8	12892-69J00-222	SHIM, TAPPET (T:2.22)	16	
9-9	12892-69J00-224	SHIM, TAPPET (T:2.24)	16	
9-10	12892-69J00-226	SHIM, TAPPET (T:2.26)	16	
9-11	12892-69J00-228	SHIM, TAPPET (T:2.28)	16	
9-12	12892-69J00-230	SHIM, TAPPET (T:2.30)	16	
9-13	12892-69J00-232	SHIM, TAPPET (T:2.32)	16	
9-14	12892-69J00-234	SHIM, TAPPET (T:2.34)	16	
9-15	12892-69J00-236	SHIM, TAPPET (T:2.36)	16	
9-16	12892-69J00-238	SHIM, TAPPET (T:2.38)	16	
9-17	12892-69J00-240	SHIM, TAPPET (T:2.40)	16	
9-18	12892-69J00-242	SHIM, TAPPET (T:2.42)	16	
9-19	12892-69J00-244	SHIM, TAPPET (T:2.44)	16	
9-20	12892-69J00-246	SHIM, TAPPET (T:2.46)	16	
9-21	12892-69J00-248	SHIM, TAPPET (T:2.48)	16	
9-22	12892-69J00-250	SHIM, TAPPET (T:2.50)	16	
9-23	12892-69J00-252	SHIM, TAPPET (T:2.52)	16	
9-24	12892-69J00-254	SHIM, TAPPET (T:2.54)	16	
9-25	12892-69J00-256	SHIM, TAPPET (T:2.56)	16	
9-26	12892-69J00-258	SHIM, TAPPET (T:2.58)	16	
9-27	12892-69J00-260	SHIM, TAPPET (T:2.60)	16	

FIG.121B




FIG.121B (1-B-15) CAMSHAFT (DF80A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
9-28	12892-69J00-262	SHIM, TAPPET (T:2.62)	16	
9-29	12892-69J00-264	SHIM, TAPPET (T:2.64)	16	
9-30	12892-69J00-266	SHIM, TAPPET (T:2.66)	16	
9-31	12892-69J00-268	SHIM, TAPPET (T:2.68)	16	
9-32	12892-69J00-270	SHIM, TAPPET (T:2.70)	16	
9-33	12892-69J00-272	SHIM, TAPPET (T:2.72)	16	
9-34	12892-69J00-274	SHIM, TAPPET (T:2.74)	16	
9-35	12892-69J00-276	SHIM, TAPPET (T:2.76)	16	
9-36	12892-69J00-278	SHIM, TAPPET (T:2.78)	16	
9-37	12892-69J00-280	SHIM, TAPPET (T:2.80)	16	
9-38	12892-69J00-282	SHIM, TAPPET (T:2.82)	16	
9-39	12892-69J00-284	SHIM, TAPPET (T:2.84)	16	
9-40	12892-69J00-286	SHIM, TAPPET (T:2.86)	16	
9-41	12892-69J00-288	SHIM, TAPPET (T:2.88)	16	
9-42	12892-69J00-290	SHIM, TAPPET (T:2.90)	16	
10	12911-87L00	VALVE, INTK	8	
11	12915-87L50	VALVE, EXH	8	
12	12921-87J11	SPRING, VALVE	16	
13	12931-78G00	RETAINER, VALVE SPRING	16	
14	12932-24400	COTTER, VALVE	32	
15	12933-51E00	SEAT, VALVE SPRING	16	
16	09289-05012	OIL SEAL (5.5X11.5X9.3)	16	

DF80A E01
DF80A E40



FIG.121C




FIG.121C (1-C-2) CAMSHAFT (DF90A,DF90ATH,DF90AWQH,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12701-87L10	CAMSHAFT, INTK	1	
2	12705-87L10	CAMSHAFT, EXH	1	
3	12741-90J01	SPROCKET, CAMSHAFT TIMING (NT:29)	1	
4	12748-87L00	SPROCKET, EXH CAMSHAFT (NT:29)	1	
5	12749-93J00	BOLT, CAMSHAFT	1	
6	01550-0612A	BOLT (6X12)	3	
7	04221-05109	PIN	2	
8	12891-69J00	TAPPET	16	
9-1	12892-69J00-208	SHIM, TAPPET (T:2.08)	16	
9-2	12892-69J00-210	SHIM, TAPPET (T:2.10)	16	
9-3	12892-69J00-212	SHIM, TAPPET (T:2.12)	16	
9-4	12892-69J00-214	SHIM, TAPPET (T:2.14)	16	
9-5	12892-69J00-216	SHIM, TAPPET (T:2.16)	16	
9-6	12892-69J00-218	SHIM, TAPPET (T:2.18)	16	
9-7	12892-69J00-220	SHIM, TAPPET (T:2.20)	16	
9-8	12892-69J00-222	SHIM, TAPPET (T:2.22)	16	
9-9	12892-69J00-224	SHIM, TAPPET (T:2.24)	16	
9-10	12892-69J00-226	SHIM, TAPPET (T:2.26)	16	
9-11	12892-69J00-228	SHIM, TAPPET (T:2.28)	16	
9-12	12892-69J00-230	SHIM, TAPPET (T:2.30)	16	
9-13	12892-69J00-232	SHIM, TAPPET (T:2.32)	16	
9-14	12892-69J00-234	SHIM, TAPPET (T:2.34)	16	
9-15	12892-69J00-236	SHIM, TAPPET (T:2.36)	16	
9-16	12892-69J00-238	SHIM, TAPPET (T:2.38)	16	
9-17	12892-69J00-240	SHIM, TAPPET (T:2.40)	16	
9-18	12892-69J00-242	SHIM, TAPPET (T:2.42)	16	
9-19	12892-69J00-244	SHIM, TAPPET (T:2.44)	16	
9-20	12892-69J00-246	SHIM, TAPPET (T:2.46)	16	
9-21	12892-69J00-248	SHIM, TAPPET (T:2.48)	16	
9-22	12892-69J00-250	SHIM, TAPPET (T:2.50)	16	
9-23	12892-69J00-252	SHIM, TAPPET (T:2.52)	16	
9-24	12892-69J00-254	SHIM, TAPPET (T:2.54)	16	
9-25	12892-69J00-256	SHIM, TAPPET (T:2.56)	16	
9-26	12892-69J00-258	SHIM, TAPPET (T:2.58)	16	
9-27	12892-69J00-260	SHIM, TAPPET (T:2.60)	16	



FIG.121C




FIG.121C (1-C-3) CAMSHAFT (DF90A,DF90ATH,DF90AWQH,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
9-28	12892-69J00-262	SHIM, TAPPET (T:2.62)	16	
9-29	12892-69J00-264	SHIM, TAPPET (T:2.64)	16	
9-30	12892-69J00-266	SHIM, TAPPET (T:2.66)	16	
9-31	12892-69J00-268	SHIM, TAPPET (T:2.68)	16	
9-32	12892-69J00-270	SHIM, TAPPET (T:2.70)	16	
9-33	12892-69J00-272	SHIM, TAPPET (T:2.72)	16	
9-34	12892-69J00-274	SHIM, TAPPET (T:2.74)	16	
9-35	12892-69J00-276	SHIM, TAPPET (T:2.76)	16	
9-36	12892-69J00-278	SHIM, TAPPET (T:2.78)	16	
9-37	12892-69J00-280	SHIM, TAPPET (T:2.80)	16	
9-38	12892-69J00-282	SHIM, TAPPET (T:2.82)	16	
9-39	12892-69J00-284	SHIM, TAPPET (T:2.84)	16	
9-40	12892-69J00-286	SHIM, TAPPET (T:2.86)	16	
9-41	12892-69J00-288	SHIM, TAPPET (T:2.88)	16	
9-42	12892-69J00-290	SHIM, TAPPET (T:2.90)	16	
10	12911-87L00	VALVE, INTK	8	
11	12915-87L50	VALVE, EXH	8	
12	12921-87J11	SPRING, VALVE	16	
13	12931-78G00	RETAINER, VALVE SPRING	16	
14	12932-24400	COTTER, VALVE	32	
15	12933-51E00	SEAT, VALVE SPRING	16	
16	09289-05012	OIL SEAL (5.5X11.5X9.3)	16	

- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF90ATH E01
- DF90ATH E11
- DF90ATH E40
- DF90AWQH E40
- DF100B E01
- DF100B E40



FIG.122A




FIG.122A (1-C-4) INTAKE MANIFOLD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-87L00	MANIFOLD, INTAKE	1	
2	13119-87L00	.GASKET, INTAKE MANIFOLD	4	
3	13125-87L00	.GASKET, THROTTLE BODY	1	
4	01421-08257	STUD BOLT	2	
5	01550-0830C	BOLT	4	
6	01550-0845C	BOLT	1	
7	08316-1008C	NUT	2	
8	18137-87L02	VALVE, IAC	1	
9	02112-34167	SCREW	3	

FIG.134A




FIG.134A (1-C-5) SILENCER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13710-99E00	ARRESTER, FLAME	1	
2	13810-87L00	SILENCER	1	
3	13813-87L01	HOLDER, FLAME ARRESTER	1	
4	09116-06215	BOLT (6X30)	2	
5	09169-06075	WASHER	2	
6	09320-09059	CUSHION	2	

FIG.136A




FIG.136A (1-C-6) RING GEAR COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11510-87L03	COVER, RING GEAR	1	
2	01550-0630C	BOLT	4	
3	09320-09016	CUSHION	1	
4	03542-06209	SCREW	2	
5	11514-87L00	PLATE, RING GEAR COVER	1	
6	61472-88L01	LABEL, MAG COVER	1	
7	69711-93E11	LABEL, S.I.G.P	1	
8	61494-87L02	LABEL, OIL & CLEARANCE	1	

FIG.140A




FIG.140A (1-C-7) EXHAUST COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	14141-87L00	COVER, EXHAUST	1	
2	14151-87L00	GASKET, EXH COVER	1	
3	01550-06307	BOLT	9	
4	11261-93J00	COVER, PROTECTION ANODE	1	
5	09280-22019	O RING (D:1.9,ID:21.8)	1	
6	55321-87J01	ANODE, PROTECTION	1	
7	09103-06281	BOLT (6X14)	1	
8	01550-0820C	BOLT	1	



FIG.143A




FIG.143A (1-C-8) FUEL VAPOR SEPARATOR (E01,E03,E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15600-92J40	SEPARATOR ASSY, FUEL VAPOR	1	
2	13370-88L00	.VALVE ASSY, NEEDLE	1	
3	15200-92J20	.PUMP ASSY, FUEL	1	
4	15626-92J01	.SEAL	1	
5	15628-99E00	.SCREW (L:15)	5	
6	15629-99E10	.SCREW, DRAIN	1	
7	15641-88L00	.SPACER	1	
8	15642-88L00	.FILTER ASSY	1	
9	15650-99E00	.FLOAT	1	
10	15654-88L00	.PIN	1	
11	15683-87J00	.HOSE (L:120)	1	
12	15760-88L00	.REGULATOR ASSY	1	
13	15644-88L00	.O RING	1	
14	15645-88L00	.HOLDER, REGULATOR	1	
15	02112-0408A	.SCREW	1	
16	15648-92J00	.RING	1	
17	15643-88L10	.JOINT	1	
18	15641-88L31	.BUSH	1	
19	15641-88L51	.BUSH	1	
20	15642-88L10	.FILTER	1	
21	15612-88L00	.COVER, VAPOR SEPARATOR	1	
22	15613-88L00	.O RING	1	
23	15614-88L00	.SCREW	3	
24	02142-0408B	.SCREW	1	
25	15613-92J00	.GASKET	1	
26	15620-92J00	.CASE ASSY, VAPOR SEPARATOR UPR	1	UPPER
27	15610-92J00	.CASE ASSY, VAPOR SEPARATOR LWR	1	LOWER
28	09116-06217	BOLT (6X30)	3	
29	09169-06090	WASHER	3	
30	15691-92J00	CUSHION, FUEL VAPOR SEPARATOR	3	
31	09352-50003-490	HOSE (5X8.2X490)	1	
32	09401-08412	CLIP	1	
33	18498-99E01	PROTECTOR, HOSE (9.5X11.5X390)	1	
34	09403-12324	CLAMP	1	

FIG.143A




FIG.143A (1-C-9) FUEL VAPOR SEPARATOR (E01,E03,E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	01550-0612C	BOLT	1	
36	55127-87D00	UNION, SPEEDOMETER HOSE	1	

- DF70A E01
- DF70A E03
- DF70A E11
- DF70ATH E01
- DF70ATH E11
- DF80A E01
- DF90A E01
- DF90A E03
- DF90A E11
- DF90ATH E01
- DF90ATH E11
- DF100B E01

FIG.143B




FIG.143B (1-C-10) FUEL VAPOR SEPARATOR (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15600-92J50	SEPARATOR ASSY, FUEL VAPOR	1	
2	13370-88L10	.VALVE ASSY, NEEDLE	1	
3	15200-92J30	.PUMP ASSY, FUEL	1	
4	15626-92J10	.SEAL	1	
5	15628-99E00	.SCREW (L:15)	5	
6	15629-99E10	.SCREW, DRAIN	1	
7	15641-88L10	.SPACER	1	
8	15642-88L00	.FILTER ASSY	1	
9	15650-99E00	.FLOAT	1	
10	15654-88L00	.PIN	1	
11	15683-87J00	.HOSE (L:120)	1	
12	15760-88L00	.REGULATOR ASSY	1	
13	15644-88L10	.O RING	1	
14	15645-88L00	.HOLDER, REGULATOR	1	
15	13614-89J00	.SCREW	1	
16	13614-93J00	.SCREW	1	
17	15643-88L10	.JOINT	1	
18	15641-88L31	.BUSH	1	
19	15641-88L51	.BUSH	1	
20	15642-88L10	.FILTER	1	
21	15612-88L00	.COVER, VAPOR SEPARATOR	1	
22	15613-88L00	.O RING	1	
23	15614-88L00	.SCREW	3	
24	15648-92J00	.RING	1	
25	15613-92J00	.GASKET	1	
26	15620-92J10	.CASE ASSY, VAPOR SEPARATOR UPR	1	UPPER
27	15610-92J00	.CASE ASSY, VAPOR SEPARATOR LWR	1	LOWER
28	09116-06217	BOLT (6X30)	3	
29	09169-06090	WASHER	3	
30	15691-92J00	CUSHION, FUEL VAPOR SEPARATOR	3	
31	09352-50003-490	HOSE (5X8.2X490)	1	
32	09401-08412	CLIP	1	
33	18498-99E01	PROTECTOR, HOSE (9.5X11.5X390)	1	
34	09403-12324	CLAMP	1	

FIG.143B




FIG.143B (1-C-11) FUEL VAPOR SEPARATOR (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	01550-0612C	BOLT	1	
36	55127-87D00	UNION, SPEEDOMETER HOSE	1	

DF70A E40
DF70ATH E40
DF80A E40
DF90A E40
DF90ATH E40
DF90AWQH E40
DF100B E40

FIG.144A




FIG.144A (1-C-12) FUEL INJECTOR (E01,E03,E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-92J01	HOSE, FUEL	1	
2	15710-82K50	INJECTOR ASSY, FUEL	4	
3	15716-65DT0	.GROMMET SET, FUEL INJECTOR	4	
4	15750-87L30	PIPE, DELIVERY	1	
5	15830-87L30	.JOINT, FUEL MAIN	1	
6	09103-06281	.BOLT (6X14)	1	
7	09280-08012	.O RING (D:1.9,ID:7.8)	1	
8	18498-87J51	PROTECTOR, EVAP HOSE (L:160)	1	
9	09320-08062	CUSHION (8.7X16.3X5.5)	4	
10	09401-11425	CLIP	2	
11	09408-00233	CLAMP	1	
12	01550-0825C	BOLT	2	

- DF70A E01
- DF70A E03
- DF70A E11
- DF70ATH E01
- DF70ATH E11
- DF80A E01
- DF90A E01
- DF90A E03
- DF90A E11
- DF90ATH E01
- DF90ATH E11
- DF100B E01



FIG.144B





FIG.144B (1-C-13) FUEL INJECTOR (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-92J01	HOSE, FUEL	1	
2	15710-82K50	INJECTOR ASSY, FUEL	4	
3	15716-65DT0	.GROMMET SET, FUEL INJECTOR	4	
4	15750-87L40	PIPE, DELIVERY	1	
5	15830-87L40	.JOINT, FUEL MAIN	1	
6	09103-06281	.BOLT (6X14)	1	
7	09280-08012	.O RING (D:1.9,ID:7.8)	1	
8	18498-87J51	PROTECTOR, EVAP HOSE (L:160)	1	
9	09320-08062	CUSHION (8.7X16.3X5.5)	4	
10	09401-11425	CLIP	2	
11	09408-00233	CLAMP	1	
12	01550-0825C	BOLT	2	

- DF70A E40
- DF70ATH E40
- DF80A E40
- DF90A E40
- DF90ATH E40
- DF90AWQH E40
- DF100B E40



FIG.146A (1-C-14) FUEL PUMP (SEE NOTE)



DF70A E01
DF70A E03
DF70A E40
DF70ATH E01
DF70ATH E40
DF80A E01
DF80A E40
DF90A E01
DF90A E03
DF90A E40
DF90ATH E01
DF90ATH E40

FIG.146B


This diagram is an exploded view of a vehicle component assembly, likely a brake master cylinder. It shows the following parts and their assembly relationships:

- Main Assembly:**
 - 1:** Main body of the master cylinder.
 - 2:** Bolt for mounting the main body.
 - 3:** O-ring for the main body.
 - 4:** Reservoir housing.
 - 5:** Piston rod.
 - 6:** Piston seal.
 - 7:** Piston.
 - 8:** O-ring for the piston.
 - 9:** Mounting bracket.
 - 10:** Bolt for the mounting bracket.
 - 11:** Flexible hose.
 - 12:** Hard hose.
 - 13:** Fitting for the hard hose.
 - 14:** Hard hose.
 - 15:** Hard hose.
 - 16:** Fitting for the hard hose.
 - 17:** Mounting bracket.
 - 18:** Bolt for the mounting bracket.
 - 19:** Bolt for the mounting bracket.
 - 20:** Piston rod.
 - 21:** Fitting for the reservoir.
 - 22:** Hard hose.
 - 23:** Fitting for the hard hose.
 - 24:** Hard hose.
 - 25:** Fitting for the hard hose.
- Directional Arrow:** A black arrow pointing left with the text "FWD" (Front) inside it.

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-90J11	PUMP ASSY, FUEL	1	
2	01550-0625C	BOLT	2	
3	09280-26005	O RING (D:2.4, ID:26.2)	1	
4	15410-92J10	FILTER, FUEL	1	
5	15411-92J10	.CAP, FUEL FILTER	1	
6	15412-92J00	.FILTER, FUEL	1	
7	15413-92J00	.CASE, FUEL FILTER	1	
8	15415-92J00	.SEAL, FUEL FILTER	1	
9	15421-87L10	BRACKET, FUEL FILTER	1	
10	01550-0616C	BOLT	2	
11	15190-87L20	HOSE, FUEL INLET	1	
12	15192-87L30	HOSE, FUEL	1	
13	09343-70503-600	HOSE (7X12X600)	1	L:600->510
14	18498-96J21	PROTECTOR, FUEL HOSE (13.5X16.5X370)	1	
15	18498-99E11	PROTECTOR, FUEL HOSE (L:610)	1	L:610->450
16	09401-11423	CLIP	5	
17	15198-87L00	BRACKET, FUEL HOSE	1	
18	09403-11320	CLAMP	1	
19	01550-0612C	BOLT	1	
20	15419-92J00	CAP, JOINT	1	
21	08316-10087	NUT	1	
22	15195-87L00	HOSE, FUEL	1	
23	15831-96L00	UNION, 2 WAY FUEL HOSE	2	
24	15195-96L00	HOSE, FUEL	1	
25	09401-14409	CLIP	4	

DF100B E01
DF100B E40

FIG.146C



DF90A_E11_021_146C
FUEL PUMP

FIG.146C (1-D-3) FUEL PUMP (021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	15100-90J04	PUMP ASSY, FUEL	1	E01,E11
1-2	15100-90J11	PUMP ASSY, FUEL	1	E40
2	01550-0625C	BOLT	2	
3	09280-26005	O RING (D:2.4,ID:26.2)	1	
4	15410-92J10	FILTER, FUEL	1	
5	15411-92J10	.CAP, FUEL FILTER	1	
6	15412-92J00	.FILTER, FUEL	1	
7	15413-92J00	.CASE, FUEL FILTER	1	
8	15415-92J00	.SEAL, FUEL FILTER	1	
9	15421-87L10	BRACKET, FUEL FILTER	1	
10	01550-0616C	BOLT	2	
11	15190-87L20	HOSE, FUEL INLET	1	
12	15192-87L30	HOSE, FUEL	1	
13	09343-70503-600	HOSE (7X12X600)	1	L:600->510
14	18498-96J21	PROTECTOR, FUEL HOSE (13.5X16.5X370)	1	
15	18498-99E11	PROTECTOR, FUEL HOSE (L:610)	1	L:610->450
16	09401-11423	CLIP	5	
17	15198-87L00	BRACKET, FUEL HOSE	1	
18	09403-11320	CLAMP	1	
19	01550-0612C	BOLT	1	
20	15419-92J00	CAP, JOINT	1	
21	08316-10087	NUT	1	
22	15195-87L00	HOSE, FUEL	1	
23	15831-96L00	UNION, 2 WAY FUEL HOSE	2	
24	15195-96L00	HOSE, FUEL	1	

DF90A_E11_021

FIG.146C




FIG.146C (1-D-4) FUEL PUMP (021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25	09401-14409	CLIP	4	

- DF70A E11
- DF70A E40
- DF70ATH E11
- DF80A E01
- DF80A E40
- DF90A E11
- DF90A E40
- DF90ATH E11
- DF90ATH E40
- DF100B E01
- DF100B E40

FIG.160A




FIG.160A (1-D-5) WATER PUMP (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-99E10	CASE, WATER PUMP	1	
2-1	17461-87E12	IMPELLER, WATER PUMP	1	(E01,E03,E11):(DF70A,DF90A), E01:DF80A
2-2	17461-87L00	IMPELLER, WATER PUMP	1	E01:DF100B
3	17471-87L01	PANEL, PUMP CASE UNDER	1	
4	17472-87L00	GASKET, PUMP CASE PANEL	1	
5-1	17561-87L20	TUBE, WATER	1	W/TRANSOM(L)
5-2	17561-87L30	TUBE, WATER	1	W/TRANSOM(X)
6	17562-87L01	GROMMET, WATER TUBE UPPER	1	UPPER
7	17563-87D01	BUSH, WATER TUBE LOWER	1	LOWER
8	17564-87D00	BUSH, WATER PUMP CASE	1	
9	17631-87L00	FILTER, WATER PORT SIDE	1	PORT
10	17632-87L01	FILTER, WATER STBD SIDE	1	STBD
11	29116-93J10	BOLT	4	
12	09161-16008	WASHER (15.8X26X1.0)	2	
13	09202-06031	PIN (6X12)	2	
14	09420-04009	KEY	1	
15	09132-04034	SCREW (4X18)	1	
16	17413-99E11	SLEEVE, WATER PUMP CASE	1	
17	17416-99E11	SEALING, WATER PUMP CASE NO.1	1	
18	17400-87L04	KIT, WATER PUMP REPAIR	1	OPT

NOTE : (E01,E03,E11):(DF70A,DF90A),E01:(DF80A,DF100B)

- DF70A E01
- DF70A E03
- DF70A E11
- DF80A E01
- DF90A E01
- DF90A E03
- DF90A E11
- DF100B E01

FIG.160B




FIG.160B (1-D-6) WATER PUMP ((E01,E11):(DF70ATH,DF90ATH))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-99E10	CASE, WATER PUMP	1	
2	17461-87E12	IMPELLER, WATER PUMP	1	
3	17471-87L01	PANEL, PUMP CASE UNDER	1	
4	17472-87L00	GASKET, PUMP CASE PANEL	1	
5	17561-87L20	TUBE, WATER	1	
6	17562-87L01	GROMMET, WATER TUBE UPPER	1	UPPER
7	17563-87D01	BUSH, WATER TUBE LOWER	1	LOWER
8	17564-87D00	BUSH, WATER PUMP CASE	1	
9	17631-87L00	FILTER, WATER PORT SIDE	1	PORT
10	17632-87L01	FILTER, WATER STBD SIDE	1	STBD
11	29116-93J10	BOLT	4	
12	09161-16008	WASHER (15.8X26X1.0)	2	
13	09202-06031	PIN (6X12)	2	
14	09420-04009	KEY	1	
15	09132-04034	SCREW (4X18)	1	
16	17413-99E11	SLEEVE, WATER PUMP CASE	1	
17	17416-99E11	SEALING, WATER PUMP CASE NO.1	1	
18	17400-87L04	KIT, WATER PUMP REPAIR	1	OPT

DF70ATH E01
DF70ATH E11
DF90ATH E01
DF90ATH E11

FIG.160C




FIG.160C (1-D-7) WATER PUMP (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-99E10	CASE, WATER PUMP	1	
2-1	17461-87E12	IMPELLER, WATER PUMP	1	DF70A,DF70ATH,DF80A,DF90A,DF90ATH,DF90AWQH
2-2	17461-87L00	IMPELLER, WATER PUMP	1	DF100B
3	17471-87L11	PANEL, PUMP CASE UNDER	1	
4	17472-87L00	GASKET, PUMP CASE PANEL	1	
5-1	17561-87L20	TUBE, WATER	1	W/TRANSOM(L)
5-2	17561-87L30	TUBE, WATER	1	W/TRANSOM(X)
6	17562-87L01	GROMMET, WATER TUBE UPPER	1	UPPER
7	17563-87D01	BUSH, WATER TUBE LOWER	1	LOWER
8	17564-87D00	BUSH, WATER PUMP CASE	1	
9	17631-87L00	FILTER, WATER PORT SIDE	1	PORT
10	17632-87L01	FILTER, WATER STBD SIDE	1	STBD
11	29116-93J10	BOLT	4	
12	09161-16008	WASHER (15.8X26X1.0)	2	
13	09202-06031	PIN (6X12)	2	
14	09420-04009	KEY	1	
15	09132-04034	SCREW (4X18)	1	
16	17413-99E21	SLEEVE, WATER PUMP CASE	1	
17	17416-99E11	SEALING, WATER PUMP CASE NO.1	1	
18	17400-87L12	KIT, WATER PUMP REPAIR	1	OPT

DF70A E40
DF70ATH E40
DF80A E40
DF90A E40
DF90ATH E40
DF90AWQH E40
DF100B E40

FIG.162A




FIG.162A (1-D-8) THERMOSTAT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11196-87L00	HOSE, WATER RETURN	1	
2	17611-90J00	COVER, WTR PRESS VALVE	1	
3	17660-99E01	VALVE, WATER PRESSURE	1	
4-1	17670-90J01	THERMOSTAT (60C)	1	
4-2	17670-90J11	THERMOSTAT (71C)	1	OPT
5	17681-87L00	COVER, THERMOSTAT	1	
6	17685-87L01	SEAL, THERMOSTAT COVER	1	
7	01550-0630C	BOLT	2	
8	09116-06121	BOLT (6X25)	2	
9	09280-26006	O RING (D:3.1,ID:26.4)	1	
10	09401-26408	CLIP	2	
11	17915-87L01	HOSE, WATER FLUSH	1	
12	09401-15414	CLIP	2	
13	09352-50006-600	HOSE (5X9X600)	1	L:600->320,UNION TO COOLER
14	09352-50006-600	HOSE (5X9X600)	1	L:600->190,E/H TO SEPARATOR
15	09401-08413	CLIP	3	
16	09407-11401	CLAMP (L:95)	1	

FIG.163A




FIG.163A (1-D-9) THROTTLE BODY

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-87L11	BODY ASSY, THROTTLE	1	
2	13353-99E00	.ADJUSTER ASSY	1	
3	13354-99E00	.CAP	1	
4	13315-87L00	BRACKET, THROTTLE BODY	1	
5	01550-0650C	BOLT	2	
6	01550-0616C	BOLT	3	
7	01550-0655C	BOLT	2	
8	09160-06084	WASHER (6.5X18X1.6)	1	
9	13510-87L00	ROD, THROTTLE NO.1	1	
10	19115-87L00	HOLDER, THROTTLE LEVER	1	
11-1	19120-87L00	LEVER, THROTTLE	1	DF70A,DF80A,DF90A,DF100B
11-2	19120-87L10	LEVER, THROTTLE	1	DF70ATH,DF90ATH,DF90AWQH
12	19131-95502	CONNECTOR	1	
13	09140-05005	NUT	1	
14	09160-06046	WASHER (6.5X20X1.5)	1	
15	09180-06186	SPACER (6.2X12.6X21)	1	
16	01550-06357	BOLT (6X35)	1	
17	01550-0830C	BOLT	2	

FIG.175A




FIG.175A (1-D-10) OIL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	16400-87L00	PUMP ASSY, OIL	1	
2	09103-06220	BOLT (6X60)	4	
3	16440-99E00	VALVE ASSY, OIL RELIEF	1	
4	09168-16002	GASKET (16X22X2)	1	
5	16520-87L00	STRAINER, OIL PUMP	1	
6	09280-17002	O RING (D:2.4,ID:16.8)	2	
7	01550-0616A	BOLT (6X16)	2	
8	16519-87L00	SEAL, ENGINE HOLDER	1	
9	11241-73003	STAND, OIL FILTER	1	
10	16510-61A31	FILTER ASSY, OIL	1	
11	16531-87L00	CASE, OIL FILTER ADAPTER	1	
12	16539-87L00	GASKET, OIL FILTER ADAPTER CASE	1	
13	01550-08307	BOLT	2	
14	09246-04009	PLUG (1/8PT,H:8)	1	

FIG.180A




FIG.180A (1-D-11) OIL PAN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11489-87L00	GASKET, OIL PAN	1	
2-1	11501-87L10-YAY	PAN, OIL (BLACK)	1	FOR YAY
2-2	11501-87L10-Y5S	PAN, OIL (WHITE)	1	FOR QTN,Y5S
3-1	11541-87L00-YAY	PIPE, EXHAUST (BLACK)	1	
3-2	11541-87L00-Y5S	PIPE, EXHAUST (WHITE)	1	
3-3	11541-87L00-QTN	PIPE, EXHAUST (WHITE)	1	
4	11542-87L00	GASKET, EXHAUST TUBE	1	
5-1	11551-87L00-YAY	COVER, WATER JACKET OIL PAN (BLACK)	1	
5-2	11551-87L00-Y5S	COVER, WATER JACKET OIL PAN (WHITE)	1	
5-3	11551-87L00-QTN	COVER, WATER JACKET OIL PAN (WHITE)	1	
6	11552-87L01	GASKET, OIL PAN WTR JKT COVER	1	
7	09116-06121	BOLT (6X25)	5	
8	17913-93J00	PLUG, WATER	1	
9	17914-93J01	GASKET, WATER PLUG	1	
10	09116-08178	BOLT (8X40)	4	
11	29116-93J00	BOLT (6X20)	3	
12	29404-93J01	CLAMP	1	
13	09168-12012	GASKET (12.5X20X2.5)	1	
14	09248-12009	PLUG (12X18.65)	1	
15	09116-10129	BOLT (10X160)	6	
16	09116-10181	BOLT (10X44)	2	
17	16910-87L00	GAUGE, OIL LEVEL	1	
18	16930-87L00	GUIDE, OIL LEVEL GAUGE	1	
19	09280-09008	O RING (D:2.1,ID:8.8)	1	
20	01550-0612C	BOLT	1	

FIG.204A




FIG.204A (1-D-12) CLUTCH SHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-87L10	LEVER, CLUTCH	1	
2	21131-93J00	BUSH, CLUTCH LEVER	1	
3	21151-87L00	HOLDER, CLUTCH LEVER	1	
4	21152-87L00	PLATE, CLUTCH HOLDER	1	
5	21153-87L00	BUSH, CLUTCH LEVER	2	
6	21157-87L00	SEAL, CLUTCH HOLDER	1	
7	23115-87L00	LINK, CLUTCH LEVER	1	
8	09160-09019	WASHER (9.2X16X1)	1	
9	09204-01006	PIN	1	
10	09307-09002	BUSH	1	
11	01550-0640C	BOLT	2	
12	09116-05010	BOLT (5X12)	3	
13	21210-87L01	SHAFT, CLUTCH	1	
14	09160-09019	WASHER (9.2X16X1)	1	
15	09204-01006	PIN	1	
16	09248-12011	PLUG (12X9)	1	
17	09307-09002	BUSH	1	
18	11118-95J00	PLUG, NOTCH SPRING	1	
19	09205-10008	SPRING PIN (10.2X13)	1	
20	09260-10005	BALL	1	
21	09440-07071	SPRING	1	
22	22511-99011	NIPPLE, GREASE	1	
23	08331-41359	CIRCLIP	1	
24	67467-89J01	CONNECTOR	2	DF90AWQH
25	09160-06055	WASHER (7X12X1.0)	2	DF90AWQH
26	09385-06012	CLIP	2	DF90AWQH

FIG.206A




FIG.206A (1-D-13) CLUTCH ROD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	25111-87L01	ROD, SHIFT	1	W/TRANSOM(L)
1-2	25111-87L11	ROD, SHIFT	1	W/TRANSOM(X)
2	25131-87L01	YOKE, SHIFTER	1	
3	25232-96302	MAGNETO, GEAR CASE	2	
4	08332-1107A	E-RING	4	
5	25141-87L00	HOUSING, SHIFT ROD GUIDE	1	
6	25223-94400	SEAL, SHIFT ROD DUST	1	
7	29116-93J00	BOLT (6X20)	1	
8	09280-55006	O RING (D:3.4,ID:53.4)	1	
9	09282-08005	OIL SEAL (8X22X7)	1	



FIG.220A





FIG.220A (1-D-14) TRANSMISSION

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57110-87L21	SHAFT, DRIVE	1	W/TRANSOM(L)
1-2	57110-87L31	SHAFT, DRIVE	1	W/TRANSOM(X)
2	57133-87L01	COLLAR, DRIVE SHAFT	1	
3	09205-05011	SPRING PIN (5X14)	1	
4	09265-25046	BEARING (25X52X19.25)	1	
5	57300-87890	PINION & GEAR SET	1	
6	09263-25067	.BEARING (25X32X26)	1	
7	09265-40003	.BEARING (40X75X26)	1	
8	57500-87873	SHIM SET, DRIVE SHAFT	1	
9-1	09181-40186	.SHIM (41X52X0.50)	1	
9-2	09181-41002	.SHIM (41X52X0.55)	1	
9-3	09181-41003	.SHIM (41X52X0.6)	1	
9-4	09181-41004	.SHIM (41X52X0.65)	1	
9-5	09181-41005	.SHIM (41X52X0.7)	1	
9-6	09181-41006	.SHIM (41X52X0.75)	1	
9-7	09181-40190	.SHIM (40X52X0.8)	1	
9-8	09181-41008	.SHIM (41X52X0.85)	1	
9-9	09181-41009	.SHIM (41X52X0.9)	1	
9-10	09181-41010	.SHIM (41X52X0.95)	1	
9-11	09181-40195	.SHIM (40X52X1)	1	
9-12	09181-41012	.SHIM (41X52X1.05)	1	
9-13	09181-41013	.SHIM (41X52X1.1)	1	
9-14	09181-41014	.SHIM (41X52X1.15)	1	
10	09140-14024	NUT	1	
11-1	09181-25130	SHIM (25X32X0.5)	1	PROP SHAFT REV THRUST
11-2	09181-25139	SHIM (25X32X1.00)	1	PROP SHAFT REV THRUST
11-3	09181-25143	SHIM (25X32X1.09)	1	PROP SHAFT REV THRUST
11-4	09181-25149	SHIM (25X32X1.21)	1	PROP SHAFT REV THRUST
11-5	09181-25153	SHIM (25X32X1.30)	1	PROP SHAFT REV THRUST
11-6	09181-25072	SHIM (25X32X1.4)	1	PROP SHAFT REV THRUST
11-7	09181-25073	SHIM (25X32X1.5)	1	PROP SHAFT REV THRUST
11-8	09181-25074	SHIM (25X32X1.6)	1	PROP SHAFT REV THRUST
11-9	09181-25075	SHIM (25X32X1.7)	1	PROP SHAFT REV THRUST

FIG.220A



DF90A_E11_021_220A
TRANSMISSION

FIG.220A (1-D-15) TRANSMISSION

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
12-1	09181-40018	SHIM (40X46.8X0.55)	1	REV GEAR
12-2	09181-40004	SHIM (40X46.8X0.6)	1	REV GEAR
12-3	09181-40005	SHIM (40X46.8X0.65)	1	REV GEAR
12-4	09181-40006	SHIM (40X46.8X0.7)	1	REV GEAR
12-5	09181-40007	SHIM (40X46.8X0.75)	1	REV GEAR
12-6	09181-40008	SHIM (40X46.8X0.8)	1	REV GEAR
12-7	09181-40009	SHIM (40X46.8X0.85)	1	REV GEAR
12-8	09181-40010	SHIM (40X46.8X0.9)	1	REV GEAR
12-9	09181-40011	SHIM (40X46.8X0.95)	1	REV GEAR
12-10	09181-40012	SHIM (40X46.8X1)	1	REV GEAR
12-11	09181-40013	SHIM (40X46.8X1.05)	1	REV GEAR
13	57500-87882	SHIM SET, FORWARD GEAR	1	FWD GEAR
14-1	09181-64002	.SHIM (64X75X0.55)	1	FWD GEAR
14-2	09181-64003	.SHIM (64X75X0.6)	1	FWD GEAR
14-3	09181-64004	.SHIM (64X75X0.65)	1	FWD GEAR
14-4	09181-64005	.SHIM (64X75X0.7)	1	FWD GEAR
14-5	09181-64006	.SHIM (64X75X0.75)	1	FWD GEAR
14-6	09181-64007	.SHIM (64X75X0.8)	1	FWD GEAR
14-7	09181-64008	.SHIM (64X75X0.85)	1	FWD GEAR
14-8	09181-64009	.SHIM (64X75X0.9)	1	FWD GEAR
14-9	09181-64010	.SHIM (64X75X0.95)	1	FWD GEAR
14-10	09181-64011	.SHIM (64X75X1.0)	1	FWD GEAR
15	57610-87L00	SHAFT, PROPELLER	1	
16	57621-87L10	SHIFTER, CLUTCH DOG	1	
17	57631-87L00	PIN, CONNECTOR	1	
18	09202-07003	PIN	1	
19	09440-09043	SPRING	1	
20	09440-42002	SPRING	1	
21	06111-07004	BALL	2	
22	06111-11004	BALL	2	
23	09181-25030	SHIM (25X32X3)	1	

DF90A_E11_021

FIG.220A




FIG.220A (1-E-2) TRANSMISSION

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24-1	56120-87L30-YAY	HOUSING, PROPELLER SFT BRG (BLACK)	1	
24-2	56120-87L30-Y5S	HOUSING, PROPELLER SFT BRG (WHITE)	1	
24-3	56120-87L30-QTN	HOUSING, PROPELLER SFT BRG (WHITE)	1	
25	09263-25067	.BEARING (25X32X26)	1	
26	09280-92004	.O RING (D:3.1,ID:89.4)	1	
27	09282-25001	.OIL SEAL (25X38X8)	2	
28	08113-60087	.BEARING	1	
29	09116-08122	BOLT (8X30)	2	
30	56130-87L01	HOUSING, DRIVE SFT OIL SEAL	1	
31	09280-46004	.O RING (D:3.5,ID:45.7)	1	
32	09282-22007	.OIL SEAL (22X36X6)	2	
33	09117-08110	BOLT (8X25)	4	
34	57134-87L00	WASHER, DRIVE SHAFT	1	
35	57135-87L00	SPACER, DRIVE SHAFT	1	
36	09164-31001	WASHER	1	
37	09181-31001	SHIM (31X46X2)	1	

FIG.301A




FIG.301A (1-E-3) STARTING MOTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-98L10	MOTOR ASSY, STARTING	1	
2	31150-98L00	.CASE, GEAR	1	
3	31170-92J00	.HOUSING, REAR	1	
4	31173-98L00	.HOLDER ASSY, BRUSH	1	
5	31191-63J00	.LEVER SET	1	
6	31220-98L10	.SWITCH ASSY	1	
7	31311-63J00	ARMATURE	1	
8	31192-92J00	.SCREW SET	1	
9	31261-75F10	.BOLT	2	
10	31340-98L00	.CLUTCH SET, STARTING MOTOR	1	
11	31313-86030	..STOPPER SET	1	
12	31320-98L00	..PINION	1	
13	31341-98L00	..SHAFT, PINION	1	
14	31343-63J00	..INTERNAL GEAR ASSY	1	
15	31344-63J00	..GEAR ASSY	3	
16	31912-87L00	BAND, STARTER MOTOR	1	
17	31918-92J01	DAMPER, LOWER	1	LOWER
18	01550-0616C	BOLT	1	
19	01550-08207	BOLT	1	
20	01550-0835C	BOLT	2	

FIG.303A




FIG.303A (1-E-4) MAGNETO

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32102-87L00	FLYWHEEL	1	
2	09103-16004	BOLT (16X50)	1	
3	09160-16047	WASHER (16.5X48.5X4.5)	1	
4	09420-04008	KEY (B:4,D:16,H6.5)	1	
5	32120-87L10	COIL, BATTERY CHARGING	1	
6	32160-87L00	COIL, IGN TIMING	1	
7	09106-05030	BOLT (5X10)	2	
8	33220-64L10	SENSOR ASSY, POSN	1	
9	01550-0616C	BOLT	1	
10-1	09403-13414	CLAMP	2	E01,E11,E40
10-2	09403-13413	CLAMP	2	E03
11	01550-0612C	BOLT	2	
12	09103-06211	BOLT (6X25)	3	
13	09403-20310	CLAMP	1	

FIG.310A




FIG.310A (1-E-5) RECTIFIER/IGNITION COIL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-87L00	RECTIFIER & REGULATOR ASSY	1	
2	01550-0625C	BOLT	2	
3	32890-87L10	HOLDER, ELECTRIC PARTS	1	
4	09116-06202	BOLT (6X25)	2	
5	01550-0625C	BOLT	1	
6	09169-06062	WASHER (6.3X17X1.6)	3	
7	09320-09016	CUSHION	3	
8	33410-87L00	COIL ASSY, IGNITION	4	
9	01550-0620C	BOLT	4	



FIG.315A




FIG.315A (1-E-6) SENSOR (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13650-52G00	SENSOR, INLET AIR TEMP	1	
2	13655-87J01	GROMMET, INLET AIR TEMP SNSR	1	
3	18590-68H00	SENSOR, PRESSURE	1	
4	02162-05207	SCREW	2	
5	34830-87J20	SENSOR, TEMP	1	FOR CYLINDER TEMP
6	34840-98J11	SENSOR ASSY, TRIM	1	
7	09125-05046	SCREW (5X12)	1	
8	34846-87L00	WASHER, TRIM SENSOR (5.5X12X0.8)	1	
9	34841-87L10	LEVER, TRIM SENSOR	1	
10	34842-87L01	CAM, TRIM SENSOR UPPER	1	UPPER
11	34843-87L00	CAM, TRIM SENSOR LOWER	1	LOWER
12	34845-87L10	BRACKET, TRIM SENSOR	1	
13	09103-06093	BOLT (6X20)	1	
14	37820-99E02	SWITCH ASSY, OIL PRESSURE	1	
15	09403-07338	CLAMP	1	
16	09403-13413	CLAMP	1	
17	29103-93J00	BOLT (6X12)	1	
18	36656-87L00	GROMMET, PTT CABLE	1	

NOTE : DF70A,DF70ATH,DF80A,DF90A,DF90ATH,DF100B

FIG.315A




FIG.315A (1-E-7) SENSOR (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
19	09407-14407	CLAMP (L:145)	2	

NOTE : DF70A,DF70ATH,DF80A,DF90A,DF90ATH,DF100B

- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF70ATH E01
- DF70ATH E11
- DF70ATH E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF90ATH E01
- DF90ATH E11
- DF90ATH E40
- DF100B E01
- DF100B E40

FIG.315B





FIG.315B (1-E-8) SENSOR (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13650-52G00	SENSOR, INLET AIR TEMP	1	
2	13655-87J01	GROMMET, INLET AIR TEMP SNSR	1	
3	18590-68H00	SENSOR, PRESSURE	1	
4	02162-05207	SCREW	2	
5	34830-87J20	SENSOR, TEMP	1	FOR CYLINDER TEMP
6	37820-99E02	SWITCH ASSY, OIL PRESSURE	1	
7	36656-87L10	GROMMET, PTT CABLE	1	

DF90AWQH E40



FIG.322A




DF90A_E11_021_322A
HARNESS

FIG.322A (1-E-9) HARNESS (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-90J21	CABLE ASSY, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3	36610-87L91	HARNESS ASSY, WIRING	1	
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	09320-08510	.CUSHION	2	
6	36737-98L00	.PULLER, FUSE	1	
7	36721-98L00	.O RING, UPR COVER	1	UPPER
8	36738-98L00	.COVER, FUSE CASE UPPER	1	UPPER
9	38860-76F01	.RELAY ASSY	1	ENGINE CONTROL UNIT
10	38860-76F01	.RELAY ASSY	1	STARTER MOTOR
11	09481-10504	.FUSE (10A)	3	
12	09481-30504	.FUSE (30A)	3	
13	09481-40403	.FUSE (40A)	2	
14	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
15	36611-87L10	.HARNESS ASSY, WIRING SUB	1	
16	36612-96J01	CAP, TERMINAL	1	
17	08310-00067	NUT	1	
18	08321-01067	LOCK WASHER	1	
19	09408-00021	CLIP (ID:16)	1	
20	36616-87L00	HOLDER, CABLE	1	
21	09169-06053	WASHER	2	
22	09320-04013	BUSH	2	
23	02142-06167	SCREW (6X16)	2	
24	01550-06127	BOLT	1	
25	36617-87L00	CLAMP, HARNESS	1	
26	36617-93J00	BRACKET, HARNESS	1	
27	36617-87L10	CLAMP, HARNESS	1	
28	36617-87L20	CLAMP, HARNESS	1	
29	09403-07308	CLAMP	1	
30	09407-14407	CLAMP (L:145)	1	
31	09408-00024	CLIP (ID:23)	1	
32	01550-0612C	BOLT	2	

NOTE : (DF70A,DF70ATH,DF80A,DF90A,DF90ATH):020

FIG.322A



DF90A_E11_021_322A
HARNESS

FIG.322A (1-E-10) HARNESS (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	09403-11321	CLAMP	1	
34	09403-12409	CLAMP	1	
35	36611-87L01	HARNESS ASSY, WIRING SUB	1	
36	09408-00020	CLIP	1	
37	36625-93J10	LEAD, BATTERY (L:6700)	1	OPT
38	09481-15501	.FUSE (15A)	1	OPT

NOTE : (DF70A,DF70ATH,DF80A,DF90A,DF90ATH):**2020**

- DF70A E01
- DF70A E03
- DF70A E40
- DF70ATH E01
- DF70ATH E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E40
- DF90ATH E01
- DF90ATH E40

FIG.322B




FIG.322B (1-E-11) HARNESS (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-90J21	CABLE ASSY, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3	36610-87LC1	HARNESS ASSY, WIRING	1	
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	09320-08510	.CUSHION	2	
6	36737-98L00	.PULLER, FUSE	1	
7	36721-98L00	.O RING, UPR COVER	1	UPPER
8	36738-98L00	.COVER, FUSE CASE UPPER	1	UPPER
9	38860-76F01	.RELAY ASSY	1	ENGINE CONTROL UNIT
10	38860-76F01	.RELAY ASSY	1	STARTER MOTOR
11	09481-10504	.FUSE (10A)	3	
12	09481-30504	.FUSE (30A)	3	
13	09481-40403	.FUSE (40A)	2	
14	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
15	36611-87L10	.HARNESS ASSY, WIRING SUB	1	
16	36612-96J01	CAP, TERMINAL	1	
17	08310-00067	NUT	1	
18	08321-01067	LOCK WASHER	1	
19	09408-00021	CLIP (ID:16)	1	
20	36616-87L00	HOLDER, CABLE	1	
21	09169-06053	WASHER	2	
22	09320-04013	BUSH	2	
23	02142-06167	SCREW (6X16)	2	
24	01550-06127	BOLT	1	
25	36617-87L00	CLAMP, HARNESS	1	
26	36617-93J00	BRACKET, HARNESS	1	
27	36617-87L10	CLAMP, HARNESS	1	
28	36617-87L20	CLAMP, HARNESS	1	
29	09403-07308	CLAMP	2	
30	09407-14407	CLAMP (L:145)	1	
31	09408-00024	CLIP (ID:23)	1	
32	01550-0612C	BOLT	2	

NOTE : (DF70A,DF70ATH,DF80A,DF90A,DF90ATH):**2021**

FIG.322B




FIG.322B (1-E-12) HARNESS (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	09403-11321	CLAMP	1	
34	09403-12409	CLAMP	1	
35	36611-87L01	HARNESS ASSY, WIRING SUB	1	
36	33833-87L00	TUBE, SPIRAL	1	
37	36625-93J10	LEAD, BATTERY (L:6700)	1	OPT
38	09481-15501	.FUSE (15A)	1	OPT

NOTE : (DF70A,DF70ATH,DF80A,DF90A,DF90ATH):**2021**

- DF70A E11
- DF70A E40
- DF70ATH E11
- DF80A E01
- DF80A E40
- DF90A E11
- DF90A E40
- DF90ATH E11
- DF90ATH E40

FIG.322C




FIG.322C (1-E-13) HARNESS (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-90J21	CABLE ASSY, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3	36610-87LB1	HARNESS ASSY, WIRING	1	
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	09320-08510	.CUSHION	2	
6	38860-76F01	.RELAY ASSY	1	ENGINE CONTROL UNIT STARTER MOTOR
7	38860-76F01	.RELAY ASSY	1	
8	09481-10504	.FUSE (10A)	3	
9	09481-30504	.FUSE (30A)	3	
10	09481-40403	.FUSE (40A)	2	
11	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
12	36612-96J01	CAP, TERMINAL	1	
13	08310-00067	NUT	1	
14	08321-01067	LOCK WASHER	1	
15	09408-00021	CLIP (ID:16)	1	
16	36616-87L00	HOLDER, CABLE	1	
17	09169-06053	WASHER	2	
18	09320-04013	BUSH	2	
19	02142-06167	SCREW (6X16)	2	
20	01550-06127	BOLT	1	
21	36617-87L00	CLAMP, HARNESS	1	
22	36617-93J00	BRACKET, HARNESS	1	
23	36617-87L10	CLAMP, HARNESS	1	
24	36617-87L20	CLAMP, HARNESS	1	
25	09403-07308	CLAMP	1	
26	09407-14407	CLAMP (L:145)	1	
27	09408-00024	CLIP (ID:23)	1	
28	01550-0612C	BOLT	2	
29	09403-11321	CLAMP	1	
30	09403-12409	CLAMP	1	
31	36611-87L01	HARNESS ASSY, WIRING SUB	1	
32	33833-87L00	TUBE, SPIRAL	1	

DF90AWQH E40

FIG.322D




FIG.322D (1-E-14) HARNESS (DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-90J21	CABLE ASSY, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3	36610-87LA1	HARNESS ASSY, WIRING	1	
4	33634-96J00	.CAP, SERVICE CONNECTOR	1	
5	09320-08510	.CUSHION	2	
6	36737-98L00	.PULLER, FUSE	1	
7	36721-98L00	.O RING, UPR COVER	1	UPPER
8	36738-98L00	.COVER, FUSE CASE UPPER	1	UPPER
9	38860-76F01	.RELAY ASSY	1	ENGINE CONTROL UNIT
10	38860-76F01	.RELAY ASSY	1	STARTER MOTOR
11	09481-10504	.FUSE (10A)	3	
12	09481-30504	.FUSE (30A)	3	
13	09481-40403	.FUSE (40A)	2	
14	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
15	36611-87L10	.HARNESS ASSY, WIRING SUB	1	
16	36612-96J01	CAP, TERMINAL	1	
17	08310-00067	NUT	1	
18	08321-01067	LOCK WASHER	1	
19	09408-00021	CLIP (ID:16)	1	
20	36616-87L00	HOLDER, CABLE	1	
21	09169-06053	WASHER	2	
22	09320-04013	BUSH	2	
23	02142-06167	SCREW (6X16)	2	
24	01550-06127	BOLT	1	
25	36617-87L00	CLAMP, HARNESS	1	
26	36617-93J00	BRACKET, HARNESS	1	
27	36617-87L10	CLAMP, HARNESS	1	
28	36617-87L20	CLAMP, HARNESS	1	
29	09403-07308	CLAMP	1	
30	09407-14407	CLAMP (L:145)	1	
31	09408-00024	CLIP (ID:23)	1	
32	01550-0612C	BOLT	2	
33	09403-11321	CLAMP	1	
34	09403-12409	CLAMP	1	
35	36611-87L01	HARNESS ASSY, WIRING SUB	1	
36	33833-87L00	TUBE, SPIRAL	1	

FIG.322D




FIG.322D (1-E-15) HARNESS (DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY		REMARKS
37	36625-93J10	LEAD, BATTERY (L:6700)	1	OPT	
38	09481-15501	.FUSE (15A)	1	OPT	

DF100B E01
DF100B E40

FIG.326A




FIG.326A (1-F-2) PTT SWITCH/ENGINE CONTROL UNIT (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37721-93J00	SWITCH ASSY, NEUTRAL	1	
2	09137-04004	SCREW (4X16)	2	
3	37726-90J10	BRACKET, NEUTRAL SWITCH	1	
4	37726-87L00	BRACKET, SWITCH LEAD CLAMP	1	
5	01550-0612C	BOLT	1	
6	37850-92J00	SWITCH ASSY, PTT	1	
7	37856-92J00	.TAPE, PTT SWITCH	1	
8	37857-92J01	BUSH, PTT SWITCH	1	
9	09403-11321	CLAMP	1	
10	09407-10404	CLAMP (L:100)	1	
11	38410-93J21	RELAY ASSY, PTT	1	
12	38415-93J20	HOLDER, PTT RELAY	1	
13	01550-06127	BOLT	1	
14-1	33940-87LL0	UNIT, ENGINE CONTROL	1	(DF70A,DF70ATH):E01
14-2	33940-87LL0	UNIT, ENGINE CONTROL	1	(DF70A,DF90A):E03
14-3	33950-87L60	UNIT, ENGINE CONTROL	1	(DF70A,DF70ATH):E11
14-4	33940-87LM0	UNIT, ENGINE CONTROL	1	(DF70A,DF70ATH):E40:020
14-5	33950-87L70	UNIT, ENGINE CONTROL	1	DF70A:E40:021
14-6	33940-87LG0	UNIT, ENGINE CONTROL	1	DF80A:E01:020
14-7	33950-87L20	UNIT, ENGINE CONTROL	1	DF80A:E01:021
14-8	33940-87LH0	UNIT, ENGINE CONTROL	1	DF80A:E40:020
14-9	33950-87L30	UNIT, ENGINE CONTROL	1	DF80A:E40:021
14-10	33940-87LQ0	UNIT, ENGINE CONTROL	1	(DF90A,DF90ATH):E01
14-11	33950-87L40	UNIT, ENGINE CONTROL	1	(DF90A,DF90ATH):E11
14-12	33940-87LR0	UNIT, ENGINE CONTROL	1	(DF90A,DF90ATH):E40:020
14-13	33950-87L50	UNIT, ENGINE CONTROL	1	(DF90A,DF90ATH):E40:021
14-14	33940-87LN0	UNIT, ENGINE CONTROL	1	DF100B:E01:020
14-15	33950-87L00	UNIT, ENGINE CONTROL	1	DF100B:E01:021
14-16	33940-87LP0	UNIT, ENGINE CONTROL	1	DF100B:E40:020
14-17	33950-87L10	UNIT, ENGINE CONTROL	1	DF100B:E40:021

NOTE : DF70A,DF70ATH,DF80A,DF90A,DF90ATH,DF100B

FIG.326A




FIG.326A (1-F-3) PTT SWITCH/ENGINE CONTROL UNIT (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
15	33925-92J00	CUSHION, ENGINE CONTROL UNIT	1	

NOTE : DF70A,DF70ATH,DF80A,DF90A,DF90ATH,DF100B

- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF70ATH E01
- DF70ATH E11
- DF70ATH E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF90ATH E01
- DF90ATH E11
- DF90ATH E40
- DF100B E01
- DF100B E40

FIG.326B




FIG.326B (1-F-4) PTT SWITCH/ENGINE CONTROL UNIT (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37721-93J00	SWITCH ASSY, NEUTRAL	1	
2	09137-04004	SCREW (4X16)	2	
3	37726-90J10	BRACKET, NEUTRAL SWITCH	1	
4	37726-87L00	BRACKET, SWITCH LEAD CLAMP	1	
5	01550-0612C	BOLT	1	
6	09250-40002	CAP (OD:52)	1	
7	09403-11321	CLAMP	1	
8	09407-10404	CLAMP (L:100)	1	
9	33940-87LS0	UNIT, ENGINE CONTROL	1	
10	33925-92J00	CUSHION, ENGINE CONTROL UNIT	1	

DF90AWQH E40



FIG.331A




FIG.331A (1-F-5) KEY LESS START (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32851-93J00	CUSHION, LEAD WIRE	1	
2	32980-38F00	CUSHION, CDI UNIT	1	
3	36623-96L11	HARNESS ASSY, KLS CONT	1	
4	36615-96300	.TERMINAL	1	
5	36662-96L10	HARNESS ASSY, KLS CAN (L:6500+2000)	1	
6	37173-96L10	HOLDER, KLS PARTS	1	
7	38500-93J90	BUZZER, WARNING	1	
8	38860-96L01	RELAY ASSY, KLS	1	
9	09407-14407	CLAMP (L:145)	1	
10	37117-96L00	DECAL, KLS	2	
11-1	37171-96L02	CONTROLLER ASSY, KLS	1	(DF70A,DF80A,DF90A,DF100B):E01 433MHZ
11-2	37171-96L12	CONTROLLER ASSY, KLS	1	(DF70A,DF90A):(E03,E11) 315MHZ
11-3	37171-96L02	CONTROLLER ASSY, KLS	1	(DF70A,DF90A):(E03,E11) 433MHZ

NOTE : (DF70A,DF80A,DF90A,DF100B):E01,(DF70A,DF90A):(E03,E11)

FIG.331A




FIG.331A (1-F-6) KEY LESS START (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
12-1	37172-96L01	REMOCON ASSY, KLS	2	(DF70A,DF80A,DF90A,DF100B):E01 433MHZ
12-2	37172-96L10	REMOCON ASSY, KLS	2	(DF70A,DF90A):(E03,E11) 315MHZ
12-3	37172-96L01	REMOCON ASSY, KLS	2	(DF70A,DF90A):(E03,E11) 433MHZ

NOTE : (DF70A,DF80A,DF90A,DF100B):E01,(DF70A,DF90A):(E03,E11)

- DF70A E01
- DF70A E03
- DF70A E11
- DF80A E01
- DF90A E01
- DF90A E03
- DF90A E11
- DF100B E01

FIG.335A (1-F-7) CLAMP BRACKET (SEE NOTE)



NOTE : DF70A,DF70ATH,DF80A,DF90A,DF90ATH,DF100B

FIG.335A




FIG.335A (1-F-8) CLAMP BRACKET (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
13	09160-12128	WASHER (12.5X35X3)	4	

NOTE : DF70A,DF70ATH,DF80A,DF90A,DF90ATH,DF100B

- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF70ATH E01
- DF70ATH E11
- DF70ATH E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF90ATH E01
- DF90ATH E11
- DF90ATH E40
- DF100B E01
- DF100B E40



FIG.335B




FIG.335B (1-F-9) CLAMP BRACKET (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-87L30-YAY	BRACKET, CLAMP STBD (BLACK)	1	STBD
2	41121-87L30-YAY	BRACKET, CLAMP PORT (BLACK)	1	PORT
3	41130-87L11	SHAFT, CLAMP BRACKET	1	
4	41135-93J11	WASHER, CLAMP BRACKET SHAFT	1	
5	55321-94910	ANODE	1	OPT
6	09116-08137	BOLT (8X22)	1	
7	09159-22006	NUT	1	
8	55320-94900	ANODE SET, CLAMP BRACKET	1	
9	09116-06121	.BOLT (6X25)	2	
10-1	09100-12127	BOLT (12X115)	4	
10-2	09100-12090	BOLT (12X150)	1	OPT
11	09159-12014	NUT	4	
12	09160-12110	WASHER (12.5X22X3)	4	
13	09160-12128	WASHER (12.5X35X3)	4	
14	45421-87D03	PIN, TILT LOCK	1	
15	09159-14020	NUT	2	
16	09106-10065	BOLT (10X20)	2	
17	09160-10082	WASHER (10.5X19X2.0)	2	
18	43241-87J00	MARK, RELEASE LEVER	1	

DF90AWQH E40

FIG.336A





FIG.336A (1-F-10) SWIVEL BRACKET (DF70A,DF80A,DF90A,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE, GREASE	5	
2	36894-87D00	LEAD (L:165)	1	
3	36894-87D00	LEAD (L:165)	1	
4	36895-87D10	LEAD (L:310)	1	
5-1	43111-87L20-YAY	BRACKET, SWIVEL (BLACK)	1	
5-2	43111-87L20-Y5S	BRACKET, SWIVEL (WHITE)	1	
5-3	43111-87L20-QTN	BRACKET, SWIVEL (WHITE)	1	
6	43211-93J11	BUSH, CLAMP SHAFT SWIVEL	2	
7	43711-97E11	BUSH, STEERING	2	
8-1	43750-87L20-YAY	BRACKET, STEERING LH (BLACK)	1	
8-2	43750-87L20-Y5S	BRACKET, STEERING LH (WHITE)	1	
8-3	43750-87L20-QTN	BRACKET, STEERING LH (WHITE)	1	
9	09125-06063	SCREW (6X10)	2	
10	09125-06063	SCREW (6X10)	1	
11	09125-06063	SCREW (6X10)	2	
12	09160-39001	WASHER (39.5X64X1.0)	2	
13	09169-28003	WASHER (26.2X52.0X1.0)	2	
14	09181-39001	SHIM (39.5X64X0.30)	4	
15	09282-39001	OIL SEAL (39X51X5)	1	
16	09380-38003	CIRCLIP	1	
17	43755-87L00	ATTACHMENT, STEERING BRACKET	1	
18	09108-10156	STUD BOLT	2	
19	09159-10050	NUT	2	
20	09160-10165	WASHER	2	
21	41220-93J11	LEVER, TILT LOCK	1	
22	41224-95E01	BUSH, TILT STOPPER ROD	2	
23	41230-87L00	LINK, TILT LOCK LEVER	1	
24	41233-95E10	BRACKET, TILT LOCK SPRING	1	
25	41234-93J11	LEVER, TILT LOCK PORT	1	PORT
26	09125-06063	SCREW (6X10)	1	
27	09140-10032	NUT	1	
28	09160-06082	WASHER (6.5X13X1.0)	1	
29	09204-01006	PIN	1	
30	09440-19028	SPRING	1	

This diagram shows an exploded view of a mechanical assembly. The central component is a large, complex housing or bracket (part 5). Various parts are shown in their relative positions as they would be assembled. Key components include:

- Part 1:** A small pin or screw located near the top of the main housing.
- Part 2:** A small pin or screw at the bottom left of the main housing.
- Part 3:** A small pin or screw at the bottom left of the main housing.
- Part 4:** A small pin or screw at the bottom left of the main housing.
- Part 5:** The main housing or bracket.
- Part 6:** A cylindrical component, possibly a bush or sleeve, shown in two locations.
- Part 7:** A cylindrical component, possibly a bush or sleeve, shown in two locations.
- Part 8:** A long, thin rod or shaft with a threaded end.
- Part 9:** A small pin or screw at the bottom left of the main housing.
- Part 10:** A small pin or screw at the bottom left of the main housing.
- Part 11:** A small pin or screw at the bottom left of the main housing.
- Part 12:** A small pin or screw at the bottom left of the main housing.
- Part 13:** A small pin or screw at the bottom left of the main housing.
- Part 14:** A small pin or screw at the bottom left of the main housing.
- Part 15:** A small pin or screw at the bottom left of the main housing.
- Part 16:** A small pin or screw at the bottom left of the main housing.
- Part 17:** A small pin or screw at the bottom left of the main housing.
- Part 18:** A small pin or screw at the bottom left of the main housing.
- Part 19:** A small pin or screw at the bottom left of the main housing.
- Part 20:** A small pin or screw at the bottom left of the main housing.
- Part 21:** A small pin or screw at the bottom left of the main housing.
- Part 22:** A small pin or screw at the bottom left of the main housing.
- Part 23:** A small pin or screw at the bottom left of the main housing.
- Part 24:** A small pin or screw at the bottom left of the main housing.
- Part 25:** A small pin or screw at the bottom left of the main housing.
- Part 26:** A small pin or screw at the bottom left of the main housing.
- Part 27:** A small pin or screw at the bottom left of the main housing.
- Part 28:** A small pin or screw at the bottom left of the main housing.
- Part 29:** A small pin or screw at the bottom left of the main housing.
- Part 30:** A small pin or screw at the bottom left of the main housing.
- Part 31:** A small pin or screw at the bottom left of the main housing.



REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	09443-10043	SPRING	1	

DF90A_E11_021

DF90A_E11_021_336B
SWIVEL BRACKET

DF70ATH E01
DF70ATH E11
DF70ATH E40
DF90ATH E01
DF90ATH E11
DF90ATH E40

FIG.336C




FIG.336C (1-F-13) SWIVEL BRACKET (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE, GREASE	5	
2	36894-87D00	LEAD (L:165)	1	
3	36894-87D00	LEAD (L:165)	1	
4	36895-87D10	LEAD (L:310)	1	
5	43111-87L30-YAY	BRACKET, SWIVEL (BLACK)	1	
6	43211-87L00	BUSH, SWIVEL BRACKET	2	
7	43711-97E11	BUSH, STEERING	2	
8	43750-87L30-YAY	BRACKET, STEERING LH (BLACK)	1	
9	09125-06063	SCREW (6X10)	2	
10	09125-06063	SCREW (6X10)	1	
11	09125-06063	SCREW (6X10)	2	
12	09160-39001	WASHER (39.5X64X1.0)	2	
13	09181-39001	SHIM (39.5X64X0.30)	4	
14	09282-39001	OIL SEAL (39X51X5)	1	
15	09380-38003	CIRCLIP	1	
16	41220-87L00	LEVER, TILT LOCK	1	
17	41221-95E40	LEVER, TILT LOCK PORT	1	
18	41224-95E01	BUSH, TILT STOPPER ROD	2	
19	41225-94400	RUBBER, TILT LOCK	1	
20	41228-90J00	SPRING, TILT LOCK LEVER	1	
21	41230-95E00	LINK, TILT LOCK LEVER	1	
22	41233-95E10	BRACKET, TILT LOCK SPRING	1	
23	09125-06063	SCREW (6X10)	1	
24	09140-10032	NUT	1	
25	09160-06082	WASHER (6.5X13X1.0)	1	
26	09204-01006	PIN	1	
27	09440-19028	SPRING	1	
28	43411-87L00	LEVER, STEERING ADJUSTER	1	
29	43415-87L00	PLATE, STEERING ADJUSTER	1	
30	43420-87L00	PLATE, STRG ADJ UPPER	1	
31	43427-87L00	SPACER, STRG ADJ FRICTION	2	
32	43510-87L00	PLATE, STRG ADJ FRICTION	2	
33	43512-87L00	SHAFT, STRG ADJ THREAD	1	
34	43516-87L00	WASHER, STRG ADJ FRICTION	1	
35	45255-93001	RUBBER, RELEASE LEVER	1	
36	09100-06182	BOLT	2	

FIG.336C




FIG.336C (1-F-14) SWIVEL BRACKET (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
37	09160-06094	WASHER (6.5X15X1.0)	4	
38	09100-06183	BOLT	2	
39	09159-06079	NUT	2	
40	09161-10013	WASHER	1	
41	09159-10232	NUT	1	
42	09160-06173	WASHER (6.2X19X3)	1	
43	09160-06174	WASHER	2	
44	09440-19028	SPRING	2	

DF90AWQH E40

FIG.337A




FIG.337A (1-G-2) TRIM CYLINDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-87L14	TRIM ASSY, POWER WITH TILT	1	
2	48400-87L03	.MANIFOLD ASSY	1	
3	48611-87L00	.JOINT, METAL	1	
4	48571-87L01	.TANK, RESERVOIR	1	
5	48572-87L00	.PLUG	1	
6	48557-90J00	.O RING	1	
7	48862-87J20	.BOLT, RESERVOIR	4	
8	31281-92J10	.BOLT, THROUGH	4	
9	38100-87L12	.MOTOR ASSY, PTT	1	
10	48502-87L02	.PUMP ASSY	1	
11	48582-95E01	.FILTER	1	
12	48583-95E00	.JOINT, DRIVE	1	
13	48585-95E00	.O RING	1	
14	48864-96J10	.VALVE SET, MANUAL	1	
15	48588-90J00	.O RING SET	1	
16	48862-92J20	.BOLT, PUMP NO.1	1	
17	48862-92J30	.BOLT, PUMP NO.2	1	
18	48862-90J21	.BOLT	1	
19	48321-90J00	SHAFT, TILT CYL UPPER	1	UPPER
20	48326-95E00	BUSH, TILT CYL LOWER	2	LOWER
21	48325-87L00	BUSH, TILT CYL LOWER	2	UPPER
22	09380-22015	CIRCLIP	2	
23	55321-87J01	ANODE, PROTECTION	1	
24	09103-06281	BOLT (6X14)	1	
25	48121-90J00	SHAFT, TILT CYL LOWER	1	LOWER
26	09116-10179	BOLT (10X35)	2	
27	36895-87D10	LEAD (L:310)	1	
28	09125-05050	SCREW (5X8)	1	

FIG.339A




FIG.339A (1-G-3) GAS CYLINDER (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	45260-87L00	LEVER, RELEASE	1	
2	48326-95E00	BUSH, TILT CYL LOWER	2	
3	47400-87L00	CYLINDER ASSY, GAS	1	
4	48120-87L00	SHAFT, TILT CYL LOWER	1	
5	48321-90J00	SHAFT, TILT CYL UPPER	1	
6	48325-87L00	BUSH, TILT CYL LOWER	2	
7	09160-10161	WASHER	1	
8	55321-87J01	ANODE, PROTECTION	1	
9	09100-06184	BOLT (6X16)	1	
10	09116-10179	BOLT (10X35)	1	
11	09103-06281	BOLT (6X14)	1	
12	09140-06020	NUT	1	
13	09380-22015	CIRCLIP	2	
14	45255-93001	RUBBER, RELEASE LEVER	1	
15	36894-87D00	LEAD (L:165)	1	
16	09125-06063	SCREW (6X10)	2	

DF90AWQH E40

FIG.340A




FIG.340A (1-G-4) PTT MOTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-87L12	MOTOR ASSY, PTT	1	
2	31311-93J00	.ARMATURE	1	
3	31173-94920	.HOLDER ASSY, BRUSH	1	
4	31123-94910	..O RING	1	
5	31133-90J10	..BRUSH ASSY	1	
6	31133-94910	...BRUSH	1	
7	31136-90J20	..BREAKER ASSY	1	
8	31135-94900	..SPRING	2	
9	33799-97E00	..OIL SEAL	1	
10	31111-94900	..SCREW	1	

FIG.401A




FIG.401A (1-G-5) ENGINE HOLDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	51111-87L00-YAY	HOLDER, ENGINE (BLACK)	1	FOR YAY
1-2	51111-87L00-Y5S	HOLDER, ENGINE (WHITE)	1	FOR QTN,Y5S
2	51115-87L00	UNION, WATER RETURN	1	
3	51117-87L00	UNION, WATER INDICATOR	1	
4	51211-87L10	GASKET, ENGINE HOLDER	1	
5	09116-08178	BOLT (8X40)	7	
6	09116-08159	BOLT (8X55)	1	
7	09202-08006	PIN (8X12)	2	
8	04211-11129	PIN	2	
9	04211-11129	PIN	1	
10	09160-18031	WASHER (18.5X28X2.6)	1	
11	09248-18010	PLUG (18X15)	1	
12	29116-93J00	BOLT (6X20)	1	
13	09280-11001	O RING (D:2.4,ID:10.8)	1	
14	09280-20002	O RING (D:3.1,ID:19.4)	1	
15	01550-0620C	BOLT	1	
16	09262-17019	BEARING (17X35X8)	1	
17	09289-18001	OIL SEAL (18X30X8)	1	
18	09282-22007	OIL SEAL (22X36X6)	2	
19	12281-87J00	OIL SEAL, CRANKSHAFT UNDER (30X44X7)	1	
20	51122-87L00	COVER, MOUNT CASE	1	
21	51123-87L00	GASKET, MOUNT CASE COVER	1	
22	01550-0825A	BOLT	5	
23	54120-87L11	MOUNT, UPR THRUST	1	UPPER
24	54122-87L01	SPACER, UPPER THRUST MOUNT	2	UPPER
25	54130-87L00	MOUNT, UPPER	2	UPPER
26	54166-95J02	BOLT, LOWER MOUNT	2	UPPER
27	09159-12014	NUT	2	
28	09160-12110	WASHER (12.5X22X3)	2	
29	54137-87L00	COVER, UPPER MOUNT	1	UPPER
30	09116-10181	BOLT (10X44)	2	
31	09116-10147	BOLT (10X85)	1	
32	54140-87L10	STOPPER, UPPER UNIT	1	UPPER
33	09116-08137	BOLT (8X22)	2	

FIG.405A




FIG.405A (1-G-6) DRIVE SHAFT HOUSING (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-87L00-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	
1-2	52111-87L00-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	
1-3	52111-87L00-QTN	HOUSING, DRIVE SHAFT (WHITE)	1	
2	09116-10181	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4-1	52131-87L00-YAY	CASE, EXTENSION (BLACK)	1	W/TRANSOM(X)
4-2	52131-87L00-Y5S	CASE, EXTENSION (WHITE)	1	W/TRANSOM(X)
4-3	52131-87L00-QTN	CASE, EXTENSION (WHITE)	1	W/TRANSOM(X)
5	09108-10115	STUD BOLT (10X167)	4	W/TRANSOM(X)
6	09108-10157	STUD BOLT	1	W/TRANSOM(X)
7	09202-08006	PIN (8X12)	2	W/TRANSOM(X)
8	09381-40005	CIRCLIP	1	W/TRANSOM(X)
9	57130-87E02	BUSH, DRIVE SHAFT	1	W/TRANSOM(X)
10	55321-93J01	ANODE, PROTECTION	1	W/TRANSOM(X)
11	09116-06236	BOLT (6X16)	1	W/TRANSOM(X)
12	54151-87L01	MOUNT, LWR THRUST	1	LOWER
13	54160-87L10	MOUNT, LOWER	2	LOWER
14	54166-95J02	BOLT, LOWER MOUNT	2	LOWER
15	09159-12014	NUT	2	
16	54167-87L10	MOUNT, FORWARD LOWER SIDE	2	LOWER
17	54114-90J10	WASHER, UPPER MOUNT BOLT	2	LOWER
18-1	54211-90J01-YAY	BRACKET, LOWER MOUNT (BLACK)	1	LOWER
18-2	54211-90J01-Y5S	BRACKET, LOWER MOUNT (WHITE)	1	LOWER
18-3	54211-90J01-QTN	BRACKET, LOWER MOUNT (WHITE)	1	LOWER
19-1	54221-87L00-YAY	COVER, LWR MOUNT STBD (BLACK)	1	STBD
19-2	54221-87L00-Y5S	COVER, LWR MOUNT STBD (WHITE)	1	STBD
19-3	54221-87L00-QTN	COVER, LWR MOUNT STBD (WHITE)	1	STBD
20-1	54231-87L00-YAY	COVER, LWR MOUNT PORT (BLACK)	1	PORT
20-2	54231-87L00-Y5S	COVER, LWR MOUNT PORT (WHITE)	1	PORT
20-3	54231-87L00-QTN	COVER, LWR MOUNT PORT (WHITE)	1	PORT
21	09116-10181	BOLT (10X44)	4	

NOTE : DF70A,(DF70ATH,DF90ATH);E40,DF80A,DF90A,DF90AWQH,DF100B

FIG.405A




FIG.405A (1-G-7) DRIVE SHAFT HOUSING (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	54180-88L01	DAMPER, FORWARD STOPPER	2	

NOTE : DF70A,(DF70ATH,DF90ATH):E40,DF80A,DF90A,DF90AWQH,DF100B

- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF70ATH E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF90ATH E40
- DF90AWQH E40
- DF100B E01
- DF100B E40

FIG.405B




FIG.405B (1-G-8) DRIVE SHAFT HOUSING (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	52111-87L00-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	
2	09116-10181	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4	54151-87L01	MOUNT, LWR THRUST	1	LOWER
5	54160-87L10	MOUNT, LOWER	2	LOWER
6	54166-95J02	BOLT, LOWER MOUNT	2	LOWER
7	09159-12014	NUT	2	
8	54167-87L10	MOUNT, FORWARD LOWER SIDE	2	LOWER
9	54114-90J10	WASHER, UPPER MOUNT BOLT	2	LOWER
10	54211-90J01-YAY	BRACKET, LOWER MOUNT (BLACK)	1	LOWER
11	54221-87L00-YAY	COVER, LOWER MOUNT STBD (BLACK)	1	STBD
12	54231-87L00-YAY	COVER, LOWER MOUNT PORT (BLACK)	1	PORT
13	09116-10181	BOLT (10X44)	4	
14	54180-88L01	DAMPER, FORWARD STOPPER	2	

NOTE : (DF70ATH,DF90ATH):(E01,E11)

- DF70ATH E01
- DF70ATH E11
- DF90ATH E01
- DF90ATH E11



FIG.407A




FIG.407A (1-G-9) GEAR CASE (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-87L32-YAY	CASE, GEAR (BLACK)	1	
1-2	55110-87L32-Y5S	CASE, GEAR (WHITE)	1	
2	09263-26023	.BEARING (26X34X30)	1	
3	09202-08006	PIN (8X12)	2	
4	55125-90J01	TAB, TRIM	1	
5	09116-08137	BOLT (8X22)	1	
6	09248-10008	PLUG (10X7.5)	2	
7	09168-10022	GASKET (10X17X1.5)	2	
8-1	55321-87J01	ANODE	1	
8-2	55321-87J11	ANODE	1	OPT
9	09103-06281	BOLT (6X14)	1	
10	55333-87L00	PLATE, EXHAUST SEAL	1	
11	52332-87L11	SEAL, EXH TUBE HOUSING	1	
12	55127-87D00	UNION, SPEEDOMETER HOSE	1	
13	09355-40805-00B	HOSE (4X8X2000)	1	L:2000->1500
14	09362-09008	UNION	1	
15	09407-10404	CLAMP (L:100)	2	
16	09116-10137	BOLT (10X70)	1	W/TRANSOM(L)
17	09116-10150	BOLT (10X55)	4	W/TRANSOM(L)
18	09140-10031	NUT (M10)	5	W/TRANSOM(X)
19	09160-10141	WASHER (10.5X19X2)	5	W/TRANSOM(X)
20-1	58100-87LA0-019	PROPELLER (3X14X13)	1	
20-2	58100-87LB0-019	PROPELLER (3X13.875X15)	1	
20-3	58100-87LC0-019	PROPELLER (3X13.75X17)	1	
20-4	58100-87LD0-019	PROPELLER (3X13.75X19)	1	
20-5	58100-87LE0-019	PROPELLER (3X13.75X21)	1	
20-6	58100-87LF0-019	PROPELLER (3X13.75X23)	1	
20-7	58100-90JA0-019	PROPELLER (3X14X17)	1	OPT
20-8	58100-90JB0-019	PROPELLER (3X14X19)	1	OPT
20-9	58100-90JC0-019	PROPELLER (3X14X21)	1	OPT
20-10	58100-90JD0-019	PROPELLER (3X14X23)	1	OPT
20-11	58100-90JE0-019	PROPELLER (3X13.5X15)	1	OPT

NOTE : (DF70A,(DF70ATH,DF90ATH):E40,DF80A,DF90A,DF100B):020



FIG.407A




FIG.407A (1-G-10) GEAR CASE (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20-12	58200-92J40	PROPELLER (3X13-7/8X15)	1	OPT,SUS
20-13	58200-92J50	PROPELLER (3X13-7/8X17)	1	OPT,SUS
20-14	58200-92J60	PROPELLER (3X13-7/8X19)	1	OPT,SUS
20-15	58200-92J70	PROPELLER (3X13-7/8X21)	1	OPT,SUS
20-16	58200-92J80	PROPELLER (3X13-7/8X23)	1	OPT,SUS
20-17	58200-92J90	PROPELLER (3X13-7/8X25)	1	OPT,SUS
21	58105-90J00	.BUSH SET, PROPELLER	1	
22	57632-87L01	STOPPER, PROPELLER BUSH	1	
23	57633-90J02	SPACER, PROPELLER NUT	1	
24	09141-18005	NUT	1	
25	09204-03003	PIN (D:3.6,L:25)	1	
26	09160-18028	WASHER (18.5X31X1.0)	1	
27	57630-90J00	KIT, PROPELLER NUT	1	OPT
28	25700-87L00	KIT, GEAR CASE SEALING	1	OPT,NOT ILLUSTRATED

NOTE : (DF70A,(DF70ATH,DF90ATH):E40,DF80A,DF90A,DF100B):020

- DF70A E01
- DF70A E03
- DF70A E40
- DF70ATH E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E40
- DF90ATH E40
- DF100B E01
- DF100B E40



FIG.407B




FIG.407B (1-G-11) GEAR CASE (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-87L32-YAY	CASE, GEAR (BLACK)	1	
1-2	55110-87L32-QTN	CASE, GEAR (WHITE)	1	
2	09263-26023	.BEARING (26X34X30)	1	
3	09202-08006	PIN (8X12)	2	
4	55125-90J01	TAB, TRIM	1	
5	09116-08137	BOLT (8X22)	1	
6	09248-10008	PLUG (10X7.5)	2	
7	09168-10022	GASKET (10X17X1.5)	2	
8-1	55321-93J01	ANODE	1	
8-2	55321-87J11	ANODE	1	OPT
9	09116-06236	BOLT (6X16)	1	
10	55333-87L00	PLATE, EXHAUST SEAL	1	
11	52332-87L11	SEAL, EXH TUBE HOUSING	1	
12	55127-87D00	UNION, SPEEDOMETER HOSE	1	
13	09355-40805-00B	HOSE (4X8X2000)	1	L:2000->1500
14	09362-09008	UNION	1	
15	09407-10404	CLAMP (L:100)	2	
16	09116-10137	BOLT (10X70)	1	W/TRANSOM(L)
17	09116-10150	BOLT (10X55)	4	W/TRANSOM(L)
18	09140-10031	NUT (M10)	5	W/TRANSOM(X)
19	09160-10141	WASHER (10.5X19X2)	5	W/TRANSOM(X)
20-1	58100-87LA0-019	PROPELLER (3X14X13)	1	
20-2	58100-87LB0-019	PROPELLER (3X13.875X15)	1	
20-3	58100-87LC0-019	PROPELLER (3X13.75X17)	1	
20-4	58100-87LD0-019	PROPELLER (3X13.75X19)	1	
20-5	58100-87LE0-019	PROPELLER (3X13.75X21)	1	
20-6	58100-87LF0-019	PROPELLER (3X13.75X23)	1	
20-7	58100-90JA0-019	PROPELLER (3X14X17)	1	OPT
20-8	58100-90JB0-019	PROPELLER (3X14X19)	1	OPT
20-9	58100-90JC0-019	PROPELLER (3X14X21)	1	OPT
20-10	58100-90JD0-019	PROPELLER (3X14X23)	1	OPT
20-11	58100-90JE0-019	PROPELLER (3X13.5X15)	1	OPT

NOTE : (DF70A,DF70ATH,DF80A:E01,DF90A,DF90ATH,DF100B):021

FIG.407B




FIG.407B (1-G-12) GEAR CASE (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20-12	58200-92J40	PROPELLER (3X13-7/8X15)	1	OPT,SUS
20-13	58200-92J50	PROPELLER (3X13-7/8X17)	1	OPT,SUS
20-14	58200-92J60	PROPELLER (3X13-7/8X19)	1	OPT,SUS
20-15	58200-92J70	PROPELLER (3X13-7/8X21)	1	OPT,SUS
20-16	58200-92J80	PROPELLER (3X13-7/8X23)	1	OPT,SUS
20-17	58200-92J90	PROPELLER (3X13-7/8X25)	1	OPT,SUS
21	58105-90J00	.BUSH SET, PROPELLER	1	
22	57632-87L01	STOPPER, PROPELLER BUSH	1	
23	57633-90J02	SPACER, PROPELLER NUT	1	
24	09141-18005	NUT	1	
25	09204-03003	PIN (D:3.6,L:25)	1	
26	09160-18028	WASHER (18.5X31X1.0)	1	
27	57630-90J00	KIT, PROPELLER NUT	1	OPT
28	25700-87L00	KIT, GEAR CASE SEALING	1	OPT,NOT ILLUSTRATED

NOTE : (DF70A,DF70ATH,DF80A:E01,DF90A,DF90ATH,DF100B):021

- DF70A E11
- DF70A E40
- DF70ATH E11
- DF80A E01
- DF90A E11
- DF90A E40
- DF90ATH E11
- DF90ATH E40
- DF100B E01
- DF100B E40



FIG.407C




FIG.407C (1-G-13) GEAR CASE ((DF70ATH,DF90ATH):E01:020)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55110-87L32-YAY	CASE, GEAR (BLACK)	1	
2	09263-26023	.BEARING (26X34X30)	1	
3	09202-08006	PIN (8X12)	2	
4	55125-90J01	TAB, TRIM	1	
5	09116-08137	BOLT (8X22)	1	
6	09248-10008	PLUG (10X7.5)	2	
7	09168-10022	GASKET (10X17X1.5)	2	
8-1	55321-87J01	ANODE	1	
8-2	55321-87J11	ANODE	1	OPT
9	09103-06281	BOLT (6X14)	1	
10	55333-87L00	PLATE, EXHAUST SEAL	1	
11	52332-87L11	SEAL, EXH TUBE HOUSING	1	
12	55127-87D00	UNION, SPEEDOMETER HOSE	1	
13	09355-40805-00B	HOSE (4X8X2000)	1	L:2000->1500
14	09362-09008	UNION	1	
15	09407-10404	CLAMP (L:100)	2	
16	09116-10137	BOLT (10X70)	1	
17	09116-10150	BOLT (10X55)	4	
18-1	58100-87LA0-019	PROPELLER (3X14X13)	1	
18-2	58100-87LB0-019	PROPELLER (3X13.875X15)	1	
18-3	58100-87LC0-019	PROPELLER (3X13.75X17)	1	
18-4	58100-87LD0-019	PROPELLER (3X13.75X19)	1	
18-5	58100-87LE0-019	PROPELLER (3X13.75X21)	1	
18-6	58100-87LF0-019	PROPELLER (3X13.75X23)	1	
18-7	58100-90JA0-019	PROPELLER (3X14X17)	1	OPT
18-8	58100-90JB0-019	PROPELLER (3X14X19)	1	OPT
18-9	58100-90JC0-019	PROPELLER (3X14X21)	1	OPT
18-10	58100-90JD0-019	PROPELLER (3X14X23)	1	OPT
18-11	58100-90JE0-019	PROPELLER (3X13.5X15)	1	OPT
18-12	58200-92J40	PROPELLER (3X13-7/8X15)	1	OPT,SUS
18-13	58200-92J50	PROPELLER (3X13-7/8X17)	1	OPT,SUS
18-14	58200-92J60	PROPELLER (3X13-7/8X19)	1	OPT,SUS
18-15	58200-92J70	PROPELLER (3X13-7/8X21)	1	OPT,SUS
18-16	58200-92J80	PROPELLER (3X13-7/8X23)	1	OPT,SUS
18-17	58200-92J90	PROPELLER (3X13-7/8X25)	1	OPT,SUS
19	58105-90J00	.BUSH SET, PROPELLER	1	

FIG.407C





FIG.407C (1-G-14) GEAR CASE ((DF70ATH,DF90ATH):E01:020)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	57632-87L01	STOPPER, PROPELLER BUSH	1	
21	57633-90J02	SPACER, PROPELLER NUT	1	
22	09141-18005	NUT	1	
23	09204-03003	PIN (D:3.6,L:25)	1	
24	09160-18028	WASHER (18.5X31X1.0)	1	
25	57630-90J00	KIT, PROPELLER NUT	1	OPT
26	25700-87L00	KIT, GEAR CASE SEALING	1	OPT,NOT ILLUSTRATED

DF70ATH E01
DF90ATH E01



FIG.407D



DF90A_E11_021_407D
GEAR CASE

FIG.407D (1-H-2) GEAR CASE (DF80A:E40:021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55110-87L40-YAY	CASE, GEAR (BLACK)	1	
2	09263-26023	.BEARING (26X34X30)	1	
3	09202-08006	PIN (8X12)	2	
4	55125-90J01	TAB, TRIM	1	
5	09116-08137	BOLT (8X22)	1	
6	09248-10008	PLUG (10X7.5)	2	
7	09168-10022	GASKET (10X17X1.5)	2	
8-1	55321-93J01	ANODE	1	
8-2	55321-87J11	ANODE	1	OPT
9	09116-06236	BOLT (6X16)	1	
10	55333-87L10	PLATE, EXHAUST SEAL	1	
11	55332-87L00	RUBBER, EXHAUST SEAL	1	
12	55127-87D00	UNION, SPEEDOMETER HOSE	1	
13	09355-40805-00B	HOSE (4X8X2000)	1	L:2000->1500
14	09362-09008	UNION	1	
15	09407-10404	CLAMP (L:100)	2	
16	09116-10137	BOLT (10X70)	1	W/TRANSOM(L)
17	09116-10150	BOLT (10X55)	4	W/TRANSOM(L)
18	09140-10031	NUT (M10)	5	W/TRANSOM(X)
19	09160-10141	WASHER (10.5X19X2)	5	W/TRANSOM(X)
20-1	58100-87LA0-019	PROPELLER (3X14X13)	1	
20-2	58100-87LB0-019	PROPELLER (3X13.875X15)	1	
20-3	58100-87LC0-019	PROPELLER (3X13.75X17)	1	
20-4	58100-87LD0-019	PROPELLER (3X13.75X19)	1	
20-5	58100-87LE0-019	PROPELLER (3X13.75X21)	1	
20-6	58100-87LF0-019	PROPELLER (3X13.75X23)	1	
20-7	58100-90JA0-019	PROPELLER (3X14X17)	1	OPT
20-8	58100-90JB0-019	PROPELLER (3X14X19)	1	OPT
20-9	58100-90JC0-019	PROPELLER (3X14X21)	1	OPT
20-10	58100-90JD0-019	PROPELLER (3X14X23)	1	OPT
20-11	58100-90JE0-019	PROPELLER (3X13.5X15)	1	OPT
20-12	58200-92J40	PROPELLER (3X13-7/8X15)	1	OPT,SUS
20-13	58200-92J50	PROPELLER (3X13-7/8X17)	1	OPT,SUS
20-14	58200-92J60	PROPELLER (3X13-7/8X19)	1	OPT,SUS
20-15	58200-92J70	PROPELLER (3X13-7/8X21)	1	OPT,SUS
20-16	58200-92J80	PROPELLER (3X13-7/8X23)	1	OPT,SUS

DF90A_E11_021

FIG.407D




FIG.407D (1-H-3) GEAR CASE (DF80A:E40:021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20-17	58200-92J90	PROPELLER (3X13-7/8X25)	1	OPT,SUS
21	58105-90J00	.BUSH SET, PROPELLER	1	
22	57632-87L01	STOPPER, PROPELLER BUSH	1	
23	57633-90J02	SPACER, PROPELLER NUT	1	
24	09141-18005	NUT	1	
25	09204-03003	PIN (D:3.6,L:25)	1	
26	09160-18028	WASHER (18.5X31X1.0)	1	
27	17570-87L00	CAP, WATER SUB	1	
28	17563-87D01	BUSH, WATER TUBE LOWER	1	
29	09125-06124	SCREW	1	
30	57630-90J00	KIT, PROPELLER NUT	1	OPT
31	25700-87L00	KIT, GEAR CASE SEALING	1	OPT,NOT ILLUSTRATED

DF80A E40

FIG.407E




FIG.407E (1-H-4) GEAR CASE (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55110-87L40-YAY	CASE, GEAR (BLACK)	1	
2	09263-26023	.BEARING (26X34X30)	1	
3	09202-08006	PIN (8X12)	2	
4	55125-90J01	TAB, TRIM	1	
5	09116-08137	BOLT (8X22)	1	
6	09248-10008	PLUG (10X7.5)	2	
7	09168-10022	GASKET (10X17X1.5)	2	
8-1	55321-93J01	ANODE	1	
8-2	55321-87J11	ANODE	1	OPT
9	09116-06236	BOLT (6X16)	1	
10	55333-87L10	PLATE, EXHAUST SEAL	1	
11	55332-87L00	RUBBER, EXHAUST SEAL	1	
12	55127-87D00	UNION, SPEEDOMETER HOSE	1	
13	09355-40805-00B	HOSE (4X8X2000)	1	L:2000->1500
14	09362-09008	UNION	1	
15	09407-10404	CLAMP (L:100)	2	
16	09116-10137	BOLT (10X70)	1	W/TRANSOM(L)
17	09116-10150	BOLT (10X55)	4	W/TRANSOM(L)
18	09140-10031	NUT (M10)	5	W/TRANSOM(X)
19	09160-10141	WASHER (10.5X19X2)	5	W/TRANSOM(X)
20-1	58100-87LA0-019	PROPELLER (3X14X13)	1	
20-2	58100-87LB0-019	PROPELLER (3X13.875X15)	1	
20-3	58100-87LC0-019	PROPELLER (3X13.75X17)	1	
20-4	58100-87LD0-019	PROPELLER (3X13.75X19)	1	
20-5	58100-87LE0-019	PROPELLER (3X13.75X21)	1	
20-6	58100-87LF0-019	PROPELLER (3X13.75X23)	1	
20-7	58100-90JA0-019	PROPELLER (3X14X17)	1	OPT
20-8	58100-90JB0-019	PROPELLER (3X14X19)	1	OPT
20-9	58100-90JC0-019	PROPELLER (3X14X21)	1	OPT
20-10	58100-90JD0-019	PROPELLER (3X14X23)	1	OPT
20-11	58100-90JE0-019	PROPELLER (3X13.5X15)	1	OPT
20-12	58200-92J40	PROPELLER (3X13-7/8X15)	1	OPT,SUS
20-13	58200-92J50	PROPELLER (3X13-7/8X17)	1	OPT,SUS
20-14	58200-92J60	PROPELLER (3X13-7/8X19)	1	OPT,SUS
20-15	58200-92J70	PROPELLER (3X13-7/8X21)	1	OPT,SUS
20-16	58200-92J80	PROPELLER (3X13-7/8X23)	1	OPT,SUS



FIG.407E





FIG.407E (1-H-5) GEAR CASE (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20-17	58200-92J90	PROPELLER (3X13-7/8X25)	1	OPT,SUS
21	58105-90J00	.BUSH SET, PROPELLER	1	
22	57632-87L01	STOPPER, PROPELLER BUSH	1	
23	57633-90J02	SPACER, PROPELLER NUT	1	
24	09141-18005	NUT	1	
25	09204-03003	PIN (D:3.6,L:25)	1	
26	09160-18028	WASHER (18.5X31X1.0)	1	
27	17570-87L00	CAP, WATER SUB	1	W/TRANSOM(X)
28	17563-87D01	BUSH, WATER TUBE LOWER	1	W/TRANSOM(X)
29	09125-06124	SCREW	1	
30	57630-90J00	KIT, PROPELLER NUT	1	OPT
31	25700-87L00	KIT, GEAR CASE SEALING	1	OPT,NOT ILLUSTRATED

DF90AWQH E40

FIG.410A



DF90A_E11_021_410A
SIDE COVER

FIG.410A (1-H-6) SIDE COVER (DF70A,DF80A,DF90A,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61112-99E01	RUBBER, SIDE COVER	1	
2	61134-87L01	SEAL, SIDE COVER	1	
3-1	61811-87L20-YAY	COVER, SIDE STBD (BLACK)	1	STBD
3-2	61811-87L20-Y5S	COVER, SIDE STBD (WHITE)	1	STBD
3-3	61811-87L20-QTN	COVER, SIDE STBD (WHITE)	1	STBD
4-1	61821-87L21-YAY	COVER, SIDE PORT (BLACK)	1	PORT
4-2	61821-87L21-Y5S	COVER, SIDE PORT (WHITE)	1	PORT
4-3	61821-87L21-QTN	COVER, SIDE PORT (WHITE)	1	PORT
5	09136-06148	SCREW (6X35)	8	
6	09136-06149	SCREW (6X55)	2	
7	09136-06161	SCREW (6X17)	3	
8	09321-08022	CUSHION	2	
9	61827-87L00	HOLDER, SIDE COVER	1	
10	01550-0820C	BOLT	2	
11-1	61831-87L20-YAY	PANEL, FRONT (BLACK)	1	
11-2	61831-87L20-Y5S	PANEL, FRONT (WHITE)	1	
11-3	61831-87L20-QTN	PANEL, FRONT (WHITE)	1	
12	09116-08174	BOLT (8X38)	2	
13	09169-08050	WASHER	2	
14	09320-11023	CUSHION	2	
15	17913-93J00	PLUG, WATER	1	
16	17914-93J01	GASKET, WATER PLUG	1	
17	61632-93J00	SHAFT, ENGINE COVER HOOK	2	
18	61641-87L00	HOOK, ENGINE COVER	2	
19	09116-06127	BOLT (6X12)	2	
20	61633-87L00	LEVER, HOOK REAR	1	
21	61645-87L00	LEVER, HOOK FRONT	1	
22	61673-93J11	LATCH, HOOK LEVER	2	
23	09160-13014	WASHER (13.2X25X1)	2	
24	09164-14008	WASHER	2	
25	09202-04022	PIN	2	
26	09306-13007	BUSH	2	
27	09103-05026	BOLT (5X10)	2	
28	09103-05027	BOLT (5X16)	2	
29	61124-87L20	GROMMET, R/CON CABLE	1	
30	09407-25402	CLAMP (L:250)	1	

DF90A_E11_021

FIG.410A




FIG.410A (1-H-7) SIDE COVER (DF70A,DF80A,DF90A,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	67341-87L00	HOLDER, R/CON CABLE	1	
32	01550-0616C	BOLT	2	
33	67345-87L00	PROTECTOR	1	
34	67346-87L01	PROTECTOR, HOLDER	1	
35	09409-10304-5ES	CLIP (4.7X11) (BLACK)	1	
36	67350-87L02	STOPPER, R/CON CABLE	1	
37	09352-70104-600	.HOSE (7X10.2X600)	2	L:600->14
38	01570-06127	BOLT	1	
39	09403-11320	CLAMP	1	
40	17917-87L00	CONNECTOR, FLUSH WATER	1	
41	67361-90J10	ADAPTER, HOSE	1	OPT
42	09208-06009	PIN	2	OPT
43	09383-04002	E RING	2	OPT

- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF100B E01
- DF100B E40

FIG.410B




FIG.410B (1-H-8) SIDE COVER (DF70ATH,DF90ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61112-99E01	RUBBER, SIDE COVER	1	
2	61134-87L01	SEAL, SIDE COVER	1	
3	61811-87L20-YAY	COVER, SIDE STBD (BLACK)	1	STBD
4	61821-87L21-YAY	COVER, SIDE PORT (BLACK)	1	PORT
5	09136-06148	SCREW (6X35)	8	
6	09136-06149	SCREW (6X55)	2	
7	09136-06161	SCREW (6X17)	3	
8	09321-08022	CUSHION	2	
9	61827-87L00	HOLDER, SIDE COVER	1	
10	01550-0820C	BOLT	2	
11	61831-87L20-YAY	PANEL, FRONT (BLACK)	1	
12	09116-08174	BOLT (8X38)	2	
13	09169-08050	WASHER	2	
14	09320-11023	CUSHION	2	
15	17913-93J00	PLUG, WATER	1	
16	17914-93J01	GASKET, WATER PLUG	1	
17	61632-93J00	SHAFT, ENGINE COVER HOOK	2	
18	61641-87L00	HOOK, ENGINE COVER	2	
19	09116-06127	BOLT (6X12)	2	
20	61633-87L00	LEVER, HOOK REAR	1	
21	61645-87L00	LEVER, HOOK FRONT	1	
22	61673-93J11	LATCH, HOOK LEVER	2	
23	09160-13014	WASHER (13.2X25X1)	2	
24	09164-14008	WASHER	2	
25	09202-04022	PIN	2	
26	09306-13007	BUSH	2	
27	09103-05026	BOLT (5X10)	2	
28	09103-05027	BOLT (5X16)	2	
29	61124-87L20	GROMMET, R/CON CABLE	1	
30	09407-25402	CLAMP (L:250)	1	
31	67341-87L00	HOLDER, R/CON CABLE	1	
32	01550-0616C	BOLT	2	
33	67345-87L00	PROTECTOR	1	
34	67346-87L01	PROTECTOR, HOLDER	1	
35	09409-10304-5ES	CLIP (4.7X11) (BLACK)	1	
36	67350-87L02	STOPPER, R/CON CABLE	1	

FIG.410B




FIG.410B (1-H-9) SIDE COVER (DF70ATH,DF90ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
37	09352-70104-600	.HOSE (7X10.2X600)	2	L:600->14
38	01570-06127	BOLT	1	
39	09403-11320	CLAMP	1	
40	17917-87L00	CONNECTOR, FLUSH WATER	1	
41	67300-98J10	KIT, HOSE ADAPTER	1	OPT
42	67361-90J10	.ADAPTER, HOSE	1	OPT
43	09208-06009	.PIN	2	OPT
44	09383-04002	.E RING	2	OPT

DF70ATH E01
DF70ATH E11
DF70ATH E40
DF90ATH E01
DF90ATH E11
DF90ATH E40

FIG.410C




FIG.410C (1-H-10) SIDE COVER (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61112-99E01	RUBBER, SIDE COVER	1	
2	61134-87L01	SEAL, SIDE COVER	1	
3	61811-87L20-YAY	COVER, SIDE STBD (BLACK)	1	STBD
4	61821-87L30-YAY	COVER, SIDE PORT (BLACK)	1	PORT
5	09136-06148	SCREW (6X35)	8	
6	09136-06149	SCREW (6X55)	2	
7	09136-06161	SCREW (6X17)	3	
8	09321-08022	CUSHION	2	
9	61827-87L00	HOLDER, SIDE COVER	1	
10	01550-0820C	BOLT	2	
11	61831-87L20-YAY	PANEL, FRONT (BLACK)	1	
12	09116-08174	BOLT (8X38)	2	
13	09169-08050	WASHER	2	
14	09320-11023	CUSHION	2	
15	17913-93J00	PLUG, WATER	1	
16	17914-93J01	GASKET, WATER PLUG	1	
17	61632-93J00	SHAFT, ENGINE COVER HOOK	2	
18	61641-87L00	HOOK, ENGINE COVER	2	
19	09116-06127	BOLT (6X12)	2	
20	61633-87L00	LEVER, HOOK REAR	1	
21	61645-87L00	LEVER, HOOK FRONT	1	
22	61673-93J11	LATCH, HOOK LEVER	2	
23	09160-13014	WASHER (13.2X25X1)	2	
24	09164-14008	WASHER	2	
25	09202-04022	PIN	2	
26	09306-13007	BUSH	2	
27	09103-05026	BOLT (5X10)	2	
28	09103-05027	BOLT (5X16)	2	
29	61124-87L20	GROMMET, R/CON CABLE	1	
30	09407-25402	CLAMP (L:250)	1	
31	67341-87L00	HOLDER, R/CON CABLE	1	
32	01550-0616C	BOLT	2	
33	67345-87L00	PROTECTOR	1	
34	67346-87L01	PROTECTOR, HOLDER	1	
35	09409-10304-5ES	CLIP (4.7X11) (BLACK)	1	
36	67350-87L02	STOPPER, R/CON CABLE	1	

FIG.410C

FIG.410C (1-H-11) SIDE COVER (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
37	09352-70104-600	.HOSE (7X10.2X600)	2	L:600->14
38	01570-06127	BOLT	1	
39	09403-11320	CLAMP	1	
40	17917-87L00	CONNECTOR, FLUSH WATER	1	
41	67300-98J10	KIT, HOSE ADAPTER	1	OPT
42	67361-90J10	.ADAPTER, HOSE	1	OPT
43	09208-06009	.PIN	2	OPT
44	09383-04002	.E RING	2	OPT

DF90AWQH E40




FIG.420A




FIG.420A (1-H-12) ENGINE COVER ((DF70A,DF70ATH):020)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61401-87Y01-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61401-87Y11-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-87L21-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-87L21-Y5S	.HANDLE, TILT UP (WHITE)	1	
3	61439-87L00	.SEAL, TILT UP HANDLE	1	
4	01550-0616C	.BOLT	4	
5	61476-87L00	.SEAL, AIR VENT	1	
6	61610-93J00	.FASTENER	2	
7	09329-10024	.CUSHION	2	
8	01550-0612C	.BOLT	2	
9-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	FOR YAY
9-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	FOR Y5S
10-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	FOR YAY
10-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	FOR Y5S
11	68111-87L00	.EMBLEM, "S"	1	
12	61621-87L00	.BRACKET, FASTENER	2	
13	09229-04025	.RIVET	4	
14-1	61435-87LB0	MARK, EMBLEM FRONT & REAR	2	FOR YAY
14-2	61435-87LE0	MARK, EMBLEM FRONT & REAR	2	FOR Y5S
15	61458-90J01	LABEL, ENGINE COVER	1	
16	09800-81841	TOOL SET	1	
17-1	99011-87L80-054	MANUAL, OWNER'S	1	
17-2	99011-87L80-059	MANUAL, OWNER'S	1	
17-3	99011-87L80-03B	MANUAL, OWNER'S	1	

DF70A E01
DF70A E03
DF70A E40
DF70ATH E01
DF70ATH E40

FIG.420B




FIG.420B (1-H-13) ENGINE COVER ((DF70A,DF70ATH):021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61401-87Y50-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61401-87Y60-QTN	COVER SET, ENGINE (WHITE)	1	
2-1	61431-87L21-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-87L21-QTN	.HANDLE, TILT UP (WHITE)	1	
3	61439-87L00	.SEAL, TILT UP HANDLE	1	
4	01550-0616C	.BOLT	4	
5	61476-87L00	.SEAL, AIR VENT	1	
6	61610-93J00	.FASTENER	2	
7	09329-10024	.CUSHION	2	
8	01550-0612C	.BOLT	2	
9-1	61443-88L40	.STRIPE, ENGINE COVER STBD	1	FOR YAY
9-2	61443-88L50	.STRIPE, ENGINE COVER STBD	1	FOR QTN
10-1	61453-88L40	.STRIPE, ENGINE COVER PORT	1	FOR YAY
10-2	61453-88L50	.STRIPE, ENGINE COVER PORT	1	FOR QTN
11	68111-87L00	.EMBLEM, "S"	1	
12	61621-87L00	.BRACKET, FASTENER	2	
13	09229-04056	.RIVET	4	
14-1	61435-87LG0	MARK, EMBLEM REAR	1	FOR YAY
14-2	61435-87LH0	MARK, EMBLEM REAR	1	FOR QTN
15	61458-90J01	LABEL, ENGINE COVER	1	
16	09800-81841	TOOL SET	1	
17-1	99011-87L90-054	MANUAL, OWNER'S	1	
17-2	99011-87L90-059	MANUAL, OWNER'S	1	
17-3	99011-87L90-03B	MANUAL, OWNER'S	1	

DF70A E11
DF70A E40
DF70ATH E11

FIG.420C





FIG.420C (1-H-14) ENGINE COVER (DF80A:020)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61401-87Y01-YAY	COVER SET, ENGINE (BLACK)	1	
2	61431-87L21-YAY	.HANDLE, TILT UP (BLACK)	1	
3	61439-87L00	.SEAL, TILT UP HANDLE	1	
4	01550-0616C	.BOLT	4	
5	61476-87L00	.SEAL, AIR VENT	1	
6	61610-93J00	.FASTENER	2	
7	09329-10024	.CUSHION	2	
8	01550-0612C	.BOLT	2	
9	61443-88L20	.STRIPE, ENGINE COVER STBD	1	STBD
10	61453-88L20	.STRIPE, ENGINE COVER PORT	1	PORT
11	68111-87L00	.EMBLEM, "S"	1	
12	61621-87L00	.BRACKET, FASTENER	2	
13	09229-04025	.RIVET	4	
14	61435-87LC0	MARK, EMBLEM FRONT & REAR	2	
15	61458-90J01	LABEL, ENGINE COVER	1	
16	09800-81841	TOOL SET	1	
17-1	99011-87L80-054	MANUAL, OWNER'S	1	
17-2	99011-87L80-059	MANUAL, OWNER'S	1	

DF80A E01
DF80A E40

FIG.420D



DF90A_E11_021_420D
ENGINE COVER

FIG.420D (1-1-2) ENGINE COVER (DF80A:021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61401-87Y50-YAY	COVER SET, ENGINE (BLACK)	1	
2	61431-87L21-YAY	.HANDLE, TILT UP (BLACK)	1	
3	61439-87L00	.SEAL, TILT UP HANDLE	1	
4	01550-0616C	.BOLT	4	
5	61476-87L00	.SEAL, AIR VENT	1	
6	61610-93J00	.FASTENER	2	
7	09329-10024	.CUSHION	2	
8	01550-0612C	.BOLT	2	
9	61443-88L40	.STRIPE, ENGINE COVER STBD	1	
10	61453-88L40	.STRIPE, ENGINE COVER PORT	1	
11	68111-87L00	.EMBLEM, "S"	1	
12	61621-87L00	.BRACKET, FASTENER	2	
13	09229-04056	.RIVET	4	
14	61435-87LJ0	MARK, EMBLEM REAR	1	
15	61458-90J01	LABEL, ENGINE COVER	1	
16	09800-81841	TOOL SET	1	
17-1	99011-87L90-054	MANUAL, OWNER'S	1	
17-2	99011-87L90-059	MANUAL, OWNER'S	1	

DF80A E01
DF80A E40

FIG.420E




FIG.420E (1-1-3) ENGINE COVER ((DF90A,DF90ATH):020)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1-1	61401-87Y01-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61401-87Y11-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-87L21-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-87L21-Y5S	.HANDLE, TILT UP (WHITE)	1	
3	61439-87L00	.SEAL, TILT UP HANDLE	1	
4	01550-0616C	.BOLT	4	
5	61476-87L00	.SEAL, AIR VENT	1	
6	61610-93J00	.FASTENER	2	
7	09329-10024	.CUSHION	2	
8	01550-0612C	.BOLT	2	
9-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	FOR YAY
9-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	FOR Y5S
10-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	FOR YAY
10-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	FOR Y5S
11	68111-87L00	.EMBLEM, "S"	1	
12	61621-87L00	.BRACKET, FASTENER	2	
13	09229-04025	.RIVET	4	
14-1	61435-87LD0	MARK, EMBLEM FRONT & REAR	2	FOR YAY
14-2	61435-87LF0	MARK, EMBLEM FRONT & REAR	2	FOR Y5S
15	61458-90J01	LABEL, ENGINE COVER	1	
16	09800-81841	TOOL SET	1	
17-1	99011-87L80-054	MANUAL, OWNER'S	1	
17-2	99011-87L80-059	MANUAL, OWNER'S	1	
17-3	99011-87L80-03B	MANUAL, OWNER'S	1	

DF90A E01
DF90A E03
DF90A E40
DF90ATH E01
DF90ATH E40

FIG.420F




FIG.420F (1-1-4) ENGINE COVER ((DF90A,DF90ATH):021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61401-87Y50-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61401-87Y60-QTN	COVER SET, ENGINE (WHITE)	1	
2-1	61431-87L21-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-87L21-QTN	.HANDLE, TILT UP (WHITE)	1	
3	61439-87L00	.SEAL, TILT UP HANDLE	1	
4	01550-0616C	.BOLT	4	
5	61476-87L00	.SEAL, AIR VENT	1	
6	61610-93J00	.FASTENER	2	
7	09329-10024	.CUSHION	2	
8	01550-0612C	.BOLT	2	
9-1	61443-88L40	.STRIPE, ENGINE COVER STBD	1	FOR YAY
9-2	61443-88L50	.STRIPE, ENGINE COVER STBD	1	FOR QTN
10-1	61453-88L40	.STRIPE, ENGINE COVER PORT	1	FOR YAY
10-2	61453-88L50	.STRIPE, ENGINE COVER PORT	1	FOR QTN
11	68111-87L00	.EMBLEM, "S"	1	
12	61621-87L00	.BRACKET, FASTENER	2	
13	09229-04056	.RIVET	4	
14-1	61435-87LK0	MARK, EMBLEM REAR	1	FOR YAY
14-2	61435-87LL0	MARK, EMBLEM REAR	1	FOR QTN
15	61458-90J01	LABEL, ENGINE COVER	1	
16	09800-81841	TOOL SET	1	
17-1	99011-87L90-054	MANUAL, OWNER'S	1	
17-2	99011-87L90-059	MANUAL, OWNER'S	1	
17-3	99011-87L90-03B	MANUAL, OWNER'S	1	

DF90A E11
DF90A E40
DF90ATH E11
DF90ATH E40

FIG.420G




FIG.420G (1-I-5) ENGINE COVER (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61401-87Y40-YAY	COVER SET, ENGINE (BLACK)	1	
2	61431-87L21-YAY	.HANDLE, TILT UP (BLACK)	1	
3	61439-87L00	.SEAL, TILT UP HANDLE	1	
4	01550-0616C	.BOLT	4	
5	61476-87L00	.SEAL, AIR VENT	1	
6	61610-93J00	.FASTENER	2	
7	09329-10024	.CUSHION	2	
8	01550-0612C	.BOLT	2	
9	61443-88L20	.STRIPE, ENGINE COVER STBD	1	STBD
10	61453-88L20	.STRIPE, ENGINE COVER PORT	1	PORT
11	68111-87L00	.EMBLEM, "S"	1	
12	61621-87L00	.BRACKET, FASTENER	2	
13	09229-04056	.RIVET	4	
14	61435-87LD0	MARK, EMBLEM FRONT & REAR	2	
15	61458-90J01	LABEL, ENGINE COVER	1	
16	09800-81841	TOOL SET	1	
17	99011-87L90-059	MANUAL, OWNER'S	1	
18	61424-87L00	MARK, EMBLEM	1	

DF90AWQH E40

FIG.420H




FIG.420H (1-1-6) ENGINE COVER (DF100B:020)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61401-87Y01-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61401-87Y11-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-87L21-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-87L21-Y5S	.HANDLE, TILT UP (WHITE)	1	
3	61439-87L00	.SEAL, TILT UP HANDLE	1	
4	01550-0616C	.BOLT	4	
5	61476-87L00	.SEAL, AIR VENT	1	
6	61610-93J00	.FASTENER	2	
7	09329-10024	.CUSHION	2	
8	01550-0612C	.BOLT	2	
9-1	61443-88L20	.STRIPE, ENGINE COVER STBD	1	FOR YAY
9-2	61443-88L30	.STRIPE, ENGINE COVER STBD	1	FOR Y5S
10-1	61453-88L20	.STRIPE, ENGINE COVER PORT	1	FOR YAY
10-2	61453-88L30	.STRIPE, ENGINE COVER PORT	1	FOR Y5S
11	68111-87L00	.EMBLEM, "S"	1	
12	61621-87L00	.BRACKET, FASTENER	2	
13	09229-04025	.RIVET	4	
14-1	61422-90J40	MARK, EMBLEM FRONT	2	FOR YAY
14-2	61422-87L90	MARK, EMBLEM FRONT	2	FOR Y5S
15	61458-90J01	LABEL, ENGINE COVER	1	
16	09800-81841	TOOL SET	1	
17-1	99011-87L80-054	MANUAL, OWNER'S	1	
17-2	99011-87L80-059	MANUAL, OWNER'S	1	

DF100B E01
DF100B E40

FIG.420J




FIG.420J (1-I-7) ENGINE COVER (DF100B:021)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61401-87Y50-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61401-87Y60-QTN	COVER SET, ENGINE (WHITE)	1	
2-1	61431-87L21-YAY	.HANDLE, TILT UP (BLACK)	1	
2-2	61431-87L21-QTN	.HANDLE, TILT UP (WHITE)	1	
3	61439-87L00	.SEAL, TILT UP HANDLE	1	
4	01550-0616C	.BOLT	4	
5	61476-87L00	.SEAL, AIR VENT	1	
6	61610-93J00	.FASTENER	2	
7	09329-10024	.CUSHION	2	
8	01550-0612C	.BOLT	2	
9-1	61443-88L40	.STRIPE, ENGINE COVER STBD	1	FOR YAY
9-2	61443-88L50	.STRIPE, ENGINE COVER STBD	1	FOR QTN
10-1	61453-88L40	.STRIPE, ENGINE COVER PORT	1	FOR YAY
10-2	61453-88L50	.STRIPE, ENGINE COVER PORT	1	FOR QTN
11	68111-87L00	.EMBLEM, "S"	1	
12	61621-87L00	.BRACKET, FASTENER	2	
13	09229-04056	.RIVET	4	
14-1	61435-87LM0	MARK, EMBLEM REAR	1	FOR YAY
14-2	61435-87LN0	MARK, EMBLEM REAR	1	FOR QTN
15	61458-90J01	LABEL, ENGINE COVER	1	
16	09800-81841	TOOL SET	1	
17-1	99011-87L90-054	MANUAL, OWNER'S	1	
17-2	99011-87L90-059	MANUAL, OWNER'S	1	

DF100B E01
DF100B E40

FIG.432A




FIG.432A (1-I-8) FUEL TANK (E01,E11,E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65000-94L10	TANK ASSY, FUEL (25L)	1	
2	65520-99100	.CAP ASSY, FUEL TANK	1	
3	65561-95D00	.GASKET, TANK CAP	1	
4	65740-95D01	.PLUG, FUEL CONNECTOR	1	
5	09401-11423	CLIP	1	
6	65700-90J24	HOSE, FUEL	1	
7	65750-95501	.SOCKET, FUEL HOSE	1	
8	65770-90J13	.PUMP, SQUEEZE	1	

- DF70A E01
- DF70A E11
- DF70A E40
- DF70ATH E01
- DF70ATH E11
- DF70ATH E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E11
- DF90A E40
- DF90ATH E01
- DF90ATH E11
- DF90ATH E40
- DF90AWQH E40
- DF100B E01
- DF100B E40

FIG.442A





FIG.442A (1-I-9) DRAG LINK (DF70A,DF80A,DF90A,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-87L01	LINK ASSY, DRAG	1	
3	67721-87L00	.SPACER, DRAG LINK	1	
4	67725-99E20	.BOLT, DRAG LINK	1	
5	67726-99E00	.NUT, LOCK	2	
6	67728-99E00	.WASHER	4	
7	67467-89J01	CONNECTOR	2	
8	09385-06012	CLIP	2	
9	09160-06055	WASHER (7X12X1.0)	2	


- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF100B E01
- DF100B E40

FIG.442B (1-I-10) DRAG LINK (DF70ATH,DF90ATH)



DF90A_E11_021

FIG.444A



DF90A_E11_021_444A
TILLER HANDLE

FIG.444A (1-I-11) TILLER HANDLE (DF70ATH,DF90ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	43761-88L01-YAY	BRACKET, TILLER HANDLE (BLACK)	1	
2	63110-87L15-YAY	HANDLE ASSY, TILLER (BLACK)	1	
3	21110-88L00	.LEVER, SHIFT	1	
4	23230-90J10	.CABLE, SHIFT	1	
5	36620-87L01	.WIRE ASSY, HANDLE	1	
6	37110-87L02	.SWITCH ASSY, IGNITION	1	
7-1	37141-99E00	..KEY (931)	1	
7-2	37141-99E10	..KEY (932)	1	
7-3	37141-99E20	..KEY (933)	1	
7-4	37141-99E30	..KEY (934)	1	
7-5	37141-99E40	..KEY (935)	1	
7-6	37141-99E50	..KEY (936)	1	
7-7	37141-99E60	..KEY (937)	1	
7-8	37141-99E70	..KEY (938)	1	
7-9	37141-99E80	..KEY (939)	1	
7-10	37141-99E90	..KEY (940)	1	
7-11	37141-99EA0	..KEY (941)	1	
7-12	37141-99EB0	..KEY (942)	1	
8	37143-99E01	..CAP, KEY	1	
9	37149-93J00	..CAP, CYLINDER BODY	1	
10	37820-87L11	.SWITCH ASSY, EMERGENCY	1	
11	37823-92E02	..PLATE ASSY, EMERGENCY SW	1	
		LOCK		
12	37826-92J10	..NUT	1	
13	38500-93J90	.BUZZER, WARNING	1	
14	37850-87L01	.SWITCH ASSY, PTT	1	
15	37852-87J00	.PLATE, TRIM SWITCH	1	
16	63121-88L10	.COVER, UNDER	1	
17	63210-88L00	.GRIP, HANDLE	1	
18	63221-88L00	.SHAFT, THROTTLE	1	
19	63223-92D00	.STOPPER, HANDLE ROD	1	
20	63225-88L00	.BUSH, HANDLE ROD	1	
21	63227-93200	.PIN, HANDLE ROD	1	
22	63235-88L00	.PLATE, THROTTLE SHAFT	1	
23	63246-88L00	.STOPPER, THROTTLE ADJUST	1	
24	63250-88L00	.ARM ASSY, THROTTLE	1	

DF90A_E11_021

FIG.444A




FIG.444A (1-I-12) TILLER HANDLE (DF70ATH,DF90ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25	63251-87J00	.BOLT, SHIFT GEAR ASSY	4	
26	63260-88L00	.GEAR ASSY, SHIFT	1	
27	63272-87J00	.PLATE, BALL GUIDE	1	
28	63273-87J00	.BALL	1	
29	63262-87J00	.BUSH, SHIFT LEVER	1	
30	63271-87J00	.PLATE, LOCK	1	
31	63248-99J00	.PLATE, THROTTLE ADJ NOTCH	1	
32	63261-87J00	.BUSH, SHIFT GEAR	1	
33	63274-87J00	.E RING	1	
34	63610-87J00	.CABLE, THROTTLE	1	
35	37853-88L90	.GROMMET, PTT SW LEAD	1	
36	63626-88L00	.GROMMET, CABLE	1	
37	67292-87J00	.E RING	2	
38	09126-06015	.SCREW (6X23)	1	
39	09163-06001	.LOCK WASHER (6.4X12X0.5)	1	
40	09440-12027	.SPRING	1	
41	21112-88L00	.BOLT, SHIFT LEVER	1	
42	09125-05047	.SCREW (5X14)	6	
43	63611-88L00	.BOLT, CLAMP BRACKET	3	
44	63612-87J00	.BRACKET, CLAMP	1	
45	34200-87L00	.TACHOMETER ASSY, WITH MONITOR	1	
46	36617-88L90	.CLAMP, MAIN HARNESS	1	
47	37112-88L91	.LABEL, IGNITION SW	1	
48	37835-91J00-YAY	.LABEL, STOP (BLACK)	1	
49	37851-88L90	.BASE, PTT SW	1	
50	37852-88L90	.HARNESS GUIDE	1	
51	37861-87L11	.SWITCH, TROLLING CONTROL	1	
52	37864-88L91	.LABEL, TROLL MODE	1	
53	63244-99J00	.KNOB, THROTTLE ADJ	1	
54	63245-99J00	.BUSH, THROTTLE ADJ	1	
55	63612-88L10	.BRACKET, CLAMP SHIFT	1	
56	09260-10006	.BALL	1	
57	63251-88L90	.BOLT	2	
58	37855-88L90	.SCREW, THROTTLE GRIP	1	
59	37854-88L90	.WASHER, THROTTLE GRIP	1	
60	63258-88L00	.WASHER	1	

FIG.444A




FIG.444A (1-I-13) TILLER HANDLE (DF70ATH,DF90ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
61	09440-06037	.SPRING	1	
62	03522-05169	.SCREW	3	
63	63247-99J00	.PLATE, THROTTLE ADJ KNOB	1	
64	63111-88L00-YAY	.HOUSING, TILLER HANDLE (BLACK)	1	
65	09116-08137	BOLT (8X22)	1	
66	09159-12014	NUT	1	
67	09160-12066	WASHER (12.5X22X2.5)	2	
68	09160-12124	WASHER (12.5X32X1.5)	1	
69	63115-88L01	BUSH, TILLER HANDLE PIVOT	2	
70	09164-13010	WASHER	1	
71	21131-88L02	MARK, CLUTCH SHIFT	1	
72	63215-93110	MARK, HANDLE GRIP	1	
73	43776-87L00	SPACER, STEERING BRACKET	1	
74	09116-10150	BOLT (10X55)	2	
75	43770-99E03	ADJUSTER ASSY, STEERING	1	
76	63132-88L00	STOPPER, TILLER HANDLE	1	
77	43762-88L00	BOLT, TILLER HANDLE PIVOT	1	
78	43768-88L00	SPACER, TILLER HANDLE	1	

DF70ATH E01
DF70ATH E11
DF70ATH E40
DF90ATH E01
DF90ATH E11
DF90ATH E40

FIG.444B




FIG.444B (1-14) TILLER HANDLE (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	43761-87L00-YAY	BRACKET, TILLER HANDLE (BLACK)	1	
2	63110-87L20-YAY	HANDLE ASSY, TILLER (BLACK)	1	
3	21110-88L00	.LEVER, SHIFT	1	
4	23230-90J10	.CABLE, SHIFT	1	
5	36620-87L10	.WIRE ASSY, HARNESS	1	
6	37110-87L02	.SWITCH ASSY, IGNITION	1	
7-1	37141-99E00	..KEY (931)	1	
7-2	37141-99E10	..KEY (932)	1	
7-3	37141-99E20	..KEY (933)	1	
7-4	37141-99E30	..KEY (934)	1	
7-5	37141-99E40	..KEY (935)	1	
7-6	37141-99E50	..KEY (936)	1	
7-7	37141-99E60	..KEY (937)	1	
7-8	37141-99E70	..KEY (938)	1	
7-9	37141-99E80	..KEY (939)	1	
7-10	37141-99E90	..KEY (940)	1	
7-11	37141-99EA0	..KEY (941)	1	
7-12	37141-99EB0	..KEY (942)	1	
8	37143-99E01	..CAP, KEY	1	
9	37149-93J00	..CAP, CYLINDER BODY	1	
10	37820-87L11	.SWITCH ASSY, EMERGENCY	1	
11	37823-92E02	..PLATE ASSY, EMERGENCY SW	1	
12	37826-92J10	LOCK	1	
13	38500-93J90	..NUT	1	
14	67263-88L00	.BUZZER, WARNING	1	
15	37852-87J00	.CAP, SWITCH	1	
16	37852-87J00	.PLATE, TRIM SWITCH	1	
17	63121-88L10	.COVER, UNDER	1	
18	63210-88L00	.GRIP, HANDLE	1	
19	63221-88L00	.SHAFT, THROTTLE	1	
20	63223-92D00	.STOPPER, HANDLE ROD	1	
21	63225-88L00	.BUSH, HANDLE ROD	1	
22	63227-93200	.PIN, HANDLE ROD	1	
23	63235-88L00	.PLATE, THROTTLE SHAFT	1	
24	63246-88L00	.STOPPER, THROTTLE ADJUST	1	
25	63250-88L00	.ARM ASSY, THROTTLE	1	

FIG.444B




FIG.444B (1-15) TILLER HANDLE (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25	63251-87J00	.BOLT, SHIFT GEAR ASSY	4	
26	63260-88L00	.GEAR ASSY, SHIFT	1	
27	63272-87J00	..PLATE, BALL GUIDE	1	
28	63273-87J00	..BALL	1	
29	63262-87J00	.BUSH, SHIFT LEVER	1	
30	63271-87J00	.PLATE, LOCK	1	
31	63248-99J00	.PLATE, THROTTLE ADJ NOTCH	1	
32	63261-87J00	.BUSH, SHIFT GEAR	1	
33	63274-87J00	.E RING	1	
34	63610-87J00	.CABLE, THROTTLE	1	
35	37853-88L90	.GROMMET, PTT SW LEAD	1	
36	63626-88L00	.GROMMET, CABLE	1	
37	67292-87J00	.E RING	2	
38	09126-06015	.SCREW (6X23)	1	
39	09163-06001	.LOCK WASHER (6.4X12X0.5)	1	
40	09440-12027	.SPRING	1	
41	21112-88L10	.BOLT, SHIFT LEVER	1	
42	09125-05047	.SCREW (5X14)	6	
43	63611-88L00	.BOLT, CLAMP BRACKET	3	
44	63612-87J00	.BRACKET, CLAMP	1	
45	36360-87L00	.WARNING INDICATOR	1	
46	36617-88L90	.CLAMP, MAIN HARNESS	1	
47	37112-88L91	.LABEL, IGNITION SW	1	
48	37835-91J00-YAY	.LABEL, STOP (BLACK)	1	
49	37851-88L90	.BASE, PTT SW	1	
50	67263-88L00	.CAP, SWITCH	1	
51	63244-99J00	.KNOB, THROTTLE ADJ	1	
52	63245-99J00	.BUSH, THROTTLE ADJ	1	
53	63612-88L10	.BRACKET, CLAMP SHIFT	1	
54	09260-10006	.BALL	1	
55	63251-88L90	.BOLT	2	
56	37855-88L90	.SCREW, THROTTLE GRIP	1	
57	37854-88L90	.WASHER, THROTTLE GRIP	1	
58	63258-88L00	.WASHER	1	
59	09440-06037	.SPRING	1	
60	03522-05169	.SCREW	3	

FIG.444B




FIG.444B (1-J-2) TILLER HANDLE (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
61	63247-99J00	.PLATE, THROTTLE ADJ KNOB	1	
62	63111-88L00-YAY	.HOUSING, TILLER HANDLE (BLACK)	1	
63	09116-08137	BOLT (8X22)	1	
64	09159-12014	NUT	1	
65	09160-12066	WASHER (12.5X22X2.5)	2	
66	09160-12124	WASHER (12.5X32X1.5)	1	
67	63115-88L01	BUSH, TILLER HANDLE PIVOT	2	
68	09164-13010	WASHER	1	
69	21131-88L02	MARK, CLUTCH SHIFT	1	
70	63215-93110	MARK, HANDLE GRIP	1	
71	09116-10150	BOLT (10X55)	2	
72	63132-88L00	STOPPER, TILLER HANDLE	1	
73	43762-88L00	BOLT, TILLER HANDLE PIVOT	1	
74	43768-88L00	SPACER, TILLER HANDLE	1	
75	09202-08006	PIN (8X12)	2	
76	34200-87L00	TACHOMETER ASSY, WITH MONITOR	1	OPT
77	37861-87L11	SWITCH, TROLLING CONTROL	1	OPT
78	37864-88L91	LABEL, TROLL MODE	1	OPT

DF90AWQH E40

FIG.460A




FIG.460A (1-J-3) METER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34800-93J02	METER ASSY, TRIM	1	BLACK
1-2	34800-93J13	METER ASSY, TRIM	1	WHITE
2	09471-12108	.BULB (12V1.7W,T6.5)	1	
3-1	34500-93J02	METER ASSY, HOUR	1	BLACK
3-2	34500-93J13	METER ASSY, HOUR	1	WHITE
4	09471-12103	.BULB (12V3W,T6.5)	1	
5-1	34200-93J02	TACHOMETER ASSY, WITH MONITOR	1	BLACK
5-2	34200-93J14	TACHOMETER ASSY, WITH MONITOR	1	WHITE
6	09471-12077	.BULB (12V1.7W,T10)	1	

NOTE : (DF70A,DF90A):(E01,E11,E40),DF80A,DF100B

- DF70A E01
- DF70A E11
- DF70A E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E11
- DF90A E40
- DF100B E01
- DF100B E40

FIG.475A

FIG.475A (1-J-4) SQUEEZE PUMP ((E03,E11):N/TANK)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65770-90J04	PUMP, SQUEEZE	1	

- DF70A E03
- DF70A E11
- DF70ATH E11
- DF90A E03
- DF90A E11
- DF90ATH E11




FIG.501A




FIG.501A (1-J-5) OPT:METER (DF70A,DF80A,DF90A,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34800-93J02	METER ASSY, TRIM	1	BLACK
1-2	34800-93J13	METER ASSY, TRIM	1	WHITE
2	09471-12108	.BULB (12V1.7W,T6.5)	1	
3-1	34100-93J02	SPEEDOMETER ASSY	1	MAX 130KM/H BLACK
3-2	34100-93J13	SPEEDOMETER ASSY	1	MAX 130KM/H WHITE
3-3	34100-93J22	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
3-4	34100-93J33	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
3-5	34100-93J42	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
3-6	34100-93J53	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
3-7	34100-93J62	SPEEDOMETER ASSY	1	MAX 65KNOTS WHITE
4	09471-12028	.BULB (12V3.4W,T10)	1	
5	34191-92E00	.TUBE	1	
6	09407-14407	.CLAMP (L:145)	2	
7	36615-96300	.TERMINAL	2	
8-1	34600-93J02	METER ASSY, VOLTAGE	1	BLACK
8-2	34600-93J13	METER ASSY, VOLTAGE	1	WHITE
9	09471-12103	.BULB (12V3W,T6.5)	1	
10-1	34300-93J02	GAUGE ASSY, FUEL	1	BLACK
10-2	34300-93J13	GAUGE ASSY, FUEL	1	WHITE
11	34310-92E00	.LEAD ASSY, FUEL GAUGE	1	
12	34360-92E00	ADAPTER, FUEL GAUGE	1	
13	09471-12103	.BULB (12V3W,T6.5)	1	
14-1	34500-93J02	METER ASSY, HOUR	1	BLACK
14-2	34500-93J13	METER ASSY, HOUR	1	WHITE
15	09471-12103	.BULB (12V3W,T6.5)	1	
16-1	34650-93J22	GAUGE ASSY, WATER PRESS 15PSI	1	15PSI BLACK
16-2	34650-93J33	GAUGE ASSY, WATER PRESS 15PSI	1	15PSI WHITE
17	34191-92E00	.TUBE	1	
18	09407-14407	.CLAMP (L:145)	2	
19	09471-12103	.BULB (12V3W,T6.5)	1	
20-1	34200-93J02	TACHOMETER ASSY, WITH MONITOR	1	BLACK
20-2	34200-93J14	TACHOMETER ASSY, WITH MONITOR	1	WHITE
21	09471-12077	.BULB (12V1.7W,T10)	1	
22	34190-87D00	SENDER, SPEEDOMETER	1	
23	34120-98J01	KIT, SPEEDOMETER SUB	1	
24	34190-95500	.SENDER, SPEEDOMETER	1	

FIG.501A




FIG.501A (1-J-6) OPT:METER (DF70A,DF80A,DF90A,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25	03112-0630B	..SCREW	2	
26	55127-87D00	.UNION, SPEEDOMETER HOSE	1	
27	09355-40805-00B	.HOSE (4X8X2000)	1	L:2000->1700
28	09407-10404	.CLAMP (L:100)	2	
29-1	34200-93J43	TACHOMETER ASSY, WITH MONITOR	1	BLACK
29-2	34200-93J54	TACHOMETER ASSY, WITH MONITOR	1	WHITE
30	09471-12077	.BULB (12V1.7W,T10)	1	
31	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	

DF70A E01
DF70A E03
DF70A E11
DF70A E40
DF80A E01
DF80A E40
DF90A E01
DF90A E03
DF90A E11
DF90A E40
DF100B E01
DF100B E40

FIG.501B




FIG.501B (1-J-7) OPT:METER (DF70ATH,DF90ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34800-93J02	METER ASSY, TRIM	1	BLACK
1-2	34800-93J13	METER ASSY, TRIM	1	WHITE
2	09471-12108	.BULB (12V1.7W,T6.5)	1	
3-1	34100-93J02	SPEEDOMETER ASSY	1	MAX 130KM/H BLACK
3-2	34100-93J13	SPEEDOMETER ASSY	1	MAX 130KM/H WHITE
3-3	34100-93J22	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
3-4	34100-93J33	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
3-5	34100-93J42	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
3-6	34100-93J53	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
3-7	34100-93J62	SPEEDOMETER ASSY	1	MAX 65KNOTS WHITE
4	09471-12028	.BULB (12V3.4W,T10)	1	
5	34191-92E00	.TUBE	1	
6	09407-14407	.CLAMP (L:145)	2	
7	36615-96300	.TERMINAL	2	
8-1	34600-93J02	METER ASSY, VOLTAGE	1	BLACK
8-2	34600-93J13	METER ASSY, VOLTAGE	1	WHITE
9	09471-12103	.BULB (12V3W,T6.5)	1	
10-1	34300-93J02	GAUGE ASSY, FUEL	1	BLACK
10-2	34300-93J13	GAUGE ASSY, FUEL	1	WHITE
11	34310-92E00	.LEAD ASSY, FUEL GAUGE	1	
12	34360-92E00	ADAPTER, FUEL GAUGE	1	
13	09471-12103	.BULB (12V3W,T6.5)	1	
14-1	34500-93J02	METER ASSY, HOUR	1	BLACK
14-2	34500-93J13	METER ASSY, HOUR	1	WHITE
15	09471-12103	.BULB (12V3W,T6.5)	1	
16-1	34650-93J22	GAUGE ASSY, WATER PRESS 15PSI	1	15PSI BLACK
16-2	34650-93J33	GAUGE ASSY, WATER PRESS 15PSI	1	15PSI WHITE
17	34191-92E00	.TUBE	1	
18	09407-14407	.CLAMP (L:145)	2	
19	09471-12103	.BULB (12V3W,T6.5)	1	
20-1	34200-93J02	TACHOMETER ASSY, WITH MONITOR	1	BLACK
20-2	34200-93J14	TACHOMETER ASSY, WITH MONITOR	1	WHITE
21	09471-12077	.BULB (12V1.7W,T10)	1	
22	34190-87D00	SENDER, SPEEDOMETER	1	
23	34120-98J01	KIT, SPEEDOMETER SUB	1	
24	34190-95500	.SENDER, SPEEDOMETER	1	

FIG.501B




FIG.501B (1-J-8) OPT:METER (DF70ATH,DF90ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25	03112-0630B	..SCREW	2	
26	55127-87D00	.UNION, SPEEDOMETER HOSE	1	
27	09355-40805-00B	.HOSE (4X8X2000)	1	L:2000->1700
28	09407-10404	.CLAMP (L:100)	2	
29	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	

DF70ATH E01
DF70ATH E11
DF70ATH E40
DF90ATH E01
DF90ATH E11
DF90ATH E40

FIG.507A




FIG.507A (1-J-9) OPT:WATER PRESSURE GAUGE SUB KIT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34660-90J04	KIT, WATER PRESS GAUGE SUB	1	
2	09352-50006-600	.HOSE (5X9X600)	1	L:600->160
3	09352-50006-600	.HOSE (5X9X600)	1	L:600->210
4	09367-06006	.3 WAY	1	
5	09401-08413	.CLIP	4	
6	18498-99EA1	.PROTECTOR (L:80)	1	
7	09407-20405	.CLAMP (L:202)	1	

FIG.508A




FIG.508A (1-J-10) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J61	REMOTE CONTROL ASSY	1	
2	36628-92E01	.GROMMET, WIRING HARNESS	1	
3	37110-93J12	.SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E01	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37721-93J91	.SWITCH ASSY, NEUTRAL	1	
8	37820-93J11	.SWITCH ASSY, EMERGENCY	1	
9	37823-92E02	..PLATE ASSY, EMERGENCY SW	1	
		LOCK		
10	37826-92J10	..NUT	1	
11	37850-96L00	.SWITCH ASSY, PTT	1	
12	38500-93J90	.BUZZER, WARNING	1	
13	67212-95600	.WASHER	1	
14	67296-92E11	.SCREW, NEUTRAL SWITCH (3X15)	2	
15	67220-95630	.PLATE ASSY	1	
16	67223-99E10	.KNOB, BRAKE ADJUST	1	
17	67229-95600	.ROLLER	1	
18	67232-95600	.BUSH	1	
19	67238-87D00	.GEAR, DRIVE	1	

NOTE : N/KEY LESS START:((E01,E40):(DF70A,DF80A,DF90A,DF100B),
E11:(DF70A,DF90A))

FIG.508A




FIG.508A (1-J-11) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E11	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-96L00	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-96L00	.NEUTRAL LOCK ARM	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-96L00	.CAP ASSY, LEVER	1	
30	77811-54GB0-0PG	..EMBLEM, RR MARK S (CHROME)	1	
31	67258-99E00	.BRACKET	1	
32	67259-87D00	.SPRING, NEUTRAL ARM	1	
33	67261-96L00	.GRIP	1	
34	67296-96L10	.SCREW	2	
35	67264-95600	.WASHER	1	
36	67267-96L00	.COVER, WIRE SUB ASSY	1	
37	67273-95601	.SPACER	1	
38	67275-95600	.END, CABLE	2	
39	67292-94300	.E RING	3	
40	67294-95600	.SPACER	3	
41	67296-90J20	.SCREW	5	
42	67296-96L00	.SCREW	2	
43	67296-95630	.SCREW	3	
44	67296-95610	.SCREW	2	
45	67297-95600	.WASHER	2	
46	09100-08232	.BOLT (8X30)	1	
47	67269-96L10	.SCREW (5X12)	2	
48	09140-06020	.NUT	3	
49	67288-94320	.WAHSER (6.5X24X2)	3	
50	67224-96L00	.ARM, BRAKE ASSY	1	

NOTE : N/KEY LESS START:((E01,E40):(DF70A,DF80A,DF90A,DF100B),
E11:(DF70A,DF90A))

FIG.508A




FIG.508A (1-J-12) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
51	67238-96L00	.GEAR, SHIFT ASSY	1	
52	67284-94L10	.MARK, HANDLE LEVER	1	
53-1	36620-93J03	WIRE ASSY, REMOTE CONTROL (L:5000)	1	
53-2	36620-93J52	WIRE ASSY, REMOTE CONTROL (L:3500)	1	
53-3	36620-93J62	WIRE ASSY, REMOTE CONTROL (L:6500)	1	
54	09481-10501	.FUSE (10A)	1	

NOTE : N/KEY LESS START:((E01,E40):(DF70A,DF80A,DF90A,DF100B),
E11:(DF70A,DF90A))

- DF70A E01
- DF70A E11
- DF70A E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E11
- DF90A E40
- DF100B E01
- DF100B E40

FIG.508B




FIG.508B (1-J-13) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-96L11	REMOTE CONTROL ASSY	1	
2	36628-92E01	.GROMMET, WIRING HARNESS	1	
3	37110-96L10	.SWITCH ASSY, MAIN	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
5	37143-96L00	..KNOB, MAIN SWITCH	1	
6	37721-93J91	.SWITCH ASSY, NEUTRAL	1	
7	37820-93J11	.SWITCH ASSY, EMERGENCY	1	
8	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
9	37826-92J10	..NUT	1	
10	37850-96L00	.SWITCH ASSY, PTT	1	
11	38500-93J90	.BUZZER, WARNING	1	
12	67212-95600	.WASHER	1	
13	67296-92E11	.SCREW, NEUTRAL SWITCH (3X15)	2	
14	67220-95630	.PLATE ASSY	1	
15	67223-99E10	.KNOB, BRAKE ADJUST	1	
16	67229-95600	.ROLLER	1	
17	67232-95600	.BUSH	1	
18	67238-87D00	.GEAR, DRIVE	1	
19	67241-99E11	.LEVER, FREE THROTTLE	1	
20	67243-95600	.BUSH	1	
21	67244-95600	.WAVE WASHER	1	
22	67245-95600	.DRUM, FREE THROTTLE	1	
23	67251-96L00	.LEVER, HANDLE	1	
24	67252-95600	.BUSH	2	
25	67253-95600	.WASHER	1	
26	67255-96L00	.NEUTRAL LOCK ARM	1	

NOTE : W/KEY LESS START:(E01,E11,E40)

FIG.508B




FIG.508B (1-J-14) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27	67256-95600	.HOLDER, NEUTRAL LOCK	1	
28	67257-96L00	.CAP ASSY, LEVER	1	
29	77811-54GB0-OPG	..EMBLEM, RR MARK S (CHROME)	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-96L00	.GRIP	1	
33	67296-96L10	.SCREW	2	
34	67264-95600	.WASHER	1	
35	67267-96L00	.COVER, WIRE SUB ASSY	1	
36	67273-95601	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67292-94300	.E RING	3	
39	67294-95600	.SPACER	3	
40	67296-90J20	.SCREW	5	
41	67296-96L00	.SCREW	2	
42	67296-95630	.SCREW	3	
43	67296-95610	.SCREW	2	
44	67297-95600	.WASHER	2	
45	09100-08232	.BOLT (8X30)	1	
46	67269-96L10	.SCREW (5X12)	2	
47	09140-06020	.NUT	3	
48	67288-94320	.WAHSER (6.5X24X2)	3	
49	67224-96L00	.ARM, BRAKE ASSY	1	
50	67238-96L00	.GEAR, SHIFT ASSY	1	
51	67284-94L10	.MARK, HANDLE LEVER	1	
52	67285-96L00	.MARK, KLS MAIN SW	1	
53-1	36620-93J03	WIRE ASSY, REMOTE CONTROL (L:5000)	1	
53-2	36620-93J52	WIRE ASSY, REMOTE CONTROL (L:3500)	1	
53-3	36620-93J62	WIRE ASSY, REMOTE CONTROL (L:6500)	1	

NOTE : W/KEY LESS START:(E01,E11,E40)

FIG.508B




FIG.508B (1-J-15) OPT:REMOTE CONTROL (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
54	09481-10501	.FUSE (10A)	1	

NOTE : W/KEY LESS START:(E01,E11,E40)

- DF70A E01
- DF70A E11
- DF70A E40
- DF70ATH E01
- DF70ATH E11
- DF70ATH E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E11
- DF90A E40
- DF90ATH E01
- DF90ATH E11
- DF90ATH E40
- DF90AWQH E40
- DF100B E01
- DF100B E40

FIG.517A




FIG.517A (1-K-2) OPT:CONCEALED REMOCON (1) (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J34	REMOTE CONTROL ASSY, CONCEAL	1	
2	67298-92E50	.SPRING	1	
3	67296-94310	.SCREW	1	
4	67295-92E10	.SCREW (3X12)	2	
5	37850-92E27	.SWITCH ASSY, PTT	1	
6	67288-92E60	.WASHER	1	
7	09125-04021	.SCREW (4X20)	1	
8	67255-92E50	.ARM, NEUTRAL LOCK	1	
9	67251-92E50	.LEVER, HANDLE	1	
10	67261-92E50	.GRIP	1	
11	67256-92E50	.HOLDER, NEUTRAL LOCK	1	
12	67257-92E00	.CAP, LEVER	1	
13	67242-92E50	.SHAFT, FREE ACC	1	
14	67288-92E20	.WASHER	6	
15	67296-88D10	.SCREW (5X16)	4	
16	67288-92E70	.WASHER	1	
17	67296-88D20	.SCREW (6X35)	3	
18	67295-92E50	.SCREW (6X30)	3	
19	67287-92E50	.NUT	3	
20	09160-06104	.WASHER (6.5X24X2)	3	
21	67296-88D30	.SCREW (5X30)	4	
22	67254-92E50	.COVER, LOCK ARM	1	
23	36890-93J00	.WIRE, NEUTRAL & PTT SW	1	
24	67275-95600	.END, CABLE	2	
25	67273-95601	.SPACER	1	
26	67283-92E50	.DECAL, LEVER	1	
27	67284-92E50	.DECAL, CLUTCH	1	
28	67274-92E50	.BASE	1	

NOTE : DF70A,DF80A,DF90A,DF100B

FIG.517A




FIG.517A (1-K-3) OPT:CONCEALED REMOCON (1) (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	67211-92E50	.COVER	1	

NOTE : DF70A,DF80A,DF90A,DF100B

- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF100B E01
- DF100B E40

FIG.518A




FIG.518A (1-K-4) OPT:CONCEALED REMOCON (2) (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J34	REMOTE CONTROL ASSY, CONCEAL	1	
2	67222-92E50	.DUEL PLATE	1	
3	67292-94300	.E RING	3	
4	67288-92E10	.WASHER	1	
5	67291-92E00	.SNAP RING	2	
6	67223-92E50	.BRAKE ADJUST	1	
7	67221-92E50	.HOLDER ASSY	1	
8	67224-92E50	.BRAKE SHOE ASSY	1	
9	67225-92E50	.DISC, BRAKE	1	
10	09140-06020	.NUT	2	
11	67294-92E00	.SPACER	1	
12	37721-95500	.SWITCH ASSY, NEUTRAL	1	
13	67296-92E11	.SCREW, NEUTRAL SWITCH (3X15)	2	
14	67226-92E10	.BOLT, STOPPER	2	
15	67296-92E20	.SCREW (5X25)	2	
16	67240-92E50	.THROTTLE ARM ASSY	1	
17	67228-92E00	.WASHER	1	
18	67286-92E00	.BOLT (6X18)	3	
19	67230-92E00	.SHIFT ARM ASSY	1	
20	09125-05042	.SCREW (5X10)	11	
21	67234-92E00	.CASE, GEAR	1	
22	67245-92E00	.LEVER ASSY, THROTTLE	1	
23	67227-92E00	.STOPPER	1	
24	67296-88D10	.SCREW (5X16)	2	
25	67225-92E00	.SPRING	1	
26	09125-04004	.SCREW (4X6)	1	
27	67233-92E00	.SPRING	1	
28	67235-92E00	.PLATE, SHIFT LOCK	1	
29	67239-92E10	.PLATE, SHIFT PIN	1	
30	67236-92E00	.ROLLER	1	
31	67237-92E01	.SPRING	5	
32	67238-92E50	.GEAR, DRIVE	1	

NOTE : DF70A,DF80A,DF90A,DF100B

FIG.518A




FIG.518A (1-K-5) OPT:CONCEALED REMOCON (2) (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	67239-92E00	.PIN	1	
34	67246-92E50	.SHAFT, DRIVE	1	
35	67252-92E00	.BUSH	1	
36	67291-92E10	.SNAP RING	1	
37	67253-92E10	.WASHER	1	
38	67252-92E10	.BUSH	1	
39	67253-95600	.WASHER	1	
40	67231-92E00	.GEAR, SHIFT	1	
41	67232-95600	.BUSH	1	
42	67241-92E50	.ROD, FREE ACC	1	
43	67232-92E50	.BUSH	1	

NOTE : DF70A,DF80A,DF90A,DF100B

- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF100B E01
- DF100B E40

FIG.519A




FIG.519A (1-K-6) OPT:REMOTE CONTROL SPACER (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67500-88L00	KIT, R/CON SPACER SINGLE	1	
2	09125-05135	.SCREW (5X65)	4	
3	09160-05029	.WASHER (5.5X12X0.8)	4	
4	09140-05005	.NUT	4	
5	67273-88L00	.GROMMET, R/CON SINGLE	1	

NOTE : DF70A,DF70ATH,DF80A,DF90A,DF90ATH,DF100B

- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF70ATH E01
- DF70ATH E11
- DF70ATH E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF90ATH E01
- DF90ATH E11
- DF90ATH E40
- DF100B E01
- DF100B E40

FIG.521A




FIG.521A (1-K-7) OPT:HARNESS (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	36620-93J10	WIRE ASSY, REMOTE CONTROL EXT (L:2000)	1	
1-2	36620-93J41	WIRE ASSY, REMOTE CONTROL EXT (L:3000)	1	
2	36620-93J30	WIRE ASSY, R/CON ADAPTER (L:2000)	1	
3	38500-93J00	BUZZER ASSY, WARNING	1	
4	36990-87D00	TERMINAL & SLEEVE SET	1	
5	36667-96L20	WIRE, GAUGE EXT	1	

NOTE : (DF70A,DF90A):(E01,E40),DF80A,DF100B

- DF70A E01
- DF70A E11
- DF70A E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E11
- DF90A E40
- DF100B E01
- DF100B E40

FIG.521B




FIG.521B (1-K-8) OPT:HARNESS ((DF70A,DF90A):(E03,E11))

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	36620-93J10	WIRE ASSY, REMOTE CONTROL EXT (L:2000)	1	
1-2	36620-93J41	WIRE ASSY, REMOTE CONTROL EXT (L:3000)	1	
2	36620-93J30	WIRE ASSY, R/CON ADAPTER (L:2000)	1	
3	38500-93J00	BUZZER ASSY, WARNING	1	
4	36990-87D00	TERMINAL & SLEEVE SET	1	
5-1	36620-93J03	WIRE ASSY, REMOTE CONTROL (L:5000)	1	
5-2	36620-93J52	WIRE ASSY, REMOTE CONTROL (L:3500)	1	
5-3	36620-93J62	WIRE ASSY, REMOTE CONTROL (L:6500)	1	
6	09481-10501	.FUSE (10A)	1	
7	36667-96L20	WIRE, GAUGE EXT	1	

DF70A E03
DF70A E11
DF90A E03
DF90A E11

FIG.521C





FIG.521C (1-K-9) OPT:HARNESS (DF70ATH,DF90ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38500-93J00	BUZZER ASSY, WARNING	1	
2-1	36620-93J03	WIRE ASSY, REMOTE CONTROL	1	
		(L:5000)		
2-2	36620-93J52	WIRE ASSY, REMOTE CONTROL	1	
		(L:3500)		
2-3	36620-93J62	WIRE ASSY, REMOTE CONTROL	1	
		(L:6500)		
3	09481-10501	.FUSE (10A)	1	
4	36990-87D00	TERMINAL & SLEEVE SET	1	
5	36630-92E00	WIRE ASSY, INSTRUMENT	1	
6	36660-94480	WIRE, SENDER EXT	1	
7	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	
8	36667-96L20	WIRE, GAUGE EXT	1	

DF70ATH E01
DF70ATH E11
DF70ATH E40
DF90ATH E01
DF90ATH E11
DF90ATH E40

FIG.530A




DF90A_E11_021_530A
OPT:SWITCH

FIG.530A (1-K-10) OPT:SWITCH (DF70A,DF80A,DF90A,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J01	PANEL ASSY, IGNITION SWITCH	1	
2	37110-93J02	.SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E01	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	.PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J06	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J11	.SWITCH ASSY, EMERGENCY	1	
11	37823-92E02	..PLATE ASSY, EMERGENCY SW	1	
		LOCK		
12	37826-92J10	..NUT	1	
13	37825-99E10	.PANEL, EMERGENCY STOP SW	1	
14	03122-05165	.SCREW	4	
15	37805-93J00	PANEL ASSY, PTT SW	1	
16	37855-99E00	.PANEL, PTT SW	1	
17	37210-93J00	PANEL ASSY, LIGHTING SW	1	
18	37212-93J00	.PANEL, LIGHTING SW	1	
19	37100-96J27	PANEL ASSY, ENGINE SWITCH	1	
20	37110-93J02	.SWITCH ASSY, IGNITION	1	

FIG.530A



DF90A_E11_021_530A
OPT:SWITCH

FIG.530A (1-K-11) OPT:SWITCH (DF70A,DF80A,DF90A,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21-1	37141-99E00	..KEY (931)	2	
21-2	37141-99E10	..KEY (932)	2	
21-3	37141-99E20	..KEY (933)	2	
21-4	37141-99E30	..KEY (934)	2	
21-5	37141-99E40	..KEY (935)	2	
21-6	37141-99E50	..KEY (936)	2	
21-7	37141-99E60	..KEY (937)	2	
21-8	37141-99E70	..KEY (938)	2	
21-9	37141-99E80	..KEY (939)	2	
21-10	37141-99E90	..KEY (940)	2	
21-11	37141-99EA0	..KEY (941)	2	
21-12	37141-99EB0	..KEY (942)	2	
22	37143-99E01	..CAP, KEY	1	
23	37149-93J00	..CAP, CYLINDER BODY	1	
24	37139-99E40	.PANEL, IGNITION SWITCH	1	
25	37820-93J11	.SWITCH ASSY, EMERGENCY	1	
26	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
27	37826-92J10	..NUT	1	
28	03121-0516A	.SCREW	4	
29	38500-93J90	.BUZZER, WARNING	1	
30	09407-08401	.CLAMP (L:80)	1	
31	37860-87L00	PANEL ASSY, TROLLING CONTROL SW	1	
32	37862-87L00	.PANEL	1	

FIG.530A




FIG.530A (1-K-12) OPT:SWITCH (DF70A,DF80A,DF90A,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	09131-05004	.SCREW (5X16)	4	

- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF100B E01
- DF100B E40

FIG.535A




FIG.535A (1-K-13) OPT:KEY LESS START (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96L12	PANEL ASSY, MAIN SWITCH	1	
2	37110-96L10	.SWITCH ASSY, MAIN	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
4	37143-96L00	..KNOB, MAIN SWITCH	1	
5	37114-96L10	.SHEET, MAIN SWITCH PANEL	1	
6	37139-96L40	.PANEL, MAIN SWITCH	1	
7	37820-93J11	.SWITCH ASSY, EMERGENCY	1	
8	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
9	37826-92J10	..NUT	1	
10	38500-93J90	..BUZZER, WARNING	1	
11	09407-08401	..CLAMP (L:80)	1	
12	03122-05165	..SCREW	4	
13	37173-96L00	HOLDER, KLS PARTS	1	LARGE TYPE
14	37105-96L12	HARNESS SET, KLS CONTROLLER	1	
15	32851-93J00	..CUSHION, LEAD WIRE	1	
16	32980-38F00	..CUSHION, CDI UNIT	1	
17	36623-96L11	..HARNESS ASSY, KLS CONT	1	
18	36615-96300	..TERMINAL	1	
19	36662-96L10	..HARNESS ASSY, KLS CAN (L:6500+2000)	1	
20	37173-96L10	..HOLDER, KLS PARTS	1	SMALL TYPE
21	38500-93J90	..BUZZER, WARNING	1	
22	38860-96L01	..RELAY ASSY, KLS	1	

NOTE : (DF70A,DF80A,DF90A,DF100B):E01,(DF70A,DF90A):(E03,E11)

FIG.535A




FIG.535A (1-K-14) OPT:KEY LESS START (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23-1	37170-96L04	CONTROLLER SET, KLS	1	(DF70A,DF80A,DF90A,DF100B):E01 433MHZ
23-2	37170-96L14	CONTROLLER SET, KLS	1	(DF70A,DF90A):(E03,E11) 315MHZ
23-3	37170-96L04	CONTROLLER SET, KLS	1	(DF70A,DF90A):(E03,E11) 433MHZ
24	37117-96L00	.DECAL, KLS	2	
25-1	37171-96L02	.CONTROLLER ASSY, KLS	1	(DF70A,DF80A,DF90A,DF100B):E01 433MHZ
25-2	37171-96L12	.CONTROLLER ASSY, KLS	1	(DF70A,DF90A):(E03,E11) 315MHZ
25-3	37171-96L02	.CONTROLLER ASSY, KLS	1	(DF70A,DF90A):(E03,E11) 433MHZ
26-1	37172-96L01	.REMOCON ASSY, KLS	2	(DF70A,DF80A,DF90A,DF100B):E01 433MHZ
26-2	37172-96L10	.REMOCON ASSY, KLS	2	(DF70A,DF90A):(E03,E11) 315MHZ
26-3	37172-96L01	.REMOCON ASSY, KLS	2	(DF70A,DF90A):(E03,E11) 433MHZ
27	09407-14407	CLAMP (L:145)	1	

NOTE : (DF70A,DF80A,DF90A,DF100B):E01,(DF70A,DF90A):(E03,E11)

DF70A E01
DF70A E03
DF70A E11
DF80A E01
DF90A E01
DF90A E03
DF90A E11
DF100B E01

FIG.544A




FIG.544A (1-L-2) OPT:REMOTE CONTROL ASSY SINGLE (1) (SEE NOTE)


REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-88L01	REMOTE CONTROL ASSY, SINGLE	1	
2	67261-88L10	.GRIP, REMOCON NO.2	1	
3	67261-88L00	.GRIP, REMOCON NO.1	1	
4	37850-88L00	.SWITCH ASSY, GRIP PTT	1	
5	67296-88L00	.SCREW	3	
6	67288-92E20	.WASHER	3	
7	67212-88L00	.COVER, PLUG	1	
8	68111-88L00	.EMBLEM, MARK	1	
9	67257-88L00	.CAP, REMOCON LEVER	1	
10	67281-88L00	.DECAL	1	
11	67296-92E60	.SCREW	2	
12	67288-92E60	.WASHER	2	
13	67253-92E00	.WASHER	1	
14	67275-95600	.END, CABLE	2	
15	67273-95601	.SPACER	1	
16	67271-88L10	.COVER, REMOCON LEVER LOWER	1	LOWER
17	67211-88L00	.COVER	1	
18	67264-88L00	.COVER, LEVER DESIGN	1	
19	67264-88L10	.COVER, LEVER PLATING	1	
20	67251-88L00	.LEVER, HANDLE	1	
21	67500-88L00	KIT, R/CON SPACER SINGLE	1	
22	09125-05135	.SCREW (5X65)	4	
23	09160-05029	.WASHER (5.5X12X0.8)	4	
24	09140-05005	.NUT	4	

NOTE : DF70A,DF80A,DF90A,DF100B

FIG.544A

FIG.544A (1-L-3) OPT:REMOTE CONTROL ASSY SINGLE (1) (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25	67273-88L00	.GROMMET, R/CON SINGLE	1	



NOTE : DF70A,DF80A,DF90A,DF100B

- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF100B E01
- DF100B E40

FIG.545A




FIG.545A (1-L-4) OPT:REMOTE CONTROL ASSY SINGLE (2) (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-88L01	REMOTE CONTROL ASSY, SINGLE	1	
2	67222-92E00	.DUEL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67272-88L00	.GOM SEAL, WATERPROOF	1	
7	67291-92E00	.SNAP RING	1	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	09140-06020	.NUT	2	
11	37721-88L01	.SWITCH ASSY, NEUTRAL	1	
12	67236-92E00	.ROLLER	1	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER	1	
16	67226-92E10	.BOLT, STOPPER	1	
17	67240-92E00	.THROTTLE ARM ASSY	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-88L00	ARM ASSY, REMOCON SHIFT	1	
21	09125-05042	.SCREW (5X10)	10	
22	67234-88L00	.CASE, REMOCON GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67237-92E01	.SPRING	5	
29	67269-92E01	.BRACKET	1	
30	67296-88D10	.SCREW (5X16)	1	
31	67238-88L00	.GEAR, REMOCON DRIVE	1	
32	67231-88L00	.GEAR, REMOCON SHIFT	1	

NOTE : DF70A,DF80A,DF90A,DF100B

FIG.545A




FIG.545A (1-L-5) OPT:REMOTE CONTROL ASSY SINGLE (2) (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	67232-88L00	.BUSH, SHIFT GEAR	1	
34	67241-88L00	.ROD, REMOCON FREE ACCEL	1	
35	67239-92E00	.PIN	1	
36	67246-88L00	.SHAFT, REMOCON DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67243-92E00	.CAP, HOLE	1	
39	67252-88L00	.BUSH, REMOCON DRIVE SHAFT	1	
40	67253-88L00	.WASHER, REMOCON DRIVE SHAFT	1	
41	67239-92E10	.PLATE, SHIFT PIN	1	
42	67274-88L00	.FLANGE, COVER BASE	2	
43	67296-95610	.SCREW	4	
44	67296-92E30	.SCREW	4	
45	09160-05024	.WASHER (5.5X16X1.5)	4	
46	67287-92E00	.NUT	4	
47	67273-88L00	.GROMMET, R/CON SINGLE	1	

NOTE : DF70A,DF80A,DF90A,DF100B

- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF100B E01
- DF100B E40

FIG.570A




FIG.570A (1-L-6) OPT:TILLER HANDLE (DF70A,DF80A,DF90A,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63002-87L17-YAY	SET, TILLER HANDLE (BLACK)	1	
2	21110-88L00	.LEVER, SHIFT	1	
3	23230-90J10	.CABLE, SHIFT	1	
4	36620-87L01	.WIRE ASSY, HANDLE	1	
5	37110-87L02	.SWITCH ASSY, IGNITION	1	
6-1	37141-99E00	..KEY (931)	1	
6-2	37141-99E10	..KEY (932)	1	
6-3	37141-99E20	..KEY (933)	1	
6-4	37141-99E30	..KEY (934)	1	
6-5	37141-99E40	..KEY (935)	1	
6-6	37141-99E50	..KEY (936)	1	
6-7	37141-99E60	..KEY (937)	1	
6-8	37141-99E70	..KEY (938)	1	
6-9	37141-99E80	..KEY (939)	1	
6-10	37141-99E90	..KEY (940)	1	
6-11	37141-99EA0	..KEY (941)	1	
6-12	37141-99EB0	..KEY (942)	1	
7	37143-99E01	..CAP, KEY	1	
8	37149-93J00	..CAP, CYLINDER BODY	1	
9	37820-87L11	.SWITCH ASSY, EMERGENCY	1	
10	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
11	37826-92J10	..NUT	1	
12	38500-93J90	.BUZZER, WARNING	1	
13	37850-87L01	.SWITCH ASSY, PTT	1	
14	37852-87J00	.PLATE, TRIM SWITCH	1	
15	63121-88L10	.COVER, UNDER	1	
16	63210-88L00	.GRIP, HANDLE	1	
17	63221-88L00	.SHAFT, THROTTLE	1	
18	63223-92D00	.STOPPER, HANDLE ROD	1	
19	63225-88L00	.BUSH, HANDLE ROD	1	
20	63227-93200	.PIN, HANDLE ROD	1	
21	63235-88L00	.PLATE, THROTTLE SHAFT	1	
22	63246-88L00	.STOPPER, THROTTLE ADJUST	1	
23	63250-88L00	.ARM ASSY, THROTTLE	1	
24	63251-87J00	.BOLT, SHIFT GEAR ASSY	4	

FIG.570A




FIG.570A (1-L-7) OPT:TILLER HANDLE (DF70A,DF80A,DF90A,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25	63260-88L00	.GEAR ASSY, SHIFT	1	
26	63272-87J00	..PLATE, BALL GUIDE	1	
27	63273-87J00	..BALL	1	
28	63262-87J00	.BUSH, SHIFT LEVER	1	
29	63271-87J00	.PLATE, LOCK	1	
30	63248-99J00	.PLATE, THROTTLE ADJ NOTCH	1	
31	63261-87J00	.BUSH, SHIFT GEAR	1	
32	63274-87J00	.E RING	1	
33	63610-87J00	.CABLE, THROTTLE	1	
34	37853-88L90	.GROMMET, PTT SW LEAD	1	
35	63626-88L00	.GROMMET, CABLE	1	
36	67292-87J00	.E RING	2	
37	09126-06015	.SCREW (6X23)	1	
38	09163-06001	.LOCK WASHER (6.4X12X0.5)	1	
39	09440-12027	.SPRING	1	
40	21112-88L00	.BOLT, SHIFT LEVER	1	
41	09125-05047	.SCREW (5X14)	6	
42	63611-88L00	.BOLT, CLAMP BRACKET	3	
43	63612-87J00	.BRACKET, CLAMP	1	
44	34200-87L00	.TACHOMETER ASSY, WITH MONITOR	1	
45	36617-88L90	.CLAMP, MAIN HARNESS	1	
46	37112-88L91	.LABEL, IGNITION SW	1	
47	37835-91J00-YAY	.LABEL, STOP (BLACK)	1	
48	37851-88L90	.BASE, PTT SW	1	
49	37852-88L90	.HARNESS GUIDE	1	
50	37861-87L11	.SWITCH, TROLLING CONTROL	1	
51	37864-88L91	.LABEL, TROLL MODE	1	
52	63244-99J00	.KNOB, THROTTLE ADJ	1	
53	63245-99J00	.BUSH, THROTTLE ADJ	1	
54	63612-88L10	.BRACKET, CLAMP SHIFT	1	
55	09260-10006	.BALL	1	
56	19120-87L10	.LEVER, THROTTLE	1	
57	21131-88L02	.MARK, CLUTCH SHIFT	1	
58	43761-88L01-YAY	.BRACKET, TILLER HANDLE (BLACK)	1	
59	43762-88L00	.BOLT, TILLER HANDLE PIVOT	1	

FIG.570A




FIG.570A (1-L-8) OPT:TILLER HANDLE (DF70A,DF80A,DF90A,DF100B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
60	43768-88L00	.SPACER, TILLER HANDLE	1	
61	43776-87L00	.SPACER, STEERING BRACKET	1	
62	09116-08137	.BOLT (8X22)	1	
63	09159-12014	.NUT	1	
64	09160-12066	.WASHER (12.5X22X2.5)	2	
65	09160-12124	.WASHER (12.5X32X1.5)	1	
66	63115-88L01	.BUSH, TILLER HANDLE PIVOT	2	
67	09164-13010	.WASHER	1	
68	63215-93110	.MARK, HANDLE GRIP	1	
69	09116-10150	.BOLT (10X55)	2	
70	43770-99E03	.ADJUSTER ASSY, STEERING	1	
71	63132-88L00	.STOPPER, TILLER HANDLE	1	
72	63251-88L90	.BOLT	2	
73	37855-88L90	.SCREW, THROTTLE GRIP	1	
74	37854-88L90	.WASHER, THROTTLE GRIP	1	
75	63258-88L00	.WASHER	1	
76	09440-06037	.SPRING	1	
77	03522-05169	.SCREW	3	
78	63247-99J00	.PLATE, THROTTLE ADJ KNOB	1	
79	63111-88L00-YAY	.HOUSING, TILLER HANDLE (BLACK)	1	

- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF100B E01
- DF100B E40

FIG.585A




FIG.585A (1-L-9) OPT:GASKET SET (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11410-87851	GASKET SET	1	
2	11141-87L00	.GASKET, CYLINDER HEAD	1	
3	11189-87L00	.GASKET, CYLINDER HEAD COVER	1	
4	14151-87L00	.GASKET, EXH COVER	1	
5	17472-87L00	.GASKET, PUMP CASE PANEL	1	
6	11489-87L00	.GASKET, OIL PAN	1	
7	11542-87L00	.GASKET, EXHAUST TUBE	1	
8	11552-87L01	.GASKET, OIL PAN WTR JKT COVER	1	
9	51123-87L00	.GASKET, MOUNT CASE COVER	1	
10	51211-87L10	.GASKET, ENGINE HOLDER	1	
11	52331-87L00	.GASKET, EXH TUBE HOUSING	1	
12	16539-87L00	.GASKET, OIL FILTER ADAPTER CASE	1	

NOTE : DF70A,DF70ATH,DF80A,DF90A,DF90ATH,DF100B

- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF70ATH E01
- DF70ATH E11
- DF70ATH E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF90ATH E01
- DF90ATH E11
- DF90ATH E40
- DF100B E01
- DF100B E40

FIG.600A




FIG.600A (1-L-10) OPT:MULTI FUNCTION GAUGE (DF70ATH,DF90ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-96L15	GAUGE SET, MULTI	1	
2	34112-96L00	.NUT, GAUGE	1	
3	34193-96L00	.BEZEL, GAUGE	1	
4	34211-96L00	.COVER, GAUGE	1	
5	34825-96L00	.PACKING, GAUGE	1	
6	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
7	36662-88L10	WIRE, 2 EXTENSION	1	
8	36662-88L20	WIRE, 6 EXTENSION	1	
9	36662-88L30	WIRE, 15 EXTENSION	1	
10	36662-88L00	WIRE, 25 EXTENSION	1	
11	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
12	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
13	36665-88L00	UNIT, RESISTOR FEMALE	1	
14	36665-88L10	UNIT, RESISTOR MALE	1	
15	36664-88L00	CONNECTOR, BRANCH	1	

DF70ATH E01
DF70ATH E11
DF70ATH E40
DF90ATH E01
DF90ATH E11
DF90ATH E40

FIG.601A




FIG.601A (1-L-11) OPT:MULTI FUNCTION GAUGE (1) (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L45	KIT, SINGLE GAUGE MECH	1	
2	34011-96L15	..GAUGE SET, MULTI	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L30	..ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	

NOTE : DF70A,DF80A,DF90A,DF90AWQH,DF100B

- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF90AWQH E40
- DF100B E01
- DF100B E40

FIG.602A




FIG.602A (1-L-12) OPT:MULTI FUNCTION GAUGE (2) (SEE NOTE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36001-88L00	SET, WIRE	1	
2	36662-88L10	.WIRE, 2 EXTENSION	1	
3	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
4	36664-88L00	.CONNECTOR, BRANCH	1	
5	36665-88L00	.UNIT, RESISTOR FEMALE	1	
6	36665-88L10	.UNIT, RESISTOR MALE	1	
7	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
8	36662-88L10	WIRE, 2 EXTENSION	1	
9	36662-88L20	WIRE, 6 EXTENSION	1	
10	36662-88L30	WIRE, 15 EXTENSION	1	
11	36662-88L00	WIRE, 25 EXTENSION	1	
12	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
13	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
14	36665-88L00	UNIT, RESISTOR FEMALE	1	
15	36665-88L10	UNIT, RESISTOR MALE	1	
16	36664-88L00	CONNECTOR, BRANCH	1	
17	36667-96L20	WIRE, GAUGE EXT	1	
18	36990-87D00	TERMINAL & SLEEVE SET	1	

NOTE : DF70A,DF80A,DF90A,DF100B

- DF70A E01
- DF70A E03
- DF70A E11
- DF70A E40
- DF80A E01
- DF80A E40
- DF90A E01
- DF90A E03
- DF90A E11
- DF90A E40
- DF100B E01
- DF100B E40

FIG.602B




FIG.602B (1-L-13) OPT:MULTI FUNCTION GAUGE (2) (DF90AWQH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36660-89L03	SET, ENG TO INTERFACE WIRE	1	
2	29404-93J01	.CLAMP	1	
3	09407-14407	.CLAMP (L:145)	1	
4	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
5	36662-88L10	WIRE, 2 EXTENSION	1	
6	36662-88L20	WIRE, 6 EXTENSION	1	
7	36662-88L30	WIRE, 15 EXTENSION	1	
8	36662-88L00	WIRE, 25 EXTENSION	1	
9	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
10	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
11	36665-88L00	UNIT, RESISTOR FEMALE	1	
12	36665-88L10	UNIT, RESISTOR MALE	1	
13	36664-88L00	CONNECTOR, BRANCH	1	
14	36667-96L20	WIRE, GAUGE EXT	1	
15	36990-87D00	TERMINAL & SLEEVE SET	1	
16	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	

DF90AWQH E40

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
10000		11410-87851	111C-15	12730-87L00	119A-1
		11489-87L00	585A-1	12741-90J01	121A-3
			180A-1		121B-3
			585A-6		121C-3
11100-87L11	111A-1	11501-87L10-Y5S	180A-2-2	12748-87L00	121A-4
		11501-87L10-YAY	180A-2-1		121B-4
		11510-87L03	136A-1		121C-4
		11514-87L00	136A-5	12749-93J00	121A-5
11112-96L00	111A-14	11541-87L00-QTN	180A-3-3		121B-5
		11541-87L00-Y5S	180A-3-2		121C-5
		11541-87L00-YAY	180A-3-1	12761-87L00	119A-4
		11542-87L00	180A-4	12771-87L00	119A-5
11115-73G01-001	111B-4		585A-7	12810-87L00	119A-7
		11551-87L00-QTN	180A-5-3	12812-90J00	119A-10
		11551-87L00-Y5S	180A-5-2	12813-73G00	119A-8
		11551-87L00-YAY	180A-5-1	12831-93J01	119A-11
11117-89J00	111B-10	11552-87L01	180A-6	12891-69J00	121A-8
			585A-8		121B-8
			116A-7-6		121C-8
			116A-7-1	12892-69J00-208	121A-9-1
11117-90J10	113A-4	12100-69830-025	116A-7-2		121B-9-1
		12100-69830-0A0	116A-7-3		121C-9-1
		12100-69830-0B0	116A-7-4	12892-69J00-210	121A-9-2
		12100-69830-0C0	116A-7-5		121B-9-2
11118-95J00	204A-18	12100-69830-0D0	116A-13		121C-9-2
		12100-69830-0E0	116A-1	12892-69J00-212	121A-9-3
		12100-69830-0F0	116A-2		121B-9-3
		12100-69830-0G0	116A-14		121C-9-3
11118-98J02	111A-11	12100-69830-0H0	116A-3	12892-69J00-214	121A-9-4
		12100-69830-0I0	116A-5		121B-9-4
		12100-69830-0J0	116A-8		121C-9-4
		12100-69830-0K0	121A-19	12892-69J00-216	121A-9-5
11141-87L00	111B-11	12100-69830-0L0	116A-9-6		121B-9-5
		12100-69830-0M0	116A-9-7		121C-9-5
		12100-69830-0N0	116A-9-8	12892-69J00-218	121A-9-6
		12100-69830-0O0	116A-9-9		121B-9-6
11170-87L11	111A-17	12100-69830-0P0	116A-9-10		121C-9-6
		12100-69830-0Q0	116A-10	12892-69J00-220	121A-9-7
		12100-69830-0R0	116A-11		121B-9-7
		12100-69830-0S0	116A-12		121C-9-7
11173-87L00	111B-17	12100-69830-0T0	116A-9-5	12892-69J00-222	121A-9-8
		12100-69830-0U0	116A-9-1		121B-9-8
		12100-69830-0V0	116A-9-2		121C-9-8
		12100-69830-0W0	116A-9-3	12892-69J00-224	121A-9-9
11177-87L00	111A-21	12100-69830-0X0	121B-1		121B-9-9
		12100-69830-0Y0	121C-1		121C-9-9
		12100-69830-0Z0	121A-1	12892-69J00-226	121A-9-10
		12100-69830-0A1	121A-2		121B-9-10
11189-87L00	111B-21	12100-69830-0B1	121B-2		121C-9-10
		12100-69830-0C1	121C-2	12892-69J00-228	121A-9-11
		12100-69830-0D1			
		12100-69830-0E1			
11194-87L10	111C-21	12100-69830-0F1			
		12100-69830-0G1			
		12100-69830-0H1			
		12100-69830-0I1			
11194-87L20	111A-18	12100-69830-0J1			
		12100-69830-0K1			
		12100-69830-0L1			
		12100-69830-0M1			
11196-87L00	111B-18	12100-69830-0N1			
		12100-69830-0O1			
		12100-69830-0P1			
		12100-69830-0Q1			
11216-90J10	113A-5	12100-69830-0R1			
		12100-69830-0S1			
		12100-69830-0T1			
		12100-69830-0U1			
11223-87L00	113A-12	12100-69830-0V1			
		12100-69830-0W1			
		12100-69830-0X1			
		12100-69830-0Y1			
11224-87L00	113A-14	12100-69830-0Z1			
		12100-69830-0A2			
		12100-69830-0B2			
		12100-69830-0C2			
11241-73003	175A-9	12100-69830-0D2			
		12100-69830-0E2			
		12100-69830-0F2			
		12100-69830-0G2			
11261-93J00	111A-5	12100-69830-0H2			
		12100-69830-0I2			
		12100-69830-0J2			
		12100-69830-0K2			
11291-87L00	140A-4	12100-69830-0L2			
		12100-69830-0M2			
		12100-69830-0N2			
		12100-69830-0O2			
11300-87L11	113A-1	12100-69830-0P2			
		12100-69830-0Q2			
		12100-69830-0R2			
		12100-69830-0S2			
11382-93J00	111A-15	12100-69830-0T2			
		12100-69830-0U2			
		12100-69830-0V2			
		12100-69830-0W2			
11382-93J00	111B-15	12100-69830-0X2			
		12100-69830-0Y2			
		12100-69830-0Z2			
		12100-69830-0A3			

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
12892-69J00-230	121B-9-11	12892-69J00-262	121A-9-28	12921-87J11	121C-11
	121C-9-11		121B-9-28		121A-12
	121A-9-12	121C-9-28	121B-12		
	121B-9-12	121A-9-29	121C-12		
12892-69J00-232	121C-9-12	12892-69J00-264	121B-9-29	12931-78G00	121A-13
	121A-9-13		121C-9-29		121B-13
12892-69J00-234	121B-9-13	12892-69J00-266	121A-9-30	12932-24400	121C-13
	121C-9-13		121B-9-30		121A-14
	121A-9-14	121C-9-30	121B-14		
	121B-9-14	121A-9-31	121C-14		
12892-69J00-236	121C-9-14	12892-69J00-268	121B-9-31	12933-51E00	121A-15
	121A-9-15		121C-9-31		121B-15
	121B-9-15	121A-9-32	121C-15		
	121C-9-15	121B-9-32	13110-87L00		122A-1
12892-69J00-238	121A-9-16	121C-9-32	13119-87L00	122A-2	122A-2
	121B-9-16		121A-9-33		13125-87L00
	121C-9-16	121B-9-33	13300-87L11		163A-1
	121A-9-17	121C-9-33	13315-87L00		163A-4
12892-69J00-240	121B-9-17	12892-69J00-274	121A-9-34	13353-99E00	163A-2
	121C-9-17		121B-9-34		13354-99E00
	121A-9-18	121C-9-34	13370-88L00		143A-2
	121B-9-18	121A-9-35	13370-88L10		143B-2
12892-69J00-242	121C-9-18	12892-69J00-276	121B-9-35	13510-87L00	163A-9
	121A-9-19		121C-9-35		13614-89J00
	121B-9-19	121A-9-36	13614-93J00		143B-16
	121C-9-19	121B-9-36	13650-52G00		315A-1
12892-69J00-246	121A-9-20	121C-9-36	1315B-1	1355B-2	315B-1
	121B-9-20		121A-9-37		315A-2
	121C-9-20	121B-9-37	315B-2		
	121A-9-21	121C-9-37	13710-99E00		134A-1
12892-69J00-248	121B-9-21	12892-69J00-282	121A-9-38	13810-87L00	134A-2
	121C-9-21		121B-9-38		13813-87L01
	121A-9-22	121C-9-38	14141-87L00		140A-1
	121B-9-22	121A-9-39	14151-87L00		140A-2
12892-69J00-250	121C-9-22	12892-69J00-284	121B-9-39	585A-4	585A-4
	121A-9-23		121C-9-39		15100-90J04
	121B-9-23	121A-9-40	15100-90J11		146A-1
	121C-9-23	121B-9-40	146B-1		
12892-69J00-252	121A-9-24	12892-69J00-286	121C-9-40	146C-1-2	146C-1-2
	121B-9-24		121A-9-41		15190-87L00
	121C-9-24	121B-9-41	15190-87L20		146B-11
	121A-9-25	121C-9-41	146C-11		
12892-69J00-254	121B-9-25	12892-69J00-290	121A-9-42	15192-87L11	146A-11
	121C-9-25		121B-9-42		15192-87L30
	121A-9-26	121C-9-42	146C-12		
	121B-9-26	12911-87L00	121A-10		15195-87L00
12892-69J00-256	121C-9-26	12915-87L50	121B-10	15195-96L00	146C-22
	121A-9-27		121C-10		146B-24
	121B-9-27	121A-11	146C-24		
	121C-9-27	121B-11	15198-87L00		146A-16

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	146B-17		143B-8		160B-16
	146C-17	15642-88L10	143A-20	17413-99E21	160C-16
15200-92J20	143A-3		143B-20	17416-99E11	160A-17
15200-92J30	143B-3	15643-88L10	143A-17		160B-17
15410-87L00	146A-4		143B-17		160C-17
15410-92J10	146B-4	15644-88L00	143A-13	17461-87E12	160A-2-1
	146C-4	15644-88L10	143B-13		160B-2
15411-92J10	146B-5	15645-88L00	143A-14		160C-2-1
	146C-5		143B-14	17461-87L00	160A-2-2
15412-92J00	146B-6	15648-92J00	143A-16		160C-2-2
	146C-6		143B-24	17471-87L01	160A-3
15413-92J00	146B-7	15650-99E00	143A-9		160B-3
	146C-7		143B-9	17471-87L11	160C-3
15415-92J00	146B-8	15654-88L00	143A-10	17472-87L00	160A-4
	146C-8		143B-10		160B-4
15419-87J00	146A-5	15681-92J01	144A-1		160C-4
15419-92J00	146A-19		144B-1		585A-5
	146B-20	15683-87J00	143A-11	17561-87L20	160A-5-1
	146C-20		143B-11		160B-5
15421-87L00	146A-8	15691-92J00	143A-30		160C-5-1
15421-87L10	146B-9		143B-30	17561-87L30	160A-5-2
	146C-9	15710-82K50	144A-2		160C-5-2
15422-96J01	146A-7		144B-2	17562-87L01	160A-6
15600-92J40	143A-1	15716-65DT0	144A-3		160B-6
15600-92J50	143B-1		144B-3		160C-6
15610-92J00	143A-27	15750-87L30	144A-4	17563-87D01	160A-7
	143B-27	15750-87L40	144B-4		160B-7
15612-88L00	143A-21	15760-88L00	143A-12		160C-7
	143B-21		143B-12		407D-28
15613-88L00	143A-22	15830-87L30	144A-5		407E-28
	143B-22	15830-87L40	144B-5	17564-87D00	160A-8
15613-92J00	143A-25	15831-96L00	146B-23		160B-8
	143B-25		146C-23		160C-8
15614-88L00	143A-23	16400-87L00	175A-1	17570-87L00	407D-27
	143B-23	16440-99E00	175A-3		407E-27
15620-92J00	143A-26	16510-61A31	175A-10	17611-90J00	162A-2
15620-92J10	143B-26	16519-87L00	175A-8	17631-87L00	160A-9
15626-92J01	143A-4	16520-87L00	175A-5		160B-9
15626-92J10	143B-4	16531-87L00	175A-11		160C-9
15628-99E00	143A-5	16539-87L00	175A-12	17632-87L01	160A-10
	143B-5		585A-12		160B-10
15629-99E10	143A-6	16910-87L00	180A-17		160C-10
	143B-6	16930-87L00	180A-18	17660-99E01	162A-3
15641-88L00	143A-7	17400-87L04	160A-18	17670-90J01	162A-4-1
15641-88L10	143B-7		160B-18	17670-90J11	162A-4-2
15641-88L31	143A-18	17400-87L12	160C-18	17681-87L00	162A-5
	143B-18	17410-99E10	160A-1	17685-87L01	162A-6
15641-88L51	143A-19		160B-1	17913-93J00	180A-8
	143B-19		160C-1		410A-15
15642-88L00	143A-8	17413-99E11	160A-16		410B-15

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	410C-15	21131-93J00	204A-2	31173-98L00	301A-4
17914-93J01	180A-9	21151-87L00	204A-3	31191-63J00	301A-5
	410A-16	21152-87L00	204A-4	31192-92J00	301A-8
	410B-16	21153-87L00	204A-5	31220-98L10	301A-6
	410C-16	21157-87L00	204A-6	31261-75F10	301A-9
17915-87L01	162A-11	21210-87L01	204A-13	31281-92J10	337A-8
17917-87L00	410A-40	22511-99011	204A-22	31311-63J00	301A-7
	410B-40		336A-1	31311-93J00	340A-2
	410C-40		336B-1	31313-86030	301A-11
18137-87L02	122A-8		336C-1	31320-98L00	301A-12
18498-87J21	146A-13	23115-87L00	204A-7	31340-98L00	301A-10
18498-87J51	144A-8	23230-90J10	444A-4	31341-98L00	301A-13
	144B-8		444B-4	31343-63J00	301A-14
18498-95J01	111A-24		570A-3	31344-63J00	301A-15
	111B-24	25111-87L01	206A-1-1	31912-87L00	301A-16
	111C-24	25111-87L11	206A-1-2	31918-92J01	301A-17
18498-96J21	146B-14	25131-87L01	206A-2	32102-87L00	303A-1
	146C-14	25141-87L00	206A-5	32120-87L10	303A-5
18498-99E01	143A-33	25223-94400	206A-6	32160-87L00	303A-6
	143B-33	25232-96302	206A-3	32800-87L00	310A-1
18498-99E11	146A-14	25700-87L00	407A-28	32851-93J00	331A-1
	146B-15		407B-28		535A-15
	146C-15		407C-26	32890-87L10	310A-3
18498-99EA1	507A-6		407D-31	32980-38F00	331A-2
18590-68H00	315A-3		407E-31		535A-16
	315B-3	29103-93J00	315A-17	33220-64L10	303A-8
19115-87L00	163A-10	29116-93J00	180A-11	33410-87L00	310A-8
19120-87L00	163A-11-1		206A-7	33634-96J00	322A-4
19120-87L10	163A-11-2		401A-12		322B-4
	570A-56	29116-93J10	160A-11		322C-4
19131-95502	163A-12		160B-11		322D-4
			160C-11	33799-97E00	340A-9
		29404-93J01	180A-12	33810-90J21	322A-1
			602B-2		322B-1
					322C-1
					322D-1
				33833-87L00	322B-36
					322C-32
					322D-36
				33925-92J00	326A-15
					326B-10
21110-87L10	204A-1	31100-98L10	301A-1		326A-14-6
21110-88L00	444A-3	31111-94900	340A-10	33940-87LGO	326A-14-8
	444B-3	31123-94910	340A-4	33940-87LH0	326A-14-1
	570A-2	31133-90J10	340A-5	33940-87LLO	326A-14-2
21112-88L00	444A-41	31133-94910	340A-6		326A-14-4
	570A-40	31135-94900	340A-8	33940-87LM0	326A-14-4
21112-88L10	444B-41	31136-90J20	340A-7	33940-87LN0	326A-14-14
21131-88L02	444A-71	31150-98L00	301A-2	33940-87LP0	326A-14-16
	444B-69	31170-92J00	301A-3	33940-87LQ0	326A-14-10
	570A-57	31173-94920	340A-3	33940-87LR0	326A-14-12

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
33940-87LS0	326B-9		501A-20-2	36610-87LC1	322B-3
33950-87L00	326A-14-15		501B-20-2	36611-87L01	322A-35
33950-87L10	326A-14-17	34200-93J43	501A-29-1		322B-35
33950-87L20	326A-14-7	34200-93J54	501A-29-2		322C-31
33950-87L30	326A-14-9	34211-96L00	600A-4		322D-35
33950-87L40	326A-14-11		601A-5	36611-87L10	322A-15
33950-87L50	326A-14-13	34300-93J02	501A-10-1		322B-15
33950-87L60	326A-14-3		501B-10-1		322D-15
33950-87L70	326A-14-5	34300-93J13	501A-10-2	36612-96J01	322A-16
34000-96L45	601A-1		501B-10-2		322B-16
34011-96L15	600A-1	34310-92E00	501A-11		322C-12
	601A-2		501B-11		322D-16
34100-93J02	501A-3-1	34360-92E00	501A-12	36615-96300	331A-4
	501B-3-1		501B-12		501A-7
34100-93J13	501A-3-2	34500-93J02	460A-3-1		501B-7
	501B-3-2		501A-14-1		535A-18
34100-93J22	501A-3-3		501B-14-1		601A-8
	501B-3-3	34500-93J13	460A-3-2	36616-87L00	322A-20
34100-93J33	501A-3-4		501A-14-2		322B-20
	501B-3-4		501B-14-2		322C-16
34100-93J42	501A-3-5	34600-93J02	501A-8-1		322D-20
	501B-3-5		501B-8-1	36617-87L00	322A-25
34100-93J53	501A-3-6	34600-93J13	501A-8-2		322B-25
	501B-3-6		501B-8-2		322C-21
34100-93J62	501A-3-7	34650-93J22	501A-16-1		322D-25
	501B-3-7		501B-16-1	36617-87L10	322A-27
34112-96L00	600A-2	34650-93J33	501A-16-2		322B-27
	601A-3		501B-16-2		322C-23
34120-98J01	501A-23	34660-90J04	507A-1		322D-27
	501B-23	34800-93J02	460A-1-1	36617-87L20	322A-28
34190-87D00	501A-22		501A-1-1		322B-28
	501B-22		501B-1-1		322C-24
34190-88L00	600A-6	34800-93J13	460A-1-2		322D-28
	602A-7		501A-1-2	36617-88L90	444A-46
	602B-4		501B-1-2		444B-46
34190-95500	501A-24	34825-96L00	600A-5		570A-45
	501B-24		601A-6	36617-93J00	322A-26
34191-92E00	501A-5	34830-87J20	315A-5		322B-26
	501A-17		315B-5		322C-22
	501B-5	34840-98J11	315A-6		322D-26
	501B-17	34841-87L10	315A-9	36618-43410	322A-14
34193-96L00	600A-3	34842-87L01	315A-10		322B-14
	601A-4	34843-87L00	315A-11		322C-11
34200-87L00	444A-45	34845-87L10	315A-12		322D-14
	444B-76	34846-87L00	315A-8	36620-87L01	444A-5
	570A-44	36001-88L00	602A-1		570A-4
34200-93J02	460A-5-1	36360-87L00	444B-45	36620-87L10	444B-5
	501A-20-1	36610-87L91	322A-3	36620-93J03	508A-53-1
	501B-20-1	36610-87LA1	322D-3		508B-53-1
34200-93J14	460A-5-2	36610-87LB1	322C-3		521B-5-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	521C-2-1		602B-13		570A-5
36620-93J10	521A-1-1		600A-13	37110-93J02	530A-2
	521B-1-1	36665-88L00	602A-5		530A-20
36620-93J30	521A-2		602A-14	37110-93J12	508A-3
	521B-2		602B-11	37110-96L10	508B-3
36620-93J41	521A-1-2	36665-88L10	600A-14		535A-2
	521B-1-2		602A-6	37112-88L91	444A-47
36620-93J52	508A-53-2		602A-15		444B-47
	508B-53-2		602B-12		570A-46
	521B-5-2	36667-96L20	521A-5	37114-96L10	535A-5
	521C-2-2		521B-7	37117-96L00	331A-10
36620-93J62	508A-53-3		521C-8		535A-24
	508B-53-3		602A-17	37139-96L40	535A-6
	521B-5-3		602B-14	37139-99E00	530A-6
	521C-2-3	36682-92E00	501A-31	37139-99E40	530A-24
36623-96L11	331A-3		501B-29	37141-99E00	444A-7-1
	535A-17		521C-7		444B-7-1
36625-93J10	322A-37		602B-16		508A-4-1
	322B-37	36721-98L00	322A-7		508B-4-1
	322D-37		322B-7		530A-3-1
36628-92E01	508A-2		322D-7		530A-21-1
	508B-2	36737-98L00	322A-6		535A-3-1
36630-92E00	521C-5		322B-6		570A-6-1
36656-87L00	315A-18		322D-6	37141-99E10	444A-7-2
36656-87L10	315B-7	36738-98L00	322A-8		444B-7-2
36660-89L03	602B-1		322B-8		508A-4-2
36660-94480	521C-6		322D-8		508B-4-2
36661-96L30	601A-7	36890-93J00	517A-23		530A-3-2
36662-88L00	600A-10	36894-87D00	336A-2		530A-21-2
	602A-11		336A-3		535A-3-2
	602B-8		336B-2		570A-6-2
36662-88L10	600A-7		336B-3	37141-99E20	444A-7-3
	602A-2		336C-2		444B-7-3
	602A-8		336C-3		508A-4-3
	602B-5		339A-15		508B-4-3
36662-88L20	600A-8	36895-87D10	336A-4		530A-3-3
	602A-9		336B-4		530A-21-3
	602B-6		336C-4		535A-3-3
36662-88L30	600A-9		337A-27		570A-6-3
	602A-10	36990-87D00	521A-4	37141-99E30	444A-7-4
	602B-7		521B-4		444B-7-4
36662-96L10	331A-5		521C-4		508A-4-4
	535A-19		602A-18		508B-4-4
36663-88L00	600A-12		602B-15		530A-3-4
	602A-3	37100-96J01	530A-1		530A-21-4
	602A-13	37100-96J27	530A-19		535A-3-4
	602B-10	37100-96L12	535A-1		570A-6-4
36664-88L00	600A-15	37105-96L12	535A-14	37141-99E40	444A-7-5
	602A-4	37110-87L02	444A-6		444B-7-5
	602A-16		444B-6		508A-4-5

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	508B-4-5		535A-4		530A-10
	530A-3-5	37143-99E01	444A-8		530A-25
	530A-21-5		444B-8		535A-7
	535A-3-5		508A-5	37820-99E02	315A-14
	570A-6-5		530A-4		315B-6
37141-99E50	444A-7-6		530A-22	37823-92E02	444A-11
	444B-7-6		570A-7		444B-11
	508A-4-6	37149-93J00	444A-9		508A-9
	508B-4-6		444B-9		508B-8
	530A-3-6		508A-6		530A-11
	530A-21-6		530A-5		530A-26
	535A-3-6		530A-23		535A-8
	570A-6-6		570A-8		570A-10
37141-99E60	444A-7-7	37170-96L04	535A-23-1	37825-99E10	530A-13
	444B-7-7		535A-23-3	37826-92J10	444A-12
	508A-4-7	37170-96L14	535A-23-2		444B-12
	530A-3-7	37171-96L02	331A-11-1		508A-10
	530A-21-7		331A-11-3		508B-9
	570A-6-7		535A-25-1		530A-12
37141-99E70	444A-7-8		535A-25-3		530A-27
	444B-7-8	37171-96L12	331A-11-2		535A-9
	508A-4-8		535A-25-2		570A-11
	530A-3-8	37172-96L01	331A-12-1	37835-91J00-YAY	444A-48
	530A-21-8		331A-12-3		444B-48
	570A-6-8		535A-26-1		570A-47
37141-99E80	444A-7-9		535A-26-3	37850-87L01	444A-14
	444B-7-9	37172-96L10	331A-12-2		570A-13
	508A-4-9		535A-26-2	37850-88L00	544A-4
	530A-3-9	37173-96L00	535A-13	37850-92E27	517A-5
	530A-21-9	37173-96L10	331A-6	37850-92J00	326A-6
	570A-6-9		535A-20	37850-96L00	508A-11
37141-99E90	444A-7-10	37210-93J00	530A-17		508B-10
	444B-7-10	37212-93J00	530A-18	37851-88L90	444A-49
	508A-4-10	37721-88L01	545A-11		444B-49
	530A-3-10	37721-93J00	326A-1		570A-48
	530A-21-10		326B-1	37852-87J00	444A-15
	570A-6-10	37721-93J91	508A-7		444B-15
	444A-7-11		508B-6		570A-14
	444B-7-11	37721-95500	518A-12	37852-88L90	444A-50
	508A-4-11	37726-87L00	326A-4		570A-49
	530A-3-11		326B-4	37853-88L90	444A-35
	530A-21-11	37726-90J10	326A-3		444B-35
	570A-6-11		326B-3		570A-34
37141-99EB0	444A-7-12	37803-93J06	530A-9	37854-88L90	444A-59
	444B-7-12	37805-93J00	530A-15		444B-57
	508A-4-12	37820-87L11	444A-10		570A-74
	530A-3-12		444B-10	37855-88L90	444A-58
	530A-21-12		570A-9		444B-56
	570A-6-12	37820-93J11	508A-8		570A-73
37143-96L00	508B-5		508B-7	37855-99E00	530A-16

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
37856-92J00	326A-7	41121-87L11-Y5S	335A-2-2	43755-87L00	336A-17
37857-92J01	326A-8	41121-87L11-YAY	335A-2-1	43761-87L00-YAY	444B-1
37860-87L00	530A-31	41121-87L30-YAY	335B-2	43761-88L01-YAY	444A-1
37861-87L11	444A-51	41130-87L11	335A-3		570A-58
	444B-77		335B-3	43762-88L00	444A-77
	570A-50	41135-93J11	335A-4		444B-73
37862-87L00	530A-32		335B-4		570A-59
37864-88L91	444A-52	41161-94400	442A-1	43768-88L00	444A-78
	444B-78		442B-2		444B-74
	570A-51	41220-87L00	336C-16		570A-60
38100-87L12	337A-9	41220-93J11	336A-21	43770-99E03	444A-75
	340A-1		336B-17		570A-70
38410-93J21	326A-11	41221-95E40	336C-17	43776-87L00	444A-73
38415-93J20	326A-12	41224-95E01	336A-22		570A-61
38500-93J00	521A-3		336B-18	45255-93001	336C-35
	521B-3		336C-18		339A-14
	521C-1	41225-94400	336C-19	45260-87L00	339A-1
38500-93J90	331A-7	41228-90J00	336C-20	45421-87D03	335B-14
	444A-13	41230-87L00	336A-23	47400-87L00	339A-3
	444B-13		336B-19	48000-87L14	337A-1
	508A-12	41230-95E00	336C-21	48120-87L00	339A-4
	508B-11	41233-95E10	336A-24	48121-90J00	337A-25
	530A-7		336B-20	48321-90J00	337A-19
	530A-29		336C-22		339A-5
	535A-10	41234-93J11	336A-25	48325-87L00	337A-21
	535A-21		336B-21		339A-6
	570A-12	43111-87L20-QTN	336A-5-3	48326-95E00	337A-20
38860-76F01	322A-9	43111-87L20-Y5S	336A-5-2		339A-2
	322A-10	43111-87L20-YAY	336A-5-1	48400-87L03	337A-2
	322B-9		336B-5	48502-87L02	337A-10
	322B-10	43111-87L30-YAY	336C-5	48557-90J00	337A-6
	322C-6	43211-87L00	336C-6	48571-87L01	337A-4
	322C-7	43211-93J11	336A-6	48572-87L00	337A-5
	322D-9		336B-6	48582-95E01	337A-11
	322D-10	43241-87J00	335B-18	48583-95E00	337A-12
38860-96L01	331A-8	43411-87L00	336C-28	48585-95E00	337A-13
	535A-22	43415-87L00	336C-29	48588-90J00	337A-15
39950-88L02	600A-11	43420-87L00	336C-30	48611-87L00	337A-3
	602A-12	43427-87L00	336C-31	48862-87J20	337A-7
	602B-9	43510-87L00	336C-32	48862-90J21	337A-18
		43512-87L00	336C-33	48862-92J20	337A-16
		43516-87L00	336C-34	48862-92J30	337A-17
		43711-97E11	336A-7	48864-96J10	337A-14
			336B-7		
			336C-7		
41111-87L10-QTN	335A-1-3	43750-87L20-QTN	336A-8-3		
41111-87L10-Y5S	335A-1-2	43750-87L20-Y5S	336A-8-2		
41111-87L10-YAY	335A-1-1	43750-87L20-YAY	336A-8-1		
41111-87L30-YAY	335B-1		336B-8		
41121-87L11-QTN	335A-2-3	43750-87L30-YAY	336C-8		

50000

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
51111-87L00-Y5S	401A-1-2	55110-87L32-QTN	407B-1-2	56120-87L30-Y5S	220A-24-2
51111-87L00-YAY	401A-1-1	55110-87L32-Y5S	407A-1-2	56120-87L30-YAY	220A-24-1
51115-87L00	401A-2	55110-87L32-YAY	407A-1-1	56130-87L01	220A-30
51117-87L00	401A-3		407B-1-1	57110-87L21	220A-1-1
51122-87L00	401A-20		407C-1	57110-87L31	220A-1-2
51123-87L00	401A-21	55110-87L40-YAY	407D-1	57130-87E02	405A-9
	585A-9		407E-1	57133-87L01	220A-2
51211-87L10	401A-4	55125-90J01	407A-4	57134-87L00	220A-34
	585A-10		407B-4	57135-87L00	220A-35
52111-87L00-QTN	405A-1-3		407C-4	57300-87890	220A-5
52111-87L00-Y5S	405A-1-2		407D-4	57500-87873	220A-8
52111-87L00-YAY	405A-1-1		407E-4	57500-87882	220A-13
	405B-1	55127-87D00	143A-36	57610-87L00	220A-15
52131-87L00-QTN	405A-4-3		143B-36	57621-87L10	220A-16
52131-87L00-Y5S	405A-4-2		407A-12	57630-90J00	407A-27
52131-87L00-YAY	405A-4-1		407B-12		407B-27
52331-87L00	585A-11		407C-12		407C-25
52332-87L11	407A-11		407D-12		407D-30
	407B-11		407E-12		407E-30
	407C-11		501A-26	57631-87L00	220A-17
54114-90J10	405A-17		501B-26	57632-87L01	407A-22
	405B-9	55320-94900	335A-8		407B-22
54120-87L11	401A-23		335B-8		407C-20
54122-87L01	401A-24	55321-87J01	111A-7		407D-22
54130-87L00	401A-25		111B-7		407E-22
54137-87L00	401A-29		111C-7	57633-90J02	407A-23
54140-87L10	401A-32		140A-6		407B-23
54151-87L01	405A-12		337A-23		407C-21
	405B-4		339A-8		407D-23
54160-87L10	405A-13		407A-8-1		407E-23
	405B-5		407C-8-1	58100-87LA0-019	407A-20-1
54166-95J02	401A-26	55321-87J11	407A-8-2		407B-20-1
	405A-14		407B-8-2		407C-18-1
	405B-6		407C-8-2		407D-20-1
54167-87L10	405A-16		407D-8-2		407E-20-1
	405B-8		407E-8-2	58100-87LB0-019	407A-20-2
54180-88L01	405A-22	55321-93J01	405A-10		407B-20-2
	405B-14		407B-8-1		407C-18-2
54211-90J01-QTN	405A-18-3		407D-8-1		407D-20-2
54211-90J01-Y5S	405A-18-2		407E-8-1		407E-20-2
54211-90J01-YAY	405A-18-1	55321-94910	335A-5	58100-87LC0-019	407A-20-3
	405B-10		335B-5		407B-20-3
54221-87L00-QTN	405A-19-3	55332-87L00	407D-11		407C-18-3
54221-87L00-Y5S	405A-19-2		407E-11		407D-20-3
54221-87L00-YAY	405A-19-1	55333-87L00	407A-10		407E-20-3
	405B-11		407B-10	58100-87LD0-019	407A-20-4
54231-87L00-QTN	405A-20-3		407C-10		407B-20-4
54231-87L00-Y5S	405A-20-2	55333-87L10	407D-10		407C-18-4
54231-87L00-YAY	405A-20-1		407E-10		407D-20-4
	405B-12	56120-87L30-QTN	220A-24-3		407E-20-4

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
58100-87LE0-019	407A-20-5	58200-92J60	407A-20-14	61422-90J40	420H-14-1
	407B-20-5		407B-20-14	61424-87L00	420G-18
	407C-18-5		407C-18-14	61431-87L21-QTN	420B-2-2
	407D-20-5		407D-20-14		420F-2-2
	407E-20-5		407E-20-14		420J-2-2
58100-87LF0-019	407A-20-6	58200-92J70	407A-20-15	61431-87L21-Y5S	420A-2-2
	407B-20-6		407B-20-15		420E-2-2
	407C-18-6		407C-18-15		420H-2-2
	407D-20-6		407D-20-15	61431-87L21-YAY	420A-2-1
	407E-20-6		407E-20-15		420B-2-1
58100-90JA0-019	407A-20-7	58200-92J80	407A-20-16		420C-2
	407B-20-7		407B-20-16		420D-2
	407C-18-7		407C-18-16		420E-2-1
	407D-20-7		407D-20-16		420F-2-1
	407E-20-7		407E-20-16		420G-2
58100-90JB0-019	407A-20-8	58200-92J90	407A-20-17		420H-2-1
	407B-20-8		407B-20-17		420J-2-1
	407C-18-8		407C-18-17	61435-87LB0	420A-14-1
	407D-20-8		407D-20-17	61435-87LC0	420C-14
	407E-20-8		407E-20-17	61435-87LD0	420E-14-1
58100-90JC0-019	407A-20-9	60000	407A-20-18		420G-14
	407B-20-9		407B-20-18	61435-87LE0	420A-14-2
	407C-18-9		407C-18-18	61435-87LF0	420E-14-2
	407D-20-9		407D-20-18	61435-87LG0	420B-14-1
	407E-20-9		407E-20-18	61435-87LH0	420B-14-2
58100-90JD0-019	407A-20-10	61112-99E01	410A-1	61435-87LJ0	420D-14
	407B-20-10		410B-1	61435-87LK0	420F-14-1
	407C-18-10		410C-1	61435-87LL0	420F-14-2
	407D-20-10	61124-87L20	410A-29	61435-87LM0	420J-14-1
	407E-20-10		410B-29	61435-87LN0	420J-14-2
58100-90JE0-019	407A-20-11	61134-87L01	410C-29	61439-87L00	420A-3
	407B-20-11		410A-2		420B-3
	407C-18-11		410B-2		420C-3
	407D-20-11		410C-2		420D-3
	407E-20-11	61401-87Y01-YAY	420A-1-1		420E-3
58105-90J00	407A-21		420C-1		420F-3
	407B-21		420E-1-1		420G-3
	407C-19		420H-1-1		420H-3
	407D-21	61401-87Y11-Y5S	420A-1-2		420J-3
	407E-21		420E-1-2	61443-88L20	420A-9-1
58200-92J40	407A-20-12		420H-1-2		420C-9
	407B-20-12	61401-87Y40-YAY	420G-1		420E-9-1
	407C-18-12	61401-87Y50-YAY	420B-1-1		420G-9
	407D-20-12		420D-1		420H-9-1
	407E-20-12		420F-1-1	61443-88L30	420A-9-2
58200-92J50	407A-20-13		420J-1-1		420E-9-2
	407B-20-13	61401-87Y60-QTN	420B-1-2		420H-9-2
	407C-18-13		420F-1-2	61443-88L40	420B-9-1
	407D-20-13		420J-1-2		420D-9
	407E-20-13	61422-87L90	420H-14-2		420F-9-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
61443-88L50	420J-9-1		420C-12		444B-16
	420B-9-2		420D-12		570A-15
	420F-9-2		420E-12	63132-88L00	444A-76
	420J-9-2		420F-12		444B-72
61453-88L20	420A-10-1		420G-12		570A-71
	420C-10		420H-12	63210-88L00	444A-17
	420E-10-1	61632-93J00	420J-12		444B-17
	420G-10		410A-17		570A-16
61453-88L30	420H-10-1		410B-17	63215-93110	444A-72
	420A-10-2		410C-17		444B-70
	420E-10-2	61633-87L00	410A-20		570A-68
	420H-10-2		410B-20	63221-88L00	444A-18
61453-88L40	420B-10-1		410C-20		444B-18
	420D-10	61641-87L00	410A-18		570A-17
	420F-10-1		410B-18	63223-92D00	444A-19
	420J-10-1		410C-18		444B-19
61453-88L50	420B-10-2	61645-87L00	410A-21		570A-18
	420F-10-2		410B-21	63225-88L00	444A-20
	420J-10-2		410C-21		444B-20
			410A-22		570A-19
61458-90J01	420A-15	61673-93J11	410B-22	63227-93200	444A-21
	420B-15		410C-22		444B-21
	420C-15		410A-3-3		570A-20
	420D-15	61811-87L20-QTN	410A-3-2	63235-88L00	444A-22
	420E-15	61811-87L20-Y5S	410A-3-1		444B-22
	420F-15	61811-87L20-YAY	410B-3		570A-21
	420G-15		410C-3	63244-99J00	444A-53
	420H-15		410A-4-3		444B-51
61472-88L01	420J-15	61821-87L21-QTN	410A-4-2		570A-52
61476-87L00	136A-6	61821-87L21-Y5S	410A-4-1	63245-99J00	444A-54
	420A-5	61821-87L21-YAY	410B-4		444B-52
	420B-5		410C-4		570A-53
	420C-5	61821-87L30-YAY	410A-9	63246-88L00	444A-23
	420D-5	61827-87L00	410B-9		444B-23
	420E-5		410C-9		570A-22
	420F-5		410A-11-3	63247-99J00	444A-63
	420G-5	61831-87L20-QTN	410A-11-2		444B-61
61494-87L02	420H-5	61831-87L20-Y5S	410A-11-1		570A-78
	420J-5	61831-87L20-YAY	410B-11	63248-99J00	444A-31
	136A-8		410C-11		444B-31
	420A-6		570A-30		570A-30
61610-93J00	420B-6	63002-87L17-YAY	444A-2	63250-88L00	444A-24
	420C-6	63110-87L15-YAY	444B-2		444B-24
	420D-6	63110-87L20-YAY	444A-64		570A-23
	420E-6	63111-88L00-YAY	444B-62	63251-87J00	444A-25
	420F-6		570A-79		444B-25
61621-87L00	420G-6	63115-88L01	444A-69		570A-24
	420H-6		444B-67	63251-88L90	444A-57
	420J-6		570A-66		444B-55
	420A-12		444A-16		570A-72
	420B-12	63121-88L10			

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
63258-88L00	444A-60		518A-1	67237-92E01	518A-31
	444B-58		508A-1		545A-28
	570A-75	67200-93J61	508B-1	67238-87D00	508A-19
	444A-26	67200-96L11	544A-17		508B-18
63260-88L00	444B-26	67211-88L00	517A-29	67238-88L00	545A-31
	570A-25	67211-92E50	544A-7	67238-92E50	518A-32
	444A-32	67212-88L00	508A-13	67238-96L00	508A-51
	444B-32	67212-95600	508B-12		508B-50
63261-87J00	570A-31		508A-15	67239-92E00	518A-33
	444A-29	67220-95630	508B-14		545A-35
	444B-29		545A-8	67239-92E10	518A-29
	570A-28	67221-92E00	518A-7		545A-41
63271-87J00	444A-30	67222-92E00	545A-2	67240-92E00	545A-17
	444B-30	67222-92E50	518A-2	67240-92E50	518A-16
	570A-29	67223-92E00	545A-3	67241-88L00	545A-34
	444A-27	67223-92E50	518A-6	67241-92E50	518A-42
63272-87J00	444B-27	67223-99E10	508A-16	67241-99E11	508A-20
	570A-26		508B-15		508B-19
	444A-28	67224-92E00	545A-9	67242-92E50	517A-13
	444B-28	67224-92E50	518A-8	67243-92E00	545A-38
63274-87J00	570A-27	67224-96L00	508A-50	67243-95600	508A-21
	444A-33		508B-49		508B-20
	444B-33	67225-92E00	518A-25	67244-95600	508A-22
	570A-32	67225-92E50	518A-9		508B-21
63610-87J00	444A-34	67226-92E00	545A-15	67245-92E00	518A-22
	444B-34	67226-92E10	518A-14		545A-23
	570A-33		545A-16	67245-95600	508A-23
	444A-43	67227-92E00	518A-23		508B-22
63611-88L00	444B-43		545A-24	67246-88L00	545A-36
	570A-42	67228-92E00	518A-17	67246-92E50	518A-34
	444A-44		545A-18	67251-88L00	544A-20
	444B-44	67229-95600	508A-17	67251-92E50	517A-9
63612-87J00	570A-43		508B-16	67251-96L00	508A-24
	444A-55	67230-88L00	545A-20		508B-23
	444B-53	67230-92E00	518A-19	67252-88L00	545A-39
	570A-54	67231-88L00	545A-32	67252-92E00	518A-35
63626-88L00	444A-36	67231-92E00	518A-40	67252-92E10	518A-38
	444B-36	67232-88L00	545A-33	67252-95600	508A-25
	570A-35	67232-92E50	518A-43		508B-24
	432A-1	67232-95600	508A-18	67253-88L00	545A-40
65000-94L10	432A-2		508B-17	67253-92E00	544A-13
65520-99100	432A-3		518A-41	67253-92E10	518A-37
65561-95D00	432A-6	67233-92E00	518A-27	67253-95600	508A-26
65700-90J24	432A-4		545A-26		508B-25
65740-95D01	432A-7	67234-88L00	545A-22		518A-39
65750-95501	475A-1	67234-92E00	518A-21	67254-92E50	517A-22
65770-90J04	432A-8	67235-92E00	518A-28	67255-92E50	517A-8
67200-88L01	544A-1		545A-27	67255-96L00	508A-27
	545A-1	67236-92E00	518A-30		508B-26
67200-93J34	517A-1		545A-12	67256-92E50	517A-11

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67256-95600	508A-28	67287-92E50	517A-19	67296-96L10	508A-34
	508B-27	67288-92E00	545A-4		508B-33
67257-88L00	544A-9	67288-92E10	518A-4	67297-95600	508A-45
67257-92E00	517A-12	67288-92E20	517A-14		508B-44
67257-96L00	508A-29		544A-6	67298-92E50	517A-2
	508B-28	67288-92E60	517A-6	67300-98J10	410B-41
67258-99E00	508A-31		544A-12		410C-41
	508B-30	67288-92E70	517A-16	67341-87L00	410A-31
67259-87D00	508A-32	67288-94320	508A-49		410B-31
	508B-31		508B-48		410C-31
67261-88L00	544A-3	67291-92E00	518A-5	67345-87L00	410A-33
67261-88L10	544A-2		545A-7		410B-33
67261-92E50	517A-10	67291-92E10	518A-36		410C-33
67261-96L00	508A-33		545A-37	67346-87L01	410A-34
	508B-32	67292-87J00	444A-37		410B-34
67263-88L00	444B-14		444B-37		410C-34
	444B-50		570A-36	67350-87L02	410A-36
67264-88L00	544A-18	67292-94300	508A-39		410B-36
67264-88L10	544A-19		508B-38		410C-36
67264-95600	508A-35		518A-3	67361-90J10	410A-41
	508B-34		545A-5		410B-42
67267-96L00	508A-36	67294-92E00	518A-11		410C-42
	508B-35	67294-95600	508A-40	67467-89J01	204A-24
67269-92E01	545A-29		508B-39		442A-7
67269-96L10	508A-47	67295-92E10	517A-4		442B-8
	508B-46	67295-92E50	517A-18	67500-88L00	519A-1
67271-88L10	544A-16	67296-88D10	517A-15		544A-21
67272-88L00	545A-6		518A-24	67700-87L01	442B-1
67273-88L00	519A-5		545A-13	67701-87L01	442A-2
	544A-25		545A-30		442B-3
	545A-47	67296-88D20	517A-17	67721-87L00	442A-3
67273-95601	508A-37	67296-88D30	517A-21		442B-4
	508B-36	67296-88L00	544A-5	67725-99E20	442A-4
	517A-25	67296-90J20	508A-41		442B-5
	544A-15		508B-40	67726-99E00	442A-5
67274-88L00	545A-42	67296-92E11	508A-14		442B-6
67274-92E50	517A-28		508B-13	67728-99E00	442A-6
67275-95600	508A-38		518A-13		442B-7
	508B-37	67296-92E20	518A-15	68111-87L00	420A-11
	517A-24		545A-14		420B-11
	544A-14	67296-92E30	545A-44		420C-11
67281-88L00	544A-10	67296-92E60	544A-11		420D-11
67283-92E50	517A-26	67296-94310	517A-3		420E-11
67284-92E50	517A-27	67296-95610	508A-44		420F-11
67284-94L10	508A-52		508B-43		420G-11
	508B-51		545A-43		420H-11
67285-96L00	508B-52	67296-95630	508A-43		420J-11
67286-92E00	518A-18		508B-42	68111-88L00	544A-8
	545A-19	67296-96L00	508A-42	69711-93E11	136A-7
67287-92E00	545A-46		508B-41		

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
70000		01550-0612A	326A-13		310A-9
			121A-6		401A-15
			121B-6	01550-0625C	111A-19
			121C-6		111B-19
		01550-0612C	113A-13		111C-19
77811-54GB0-0PG	508A-30		143A-35		146A-2
	508B-29		143B-35		146B-2
			146A-18		146C-2
			146B-19		310A-2
			146C-19		310A-5
			180A-20	01550-06307	140A-3
			303A-11	01550-0630C	136A-2
			322A-32		162A-7
			322B-32	01550-06357	163A-16
			322C-28	01550-0640C	204A-11
99011-87L80-03B	420A-17-3		322D-32	01550-0645C	111A-20
	420E-17-3				111B-20
99011-87L80-054	420A-17-1		326A-5		111C-20
	420C-17-1		420A-8	01550-0650C	163A-5
	420E-17-1		420B-8	01550-0655C	163A-7
	420H-17-1		420C-8	01550-08207	301A-19
99011-87L80-059	420A-17-2		420D-8	01550-0820C	111A-9
	420C-17-2		420E-8		111B-9
	420E-17-2		420F-8		111C-9
	420H-17-2		420G-8		113A-2
99011-87L90-03B	420B-17-3		420H-8		140A-8
	420F-17-3		420J-8		410A-10
99011-87L90-054	420B-17-1	01550-0616A	175A-7		410B-10
	420D-17-1	01550-0616C	146A-9		410C-10
	420F-17-1		146B-10	01550-0825A	119A-6
	420J-17-1		146C-10		401A-22
99011-87L90-059	420B-17-2		163A-6	01550-0825C	144A-12
	420D-17-2		301A-18		144B-12
	420F-17-2		303A-9	01550-08307	175A-13
	420G-17		410A-32	01550-0830C	122A-5
	420J-17-2		410B-32		163A-17
			410C-32	01550-0835A	119A-9
			420A-4	01550-0835C	301A-20
			420B-4	01550-08407	111A-12
			420C-4		111B-12
			420D-4		111C-12
			420E-4		113A-10
			420F-4	01550-0845C	122A-6
			420G-4	01570-06127	410A-38
			420H-4		410B-38
			420J-4		410C-38
01421-08257	122A-4		119A-12	02112-0408A	143A-15
01550-06127	322A-24	01550-0620A	111A-28	02112-0612A	111A-22
	322B-24	01550-0620C	111B-28		111B-22
	322C-20		111C-28		111C-22
	322D-24				

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
02112-34167	122A-9		508B-45	09116-08137	335A-6
02142-0408B	143A-24	09100-12090	335A-10-2		335B-6
02142-06167	322A-23		335B-10-2		401A-33
	322B-23	09100-12127	335A-10-1		407A-5
	322C-19		335B-10-1		407B-5
	322D-23	09103-05026	410A-27		407C-5
02162-05207	315A-4		410B-27		407D-5
	315B-4		410C-27		407E-5
03112-0630B	501A-25	09103-05027	410A-28		444A-65
	501B-25		410B-28		444B-63
			410C-28		570A-62
03121-0516A	530A-28	09103-06093	315A-13	09116-08159	401A-6
03122-05165	530A-14	09103-06211	303A-12	09116-08174	410A-12
	535A-12		175A-2		410B-12
03522-05169	444A-62	09103-06220	111A-2		410C-12
	444B-60	09103-06266	111B-2	09116-08178	180A-10
	570A-77		111C-2		401A-5
03542-06209	136A-4		111A-8	09116-10129	180A-15
04211-11129	401A-8	09103-06281	111B-8	09116-10137	407A-16
	401A-9		111C-8		407B-16
04211-13189	111A-13		140A-7		407C-16
	111B-13		144A-6		407D-16
	111C-13		144B-6		407E-16
04221-04089	116A-6		337A-24	09116-10147	401A-31
04221-05109	121A-7		339A-11	09116-10150	407A-17
	121B-7		407A-9		407B-17
	121C-7		407C-9		407C-17
06111-07004	220A-21	09103-16004	303A-2		407D-17
06111-11004	220A-22	09106-05030	303A-7		407E-17
08113-60087	220A-28		335B-16		444A-74
08310-00067	322A-17	09106-10065	405A-5		444B-71
	322B-17	09108-10115	336A-18		570A-69
	322C-13	09108-10156	405A-6	09116-10179	337A-26
	322D-17	09108-10157	204A-12		339A-10
08316-10087	146B-21	09116-05010	162A-8	09116-10181	180A-16
	146C-21	09116-06121	180A-7		401A-30
	322A-2		335A-9		405A-2
	322B-2		335B-9		405A-21
	322C-2	09116-06127	410A-19		405B-2
	322D-2		410B-19		405B-13
08316-1008C	122A-7		410C-19	09117-08110	220A-33
08321-01067	322A-18		310A-4	09125-04004	518A-26
	322B-18	09116-06202	134A-4	09125-04021	517A-7
	322C-14	09116-06215	143A-28	09125-05042	518A-20
	322D-18	09116-06217	143B-28		545A-21
08331-41359	204A-23		405A-11	09125-05046	315A-7
08332-1107A	206A-4	09116-06236	407B-9	09125-05047	444A-42
09100-06182	336C-36		407D-9		444B-42
09100-06183	336C-38		407E-9		570A-41
09100-06184	339A-9		220A-29	09125-05050	337A-28
09100-08232	508A-46	09116-08122			

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09125-05135	519A-2		336C-24		401A-28
	544A-22	09140-14024	220A-10	09160-12124	444A-68
09125-06063	336A-9	09141-18005	407A-24		444B-66
	336A-10		407B-24		570A-65
	336A-11		407C-22	09160-12128	335A-13
	336A-26		407D-24		335B-13
	336B-9		407E-24	09160-13014	410A-23
	336B-10	09159-06079	336C-39		410B-23
	336B-11	09159-10050	336A-19		410C-23
	336B-22	09159-10232	336C-41	09160-16047	303A-3
	336C-9	09159-12014	335A-11	09160-18028	407A-26
	336C-10		335B-11		407B-26
	336C-11		401A-27		407C-24
	336C-23		405A-15		407D-26
	339A-16		405B-7		407E-26
09125-06124	407D-29		444A-66	09160-18031	401A-10
	407E-29		444B-64	09160-39001	336A-12
09126-06006	545A-25		570A-63		336B-12
09126-06015	444A-38	09159-14020	335B-15		336C-12
	444B-38	09159-22006	335A-7	09161-10013	336C-40
	570A-37		335B-7	09161-16008	160A-12
09131-05004	530A-33	09160-05024	545A-45		160B-12
09132-04034	160A-15	09160-05029	519A-3		160C-12
	160B-15		544A-23	09163-06001	444A-39
	160C-15	09160-06046	163A-14		444B-39
09136-06148	410A-5	09160-06055	204A-25		570A-38
	410B-5		442A-9	09164-13010	444A-70
	410C-5		442B-10		444B-68
09136-06149	410A-6	09160-06082	336A-28		570A-67
	410B-6		336B-24	09164-14008	410A-24
	410C-6		336C-25		410B-24
09136-06161	410A-7	09160-06084	163A-8		410C-24
	410B-7	09160-06094	336C-37	09164-31001	220A-36
	410C-7	09160-06104	517A-20	09168-10022	407A-7
09137-04004	326A-2	09160-06173	336C-42		407B-7
	326B-2	09160-06174	336C-43		407C-7
09140-05005	163A-13	09160-09019	204A-8		407D-7
	519A-4		204A-14		407E-7
	544A-24	09160-10082	335B-17	09168-12012	180A-13
09140-06020	339A-12	09160-10141	407A-19	09168-16002	175A-4
	508A-48		407B-19	09169-06053	322A-21
	508B-47		407D-19		322B-21
	518A-10		407E-19		322C-17
	545A-10	09160-10161	339A-7		322D-21
09140-10031	407A-18	09160-10165	336A-20	09169-06062	111A-29
	407B-18	09160-12066	444A-67		111B-29
	407D-18		444B-65		111C-29
	407E-18		570A-64		310A-6
09140-10032	336A-27	09160-12110	335A-12	09169-06075	134A-5
	336B-23		335B-12	09169-06090	143A-29

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09169-08050	143B-29	09181-64006	220A-14-5		420J-13
	410A-13	09181-64007	220A-14-6	09246-04009	175A-14
	410B-13	09181-64008	220A-14-7	09248-10008	407A-6
	410C-13	09181-64009	220A-14-8		407B-6
09169-28003	336A-13	09181-64010	220A-14-9		407C-6
	336B-13	09181-64011	220A-14-10		407D-6
09180-06186	163A-15	09202-04022	410A-25		407E-6
09181-25030	220A-23		410B-25	09248-12009	180A-14
09181-25072	220A-11-6		410C-25	09248-12011	204A-16
09181-25073	220A-11-7	09202-06031	160A-13	09248-18010	401A-11
09181-25074	220A-11-8		160B-13	09248-18011	113A-6
09181-25075	220A-11-9		160C-13	09248-18014	113A-7
09181-25130	220A-11-1	09202-07003	220A-18	09250-40002	326B-6
09181-25139	220A-11-2	09202-08006	401A-7	09260-10005	204A-20
09181-25143	220A-11-3		405A-3	09260-10006	444A-56
09181-25149	220A-11-4		405A-7		444B-54
09181-25153	220A-11-5		405B-3		570A-55
09181-31001	220A-37		407A-3	09262-17019	401A-16
09181-39001	336A-14		407B-3	09262-32023	119A-2
	336B-14		407C-3	09262-35070	119A-3
	336C-13		407D-3	09263-25067	220A-6
09181-40004	220A-12-2		407E-3		220A-25
09181-40005	220A-12-3	09204-01006	444B-75	09263-26023	407A-2
09181-40006	220A-12-4		204A-9		407B-2
09181-40007	220A-12-5		204A-15		407C-2
09181-40008	220A-12-6		336A-29		407D-2
09181-40009	220A-12-7		336B-25		407E-2
09181-40010	220A-12-8		336C-26	09265-25046	220A-4
09181-40011	220A-12-9	09204-03003	407A-25	09265-40003	220A-7
09181-40012	220A-12-10		407B-25	09280-08012	144A-7
09181-40013	220A-12-11		407C-23		144B-7
09181-40018	220A-12-1		407D-25	09280-09008	180A-19
09181-40186	220A-9-1		407E-25	09280-11001	401A-13
09181-40190	220A-9-7	09205-05011	220A-3	09280-17002	175A-6
09181-40195	220A-9-11	09205-10008	204A-19	09280-20002	401A-14
09181-41002	220A-9-2	09206-08001	111A-3	09280-22019	111A-6
09181-41003	220A-9-3		111B-3		111B-6
09181-41004	220A-9-4		111C-3		111C-6
09181-41005	220A-9-5	09206-13019	113A-9		140A-5
09181-41006	220A-9-6	09208-06009	410A-42	09280-26005	146A-3
09181-41008	220A-9-8		410B-43		146B-3
09181-41009	220A-9-9		410C-43		146C-3
09181-41010	220A-9-10	09229-04025	420A-13	09280-26006	111A-16
09181-41012	220A-9-12		420C-13		111B-16
09181-41013	220A-9-13		420E-13		111C-16
09181-41014	220A-9-14		420H-13		162A-9
09181-64002	220A-14-1	09229-04056	420B-13	09280-46004	220A-31
09181-64003	220A-14-2		420D-13	09280-55006	206A-8
09181-64004	220A-14-3		420F-13	09280-92004	220A-26
09181-64005	220A-14-4		420G-13	09282-08005	206A-9

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09282-22007	220A-32	09352-50003-490	143A-31		146C-25
	401A-18		143B-31	09401-15414	111A-25
09282-25001	220A-27	09352-50006-600	162A-13		111B-25
09282-39001	336A-15		162A-14		111C-25
	336B-15		507A-2		113A-11
	336C-14		507A-3		162A-12
09283-52006	116A-12	09352-70104-600	410A-37	09401-26408	162A-10
09289-05012	121A-16		410B-37	09403-07308	322A-29
	121B-16		410C-37		322B-29
	121C-16	09355-11165-600	111A-23		322C-25
09289-18001	401A-17		111B-23		322D-29
09306-13007	410A-26		111C-23	09403-07338	315A-15
	410B-26	09355-40805-008	407A-13	09403-11320	146A-17
	410C-26		407B-13		146B-18
09307-09002	204A-10		407C-13		146C-18
	204A-17		407D-13		410A-39
09320-04013	322A-22		407E-13		410B-39
	322B-22		501A-27		410C-39
	322C-18		501B-27	09403-11321	322A-33
	322D-22	09362-09008	407A-14		322B-33
09320-08062	144A-9		407B-14		322C-29
	144B-9		407C-14		322D-33
09320-08510	322A-5		407D-14		326A-9
	322B-5		407E-14		326B-7
	322C-5	09367-06006	507A-4	09403-12324	143A-34
	322D-5	09380-22015	337A-22		143B-34
09320-09016	111A-30		339A-13	09403-12409	322A-34
	111B-30	09380-38003	336A-16		322B-34
	111C-30		336B-16		322C-30
	136A-3		336C-15		322D-34
	310A-7	09381-18002	116A-4	09403-13413	303A-10-2
09320-09059	134A-6	09381-40005	405A-8		315A-16
09320-11023	410A-14	09383-04002	410A-43	09403-13414	303A-10-1
	410B-14		410B-44	09403-20310	303A-13
	410C-14		410C-44	09407-08401	530A-8
09321-08022	410A-8	09385-06012	204A-26		530A-30
	410B-8		442A-8		535A-11
	410C-8		442B-9	09407-10404	326A-10
09329-10024	420A-7	09401-08412	143A-32		326B-8
	420B-7		143B-32		407A-15
	420C-7	09401-08413	162A-15		407B-15
	420D-7		507A-5		407C-15
	420E-7	09401-11423	146A-6		407D-15
	420F-7		146A-15		407E-15
	420G-7		146B-16		501A-28
	420H-7		146C-16		501B-28
	420J-7		432A-5	09407-11401	162A-16
09343-70503-600	146A-12	09401-11425	144A-10	09407-14407	315A-19
	146B-13		144B-10		322A-30
	146C-13	09401-14409	146B-25		322B-30

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	322C-26		501B-4		
	322D-30	09471-12077	460A-6		
	331A-9		501A-21		
	501A-6		501A-30		
	501A-18		501B-21		
	501B-6	09471-12103	460A-4		
	501B-18		501A-9		
	535A-27		501A-13		
	602B-3		501A-15		
09407-20405	507A-7		501A-19		
09407-25402	410A-30		501B-9		
	410B-30		501B-13		
	410C-30		501B-15		
09408-00020	322A-36		501B-19		
09408-00021	322A-19	09471-12108	460A-2		
	322B-19		501A-2		
	322C-15		501B-2		
	322D-19	09481-10501	508A-54		
09408-00024	322A-31		508B-54		
	322B-31		521B-6		
	322C-27		521C-3		
	322D-31	09481-10504	322A-11		
09408-00155	111A-26		322B-11		
	111B-26		322C-8		
	111C-26		322D-11		
09408-00233	144A-11	09481-15501	322A-38		
	144B-11		322B-38		
09409-10304-5ES	410A-35		322D-38		
	410B-35	09481-30504	322A-12		
	410C-35		322B-12		
09420-04008	303A-4		322C-9		
09420-04009	160A-14		322D-12		
	160B-14	09481-40403	322A-13		
	160C-14		322B-13		
09440-06037	444A-61		322C-10		
	444B-59		322D-13		
	570A-76	09482-00446	111A-31		
09440-07071	204A-21		111B-31		
09440-09043	220A-19		111C-31		
09440-12027	444A-40	09800-81841	420A-16		
	444B-40		420B-16		
	570A-39		420C-16		
09440-19028	336A-30		420D-16		
	336B-26		420E-16		
	336C-27		420F-16		
	336C-44		420G-16		
09440-42002	220A-20		420H-16		
09443-10043	336A-31		420J-16		
	336B-27				
09471-12028	501A-4				

[illegible]

SUZUKI DF70A/80A/90A/100B PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION

Service Material Development Group, Service Engineering Dept.

300 Takatsuka, Minami, Hamamatsu, Japan

SUZUKI MOTOR CORPORATION