

SUZUKI

PARTS CATALOGUE

DF115BG

DF115BG/BZG



OUTBOARD MOTOR

021

2020-10

E11/E40
E11 = NORGE

1ST EDITION

PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF115BG/115BZG production start 2020.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E. NO.	: Engine number	OS	: Over size
F. NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	W/	: With
LH(PORT)	: Left hand side	L, X	: Transom type
RH(STBD)	: Right hand side	SUS	: Stainless steel
~123456	: Up to E. NO. 14003F-123456	PTT	: Power trim and tilt
123456~	: From E. NO. 14003F-123456		

12 x 34 x 5.6..... Figures in the description column
| | | show the dimensions of parts.
ID OD T(or W, L)

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

↔12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual.
When assembling, use "SUZUKI SERVICE MANUAL".

6. MODEL NAME AND ENGINE NUMBER

MODEL	DESTINATION	TYPE	TRANSOM	COLOR	ENGINE No.
DF115BG	E11, E40	11505F	L, X	YAY, QTN	11505F-140001~
DF115BZG	E11, E40	11505Z	L, X	YAY, QTN	11505Z-140001~

PREFACE

Quand il devient nécessaire de remplacer des pièces sur SUZUKI MOTEURS HORSBOARD toujours utiliser les PIÈCES D'ORIGINE SUZUKI qui ont été soumises à des contrôles de qualité sévères leur garantissant qualité et performance impeccables.

Ce catalogue de pièces détachées couvre la liste de toutes les pièces de rechange pour SUZUKI DF115BG/115BZG production start 2020.

INSTRUCTIONS POUR UTILISER LE CATALOGUE

1. DIMENSIONS

Les dimensions des pièces dans ce catalogue sont indiquées en unités de millimètres.

2. ABREVIATIONS

Les abréviations utilisées dans ce catalogue sont les suivantes:

AR	: Comme requis	NT	: Nombre de dents
ASSY	: Assemblage	OPT	: Sur option
E. NO.	: Numéro du moteur	OS	: Sur-dimensionné
F. NO.	: Numéro du chfssis	T	: Epaisseur
ID	: Diamètre intérieur	US	: Sous-dimensionné
OD	: Diamètre extérieur	W	: Largeur

L : Longueur

LH(PORT) : Côte gauche

RH(STBD) : Côte droit

~123456 : Jusqu'à E. NO. 14003F-123456

123456~ : Depuis E. NO. 14003F-123456

12 x 34 x 5.6..... Les chiffres dans la colonne

| | | remarques montrent les dimensions

ID OD T(or W, L) des pieces comme suit.

~12345-56781 (N° de pieces) : indique que le numéro des pièces a été échangé en 12345-56781 et que les nouvelles pièces sont interchangeables avec les anciennes, mais que celles-ci ne sont pas interchangeables avec les nouvelles.

~12345-56781 (N° de pieces) : indique que les anciennes et nouvelles pièces sont interchangeables les unes avec les autres et sont utilisables chacune.

3. PIÈCES INTERNES DE L'ASSEMBLAGE

Les numéros de pièces qui comportent un point (.) avant la désignation de pièce détachée indique la pièce interne se rapportant à l'assemblage.

4. AVIS DE MODIFICATION

Un bulletin de pièces détachées vous sera envoyé à tout moment opportun quand des changements de pièces ont lieu, y compris les modifications de pièces interchangeables entre les nouvelles et anciennes pièces.

5. A NOTER

5-1. Il existe certaines pièces différentes de celles de rechange pour les modèles de production vu des raisons administratives et dont l'usage est commun avec celles d'autres modèles.

5-2. Concernant les durites en caoutchouc et les tuyaux en vinyle, ne pas manquer de les couper à la bonne longueur comme indiqué dans le catalogue des pièces détachées ou selon ce qui est utile pour le véhicule affecté.

5-3. Noter que les dessins à la page d'illustration servent à titre de référence pour les numéros de pièces détachées, et non pas comme référence pour l'assemblage. Pour cette dernière opération, se reporter au "MANUEL D'ENTRETIEN SUZUKI".

6. NOM DU MODÈLE / NUMÉRO DE SÉRIE DU MOTEUR

MODELE	DESTINATION	TYPE	HOUTEUR DE		N° DELA MOTEUR
			BARRE D' ARCASSE	COULEUR	
DF115BG	E11, E40	11505F	L, X	YAY, QTN	11505F-140001~
DF115BZG	E11, E40	11505Z	L, X	YAY, QTN	11505Z-140001~

[illegible][illegible]

MILLIMETER → INCH CONVERSION CHART


	0	1	2	3	4	5	6	7	8	9
00	.000	.039	.079	.118	.157	.197	.236	.276	.315	.354
10	.394	.433	.472	.512	.551	.591	.630	.669	.709	.748
20	.787	.827	.866	.906	.945	.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.535
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.214	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.031	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

How to read

	0	1	2	3	4
00	...	...	...	...	...
10	...	...	...	...	...
20	...	...	...	0.906	...
30	...	...	...	...	...


23 millimeters equal 0.906 inch

FIG.111A




3P173ABZ, ETL, 631, 111A
CYLINDER HEAD

FIG.113A




3P173ABZ, ETL, 631, 113A
CYLINDER BLOCK

FIG.116A




3P173ABZ, ETL, 631, 116A
CRANKSHAFT

FIG.119A




3P173ABZ, ETL, 631, 119A
TIMING BELT

FIG.121A




3P173ABZ, ETL, 631, 121A
CAMSHAFT

FIG.122A




3P173ABZ, ETL, 631, 122A
INTAKE MANIFOLD

FIG.134A




3P173ABZ, ETL, 631, 134A
AIR FILTER

FIG.136A




3P173ABZ, ETL, 631, 136A
RING GEAR COVER

FIG.143A




0F1143BZ, ETL, 031, 143A
FUEL INJECTOR

FIG.143B




0F1143BZ, ETL, 031, 143B
FUEL INJECTOR

FIG.144A




0F1144BZ, ETL, 031, 144A
FUEL INJECTOR

FIG.144B




0F1144BZ, ETL, 031, 144B
FUEL INJECTOR

FIG.146A




0F1146BZ, ETL, 031, 146A
FUEL PUMP

FIG.160A




0F1160BZ, ETL, 031, 160A
WATER PUMP

FIG.160B




0F1160BZ, ETL, 031, 160B
WATER PUMP

FIG.162A




0F1162BZ, ETL, 031, 162A
WATER PUMP

FIG.163A




0FT100BL,ET1L,001L,100M
THROTTLE BODY

FIG.175A




0FT100BL,ET1L,001L,170M
CL. 25-6P

FIG.180A




0FT100BL,ET1L,001L,100M
CL. 24V

FIG.204A




0FT100BL,ET1L,001L,200M
CL.001/004/007

FIG.210A




0FT100BL,ET1L,001L,210M
SHIFT ROD

FIG.210B




0FT100BL,ET1L,001L,210B
SHIFT ROD

FIG.220A




0FT100BL,ET1L,001L,220M
TRANSMISSION

FIG.220B




0FT100BL,ET1L,001L,220B
TRANSMISSION

FIG.301A




3011000Z, ETL, 601, 301A
STARTING MOTOR

FIG.303A




3011000Z, ETL, 601, 303A
MAGNETS

FIG.310A




3011000Z, ETL, 601, 310A
ELECTRONIC CONTROL UNIT

FIG.315A




3011000Z, ETL, 601, 315A
SENSOR

FIG.322A




3011000Z, ETL, 601, 322A
HARNESS

FIG.326A




3011000Z, ETL, 601, 326A
PTT SWITCH/HORNIE CONTROLS UNIT

FIG.331A




3011000Z, ETL, 601, 331A
KEY-LESS START

FIG.335A




3011000Z, ETL, 601, 335A
CLAMP BRACKET

FIG.336A




0FT100RE,ETL,601,500A
DRIVE SHAFT

FIG.337A




0FT100RE,ETL,601,500A
DRIVE SHAFT

FIG.340A




0FT100RE,ETL,601,500A
DRIVE SHAFT

FIG.401A




0FT100RE,ETL,601,601A
DRIVE SHAFT

FIG.405A




0FT100RE,ETL,601,601A
DRIVE SHAFT

FIG.407A




0FT100RE,ETL,601,601A
DRIVE SHAFT

FIG.407B




0FT100RE,ETL,601,601B
DRIVE SHAFT

FIG.407C




0FT100RE,ETL,601,601C
DRIVE SHAFT

FIG.407D




0FT100BL, ETL, 601, 401D
SEAFOUR

FIG.410A




0FT100BL, ETL, 601, 401A
SEAFOUR

FIG.420A




0FT100BL, ETL, 601, 401A
SEAFOUR

FIG.430A




0FT100BL, ETL, 601, 401A
SEAFOUR

FIG.432A




0FT100BL, ETL, 601, 401A
SEAFOUR

FIG.442A




0FT100BL, ETL, 601, 401A
SEAFOUR

FIG.475A




0FT100BL, ETL, 601, 401A
SEAFOUR

FIG.507A




0FT100BL, ETL, 601, 401A
SEAFOUR

FIG.520A




0FT100EL, ETL, 601, 604
OPTIFLEX/US/INT 624000201

FIG.522A




0FT100EL, ETL, 601, 604
OPTIFLEX/US/INT 624000201

FIG.523A




0FT100EL, ETL, 601, 604
OPTIFLEX/US/INT 624000201

FIG.530A




0FT100EL, ETL, 601, 604
OPTIFLEX/US/INT 624000201

FIG.535A




0FT100EL, ETL, 601, 604
OPTIFLEX/US/INT 624000201

FIG.540A




0FT100EL, ETL, 601, 604
OPTIFLEX/US/INT 624000201

FIG.543A




0FT100EL, ETL, 601, 604
OPTIFLEX/US/INT 624000201

FIG.585A




0FT100EL, ETL, 601, 604
OPTIFLEX/US/INT 624000201

FIG.601A




DETILED ETI 011 0019
DETILED ETI FUNCTION GAUGE (1)

FIG.602A



DETILED ETI 011 0019
DETILED ETI FUNCTION GAUGE (2)

FIG.111A



DF115BG_E11_021_111A
CYLINDER HEAD

FIG.111A (1-B-2) CYLINDER HEAD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-99L00	HEAD, CYLINDER	1	
2	09103-06266	.BOLT (6X40)	21	
3	09206-08001	.PIN (8X11)	18	
4	11115-85FA1-001	GUIDE, VALVE (OS:0.3)	16	OPT
5	11261-93J00	COVER, PROTECTION ANODE	2	
6	09280-22019	O RING (D:1.9,ID:21.8)	2	
7	55321-87J01	ANODE, PROTECTION	2	
8	09103-06281	BOLT (6X14)	2	
9	01550-0820C	BOLT	2	
10	11117-89J00	BOLT, CYLINDER HEAD	10	
11	11141-99L00	GASKET, CYLINDER HEAD	1	
12	09116-08177	BOLT (8X52)	8	
13	04211-13189	PIN	2	
14	11170-99L00	COVER, CYLINDER HEAD	1	
15	11173-99L00	PLATE, BREATHER	1	
16	11179-90J00	GASKET, SPARK PLUG HOLE	4	
17	11189-90J00	GASKET, CYLINDER HEAD COVER	1	
18	11382-93J00	CAP, OIL FILLER	1	
19	11174-99L00	HOSE COMP, BREATHER	1	
20	09280-26006	O RING (D:3.1,ID:26.4)	1	
21	11194-99L00	GUARD, FUEL HOSE	1	
22	09401-20409	CLIP	2	
23	01547-0625C	BOLT	11	
24	01547-0655C	BOLT	4	
25	02112-0612A	SCREW	8	
26	09482-00649	SPARK PLUG (LKR6E) CUSHION	4	NGK
27	09320-08517	CUSHION	4	
28	09329-12004		2	

FIG.113A




FIG.113A (1-B-3) CYLINDER BLOCK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11291-99L00	HOOK, ENGINE	1	
2	01550-1230C	BOLT	2	
3	11301-99L00	BLOCK, CYLINDER	1	
4	11117-90J10	.BOLT, CRANKCASE	10	
5	11216-90J10	.GASKET, OIL GALLERY PLUG	3	
6	09248-18014	.PLUG (18X8)	3	
7	09206-13019	.PIN (10.4X13X16)	5	
8	01550-0840C	.BOLT	10	
9	11112-90J00	.PLUG, OIL VENTURI	1	
10	09246-04009	PLUG, OIL GALLERY	1	
11	11261-93J00	COVER, PROTECTION ANODE	1	
12	09280-22019	O RING (D:1.9,ID:21.8)	1	
13	55321-87J01	ANODE, PROTECTION	1	
14	09103-06281	BOLT (6X14)	1	
15	01550-0820C	BOLT	1	

FIG.116A




FIG.116A (1-B-4) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12111-99L00	PISTON	4	
2	12140-92J10	RING SET, PISTON	4	
3	12151-99L00	PIN, PISTON	4	
4	09381-21002	SNAP RING	8	
5	12160-92J10	CONNROD ASSY	4	
6	12163-35F00	.BOLT, CONNROD	8	
7	04221-04089	.PIN	8	
8-1	12100-92841-0A0	BEARING SET, CONNROD (GREEN)	4	
8-2	12100-92840-025	BEARING SET, CONNROD (US:0.25)	4	OPT
9	12220-99L00	CRANKSHAFT (NT:29)	1	
10	09202-05027	.PIN (5X8.8)	1	
11-1	12340-85FB3-0A0	BEARING SET, CRANKSHAFT	5	GREEN
11-2	12340-85FB3-0B0	BEARING SET, CRANKSHAFT	5	BLACK
11-3	12340-85FB3-0C0	BEARING SET, CRANKSHAFT	5	NON
11-4	12340-85FB3-0D0	BEARING SET, CRANKSHAFT	5	YELLOW
11-5	12340-85FB3-0E0	BEARING SET, CRANKSHAFT	5	BLUE
11-6	12300-85854-0AA	BEARING SET, CRANKSHAFT (US:0.25)	5	OPT
11-7	12300-85854-0BA	BEARING SET, CRANKSHAFT (US:0.25)	5	RED/GREEN
11-8	12300-85854-0CA	BEARING SET, CRANKSHAFT (US:0.25)	5	OPT
11-9	12300-85854-0DA	BEARING SET, CRANKSHAFT (US:0.25)	5	RED
11-10	12300-85854-0EA	BEARING SET, CRANKSHAFT (US:0.25)	5	OPT
12-1	12300-85830	BEARING SET, CRANK THRUST	1	RED/YELLOW
12-2	12300-85830-012	BEARING SET, CRANK THRUST (OS:0.12)	1	OPT
13	09283-52006	OIL SEAL (52X70X10)	1	RED/BLUE
14	12100-99L00-050	PISTON SET (OS:0.50)	4	OPT
15	12140-92J10-050	.RING SET, PISTON (OS:0.50)	4	OPT

FIG.119A




FIG.119A (1-B-5) TIMING CHAIN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12732-90J01	GEAR, DRIVEN (NT:18)	1	
2	12741-90J01	SPROCKET, CAM SHAFT TIMING (NT:29)	2	
3	09103-12049	BOLT (12X25)	2	
4	12733-90J00	PLUG, DRIVEN GEAR	1	
5	04221-05109	PIN	2	
6	09262-35068	BEARING (35X62X14)	1	UPPER
7	09280-22022	O RING (D:1.9,ID:21.8)	1	
8	08331-41269	CIRCLIP	1	
9	12761-90J10	CHAIN, TIMING	1	
10	12771-90J00	GUIDE, TIMING CHAIN	1	
11	12810-90J00	TENSIONER, TIMING CHAIN	1	
12	12813-73G00	.PAD, TIMING CHAIN TENSIONER	1	
13	12812-90J00	SPACER, TIMING CHAIN TENSIONER	1	
14	12831-90J02	ADJUSTER, TENSIONER	1	
15	01421-0616A	STUD BOLT	1	
16	01550-0616A	BOLT	2	
17	01550-0620A	BOLT	1	
18	01550-0835A	BOLT	1	
19	08316-1006A	NUT	1	



FIG.121A




FIG.121A (1-B-6) CAMSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12711-99L00	CAMSHAFT, INTAKE	1	
2	12720-99L00	CAMSHAFT, EXHAUST	1	
3	12891-69G00	TAPPET	16	
4-1	12892-69G10-218	SHIM, TAPPET (T:2.175)	AR	
4-2	12892-69G10-220	SHIM, TAPPET (T:2.200)	AR	
4-3	12892-69G10-223	SHIM, TAPPET (T:2.225)	AR	
4-4	12892-69G10-225	SHIM, TAPPET (T:2.250)	AR	
4-5	12892-69G10-228	SHIM, TAPPET (T:2.275)	AR	
4-6	12892-69G10-230	SHIM, TAPPET (T:2.300)	AR	
4-7	12892-69G10-233	SHIM, TAPPET (T:2.325)	AR	
4-8	12892-69G10-235	SHIM, TAPPET (T:2.350)	AR	
4-9	12892-69G10-238	SHIM, TAPPET (T:2.375)	AR	
4-10	12892-69G10-240	SHIM, TAPPET (T:2.400)	AR	
4-11	12892-69G10-243	SHIM, TAPPET (T:2.425)	AR	
4-12	12892-69G10-245	SHIM, TAPPET (T:2.450)	AR	
4-13	12892-69G10-248	SHIM, TAPPET (T:2.475)	AR	
4-14	12892-69G10-250	SHIM, TAPPET (T:2.500)	AR	
4-15	12892-69G10-253	SHIM, TAPPET (T:2.525)	AR	
4-16	12892-69G10-255	SHIM, TAPPET (T:2.550)	AR	
4-17	12892-69G10-258	SHIM, TAPPET (T:2.575)	AR	
4-18	12892-69G10-260	SHIM, TAPPET (T:2.600)	AR	
4-19	12892-69G10-263	SHIM, TAPPET (T:2.625)	AR	
4-20	12892-69G10-265	SHIM, TAPPET (T:2.650)	AR	
4-21	12892-69G10-268	SHIM, TAPPET (T:2.675)	AR	
4-22	12892-69G10-270	SHIM, TAPPET (T:2.700)	AR	
4-23	12892-69G10-273	SHIM, TAPPET (T:2.725)	AR	
4-24	12892-69G10-275	SHIM, TAPPET (T:2.750)	AR	
4-25	12892-69G10-278	SHIM, TAPPET (T:2.775)	AR	
4-26	12892-69G10-280	SHIM, TAPPET (T:2.800)	AR	
4-27	12892-69G10-283	SHIM, TAPPET (T:2.825)	AR	
4-28	12892-69G10-285	SHIM, TAPPET (T:2.850)	AR	
4-29	12892-69G10-288	SHIM, TAPPET (T:2.875)	AR	
4-30	12892-69G10-290	SHIM, TAPPET (T:2.900)	AR	
4-31	12892-69G10-293	SHIM, TAPPET (T:2.925)	AR	

FIG.121A




FIG.121A (1-B-7) CAMSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
4-32	12892-69G10-295	SHIM, TAPPET (T:2.950)	AR	
4-33	12892-69G10-298	SHIM, TAPPET (T:2.975)	AR	
4-34	12892-69G10-300	SHIM, TAPPET (T:3.000)	AR	
5	12911-86FA2	VALVE, INTAKE	8	
6	12915-86F51	VALVE, EXHAUST	8	
7	12921-90J01	SPRING, VALVE	16	
8	12931-90J00	RETAINER, VALVE SPRING	16	
9	12932-85FA0	COTTER, VALVE	32	
10	12933-86510	SEAT, VALVE SPRING	16	
11	09289-06003	OIL SEAL (6X12.8X10.2)	16	

FIG.122A




FIG.122A (1-B-8) INTAKE MANIFOLD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-99L00	MANIFOLD, INTAKE	1	
2	13119-99L00	.GASKET, INTAKE MANIFOLD	4	
3	13125-99L00	.GASKET, THROTTLE BODY	1	
4	01421-0830C	STUD BOLT	2	
5	01550-0835C	BOLT	6	
6	08316-1008C	NUT	2	

FIG.134A




FIG.134A (1-B-9) SILENCER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13710-99E00	ARRESTER, FLAME	1	
2	13810-99L00	SILENCER	1	
3	13813-99L00	HOLDER, FLAME ARRESTER	1	
4	09169-06090	WASHER	2	
5	09320-09059	CUSHION	2	
6	09116-06517	BOLT (6X25)	2	

FIG.136A




FIG.136A (1-B-10) RING GEAR COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11511-99L00	COVER, RING GEAR	1	
2	11514-99L00	PLATE, RING GEAR COVER	1	
3	03542-06209	SCREW	3	
4	11512-99L00	CUSHION, RING GEAR COVER	2	
5	11515-99L00	BRACE, RING GEAR COVER	1	
6	09103-06240	BOLT	2	
7	09108-06060	BOLT, STUD RING GEAR COVER	1	
8	09160-06084	WASHER, RING GEAR COVER	1	
9	09169-06097	WASHER, RING GEAR COVER	1	
10	08316-10067	NUT	1	
11	61494-99L00	LABEL, OIL & CLEARANCE	1	
12	69711-93E11	LABEL (S.I.G.P.)	1	

FIG.143A




FIG.143A (1-B-11) FUEL VAPOR SEPARATOR (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15600-99L00	SEPARATOR ASSY, FUEL VAPOR	1	
2	13370-99L00	.VALVE ASSY, NEEDLE	1	
3	15200-92J20	.PUMP ASSY, FUEL (H)	1	
4	15626-92J01	.SEAL	1	
5	15628-99E00	.SCREW (L:15)	5	
6	15629-99E10	.SCREW, DRAIN	1	
7	15641-88L00	.SPACER	1	
8	15642-88L00	.FILTER ASSY	1	
9	15650-99E00	.FLOAT	1	
10	15654-88L00	.PIN	1	
11	13684-99L00	.HOSE, DRAIN (L:280)	1	
12	15760-88L00	.REGULATOR ASSY	1	
13	15644-88L00	.O RING	1	
14	15645-88L00	.HOLDER, REGULATOR	1	
15	02112-0408A	.SCREW	1	
16	15648-92J00	.RING	1	
17	15643-88L10	.JOINT	1	
18	15641-88L31	.BUSH	1	
19	15641-88L51	.BUSH	1	
20	15642-88L10	.FILTER	1	
21	15612-88L00	.COVER	1	
22	15613-88L00	.O RING	1	
23	15614-88L00	.SCREW	3	
24	02142-0408B	.SCREW	1	
25	15613-92J00	.GASKET	1	
26	15620-99L00	.CASE ASSY, VAPOR SEPARATOR UPPER	1	
27	15610-92J00	.CASE ASSY, VAPOR SEPARATOR LOWER	1	

FIG.143A




FIG.143A (1-B-12) FUEL VAPOR SEPARATOR (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09116-06517	BOLT (6X25)	3	
29	09169-06090	WASHER	3	
30	15691-92J00	CUSHION	3	
31	15660-99L00	HOSE COMP, EVAPORATION	1	
32	36617-93J00	BRACKET, HARNESS	1	
33	36617-93J10	BRACKET, HARNESS	2	
34	09320-08517	CUSHION, CABLE HOLDER	2	
35	09352-50003-065	HOSE, EVAPORATION NO.1	1	
36	09352-50003-120	HOSE, EVAPORATION NO.2	1	
37	09367-05004	JOINT, HOSE	1	
38	09401-08412	CLIP	5	
39	09403-08329	CLAMP	4	
40	01550-0612C	BOLT	3	
41	09403-11321	CLIP	1	

DF115BG E11
DF115BZG E11

FIG.143B




FIG.143B (1-B-13) FUEL VAPOR SEPARATOR (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15600-99L10	SEPARATOR ASSY, FUEL VAPOR	1	
2	13370-99L10	.VALVE ASSY, NEEDLE	1	
3	15200-92J30	.PUMP ASSY, FUEL (H)	1	
4	15626-92J10	.SEAL	1	
5	15628-99E00	.SCREW (L:15)	5	
6	15629-99E10	.SCREW, DRAIN	1	
7	15641-88L10	.SPACER	1	
8	15642-88L00	.FILTER ASSY	1	
9	15650-99E00	.FLOAT	1	
10	15654-88L00	.PIN	1	
11	13684-99L00	.HOSE, DRAIN (L:280)	1	
12	15760-88L00	.REGULATOR ASSY	1	
13	15644-88L10	.O RING	1	
14	15645-88L00	.HOLDER, REGULATOR	1	
15	13614-89J00	.SCREW	1	
16	15648-92J00	.RING	1	
17	15643-88L10	.JOINT	1	
18	15641-88L31	.BUSH	1	
19	15641-88L51	.BUSH	1	
20	15642-88L10	.FILTER	1	
21	15612-88L00	.COVER	1	
22	15613-88L00	.O RING	1	
23	15614-88L00	.SCREW	3	
24	13614-93J00	.SCREW	1	
25	15613-92J00	.GASKET	1	
26	15620-99L10	.CASE ASSY, VAPOR SEPARATOR UPPER	1	
27	15610-92J00	.CASE ASSY, VAPOR SEPARATOR LOWER	1	

FIG.143B




FIG.143B (1-B-14) FUEL VAPOR SEPARATOR (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09116-06517	BOLT (6X25)	3	
29	09169-06090	WASHER	3	
30	15691-92J00	CUSHION	3	
31	15660-99L00	HOSE COMP, EVAPORATION	1	
32	36617-93J00	BRACKET, HARNESS	1	
33	36617-93J10	BRACKET, HARNESS	2	
34	09320-08517	CUSHION, CABLE HOLDER	2	
35	09352-50003-065	HOSE, EVAPORATION NO.1	1	
36	09352-50003-120	HOSE, EVAPORATION NO.2	1	
37	09367-05004	JOINT, HOSE	1	
38	09401-08412	CLIP	5	
39	09403-08329	CLAMP	4	
40	01550-0612C	BOLT	3	
41	09403-11321	CLIP	1	

DF115BG E40
DF115BZG E40

FIG.144A




FIG.144A (1-B-15) FUEL INJECTOR (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-99L00	HOSE, FUEL (SEPARATOR TO DLVY)	1	
2	15710-99L00	INJECTOR, FUEL	4	
3	15716-65DT0	.GROMMET SET	4	
4	15423-99L00	GUARD, FUEL HOSE	1	
5	15751-99L00	PIPE, DELIVERY	1	
6	01550-0625C	BOLT	2	
7	09168-12013	GASKET (11.8X22X1.2)	3	
8	09320-08062	CUSHION	4	
9	09360-12008	UNION	1	
10	09363-08004	UNION	1	
11	09401-11425	CLIP	2	
12	01421-0820C	STUD BOLT	2	
13	01550-12167	BOLT	1	
14	08316-1008C	NUT	2	

DF115BG E11
DF115BZG E11



FIG.144B




FIG.144B (1-C-2) FUEL INJECTOR (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-99L00	HOSE, FUEL (SEPARATOR TO DLVY)	1	
2	15710-99L00	INJECTOR, FUEL	4	
3	15716-65DT0	.GROMMET SET	4	
4	15423-99L00	GUARD, FUEL HOSE	1	
5	15751-99L00	PIPE, DELIVERY	1	
6	01550-0625C	BOLT	2	
7	15762-90J00	GASKET	3	
8	09320-08062	CUSHION	4	
9	09360-12013	UNION	1	
10	15830-90J00	UNION	1	
11	09401-11425	CLIP	2	
12	01421-0820C	STUD BOLT	2	
13	09247-12013	BOLT	1	
14	08316-1008C	NUT	2	

DF115BG E40
DF115BZG E40



FIG.146A




FIG.146A (1-C-3) FUEL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY		REMARKS
1-1	15100-96J01	PUMP ASSY, FUEL	1	E11	
1-2	15100-96J11	PUMP ASSY, FUEL	1	E40	
2	15190-99L00	HOSE, FUEL INLET (TO 2WAY)	1		
3	09251-07003	CAP(OD:11.5)	1		
4	15195-96L00	HOSE, FUEL (2WAY TO FILTER)	1		
5	15192-99L00	HOSE, FUEL (FILTER TO PUMP)	1		
6	15410-92J10	FILTER, FUEL	1		
7	15411-92J10	.CAP, FUEL FILTER	1		
8	15412-92J00	.FILTER, FUEL	1		
9	15413-92J00	.CASE, FUEL FILTER	1		
10	15415-92J00	.SEAL, FUEL FILTER	1		
11	15421-99L00	BRACKET, FUEL FILTER	1		
12	15195-96L10	HOSE, FUEL (PUMP TO 2WAY)	1		
13	09280-33004	O RING (D:3.1,ID:32.7)	1		
14	15193-99L00	HOSE, FUEL (2WAY TO SEPARATOR)	1		
15	09403-12314	CLAMP	3		
16	15831-96L00	UNION, 2 WAY FUEL HOSE	2		
17	09401-14409	CLIP	6		
18	09401-11006	CLIP	3		
19	08316-1008C	NUT	1		
20	09103-06211	BOLT (6X25)	2		
21	01550-0616C	BOLT (6X16)	2		

[illegible]

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	17410-92J00	CASE, WATER PUMP	1	
2	17461-90J01	IMPELLER, WATER PUMP	1	
3	17471-92J00	PANEL, PUMP CASE UNDER	1	
4	17472-87E10	GASKET, PUMP CASE PANEL	1	
5-1	17561-90J03	TUBE, WATER (L)	1	W/TRANSOM(L)
5-2	17561-90J13	TUBE, WATER (X)	1	W/TRANSOM(X)
6	17562-90J01	BUSH, WATER TUBE UPPER	1	
7	17563-87D01	BUSH, WATER TUBE LOWER	1	
8	17564-87D00	BUSH, WATER PUMP CASE	1	
9	17631-90J00	FILTER, WATER PORT SIDE	1	
10	17632-90J00	FILTER, WATER STBD SIDE	1	
11	17635-90J00	PLUG, SUB WATER TUBE	1	
12	09116-08131	BOLT (8X45)	4	
13	09125-05046	SCREW (5X12)	2	
14	09161-16008	WASHER (15.8X26X1)	2	
15	09202-06031	PIN (6X12)	2	
16	09420-05009	KEY	1	
17	09132-04034	SCREW (4X18)	2	
18	17413-92J01	SLEEVE, WATER PUMP CASE	1	
19	17416-92J11	SEALING, WATER PUMP CASE	1	
20	17612-90J01	SPACER, WATER TUBE	1	W/TRANSOM(X)

[illegible]

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
21	17400-92J23	KIT, WATER PUMP REPAIR	1 OPT	
22	17500-90J11	KIT, WATER SUB TUBE	1 OPT	
23	17520-90J00	.TUBE, WATER SUB	1 OPT	
24	17563-87D01	.BUSH, WATER TUBE LOWER	1 OPT	
25	17635-87E00	.FILTER, WATER SUB	1 OPT	
26	55332-87D02	.RUBBER, EXHAUST SEAL	1 OPT	
27	55333-87D02	.PLATE, EXHAUST SEAL	1 OPT	
28	09125-06063	.SCREW (6X10)	1 OPT	

DF115BG_E11_021

FIG.160B





FIG.160B (1-C-6) WATER PUMP (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-92J00	CASE, WATER PUMP	1	
2	17461-90J01	IMPELLER, WATER PUMP	1	
3	17471-92J10	PANEL, PUMP CASE UNDER	1	
4	17472-87E10	GASKET, PUMP CASE PANEL	1	
5-1	17561-90J03	TUBE, WATER (L)	1	W/TRANSOM(L)
5-2	17561-90J13	TUBE, WATER (X)	1	W/TRANSOM(X)
6	17562-90J01	BUSH, WATER TUBE UPPER	1	
7	17563-87D01	BUSH, WATER TUBE LOWER	1	
8	17564-87D00	BUSH, WATER PUMP CASE	1	
9	17631-90J00	FILTER, WATER PORT SIDE	1	
10	17632-90J00	FILTER, WATER STBD SIDE	1	
11	17635-90J00	PLUG, SUB WATER TUBE	1	
12	09116-08131	BOLT (8X45)	4	
13	09125-05046	SCREW (5X12)	2	
14	09161-16008	WASHER (15.8X26X1)	2	
15	09202-06031	PIN (6X12)	2	
16	09420-05009	KEY	1	
17	09132-04034	SCREW (4X18)	2	
18	17413-92J11	SLEEVE, WATER PUMP CASE	1	
19	17416-92J11	SEALING, WATER PUMP CASE	1	
20	17612-90J01	SPACER, WATER TUBE	1	W/TRANSOM(X)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
21	17400-92J11	KIT, WATER PUMP REPAIR	1 OPT	
22	17500-90J11	KIT, WATER SUB TUBE	1 OPT	
23	17520-90J00	.TUBE, WATER SUB	1 OPT	
24	17563-87D01	.BUSH, WATER TUBE LOWER	1 OPT	
25	17635-87E00	.FILTER, WATER SUB	1 OPT	
26	55332-87D02	.RUBBER, EXHAUST SEAL	1 OPT	
27	55333-87D02	.PLATE, EXHAUST SEAL	1 OPT	
28	09125-06063	.SCREW (6X10)	1 OPT	

DF115BG_E11_021

FIG.162A



DF115BG_E11_021_162A
THERMOSTAT

FIG.162A (1-C-8) THERMOSTAT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11196-99L00	HOSE, WATER RETURN	1	
2	17611-90J00	COVER, WATER PRESS VALVE	1	
3	17660-98L01	VALVE, WATER PRESSURE	1	
4-1	17670-90J01	THERMOSTAT, WATER 60 DEG	1	
4-2	17670-90J11	THERMOSTAT, WATER 71 DEG	1	OPT
5	17681-99L00	COVER, THERMOSTAT	1	
6	17711-90J00	3 WAY, WATER HOSE	1	
7	09116-06121	BOLT (6X25)	2	
8	09280-26006	O RING (D:3.1,ID:26.4)	1	
9	09352-11154-050	HOSE, WATER (HOLDER TO 3WAY)	1	L:50 HOLDER TO 3 WAY
10	17712-99L00	HOSE, WATER (3WAY TO SEPARATOR)	1	L:120 3WAY TO SEPARATOR
11	09352-50006-600	HOSE (5X9X600)	1	L:600->220 3WAY TO CRKC LOWER
12	17915-99L00	HOSE, FLUSH	1	
13	17710-99L00	HOSE, WATER	1	
14	17581-99L00	PIPE, WATER OUTLET	1	
15	09280-26006	O RING (D:3.1,ID:26.4)	1	
16	09401-15414	CLIP	2	
17	09401-08413	CLIP	5	
18	09401-14409	CLIP	2	
19	09401-31407	CLIP	2	
20	01550-0620C	BOLT	1	
21	01550-0620C	BOLT	3	
22	01550-0655C	BOLT	1	
23	09403-12420	CLAMP	2	
24	09403-16416	CLAMP	1	
25	09408-00056	CLAMP	2	
26	09408-00174	CLAMP	1	
27	09408-00175	CLIP	1	
28	01550-0612C	BOLT	2	
29	01550-0612C	BOLT	1	

DF115BG_E11_021

FIG.163A

FIG.163A (1-C-9) THROTTLE BODY

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-99L00	BODY ASSY, THROTTLE	1	
2	13315-99L00	BRACKET, THROTTLE BODY	1	
3	01550-0820C	BOLT, EXH PIPE STIFFENER	2	
4	01550-0860C	BOLT, COLLECTOR BRKT NO.2	4	




FIG.175A (1-C-10) OIL PUMP




FIG.180A




FIG.180A (1-C-11) OIL PAN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11489-90J10	GASKET, OIL PAN	1	
2-1	11501-90J20-YAY	PAN, OIL (BLACK)	1	
2-2	11501-90J20-QTN	PAN, OIL (WHITE)	1	
3	17913-93J00	PLUG, WATER	1	
4	43112-99E00	PIPE, EXHAUST	1	
5	61150-99E01	COVER ASSY, WATER INDICATOR	1	
6	09280-09016	.O RING (D:1.9,ID:8.8)	1	
7	61155-99E01	TUBE, WATER INDICATOR	1	
8	09116-08178	BOLT (8X40)	3	
9	09116-10129	BOLT (10X160)	8	
10	09168-12012	GASKET (12.5X20X2.5)	1	
11	09248-12009	PLUG (12X18.65)	1	OIL DRAIN
12	17914-93J01	GASKET, WATER PLUG	1	
13	16910-99L00	GAUGE, OIL LEVEL	1	
14	16930-99L00	GUIDE, OIL LEVEL	1	
15	09280-21015	O RING (D:2.1,ID:8.8)	1	
16	01550-0616C	BOLT	1	
17	16934-99L00	CASE, OIL LEVEL GUIDE	1	
18	16941-99L00	GASKET, OIL LVL GAGE GUIDE	1	
19	01550-0625C	BOLT	4	

FIG.204A




FIG.204A (1-C-12) CLUTCH SHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11118-95J00	PLUG, NOTCH SPRING	1	
2	19110-99L00	HOLDER COMP, CLUTCH	1	
3	21110-99L00	LEVER COMP, CLUTCH	1	
4	21151-99L00	HOLDER, CLUTCH LEVER	1	
5	21155-99L00	HOLDER, SHIFT LEVER	1	
6	21210-99L00	SHAFT, CLUTCH	1	
7	21230-99L00	ARM COMP, CLUTCH SHAFT	1	
8	21241-99L00	ROD, CLUTCH LEVER	1	
9	22511-99011	NIPPLE,GREASE	1	
10-1	23111-90J02	ROD, CLUTCH (L)	1	W/TRANSOM(L)
10-2	23111-90J12	ROD, CLUTCH (X)	1	W/TRANSOM(X)
11	23115-99L00	LINK, CLUTCH LEVER	1	
12	67467-89J01	CONNECTOR	1	
13	67467-89J10	CONNECTOR, REMOCON CABLE NO.2	1	
14	67471-99E00	NUT, REMOCON CABLE	1	
15	67471-99E10	NUT, REMOCON CABLE NO.2	1	
16	09160-06055	WASHER (7X12X1)	2	
17	09160-06094	WASHER (6.5X15X1.0)	2	
18	09204-01006	PIN	2	
19	09204-01006	PIN	2	
20	09206-11019	PIN, CLUTCH HOLDER	2	
21	09248-12011	PLUG (12X9)	1	
22	09260-10005	BALL	1	
23	09306-06004	BUSH	2	
24	09306-10022	BUSH	1	
25	09306-12014	BUSH, CLUTCH HOLDER	2	
26	09383-08005	E RING	1	
27	09440-07071	SPRING	1	
28	01550-0616C	BOLT	1	
29	01550-0825C	BOLT, DELIVERY PIPE	1	
30	01550-0830C	BOLT	2	
31	01550-0855C	BOLT	1	
32	01550-0880C	BOLT, CLUTCH HOLDER NO.1	1	
33	08331-41359	CIRCLIP	1	



FIG.210A




FIG.210A (1-C-13) SHIFT ROD (DF115BG)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	25131-92J01	YOKE, SHIFTER	1	
2	25141-92J01	HOUSING, SHIFT ROD GUIDE	1	
3	25222-90J01	COVER, SFT GUIDE HSG OIL SEAL	1	
4	25232-90J00	MAGNET, GEAR CASE	2	
5	25321-92J10	SLIDER, SHIFT HORIZONTAL	1	
6-1	25111-92J00	ROD ASSY, SHIFT (L)	1	W/TRANSOM(L)
6-2	25111-92J10	ROD ASSY, SHIFT (X)	1	W/TRANSOM(X)
7	41226-97E00	BUSH	1	
8	29116-93J00	BOLT (6X20)	2	
9	09205-04014	SPRING PIN (4X14)	2	
10	09280-69001	O RING (D:3.1, ID:68.5)	1	
11	09283-10011	OIL SEAL (10X22X8)	2	

DF115BG E11
DF115BG E40

FIG.210B




FIG.210B (1-C-14) SHIFT ROD (DF115BZG)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	25131-92J01	YOKE, SHIFTER	1	
2	25141-92J01	HOUSING, SHIFT ROD GUIDE	1	
3	25222-90J01	COVER, SFT GUIDE HSG OIL SEAL	1	
4	25232-90J00	MAGNET, GEAR CASE	2	
5	25321-92J20	SLIDER, SHIFT HORIZONTAL	1	
6-1	25111-92J00	ROD ASSY, SHIFT (L)	1	W/TRANSOM(L)
6-2	25111-92J10	ROD ASSY, SHIFT (X)	1	W/TRANSOM(X)
7	41226-97E00	BUSH	1	
8	29116-93J00	BOLT (6X20)	2	
9	09205-04014	SPRING PIN (4X14)	2	
10	09280-69001	O RING (D:3.1, ID:68.5)	1	
11	09283-10011	OIL SEAL (10X22X8)	2	

DF115BZG E11
DF115BZG E40

FIG.220A




FIG.220A (1-C-15) TRANSMISSION (DF115BG)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57110-92J60	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-2	57110-92J70	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	57133-90J02	COLLAR, DRIVE SHAFT	1	
3	09164-31001	WASHER	1	DRIVE SHAFT WAVE
4	09169-31001	WASHER	1	DRIVE SHAFT NO.1
5	09181-31001	WASHER (31X46X2)	3	DRIVE SHAFT NO.2
6	09265-25046	BEARING (25X52X19.25)	1	
7	57300-99L10	PINION/GEAR SET (NT:25)	1	
8	09140-14024	NUT	1	
9	57500-87873	SHIM SET, DRIVE SHAFT	1	
10-1	09181-40186	.SHIM (T:0.50)	1	
10-2	09181-41002	.SHIM (T:0.55)	1	
10-3	09181-41003	.SHIM (T:0.60)	1	
10-4	09181-41004	.SHIM (T:0.65)	1	
10-5	09181-41005	.SHIM (T:0.70)	1	
10-6	09181-41006	.SHIM (T:0.75)	1	
10-7	09181-40190	.SHIM (T:0.80)	1	
10-8	09181-41008	.SHIM (T:0.85)	1	
10-9	09181-41009	.SHIM (T:0.90)	1	
10-10	09181-41010	.SHIM (T:0.95)	1	
10-11	09181-40195	.SHIM (T:1.00)	1	
10-12	09181-41012	.SHIM (T:1.05)	1	
10-13	09181-41013	.SHIM (T:1.10)	1	
10-14	09181-41014	.SHIM (T:1.15)	1	
11	57500-87861	SHIM SET, PROP SHAFT REV	1	
12-1	08211-30382	.WASHER (T:1.5)	1	
12-2	09160-30036	.WASHER (T:1.7)	1	
12-3	09160-30037	.WASHER (T:1.9)	1	
12-4	09160-30038	.WASHER (T:2.1)	1	
12-5	09160-30039	.WASHER (T:2.3)	1	

FIG.220A




FIG.220A (1-D-2) TRANSMISSION (DF115BG)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
12-6	09160-30041	.WASHER (T:2.4)	1	
12-7	09160-30042	.WASHER (T:2.6)	1	
12-8	09160-30043	.WASHER (T:2.7)	1	
12-9	09160-30044	.WASHER (T:2.8)	1	
13	09160-70002	WASHER (70X95X5.25)	1	FWD GEAR
14-1	09181-45003	SHIM (T:1.0)	1	REV GEAR
14-2	09181-45004	SHIM (T:1.1)	1	REV GEAR
14-3	09181-45005	SHIM (T:1.2)	1	REV GEAR
14-4	09181-45006	SHIM (T:1.3)	1	REV GEAR
14-5	09181-45007	SHIM (T:1.4)	1	REV GEAR
14-6	09181-45008	SHIM (T:1.5)	1	REV GEAR
14-7	09181-45009	SHIM (T:1.6)	1	REV GEAR
14-8	09181-45013	SHIM (T:1.35)	1	REV GEAR
14-9	09181-45014	SHIM (T:1.45)	1	REV GEAR
14-10	09181-45015	SHIM (T:1.55)	1	REV GEAR
14-11	09181-45016	SHIM (T:1.65)	1	REV GEAR
14-12	09181-45017	SHIM (T:1.70)	1	REV GEAR
14-13	09181-45018	SHIM (T:1.75)	1	REV GEAR
15	57500-92813	SHIM SET, FWD GEAR	1	FWD GEAR
16-1	09181-70001	.SHIM (T:0.70)	1	FWD GEAR
16-2	09181-70002	.SHIM (T:0.80)	1	FWD GEAR
16-3	09181-70003	.SHIM (T:0.90)	1	FWD GEAR
16-4	09181-70004	.SHIM (T:1.00)	1	FWD GEAR
16-5	09181-70006	.SHIM (T:0.60)	1	FWD GEAR
16-6	09181-70009	.SHIM (T:0.65)	1	FWD GEAR
16-7	09181-70010	.SHIM (T:0.75)	1	FWD GEAR
16-8	09181-70011	.SHIM (T:0.85)	1	FWD GEAR
16-9	09181-70012	.SHIM (T:0.95)	1	FWD GEAR
16-10	09181-70008	.SHIM (T:0.55)	1	FWD GEAR
17	09269-70001	BEARING (70X95X4)	1	
18	57610-99L00	SHAFT ASSY, PROPELLER	1	
19	57621-99L00	SHIFTER, CLUTCH DOG	1	
20	09202-07002	PIN (7X48)	1	

FIG.220A




FIG.220A (1-D-3) TRANSMISSION (DF115BG)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21	57631-92J10	PIN, CONNECTOR	1	
22	09440-09040	SPRING	1	
23	06111-07004	BALL	2	NO.1
24	06111-11004	BALL	2	NO.2
25	09440-49004	SPRING	1	
26	57616-90J00	SPACER, CLUTCH DOG FWD	1	
27-1	56120-92J01-YAY	HOUSING, PROP SFT BRG (BLACK)	1	
27-2	56120-92J01-QTN	HOUSING, PROP SFT BRG (WHITE)	1	
28	56123-92J00	.WASHER, OIL SEAL PROTECTOR	1	
29	09263-30051	.BEARING (30X37X26)	1	
30	09280-97001	.O RING (D:3.5,ID:95)	1	
31	09282-30007	.OIL SEAL (30X50X6)	2	
32	08113-62090	.BEARING	1	
33	09387-52001	.RING SET	1	
34	09116-08122	BOLT (8X30)	2	
35	56130-90J00	HOUSING, DRIVESHAFT BRG	1	
36	09280-46004	.O RING (D:3.5,ID:45.7)	1	
37	09282-24004	.OIL SEAL (24X40X7)	2	
38	09117-08110	BOLT (8X25)	4	
39	56140-92J00	HOUSING, FWD GEAR BRG	1	
40	09206-09012	.PIN (7.4X9X10)	1	
41	09263-50001	.BEARING (50X62X25)	1	

DF115BG E11
DF115BG E40

FIG.220B




FIG.220B (1-D-4) TRANSMISSION (DF115BZG)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	56120-92J12-YAY	HOUSING, PROP SFT BRG (BLACK)	1	
1-2	56120-92J12-QTN	HOUSING, PROP SFT BRG (WHITE)	1	
2	56123-92J00	.WASHER, OIL SEAL PROTECTOR	1	
3	09263-30051	.BEARING (30X37X26)	1	
4	09263-50001	.BEARING (50X62X25)	1	
5	09280-97001	.O RING (D:3.5,ID:95)	1	
6	09282-30007	.OIL SEAL (30X50X6)	2	
7	09387-52001	.RING SET	1	
8	56130-90J00	HOUSING, DRIVE SHAFT BRG	1	
9	09280-46004	.O RING (D:3.5,ID:45.7)	1	
10	09282-24004	.OIL SEAL (24X40X7)	2	
11	56140-92J30	HOUSING, REV GEAR BRG	1	
12	09206-09012	.PIN (7.4X9X10)	1	
13	09263-45004	.BEARING (45X52X16)	1	
14	09116-08122	BOLT (8X30)	2	
15	09117-08110	BOLT (8X25)	4	
16-1	57110-92J60	SHAFT, DRIVE (L)	1	W/TRANSOM(L)
16-2	57110-92J70	SHAFT, DRIVE (X)	1	W/TRANSOM(X)
17	57133-90J02	COLLAR, DRIVE SHAFT	1	
18	09164-31001	WASHER	1	DRIVE SHAFT WAVE
19	09169-31001	WASHER	1	DRIVE SHAFT NO.1
20	09181-31001	WASHER (31X46X2)	3	DRIVE SHAFT NO.2
21	09265-25046	BEARING (25X52X19.25)	1	
22	57300-99L30	PINION/GEAR SET (NT:25)	1	
23	09140-14024	NUT	1	
24	57500-87873	SHIM SET, DRIVE SHAFT	1	
25-1	09181-40186	.SHIM (T:0.50)	1	
25-2	09181-41002	.SHIM (T:0.55)	1	
25-3	09181-41003	.SHIM (T:0.60)	1	
25-4	09181-41004	.SHIM (T:0.65)	1	

FIG.220B




FIG.220B (1-D-5) TRANSMISSION (DF115BZG)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25-5	09181-41005	.SHIM (T:0.70)	1	
25-6	09181-41006	.SHIM (T:0.75)	1	
25-7	09181-40190	.SHIM (T:0.80)	1	
25-8	09181-41008	.SHIM (T:0.85)	1	
25-9	09181-41009	.SHIM (T:0.90)	1	
25-10	09181-41010	.SHIM (T:0.95)	1	
25-11	09181-40195	.SHIM (T:1.00)	1	
25-12	09181-41012	.SHIM (T:1.05)	1	
25-13	09181-41013	.SHIM (T:1.10)	1	
25-14	09181-41014	.SHIM (T:1.15)	1	
26-1	09160-35015	WASHER (T:0.60)	1	PROP SAFT REV
26-2	09160-35014	WASHER (T:0.70)	1	PROP SAFT REV
26-3	09160-35013	WASHER (T:0.80)	1	PROP SAFT REV
26-4	09160-35006	WASHER (T:0.90)	1	PROP SAFT REV
26-5	09160-35008	WASHER (T:0.95)	1	PROP SAFT REV
26-6	09160-35002	WASHER (T:1.00)	1	PROP SAFT REV
26-7	09160-35009	WASHER (T:1.05)	1	PROP SAFT REV
26-8	09160-35003	WASHER (T:1.10)	1	PROP SAFT REV
26-9	09160-35010	WASHER (T:1.15)	1	PROP SAFT REV
27	09160-60011	WASHER (60X85X3)	1	REV GEAR
28-1	09160-60008	WASHER (T:0.8)	1	REV GEAR
28-2	09160-60009	WASHER (T:0.9)	1	REV GEAR
28-3	09160-60003	WASHER (T:1.0)	1	REV GEAR
28-4	09160-60004	WASHER (T:1.1)	1	REV GEAR
28-5	09160-60005	WASHER (T:1.2)	1	REV GEAR
28-6	09160-60006	WASHER (T:1.3)	1	REV GEAR
28-7	09160-60007	WASHER (T:1.4)	1	REV GEAR
28-8	09160-60013	WASHER (T:0.55)	1	REV GEAR
28-9	09160-60014	WASHER (T:0.60)	1	REV GEAR
28-10	09160-60015	WASHER (T:0.65)	1	REV GEAR
28-11	09160-60016	WASHER (T:0.70)	1	REV GEAR
28-12	09160-60017	WASHER (T:0.75)	1	REV GEAR
28-13	09160-60018	WASHER (T:0.85)	1	REV GEAR
28-14	09160-60019	WASHER (T:0.95)	1	REV GEAR
28-15	09160-60020	WASHER (T:1.05)	1	REV GEAR

FIG.220B




FIG.220B (1-D-6) TRANSMISSION (DF115BZG)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	09160-70005	WASHER (70X95X2)	1	FWD GEAR
30	57500-92813	SHIM SET, FWD GEAR	1	FWD GEAR
31-1	09181-70006	.SHIM (T:0.60)	1	FWD GEAR
31-2	09181-70009	.SHIM (T:0.65)	1	FWD GEAR
31-3	09181-70001	.SHIM (T:0.70)	1	FWD GEAR
31-4	09181-70010	.SHIM (T:0.75)	1	FWD GEAR
31-5	09181-70002	.SHIM (T:0.80)	1	FWD GEAR
31-6	09181-70011	.SHIM (T:0.85)	1	FWD GEAR
31-7	09181-70003	.SHIM (T:0.90)	1	FWD GEAR
31-8	09181-70012	.SHIM (T:0.95)	1	FWD GEAR
31-9	09181-70004	.SHIM (T:1.00)	1	FWD GEAR
31-10	09181-70008	.SHIM (T:0.55)	1	FWD GEAR
32	09269-60001	BEARING (60X85X3)	1	REV
33	09269-70001	BEARING (70X95X4)	1	FWD
34	57610-99L10	SHAFT, PROPELLER	1	
35	57621-99L00	SHIFTER, CLUTCH DOG	1	
36	57631-92J10	PIN, CONNECTOR	1	
37	09440-09040	SPRING	1	
38	06111-07004	BALL	2	NO.1
39	06111-11004	BALL	2	NO.2
40	09202-07002	PIN (7X48)	1	
41	09440-49004	SPRING	1	
42	57616-92J00	SPACER, CLUTCH DOG FWD	1	
43	09160-30055	WASHER (30X47X6)	1	PROP SAFT REV
44	09160-30056	WASHER (32X47X3)	1	PROP SAFT REV
45	09269-30014	BEARING (30X47X2)	1	PROP SAFT REV

DF115BGZ E40
DF115BZG E40

FIG.301A




FIG.301A (1-D-7) STARTING MOTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-92J00	STARTING MOTOR	1	
2	31150-92J00	.HOUSING, FRONT	1	
3	31170-92J00	.HOUSING, REAR	1	
4	31173-92J00	.HOLDER ASSY, BRUSH	1	
5	31191-92J00	.LEVER, SHIFT	1	
6	31192-92J00	.SCREW SET	1	
7	31220-92J00	.SWITCH ASSY	1	
8	31261-75F10	.BOLT	2	
9	31311-63J00	.ARMATURE	1	
10	31340-92J00	.CLUTCH SET, STARTING MOTOR	1	
11	31312-92J00	..SET, PINION STOPPER	1	
12	31320-92J00	..PINION	1	
13	31341-92J00	..SHAFT, PINION	1	
14	31343-63J00	..INTERNAL GEAR	1	
15	31344-63J00	..PLANETARY GEAR	3	
16	31912-90J00	BAND, STARTING MOTOR	1	
17	31918-92J01	DAMPER, LOWER	1	
18	01550-08207	BOLT	2	
19	01550-1050C	BOLT	2	
20	04211-13149	PIN	2	

FIG.303A




FIG.303A (1-D-8) MAGNETO

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32102-99L00	FLYWHEEL	1	
2	32120-99L00	COIL, BATTERY CHARGING	1	
3	32160-99L00	COIL, IGNITION TIMING	1	
4	33220-64L10	SENSOR, CAM POSITION	1	
5	36617-93J00	BRACKET, HARNESS	1	
6	09103-06231	BOLT (6X35)	4	
7	09103-16004	BOLT (16X50)	1	
8	09160-16048	WASHER (16.5X60X7)	1	
9	01550-0616C	BOLT	1	
10	09106-05030	BOLT (5X10)	2	
11	08341-31059	KEY	1	
12	36617-93J10	BRACKET, HARNESS	1	
13	09403-11321	CLAMP	1	
14	09403-13311	CLAMP	1	
15	09403-13413	CLAMP	1	
16	09403-16313	CLAMP, STATOR LEAD	1	
17	01550-0612C	BOLT	3	

FIG.310A




FIG.310A (1-D-9) RECTIFIER/IGNITION COIL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33410-99L00	COIL ASSY, IGNITION	4	
2	01550-0620C	BOLT	4	
3	11261-87E10	COVER, PROTECTION ANODE	2	
4	11265-87E10	GASKET, PROTECTION COVER	2	
5-1	55321-87J01	ANODE, PROTECTION	2	
5-2	55321-87J11	ANODE (MAGNESIUM)	1	OPT
6	09103-06281	BOLT (6X14)	2	
7	14151-90J00	GASKET, RECTIFIER	1	
8	36616-99L20	HOLDER, CONNECTOR	1	
9	36617-88L00	BRACKET, PTT CABLE CLAMP	1	
10	32800-99L00	RECTIFIER & REGULATOR ASSY	1	
11	32890-99L00	HOLDER, ELECTRIC PARTS	1	
12	09160-06084	WASHER (6.5X18X1.6)	1	
13	09320-10075	CUSHION	2	
14	09320-09016	CUSHION	1	
15	09169-06062	WASHER	1	
16	09329-01007	CUSHION	1	
17	29404-93J11	CLAMP	2	
18	01550-06257	BOLT	1	
19	01550-0620C	BOLT	4	
20	01550-0630C	BOLT	9	
21	01550-0612C	BOLT	3	
22	09116-06517	BOLT (6X25)	2	
23	09169-06062	WASHER	2	
24	09320-09016	CUSHION	2	

FIG.315A




FIG.315A (1-D-10) SENSOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13650-52G00	SENSOR, INLET AIR TEMP	1	
2	13655-87J01	GROMMET, AIR TEMP SENSOR	1	
3	18590-59S00	SENSOR, PRESSURE	1	
4	34830-87J20	SENSOR ASSY, EXHAUST TEMP	2	
5	18640-98L01	SENSOR ASSY, KNOCK	1	
6	34840-98J03	SENDER ASSY, TRIM	1	
7	18213-98J30	SENSOR, OXYGEN	1	
8	34841-92J00	LEVER, TRIM SENSOR	1	
9	34842-92J01	CAM, TRIM SENSOR UPPER	1	
10	34843-87L00	CAM, TRIM SENSOR LOWER	1	
11	34846-87L00	WASHER, TRIM SENSOR	1	
12	37820-99E02	SWITCH, OIL PRESSURE	1	
13	34845-92J00	BRACKET, TRIM SENSOR	1	
14	02162-05207	SCREW	1	
15	09103-06093	BOLT (6X20)	1	
16	09125-05046	SCREW (5X12)	1	
17	09407-10404	CLAMP (L:100)	1	
18	36617-93J10	BRACKET, HARNESS	1	KNOCK SENSOR LEAD
19	09407-14407	CLAMP (L:145)	2	
20	09407-18402	CLAMP (L:165)	1	OXYGEN SENSOR LEAD
21	29103-93J00	BOLT (6X12)	1	
22	09403-13413	CLAMP	1	PTT CABLE
23	09403-07340	CLAMP	1	KNOCK SENSOR LEAD
24	09403-11321	CLAMP	1	PTT CABLE

DF115BG_E11_021_322A
HARNESS



DF115BG_E11_021

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	33810-90J30	CABLE ASSY, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3	36616-99L00	HOLDER, CABLE	1	
4	36616-99L10	HOLDER, CONNECTOR	1	
5	01550-0616C	BOLT	3	
6	02142-0616C	SCREW (6X16)	2	
7	36610-99L10	HARNESS ASSY, WIRING	1	
8	33634-96J00	.CAP, SERVICE CONNECTOR	1	
9	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
10	09320-08510	.CUSHION (8.5X20X8)	2	
11	01500-06167	.BOLT	1	
12	08310-00067	.NUT	1	UPPER
13	38860-76F01	.RELAY ASSY	1	FOR MAIN
14	38860-76F01	.RELAY ASSY	1	FOR STARTER
15	09481-10504	.FUSE (10A)	2	
16	09481-15504	.FUSE (15A)	4	
17	09481-30504	.FUSE (30A)	3	
18	09481-60403	.FUSE (60A)	3	
19	36617-88L00	BRACKET, PTT CABLE CLAMP	1	
20	36617-93J10	BRACKET, HARNESS	8	
21	36612-96J01	CAP, TERMINAL	1	
22	08321-01067	LOCK WASHER	1	
23	08310-00067	NUT	1	
24	36617-93J00	BRACKET, HARNESS	1	
25	36611-99L00	HARNESS ASSY, WIRING SUB	1	
26	01550-0612C	BOLT	10	
27	09403-11321	CLAMP	2	
28	09407-14403	CLAMP (L:125)	3	
29	09403-13311	CLAMP	1	
30	09408-00213	CLAMP	1	
31	09169-06053	WASHER (6.3X16X1)	2	

FIG.326A




FIG.326A (1-D-12) PTT SWITCH/ENGINE CONTROL UNIT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13580-98J03	SENSOR ASSY, SHIFT POSITION	1	
2	13575-40F00	.O RING	1	
3	36617-87L20	CLAMP, HARNESS	1	
4	37721-93J00	SWITCH ASSY, NEUTRAL	1	
5	37724-99L00	ARM, NEUTRAL SWITCH	1	
6	37726-99L00	BRACKET, NEUTRAL SWITCH	1	
7	37850-92J00	SWITCH ASSY, PTT	1	
8	37856-92J00	.TAPE, PTT SWITCH	1	
9	37857-92J01	BUSH, PTT SWITCH	1	
10	09160-05029	WASHER (5.5X12X0.8)	1	
11	09403-11321	CLAMP	1	
12	09407-10404	CLAMP (L:100)	1	
13	09407-14407	CLAMP (L:145)	1	
14	09448-10006	SPRING, NEUTRAL SWITCH	1	
15	01550-0612C	BOLT	1	
16	02122-04167	SCREW, NEUTRAL SWITCH	2	
17	07130-05167	BOLT	1	
18	08321-0105C	WASHER, SHIFT POSITION SENSOR	1	
19	38410-93J21	RELAY ASSY, PTT	1	
20	38415-93J20	HOLDER, PTT RELAY	1	
21	33920-99L10	UNIT,ENGINE CONTROL	1	
22	33925-99L00	CUSHION, ENGINE CONTROL UNIT	1	
23	38890-99L00	ACTUATOR ASSY, SHIFT	1	
24	38892-98J01	DAMPER, SHIFT ACTUATOR	1	
25	38895-99L00	BRACKET, SHIFT ACTUATOR	1	
26	01550-0616C	BOLT	2	
27	01550-0620C	BOLT	1	
28	01550-06357	BOLT	1	
29	01550-0655C	BOLT, THROTTLE BODY NO.3	1	
30	38860-76F01	RELAY ASSY	2	
31	38915-90J00	HOLDER, RELAY	2	

FIG.331A




FIG.331A (1-D-13) KEY LESS START (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32851-93J00	CUSHION, KLS CONTROLLER	1	
2	32980-38F00	HOLDER, KLS CONTROLLER	1	
3	36623-96L02	HARNESS ASSY, KLS CONT	1	
4	36615-96300	.TERMINAL	1	
5	36662-96L01	HARNESSASSY, KLS CAN	1	L:6500+2000
6	37117-96L00	DECAL, KLS	2	
7-1	37171-96L02	CONTROLLER ASSY, KLS 433MHZ	1	
7-2	37171-96L12	CONTROLLER ASSY, KLS 315MHZ	1	
8-1	37172-96L01	REMOCON ASSY, KLS 433MHZ	2	
8-2	37172-96L10	REMOCON ASSY, KLS 315MHZ	2	
9	37173-96L10	HOLDER, KLS PARTS	1	
10	38500-93J90	BUZZER ASSY	1	
11	38860-96L01	RELAY ASSY, KLS	1	
12	09407-14407	CLAMP (L:145)	1	

NOTE: USE FREQUENCY ASSIGNED ON YOUR MARKET.
FOR DETAILS, PLEASE MAKE SURE OF SUZUKI DEALERS.

DF115BG E11
DF115BZG E11

FIG.335A




FIG.335A (1-D-14) CLAMP BRACKET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-90J13-YAY	BRACKET, CLAMP STBD (BLACK)	1	
1-2	41111-90J13-QTN	BRACKET, CLAMP STBD (WHITE)	1	
2-1	41121-90J21-YAY	BRACKET, CLAMP PORT (BLACK)	1	
2-2	41121-90J21-QTN	BRACKET, CLAMP PORT (WHITE)	1	
3	41130-92J30	SHAFT, CLAMP BRACKET	1	
4	55320-94900	ANODE SET, CLAMP BRACKET	1	
5	09116-06121	.BOLT (6X25)	2	
6-1	09100-12091	BOLT (12X115)	4	
6-2	09100-12090	BOLT (12X150)	1	OPT
7	09159-12014	NUT	4	
8	09159-22006	NUT	1	
9	09160-12128	WASHER (12.5X35X3)	4	
10	09160-12110	WASHER (12.5X22X3)	4	
11	41135-92J00	WASHER, CLAMP BRACKET SHAFT	1	
12	09106-10065	BOLT (10X20)	2	
13	09160-10082	WASHER (10.5X19X2.0)	2	
14	09116-08137	BOLT (8X22)	1	
15	45421-90J00	PIN, TILT LOCK	1	OPT
16	09159-14020	NUT	2	OPT
17	55321-94910	ANODE (MAGNESIUM)	1	OPT

FIG.336A





FIG.336A (1-D-15) SWIVEL BRACKET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE, GREASE	5	W/TRANSOM(L)
1-2	22511-99011	NIPPLE, GREASE	4	W/TRANSOM(X)
2	36894-95201	LEAD (CLAMP TO SWIVEL)	1	
3	36894-87D00	LEAD (SWIVEL TO MOUNT BRKT)	1	
4-1	43111-90J40-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L)
4-2	43111-90J40-QTN	BRACKET, SWIVEL (L) (WHITE)	1	W/TRANSOM(L)
4-3	43111-90J50-YAY	BRACKET, SWIVEL (UL) (BLACK)	1	W/TRANSOM(X)
4-4	43111-90J50-QTN	BRACKET, SWIVEL (UL) (WHITE)	1	W/TRANSOM(X)
5	43211-93J11	BUSH, CLAMP SHAFT SWIVEL	2	
6	43711-97E11	BUSH, STEERING	2	
7-1	43750-90J61-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L)
7-2	43750-90J61-QTN	BRACKET, STEERING (L) (WHITE)	1	W/TRANSOM(L)
7-3	43750-90J71-YAY	BRACKET, STEERING (X) (BLACK)	1	W/TRANSOM(X)
7-4	43750-90J71-QTN	BRACKET, STEERING (X) (WHITE)	1	W/TRANSOM(X)
8	09125-05050	SCREW (5X8)	3	
9	36895-87D10	LEAD (SWIVEL TO HOUSING)	1	
10	09160-39001	WASHER (39.5X64X1)	2	
11	09169-28003	WASHER	2	
12	09181-39001	SHIM (39.5X64X0.3)	4	
13	09250-10001	CAP (OD:14)	2	
14	09282-39001	OIL SEAL (39X51X5)	1	
15	09380-38003	CIRCLIP	1	
16	09440-19028	SPRING	1	
17	41220-95E13	LEVER, TILT LOCK	1	
18	41221-95E40	LEVER, TILT LOCK PORT	1	
19	41224-95E01	BUSH, TILT STOPPER ROD	2	
20	41225-94401	RUBBER, TILT LOCK LEVER	1	
21	41228-90J00	SPRING, TILT LOCK LEVER	1	
22	41230-95E00	LINK, TILT LOCK LEVER	1	
23	41233-95E10	BRACKET, TILT LOCK SPRING	1	
24	09125-06063	SCREW (6X10)	1	
25	09140-10032	NUT	1	
26	09160-06082	WASHER (6.5X13X1.0)	1	
27	09204-01006	PIN	1	
28	09125-06063	SCREW (6X10)	1	
29	09125-06063	SCREW (6X10)	1	

FIG.337A



DF115BG_E11_021_337A
TRIM CYLINDER

FIG.337A (1-E-2) TRIM CYLINDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-90J39	TRIM ASSY, POWER WITH TILT	1	
2	38100-92J13	.MOTOR ASSY, PTT	1	
3	48400-90J03	.MANIFOLD ASSY	1	
4	48611-90J00	.JOINT, METAL	1	
5	48571-87L01	.TANK, RESERVOIR	1	
6	48572-87J10	.PLUG	1	
7	48557-90J00	.O RING	1	
8	48862-87J20	.BOLT, RESERVOIR	4	
9	48502-90J13	.PUMP ASSY, PTT	1	
10	48583-95E00	..JOINT, DRIVE	1	
11	48582-95E01	..FILTER	1	
12	48585-95E00	..O RING	1	
13	48864-93J01	.MANUAL VALVE	1	
14	48588-90J00	.O RING SET	1	
15	48862-92J20	.BOLT, PUMP NO.1	1	
16	48862-92J30	.BOLT, PUMP NO.2	1	
17	48862-90J21	.BOLT	1	
18	31281-92J10	.BOLT, THROUGH	4	
19	48121-90J00	SHAFT, TILT CYL LOWER	1	
20	48321-90J00	SHAFT, TILT CYL UPPER	1	
21	48326-95E00	BUSH, TILT CYL LOWER	4	
22	09116-10179	BOLT (10X35)	2	
23	09380-22015	CIRCLIP	2	
24	55321-87J01	ANODE, PROTECTION	1	
25	09103-06281	BOLT (6X14)	1	
26	36895-87D10	LEAD (L:310)	1	
27	09125-05050	SCREW (5X8)	1	

DF115BG_E11_021

FIG.340A





FIG.340A (1-E-3) PTT MOTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-92J13	MOTOR ASSY, PTT	1	
2	31311-94900	.ARMATURE	1	
3	31173-94920	.HOLDER ASSY, BRUSH	1	
4	31123-94910	..O RING	1	
5	31133-90J10	...BRUSH ASSY	1	
6	31133-94910	...BRUSH	1	
7	31136-90J20	..BREAKER ASSY	1	
8	31135-94900	..SPRING	2	
9	33799-97E00	..OIL SEAL	1	
10	31111-94900	..SCREW	2	

FIG.401A



DF115BG_E11_021_401A
ENGINE HOLDER

FIG.401A (1-E-4) ENGINE HOLDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	51110-99810-YAY	HOLDER SET, ENGINE (BLACK)	1	FOR YAY
1-2	51110-99810-Y5S	HOLDER SET, ENGINE (WHITE)	1	FOR QTN
2	09262-17019	.BEARING (17X35X8)	1	
3	09282-24003	.OIL SEAL (24X36X6)	2	
4	09283-32044	.OIL SEAL (32X47X6)	1	
5	09289-18001	.OIL SEAL (18X30X8)	1	
6	08331-41359	.CIRCLIP	1	
7	09262-35069	.BEARING (35X62X16)	1	
8	51115-90J00	UNION, WATER RETURN	1	
9	51211-90J30	GASKET, ENGINE HOLDER	1	
10	09116-08160	BOLT (8X70)	4	
11	09116-08178	BOLT (8X40)	4	
12	09206-08001	PIN (8X11)	2	
13	09280-26006	O RING (D:3.1,ID:26.4)	1	
14	01550-0625C	BOLT	1	
15	29117-93J10	BOLT (8X45)	1	
16	09160-08059	WASHER (8.5X18X1.6)	1	
17	04211-11129	PIN	3	
18	51122-90J00	COVER, MOUNT CASE	1	
19	51123-90J01	GASKET, MOUNT CASE COVER	1	
20	01550-0825A	BOLT	4	
21	54123-90J01	PLATE, UPPER MOUNT	1	
22	54112-90J21	BOLT, UPPER MOUNT	2	
23	54130-90J40	MOUNT, UPPER	2	
24	09159-12014	NUT	2	
25	54114-90J10	WASHER, UPPER MOUNT	2	
26	54125-90J11	MOUNT, UPPER THRUST	1	
27	54148-90J11	COVER, UPPER MOUNT	2	
28	09116-10181	BOLT (10X44)	4	
29	09159-12014	NUT	2	
30	09160-12110	WASHER (12.5X22X3)	2	

DF115BG_E11_021

FIG.405A





FIG.405A (1-E-5) DRIVE SHAFT HOUSING

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-90J02-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	W/TRANSOM(L)
1-2	52111-90J02-QTN	HOUSING, DRIVE SHAFT (WHITE)	1	W/TRANSOM(L)
1-3	52111-90J12-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	W/TRANSOM(X)
1-4	52111-90J12-QTN	HOUSING, DRIVE SHAFT (WHITE)	1	W/TRANSOM(X)
2	09116-10181	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4	09387-45001	RING	1	W/TRANSOM(X)
5	57130-92J01	BUSH, DRIVE SHAFT	1	W/TRANSOM(X)
6-1	54221-90J02-YAY	COVER, LOWER MOUNT (BLACK)	2	
6-2	54221-90J02-QTN	COVER, LOWER MOUNT (WHITE)	2	
7	09116-10181	BOLT (10X44)	6	
8	54121-87D01	DAMPER, REVERSE STOPPER LOWER	2	
9	54160-90J20	MOUNT, LOWER	2	
10	54166-90J11	BOLT (12X231)	2	
11	09159-12014	NUT	2	
12	09160-12132	WASHER (12.1X40X3)	2	
13	54114-90J10	WASHER, LOWER MOUNT	2	
14	54151-90J00	MOUNT, LOWER THRUST	1	
15-1	54211-90J01-YAY	BRACKET, LOWER MOUNT (BLACK)	1	
15-2	54211-90J01-QTN	BRACKET, LOWER MOUNT (WHITE)	1	
16	09160-12133	WASHER (12.5X30X2.5)	2	

FIG.407A



DF115BG_E11_021_407A
GEAR CASE

FIG.407A (1-E-6) GEAR CASE (DF115BG E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-90J16-YAY	CASE, GEAR (BLACK)	1	
1-2	55110-90J16-QTN	CASE, GEAR (WHITE)	1	
2	09263-28016	.BEARING (28.6X38X31.8)	1	
3	55125-90J01	TAB, TRIM	1	
4	55127-87D00	UNION	1	
5	55321-90J01	ANODE, GEAR CASE	1	
6	55332-87D12	RUBBER, EXHAUST SEAL	1	
7	55333-87D10	PLATE, EXHAUST SEAL	1	
8	09100-06131	BOLT (6X12)	1	
9	09116-08137	BOLT (8X22)	1	
10	09116-10150	BOLT (10X55)	6	
11	09117-10039	BOLT (10X80)	1	
12	09160-06085	WASHER (6.5X15X1)	1	
13	09168-10022	GASKET (10X17X1.5)	2	
14	09202-08006	PIN (8X12)	2	
15	09248-10008	PLUG (10X7.5)	2	
16-1	09355-40805-600	HOSE (4X8X600)	1	W/TRANSOM(L) L:600->50
16-2	09355-40805-600	HOSE (4X8X600)	1	W/TRANSOM(X) L:600->100
17	09362-09008	UNION	1	
18	09407-10404	CLAMP (L:100)	2	
19-1	58100-90JA0-019	PROPELLER (3X14X17)	1	
19-2	58100-90JB0-019	PROPELLER (3X14X19)	1	
19-3	58100-90JC0-019	PROPELLER (3X14X21)	1	
19-4	58100-90JD0-019	PROPELLER (3X14X23)	1	
19-5	58100-90JE0-019	PROPELLER (3X13-1/2X15)	1	
20	58105-90J00	.BUSH	1	

FIG.407A





FIG.407A (1-E-7) GEAR CASE (DF115BG E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY		REMARKS
21-1	58200-92J40	PROPELLER (3X13-7/8X15)	1	OPT	
21-2	58200-92J50	PROPELLER (3X13-7/8X17)	1	OPT	
21-3	58200-92J60	PROPELLER (3X13-7/8X19)	1	OPT	
21-4	58200-92J70	PROPELLER (3X13-7/8X21)	1	OPT	
21-5	58200-92J80	PROPELLER (3X13-7/8X23)	1	OPT	
21-6	58200-92J90	PROPELLER (3X13-7/8X25)	1	OPT	
22	58105-90J00	.BUSH, PROPELLER	1	OPT	
23	57633-90J02	SPACER, PROPELLER NUT	1		
24	57635-92J01	STOPPER, PROPELLER BUSH	1		
25	09141-18005	NUT	1		
26	09160-18028	WASHER (18.5X31X1)	1		
27	09204-03003	PIN	1		
28	55116-87E00	PLUG	1	OPT	
29	57630-90J00	KIT, PROPELLER NUT	1	OPT	
30	25700-92J00	SEALING KIT, GEAR CASE	1	OPT	
					NOT ILLUSTRATED

DF115BG E11

FIG.407B



DF115BG_E11_021_407B
GEAR CASE

FIG.407B (1-E-8) GEAR CASE (DF115BZG E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-92J01-YAY	CASE, GEAR (BLACK)	1	
1-2	55110-92J01-QTN	CASE, GEAR (WHITE)	1	
2	09263-28016	.BEARING (28.6X38X31.8)	1	
3-1	55125-92J00-YAY	TAB, TRIM (BLACK)	1	
3-2	55125-92J00-QTN	TAB, TRIM (WHITE)	1	
4	55127-87D00	UNION	1	
5	55321-90J01	ANODE, GEAR CASE	1	
6	55332-87D12	RUBBER, EXHAUST SEAL	1	
7	55333-87D10	PLATE, EXHAUST SEAL	1	
8	09100-06131	BOLT (6X12)	1	
9	09116-08137	BOLT (8X22)	1	
10	09116-10150	BOLT (10X55)	6	
11	09117-10039	BOLT (10X80)	1	
12	09160-06085	WASHER (6.5X15X1)	1	
13	09168-10022	GASKET (10X17X1.5)	2	
14	09202-08006	PIN (8X12)	2	
15	09248-10008	PLUG (10X7.5)	2	
16-1	09355-40805-600	HOSE (4X8X600)	1	W/TRANSOM(L) L:600->50
16-2	09355-40805-600	HOSE (4X8X600)	1	W/TRANSOM(X) L:600->100
17	09362-09008	UNION	1	
18	09407-10404	CLAMP (L:100)	2	
19-1	58200-92JA0	PROPELLER (3X13-7/8X17)	1	OPT
19-2	58200-92JB0	PROPELLER (3X13-7/8X19)	1	OPT
19-3	58200-92JC0	PROPELLER (3X13-7/8X21)	1	OPT
19-4	58200-92JD0	PROPELLER (3X13-7/8X23)	1	OPT
20	58105-90J00	.BUSH	1	OPT

DF115BG_E11_021

FIG.407B





FIG.407B (1-E-9) GEAR CASE (DF115BZG E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21	57633-90J02	SPACER, PROPELLER	1	
22	57635-92J01	STOPPER, PROPELLER BUSH	1	
23	09141-18005	NUT	1	
24	09160-18028	WASHER (18.5X31X1)	1	
25	09204-03003	PIN	1	
26	55116-87E00	PLUG	1	OPT
27	57630-90J00	KIT, PROPELLER NUT	1	OPT
28	25700-92J00	SEALING KIT, GEAR CASE	1	OPT
				NOT ILLUSTRATED

DF115BZG E11

FIG.407C



DF115BG_E11_021_407C
GEAR CASE

FIG.407C (1-E-10) GEAR CASE (DF115BG E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-90J16-YAY	CASE, GEAR (BLACK)	1	
1-2	55110-90J16-QTN	CASE, GEAR (WHITE)	1	
2	09263-28016	.BEARING (28.6X38X31.8)	1	
3	55125-90J01	TAB, TRIM	1	
4	55127-87D00	UNION	1	
5	55321-90J01	ANODE, GEAR CASE	1	
6	55332-87D12	RUBBER, EXHAUST SEAL	1	
7	55333-87D10	PLATE, EXHAUST SEAL	1	
8	09100-06131	BOLT (6X12)	1	
9	09116-08137	BOLT (8X22)	1	
10	09116-10150	BOLT (10X55)	6	
11	09117-10039	BOLT (10X80)	1	
12	09160-06085	WASHER (6.5X15X1)	1	
13	09168-10022	GASKET (10X17X1.5)	2	
14	09202-08006	PIN (8X12)	2	
15	09248-10008	PLUG (10X7.5)	2	
16-1	09355-40805-600	HOSE (4X8X600)	1	W/TRANSOM(L) L:600->50
16-2	09355-40805-600	HOSE (4X8X600)	1	W/TRANSOM(X) L:600->100
17	09362-09008	UNION	1	
18	09407-10404	CLAMP (L:100)	2	
19-1	58100-90JA0-019	PROPELLER (3X14X17)	1	
19-2	58100-90JB0-019	PROPELLER (3X14X19)	1	
19-3	58100-90JC0-019	PROPELLER (3X14X21)	1	
19-4	58100-90JD0-019	PROPELLER (3X14X23)	1	
19-5	58100-90JE0-019	PROPELLER (3X13-1/2X15)	1	
20	58105-90J00	.BUSH	1	

DF115BG_E11_021

FIG.407C




FIG.407C (1-E-11) GEAR CASE (DF115BG E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21	57633-90J02	SPACER, PROPELLER NUT	1	
22	57635-92J01	STOPPER, PROPELLER BUSH	1	
23	09141-18005	NUT	1	
24	09160-18028	WASHER (18.5X31X1)	1	
25	09204-03003	PIN	1	
26	25700-92J00	SEALING KIT, GEAR CASE	1	OPT NOT ILLUSTRATED

DF115BG E40

FIG.407D (1-E-12) GEAR CASE (DF115BZG E40)


DF115BZG E40

FIG.410A




FIG.410A (1-E-13) SIDE COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61811-99L00-YAY	COVER, SIDE STBD (BLACK)	1	STBD
1-2	61811-99L00-QTN	COVER, SIDE STBD (WHITE)	1	STBD
2-1	61820-99L00-YAY	COVER, SIDE PORT (BLACK)	1	PORT
2-2	61820-99L00-QTN	COVER, SIDE PORT (WHITE)	1	PORT
3	61827-99L00	STAND, SIDE COVER	1	
4	09136-06149	SCREW (6X55)	4	
5	61814-99L00	SILENCER, SIDE COVER STBD	1	
6	61824-99L00	SILENCER, SIDE COVER PORT	1	
7	61134-99L00	SEAL, SIDE COVER	1	
8	09409-05302-5PK	CLIP (BLACK)	2	
9	09136-06148	SCREW (6X35)	7	
10	17913-93J00	PLUG, WATER	1	
11	17914-93J01	GASKET, WATER PLUG	1	
12-1	61830-99L00-YAY	PANEL, FRONT (BLACK)	1	
12-2	61830-99L00-QTN	PANEL, FRONT (WHITE)	1	
13	09116-08174	BOLT (8X38)	2	
14	09169-08050	WASHER (ID:8.5)	2	
15	09320-11023	CUSHION	2	
16	61632-93J00	SHAFT, ENGINE COVER HOOK	2	
17	61633-96J02	LEVER, HOOK REAR STBD	1	STBD
18	61634-96J02	LEVER, HOOK REAR PORT	1	PORT
19	61641-93J10	HOOK, ENGINE COVER	3	
20-1	61645-90J01-YAY	LEVER, HOOK FR (BLACK)	1	
20-2	61645-90J01-QTN	LEVER, HOOK FR (WHITE)	1	
21	61673-96J02	LATCH, HOOK LEVER	2	
22	09116-06127	BOLT (6X12)	3	
23	09160-13014	WASHER (13.2X25X1)	3	
24	09164-14008	WASHER	3	
25	09202-04022	PIN	2	
26	09306-13007	BUSH	2	
27	09103-05026	BOLT (5X10)	4	
28	61124-99L00	GROMMET, R/CON CABLE	1	
29	09407-20405	CLAMP (L:202)	1	
30	17917-87L00	CONNECTOR, FLUSH WATER	1	

FIG.410A




FIG.410A (1-E-14) SIDE COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	09329-14004	CUSHION, SIDE COVER HOLDER	1	
32	09329-14003	CUSHION (14X20X9)	2	
33	61648-99L00	SPRING, HOOK LEVER	1	
34	09306-13011	BUSH	1	
35	61458-90J01	LABEL, ENGINE COVER	1	
36	67361-90J10	ADAPTER, HOSE	1	OPT
37	09208-06011	PIN	2	OPT

FIG.420A




FIG.420A (1-E-15) ENGINE COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61401-99810-YAY	COVER SET, ENGINE (BLACK)	1	FOR YAY
1-2	61401-99820-QTN	COVER SET, ENGINE (WHITE)	1	FOR QTN
2	41225-94401	.CUSHION, COVER STAND	1	
3	61112-99L00	.SEAL, ENGINE COVER	1	
4	61610-93J00	.FASTENER	3	
5	61621-93J01	.BRACKET, FASTENER	3	
6	61682-99L00	.STAND, ENGINE COVER	1	
7	09329-10024	.CUSHION, ENGINE COVER FASTENER	3	
8	01547-0616C	.BOLT	4	
9	01547-0620C	.BOLT	2	
10	01550-0612C	.BOLT	3	
11-1	61443-99L00	.STRIPE, ENGINE COVER STBD	1	FOR YAY
11-2	61443-99L10	.STRIPE, ENGINE COVER STBD	1	FOR QTN
12-1	61453-99L00	.STRIPE, ENGINE COVER PORT	1	FOR YAY
12-2	61453-99L10	.STRIPE, ENGINE COVER PORT	1	FOR QTN
13	61441-92J10	.MARK, SUZUKI	2	
14	68111-93J00	.EMBLEM,S	1	
15-1	61435-99L20	MARK, EMBLEM REAR (115)	1	FOR YAY
15-2	61435-99L30	MARK, EMBLEM REAR (115)	1	FOR QTN
16	09800-81841	TOOL SET	1	
17-1	99011-99L00-054	MANUAL, OWNER'S	1	E11
17-2	99011-99L00-03B	MANUAL, OWNER'S	1	E11
17-3	99011-99L00-059	MANUAL, OWNER'S	1	E11,E40

FIG.430A




FIG.430A (1-F-2) FUEL HOSE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65700-90J24	HOSE, FUEL (TANK TO ENGINE)	1	
2	65750-95501	.SOCKET, FUEL HOSE	1	
3	65770-90J13	.PUMP, SQUEEZE	1	
4	09401-11423	CLIP	1	

FIG.432A




FIG.432A (1-F-3) FUEL TANK (E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65000-94L10	TANK ASSY, FUEL (25L)	1	
2	65520-99100	.CAP ASSY, FUEL TANK	1	
3	65561-95D00	.GASKET, TANK CAP	1	
4	65740-95D01	.PLUG, FUEL CONNECTOR	1	
5	65700-90J24	HOSE, FUEL (TANK TO ENGINE)	1	
6	65750-95501	.SOCKET, FUEL HOSE	1	
7	65770-90J13	.PUMP, SQUEEZE	1	
8	09401-11423	CLIP	1	

DF115BG E40
DF115BZG E40

FIG.442A




FIG.442A (1-F-4) DRAG LINK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-90J01	LINK, DRAG	1	
3	67721-99E00	.SPACER	1	
4	67725-99E00	.BOLT, DRAG LINK	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	
7	67600-99L00	KIT, TIE ROD	1	OPT,NOT ILLUSTRATED
8	67631-99L00	.BRACKET, TIE ROD	2	OPT,NOT ILLUSTRATED
9	67725-99E10	.BOLT	2	OPT,NOT ILLUSTRATED
10	67726-99E00	.NUT	2	OPT,NOT ILLUSTRATED
11	09100-12081	.BOLT (12X25)	4	OPT,NOT ILLUSTRATED
12	09160-12066	.WASHER (12.5X22X2.5)	4	OPT,NOT ILLUSTRATED
13	09180-09022	.SPACER (9.6X18X12)	2	OPT,NOT ILLUSTRATED

FIG.475A

FIG.475A (1-F-5) SQUEEZE PUMP (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65770-90J04	PUMP, SQUEEZE	1	

DF115BG E11
DF115BZG E11




FIG.507A




FIG.507A (1-F-6) OPT:WATER PRESSURE GAUGE SUB KIT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34660-90J04	WATER PRESS GAUGE SUB KIT	1	
2	09352-50006-600	.HOSE (5X9X600)	1	L:600->160
3	09352-50006-600	.HOSE (5X9X600)	1	L:600->210
4	09367-06006	.3 WAY	1	
5	09401-08413	.CLIP	4	
6	18498-99EA1	.PROTECTOR (9.5X11.5X80)	1	
7	09407-20405	.CLAMP (L:202)	1	

FIG.520A




FIG.520A (1-F-7) OPT:FLUSH MOUNT REMOCON

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-98J24	REMOTE CONTROL ASSY, FLASH MT	1	
2	67271-98J20	.COVER, BOTTOM BASE	1	
3	67264-98J00	.COVER, TOP BASE	1	
4	67263-98J20	.COVER, LEVER	1	
5	67261-98J20	.GRIP, A	1	
6	67261-98J30	.GRIP, B	1	
7	67265-98J00	.BUTTON, NEUTRAL LOCK	1	
8	67255-98J00	.LINK, NEUTRAL LOCK NO.1	1	
9	67258-98J00	.PLATE, JOINT	1	
10	67256-98J00	.BLOCK, NEUTRAL LOCK	1	
11	67259-98J00	.SPRING	3	
12	67251-98J20	.LEVER, HANDLE	1	
13	67294-98J00	.SPACER	1	
14	67254-98J00	.LINK, NEUTRAL LOCK NO.2	1	
15	67233-98J00	.SLIDER, NEUTRAL BUTTON	1	
16	67296-98JA0	.SCREW (4X10)	3	
17	67234-98J00	.PLATE, LEVER	1	
18	67211-98J20	.HOUSING	1	
19	67269-98J20	.CLAMP, LEAD	1	
20	67296-98JB0	.SCREW (4X30)	1	
21	67227-98J20	.SCREW (4X35)	1	
22	67227-98J30	.SCREW (4X20)	1	
23	67288-98J50	.WASHER, PLANE	8	
24	67296-98JC0	.SCREW (6X40)	4	
25	67287-98J00	.NUT	4	
26	67226-98J10	.BOLT (6X50)	4	
27	67288-98J60	.WASHER, ININTERNAL TOOTH (M4)	3	
28	67296-98JD0	.SCREW (5X40)	1	
29	67238-98J00	.PIN	2	
30	67288-98J70	.WASHER, PLANE	5	
31	67246-98J00	.SHAFT, DRIVE	1	
32	67222-98J00	.PANEL ASSY, BACK	1	
33	67236-98J00	.ROLLER, DETENT	1	
34	67235-98J00	.GUIDE, DETENT ROOLER	1	

FIG.520A




FIG.520A (1-F-8) OPT:FLUSH MOUNT REMOCON

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67237-98J00	.SPRING, DETENT	1	
36	67223-98J00	.PAD, BRAKE	1	
37	67296-98JE0	.SCREW (5X35)	1	
38	67252-98J00	.BUSH, DRIVE SHAFT	1	
39	67288-98J20	.WASHER	1	
40	67292-98J00	.C RING	1	
41	15980-98J00	.POTENTIOMETER	1	
42	67227-98J10	.LEVER, POTENTIOMETER NO.2	1	
43	67296-94300	.SCREW (4X10)	2	
44	67288-98J00	.WASHER, POTENTIOMETER	5	
45	67296-98J10	.SCREW (5X35)	1	
46	67288-98J10	.WASHER, SPRING	8	
47	67228-98J50	.WASHER, WAVE	2	
48	67296-98J60	.SCREW (8X30)	1	
49	67288-94310	.WASHER (6.5X24X2)	4	
50	67296-98J50	.SCREW (5X18)	2	
51	67272-98J00	.GROMMET, COVER	2	
52	37850-98J03	.SWITCH ASSY, PTT	1	
53	67269-98J10	.BAND	1	
54	67257-98J00	.MARK, LEVER	1	
55	36890-98J00	.HARNESS, CONDENSER ADAPTER	1	

FIG.522A





FIG.522A (1-F-9) OPT:HARNESS (1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-98J51	WIRE ASSY, REMOTE CONTROL	1	
2	36612-98J20	CONNECTOR, COUNTER SELECT	AR	
3	36990-87D00	TERMINAL & SLEEVE SET	1	
4	36667-96L20	WIRE, GAUGE EXT	1	
5	33911-88BL0	CAP, RUBBER	1	
6	33925-93J00	CUSHION, ENGINE CONTROL UNIT	AR	
7	33926-98J00	RESISTOR, TERMINAL	AR	
8	36623-98J21	HARNESS ASSY, BCM NO.1 FOR SNGL	1	
9	36615-96300	.TERMINAL	4	
10-1	36770-98J13	CONTROLLER ASSY, BOAT ELECTRIC	1	
10-2	36770-98J22	CONTROLLER ASSY, BOAT ELECTRIC	2	
11	36775-98J00	HOLDER, BCM LH	AR	
12	36776-98J00	HOLDER, BCM RH	AR	
13	36622-98J00	HARNESS ASSY, DUAL STATION MAIN	AR	
14	09481-10501	.FUSE (10A)	AR	
15	36624-98J02	HARNESS ASSY, BCM NO.2 FOR SNGL	1	
16	36615-96300	.TERMINAL	2	
17	36621-98J00	HARNESS ASSY, DUAL ENGINE	AR	
18	36623-98J30	HARNESS ASSY, BCM NO.1 FOR MULT	1	
19	36615-96300	.TERMINAL	5	
20	36624-98J11	HARNESS ASSY, BCM NO.2 FOR MULT	1	
21	36615-96300	.TERMINAL	2	
22	36621-98J10	HARNESS ASSY, TRIPLE ENGINE	1	
23	09403-13402	CLAMP (ID:13)	AR	

FIG.523A




DF115BG_E11_021_523A
OPT:HARNESS (2)

FIG.523A (1-F-10) OPT:HARNESS (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36625-98J10	WIRE ASSY, BATTERY	AR	
2	09481-30501	.FUSE (30A)	AR	
3	36623-98J40	HARNESS ASSY, BCM FOR QUADRUPLE	1	
4	36615-96300	.TERMINAL	8	
5	36627-98J00	.HARNESS, R/CON EXTENSION	1	

FIG.530A



DF115BG_E11_021_530A
OPT:SWITCH

FIG.530A (1-F-11) OPT:SWITCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-98J07	PANEL ASSY, MAIN SWITCH	1	
2	37110-98J02	..SWITCH ASSY, MAIN	1	
3-1	37141-99EA0	..KEY (941)	1	
3-2	37141-99EB0	..KEY (942)	1	
3-3	37141-99E00	..KEY (931)	1	
3-4	37141-99E10	..KEY (932)	1	
3-5	37141-99E20	..KEY (933)	1	
3-6	37141-99E30	..KEY (934)	1	
3-7	37141-99E40	..KEY (935)	1	
3-8	37141-99E50	..KEY (936)	1	
3-9	37141-99E60	..KEY (937)	1	
3-10	37141-99E70	..KEY (938)	1	
3-11	37141-99E80	..KEY (939)	1	
3-12	37141-99E90	..KEY (940)	1	
4	37143-99E01	..CAP, KEY	1	
5	37139-98J10	..PANEL, MAIN SW	1	
6	37820-93J11	..SWITCH ASSY, EMERGENCY	1	
7	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
8	37826-92J10	..NUT	1	
9	03122-05165	..SCREW	4	
10	37114-98J00	..SHEET, MAIN SW PANEL	1	
11	37100-98J11	PANEL ASSY, SINGLE	1	
12	37112-98J00	..NUT	1	
13	09407-08401	CLAMP (L:80)	AR	
14	37803-93J06	PANEL ASSY, EMERGENCY SW	1	
15	37820-93J11	..SWITCH ASSY, EMERGENCY	1	
16	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
17	37826-92J10	..NUT	1	
18	37825-99E10	..PANEL, EMERGENCY STOP SW	1	
19	03122-05169	..SCREW	4	
20	37100-98J21	PANEL ASSY, DUAL	AR	
21	37112-98J10	..NUT	AR	
22	37100-98J31	PANEL ASSY, TRIPLE	1	
23	37112-98J10	..NUT	1	

FIG.530A




FIG.530A (1-F-12) OPT:SWITCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24	37860-87L00	PANEL ASSY ,TROLLING CONTROL SW	1	
25	37862-87L00	.PANEL	1	
26	09131-05004	.SCREW (5X16)	4	
27	38500-93J90	BUZZER, WARNING	AR	

FIG.535A

Exploded perspective view of a vehicle security system assembly (FIG. 535A). The diagram shows various components numbered 1 through 27. Component 1 is the main control unit, which is a rectangular box with a mounting plate (2) and a connector (10). A coiled cable (8) is attached to the side of the unit. Other components include a key (4), a small rectangular module (12), a larger rectangular module (16), a small rectangular module (18), a small rectangular module (19), a small rectangular module (21), a small rectangular module (23), a small rectangular module (24), a small rectangular module (25), a small rectangular module (26), a small rectangular module (27), a small rectangular module (28), a small rectangular module (29), a small rectangular module (30), a small rectangular module (31), a small rectangular module (32), a small rectangular module (33), a small rectangular module (34), a small rectangular module (35), a small rectangular module (36), a small rectangular module (37), a small rectangular module (38), a small rectangular module (39), a small rectangular module (40), a small rectangular module (41), a small rectangular module (42), a small rectangular module (43), a small rectangular module (44), a small rectangular module (45), a small rectangular module (46), a small rectangular module (47), a small rectangular module (48), a small rectangular module (49), a small rectangular module (50), a small rectangular module (51), a small rectangular module (52), a small rectangular module (53), a small rectangular module (54), a small rectangular module (55), a small rectangular module (56), a small rectangular module (57), a small rectangular module (58), a small rectangular module (59), a small rectangular module (60), a small rectangular module (61), a small rectangular module (62), a small rectangular module (63), a small rectangular module (64), a small rectangular module (65), a small rectangular module (66), a small rectangular module (67), a small rectangular module (68), a small rectangular module (69), a small rectangular module (70), a small rectangular module (71), a small rectangular module (72), a small rectangular module (73), a small rectangular module (74), a small rectangular module (75), a small rectangular module (76), a small rectangular module (77), a small rectangular module (78), a small rectangular module (79), a small rectangular module (80), a small rectangular module (81), a small rectangular module (82), a small rectangular module (83), a small rectangular module (84), a small rectangular module (85), a small rectangular module (86), a small rectangular module (87), a small rectangular module (88), a small rectangular module (89), a small rectangular module (90), a small rectangular module (91), a small rectangular module (92), a small rectangular module (93), a small rectangular module (94), a small rectangular module (95), a small rectangular module (96), a small rectangular module (97), a small rectangular module (98), a small rectangular module (99), a small rectangular module (100).

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	37100-96L02	PANEL ASSY, MAIN SWITCH	1	
2	37110-96L00	.SWITCH ASSY, MAIN	1	
3-1	37141-99E00	..KEY (931)	1	
3-2	37141-99E10	..KEY (932)	1	
3-3	37141-99E20	..KEY (933)	1	
3-4	37141-99E30	..KEY (934)	1	
3-5	37141-99E40	..KEY (935)	1	
3-6	37141-99E50	..KEY (936)	1	
4	37143-96L00	..KNOB, MAIN SWITCH	1	
5	37114-98J00	.SHEET, MAIN SW PANEL	1	
6	37139-96L30	.PANEL, MAIN SWITCH	1	
7	37820-93J11	.SWITCH ASSY, EMERGENCY	1	
8	37823-92E02	..PLATE ASSY, EMERGENCY SW LOCK	1	
9	37826-92J10	..NUT	1	
10	03122-05165	.SCREW	4	
11	37105-96L04	HARNESS SET, KLS CONTROLLER	1	
12	32980-38F00	.CUSHION, CDI UNIT	1	
13	36623-96L02	.HARNESS ASSY, KLS CONTROLLER	1	
14	36615-96300	..TERMINAL	1	
15	36662-96L01	.HARNESS ASSY, KLS CAN (L:6500+110)	1	
16	37173-96L10	.HOLDER, KLS PARTS	1	SMALL TYPE
17	38500-93J90	.BUZZER, WARNING	1	
18	38860-96L01	.RELAY ASSY, KLS	1	
19	32851-93J00	.CUSHION, LEAD WIRE	1	
20	09407-14407	.CLAMP (L:145)	1	
21-1	37170-96L05	CONTROLLER SET, KLS	1	433MHZ
21-2	37170-96L15	CONTROLLER SET, KLS	1	315MHZ
22	37117-96L00	.DECAL, KLS	2	
23-1	37171-96L02	.CONTROLLER ASSY, KLS	1	433MHZ
23-2	37171-96L12	.CONTROLLER ASSY, KLS	1	315MHZ
24-1	37172-96L01	.REMOCON ASSY, KLS	2	433MHZ
24-2	37172-96L10	.REMOCON ASSY, KLS	2	315MHZ

FIG.535A





FIG.535A (1-F-14) OPT:KEY LESS START (E11)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25	36663-96L00	WIRE, KLS CAN EXT	1	
26	36664-96L00	HARNESS ASSY, KLS CAN (L:810+110)	AR	
27	37173-96L00	HOLDER, KLS PARTS	1	LARGE TYPE

DF115BG E11
DF115BZG E11

FIG.540A




DF115BG_E11_021_540A
OPT:REMOTE CONTROL ASSY DUAL

FIG.540A (1-F-15) OPT:REMOTE CONTROL ASSY DUAL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-98J16	REMOTE CONTROL ASSY, MULTIPLE	1	
2	67211-98J20	.HOUSING	1	
3	67251-98J00	.LEVER, HANDLE	2	
4	67246-98J10	.SHAFT, DRIVE REMOCON	1	
5	67261-98J00	.GRIP, NO.1	1	
6	67261-98J10	.GRIP, NO.2	1	
7	67263-98J00	.COVER, LEVER	2	
8	67212-98J30	.COVER, REMOCON UPPER	1	UPPER
9	67271-98J40	.COVER, REMOCON BOTTOM	1	
10	67222-98J10	.PANEL ASSY, BACK	1	
11	67236-98J10	.ROLLER, DETENT	2	
12	67235-98J10	.GUIDE, DETENT ROLLER	2	
13	67237-98J40	.SPRING, DETENT	2	
14	67233-98J10	.HOLDER, DETENT SPRING	2	
15	67287-92E00	.NUT (M5)	2	
16	67239-98J00	.SCREW, DETENT ADJUSTMENT (5X14)	2	
17	67223-98J00	.PAD, BRAKE	2	
18	67296-98J50	.SCREW (5X18)	8	
19	67296-98JA0	.SCREW (4X10)	2	
20	67272-98J10	.GROMMET, REMOCON COVER	2	
21	67252-98J10	.BUSH, DRIVE SHAFT	2	
22	67288-98J20	.WASHER	2	
23	67292-98J00	.C RING	2	
24	15980-98J00	.POTENTIOMETER	2	
25	67227-98J10	.LEVER, POTENTIOMETER NO.2	1	
26	37850-98J03	.SWITCH ASSY, PTT	1	
27	67269-98J01	.CLAMP, LEAD	1	
28	67273-98J20	.PACKING	1	
29	67296-98J60	.SCREW (8X30)	2	
30	67296-98J30	.SCREW (5X70)	4	
31	67296-98JG0	.SCREW (5X14)	2	
32	67296-98J00	.SCREW (5X12)	1	
33	67296-94300	.SCREW (4X10)	4	
34	67288-98J40	.WASHER, BOTTOM COVER	14	
35	67288-98J00	.WASHER, POTENTIOMETER	4	

DF115BG_E11_021

FIG.540A




DF115BG_E11_021_540A
OPT:REMOTE CONTROL ASSY DUAL

FIG.540A (1-G-2) OPT:REMOTE CONTROL ASSY DUAL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
36	67288-92E20	.WASHER	2	
37	67226-98J00	.BOLT (5X50)	4	
38	09160-05024	.WASHER (5.5X16X1.5)	4	
39	67287-92E00	.NUT (M5)	4	
40	67296-98J90	.SCREW (8X30)	2	
41	67227-98J00	.LEVER, POTENTIOMETER NO.1	1	
42	67284-98J10	.MARK	1	
43	67257-98J00	.MARK, LEVER	2	
44	67269-98J30	.BAND	1	
45	67288-98J10	.WASHER, SPRING	16	
46	67288-98J30	.WASHER, LEVER COVER	2	
47	67228-98J50	.WASHER, WAVE	2	
48	67211-98J30	.HOUSING, REMOCON	1	
49	67222-98J20	.PANEL ASSY, BACK	1	
50	67246-98J20	.SHAFT, DRIVE REMOCON	1	
51	67273-98J10	.PACKING, FRONT	1	
52	67273-98J30	.PACKING, REAR	1	
53	67277-98J00	.GROMMET, REMOCON BOTTOM COVER	1	
54	67296-98JF0	.BOLT, UPPER COVER (5X14)	1	
55	67297-98J00	.NUT, UPPER COVER BOLT	1	
56	67237-98J50	.SPRING, DETENT	2	
57	36890-98J00	.HARNES, CONDENSER ADAPTER	1	
58-1	36620-98J31	WIRE ASSY, REMOTE CONTROL (L:6500)	1	
58-2	36620-98J41	WIRE ASSY, REMOTE CONTROL (L:9500)	1	

FIG.543A



DF115BG_E11_021_543A
OPT:REMOTE CONTROL ASSY SINGLE

FIG.543A (1-G-3) OPT:REMOTE CONTROL ASSY SINGLE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-98J06	REMOTE CONTROL ASSY, SINGLE	1	
2	67211-98J20	.HOUSING	1	
3	67251-98J00	.LEVER, HANDLE	1	
4	67246-98J10	.SHAFT, DRIVE REMOCON	1	
5	67261-98J00	.GRIP, NO.1	1	
6	67263-98J00	.COVER, LEVER	1	
7	67212-98J20	.COVER, REMOCON UPPER	1	UPPER
8	67271-98J30	.COVER, REMOCON BOTTOM	1	
9	67222-98J10	.PANEL ASSY, BACK	1	
10	67236-98J10	.ROLLER, DETENT	1	
11	67235-98J10	.GUIDE, DETENT ROLLER	1	
12	67237-98J30	.SPRING, DETENT	1	
13	67233-98J10	.HOLDER, DETENT SPRING	1	
14	67287-92E00	.NUT (M5)	1	
15	67239-98J00	.SCREW, DETENT ADJUSTMENT (5X14)	1	
16	67223-98J00	.PAD, BRAKE	1	
17	67296-98J50	.SCREW (5X18)	6	
18	67296-98JA0	.SCREW (4X10)	1	
19	67272-98J10	.GROMMET, REMOCON COVER	1	
20	67252-98J10	.BUSH, DRIVE SHAFT	1	
21	67288-98J20	.WASHER	1	
22	67292-98J00	.C RING	1	
23	15980-98J00	.POTENTIOMETER	1	
24	67227-98J10	.LEVER, POTENTIOMETER NO.2	1	
25	37850-98J03	.SWITCH ASSY, PTT	1	
26	67269-98J01	.CLAMP, LEAD	1	
27	67273-98J00	.PACKING	1	
28	67296-98J60	.SCREW (8X30)	1	
29	67274-98J00	.FLANGE, BASE	1	
30	67288-92E20	.WASHER	1	
31	67296-98J90	.SCREW (8X30)	1	
32	67296-98JG0	.SCREW (5X14)	1	
33	67296-94300	.SCREW (4X10)	2	
34	67288-98J00	.WASHER, POTENTIOMETER	2	
35	67296-98J20	.SCREW (5X50)	2	

DF115BG_E11_021

FIG.543A




FIG.543A (1-G-4) OPT:REMOTE CONTROL ASSY SINGLE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
36	67226-98J00	.BOLT (5X50)	4	
37	09160-05024	.WASHER (5.5X16X1.5)	4	
38	67287-92E00	.NUT (M5)	4	
39	67296-98J00	.SCREW (5X12)	1	
40	67288-98J40	.WASHER, BOTTOM COVER	12	
41	67296-98J10	.SCREW (5X35)	1	
42	67284-98J10	.MARK	1	
43	67257-98J00	.MARK, LEVER	1	
44	67269-98J30	.BAND	1	
45	67288-98J10	.WASHER, SPRING	8	
46	67288-98J30	.WASHER, LEVER COVER	1	
47	67228-98J50	.WASHER, WAVE	1	
48	67273-98J10	.PACKING, FRONT	1	
49	67273-98J30	.PACKING, REAR	1	
50	67277-98J00	.GROMMET, REMOCON BOTTOM COVER	1	
51	67296-98JF0	.BOLT, UPPER COVER (5X14)	1	
52	67297-98J00	.NUT, UPPER COVER BOLT	1	
53	36890-98J00	.HARNESS, CONDENSER ADAPTER	1	
54-1	36620-98J31	WIRE ASSY, REMOTE CONTROL (L:6500)	1	
54-2	36620-98J41	WIRE ASSY, REMOTE CONTROL (L:9500)	1	

FIG.585A




FIG.585A (1-G-5) OPT:GASKET SET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11400-99840	GASKET SET	1	
2	11141-99L00	.GASKET, CYLINDER HEAD	1	
3	11189-90J00	.GASKET, CYLINDER HEAD COVER	1	
4	11265-87E10	.GASKET, PROTECTION COVER	2	
5	11489-90J10	.GASKET, OIL PAN	1	
6	13119-99L00	.GASKET, INTAKE MANIFOLD	4	
7	13125-99L00	.GASKET, THROTTLE BODY	1	
8	14151-90J00	.GASKET, RECT & REGULATOR	1	
9	16941-99L00	.GASKET, OIL LVL GAGE GUIDE CAS	1	
10	17472-87E10	.GASKET, PUMP CASE PANEL	1	
11	51211-90J30	.GASKET, ENGINE HOLDER	1	

FIG.601A




FIG.601A (1-G-6) OPT:MULTI FUNCTION GAUGE (1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L65	KIT, SINGLE GAUGE ELECTRIC	1	
2	34011-96L15	.GAUGE SET, MULTI	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L20	.ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	34000-96L75	KIT, DUAL GAUGE ELECTRIC	1	
10	34011-96L15	.GAUGE SET, MULTI	2	
11	34112-96L00	..NUT, GAUGE	2	
12	34193-96L00	..BEZEL, GAUGE	2	
13	34211-96L00	..COVER, GAUGE	2	
14	34825-96L00	..PACKING, GAUGE	2	
15	36661-96L20	.ADAPTER, GAUGE	1	
16	36615-96300	..TERMINAL	5	
17	36662-88L10	.WIRE, 2 EXTENSION	2	
18	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
19	36664-88L00	.CONNECTOR, BRANCH	2	
20	36665-88L00	.UNIT, RESISTOR FEMALE	1	
21	36665-88L10	.UNIT, RESISTOR MALE	1	
22	36667-96L00	.WIRE, GAUGE ADAPTER	1	
23	36667-96L11	WIRE, DUAL GAUGE ADAPTER	1	
24	36667-96L30	WIRE, GAUGE ADAPTER	1	

FIG.602A




FIG.602A (1-G-7) OPT:MULTI FUNCTION GAUGE (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34002-96L15	KIT, DUAL STATION	1	
2	34011-96L15	.GAUGE SET, MULTI	1	
3	34112-96L00	.NUT, GAUGE	1	
4	34193-96L00	.BEZEL, GAUGE	1	
5	34211-96L00	.COVER, GAUGE	1	
6	34825-96L00	.PACKING, GAUGE	1	
7	36662-88L10	.WIRE, 2 EXTENSION	1	
8	36664-88L00	.CONNECTOR, BRANCH	1	
9	36665-96L00	.ADAPTER, DUAL STATION	1	
10	36666-96L00	.ADAPTER, GAUGE POWER	1	
11	36682-92E00	.WIRE, TRIM METER EXT (L:6500)	1	
12	34011-96L15	GAUGE SET, MULTI	1	
13	34112-96L00	.NUT, GAUGE	1	
14	34193-96L00	.BEZEL, GAUGE	1	
15	34211-96L00	.COVER, GAUGE	1	
16	34825-96L00	.PACKING, GAUGE	1	
17	36001-88L00	SET, WIRE	1	
18	36662-88L10	.WIRE, 2 EXTENSION	1	
19	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
20	36664-88L00	.CONNECTOR, BRANCH	1	
21	36665-88L00	.UNIT, RESISTOR FEMALE	1	
22	36665-88L10	.UNIT, RESISTOR MALE	1	
23	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
24	36662-88L20	WIRE, 6 EXTENSION	1	
25	36662-88L30	WIRE, 15 EXTENSION	1	
26	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
27	36662-88L00	WIRE, 25 EXTENSION	1	
28	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
29	36665-88L00	UNIT, RESISTOR FEMALE	1	
30	36665-88L10	UNIT, RESISTOR MALE	1	
31	36662-88L10	WIRE, 2 EXTENSION	1	
32	36664-88L00	CONNECTOR, BRANCH	1	
33	67237-98J20	SPRING, DETENT	1	

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
10000		12300-85830-012	116A-12-2	12892-69G10-283	121A-4-27
		12300-85854-0AA	116A-11-6	12892-69G10-285	121A-4-28
		12300-85854-0BA	116A-11-7	12892-69G10-288	121A-4-29
		12300-85854-0CA	116A-11-8	12892-69G10-290	121A-4-30
		12300-85854-0DA	116A-11-9	12892-69G10-293	121A-4-31
11100-99L00	111A-1	12300-85854-0EA	116A-11-10	12892-69G10-295	121A-4-32
11112-90J00	113A-9	12340-85FB3-0A0	116A-11-1	12892-69G10-298	121A-4-33
11115-85FA1-001	111A-4	12340-85FB3-0B0	116A-11-2	12892-69G10-300	121A-4-34
11117-89J00	111A-10	12340-85FB3-0C0	116A-11-3	12911-86FA2	121A-5
11117-90J10	113A-4	12340-85FB3-0D0	116A-11-4	12915-86F51	121A-6
11118-95J00	204A-1	12340-85FB3-0E0	116A-11-5	12921-90J01	121A-7
11141-99L00	111A-11	12632-92J12	175A-1	12931-90J00	121A-8
	585A-2	12711-99L00	121A-1	12932-85FA0	121A-9
11170-99L00	111A-14	12720-99L00	121A-2	12933-86510	121A-10
11173-99L00	111A-15	12732-90J01	119A-1	13110-99L00	122A-1
11174-99L00	111A-19	12733-90J00	119A-4	13119-99L00	122A-2
11179-90J00	111A-16	12741-90J01	119A-2		585A-6
11189-90J00	111A-17	12761-90J10	119A-9	13125-99L00	122A-3
	585A-3	12771-90J00	119A-10		585A-7
11194-99L00	111A-21	12810-90J00	119A-11	13300-99L00	163A-1
11196-99L00	162A-1	12812-90J00	119A-13	13315-99L00	163A-2
11216-90J10	113A-5	12813-73G00	119A-12	13370-99L00	143A-2
11261-87E10	310A-3	12831-90J02	119A-14	13370-99L10	143B-2
11261-93J00	111A-5	12891-69G00	121A-3	13575-40F00	326A-2
	113A-11	12892-69G10-218	121A-4-1	13580-98J03	326A-1
11265-87E10	310A-4	12892-69G10-220	121A-4-2	13614-89J00	143B-15
	585A-4	12892-69G10-223	121A-4-3	13614-93J00	143B-24
11291-99L00	113A-1	12892-69G10-225	121A-4-4	13650-52G00	315A-1
11301-99L00	113A-3	12892-69G10-228	121A-4-5	13655-87J01	315A-2
11382-93J00	111A-18	12892-69G10-230	121A-4-6	13684-99L00	143A-11
11400-99840	585A-1	12892-69G10-233	121A-4-7		143B-11
11489-90J10	180A-1	12892-69G10-235	121A-4-8	13710-99E00	134A-1
	585A-5	12892-69G10-238	121A-4-9	13810-99L00	134A-2
11501-90J20-QTN	180A-2-2	12892-69G10-240	121A-4-10	13813-99L00	134A-3
11501-90J20-YAY	180A-2-1	12892-69G10-243	121A-4-11	14151-90J00	310A-7
11511-99L00	136A-1	12892-69G10-245	121A-4-12		585A-8
11512-99L00	136A-4	12892-69G10-248	121A-4-13	15100-96J01	146A-1-1
11514-99L00	136A-2	12892-69G10-250	121A-4-14	15100-96J11	146A-1-2
11515-99L00	136A-5	12892-69G10-253	121A-4-15	15190-99L00	146A-2
12100-92840-025	116A-8-2	12892-69G10-255	121A-4-16	15192-99L00	146A-5
12100-92841-0A0	116A-8-1	12892-69G10-258	121A-4-17	15193-99L00	146A-14
12100-99L00-050	116A-14	12892-69G10-260	121A-4-18	15195-96L00	146A-4
12111-99L00	116A-1	12892-69G10-263	121A-4-19	15195-96L10	146A-12
12140-92J10	116A-2	12892-69G10-265	121A-4-20	15200-92J20	143A-3
12140-92J10-050	116A-15	12892-69G10-268	121A-4-21	15200-92J30	143B-3
12151-99L00	116A-3	12892-69G10-270	121A-4-22	15410-92J10	146A-6
12160-92J10	116A-5	12892-69G10-273	121A-4-23	15411-92J10	146A-7
12163-35F00	116A-6	12892-69G10-275	121A-4-24	15412-92J00	146A-8
12220-99L00	116A-9	12892-69G10-278	121A-4-25	15413-92J00	146A-9
12300-85830	116A-12-1	12892-69G10-280	121A-4-26	15415-92J00	146A-10

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
15421-99L00	146A-11		143B-30	17562-90J01	160A-6
15423-99L00	144A-4	15710-99L00	144A-2		160B-6
	144B-4		144B-2	17563-87D01	160A-7
15600-99L00	143A-1	15716-65DT0	144A-3		160A-24
15600-99L10	143B-1		144B-3		160B-7
15610-92J00	143A-27	15751-99L00	144A-5		160B-24
	143B-27		144B-5	17564-87D00	160A-8
15612-88L00	143A-21	15760-88L00	143A-12		160B-8
	143B-21		143B-12	17581-99L00	162A-14
15613-88L00	143A-22	15762-90J00	144B-7	17611-90J00	162A-2
	143B-22	15830-90J00	144B-10	17612-90J01	160A-20
15613-92J00	143A-25	15831-96L00	146A-16		160B-20
	143B-25	15980-98J00	520A-41	17631-90J00	160A-9
15614-88L00	143A-23		540A-24		160B-9
	143B-23		543A-23	17632-90J00	160A-10
15620-99L00	143A-26	16113-92J11	175A-2		160B-10
15620-99L10	143B-26	16400-99L00	175A-3	17635-87E00	160A-25
15626-92J01	143A-4	16440-99E00	175A-4		160B-25
15626-92J10	143B-4	16510-61A31	175A-14	17635-90J00	160A-11
15628-99E00	143A-5	16520-90J00	175A-5		160B-11
	143B-5	16531-99L00	175A-15	17660-98L01	162A-3
15629-99E10	143A-6	16539-99L00	175A-16	17670-90J01	162A-4-1
	143B-6	16910-99L00	180A-13	17670-90J11	162A-4-2
15641-88L00	143A-7	16930-99L00	180A-14	17681-99L00	162A-5
15641-88L10	143B-7	16934-99L00	180A-17	17710-99L00	162A-13
15641-88L31	143A-18	16941-99L00	180A-18	17711-90J00	162A-6
	143B-18		585A-9	17712-99L00	162A-10
15641-88L51	143A-19	17400-92J11	160B-21	17913-93J00	180A-3
	143B-19	17400-92J23	160A-21		410A-10
15642-88L00	143A-8	17410-92J00	160A-1	17914-93J01	180A-12
	143B-8		160B-1		410A-11
15642-88L10	143A-20	17413-92J01	160A-18	17915-99L00	162A-12
	143B-20	17413-92J11	160B-18	17917-87L00	410A-30
15643-88L10	143A-17	17416-92J11	160A-19	18213-98J30	315A-7
	143B-17		160B-19	18498-99EA1	507A-6
15644-88L00	143A-13	17461-90J01	160A-2	18590-59S00	315A-3
15644-88L10	143B-13		160B-2	18640-98L01	315A-5
15645-88L00	143A-14	17471-92J00	160A-3	19110-99L00	204A-2
	143B-14	17471-92J10	160B-3		
15648-92J00	143A-16	17472-87E10	160A-4		
	143B-16		160B-4		
15650-99E00	143A-9		585A-10		
	143B-9	17500-90J11	160A-22		
15654-88L00	143A-10		160B-22		
	143B-10	17520-90J00	160A-23		
15660-99L00	143A-31		160B-23	21110-99L00	204A-3
	143B-31	17561-90J03	160A-5-1	21151-99L00	204A-4
15681-99L00	144A-1		160B-5-1	21155-99L00	204A-5
	144B-1	17561-90J13	160A-5-2	21210-99L00	204A-6
15691-92J00	143A-30		160B-5-2	21230-99L00	204A-7

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
21241-99L00	204A-8	31281-92J10	337A-18	34660-90J04	507A-1
22511-99011	204A-9	31311-63J00	301A-9	34825-96L00	601A-6
	336A-1-1	31311-94900	340A-2		601A-14
	336A-1-2	31312-92J00	301A-11		602A-6
23111-90J02	204A-10-1	31320-92J00	301A-12		602A-16
23111-90J12	204A-10-2	31340-92J00	301A-10	34830-87J20	315A-4
23115-99L00	204A-11	31341-92J00	301A-13	34840-98J03	315A-6
25111-92J00	210A-6-1	31343-63J00	301A-14	34841-92J00	315A-8
	210B-6-1	31344-63J00	301A-15	34842-92J01	315A-9
25111-92J10	210A-6-2	31912-90J00	301A-16	34843-87L00	315A-10
	210B-6-2	31918-92J01	301A-17	34845-92J00	315A-13
25131-92J01	210A-1	32102-99L00	303A-1	34846-87L00	315A-11
	210B-1	32120-99L00	303A-2	36001-88L00	602A-17
25141-92J01	210A-2	32160-99L00	303A-3	36610-99L10	322A-7
	210B-2	32800-99L00	310A-10	36611-99L00	322A-25
25222-90J01	210A-3	32851-93J00	331A-1	36612-96J01	322A-21
	210B-3		535A-19	36612-98J20	522A-2
25232-90J00	210A-4	32890-99L00	310A-11	36615-96300	331A-4
	210B-4	32980-38F00	331A-2		522A-9
25321-92J10	210A-5		535A-12		522A-16
25321-92J20	210B-5	33220-64L10	303A-4		522A-19
25700-92J00	407A-30	33410-99L00	310A-1		522A-21
	407B-28	33634-96J00	322A-8		523A-4
	407C-26	33799-97E00	340A-9		535A-14
	407D-24	33810-90J30	322A-1		601A-8
29103-93J00	315A-21	33911-88BL0	522A-5		601A-16
29116-93J00	210A-8	33920-99L10	326A-21	36616-99L00	322A-3
	210B-8	33925-93J00	522A-6	36616-99L10	322A-4
29117-93J10	401A-15	33925-99L00	326A-22	36616-99L20	310A-8
29404-93J11	310A-17	33926-98J00	522A-7	36617-87L20	326A-3
		34000-96L65	601A-1	36617-88L00	310A-9
		34000-96L75	601A-9		322A-19
		34002-96L15	602A-1	36617-93J00	143A-32
		34011-96L15	601A-2		143B-32
			601A-10		303A-5
31100-92J00	301A-1		602A-2		322A-24
31111-94900	340A-10		602A-12	36617-93J10	143A-33
31123-94910	340A-4	34112-96L00	601A-3		143B-33
31133-90J10	340A-5		601A-11		303A-12
31133-94910	340A-6		602A-3		315A-18
31135-94900	340A-8		602A-13		322A-20
31136-90J20	340A-7	34190-88L00	602A-23	36618-43410	322A-9
31150-92J00	301A-2	34193-96L00	601A-4	36620-98J31	540A-58-1
31170-92J00	301A-3		601A-12		543A-54-1
31173-92J00	301A-4		602A-4	36620-98J41	540A-58-2
31173-94920	340A-3		602A-14		543A-54-2
31191-92J00	301A-5	34211-96L00	601A-5	36620-98J51	522A-1
31192-92J00	301A-6		601A-13	36621-98J00	522A-17
31220-92J00	301A-7		602A-5	36621-98J10	522A-22
31261-75F10	301A-8		602A-15	36622-98J00	522A-13

30000

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
36623-96L02	331A-3	36894-95201	336A-2		535A-24-2
	535A-13	36895-87D10	336A-9	37173-96L00	535A-27
36623-98J21	522A-8		337A-26	37173-96L10	331A-9
36623-98J30	522A-18	36990-87D00	522A-3		535A-16
36623-98J40	523A-3	37100-96L02	535A-1	37721-93J00	326A-4
36624-98J02	522A-15	37100-98J07	530A-1	37724-99L00	326A-5
36624-98J11	522A-20	37100-98J11	530A-11	37726-99L00	326A-6
36625-98J10	523A-1	37100-98J21	530A-20	37803-93J06	530A-14
36627-98J00	523A-5	37100-98J31	530A-22	37820-93J11	530A-6
36661-96L20	601A-7	37105-96L04	535A-11		530A-15
	601A-15	37110-96L00	535A-2		535A-7
36662-88L00	602A-27	37110-98J02	530A-2	37820-99E02	315A-12
36662-88L10	601A-17	37112-98J00	530A-12	37823-92E02	530A-7
	602A-7	37112-98J10	530A-21		530A-16
	602A-18		530A-23		535A-8
	602A-31	37114-98J00	530A-10	37825-99E10	530A-18
36662-88L20	602A-24		535A-5	37826-92J10	530A-8
36662-88L30	602A-25	37117-96L00	331A-6		530A-17
36662-96L01	331A-5		535A-22		535A-9
	535A-15	37139-96L30	535A-6	37850-92J00	326A-7
36663-88L00	601A-18	37139-98J10	530A-5	37850-98J03	520A-52
	602A-19	37141-99E00	530A-3-3		540A-26
	602A-28		535A-3-1		543A-25
36663-96L00	535A-25	37141-99E10	530A-3-4	37856-92J00	326A-8
36664-88L00	601A-19		535A-3-2	37857-92J01	326A-9
	602A-8	37141-99E20	530A-3-5	37860-87L00	530A-24
	602A-20		535A-3-3	37862-87L00	530A-25
	602A-32	37141-99E30	530A-3-6	38100-92J13	337A-2
36664-96L00	535A-26		535A-3-4		340A-1
36665-88L00	601A-20	37141-99E40	530A-3-7	38410-93J21	326A-19
	602A-21		535A-3-5	38415-93J20	326A-20
	602A-29	37141-99E50	530A-3-8	38500-93J90	331A-10
36665-88L10	601A-21		535A-3-6		530A-27
	602A-22	37141-99E60	530A-3-9		535A-17
	602A-30	37141-99E70	530A-3-10	38860-76F01	322A-13
36665-96L00	602A-9	37141-99E80	530A-3-11		322A-14
36666-96L00	602A-10	37141-99E90	530A-3-12		326A-30
36667-96L00	601A-22	37141-99EA0	530A-3-1	38860-96L01	331A-11
36667-96L11	601A-23	37141-99EB0	530A-3-2		535A-18
36667-96L20	522A-4	37143-96L00	535A-4	38890-99L00	326A-23
36667-96L30	601A-24	37143-99E01	530A-4	38892-98J01	326A-24
36682-92E00	602A-11	37170-96L05	535A-21-1	38895-99L00	326A-25
36770-98J13	522A-10-1	37170-96L15	535A-21-2	38915-90J00	326A-31
36770-98J22	522A-10-2	37171-96L02	331A-7-1	39950-88L02	602A-26
36775-98J00	522A-11		535A-23-1		
36776-98J00	522A-12	37171-96L12	331A-7-2		
36890-98J00	520A-55		535A-23-2		
	540A-57	37172-96L01	331A-8-1		
	543A-53		535A-24-1		
36894-87D00	336A-3	37172-96L10	331A-8-2		

40000

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
41111-90J13-QTN	335A-1-2	50000			407D-4
41111-90J13-YAY	335A-1-1			55320-94900	335A-4
41121-90J21-QTN	335A-2-2			55321-87J01	111A-7
41121-90J21-YAY	335A-2-1				113A-13
41130-92J30	335A-3				310A-5-1
41135-92J00	335A-11		51110-99810-Y5S	401A-1-2	337A-24
41161-94400	442A-1		51110-99810-YAY	401A-1-1	310A-5-2
41220-95E13	336A-17		51115-90J00	401A-8	407A-5
41221-95E40	336A-18		51122-90J00	401A-18	407B-5
41224-95E01	336A-19		51123-90J01	401A-19	407C-5
41225-94401	336A-20		51211-90J30	401A-9	407D-5
	420A-2			585A-11	335A-17
41226-97E00	210A-7		52111-90J02-QTN	405A-1-2	160A-26
	210B-7		52111-90J02-YAY	405A-1-1	160B-26
41228-90J00	336A-21		52111-90J12-QTN	405A-1-4	407A-6
41230-95E00	336A-22		52111-90J12-YAY	405A-1-3	407B-6
41233-95E10	336A-23		54112-90J21	401A-22	407C-6
43111-90J40-QTN	336A-4-2		54114-90J10	401A-25	407D-6
43111-90J40-YAY	336A-4-1			405A-13	160A-27
43111-90J50-QTN	336A-4-4		54121-87D01	405A-8	160B-27
43111-90J50-YAY	336A-4-3		54123-90J01	401A-21	407A-7
43112-99E00	180A-4		54125-90J11	401A-26	407B-7
43211-93J11	336A-5		54130-90J40	401A-23	407C-7
43711-97E11	336A-6		54148-90J11	401A-27	407D-7
43750-90J61-QTN	336A-7-2		54151-90J00	405A-14	220A-27-2
43750-90J61-YAY	336A-7-1		54160-90J20	405A-9	220A-27-1
43750-90J71-QTN	336A-7-4		54166-90J11	405A-10	220B-1-2
43750-90J71-YAY	336A-7-3		54211-90J01-QTN	405A-15-2	220B-1-1
45421-90J00	335A-15		54211-90J01-YAY	405A-15-1	220A-28
48000-90J39	337A-1		54221-90J02-QTN	405A-6-2	220B-2
48121-90J00	337A-19		54221-90J02-YAY	405A-6-1	220A-35
48321-90J00	337A-20		55110-90J16-QTN	407A-1-2	220B-8
48326-95E00	337A-21			407C-1-2	220A-39
48400-90J03	337A-3		55110-90J16-YAY	407A-1-1	220B-11
48502-90J13	337A-9			407C-1-1	220A-1-1
48557-90J00	337A-7		55110-92J01-QTN	407B-1-2	220B-16-1
48571-87L01	337A-5			407D-1-2	220A-1-2
48572-87J10	337A-6		55110-92J01-YAY	407B-1-1	220B-16-2
48582-95E01	337A-11			407D-1-1	405A-5
48583-95E00	337A-10		55116-87E00	407A-28	220A-2
48585-95E00	337A-12			407B-26	220B-17
48588-90J00	337A-14		55125-90J01	407A-3	220A-7
48611-90J00	337A-4			407C-3	220B-22
48862-87J20	337A-8		55125-92J00-QTN	407B-3-2	220A-11
48862-90J21	337A-17			407D-3-2	220A-9
48862-92J20	337A-15		55125-92J00-YAY	407B-3-1	220B-24
48862-92J30	337A-16			407D-3-1	220A-15
48864-93J01	337A-13		55127-87D00	407A-4	220B-30
				407B-4	220A-18
				407C-4	220B-34

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
57616-90J00	220A-26	61401-99810-YAY	420A-1-1	67212-98J30	540A-8
57616-92J00	220B-42	61401-99820-QTN	420A-1-2	67222-98J00	520A-32
57621-99L00	220A-19	61435-99L20	420A-15-1	67222-98J10	540A-10
	220B-35	61435-99L30	420A-15-2		543A-9
57630-90J00	407A-29	61441-92J10	420A-13	67222-98J20	540A-49
	407B-27	61443-99L00	420A-11-1	67223-98J00	520A-36
57631-92J10	220A-21	61443-99L10	420A-11-2		540A-17
	220B-36	61453-99L00	420A-12-1		543A-16
57633-90J02	407A-23	61453-99L10	420A-12-2	67226-98J00	540A-37
	407B-21	61458-90J01	410A-35		543A-36
	407C-21	61494-99L00	136A-11	67226-98J10	520A-26
57635-92J01	407D-19	61610-93J00	420A-4	67227-98J00	540A-41
	407A-24	61621-93J01	420A-5	67227-98J10	520A-42
	407B-22	61632-93J00	410A-16		540A-25
	407C-22	61633-96J02	410A-17		543A-24
	407D-20	61634-96J02	410A-18	67227-98J20	520A-21
58100-90JA0-019	407A-19-1	61641-93J10	410A-19	67227-98J30	520A-22
	407C-19-1	61645-90J01-QTN	410A-20-2	67228-98J50	520A-47
58100-90JB0-019	407A-19-2	61645-90J01-YAY	410A-20-1		540A-47
	407C-19-2	61648-99L00	410A-33		543A-47
58100-90JC0-019	407A-19-3	61673-96J02	410A-21	67233-98J00	520A-15
	407C-19-3	61682-99L00	420A-6	67233-98J10	540A-14
58100-90JD0-019	407A-19-4	61811-99L00-QTN	410A-1-2		543A-13
	407C-19-4	61811-99L00-YAY	410A-1-1	67234-98J00	520A-17
58100-90JE0-019	407A-19-5	61814-99L00	410A-5	67235-98J00	520A-34
	407C-19-5	61820-99L00-QTN	410A-2-2	67235-98J10	540A-12
58105-90J00	407A-20	61820-99L00-YAY	410A-2-1		543A-11
	407A-22	61824-99L00	410A-6	67236-98J00	520A-33
	407B-20	61827-99L00	410A-3	67236-98J10	540A-11
	407C-20	61830-99L00-QTN	410A-12-2		543A-10
58200-92J40	407A-21-1	61830-99L00-YAY	410A-12-1	67237-98J00	520A-35
58200-92J50	407A-21-2	65000-94L10	432A-1	67237-98J20	602A-33
58200-92J60	407A-21-3	65520-99100	432A-2	67237-98J30	543A-12
58200-92J70	407A-21-4	65561-95D00	432A-3	67237-98J40	540A-13
58200-92J80	407A-21-5	65700-90J24	430A-1	67237-98J50	540A-56
58200-92J90	407A-21-6		432A-5	67238-98J00	520A-29
58200-92JA0	407B-19-1	65740-95D01	432A-4	67239-98J00	540A-16
58200-92JB0	407B-19-2	65750-95501	430A-2		543A-15
58200-92JC0	407B-19-3		432A-6	67246-98J00	520A-31
58200-92JD0	407B-19-4	65770-90J04	475A-1	67246-98J10	540A-4
		65770-90J13	430A-3		543A-4
			432A-7	67246-98J20	540A-50
		67200-98J06	543A-1	67251-98J00	540A-3
		67200-98J16	540A-1		543A-3
		67200-98J24	520A-1	67251-98J20	520A-12
61112-99L00	420A-3	67211-98J20	520A-18	67252-98J00	520A-38
61124-99L00	410A-28		540A-2	67252-98J10	540A-21
61134-99L00	410A-7		543A-2		543A-20
61150-99E01	180A-5	67211-98J30	540A-48	67254-98J00	520A-14
61155-99E01	180A-7	67212-98J20	543A-7	67255-98J00	520A-8

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67256-98J00	520A-10	67288-98J10	520A-46	67471-99E00	204A-14
67257-98J00	520A-54		540A-45	67471-99E10	204A-15
	540A-43		543A-45	67600-99L00	442A-7
	543A-43	67288-98J20	520A-39	67631-99L00	442A-8
67258-98J00	520A-9		540A-22	67701-90J01	442A-2
67259-98J00	520A-11		543A-21	67721-99E00	442A-3
67261-98J00	540A-5	67288-98J30	540A-46	67725-99E00	442A-4
	543A-5		543A-46	67725-99E10	442A-9
67261-98J10	540A-6	67288-98J40	540A-34	67726-99E00	442A-5
67261-98J20	520A-5		543A-40		442A-10
67261-98J30	520A-6	67288-98J50	520A-23	67728-99E00	442A-6
67263-98J00	540A-7	67288-98J60	520A-27	68111-93J00	420A-14
	543A-6	67288-98J70	520A-30	69711-93E11	136A-12
67263-98J20	520A-4	67292-98J00	520A-40		
67264-98J00	520A-3		540A-23		
67265-98J00	520A-7		543A-22		
67269-98J01	540A-27	67294-98J00	520A-13	90000	
	543A-26	67296-94300	520A-43		
67269-98J10	520A-53		540A-33		
67269-98J20	520A-19		543A-33		
67269-98J30	540A-44	67296-98J00	540A-32	99011-99L00-03B	420A-17-2
	543A-44		543A-39	99011-99L00-054	420A-17-1
67271-98J20	520A-2	67296-98J10	520A-45	99011-99L00-059	420A-17-3
67271-98J30	543A-8		543A-41		
67271-98J40	540A-9	67296-98J20	543A-35		
67272-98J00	520A-51	67296-98J30	540A-30		
67272-98J10	540A-20	67296-98J50	520A-50		
	543A-19		540A-18	00000	
67273-98J00	543A-27		543A-17		
67273-98J10	540A-51	67296-98J60	520A-48		
	543A-48		540A-29		
67273-98J20	540A-28		543A-28	01421-0616A	119A-15
67273-98J30	540A-52	67296-98J90	540A-40	01421-0820C	144A-12
	543A-49		543A-31	01421-0830C	122A-4
67274-98J00	543A-29	67296-98JA0	520A-16	01500-06167	322A-11
67277-98J00	540A-53		540A-19	01547-0616C	420A-8
	543A-50		543A-18	01547-0620C	420A-9
67284-98J10	540A-42	67296-98JB0	520A-20	01547-0625A	175A-10
	543A-42	67296-98JC0	520A-24	01547-0625C	111A-23
67287-92E00	540A-15	67296-98JD0	520A-28	01547-0635A	175A-11
	540A-39	67296-98JE0	520A-37	01547-0655C	111A-24
	543A-14	67296-98JF0	540A-54	01550-0612C	143A-40
	543A-38		543A-51		143B-40
67287-98J00	520A-25	67296-98JG0	540A-31		162A-28
67288-92E20	540A-36		543A-32		162A-29
	543A-30	67297-98J00	540A-55		303A-17
67288-94310	520A-49		543A-52		310A-21
67288-98J00	520A-44	67361-90J10	410A-36		322A-26
	540A-35	67467-89J01	204A-12		326A-15
	543A-34	67467-89J10	204A-13		420A-10

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
01550-0616A	119A-16	04211-11129	401A-17	09116-06121	162A-7
	175A-12	04211-13149	301A-20		335A-5
01550-0616C	146A-21	04211-13189	111A-13	09116-06127	410A-22
	180A-16	04221-04089	116A-7	09116-06517	134A-6
	204A-28	04221-05109	119A-5		143A-28
	303A-9	06111-07004	220A-23		143B-28
	322A-5		220B-38		310A-22
	326A-26	06111-11004	220A-24	09116-08122	220A-34
01550-0620A	119A-17		220B-39		220B-14
01550-0620C	162A-20	07130-05167	326A-17	09116-08131	160A-12
	162A-21	08113-62090	220A-32		160B-12
	310A-2	08211-30382	220A-12-1	09116-08137	335A-14
	310A-19	08310-00067	322A-12		407A-9
	326A-27		322A-23		407B-9
01550-06257	310A-18	08316-10067	136A-10		407C-9
01550-0625C	144A-6	08316-1006A	119A-19		407D-9
	144B-6	08316-10087	322A-2	09116-08160	401A-10
	180A-19	08316-1008C	122A-6	09116-08174	410A-13
	401A-14		144A-14	09116-08177	111A-12
01550-0630C	310A-20		144B-14	09116-08178	180A-8
01550-06357	326A-28		146A-19		401A-11
01550-0655C	162A-22	08321-0105C	326A-18	09116-10129	180A-9
	326A-29	08321-01067	322A-22	09116-10150	407A-10
01550-08207	301A-18	08331-3112A	175A-13		407B-10
01550-0820C	111A-9	08331-41269	119A-8		407C-10
	113A-15	08331-41359	204A-33		407D-10
	163A-3		401A-6	09116-10179	337A-22
01550-0825A	401A-20	08341-31059	303A-11	09116-10181	401A-28
01550-0825C	175A-17	09100-06131	407A-8		405A-2
	204A-29		407B-8		405A-7
01550-0830C	204A-30		407C-8	09117-08110	220A-38
01550-0835A	119A-18		407D-8		220B-15
01550-0835C	122A-5	09100-12081	442A-11	09117-10039	407A-11
01550-0840C	113A-8	09100-12090	335A-6-2		407B-11
01550-0855C	204A-31	09100-12091	335A-6-1		407C-11
01550-0860C	163A-4	09103-05026	410A-27		407D-11
01550-0880C	204A-32	09103-06093	315A-15	09125-05046	160A-13
01550-1050C	301A-19	09103-06211	146A-20		160B-13
01550-12167	144A-13	09103-06231	303A-6		315A-16
01550-1230C	113A-2	09103-06240	136A-6	09125-05050	336A-8
02112-0408A	143A-15	09103-06266	111A-2		337A-27
02112-0612A	111A-25	09103-06281	111A-8	09125-06063	160A-28
02122-04167	326A-16		113A-14		160B-28
02142-0408B	143A-24		310A-6		336A-24
02142-0616C	322A-6		337A-25		336A-28
02162-05207	315A-14	09103-12049	119A-3		336A-29
03122-05165	530A-9	09103-16004	303A-7	09131-05004	530A-26
	535A-10	09106-05030	303A-10	09132-04034	160A-17
03122-05169	530A-19	09106-10065	335A-12		160B-17
03542-06209	136A-3	09108-06060	136A-7	09136-06148	410A-9

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09136-06149	410A-4	09160-35002	220B-26-6		220B-19
09140-10032	336A-25	09160-35003	220B-26-8	09180-09022	442A-13
09140-14024	220A-8	09160-35006	220B-26-4	09181-12158	175A-7
	220B-23	09160-35008	220B-26-5	09181-31001	220A-5
09141-18005	407A-25	09160-35009	220B-26-7		220B-20
	407B-23	09160-35010	220B-26-9	09181-39001	336A-12
	407C-23	09160-35013	220B-26-3	09181-40186	220A-10-1
	407D-21	09160-35014	220B-26-2		220B-25-1
09159-12014	335A-7	09160-35015	220B-26-1	09181-40190	220A-10-7
	401A-24	09160-39001	336A-10		220B-25-7
	401A-29	09160-60003	220B-28-3	09181-40195	220A-10-11
	405A-11	09160-60004	220B-28-4		220B-25-11
09159-14020	335A-16	09160-60005	220B-28-5	09181-41002	220A-10-2
09159-22006	335A-8	09160-60006	220B-28-6		220B-25-2
09160-05024	540A-38	09160-60007	220B-28-7	09181-41003	220A-10-3
	543A-37	09160-60008	220B-28-1		220B-25-3
09160-05029	326A-10	09160-60009	220B-28-2	09181-41004	220A-10-4
09160-06055	204A-16	09160-60011	220B-27		220B-25-4
09160-06082	336A-26	09160-60013	220B-28-8	09181-41005	220A-10-5
09160-06084	136A-8	09160-60014	220B-28-9		220B-25-5
	310A-12	09160-60015	220B-28-10	09181-41006	220A-10-6
09160-06085	407A-12	09160-60016	220B-28-11		220B-25-6
	407B-12	09160-60017	220B-28-12	09181-41008	220A-10-8
	407C-12	09160-60018	220B-28-13		220B-25-8
	407D-12	09160-60019	220B-28-14	09181-41009	220A-10-9
09160-06094	204A-17	09160-60020	220B-28-15		220B-25-9
09160-08059	401A-16	09160-70002	220A-13	09181-41010	220A-10-10
09160-10082	335A-13	09160-70005	220B-29		220B-25-10
09160-12066	442A-12	09161-16008	160A-14	09181-41012	220A-10-12
09160-12110	335A-10		160B-14		220B-25-12
	401A-30	09164-14008	410A-24	09181-41013	220A-10-13
09160-12128	335A-9	09164-31001	220A-3		220B-25-13
09160-12132	405A-12		220B-18	09181-41014	220A-10-14
09160-12133	405A-16	09168-10022	407A-13		220B-25-14
09160-13014	410A-23		407B-13	09181-45003	220A-14-1
09160-16048	303A-8		407C-13	09181-45004	220A-14-2
09160-18028	407A-26		407D-13	09181-45005	220A-14-3
	407B-24	09168-12012	180A-10	09181-45006	220A-14-4
	407C-24	09168-12013	144A-7	09181-45007	220A-14-5
	407D-22	09168-16002	175A-6	09181-45008	220A-14-6
09160-30036	220A-12-2	09169-06053	322A-31	09181-45009	220A-14-7
09160-30037	220A-12-3	09169-06062	310A-15	09181-45013	220A-14-8
09160-30038	220A-12-4		310A-23	09181-45014	220A-14-9
09160-30039	220A-12-5	09169-06090	134A-4	09181-45015	220A-14-10
09160-30041	220A-12-6		143A-29	09181-45016	220A-14-11
09160-30042	220A-12-7		143B-29	09181-45017	220A-14-12
09160-30043	220A-12-8	09169-06097	136A-9	09181-45018	220A-14-13
09160-30044	220A-12-9	09169-08050	410A-14	09181-70001	220A-16-1
09160-30055	220B-43	09169-28003	336A-11		220B-31-3
09160-30056	220B-44	09169-31001	220A-4	09181-70002	220A-16-2

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	220B-31-5	09248-12009	180A-11	09283-32044	401A-4
09181-70003	220A-16-3	09248-12011	204A-21	09283-52006	116A-13
	220B-31-7	09248-18014	113A-6	09289-06003	121A-11
09181-70004	220A-16-4	09250-10001	336A-13	09289-18001	401A-5
	220B-31-9	09251-07003	146A-3	09306-06004	204A-23
09181-70006	220A-16-5	09260-10005	204A-22	09306-10022	204A-24
	220B-31-1	09261-05006	175A-8	09306-12014	204A-25
09181-70008	220A-16-10	09262-17019	401A-2	09306-13007	410A-26
	220B-31-10	09262-35068	119A-6	09306-13011	410A-34
09181-70009	220A-16-6	09262-35069	401A-7	09320-08062	144A-8
	220B-31-2	09263-28016	407A-2		144B-8
09181-70010	220A-16-7		407B-2	09320-08510	322A-10
	220B-31-4		407C-2	09320-08517	111A-27
09181-70011	220A-16-8		407D-2		143A-34
	220B-31-6	09263-30051	220A-29		143B-34
09181-70012	220A-16-9		220B-3	09320-09016	310A-14
	220B-31-8	09263-45004	220B-13		310A-24
09202-04022	410A-25	09263-50001	220A-41	09320-09059	134A-5
09202-05027	116A-10		220B-4	09320-10075	310A-13
09202-06031	160A-15	09265-25046	220A-6	09320-11023	410A-15
	160B-15		220B-21	09329-01007	310A-16
09202-07002	220A-20	09269-30014	220B-45	09329-10024	420A-7
	220B-40	09269-60001	220B-32	09329-12004	111A-28
09202-08006	405A-3	09269-70001	220A-17	09329-14003	410A-32
	407A-14		220B-33	09329-14004	410A-31
	407B-14	09280-09016	180A-6	09352-11154-050	162A-9
	407C-14	09280-21015	180A-15	09352-50003-065	143A-35
	407D-14	09280-22019	111A-6		143B-35
09204-01006	204A-18		113A-12	09352-50003-120	143A-36
	204A-19	09280-22020	175A-9		143B-36
	336A-27	09280-22022	119A-7	09352-50006-600	162A-11
09204-03003	407A-27	09280-26006	111A-20		507A-2
	407B-25		162A-8		507A-3
	407C-25		162A-15	09355-40805-600	407A-16-1
	407D-23		401A-13		407A-16-2
09205-04014	210A-9	09280-33004	146A-13		407B-16-1
	210B-9	09280-46004	220A-36		407B-16-2
09206-08001	111A-3		220B-9		407C-16-1
	401A-12	09280-69001	210A-10		407C-16-2
09206-09012	220A-40		210B-10		407D-16-1
	220B-12	09280-97001	220A-30		407D-16-2
09206-11019	204A-20		220B-5	09360-12008	144A-9
09206-13019	113A-7	09282-24003	401A-3	09360-12013	144B-9
09208-06011	410A-37	09282-24004	220A-37	09362-09008	407A-17
09246-04009	113A-10		220B-10		407B-17
09247-12013	144B-13	09282-30007	220A-31		407C-17
09248-10008	407A-15		220B-6		407D-17
	407B-15	09282-39001	336A-14	09363-08004	144A-10
	407C-15	09283-10011	210A-11	09367-05004	143A-37
	407D-15		210B-11		143B-37

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09367-06006	507A-4		331A-12		
09380-22015	337A-23		535A-20		
09380-38003	336A-15	09407-18402	315A-20		
09381-21002	116A-4	09407-20405	410A-29		
09383-08005	204A-26		507A-7		
09387-45001	405A-4	09408-00056	162A-25		
09387-52001	220A-33	09408-00174	162A-26		
	220B-7	09408-00175	162A-27		
09401-08412	143A-38	09408-00213	322A-30		
	143B-38	09409-05302-5PK	410A-8		
09401-08413	162A-17	09420-05009	160A-16		
	507A-5		160B-16		
09401-11006	146A-18	09440-07071	204A-27		
09401-11423	430A-4	09440-09040	220A-22		
	432A-8		220B-37		
09401-11425	144A-11	09440-19028	336A-16		
	144B-11	09440-49004	220A-25		
09401-14409	146A-17		220B-41		
	162A-18	09448-10006	326A-14		
09401-15414	162A-16	09481-10501	522A-14		
09401-20409	111A-22	09481-10504	322A-15		
09401-31407	162A-19	09481-15504	322A-16		
09403-07340	315A-23	09481-30501	523A-2		
09403-08329	143A-39	09481-30504	322A-17		
	143B-39	09481-60403	322A-18		
09403-11321	143A-41	09482-00649	111A-26		
	143B-41	09800-81841	420A-16		
	303A-13				
	315A-24				
	322A-27				
	326A-11				
09403-12314	146A-15				
09403-12420	162A-23				
09403-13311	303A-14				
	322A-29				
09403-13402	522A-23				
09403-13413	303A-15				
	315A-22				
09403-16313	303A-16				
09403-16416	162A-24				
09407-08401	530A-13				
09407-10404	315A-17				
	326A-12				
	407A-18				
	407B-18				
	407C-18				
	407D-18				
09407-14403	322A-28				
09407-14407	315A-19				
	326A-13				

[illegible]

SUZUKI **DF115BG** PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION

Service Material Development Group, Service Engineering Dept.
300 Takatsuka, Minami, Hamamatsu, Japan

SUZUKI MOTOR CORPORATION