

# **SUZUKI**

## PARTS CATALOGUE

# **DF140BG/115BG**

DF140BG/BZG  
DF115BG/BZG



# **OUTBOARD MOTOR**

## **021 022**

E11/E40

2021-8

1<sup>ST</sup> EDITION

This part catalogue supersedes all the following part catalogue with immediate effect

| Model of catalogue | Parts catalogue No. |
|--------------------|---------------------|
| DF140BG_021        | 9900B-45483-000     |
| DF115BG_021        | 9900B-45489-000     |

## PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF140BG/DF140BZG/DF115BG/115BZG production start from 2020 to 2021.

### INSTRUCTIONS FOR QUOTING THE CATALOGUE

#### 1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

#### 2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

|                                                      |                              |            |                       |
|------------------------------------------------------|------------------------------|------------|-----------------------|
| AR                                                   | : As required                | NT         | : Number of teeth     |
| ASSY                                                 | : Assembly                   | OPT        | : Optional            |
| E. NO.                                               | : Engine number              | OS         | : Over size           |
| F. NO.                                               | : Frame number               | STD        | : Standard            |
| D                                                    | : Diameter of material       | T          | : Thickness           |
| ID                                                   | : Inside diameter            | US         | : Under size          |
| OD                                                   | : Outside diameter           | W          | : Width               |
| L                                                    | : Length                     | W/         | : With                |
| LH(PORT)                                             | : Left hand side             | L. X       | : Transom type        |
| RH(STBD)                                             | : Right hand side            | SUS        | : Stainless steel     |
| ~123456                                              | : Up to E. NO. 14002F-123456 | PTT        | : Power trim and tilt |
| 123456~                                              | : From E. NO. 14002F-123456  |            |                       |
| 12 x 34 x 5.6..... Figures in the description column |                              |            |                       |
| show the dimensions of parts.                        |                              |            |                       |
| ID                                                   | OD                           | T(or W, L) |                       |

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

#### 3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

#### 4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

#### 5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual.  
When assembling, use "SUZUKI SERVICE MANUAL".

#### 6. MODEL NAME AND ENGINE NUMBER

| MODEL        | DESTINATION | TYPE   | TRANSOM | COLOR    | ENGINE No.     |
|--------------|-------------|--------|---------|----------|----------------|
| DF140BG_021  | E11, E40    | 14004F | L, X    | YAY, QTN | 14004F-140001~ |
| DF140BG_022  | E11, E40    | 14004F | L, X    | YAY, QTN | 14004F-240001~ |
| DF140BZG_021 | E11, E40    | 14004Z | L, X    | YAY, QTN | 14004Z-140001~ |
| DF140BZG_022 | E11, E40    | 14004Z | L, X    | YAY, QTN | 14004Z-240001~ |
| DF115BG_021  | E11, E40    | 11505F | L, X    | YAY, QTN | 11505F-140001~ |
| DF115BG_022  | E11, E40    | 11505F | L, X    | YAY, QTN | 11505F-240001~ |
| DF115BZG_021 | E11, E40    | 11505Z | L, X    | YAY, QTN | 11505Z-140001~ |
| DF115BZG_022 | E11, E40    | 11505Z | L, X    | YAY, QTN | 11505Z-240001~ |

## PREFACE

Quand il devient nécessaire de remplacer des pièces sur SUZUKI MOTEURS HORSBOARD toujours utiliser les PIÈCES D'ORIGINE SUZUKI qui ont été soumises à des contrôles de qualité sévères leur garantissant qualité et performance impeccables.

Ce catalogue de pièces détachées couvre la liste de toutes les pièces de rechange pour SUZUKI DF140BG/DF140BZG/DF115BG/115BZG production start from 2020 to 2021.

## INSTRUCTIONS POUR UTILISER LE CATALOGUE

### 1. DIMENSIONS

Les dimensions des pièces dans ce catalogue sont indiquées en unités de millimètres.

### 2. ABREVIATIONS

Les abréviations utilisées dans ce catalogue sont les suivantes:

|        |                      |     |                    |
|--------|----------------------|-----|--------------------|
| AR     | : Comme requis       | NT  | : Nombre de dents  |
| ASSY   | : Assemblage         | OPT | : Sur option       |
| E. NO. | : Numéro du moteur   | OS  | : Sur-dimensionné  |
| F. NO. | : Numéro du chfssis  | T   | : Epaisseur        |
| ID     | : Diamètre intérieur | US  | : Sous-dimensionné |
| OD     | : Diamètre extérieur | W   | : Largeur          |

L : Longueur

LH(PORT) : Côte gauche

RH(STBD) : Côte droit

~123456 : Jusqu'à E. NO. 14002F-123456

123456~ : Depuis E. NO. 14002F-123456

12 x 34 x 5.6..... Les chiffres dans la colonne

| | | remarques montrent les dimensions

ID OD T(or W, L) des pieces comme suit.

→12345-56781 (N° de pieces) : indique que le numéro des pièces a été échangé en 12345-56781 et que les nouvelles pièces sont interchangeables avec les anciennes, mais que celles-ci ne sont pas interchangeables avec les nouvelles.

←12345-56781 (N° de pieces) : indique que les anciennes et nouvelles pièces sont interchangeables les unes avec les autres et sont utilisables chacune.

### 3. PIECES INTERNES DE L'ASSEMBLAGE

Les numéros de pièces qui comportent un point (.) avant la désignation de pièce détachée indique la pièce interne se rapportant à l'assemblage.

### 4. AVIS DE MODIFICATION

Un bulletin de pièces détachées vous sera envoyé à tout moment opportun quand des changements de pièces ont lieu, y compris les modifications de pièces interchangeables entre les nouvelles et anciennes pièces.

### 5. A NOTER

5-1. Il existe certaines pièces différentes de celles de rechange pour les modèles de production vu des raisons administratives et dont l'usage est commun avec celles d'autres modèles.

5-2. Concernant les durites en caoutchouc et les tuyaux en vinyle, ne pas manquer de les couper à la bonne longueur comme indiqué dans le catalogue des pièces détachées ou selon ce qui est utile pour le véhicule affecté.

5-3. Noter que les dessins à la page d'illustration servent à titre de référence pour les numéros de pièces détachées, et non pas comme référence pour l'assemblage. Pour cette dernière opération, se reporter au "MANUEL D'ENTRETIEN SUZUKI".

### 6. NOM DU MODELE / NUMERO DE SERIE DU MOTEUR

| MODELE       | DESTINATION | TYPE   | HOUTEUR DE<br>BARRE D' ARCASSE | COULEUR  | N° DELA MOTEUR |
|--------------|-------------|--------|--------------------------------|----------|----------------|
| DF140BG_021  | E11, E40    | 14004F | L, X                           | YAY, QTN | 14004F-140001~ |
| DF140BG_022  | E11, E40    | 14004F | L, X                           | YAY, QTN | 14004F-240001~ |
| DF140BZG_021 | E11, E40    | 14004Z | L, X                           | YAY, QTN | 14004Z-140001~ |
| DF140BZG_022 | E11, E40    | 14004Z | L, X                           | YAY, QTN | 14004Z-240001~ |
| DF115BG_021  | E11, E40    | 11505F | L, X                           | YAY, QTN | 11505F-140001~ |
| DF115BG_022  | E11, E40    | 11505F | L, X                           | YAY, QTN | 11505F-240001~ |
| DF115BZG_021 | E11, E40    | 11505Z | L, X                           | YAY, QTN | 11505Z-140001~ |
| DF115BZG_022 | E11, E40    | 11505Z | L, X                           | YAY, QTN | 11505Z-240001~ |

COLOR CHART  
TABLEAU DES COULEURS

[illegible][illegible]

MILLIMETER → INCH CONVERSION CHART


|    | 0     | 1     | 2     | 3     | 4     | 5     | 6     | 7     | 8     | 9     |
|----|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| 00 | .000  | .039  | .079  | .118  | .157  | .197  | .236  | .276  | .315  | .354  |
| 10 | .394  | .433  | .472  | .512  | .551  | .591  | .630  | .669  | .709  | .748  |
| 20 | .787  | .827  | .866  | .906  | .945  | .984  | 1.024 | 1.063 | 1.102 | 1.142 |
| 30 | 1.181 | 1.220 | 1.260 | 1.299 | 1.339 | 1.378 | 1.417 | 1.457 | 1.496 | 1.535 |
| 40 | 1.575 | 1.614 | 1.654 | 1.693 | 1.732 | 1.772 | 1.811 | 1.850 | 1.890 | 1.929 |
| 50 | 1.969 | 2.008 | 2.047 | 2.087 | 2.126 | 2.165 | 2.205 | 2.214 | 2.283 | 2.323 |
| 60 | 2.362 | 2.402 | 2.441 | 2.480 | 2.520 | 2.559 | 2.598 | 2.638 | 2.677 | 2.717 |
| 70 | 2.756 | 2.795 | 2.835 | 2.874 | 2.913 | 2.953 | 2.992 | 3.031 | 3.071 | 3.110 |
| 80 | 3.150 | 3.189 | 3.228 | 3.268 | 3.307 | 3.346 | 3.386 | 3.425 | 3.465 | 3.504 |
| 90 | 3.543 | 3.583 | 3.622 | 3.661 | 3.701 | 3.740 | 3.780 | 3.819 | 3.858 | 3.898 |

How to read

|    | 0   | 1   | 2   | 3     | 4   |
|----|-----|-----|-----|-------|-----|
| 00 | ... | ... | ... | ...   | ... |
| 10 | ... | ... | ... | ...   | ... |
| 20 | ... | ... | ... | 0.906 | ... |
| 30 | ... | ... | ... | ...   | ... |


23 millimeters equal 0.906 inch

FIG.111A




OPFAUREL ETU. 602.111A  
CYLINDER HEAD

FIG.113A




OPFAUREL ETU. 602.113A  
CYLINDER BLOCK

FIG.116A




OPFAUREL ETU. 602.116A  
CRANKSHAFT

FIG.119A




OPFAUREL ETU. 602.119A  
TIMING CHAIN

FIG.121A




OPFAUREL ETU. 602.121A  
CAMSHAFT

FIG.122A




OPFAUREL ETU. 602.122A  
INTAKE MANIFOLD

FIG.134A



OPFAUREL ETU. 602.134A  
SILENCER


FIG.136A



OPFAUREL ETU. 602.136A  
RING GEAR COVER




FIG.160B




OPTIONAL ETL 602 160B  
WATER PUMP

FIG.162A




OPTIONAL ETL 602 162A  
FUEL INJECTOR

FIG.163A




OPTIONAL ETL 602 163A  
FUEL INJECTOR

FIG.175A




OPTIONAL ETL 602 175A  
FUEL INJECTOR

FIG.180A




OPTIONAL ETL 602 180A  
FUEL INJECTOR

FIG.204A




OPTIONAL ETL 602 204A  
FUEL INJECTOR

FIG.210A




OPTIONAL ETL 602 210A  
FUEL INJECTOR

FIG.210B




OPTIONAL ETL 602 210B  
FUEL INJECTOR

FIG.220A




01FAUREL ETI, 042, 3104  
TRANSMISSION

FIG.220B




01FAUREL ETI, 042, 3105  
TRANSMISSION

FIG.301A




01FAUREL ETI, 042, 3104  
STARTING MOTOR

FIG.303A




01FAUREL ETI, 042, 3104  
HEADLIGHT

FIG.310A




01FAUREL ETI, 042, 3104  
RECTIFICATION CDE

FIG.315A




01FAUREL ETI, 042, 3104  
SENSOR

FIG.315B




01FAUREL ETI, 042, 3105  
SENSOR

FIG.322A




01FAUREL ETI, 042, 3104  
HARNESS

FIG.322B




02FA002L ETL 002\_000  
HARDNESS

FIG.322C




02FA002L ETL 002\_000  
HARDNESS

FIG.322D




02FA002L ETL 002\_000  
HARDNESS

FIG.326A




02FA002L ETL 002\_000  
PIT SWITCHING CONTROL UNIT

FIG.326B




02FA002L ETL 002\_000  
PIT SWITCHING CONTROL UNIT

FIG.331A




02FA002L ETL 002\_000  
KEY-LESS START

FIG.331B




02FA002L ETL 002\_000  
KEY-LESS START

FIG.335A




02FA002L ETL 002\_000  
CLAMP BRACKET

FIG.335B




02FA08Z,ETU,04Z,0085  
CLAMP BRACKET

FIG.336A




02FA08Z,ETU,04Z,0084  
CRANK BRACKET

FIG.336B




02FA08Z,ETU,04Z,0085  
CRANK BRACKET

FIG.337A




02FA08Z,ETU,04Z,0074  
PISTON CYLINDER

FIG.337B




02FA08Z,ETU,04Z,0075  
PISTON CYLINDER

FIG.337C




02FA08Z,ETU,04Z,0076  
PISTON CYLINDER

FIG.340A




02FA08Z,ETU,04Z,0084  
PISTON CYLINDER

FIG.340B




02FA08Z,ETU,04Z,0085  
PISTON CYLINDER

FIG.401A




DI FAURE ET L. SAS 401A  
EXTREME 140/150

FIG.405A




DI FAURE ET L. SAS 405A  
ORIGINE SHIMTT-100/120/122

FIG.407A




DI FAURE ET L. SAS 407A  
GEAR CASE

FIG.407B




DI FAURE ET L. SAS 407B  
GEAR CASE

FIG.407C




DI FAURE ET L. SAS 407C  
GEAR CASE

FIG.407D




DI FAURE ET L. SAS 407D  
GEAR CASE

FIG.410A




DI FAURE ET L. SAS 410A  
SIDE COVER

FIG.420A




DI FAURE ET L. SAS 420A  
EXTREME COVER

FIG.420B




OPTIONEL ETIL 420/425  
EXTERNE COVER

FIG.430A




OPTIONEL ETIL 430/435  
FUEL HOSE

FIG.432A




OPTIONEL ETIL 432/435  
FUEL TANK

FIG.442A




OPTIONEL ETIL 442/445  
FUEL HOSE

FIG.475A




OPTIONEL ETIL 475/480  
FUEL FILTER

FIG.507A




OPTIONEL ETIL 507/510  
OPTIONAL FUEL PRESSURE GAUGE SWIT

FIG.507B




OPTIONEL ETIL 507/510  
OPTIONAL FUEL PRESSURE GAUGE SWIT

FIG.520A




OPTIONEL ETIL 520/525  
OPTIONAL FUEL PRESSURE GAUGE SWIT

FIG.520B




OFIABLE ETI, 60L, 500B  
OPTIFLASH (QUANT 6640000)

FIG.522A




OFIABLE ETI, 60L, 500A  
OPTIFLASH (7)

FIG.522B




OFIABLE ETI, 60L, 500B  
OPTIFLASH (7)

FIG.523A




OFIABLE ETI, 60L, 500A  
OPTIFLASH (7)

FIG.523B




OFIABLE ETI, 60L, 500B  
OPTIFLASH (7)

FIG.530A




OFIABLE ETI, 60L, 500A  
OPTISWITCH

FIG.530B




OFIABLE ETI, 60L, 500B  
OPTISWITCH

FIG.535A




OFIABLE ETI, 60L, 500A  
OPTIFLASH (START)

FIG.535B




OPTIONAL ETU, GSC, SCS  
OPTIONAL KEY LESS START

FIG.540A




OPTIONAL ETU, GSC, SCS  
OPTIONAL REMOTE CONTROL ASSY DUAL

FIG.540B




OPTIONAL ETU, GSC, SCS  
OPTIONAL REMOTE CONTROL ASSY DUAL

FIG.543A




OPTIONAL ETU, GSC, SCS  
OPTIONAL REMOTE CONTROL ASSY SINGLE

FIG.543B




OPTIONAL ETU, GSC, SCS  
OPTIONAL REMOTE CONTROL ASSY SINGLE

FIG.585A




OPTIONAL ETU, GSC, SCS  
OPTIONAL GINET SET

FIG.601A




OPTIONAL ETU, GSC, SCS  
OPTIONAL FUNCTION GAUGE (1)

FIG.601B




OPTIONAL ETU, GSC, SCS  
OPTIONAL FUNCTION GAUGE (1)

FIG.602A



DETAILED VIEW OF THE  
PRESSURE GAUGE (A)

FIG.602B



DETAILED VIEW OF THE  
PRESSURE GAUGE (B)

FIG.111A




FIG.111A (1-B-2) CYLINDER HEAD

| REF NO. | PART NO.        | DESCRIPTION                 | Q'TY | REMARKS |
|---------|-----------------|-----------------------------|------|---------|
| 1       | 11100-99L00     | HEAD ASSY, CYLINDER         | 1    |         |
| 2       | 09103-06266     | .BOLT (6X40)                | 21   |         |
| 3       | 09206-08001     | .PIN (8X11)                 | 18   |         |
| 4       | 11115-85FA1-001 | GUIDE, VALVE (OS:0.3)       | 16   | OPT     |
| 5       | 11261-93J00     | COVER, PROTECTION ANODE     | 2    |         |
| 6       | 09280-22019     | O RING (D:1.9,ID:21.8)      | 2    |         |
| 7       | 55321-87J01     | ANODE, PROTECTION           | 2    |         |
| 8       | 09103-06281     | BOLT (6X14)                 | 2    |         |
| 9       | 01550-0820C     | BOLT                        | 2    |         |
| 10      | 11117-89J00     | BOLT, CRANKCASE INSIDE      | 10   |         |
| 11      | 11141-99L00     | GASKET, CYLINDER HEAD       | 1    |         |
| 12      | 09116-08177     | BOLT (8X52)                 | 8    |         |
| 13      | 04211-13189     | PIN                         | 2    |         |
| 14      | 11170-99L00     | COVER, CYLINDER HEAD        | 1    |         |
| 15      | 11173-99L00     | PLATE, BREATHER             | 1    |         |
| 16      | 11179-90J00     | GASKET, SPARK PLUG HOLE     | 4    |         |
| 17      | 11189-90J00     | GASKET, CYLINDER HEAD COVER | 1    |         |
| 18      | 11382-93J00     | CAP, OIL FILLER             | 1    |         |
| 19      | 11174-99L00     | HOSE, BREATHER              | 1    |         |
| 20      | 09280-26006     | O RING (D:3.1,ID:26.4)      | 1    |         |
| 21      | 11194-99L00     | GUARD, FUEL HOSE            | 1    |         |
| 22      | 09401-20409     | CLIP                        | 2    |         |
| 23      | 01547-0625C     | BOLT                        | 11   |         |
| 24      | 01547-0655C     | BOLT                        | 4    |         |
| 25      | 02112-0612A     | SCREW                       | 8    |         |
| 26      | 09482-00649     | SPARK PLUG (LKR6E)          | 4    | NGK     |
| 27      | 09320-08517     | GROMMET                     | 4    |         |
| 28      | 09329-12006     | CUSHION                     | 2    |         |

FIG.113A




FIG.113A (1-B-3) CYLINDER BLOCK

| REF NO. | PART NO.    | DESCRIPTION               | Q'TY | REMARKS |
|---------|-------------|---------------------------|------|---------|
| 1       | 11291-99L00 | HOOK, ENGINE              | 1    |         |
| 2       | 01550-1230C | BOLT                      | 2    |         |
| 3       | 11301-99L00 | BLOCK SET, CYLINDER       | 1    |         |
| 4       | 11117-90J10 | .BOLT, CRANKCASE          | 10   |         |
| 5       | 11216-90J10 | .GASKET, OIL GALLERY PULG | 3    |         |
| 6       | 09248-18014 | .PLUG (18X8)              | 3    |         |
| 7       | 09206-13019 | .PIN (10.4X13X16)         | 5    |         |
| 8       | 01550-0840C | .BOLT                     | 10   |         |
| 9       | 11112-90J00 | .PLUG, OIL VENTURI        | 1    |         |
| 10      | 09246-04009 | PLUG                      | 1    |         |
| 11      | 11261-93J00 | COVER, PROTECTION ANODE   | 1    |         |
| 12      | 09280-22019 | O RING (D:1.9,ID:21.8)    | 1    |         |
| 13      | 55321-87J01 | ANODE, PROTECTION         | 1    |         |
| 14      | 09103-06281 | BOLT (6X14)               | 1    |         |
| 15      | 01550-0820C | BOLT                      | 1    |         |

FIG.116A




FIG.116A (1-B-4) CRANKSHAFT

| REF NO. | PART NO.        | DESCRIPTION                         | Q'TY | REMARKS        |
|---------|-----------------|-------------------------------------|------|----------------|
| 1       | 12111-99L00     | PISTON                              | 4    |                |
| 2       | 12140-92J10     | RING SET, PISTON                    | 4    |                |
| 3       | 12151-99L00     | PIN, PISTON                         | 4    |                |
| 4       | 09381-21002     | CIRCLIP                             | 8    |                |
| 5       | 12160-92J10     | CONNECTING ROD ASSY                 | 4    |                |
| 6       | 12163-35F00     | .BOLT, CONNROD                      | 8    |                |
| 7       | 04221-04089     | .PIN                                | 8    |                |
| 8-1     | 12100-92841-0A0 | BEARING SET, CONNROD                | 4    |                |
| 8-2     | 12100-92840-025 | BEARING SET, CONNROD (US:0.25)      | 4    | OPT            |
| 9       | 12220-99L00     | CRANKSHAFT (NT:29)                  | 1    |                |
| 10      | 09202-05027     | .PIN (5X8.8)                        | 1    |                |
| 11-1    | 12340-85FB3-0A0 | BEARING SET, CRANKSHAFT (STD)       | 5    | GREEN          |
| 11-2    | 12340-85FB3-0B0 | BEARING SET, CRANKSHAFT (STD)       | 5    | BLACK          |
| 11-3    | 12340-85FB3-0C0 | BEARING SET, CRANKSHAFT (STD)       | 5    | NON            |
| 11-4    | 12340-85FB3-0D0 | BEARING SET, CRANKSHAFT (STD)       | 5    | YELLOW         |
| 11-5    | 12340-85FB3-0E0 | BEARING SET, CRANKSHAFT (STD)       | 5    | BLUE           |
| 11-6    | 12300-85854-0AA | BEARING SET, CRANKSHAFT (US:0.25)   | 5    | OPT,RED/GREEN  |
| 11-7    | 12300-85854-0BA | BEARING SET, CRANKSHAFT (US:0.25)   | 5    | OPT,RED/BLACK  |
| 11-8    | 12300-85854-0CA | BEARING SET, CRANKSHAFT (US:0.25)   | 5    | OPT,RED        |
| 11-9    | 12300-85854-0DA | BEARING SET, CRANKSHAFT (US:0.25)   | 5    | OPT,RED/YELLOW |
| 11-10   | 12300-85854-0EA | BEARING SET, CRANKSHAFT (US:0.25)   | 5    | OPT,RED/BLUE   |
| 12-1    | 12300-85830     | BEARING SET, CRANK THRUST (STD)     | 1    |                |
| 12-2    | 12300-85830-012 | BEARING SET, CRANK THRUST (OS:0.12) | 1    | OPT            |
| 13      | 09283-52006     | OIL SEAL (52X70X10)                 | 1    |                |
| 14      | 12100-99L00-050 | PISTON SET, OS (OS:0.50)            | 4    | OPT            |
| 15      | 12140-92J10-050 | .RING SET, PISTON OS (OS:0.50)      | 4    | OPT            |

FIG.119A




FIG.119A (1-B-5) TIMING CHAIN

| REF NO. | PART NO.    | DESCRIPTION                       | Q'TY | REMARKS |
|---------|-------------|-----------------------------------|------|---------|
| 1       | 12732-90J01 | GEAR, DRIVEN (NT:18)              | 1    |         |
| 2       | 12741-90J01 | SPROCKET, CAMSHAFT TIMING (NT:29) | 2    |         |
| 3       | 09103-12049 | BOLT (12X25)                      | 2    |         |
| 4       | 12733-90J00 | PLUG, DRIVEN GEAR                 | 1    |         |
| 5       | 04221-05109 | PIN                               | 2    |         |
| 6       | 09262-35068 | BEARING (35X62X14)                | 1    | UPPER   |
| 7       | 09280-22022 | O RING (D:1.9,ID:21.8)            | 1    |         |
| 8       | 08331-41269 | CIRCLIP                           | 1    |         |
| 9       | 12761-90J10 | CHAIN, TIMING                     | 1    |         |
| 10      | 12771-90J00 | GUIDE, TIMING CHAIN               | 1    |         |
| 11      | 12810-90J00 | TENSIONER, TIMING CHAIN           | 1    |         |
| 12      | 12813-73G00 | .PAD, TIMING CHAIN TENSIONER      | 1    |         |
| 13      | 12812-90J00 | SPACER, TIMING CHAIN TENSIONER    | 1    |         |
| 14      | 12831-90J02 | ADJUSTER ASSY, TENSIONER          | 1    |         |
| 15      | 01421-0616A | STUD BOLT                         | 1    |         |
| 16      | 01550-0616A | BOLT                              | 2    |         |
| 17      | 01550-0620A | BOLT                              | 1    |         |
| 18      | 01550-0835A | BOLT                              | 1    |         |
| 19      | 08316-1006A | NUT                               | 1    |         |



FIG.121A




FIG.121A (1-B-6) CAMSHAFT

| REF NO. | PART NO.        | DESCRIPTION            | Q'TY | REMARKS |
|---------|-----------------|------------------------|------|---------|
| 1       | 12711-99L00     | CAMSHAFT, INTAKE       | 1    |         |
| 2       | 12720-99L00     | CAMSHAFT, EXHAUST      | 1    |         |
| 3       | 12891-69G00     | TAPPET                 | 16   |         |
| 4-1     | 12892-69G10-218 | SHIM, TAPPET (T:2.175) | AR   |         |
| 4-2     | 12892-69G10-220 | SHIM, TAPPET (T:2.200) | AR   |         |
| 4-3     | 12892-69G10-223 | SHIM, TAPPET (T:2.225) | AR   |         |
| 4-4     | 12892-69G10-225 | SHIM, TAPPET (T:2.250) | AR   |         |
| 4-5     | 12892-69G10-228 | SHIM, TAPPET (T:2.275) | AR   |         |
| 4-6     | 12892-69G10-230 | SHIM, TAPPET (T:2.300) | AR   |         |
| 4-7     | 12892-69G10-233 | SHIM, TAPPET (T:2.325) | AR   |         |
| 4-8     | 12892-69G10-235 | SHIM, TAPPET (T:2.350) | AR   |         |
| 4-9     | 12892-69G10-238 | SHIM, TAPPET (T:2.375) | AR   |         |
| 4-10    | 12892-69G10-240 | SHIM, TAPPET (T:2.400) | AR   |         |
| 4-11    | 12892-69G10-243 | SHIM, TAPPET (T:2.425) | AR   |         |
| 4-12    | 12892-69G10-245 | SHIM, TAPPET (T:2.450) | AR   |         |
| 4-13    | 12892-69G10-248 | SHIM, TAPPET (T:2.475) | AR   |         |
| 4-14    | 12892-69G10-250 | SHIM, TAPPET (T:2.500) | AR   |         |
| 4-15    | 12892-69G10-253 | SHIM, TAPPET (T:2.525) | AR   |         |
| 4-16    | 12892-69G10-255 | SHIM, TAPPET (T:2.550) | AR   |         |
| 4-17    | 12892-69G10-258 | SHIM, TAPPET (T:2.575) | AR   |         |
| 4-18    | 12892-69G10-260 | SHIM, TAPPET (T:2.600) | AR   |         |
| 4-19    | 12892-69G10-263 | SHIM, TAPPET (T:2.625) | AR   |         |
| 4-20    | 12892-69G10-265 | SHIM, TAPPET (T:2.650) | AR   |         |
| 4-21    | 12892-69G10-268 | SHIM, TAPPET (T:2.675) | AR   |         |
| 4-22    | 12892-69G10-270 | SHIM, TAPPET (T:2.700) | AR   |         |
| 4-23    | 12892-69G10-273 | SHIM, TAPPET (T:2.725) | AR   |         |
| 4-24    | 12892-69G10-275 | SHIM, TAPPET (T:2.750) | AR   |         |
| 4-25    | 12892-69G10-278 | SHIM, TAPPET (T:2.775) | AR   |         |
| 4-26    | 12892-69G10-280 | SHIM, TAPPET (T:2.800) | AR   |         |
| 4-27    | 12892-69G10-283 | SHIM, TAPPET (T:2.825) | AR   |         |
| 4-28    | 12892-69G10-285 | SHIM, TAPPET (T:2.850) | AR   |         |
| 4-29    | 12892-69G10-288 | SHIM, TAPPET (T:2.875) | AR   |         |
| 4-30    | 12892-69G10-290 | SHIM, TAPPET (T:2.900) | AR   |         |
| 4-31    | 12892-69G10-293 | SHIM, TAPPET (T:2.925) | AR   |         |
| 4-32    | 12892-69G10-295 | SHIM, TAPPET (T:2.950) | AR   |         |
| 4-33    | 12892-69G10-298 | SHIM, TAPPET (T:2.975) | AR   |         |

FIG.121A




FIG.121A (1-B-7) CAMSHAFT

| REF NO. | PART NO.        | DESCRIPTION            | Q'TY | REMARKS |
|---------|-----------------|------------------------|------|---------|
| 4-34    | 12892-69G10-300 | SHIM, TAPPET (T:3.000) | AR   |         |
| 5       | 12911-86FA2     | VALVE, INTAKE          | 8    |         |
| 6       | 12915-86F51     | VALVE, EXHAUST         | 8    |         |
| 7       | 12921-90J01     | SPRING, VALVE          | 16   |         |
| 8       | 12931-90J00     | RETAINER, VALVE SPRING | 16   |         |
| 9       | 12932-85FA0     | COTTER, VALVE          | 32   |         |
| 10      | 12933-86510     | SEAT, VALVE SPRING     | 16   |         |
| 11      | 09289-06003     | OIL SEAL (6X12.8X10.2) | 16   |         |

FIG.122A




FIG.122A (1-B-8) INTAKE MANIFOLD

| REF NO. | PART NO.    | DESCRIPTION              | Q'TY | REMARKS |
|---------|-------------|--------------------------|------|---------|
| 1       | 13110-99L00 | MANIFOLD, INTAKE         | 1    |         |
| 2       | 13119-99L00 | .GASKET, INTAKE MANIFOLD | 4    |         |
| 3       | 13125-99L00 | .GASKET, THROTTLE BODY   | 1    |         |
| 4       | 01421-0830C | STUD BOLT                | 2    |         |
| 5       | 01550-0835C | BOLT                     | 6    |         |
| 6       | 08316-1008C | NUT                      | 2    |         |



FIG.134A




FIG.134A (1-B-9) SILENCER

| REF NO. | PART NO.    | DESCRIPTION            | Q'TY | REMARKS |
|---------|-------------|------------------------|------|---------|
| 1       | 13710-99E00 | ARRESTER, FLAME        | 1    |         |
| 2       | 13810-99L00 | SILENCER               | 1    |         |
| 3       | 13813-99L00 | HOLDER, FLAME ARRESTER | 1    |         |
| 4       | 09169-06090 | WASHER                 | 2    |         |
| 5       | 09320-09059 | CUSHION                | 2    |         |
| 6       | 09116-06517 | BOLT (6X25)            | 2    |         |

FIG.136A




FIG.136A (1-B-10) RING GEAR COVER

| REF NO. | PART NO.    | DESCRIPTION              | Q'TY | REMARKS |
|---------|-------------|--------------------------|------|---------|
| 1       | 11511-99L00 | COVER, RING GEAR         | 1    |         |
| 2       | 11514-99L00 | PLATE, RING GEAR COVER   | 1    |         |
| 3       | 03542-06209 | SCREW                    | 3    |         |
| 4       | 11512-99L00 | CUSHION, RING GEAR COVER | 2    |         |
| 5       | 11515-99L00 | BRACE, RING GEAR COVER   | 1    |         |
| 6       | 09103-06240 | BOLT                     | 2    |         |
| 7       | 09108-06060 | STUD BOLT                | 1    |         |
| 8       | 09160-06084 | WASHER (6.5X18X1.6)      | 1    |         |
| 9       | 09169-06097 | WASHER                   | 1    |         |
| 10      | 08316-10067 | NUT                      | 1    |         |
| 11      | 61494-99L00 | LABEL, OIL & CLEARANCE   | 1    |         |
| 12      | 69711-93E11 | LABEL, S.I.G.P           | 1    |         |

FIG.143A




FIG.143A (1-B-11) FUEL VAPOR SEPARATOR (E11)

| REF NO. | PART NO.    | DESCRIPTION                        | Q'TY | REMARKS |
|---------|-------------|------------------------------------|------|---------|
| 1       | 15600-99L00 | SEPARATOR ASSY, FUEL VAPOR         | 1    |         |
| 2       | 13370-99L00 | .VALVE ASSY, NEEDLE                | 1    |         |
| 3       | 15200-92J20 | .PUMP ASSY, FUEL                   | 1    |         |
| 4       | 15626-92J01 | .SEAL                              | 1    |         |
| 5       | 15628-99E00 | .SCREW (L:15)                      | 5    |         |
| 6       | 15629-99E10 | .SCREW, DRAIN                      | 1    |         |
| 7       | 15641-88L00 | .SPACER                            | 1    |         |
| 8       | 15642-88L00 | .FILTER ASSY                       | 1    |         |
| 9       | 15650-99E00 | .FLOAT                             | 1    |         |
| 10      | 15654-88L00 | .PIN                               | 1    |         |
| 11      | 13684-99L00 | .HOSE, DRAIN (L:280)               | 1    |         |
| 12      | 15760-88L00 | .REGULATOR ASSY                    | 1    |         |
| 13      | 15644-88L00 | .O RING                            | 1    |         |
| 14      | 15645-88L00 | .HOLDER, REGULATOR                 | 1    |         |
| 15      | 02112-0408A | .SCREW                             | 1    |         |
| 16      | 15648-92J00 | .RING                              | 1    |         |
| 17      | 15643-88L10 | .JOINT                             | 1    |         |
| 18      | 15641-88L31 | .BUSH                              | 1    |         |
| 19      | 15641-88L51 | .BUSH                              | 1    |         |
| 20      | 15642-88L10 | .FILTER                            | 1    |         |
| 21      | 15612-88L00 | .COVER, VAPOR SEPARATOR            | 1    |         |
| 22      | 15613-88L00 | .O RING                            | 1    |         |
| 23      | 15614-88L00 | .SCREW                             | 3    |         |
| 24      | 02142-0408B | .SCREW                             | 1    |         |
| 25      | 15613-92J00 | .GASKET                            | 1    |         |
| 26      | 15620-99L00 | .CASE ASSY, VAPOR SEPARATOR<br>UPR | 1    |         |
| 27      | 15610-92J00 | .CASE ASSY, VAPOR SEPARATOR<br>LWR | 1    |         |
| 28      | 09116-06517 | BOLT (6X25)                        | 3    |         |
| 29      | 09169-06090 | WASHER                             | 3    |         |
| 30      | 15691-92J00 | CUSHION, FUEL VAPOR SEPARATOR      | 3    |         |
| 31      | 15660-99L00 | HOSE, EVAPORATION                  | 1    |         |
| 32      | 36617-93J00 | BRACKET, HARNESS                   | 1    |         |
| 33      | 36617-93J10 | BRACKET, HARNESS                   | 2    |         |
| 34      | 09320-08517 | GROMMET                            | 2    |         |

FIG.143A




FIG.143A (1-B-12) FUEL VAPOR SEPARATOR (E11)

| REF NO. | PART NO.        | DESCRIPTION | Q'TY | REMARKS |
|---------|-----------------|-------------|------|---------|
| 35      | 09352-50003-065 | HOSE        | 1    |         |
| 36      | 09352-50003-120 | HOSE        | 1    |         |
| 37      | 09367-05004     | JOINT       | 1    |         |
| 38      | 09401-08412     | CLIP        | 5    |         |
| 39      | 09403-08329     | CLAMP       | 4    |         |
| 40      | 01550-0612C     | BOLT        | 3    |         |
| 41      | 09403-11321     | CLAMP       | 1    |         |




FIG.143B





FIG.143B (1-B-13) FUEL VAPOR SEPARATOR (E40)

| REF NO. | PART NO.        | DESCRIPTION                   | Q'TY | REMARKS |
|---------|-----------------|-------------------------------|------|---------|
| 1       | 15600-99L10     | SEPARATOR ASSY, FUEL VAPOR    | 1    |         |
| 2       | 13370-99L10     | .VALVE ASSY, NEEDLE           | 1    |         |
| 3       | 15200-92J30     | .PUMP ASSY, FUEL              | 1    |         |
| 4       | 15626-92J10     | .SEAL                         | 1    |         |
| 5       | 15628-99E00     | .SCREW (L:15)                 | 5    |         |
| 6       | 15629-99E10     | .SCREW, DRAIN                 | 1    |         |
| 7       | 15641-88L10     | .SPACER                       | 1    |         |
| 8       | 15642-88L00     | .FILTER ASSY                  | 1    |         |
| 9       | 15650-99E00     | .FLOAT                        | 1    |         |
| 10      | 15654-88L00     | .PIN                          | 1    |         |
| 11      | 13684-99L00     | .HOSE, DRAIN (L:280)          | 1    |         |
| 12      | 15760-88L00     | .REGULATOR ASSY               | 1    |         |
| 13      | 15644-88L10     | .O RING                       | 1    |         |
| 14      | 15645-88L00     | .HOLDER, REGULATOR            | 1    |         |
| 15      | 13614-89J00     | .SCREW                        | 1    |         |
| 16      | 15648-92J00     | .RING                         | 1    |         |
| 17      | 15643-88L10     | .JOINT                        | 1    |         |
| 18      | 15641-88L31     | .BUSH                         | 1    |         |
| 19      | 15641-88L51     | .BUSH                         | 1    |         |
| 20      | 15642-88L10     | .FILTER                       | 1    |         |
| 21      | 15612-88L00     | .COVER, VAPOR SEPARATOR       | 1    |         |
| 22      | 15613-88L00     | .O RING                       | 1    |         |
| 23      | 15614-88L00     | .SCREW                        | 3    |         |
| 24      | 13614-93J00     | .SCREW                        | 1    |         |
| 25      | 15613-92J00     | .GASKET                       | 1    |         |
| 26      | 15620-99L10     | .CASE ASSY, VAPOR SEPARATOR   | 1    |         |
| 27      | 15610-92J00     | .CASE ASSY, VAPOR SEPARATOR   | 1    |         |
|         |                 | LWR                           |      |         |
| 28      | 09116-06517     | BOLT (6X25)                   | 3    |         |
| 29      | 09169-06090     | WASHER                        | 3    |         |
| 30      | 15691-92J00     | CUSHION, FUEL VAPOR SEPARATOR | 3    |         |
| 31      | 15660-99L00     | HOSE, EVAPORATION             | 1    |         |
| 32      | 36617-93J00     | BRACKET, HARNESS              | 1    |         |
| 33      | 36617-93J10     | BRACKET, HARNESS              | 2    |         |
| 34      | 09320-08517     | GROMMET                       | 2    |         |
| 35      | 09352-50003-065 | HOSE                          | 1    |         |

FIG.143B



DF140BG\_E11\_022\_143B  
FUEL VAPOR SEPARATOR

FIG.143B (1-B-14) FUEL VAPOR SEPARATOR (E40)

| REF NO. | PART NO.        | DESCRIPTION | Q'TY | REMARKS |
|---------|-----------------|-------------|------|---------|
| 36      | 09352-50003-120 | HOSE        | 1    |         |
| 37      | 09367-05004     | JOINT       | 1    |         |
| 38      | 09401-08412     | CLIP        | 5    |         |
| 39      | 09403-08329     | CLAMP       | 4    |         |
| 40      | 01550-0612C     | BOLT        | 3    |         |
| 41      | 09403-11321     | CLAMP       | 1    |         |

DF140BG\_E11\_022

FIG.144A




FIG.144A (1-C-2) FUEL INJECTOR (E11:021)

| REF NO. | PART NO.    | DESCRIPTION                 | Q'TY | REMARKS |
|---------|-------------|-----------------------------|------|---------|
| 1       | 15681-99L00 | HOSE, FUEL                  | 1    |         |
| 2       | 15710-99L00 | INJECTOR, FUEL              | 4    |         |
| 3       | 15716-65DT0 | .GROMMET SET, FUEL INJECTOR | 4    |         |
| 4       | 15423-99L00 | GUARD, FUEL HOSE            | 1    |         |
| 5       | 15751-99L00 | PIPE, DELIVERY              | 1    |         |
| 6       | 01550-0625C | BOLT                        | 2    |         |
| 7       | 09168-12013 | GASKET (11.8X22X1.2)        | 3    |         |
| 8       | 09320-08062 | CUSHION                     | 4    |         |
| 9       | 09360-12008 | UNION                       | 1    |         |
| 10      | 09363-08004 | UNION                       | 1    |         |
| 11      | 09401-11425 | CLIP                        | 2    |         |
| 12      | 01421-0820C | STUD BOLT                   | 2    |         |
| 13      | 01550-12167 | BOLT                        | 1    |         |
| 14      | 08316-1008C | NUT                         | 2    |         |

FIG.144B




FIG.144B (1-C-3) FUEL INJECTOR (E11:022)

| REF NO. | PART NO.    | DESCRIPTION                 | Q'TY | REMARKS |
|---------|-------------|-----------------------------|------|---------|
| 1       | 15681-99L10 | HOSE, FUEL                  | 1    |         |
| 2       | 15710-99L00 | INJECTOR, FUEL              | 4    |         |
| 3       | 15716-65DT0 | .GROMMET SET, FUEL INJECTOR | 4    |         |
| 4       | 15751-99L10 | PIPE, DELIVERY              | 1    |         |
| 5       | 09168-12013 | GASKET (11.8X22X1.2)        | 2    |         |
| 6       | 09320-08062 | CUSHION                     | 4    |         |
| 7       | 09401-11425 | CLIP                        | 2    |         |
| 8       | 01421-0820C | STUD BOLT                   | 2    |         |
| 9       | 01550-12167 | BOLT                        | 2    |         |
| 10      | 08316-1008C | NUT                         | 2    |         |
| 11      | 15830-99L00 | JOINT, FUEL MAIN            | 1    |         |
| 12      | 01550-0612C | BOLT                        | 1    |         |
| 13      | 09280-08012 | O RING                      | 1    |         |

FIG.144C




FIG.144C (1-C-4) FUEL INJECTOR (E40:021)

| REF NO. | PART NO.    | DESCRIPTION                 | Q'TY | REMARKS |
|---------|-------------|-----------------------------|------|---------|
| 1       | 15681-99L00 | HOSE, FUEL                  | 1    |         |
| 2       | 15710-99L00 | INJECTOR, FUEL              | 4    |         |
| 3       | 15716-65DT0 | .GROMMET SET, FUEL INJECTOR | 4    |         |
| 4       | 15423-99L00 | GUARD, FUEL HOSE            | 1    |         |
| 5       | 15751-99L00 | PIPE, DELIVERY              | 1    |         |
| 6       | 01550-0625C | BOLT                        | 2    |         |
| 7       | 15762-90J00 | GASKET, UNION               | 3    |         |
| 8       | 09320-08062 | CUSHION                     | 4    |         |
| 9       | 09360-12013 | UNION                       | 1    |         |
| 10      | 15830-90J00 | JOINT, FUEL MAIN            | 1    |         |
| 11      | 09401-11425 | CLIP                        | 2    |         |
| 12      | 01421-0820C | STUD BOLT                   | 2    |         |
| 13      | 09247-12013 | PLUG                        | 1    |         |
| 14      | 08316-1008C | NUT                         | 2    |         |

FIG.144D




FIG.144D (1-C-5) FUEL INJECTOR (E40:022)

| REF NO. | PART NO.    | DESCRIPTION                 | Q'TY | REMARKS |
|---------|-------------|-----------------------------|------|---------|
| 1       | 15681-99L10 | HOSE, FUEL                  | 1    |         |
| 2       | 15710-99L00 | INJECTOR, FUEL              | 4    |         |
| 3       | 15716-65DT0 | .GROMMET SET, FUEL INJECTOR | 4    |         |
| 4       | 15751-99L10 | PIPE, DELIVERY              | 1    |         |
| 5       | 15762-90J00 | GASKET, UNION               | 2    |         |
| 6       | 09320-08062 | CUSHION                     | 4    |         |
| 7       | 09401-11425 | CLIP                        | 2    |         |
| 8       | 01421-0820C | STUD BOLT                   | 2    |         |
| 9       | 09247-12013 | PLUG                        | 2    |         |
| 10      | 08316-1008C | NUT                         | 2    |         |
| 11      | 15830-99L10 | JOINT, FUEL MAIN            | 1    |         |
| 12      | 01550-0612C | BOLT                        | 1    |         |
| 13      | 09280-08012 | O RING                      | 1    |         |

FIG.146A




FIG.146A (1-C-6) FUEL PUMP

| REF NO. | PART NO.    | DESCRIPTION            | Q'TY |     | REMARKS |
|---------|-------------|------------------------|------|-----|---------|
| 1-1     | 15100-96J01 | PUMP ASSY, FUEL        | 1    | E11 |         |
| 1-2     | 15100-96J11 | PUMP ASSY, FUEL        | 1    | E40 |         |
| 2       | 15190-99L00 | HOSE, FUEL INLET       | 1    |     |         |
| 3       | 09251-07003 | CAP (OD:11.5)          | 1    |     |         |
| 4       | 15195-96L00 | HOSE, FUEL             | 1    |     |         |
| 5       | 15192-99L00 | HOSE, FUEL             | 1    |     |         |
| 6       | 15410-92J10 | FILTER, FUEL           | 1    |     |         |
| 7       | 15411-92J10 | .CAP, FUEL FILTER      | 1    |     |         |
| 8       | 15412-92J00 | .FILTER, FUEL          | 1    |     |         |
| 9       | 15413-92J00 | .CASE, FUEL FILTER     | 1    |     |         |
| 10      | 15415-92J00 | .SEAL, FUEL FILTER     | 1    |     |         |
| 11      | 15421-99L00 | BRACKET, FUEL FILTER   | 1    |     |         |
| 12      | 15195-96L10 | HOSE, FUEL             | 1    |     |         |
| 13      | 09280-33004 | O RING (D:3.1,ID:32.7) | 1    |     |         |
| 14      | 15193-99L00 | HOSE, FUEL             | 1    |     |         |
| 15      | 09403-12314 | CLAMP                  | 3    |     |         |
| 16      | 15831-96L00 | UNION, 2 WAY FUEL HOSE | 2    |     |         |
| 17      | 09401-14409 | CLIP                   | 6    |     |         |
| 18      | 09401-11006 | CLIP                   | 3    |     |         |
| 19      | 08316-1008C | NUT                    | 1    |     |         |
| 20      | 09103-06211 | BOLT (6X25)            | 2    |     |         |
| 21      | 01550-0616C | BOLT (6X16)            | 2    |     |         |

FIG.160A




FIG.160A (1-C-7) WATER PUMP (E11)

| REF NO. | PART NO.    | DESCRIPTION              | Q'TY | REMARKS      |
|---------|-------------|--------------------------|------|--------------|
| 1       | 17410-92J00 | CASE, WATER PUMP         | 1    |              |
| 2       | 17461-90J01 | IMPELLER, WATER PUMP     | 1    |              |
| 3       | 17471-92J00 | PANEL, PUMP CASE UNDER   | 1    |              |
| 4       | 17472-87E10 | GASKET, PUMP CASE PANEL  | 1    |              |
| 5-1     | 17561-90J03 | TUBE, WATER              | 1    | W/TRANSOM(L) |
| 5-2     | 17561-90J13 | TUBE, WATER              | 1    | W/TRANSOM(X) |
| 6       | 17562-90J01 | BUSH, WATER TUBE UPPER   | 1    |              |
| 7       | 17563-87D01 | BUSH, WATER TUBE LOWER   | 1    |              |
| 8       | 17564-87D00 | BUSH, WATER PUMP CASE    | 1    |              |
| 9       | 17631-90J00 | FILTER, WATER PORT SIDE  | 1    |              |
| 10      | 17632-90J00 | FILTER, WATER STBD SIDE  | 1    |              |
| 11      | 17635-90J00 | PLUG, SUB WATER TUBE     | 1    |              |
| 12      | 09116-08131 | BOLT (8X45)              | 4    |              |
| 13      | 09125-05046 | SCREW (5X12)             | 2    |              |
| 14      | 09161-16008 | WASHER (15.8X26X1.0)     | 2    |              |
| 15      | 09202-06031 | PIN (6X12)               | 2    |              |
| 16      | 09420-05009 | KEY                      | 1    |              |
| 17      | 09132-04034 | SCREW (4X18)             | 2    |              |
| 18      | 17413-92J01 | SLEEVE, WATER PUMP CASE  | 1    |              |
| 19      | 17416-92J11 | SEALING, WATER PUMP CASE | 1    |              |
| 20      | 17612-90J01 | SPACER, WATER TUBE       | 1    | W/TRANSOM(X) |
| 21      | 17400-92J23 | KIT, WATER PUMP REPAIR   | 1    | OPT          |
| 22      | 17500-90J11 | KIT, WATER SUB TUBE      | 1    | OPT          |
| 23      | 17520-90J00 | .TUBE, WATER SUB         | 1    | OPT          |
| 24      | 17563-87D01 | .BUSH, WATER TUBE LOWER  | 1    | OPT          |
| 25      | 17635-87E00 | .FILTER, WATER SUB       | 1    | OPT          |
| 26      | 55332-87D02 | .RUBBER, EXHAUST SEAL    | 1    | OPT          |
| 27      | 55333-87D02 | .PLATE, EXHAUST SEAL     | 1    | OPT          |
| 28      | 09125-06063 | .SCREW (6X10)            | 1    | OPT          |

FIG.160B




FIG.160B (1-C-8) WATER PUMP (E40)

| REF NO. | PART NO.    | DESCRIPTION              | Q'TY | REMARKS      |
|---------|-------------|--------------------------|------|--------------|
| 1       | 17410-92J00 | CASE, WATER PUMP         | 1    |              |
| 2       | 17461-90J01 | IMPELLER, WATER PUMP     | 1    |              |
| 3       | 17471-92J10 | PANEL, PUMP CASE UNDER   | 1    |              |
| 4       | 17472-87E10 | GASKET, PUMP CASE PANEL  | 1    |              |
| 5-1     | 17561-90J03 | TUBE, WATER              | 1    | W/TRANSOM(L) |
| 5-2     | 17561-90J13 | TUBE, WATER              | 1    | W/TRANSOM(X) |
| 6       | 17562-90J01 | BUSH, WATER TUBE UPPER   | 1    |              |
| 7       | 17563-87D01 | BUSH, WATER TUBE LOWER   | 1    |              |
| 8       | 17564-87D00 | BUSH, WATER PUMP CASE    | 1    |              |
| 9       | 17631-90J00 | FILTER, WATER PORT SIDE  | 1    |              |
| 10      | 17632-90J00 | FILTER, WATER STBD SIDE  | 1    |              |
| 11      | 17635-90J00 | PLUG, SUB WATER TUBE     | 1    |              |
| 12      | 09116-08131 | BOLT (8X45)              | 4    |              |
| 13      | 09125-05046 | SCREW (5X12)             | 2    |              |
| 14      | 09161-16008 | WASHER (15.8X26X1.0)     | 2    |              |
| 15      | 09202-06031 | PIN (6X12)               | 2    |              |
| 16      | 09420-05009 | KEY                      | 1    |              |
| 17      | 09132-04034 | SCREW (4X18)             | 2    |              |
| 18      | 17413-92J11 | SLEEVE, WATER PUMP CASE  | 1    |              |
| 19      | 17416-92J11 | SEALING, WATER PUMP CASE | 1    |              |
| 20      | 17612-90J01 | SPACER, WATER TUBE       | 1    | W/TRANSOM(X) |
| 21      | 17400-92J11 | KIT, WATER PUMP REPAIR   | 1    | OPT          |
| 22      | 17500-90J11 | KIT, WATER SUB TUBE      | 1    | OPT          |
| 23      | 17520-90J00 | .TUBE, WATER SUB         | 1    | OPT          |
| 24      | 17563-87D01 | .BUSH, WATER TUBE LOWER  | 1    | OPT          |
| 25      | 17635-87E00 | .FILTER, WATER SUB       | 1    | OPT          |
| 26      | 55332-87D02 | .RUBBER, EXHAUST SEAL    | 1    | OPT          |
| 27      | 55333-87D02 | .PLATE, EXHAUST SEAL     | 1    | OPT          |
| 28      | 09125-06063 | .SCREW (6X10)            | 1    | OPT          |

FIG.162A




FIG.162A (1-C-9) THERMOSTAT

| REF NO. | PART NO.        | DESCRIPTION              | Q'TY | REMARKS                       |
|---------|-----------------|--------------------------|------|-------------------------------|
| 1       | 11196-99L00     | HOSE, WATER RETURN       | 1    |                               |
| 2       | 17611-90J00     | COVER, WTR PRESS VALVE   | 1    |                               |
| 3       | 17660-98L01     | VALVE, WATER PRESSURE    | 1    |                               |
| 4-1     | 17670-90J01     | THERMOSTAT, WATER        | 1    |                               |
| 4-2     | 17670-90J11     | THERMOSTAT, WATER 71 DEG | 1    | OPT                           |
| 5       | 17681-99L00     | COVER, THERMOSTAT        | 1    |                               |
| 6       | 17711-90J00     | 3WAY, WATER HOSE         | 1    |                               |
| 7       | 09116-06121     | BOLT (6X25)              | 2    |                               |
| 8       | 09280-26006     | O RING (D:3.1,ID:26.4)   | 1    |                               |
| 9       | 09352-11154-050 | HOSE (L:50)              | 1    | L:50,HOLDER TO 3 WAY          |
| 10      | 17712-99L00     | HOSE, WATER              | 1    | L:120,3WAY TO SEPARATOR       |
| 11      | 09352-50006-600 | HOSE (5X9X600)           | 1    | L:600->220,3WAY TO CRKC LOWER |
| 12      | 17915-99L00     | HOSE, FLUSH              | 1    |                               |
| 13      | 17710-99L00     | HOSE, WATER              | 1    |                               |
| 14      | 17581-99L00     | PIPE, WATER OUTLET       | 1    |                               |
| 15      | 09280-26006     | O RING (D:3.1,ID:26.4)   | 1    |                               |
| 16      | 09401-15414     | CLIP                     | 2    |                               |
| 17      | 09401-08413     | CLIP                     | 5    |                               |
| 18      | 09401-14409     | CLIP                     | 2    |                               |
| 19      | 09401-31407     | CLIP                     | 2    |                               |
| 20      | 01550-0620C     | BOLT                     | 1    |                               |
| 21      | 01550-0620C     | BOLT                     | 3    |                               |
| 22      | 01550-0655C     | BOLT                     | 1    |                               |
| 23      | 09403-12420     | CLAMP                    | 2    |                               |
| 24      | 09403-16416     | CLAMP                    | 1    |                               |
| 25      | 09408-00056     | CLIP                     | 2    |                               |
| 26      | 09408-00174     | CLAMP                    | 1    |                               |
| 27      | 09408-00175     | CLAMP                    | 1    |                               |
| 28      | 01550-0612C     | BOLT                     | 2    |                               |
| 29      | 01550-0612C     | BOLT                     | 1    |                               |

FIG.163A

FIG.163A (1-C-10) THROTTLE BODY

| REF NO. | PART NO.    | DESCRIPTION            | Q'TY | REMARKS |
|---------|-------------|------------------------|------|---------|
| 1       | 13300-99L00 | BODY ASSY, THROTTLE    | 1    |         |
| 2       | 13315-99L01 | BRACKET, THROTTLE BODY | 1    |         |
| 3       | 01550-0820C | BOLT                   | 2    |         |
| 4       | 01550-0860C | BOLT                   | 4    |         |




FIG.175A




FIG.175A (1-C-11) OIL PUMP

| REF NO. | PART NO.    | DESCRIPTION                  | Q'TY | REMARKS |
|---------|-------------|------------------------------|------|---------|
| 1       | 12632-92J12 | GEAR, OIL PUMP DRIVE (NT:41) | 1    |         |
| 2       | 16113-92J11 | GEAR, OIL PUMP DRIVE (NT:20) | 1    |         |
| 3       | 16400-99L00 | PUMP ASSY, OIL               | 1    |         |
| 4       | 16440-99E01 | VALVE ASSY, OIL RELIEF       | 1    |         |
| 5       | 16520-90J00 | STRAINER, OIL PUMP           | 1    |         |
| 6       | 09168-16002 | GASKET (16X22X2)             | 1    |         |
| 7       | 09181-12158 | SHIM (12X20X0.5)             | 1    |         |
| 8       | 09261-05006 | PIN (5X18)                   | 1    |         |
| 9       | 09280-22020 | O RING (D:2.4,ID:21.8)       | 2    |         |
| 10      | 01547-0625A | BOLT                         | 1    |         |
| 11      | 01547-0635A | BOLT                         | 2    |         |
| 12      | 01550-0616A | BOLT                         | 3    |         |
| 13      | 08331-3112A | CIRCLIP                      | 1    |         |
| 14      | 16510-61A31 | FILTER ASSY, OIL             | 1    |         |
| 15      | 11241-73003 | STAND, OIL FILTER            | 1    |         |
| 16      | 16531-99L00 | CASE, OIL FILTER ADAPTER     | 1    |         |
| 17      | 16539-99L01 | GASKET, OIL FILTER ADAPTER   | 1    |         |
| 18      | 01550-0825C | CASE<br>BOLT                 | 2    |         |

FIG.180A




FIG.180A (1-C-12) OIL PAN

| REF NO. | PART NO.        | DESCRIPTION                        | Q'TY | REMARKS             |
|---------|-----------------|------------------------------------|------|---------------------|
| 1       | 11489-90J10     | GASKET, OIL PAN                    | 1    |                     |
| 2-1     | 11501-90J20-YAY | PAN, OIL (BLACK)                   | 1    | FOR YAY             |
| 2-2     | 11501-90J20-QTN | PAN, OIL (WHITE)                   | 1    | FOR QTN             |
| 2-3     | 11501-90J20-YAY | PAN, OIL (BLACK)                   | 1    | FOR QTN<br>SEE NOTE |
| 3       | 17913-93J00     | PLUG, WATER                        | 1    |                     |
| 4       | 43112-99E00     | PIPE, EXHAUST                      | 1    |                     |
| 5       | 61150-99E01     | COVER ASSY, WATER INDICATOR        | 1    |                     |
| 6       | 09280-09016     | .O RING (ID:8.8,D:1.9)             | 1    |                     |
| 7       | 61155-99E01     | TUBE, WATER INDICATOR              | 1    |                     |
| 8       | 09116-08178     | BOLT (8X40)                        | 3    |                     |
| 9       | 09116-10129     | BOLT (10X160)                      | 8    |                     |
| 10      | 09168-12012     | GASKET (12.5X20X2.5)               | 1    |                     |
| 11      | 09248-12009     | PLUG (12X18.65)                    | 1    | OIL DRAIN           |
| 12      | 17914-93J01     | GASKET, WATER PLUG                 | 1    |                     |
| 13      | 16910-99L00     | GAUGE, OIL LEVEL                   | 1    |                     |
| 14      | 16930-99L00     | GUIDE, OIL LEVEL GAUGE             | 1    |                     |
| 15      | 09280-21015     | O RING (D:2.7,ID:21.4)             | 1    |                     |
| 16      | 01550-0616C     | BOLT (6X16)                        | 1    |                     |
| 17      | 16934-99L00     | CASE, OIL LEVEL GUIDE              | 1    |                     |
| 18      | 16941-99L00     | GASKET, OIL LVL GAGE GUIDE<br>CASE | 1    |                     |
| 19      | 01550-0625C     | BOLT                               | 4    |                     |

NOTE : FROM 11505F-140066, FROM 11505Z-140001,  
FROM 14004F-140476, FROM 14004Z-140067

FIG.204A




FIG.204A (1-C-13) CLUTCH SHAFT

| REF NO. | PART NO.    | DESCRIPTION                   | Q'TY | REMARKS      |
|---------|-------------|-------------------------------|------|--------------|
| 1       | 11118-95J00 | PLUG, NOTCH SPRING            | 1    |              |
| 2       | 19110-99L01 | HOLDER, CLUTCH                | 1    |              |
| 3       | 21110-99L00 | LEVER, CLUTCH                 | 1    |              |
| 4       | 21151-99L00 | HOLDER, CLUTCH LEVER          | 1    |              |
| 5       | 21155-99L00 | HOLDER, SHIFT LEVER           | 1    |              |
| 6       | 21210-99L00 | SHAFT, CLUTCH                 | 1    |              |
| 7       | 21230-99L00 | ARM, CLUTCH SHAFT             | 1    |              |
| 8       | 21241-99L00 | ROD, CLUTCH LEVER             | 1    |              |
| 9       | 22511-99011 | NIPPLE, GREASE                | 1    |              |
| 10-1    | 23111-90J02 | ROD, CLUTCH                   | 1    | W/TRANSOM(L) |
| 10-2    | 23111-90J12 | ROD, CLUTCH                   | 1    | W/TRANSOM(X) |
| 11      | 23115-99L00 | LINK, CLUTCH LEVER            | 1    |              |
| 12      | 67467-89J01 | CONNECTOR                     | 1    |              |
| 13      | 67467-89J10 | CONNECTOR, REMOCON CABLE NO.2 | 1    |              |
| 14      | 67471-99E00 | NUT, REMOCON CABLE            | 1    |              |
| 15      | 67471-99E10 | NUT, REMOCON CABLE NO.2       | 1    |              |
| 16      | 09160-06055 | WASHER (7X12X1.0)             | 2    |              |
| 17      | 09160-06094 | WASHER (6.5X15X1.0)           | 2    |              |
| 18      | 09204-01006 | PIN                           | 2    |              |
| 19      | 09204-01006 | PIN                           | 2    |              |
| 20      | 09206-11019 | PIN                           | 2    |              |
| 21      | 09248-12011 | PLUG (12X9)                   | 1    |              |
| 22      | 09260-10005 | BALL                          | 1    |              |
| 23      | 09306-06004 | BUSH                          | 2    |              |
| 24      | 09306-10022 | BUSH                          | 1    |              |
| 25      | 09306-12014 | BUSH                          | 2    |              |
| 26      | 09383-08005 | E RING                        | 1    |              |
| 27      | 09440-07071 | SPRING                        | 1    |              |
| 28      | 01550-0616C | BOLT (6X16)                   | 1    |              |
| 29      | 01550-0825C | BOLT                          | 1    |              |
| 30      | 01550-0830C | BOLT                          | 2    |              |
| 31      | 01550-0855C | BOLT                          | 1    |              |
| 32      | 01550-0880C | BOLT                          | 1    |              |
| 33      | 08331-41359 | CIRCLIP                       | 1    |              |



FIG.210A




FIG.210A (1-C-14) SHIFT ROD (DF115BG,DF140BG)

| REF NO. | PART NO.    | DESCRIPTION                   | Q'TY | REMARKS      |
|---------|-------------|-------------------------------|------|--------------|
| 1       | 25131-92J01 | YOKE, SHIFTER                 | 1    |              |
| 2       | 25141-92J01 | HOUSING, SHIFT ROD GUIDE      | 1    |              |
| 3       | 25222-90J01 | COVER, SFT GUIDE HSG OIL SEAL | 1    |              |
| 4       | 25232-90J00 | MAGNET, GEAR CASE             | 2    |              |
| 5       | 25321-92J10 | SLIDER, SHIFT HORIZONTAL      | 1    |              |
| 6-1     | 25111-92J00 | ROD, SHIFT                    | 1    | W/TRANSOM(L) |
| 6-2     | 25111-92J10 | ROD, SHIFT                    | 1    | W/TRANSOM(X) |
| 7       | 41226-97E00 | BUSH, TILT LOCK LEVER         | 1    |              |
| 8       | 29116-93J00 | BOLT (6X20)                   | 2    |              |
| 9       | 09205-04014 | SPRING PIN (4X14)             | 2    |              |
| 10      | 09280-69001 | O RING (D:3.1,ID:68.5)        | 1    |              |
| 11      | 09283-10011 | OIL SEAL (10X22X8)            | 2    |              |

FIG.210B




FIG.210B (1-D-2) SHIFT ROD (DF115BZG,DF140BZG)

| REF NO. | PART NO.    | DESCRIPTION                   | Q'TY | REMARKS      |
|---------|-------------|-------------------------------|------|--------------|
| 1       | 25131-92J01 | YOKE, SHIFTER                 | 1    |              |
| 2       | 25141-92J01 | HOUSING, SHIFT ROD GUIDE      | 1    |              |
| 3       | 25222-90J01 | COVER, SFT GUIDE HSG OIL SEAL | 1    |              |
| 4       | 25232-90J00 | MAGNET, GEAR CASE             | 2    |              |
| 5       | 25321-92J20 | SLIDER, SHIFT HORIZONTAL      | 1    |              |
| 6-1     | 25111-92J00 | ROD, SHIFT                    | 1    | W/TRANSOM(L) |
| 6-2     | 25111-92J10 | ROD, SHIFT                    | 1    | W/TRANSOM(X) |
| 7       | 41226-97E00 | BUSH, TILT LOCK LEVER         | 1    |              |
| 8       | 29116-93J00 | BOLT (6X20)                   | 2    |              |
| 9       | 09205-04014 | SPRING PIN (4X14)             | 2    |              |
| 10      | 09280-69001 | O RING (D:3.1,ID:68.5)        | 1    |              |
| 11      | 09283-10011 | OIL SEAL (10X22X8)            | 2    |              |

FIG.220A




FIG.220A (1-D-3) TRANSMISSION (DF115BG,DF140BG)

| REF NO. | PART NO.    | DESCRIPTION                  | Q'TY | REMARKS          |
|---------|-------------|------------------------------|------|------------------|
| 1-1     | 57110-92J60 | SHAFT, DRIVE                 | 1    | W/TRANSOM(L)     |
| 1-2     | 57110-92J70 | SHAFT, DRIVE                 | 1    | W/TRANSOM(X)     |
| 2       | 57133-90J02 | COLLAR, DRIVE SHAFT          | 1    |                  |
| 3       | 09164-31001 | WASHER                       | 1    | DRIVE SHAFT WAVE |
| 4       | 09169-31001 | WASHER                       | 1    | DRIVE SHAFT NO.1 |
| 5       | 09181-31001 | SHIM (31X46X2)               | 3    | DRIVE SHAFT NO.2 |
| 6       | 09265-25046 | BEARING (25X52X19.25)        | 1    |                  |
| 7       | 57300-99L10 | GEAR SET (NT:25)             | 1    |                  |
| 8       | 09140-14024 | NUT                          | 1    |                  |
| 9       | 57500-87873 | SHIM SET, DRIVE SHAFT        | 1    |                  |
| 10-1    | 09181-40186 | .SHIM (T:0.50)               | 1    |                  |
| 10-2    | 09181-41002 | .SHIM (T:0.55)               | 1    |                  |
| 10-3    | 09181-41003 | .SHIM (T:0.60)               | 1    |                  |
| 10-4    | 09181-41004 | .SHIM (T:0.65)               | 1    |                  |
| 10-5    | 09181-41005 | .SHIM (T:0.70)               | 1    |                  |
| 10-6    | 09181-41006 | .SHIM (T:0.75)               | 1    |                  |
| 10-7    | 09181-40190 | .SHIM (T:0.80)               | 1    |                  |
| 10-8    | 09181-41008 | .SHIM (T:0.85)               | 1    |                  |
| 10-9    | 09181-41009 | .SHIM (T:0.90)               | 1    |                  |
| 10-10   | 09181-41010 | .SHIM (T:0.95)               | 1    |                  |
| 10-11   | 09181-40195 | .SHIM (T:1.00)               | 1    |                  |
| 10-12   | 09181-41012 | .SHIM (T:1.05)               | 1    |                  |
| 10-13   | 09181-41013 | .SHIM (T:1.10)               | 1    |                  |
| 10-14   | 09181-41014 | .SHIM (T:1.15)               | 1    |                  |
| 11      | 57500-87861 | SHIM SET, REVERSE PROP SHAFT | 1    |                  |
| 12-1    | 08211-30382 | .WASHER (T:1.5)              | 1    |                  |
| 12-2    | 09160-30036 | .WASHER (T:1.7)              | 1    |                  |
| 12-3    | 09160-30037 | .WASHER (T:1.9)              | 1    |                  |
| 12-4    | 09160-30038 | .WASHER (T:2.1)              | 1    |                  |
| 12-5    | 09160-30039 | .WASHER (T:2.3)              | 1    |                  |
| 12-6    | 09160-30041 | .WASHER (T:2.4)              | 1    |                  |
| 12-7    | 09160-30042 | .WASHER (T:2.6)              | 1    |                  |
| 12-8    | 09160-30043 | .WASHER (T:2.7)              | 1    |                  |
| 12-9    | 09160-30044 | .WASHER (T:2.8)              | 1    |                  |
| 13      | 09160-70002 | WASHER (70X95X5.25)          | 1    | FWD GEAR         |

FIG.220A




FIG.220A (1-D-4) TRANSMISSION (DF115BG,DF140BG)

| REF NO. | PART NO.    | DESCRIPTION                | Q'TY | REMARKS  |
|---------|-------------|----------------------------|------|----------|
| 14-1    | 09181-45003 | SHIM (T:1.0)               | 1    | REV GEAR |
| 14-2    | 09181-45004 | SHIM (T:1.1)               | 1    | REV GEAR |
| 14-3    | 09181-45005 | SHIM (T:1.2)               | 1    | REV GEAR |
| 14-4    | 09181-45006 | SHIM (T:1.3)               | 1    | REV GEAR |
| 14-5    | 09181-45007 | SHIM (T:1.4)               | 1    | REV GEAR |
| 14-6    | 09181-45008 | SHIM (T:1.5)               | 1    | REV GEAR |
| 14-7    | 09181-45009 | SHIM (T:1.6)               | 1    | REV GEAR |
| 14-8    | 09181-45013 | SHIM (T:1.35)              | 1    | REV GEAR |
| 14-9    | 09181-45014 | SHIM (T:1.45)              | 1    | REV GEAR |
| 14-10   | 09181-45015 | SHIM (T:1.55)              | 1    | REV GEAR |
| 14-11   | 09181-45016 | SHIM (T:1.65)              | 1    | REV GEAR |
| 14-12   | 09181-45017 | SHIM (T:1.70)              | 1    | REV GEAR |
| 14-13   | 09181-45018 | SHIM (T:1.75)              | 1    | REV GEAR |
| 15      | 57500-92813 | SHIM SET, FORWARD GEAR     | 1    | FWD GEAR |
| 16-1    | 09181-70001 | .SHIM (T:0.70)             | 1    | FWD GEAR |
| 16-2    | 09181-70002 | .SHIM (T:0.80)             | 1    | FWD GEAR |
| 16-3    | 09181-70003 | .SHIM (T:0.90)             | 1    | FWD GEAR |
| 16-4    | 09181-70004 | .SHIM (T:1.00)             | 1    | FWD GEAR |
| 16-5    | 09181-70006 | .SHIM (T:0.60)             | 1    | FWD GEAR |
| 16-6    | 09181-70009 | .SHIM (T:0.65)             | 1    | FWD GEAR |
| 16-7    | 09181-70010 | .SHIM (T:0.75)             | 1    | FWD GEAR |
| 16-8    | 09181-70011 | .SHIM (T:0.85)             | 1    | FWD GEAR |
| 16-9    | 09181-70012 | .SHIM (T:0.95)             | 1    | FWD GEAR |
| 16-10   | 09181-70008 | .SHIM (T:0.55)             | 1    | FWD GEAR |
| 17      | 09269-70001 | BEARING (70X95X4)          | 1    |          |
| 18      | 57610-99L00 | SHAFT ASSY, PROPELLER      | 1    |          |
| 19      | 57621-99L00 | SHIFTER, CLUTCH DOG        | 1    |          |
| 20      | 09202-07002 | PIN (7X48)                 | 1    |          |
| 21      | 57631-92J10 | PIN, CONNECTOR             | 1    |          |
| 22      | 09440-09040 | SPRING                     | 1    |          |
| 23      | 06111-07004 | BALL                       | 2    | NO.1     |
| 24      | 06111-11004 | BALL                       | 2    | NO.2     |
| 25      | 09440-49004 | SPRING                     | 1    |          |
| 26      | 57616-90J00 | SPACER, CLUTCH DOG FORWARD | 1    |          |

FIG.220A




FIG.220A (1-D-5) TRANSMISSION (DF115BG,DF140BG)

| REF NO. | PART NO.        | DESCRIPTION                        | Q'TY | REMARKS |
|---------|-----------------|------------------------------------|------|---------|
| 27-1    | 56120-92J01-YAY | HOUSING, PROP SHAFT BRG<br>(BLACK) | 1    |         |
| 27-2    | 56120-92J01-QTN | HOUSING, PROP SHAFT BRG<br>(WHITE) | 1    |         |
| 28      | 56123-92J00     | .WASHER, OIL SEAL PROTECTOR        | 1    |         |
| 29      | 09263-30051     | .BEARING (30X37X26)                | 1    |         |
| 30      | 09280-97001     | .O RING (D:3.5,ID:95)              | 1    |         |
| 31      | 09282-30007     | .OIL SEAL (30X50X6)                | 2    |         |
| 32      | 08113-62090     | .BEARING                           | 1    |         |
| 33      | 09387-52001     | .RING SET                          | 1    |         |
| 34      | 09116-08122     | BOLT (8X30)                        | 2    |         |
| 35      | 56130-90J00     | HSG, DRIVE SHAFT OIL SEAL          | 1    |         |
| 36      | 09280-46004     | .O RING (D:3.5,ID:45.7)            | 1    |         |
| 37      | 09282-24004     | .OIL SEAL (24X40X7)                | 2    |         |
| 38      | 09117-08110     | BOLT (8X25)                        | 4    |         |
| 39      | 56140-92J00     | HOUSING, FWD GEAR BEARING          | 1    |         |
| 40      | 09206-09012     | .PIN (7.4X9X10)                    | 1    |         |
| 41      | 09263-50001     | .BEARING (50X62X25)                | 1    |         |

FIG.220B




FIG.220B (1-D-6) TRANSMISSION (DF115BZG,DF140BZG)

| REF NO. | PART NO.        | DESCRIPTION                        | Q'TY | REMARKS          |
|---------|-----------------|------------------------------------|------|------------------|
| 1-1     | 56120-92J12-YAY | HOUSING, PROP SHAFT BRG<br>(BLACK) | 1    |                  |
| 1-2     | 56120-92J12-QTN | HOUSING, PROP SHAFT BRG<br>(WHITE) | 1    |                  |
| 2       | 56123-92J00     | .WASHER, OIL SEAL PROTECTOR        | 1    |                  |
| 3       | 09263-30051     | .BEARING (30X37X26)                | 1    |                  |
| 4       | 09263-50001     | .BEARING (50X62X25)                | 1    |                  |
| 5       | 09280-97001     | .O RING (D:3.5,ID:95)              | 1    |                  |
| 6       | 09282-30007     | .OIL SEAL (30X50X6)                | 2    |                  |
| 7       | 09387-52001     | .RING SET                          | 1    |                  |
| 8       | 56130-90J00     | HSG, DRIVE SHAFT OIL SEAL          | 1    |                  |
| 9       | 09280-46004     | .O RING (D:3.5,ID:45.7)            | 1    |                  |
| 10      | 09282-24004     | .OIL SEAL (24X40X7)                | 2    |                  |
| 11      | 56140-92J30     | HOUSING, REV GEAR BEARING          | 1    |                  |
| 12      | 09206-09012     | .PIN (7.4X9X10)                    | 1    |                  |
| 13      | 09263-45004     | .BEARING (45X52X16)                | 1    |                  |
| 14      | 09116-08122     | BOLT (8X30)                        | 2    |                  |
| 15      | 09117-08110     | BOLT (8X25)                        | 4    |                  |
| 16-1    | 57110-92J60     | SHAFT, DRIVE                       | 1    | W/TRANSOM(L)     |
| 16-2    | 57110-92J70     | SHAFT, DRIVE                       | 1    | W/TRANSOM(X)     |
| 17      | 57133-90J02     | COLLAR, DRIVE SHAFT                | 1    |                  |
| 18      | 09164-31001     | WASHER                             | 1    | DRIVE SHAFT WAVE |
| 19      | 09169-31001     | WASHER                             | 1    | DRIVE SHAFT NO.1 |
| 20      | 09181-31001     | SHIM (31X46X2)                     | 3    | DRIVE SHAFT NO.2 |
| 21      | 09265-25046     | BEARING (25X52X19.25)              | 1    |                  |
| 22      | 57300-99L30     | PINION/GEAR SET (NT:25)            | 1    |                  |
| 23      | 09140-14024     | NUT                                | 1    |                  |
| 24      | 57500-87873     | SHIM SET, DRIVE SHAFT              | 1    |                  |

FIG.220B




FIG.220B (1-D-7) TRANSMISSION (DF115BZG,DF140BZG)

| REF NO. | PART NO.    | DESCRIPTION      | Q'TY | REMARKS       |
|---------|-------------|------------------|------|---------------|
| 25-1    | 09181-40186 | .SHIM (T:0.50)   | 1    |               |
| 25-2    | 09181-41002 | .SHIM (T:0.55)   | 1    |               |
| 25-3    | 09181-41003 | .SHIM (T:0.60)   | 1    |               |
| 25-4    | 09181-41004 | .SHIM (T:0.65)   | 1    |               |
| 25-5    | 09181-41005 | .SHIM (T:0.70)   | 1    |               |
| 25-6    | 09181-41006 | .SHIM (T:0.75)   | 1    |               |
| 25-7    | 09181-40190 | .SHIM (T:0.80)   | 1    |               |
| 25-8    | 09181-41008 | .SHIM (T:0.85)   | 1    |               |
| 25-9    | 09181-41009 | .SHIM (T:0.90)   | 1    |               |
| 25-10   | 09181-41010 | .SHIM (T:0.95)   | 1    |               |
| 25-11   | 09181-40195 | .SHIM (T:1.00)   | 1    |               |
| 25-12   | 09181-41012 | .SHIM (T:1.05)   | 1    |               |
| 25-13   | 09181-41013 | .SHIM (T:1.10)   | 1    |               |
| 25-14   | 09181-41014 | .SHIM (T:1.15)   | 1    |               |
| 26-1    | 09160-35015 | WASHER (T:0.6)   | 1    | PROP SAFT REV |
| 26-2    | 09160-35014 | WASHER (T:0.70)  | 1    | PROP SAFT REV |
| 26-3    | 09160-35013 | WASHER (T:0.8)   | 1    | PROP SAFT REV |
| 26-4    | 09160-35006 | WASHER (T:0.90)  | 1    | PROP SAFT REV |
| 26-5    | 09160-35008 | WASHER (T:0.95)  | 1    | PROP SAFT REV |
| 26-6    | 09160-35002 | WASHER (T:1.00)  | 1    | PROP SAFT REV |
| 26-7    | 09160-35009 | WASHER (T:1.05)  | 1    | PROP SAFT REV |
| 26-8    | 09160-35003 | WASHER (T:1.10)  | 1    | PROP SAFT REV |
| 26-9    | 09160-35010 | WASHER (T:1.15)  | 1    | PROP SAFT REV |
| 27      | 09160-60011 | WASHER (60X85X3) | 1    | REV GEAR      |
| 28-1    | 09160-60008 | WASHER (T:0.8)   | 1    | REV GEAR      |
| 28-2    | 09160-60009 | WASHER (T:0.9)   | 1    | REV GEAR      |
| 28-3    | 09160-60003 | WASHER (T:1.0)   | 1    | REV GEAR      |
| 28-4    | 09160-60004 | WASHER (T:1.1)   | 1    | REV GEAR      |
| 28-5    | 09160-60005 | WASHER (T:1.2)   | 1    | REV GEAR      |
| 28-6    | 09160-60006 | WASHER (T:1.3)   | 1    | REV GEAR      |
| 28-7    | 09160-60007 | WASHER (T:1.4)   | 1    | REV GEAR      |
| 28-8    | 09160-60013 | WASHER (T:0.55)  | 1    | REV GEAR      |
| 28-9    | 09160-60014 | WASHER (T:0.60)  | 1    | REV GEAR      |
| 28-10   | 09160-60015 | WASHER (T:0.65)  | 1    | REV GEAR      |
| 28-11   | 09160-60016 | WASHER (T:0.70)  | 1    | REV GEAR      |
| 28-12   | 09160-60017 | WASHER (T:0.75)  | 1    | REV GEAR      |

Exploded view diagram of a mechanical assembly, likely a fuel injector or pump, showing various components numbered 1 through 42. The diagram includes a main assembly view and several sub-assembly views. A 'FWD' arrow is present in the bottom left corner.

Key components and their numbers:

- 1**: Main housing or body.
- 2**: Spring.
- 3**: O-ring or seal.
- 4**: Needle or plunger tip.
- 5**: Needle or plunger body.
- 6**: O-ring or seal.
- 7**: Spring.
- 8**: Spring.
- 9**: O-ring or seal.
- 10**: O-ring or seal.
- 11**: Needle or plunger body.
- 12**: Needle or plunger tip.
- 13**: O-ring or seal.
- 14**: Bolt or screw.
- 15**: Bolt or screw.
- 16**: Needle or plunger body.
- 17**: Spring.
- 18**: O-ring or seal.
- 19**: O-ring or seal.
- 20**: O-ring or seal.
- 21**: O-ring or seal.
- 22**: Needle or plunger body.
- 23**: Needle or plunger tip.
- 24**: Spring.
- 25**: O-ring or seal.
- 26**: Spring.
- 27**: O-ring or seal.
- 28**: O-ring or seal.
- 29**: O-ring or seal.
- 30**: O-ring or seal.
- 31**: O-ring or seal.
- 32**: O-ring or seal.
- 33**: O-ring or seal.
- 34**: Needle or plunger body.
- 35**: Needle or plunger tip.
- 36**: Needle or plunger body.
- 37**: Spring.
- 38**: O-ring or seal.
- 39**: O-ring or seal.
- 40**: Needle or plunger body.
- 41**: Needle or plunger tip.
- 42**: Needle or plunger body.

| REF NO. | PART NO.    | DESCRIPTION                | QTY | REMARKS       |
|---------|-------------|----------------------------|-----|---------------|
| 28-13   | 09160-60018 | WASHER (T:0.85)            | 1   | REV GEAR      |
| 28-14   | 09160-60019 | WASHER (T:0.95)            | 1   | REV GEAR      |
| 28-15   | 09160-60020 | WASHER (T:1.05)            | 1   | REV GEAR      |
| 29      | 09160-70005 | WASHER (70X95X2)           | 1   | FWD GEAR      |
| 30      | 57500-92813 | SHIM SET, FORWARD GEAR     | 1   | FWD GEAR      |
| 31-1    | 09181-70006 | .SHIM (T:0.60)             | 1   | FWD GEAR      |
| 31-2    | 09181-70009 | .SHIM (T:0.65)             | 1   | FWD GEAR      |
| 31-3    | 09181-70001 | .SHIM (T:0.70)             | 1   | FWD GEAR      |
| 31-4    | 09181-70010 | .SHIM (T:0.75)             | 1   | FWD GEAR      |
| 31-5    | 09181-70002 | .SHIM (T:0.80)             | 1   | FWD GEAR      |
| 31-6    | 09181-70011 | .SHIM (T:0.85)             | 1   | FWD GEAR      |
| 31-7    | 09181-70003 | .SHIM (T:0.90)             | 1   | FWD GEAR      |
| 31-8    | 09181-70012 | .SHIM (T:0.95)             | 1   | FWD GEAR      |
| 31-9    | 09181-70004 | .SHIM (T:1.00)             | 1   | FWD GEAR      |
| 31-10   | 09181-70008 | .SHIM (T:0.55)             | 1   | FWD GEAR      |
| 32      | 09269-60001 | BEARING (60X85X3)          | 1   | REV           |
| 33      | 09269-70001 | BEARING (70X95X4)          | 1   | FWD           |
| 34      | 57610-99L10 | SHAFT, PROPELLER           | 1   |               |
| 35      | 57621-99L00 | SHIFTER, CLUTCH DOG        | 1   |               |
| 36      | 57631-92J10 | PIN, CONNECTOR             | 1   |               |
| 37      | 09440-09040 | SPRING                     | 1   |               |
| 38      | 06111-07004 | BALL                       | 2   | NO.1          |
| 39      | 06111-11004 | BALL                       | 2   | NO.2          |
| 40      | 09202-07002 | PIN (7X48)                 | 1   |               |
| 41      | 09440-49004 | SPRING                     | 1   |               |
| 42      | 57616-92J00 | SPACER, CLUTCH DOG FORWARD | 1   |               |
| 43      | 09160-30055 | WASHER (30X47X6)           | 1   | PROP SAFT REV |
| 44      | 09160-30056 | WASHER (32X47X3)           | 1   | PROP SAFT REV |
| 45      | 09269-30014 | BEARING (30X47X2)          | 1   | PROP SAFT REV |

FIG.301A




FIG.301A (1-D-9) STARTING MOTOR

| REF NO. | PART NO.    | DESCRIPTION                 | Q'TY | REMARKS |
|---------|-------------|-----------------------------|------|---------|
| 1       | 31100-92J00 | MOTOR ASSY, STARTING        | 1    |         |
| 2       | 31150-92J00 | .HOUSING, FRONT             | 1    |         |
| 3       | 31170-92J00 | .HOUSING, REAR              | 1    |         |
| 4       | 31173-92J00 | .HOLDER ASSY, BRUSH         | 1    |         |
| 5       | 31191-92J00 | .LEVER, SHIFT               | 1    |         |
| 6       | 31192-92J00 | .SCREW SET                  | 1    |         |
| 7       | 31220-92J00 | .SWITCH ASSY                | 1    |         |
| 8       | 31261-75F10 | .BOLT                       | 2    |         |
| 9       | 31311-63J00 | .ARMATURE                   | 1    |         |
| 10      | 31340-92J00 | .CLUTCH SET, STARTING MOTOR | 1    |         |
| 11      | 31312-92J00 | ..SET, PINION STOPPER       | 1    |         |
| 12      | 31320-92J00 | ..PINION                    | 1    |         |
| 13      | 31341-92J00 | ..SHAFT, PINION             | 1    |         |
| 14      | 31343-63J00 | ..INTERNAL GEAR ASSY        | 1    |         |
| 15      | 31344-63J00 | ..GEAR ASSY                 | 3    |         |
| 16      | 31912-90J00 | BAND, STARTING MOTOR        | 1    |         |
| 17      | 31918-92J01 | DAMPER, LOWER               | 1    |         |
| 18      | 01550-08207 | BOLT                        | 2    |         |
| 19      | 01550-1050C | BOLT                        | 2    |         |
| 20      | 04211-13149 | PIN                         | 2    |         |

**FIG.303A (1-D-10) MAGNETO**




FIG.310A




FIG.310A (1-D-11) RECTIFIER/IGNITION COIL

| REF NO. | PART NO.    | DESCRIPTION                | Q'TY | REMARKS |
|---------|-------------|----------------------------|------|---------|
| 1       | 33410-99L00 | COIL ASSY, IGNITION        | 4    |         |
| 2       | 01550-0620C | BOLT                       | 4    |         |
| 3       | 11261-87E10 | COVER, PROTECTION ANODE    | 2    |         |
| 4       | 11265-87E10 | GASKET, PROTECTION COVER   | 2    |         |
| 5-1     | 55321-87J01 | ANODE, PROTECTION          | 2    |         |
| 5-2     | 55321-87J11 | ANODE (MAGNESIUM)          | 1    | OPT     |
| 6       | 09103-06281 | BOLT (6X14)                | 2    |         |
| 7       | 14151-90J00 | GASKET, RECT & REGULATOR   | 1    |         |
| 8       | 36616-99L20 | HOLDER, CONNECTOR          | 1    |         |
| 9       | 36617-88L00 | BRACKET, PTT CABLE CLAMP   | 1    |         |
| 10      | 32800-99L00 | RECTIFIER & REGULATOR ASSY | 1    |         |
| 11      | 32890-99L00 | HOLDER, ELECTRIC PARTS     | 1    |         |
| 12      | 09160-06084 | WASHER (6.5X18X1.6)        | 1    |         |
| 13      | 09320-10075 | CUSHION                    | 2    |         |
| 14      | 09320-09016 | CUSHION                    | 1    |         |
| 15      | 09169-06062 | WASHER                     | 1    |         |
| 16      | 09329-01007 | CUSHION                    | 1    |         |
| 17      | 29404-93J11 | CLAMP                      | 2    |         |
| 18      | 01550-06257 | BOLT                       | 1    |         |
| 19      | 01550-0620C | BOLT                       | 4    |         |
| 20      | 01550-0630C | BOLT                       | 9    |         |
| 21      | 01550-0612C | BOLT                       | 3    |         |
| 22      | 09116-06517 | BOLT (6X25)                | 2    |         |
| 23      | 09169-06062 | WASHER                     | 2    |         |
| 24      | 09320-09016 | CUSHION                    | 2    |         |

FIG.315A




FIG.315A (1-D-12) SENSOR (021)

| REF NO. | PART NO.    | DESCRIPTION                  | Q'TY | REMARKS            |
|---------|-------------|------------------------------|------|--------------------|
| 1       | 13650-52G00 | SENSOR, INLET AIR TEMP       | 1    |                    |
| 2       | 13655-87J01 | GROMMET, INLET AIR TEMP SNSR | 1    |                    |
| 3       | 18590-59S00 | SENSOR ASSY, PRESSURE        | 1    |                    |
| 4       | 34830-87J20 | SENSOR, TEMP                 | 2    |                    |
| 5       | 18640-98L01 | SENSOR ASSY, KNOCK           | 1    |                    |
| 6       | 34840-98J03 | SENSOR ASSY, TRIM & TILT     | 1    |                    |
| 7       | 18213-98J30 | SENSOR, OXYGEN               | 1    |                    |
| 8       | 34841-92J00 | LEVER, TRIM SENSOR           | 1    |                    |
| 9       | 34842-92J01 | CAM, TRIM SENSOR UPPER       | 1    |                    |
| 10      | 34843-87L00 | CAM, TRIM SENSOR LOWER       | 1    |                    |
| 11      | 34846-87L00 | WASHER, TRIM SENSOR          | 1    |                    |
| 12      | 37820-99E02 | SWITCH ASSY, OIL PRESSURE    | 1    |                    |
| 13      | 34845-92J00 | BRACKET, TRIM SENSOR         | 1    |                    |
| 14      | 02162-05207 | SCREW                        | 1    |                    |
| 15      | 09103-06093 | BOLT (6X20)                  | 1    |                    |
| 16      | 09125-05046 | SCREW (5X12)                 | 1    |                    |
| 17      | 09407-10404 | CLAMP (L:100)                | 1    |                    |
| 18      | 36617-93J10 | BRACKET, HARNESS             | 1    | KNOCK SENSOR LEAD  |
| 19      | 09407-14407 | CLAMP (L:145)                | 2    |                    |
| 20      | 09407-18402 | CLAMP (L:165)                | 1    | OXYGEN SENSOR LEAD |
| 21      | 29103-93J00 | BOLT (6X12)                  | 1    |                    |
| 22      | 09403-13413 | CLAMP                        | 1    | PTT CABLE          |
| 23      | 09403-07340 | CLAMP                        | 1    | KNOCK SENSOR LEAD  |
| 24      | 09403-11321 | CLAMP                        | 1    | PTT CABLE          |

FIG.315B





FIG.315B (1-D-13) SENSOR (022)

| REF NO. | PART NO.    | DESCRIPTION                  | Q'TY | REMARKS            |
|---------|-------------|------------------------------|------|--------------------|
| 1       | 13650-52G00 | SENSOR, INLET AIR TEMP       | 1    |                    |
| 2       | 13655-87J01 | GROMMET, INLET AIR TEMP SNSR | 1    |                    |
| 3       | 18590-59S00 | SENSOR ASSY, PRESSURE        | 1    |                    |
| 4       | 34830-87J20 | SENSOR, TEMP                 | 2    |                    |
| 5       | 18640-98L01 | SENSOR ASSY, KNOCK           | 1    |                    |
| 6       | 34840-98J03 | SENSOR ASSY, TRIM & TILT     | 1    |                    |
| 7       | 18213-98J30 | SENSOR, OXYGEN               | 1    |                    |
| 8       | 34841-92J00 | LEVER, TRIM SENSOR           | 1    |                    |
| 9       | 34842-92J01 | CAM, TRIM SENSOR UPPER       | 1    |                    |
| 10      | 34843-87L00 | CAM, TRIM SENSOR LOWER       | 1    |                    |
| 11      | 34846-87L00 | WASHER, TRIM SENSOR          | 1    |                    |
| 12      | 37820-99E02 | SWITCH ASSY, OIL PRESSURE    | 1    |                    |
| 13      | 34845-92J00 | BRACKET, TRIM SENSOR         | 1    |                    |
| 14      | 09103-05028 | SCREW                        | 1    |                    |
| 15      | 09103-06093 | BOLT (6X20)                  | 1    |                    |
| 16      | 09125-05046 | SCREW (5X12)                 | 1    |                    |
| 17      | 09407-10404 | CLAMP (L:100)                | 1    |                    |
| 18      | 36617-93J10 | BRACKET, HARNESS             | 1    | KNOCK SENSOR LEAD  |
| 19      | 09407-14407 | CLAMP (L:145)                | 2    |                    |
| 20      | 09407-18402 | CLAMP (L:165)                | 1    | OXYGEN SENSOR LEAD |
| 21      | 29103-93J00 | BOLT (6X12)                  | 1    |                    |
| 22      | 09403-13413 | CLAMP                        | 1    | PTT CABLE          |
| 23      | 09403-07340 | CLAMP                        | 1    | KNOCK SENSOR LEAD  |
| 24      | 09403-11321 | CLAMP                        | 1    | PTT CABLE          |

**FIG.322A (1-D-14) HARNESS ((DF115BG,DF115BZG):021)**



DF140BG\_E11\_022

FIG.322A




FIG.322A (1-D-15) HARNESS ((DF115BG,DF115BZG):021)

| REF NO. | PART NO.    | DESCRIPTION       | Q'TY | REMARKS  |
|---------|-------------|-------------------|------|----------|
| 29-1    | 09403-13311 | CLAMP             | 1    |          |
| 29-2    | 09403-20308 | CLAMP             | 1    | SEE NOTE |
| 30      | 09408-00213 | CLAMP             | 1    |          |
| 31      | 09169-06053 | WASHER (6.3X16X1) | 2    |          |

NOTE : FROM 11505F-140492, FROM 11505Z-140037

FIG.322B




FIG.322B (1-E-2) HARNESS ((DF115BG,DF115BZG):022)

| REF NO. | PART NO.    | DESCRIPTION               | Q'TY | REMARKS     |
|---------|-------------|---------------------------|------|-------------|
| 1       | 33810-90J30 | CABLE ASSY, STARTER MOTOR | 1    |             |
| 2       | 08316-10087 | NUT                       | 1    |             |
| 3       | 36616-99L01 | HOLDER, CABLE             | 1    |             |
| 4       | 36616-99L10 | HOLDER, CONNECTOR         | 1    |             |
| 5       | 01550-0616C | BOLT (6X16)               | 3    |             |
| 6       | 02142-0616C | SCREW (6X16)              | 2    |             |
| 7       | 36610-99L50 | HARNESS ASSY, WIRING      | 1    |             |
| 8       | 36618-43410 | .CAP, OIL PRESSURE SWITCH | 1    |             |
| 9       | 09320-08510 | .CUSHION (8.5X20X8)       | 2    |             |
| 10      | 01500-06167 | .BOLT                     | 1    |             |
| 11      | 08310-00067 | .NUT                      | 1    | UPPER       |
| 12      | 38860-76F01 | .RELAY ASSY               | 1    | FOR MAIN    |
| 13      | 38860-76F01 | .RELAY ASSY               | 1    | FOR STARTER |
| 14      | 09481-10504 | .FUSE (10A)               | 2    |             |
| 15      | 09481-15504 | .FUSE (15A)               | 4    |             |
| 16      | 09481-30504 | .FUSE (30A)               | 3    |             |
| 17      | 09481-60403 | .FUSE (60A)               | 3    |             |
| 18      | 36617-88L00 | BRACKET, PTT CABLE CLAMP  | 1    |             |
| 19      | 36617-93J10 | BRACKET, HARNESS          | 8    |             |
| 20      | 36612-96J01 | CAP, TERMINAL             | 1    |             |
| 21      | 08321-01067 | LOCK WASHER               | 1    |             |
| 22      | 08310-00067 | NUT                       | 1    |             |
| 23      | 36617-93J00 | BRACKET, HARNESS          | 1    |             |
| 24      | 36611-99L00 | HARNESS ASSY, WIRING SUB  | 1    |             |
| 25      | 01550-0612C | BOLT                      | 10   |             |
| 26      | 09403-11321 | CLAMP                     | 2    |             |
| 27      | 09407-14403 | CLAMP (L:125)             | 3    |             |
| 28      | 09403-20308 | CLAMP                     | 1    |             |
| 29      | 09408-00213 | CLAMP                     | 1    |             |
| 30      | 09169-06053 | WASHER (6.3X16X1)         | 2    |             |

FIG.322C




FIG.322C (1-E-3) HARNESS ((DF140BG,DF140BZG):021)

| REF NO. | PART NO.    | DESCRIPTION               | Q'TY | REMARKS                                |
|---------|-------------|---------------------------|------|----------------------------------------|
| 1       | 33810-90J30 | CABLE ASSY, STARTER MOTOR | 1    |                                        |
| 2       | 08316-10087 | NUT                       | 1    |                                        |
| 3-1     | 36616-99L00 | HOLDER, CABLE             | 1    | ->36616-99L01<br>USED WITH 09403-20308 |
| 3-2     | 36616-99L01 | HOLDER, CABLE             | 1    | SEE NOTE                               |
| 4       | 36616-99L10 | HOLDER, CONNECTOR         | 1    |                                        |
| 5       | 01550-0616C | BOLT (6X16)               | 3    |                                        |
| 6       | 02142-0616C | SCREW (6X16)              | 2    |                                        |
| 7       | 36610-99L00 | HARNESS ASSY, WIRING      | 1    |                                        |
| 8       | 33634-96J00 | .CAP, SERVICE CONNECTOR   | 1    |                                        |
| 9       | 36618-43410 | .CAP, OIL PRESSURE SWITCH | 1    |                                        |
| 10      | 09320-08510 | .CUSHION (8.5X20X8)       | 2    |                                        |
| 11      | 01500-06167 | .BOLT                     | 1    |                                        |
| 12      | 08310-00067 | .NUT                      | 1    | UPPER                                  |
| 13      | 38860-76F01 | .RELAY ASSY               | 1    | FOR MAIN                               |
| 14      | 38860-76F01 | .RELAY ASSY               | 1    | FOR STARTER                            |
| 15      | 09481-10504 | .FUSE (10A)               | 2    |                                        |
| 16      | 09481-15504 | .FUSE (15A)               | 4    |                                        |
| 17      | 09481-30504 | .FUSE (30A)               | 3    |                                        |
| 18      | 09481-60403 | .FUSE (60A)               | 3    |                                        |
| 19      | 36617-88L00 | BRACKET, PTT CABLE CLAMP  | 1    |                                        |
| 20      | 36617-93J10 | BRACKET, HARNESS          | 8    |                                        |
| 21      | 36612-96J01 | CAP, TERMINAL             | 1    |                                        |
| 22      | 08321-01067 | LOCK WASHER               | 1    |                                        |
| 23      | 08310-00067 | NUT                       | 1    |                                        |
| 24      | 36617-93J00 | BRACKET, HARNESS          | 1    |                                        |
| 25      | 36611-99L00 | HARNESS ASSY, WIRING SUB  | 1    |                                        |
| 26      | 01550-0612C | BOLT                      | 10   |                                        |
| 27      | 09403-11321 | CLAMP                     | 2    |                                        |
| 28      | 09407-14403 | CLAMP (L:125)             | 3    |                                        |

NOTE : FROM 14004F-140813, FROM 14004Z-140102

FIG.322C




FIG.322C (1-E-4) HARNESS ((DF140BG,DF140BZG):021)

| REF NO. | PART NO.    | DESCRIPTION       | Q'TY | REMARKS  |
|---------|-------------|-------------------|------|----------|
| 29-1    | 09403-13311 | CLAMP             | 1    |          |
| 29-2    | 09403-20308 | CLAMP             | 1    | SEE NOTE |
| 30      | 09408-00213 | CLAMP             | 1    |          |
| 31      | 09169-06053 | WASHER (6.3X16X1) | 2    |          |

NOTE : FROM 14004F-140813, FROM 14004Z-140102

FIG.322D




FIG.322D (1-E-5) HARNESS ((DF140BG,DF140BZG):022)

| REF NO. | PART NO.    | DESCRIPTION               | Q'TY | REMARKS     |
|---------|-------------|---------------------------|------|-------------|
| 1       | 33810-90J30 | CABLE ASSY, STARTER MOTOR | 1    |             |
| 2       | 08316-10087 | NUT                       | 1    |             |
| 3       | 36616-99L01 | HOLDER, CABLE             | 1    |             |
| 4       | 36616-99L10 | HOLDER, CONNECTOR         | 1    |             |
| 5       | 01550-0616C | BOLT (6X16)               | 3    |             |
| 6       | 02142-0616C | SCREW (6X16)              | 2    |             |
| 7       | 36610-99L40 | HARNESS ASSY, WIRING      | 1    |             |
| 8       | 36618-43410 | .CAP, OIL PRESSURE SWITCH | 1    |             |
| 9       | 09320-08510 | .CUSHION (8.5X20X8)       | 2    |             |
| 10      | 01500-06167 | .BOLT                     | 1    |             |
| 11      | 08310-00067 | .NUT                      | 1    | UPPER       |
| 12      | 38860-76F01 | .RELAY ASSY               | 1    | FOR MAIN    |
| 13      | 38860-76F01 | .RELAY ASSY               | 1    | FOR STARTER |
| 14      | 09481-10504 | .FUSE (10A)               | 2    |             |
| 15      | 09481-15504 | .FUSE (15A)               | 4    |             |
| 16      | 09481-30504 | .FUSE (30A)               | 3    |             |
| 17      | 09481-60403 | .FUSE (60A)               | 3    |             |
| 18      | 36617-88L00 | BRACKET, PTT CABLE CLAMP  | 1    |             |
| 19      | 36617-93J10 | BRACKET, HARNESS          | 8    |             |
| 20      | 36612-96J01 | CAP, TERMINAL             | 1    |             |
| 21      | 08321-01067 | LOCK WASHER               | 1    |             |
| 22      | 08310-00067 | NUT                       | 1    |             |
| 23      | 36617-93J00 | BRACKET, HARNESS          | 1    |             |
| 24      | 36611-99L00 | HARNESS ASSY, WIRING SUB  | 1    |             |
| 25      | 01550-0612C | BOLT                      | 10   |             |
| 26      | 09403-11321 | CLAMP                     | 2    |             |
| 27      | 09407-14403 | CLAMP (L:125)             | 3    |             |
| 28      | 09403-20308 | CLAMP                     | 1    |             |
| 29      | 09408-00213 | CLAMP                     | 1    |             |
| 30      | 09169-06053 | WASHER (6.3X16X1)         | 2    |             |

FIG.326A





FIG.326A (1-E-6) PTT SWITCH/ENGINE CONTROL UNIT (SEE NOTE)

| REF NO. | PART NO.    | DESCRIPTION                  | Q'TY | REMARKS |
|---------|-------------|------------------------------|------|---------|
| 1       | 13580-98J03 | SENSOR ASSY, SHIFT POSITION  | 1    |         |
| 2       | 13575-40F00 | .O RING                      | 1    |         |
| 3       | 36617-87L20 | CLAMP, HARNESS               | 1    |         |
| 4       | 37721-93J00 | SWITCH ASSY, NEUTRAL         | 1    |         |
| 5       | 37724-99L00 | ARM, NEUTRAL SWITCH          | 1    |         |
| 6       | 37726-99L00 | BRACKET, NEUTRAL SWITCH      | 1    |         |
| 7       | 37850-92J00 | SWITCH ASSY, PTT             | 1    |         |
| 8       | 37856-92J00 | .TAPE, PTT SWITCH            | 1    |         |
| 9       | 37857-92J01 | BUSH, PTT SWITCH             | 1    |         |
| 10      | 09160-05029 | WASHER (5.5X12X0.8)          | 1    |         |
| 11      | 09403-11321 | CLAMP                        | 1    |         |
| 12      | 09407-10404 | CLAMP (L:100)                | 1    |         |
| 13      | 09407-14407 | CLAMP (L:145)                | 1    |         |
| 14      | 09448-10006 | SPRING                       | 1    |         |
| 15      | 01550-0612C | BOLT                         | 1    |         |
| 16      | 02122-04167 | SCREW                        | 2    |         |
| 17      | 07130-05167 | BOLT                         | 1    |         |
| 18      | 08321-0105C | WASHER                       | 1    |         |
| 19      | 38410-93J21 | RELAY ASSY, PTT              | 1    |         |
| 20      | 38415-93J20 | HOLDER, PTT RELAY            | 1    |         |
| 21-1    | 33920-99L10 | UNIT, ENGINE CONTROL         | 1    | 021     |
| 21-2    | 33920-99L60 | UNIT, ENGINE CONTROL         | 1    | 022     |
| 22      | 33925-99L00 | CUSHION, ENGINE CONTROL UNIT | 1    |         |
| 23      | 38890-99L00 | ACTUATOR ASSY, SHIFT         | 1    |         |
| 24      | 38892-98J01 | DAMPER, SHIFT ACTUATOR       | 1    |         |
| 25      | 38895-99L00 | BRACKET, SHIFT ACTUATOR      | 1    |         |
| 26      | 01550-0616C | BOLT (6X16)                  | 2    |         |
| 27      | 01550-0620C | BOLT                         | 1    |         |
| 28      | 01550-06357 | BOLT                         | 1    |         |
| 29      | 01550-0655C | BOLT                         | 1    |         |
| 30      | 38860-76F01 | RELAY ASSY                   | 2    |         |
| 31      | 38915-90J00 | HOLDER, RELAY                | 2    |         |

NOTE : DF115BG,DF115BZG

FIG.326B



DF140BG\_E11\_022\_326B  
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326B (1-E-7) PTT SWITCH/ENGINE CONTROL UNIT (SEE NOTE 1)

| REF NO. | PART NO.    | DESCRIPTION                  | Q'TY | REMARKS    |
|---------|-------------|------------------------------|------|------------|
| 1       | 13580-98J03 | SENSOR ASSY, SHIFT POSITION  | 1    |            |
| 2       | 13575-40F00 | .O RING                      | 1    |            |
| 3       | 36617-87L20 | CLAMP, HARNESS               | 1    |            |
| 4       | 37721-93J00 | SWITCH ASSY, NEUTRAL         | 1    |            |
| 5       | 37724-99L00 | ARM, NEUTRAL SWITCH          | 1    |            |
| 6       | 37726-99L00 | BRACKET, NEUTRAL SWITCH      | 1    |            |
| 7       | 37850-92J00 | SWITCH ASSY, PTT             | 1    |            |
| 8       | 37856-92J00 | .TAPE, PTT SWITCH            | 1    |            |
| 9       | 37857-92J01 | BUSH, PTT SWITCH             | 1    |            |
| 10      | 09160-05029 | WASHER (5.5X12X0.8)          | 1    |            |
| 11      | 09403-11321 | CLAMP                        | 1    |            |
| 12      | 09407-10404 | CLAMP (L:100)                | 1    |            |
| 13-1    | 09407-14407 | CLAMP (L:145)                | 2    |            |
| 13-2    | 09407-14407 | CLAMP (L:145)                | 1    | SEE NOTE 2 |
| 14      | 09448-10006 | SPRING                       | 1    |            |
| 15      | 01550-0612C | BOLT                         | 1    |            |
| 16      | 02122-04167 | SCREW                        | 2    |            |
| 17      | 07130-05167 | BOLT                         | 1    |            |
| 18      | 08321-0105C | WASHER                       | 1    |            |
| 19      | 38410-93J21 | RELAY ASSY, PTT              | 1    |            |
| 20      | 38415-93J20 | HOLDER, PTT RELAY            | 1    |            |
| 21-1    | 33920-99L00 | UNIT, ENGINE CONTROL         | 1    | 021        |
| 21-2    | 33920-99L50 | UNIT, ENGINE CONTROL         | 1    | 022        |
| 22      | 33925-99L00 | CUSHION, ENGINE CONTROL UNIT | 1    |            |
| 23      | 38890-99L00 | ACTUATOR ASSY, SHIFT         | 1    |            |
| 24      | 38892-98J01 | DAMPER, SHIFT ACTUATOR       | 1    |            |
| 25      | 38895-99L00 | BRACKET, SHIFT ACTUATOR      | 1    |            |
| 26      | 01550-0616C | BOLT (6X16)                  | 2    |            |
| 27      | 01550-0620C | BOLT                         | 1    |            |
| 28      | 01550-06357 | BOLT                         | 1    |            |

NOTE 1 : DF140BG,DF140BZG

NOTE 2 : FROM 14004F-140054, FROM 14004Z-140010

FIG.326B




FIG.326B (1-E-8) PTT SWITCH/ENGINE CONTROL UNIT (SEE NOTE 1)

| REF NO. | PART NO.    | DESCRIPTION   | Q'TY | REMARKS |
|---------|-------------|---------------|------|---------|
| 29      | 01550-0655C | BOLT          | 1    |         |
| 30      | 38860-76F01 | RELAY ASSY    | 2    |         |
| 31      | 38915-90J00 | HOLDER, RELAY | 2    |         |

NOTE 1 : DF140BG,DF140BZG




FIG.331A




FIG.331A (1-E-9) KEY LESS START (E11:021)

| REF NO. | PART NO.    | DESCRIPTION                   | Q'TY | REMARKS     |
|---------|-------------|-------------------------------|------|-------------|
| 1       | 32851-93J00 | CUSHION, LEAD WIRE            | 1    |             |
| 2       | 32980-38F00 | CUSHION, CDI UNIT             | 1    |             |
| 3       | 36623-96L02 | HARNESS ASSY, KLS CONTROLLER  | 1    |             |
| 4       | 36615-96300 | .TERMINAL                     | 1    |             |
| 5       | 36662-96L01 | HARNESS ASSY, KLS CAN         | 1    | L:6500+2000 |
| 6       | 37117-96L00 | DECAL, KLS                    | 2    |             |
| 7-1     | 37171-96L02 | CONTROLLER ASSY, KLS (433MHZ) | 1    |             |
| 7-2     | 37171-96L12 | CONTROLLER ASSY, KLS (315MHZ) | 1    |             |
| 8-1     | 37172-96L02 | REMOCON ASSY, KLS (433MHZ)    | 2    |             |
| 8-2     | 37172-96L11 | REMOCON ASSY, KLS (315MHZ)    | 2    |             |
| 9       | 37173-96L10 | HOLDER, KLS PARTS             | 1    |             |
| 10      | 38500-93J90 | BUZZER, WARNING               | 1    |             |
| 11      | 38860-96L01 | RELAY ASSY, KLS               | 1    |             |
| 12      | 09407-14407 | CLAMP (L:145)                 | 1    |             |

FIG.331B




FIG.331B (1-E-10) KEY LESS START (E11:022)

| REF NO. | PART NO.    | DESCRIPTION                       | Q'TY | REMARKS |
|---------|-------------|-----------------------------------|------|---------|
| 1       | 32851-93J00 | CUSHION, LEAD WIRE                | 1    |         |
| 2       | 32980-38F00 | CUSHION, CDI UNIT                 | 1    |         |
| 3       | 36623-98LA0 | HARNESS ASSY, KLS CONT            | 1    |         |
| 4       | 36615-96300 | .TERMINAL                         | 1    |         |
| 5       | 37117-96L00 | DECAL, KLS                        | 2    |         |
| 6-1     | 37171-98L00 | CONTROLLER ASSY, KLS 433 (433MHZ) | 1    |         |
| 6-2     | 37171-98L10 | CONTROLLER ASSY, KLS 315 (315MHZ) | 1    |         |
| 7-1     | 37172-96L02 | REMOCON ASSY, KLS (433MHZ)        | 2    |         |
| 7-2     | 37172-96L11 | REMOCON ASSY, KLS (315MHZ)        | 2    |         |
| 8       | 37173-96L10 | HOLDER, KLS PARTS                 | 1    |         |
| 9       | 38500-93J90 | BUZZER, WARNING                   | 1    |         |
| 10      | 38860-96L01 | RELAY ASSY, KLS                   | 1    |         |
| 11      | 09407-14407 | CLAMP (L:145)                     | 1    |         |

FIG.335A




FIG.335A (1-E-11) CLAMP BRACKET (DF115BG,DF115BZG)

| REF NO. | PART NO.        | DESCRIPTION                 | Q'TY | REMARKS |
|---------|-----------------|-----------------------------|------|---------|
| 1-1     | 41111-90J13-YAY | BRACKET, CLAMP STBD (BLACK) | 1    | FOR YAY |
| 1-2     | 41111-90J13-QTN | BRACKET, CLAMP STBD (WHITE) | 1    | FOR QTN |
| 2-1     | 41121-90J21-YAY | BRACKET, CLAMP PORT (BLACK) | 1    | FOR YAY |
| 2-2     | 41121-90J21-QTN | BRACKET, CLAMP PORT (WHITE) | 1    | FOR QTN |
| 3       | 41130-92J30     | SHAFT, CLAMP BRACKET        | 1    |         |
| 4       | 55320-94900     | ANODE SET, CLAMP BRACKET    | 1    |         |
| 5       | 09116-06121     | .BOLT (6X25)                | 2    |         |
| 6-1     | 09100-12091     | BOLT (12X115)               | 4    |         |
| 6-2     | 09100-12090     | BOLT (12X150)               | 1    | OPT     |
| 7       | 09159-12014     | NUT                         | 4    |         |
| 8       | 09159-22006     | NUT                         | 1    |         |
| 9       | 09160-12128     | WASHER (12.5X35X3)          | 4    |         |
| 10      | 09160-12110     | WASHER (12.5X22X3)          | 4    |         |
| 11      | 41135-92J00     | WASHER, CLAMP BRACKET SHAFT | 1    |         |
| 12      | 09106-10065     | BOLT (10X20)                | 2    |         |
| 13      | 09160-10082     | WASHER (10.5X19X2.0)        | 2    |         |
| 14      | 09116-08137     | BOLT (8X22)                 | 1    |         |
| 15      | 45421-90J00     | PIN, TILT LOCK              | 1    | OPT     |
| 16      | 09159-14020     | NUT                         | 2    | OPT     |
| 17      | 55321-94910     | ANODE (MAGNESIUM)           | 1    | OPT     |

FIG.335B




FIG.335B (1-E-12) CLAMP BRACKET (DF140BG,DF140BZG)

| REF NO. | PART NO.        | DESCRIPTION                 | Q'TY | REMARKS |
|---------|-----------------|-----------------------------|------|---------|
| 1-1     | 41111-92J03-YAY | BRACKET, CLAMP STBD (BLACK) | 1    | FOR YAY |
| 1-2     | 41111-92J03-QTN | BRACKET, CLAMP STBD (WHITE) | 1    | FOR QTN |
| 2-1     | 41121-92J21-YAY | BRACKET, CLAMP PORT (BLACK) | 1    | FOR YAY |
| 2-2     | 41121-92J21-QTN | BRACKET, CLAMP PORT (WHITE) | 1    | FOR QTN |
| 3       | 41130-92J30     | SHAFT, CLAMP BRACKET        | 1    |         |
| 4       | 41135-92J00     | WASHER, CLAMP BRACKET SHAFT | 1    |         |
| 5       | 55320-94900     | ANODE SET, CLAMP BRACKET    | 1    |         |
| 6       | 09116-06121     | .BOLT (6X25)                | 2    |         |
| 7-1     | 09100-12091     | BOLT (12X115)               | 4    |         |
| 7-2     | 09100-12090     | BOLT (12X150)               | 1    | OPT     |
| 8       | 09116-08137     | BOLT (8X22)                 | 1    |         |
| 9       | 09159-12014     | NUT                         | 4    |         |
| 10      | 09159-22006     | NUT                         | 1    |         |
| 11      | 09160-12128     | WASHER (12.5X35X3)          | 4    |         |
| 12      | 09160-12110     | WASHER (12.5X22X3)          | 4    |         |
| 13      | 09106-10065     | BOLT (10X20)                | 2    |         |
| 14      | 09160-10082     | WASHER (10.5X19X2.0)        | 2    |         |
| 15      | 45421-87D03     | PIN, TILT LOCK              | 1    |         |
| 16      | 09159-14020     | NUT                         | 2    |         |
| 17      | 55321-94910     | ANODE (MAGNESIUM)           | 1    | OPT     |

FIG.336A




FIG.336A (1-E-13) SWIVEL BRACKET (DF115BG,DF115BZG)

| REF NO. | PART NO.        | DESCRIPTION               | Q'TY | REMARKS                 |
|---------|-----------------|---------------------------|------|-------------------------|
| 1-1     | 22511-99011     | NIPPLE, GREASE            | 5    | W/TRANSOM(L)            |
| 1-2     | 22511-99011     | NIPPLE, GREASE            | 4    | W/TRANSOM(X)            |
| 2       | 36894-95201     | LEAD (L:165)              | 1    |                         |
| 3       | 36894-87D00     | LEAD (L:165)              | 1    |                         |
| 4-1     | 43111-90J40-YAY | BRACKET, SWIVEL (BLACK)   | 1    | W/TRANSOM(L)<br>FOR YAY |
| 4-2     | 43111-90J40-QTN | BRACKET, SWIVEL (WHITE)   | 1    | W/TRANSOM(L)<br>FOR QTN |
| 4-3     | 43111-90J50-YAY | BRACKET, SWIVEL (BLACK)   | 1    | W/TRANSOM(X)<br>FOR YAY |
| 4-4     | 43111-90J50-QTN | BRACKET, SWIVEL (WHITE)   | 1    | W/TRANSOM(X)<br>FOR QTN |
| 5       | 43211-93J11     | BUSH, CLAMP SHAFT SWIVEL  | 2    |                         |
| 6       | 43711-97E11     | BUSH, STEERING            | 2    |                         |
| 7-1     | 43750-90J61-YAY | BRACKET, STEERING (BLACK) | 1    | W/TRANSOM(L)<br>FOR YAY |
| 7-2     | 43750-90J61-QTN | BRACKET, STEERING (WHITE) | 1    | W/TRANSOM(L)<br>FOR QTN |
| 7-3     | 43750-90J71-YAY | BRACKET, STEERING (BLACK) | 1    | W/TRANSOM(X)<br>FOR YAY |
| 7-4     | 43750-90J71-QTN | BRACKET, STEERING (WHITE) | 1    | W/TRANSOM(X)<br>FOR QTN |
| 8       | 09125-05050     | SCREW (5X8)               | 3    |                         |
| 9       | 36895-87D10     | LEAD (L:310)              | 1    |                         |
| 10      | 09160-39001     | WASHER (39.5X64X1.0)      | 2    |                         |
| 11      | 09169-28003     | WASHER                    | 2    |                         |
| 12      | 09181-39001     | SHIM (39.5X64X0.30)       | 4    |                         |
| 13      | 09250-10001     | CAP (OD:14)               | 2    |                         |
| 14      | 09282-39001     | OIL SEAL (39X51X5)        | 1    |                         |
| 15      | 09380-38003     | CIRCLIP                   | 1    |                         |
| 16      | 09440-19028     | SPRING                    | 1    |                         |
| 17      | 41220-95E13     | LEVER, TILT LOCK          | 1    |                         |
| 18      | 41221-95E40     | LEVER, TILT LOCK PORT     | 1    |                         |
| 19      | 41224-95E01     | BUSH, TILT STOPPER ROD    | 2    |                         |
| 20      | 41225-94401     | RUBBER, TILT LOCK LEVER   | 1    |                         |
| 21      | 41228-90J00     | SPRING, TILT LOCK LEVER   | 1    |                         |

FIG.336A




FIG.336A (1-E-14) SWIVEL BRACKET (DF115BG,DF115BZG)

| REF NO. | PART NO.    | DESCRIPTION               | Q'TY | REMARKS |
|---------|-------------|---------------------------|------|---------|
| 22      | 41230-95E00 | LINK, TILT LOCK LEVER     | 1    |         |
| 23      | 41233-95E10 | BRACKET, TILT LOCK SPRING | 1    |         |
| 24      | 09125-06063 | SCREW (6X10)              | 1    |         |
| 25      | 09140-10032 | NUT                       | 1    |         |
| 26      | 09160-06082 | WASHER (6.5X13X1.0)       | 1    |         |
| 27      | 09204-01006 | PIN                       | 1    |         |
| 28      | 09125-06063 | SCREW (6X10)              | 1    |         |
| 29      | 09125-06063 | SCREW (6X10)              | 1    |         |

FIG.336B




FIG.336B (1-F-2) SWIVEL BRACKET (DF140BG,DF140BZG)

| REF NO. | PART NO.        | DESCRIPTION               | Q'TY | REMARKS                 |
|---------|-----------------|---------------------------|------|-------------------------|
| 1       | 22511-99011     | NIPPLE, GREASE            | 4    |                         |
| 2       | 36894-95201     | LEAD (L:165)              | 1    |                         |
| 3       | 36894-87D00     | LEAD (L:165)              | 1    |                         |
| 4-1     | 43111-92J80-YAY | BRACKET, SWIVEL (BLACK)   | 1    | W/TRANSOM(L)<br>FOR YAY |
| 4-2     | 43111-92J80-QTN | BRACKET, SWIVEL (WHITE)   | 1    | W/TRANSOM(L)<br>FOR QTN |
| 4-3     | 43111-92J90-YAY | BRACKET, SWIVEL (BLACK)   | 1    | W/TRANSOM(X)<br>FOR YAY |
| 4-4     | 43111-92J90-QTN | BRACKET, SWIVEL (WHITE)   | 1    | W/TRANSOM(X)<br>FOR QTN |
| 5       | 43211-93J11     | BUSH, CLAMP SHAFT SWIVEL  | 2    |                         |
| 6       | 43711-97E11     | BUSH, STEERING            | 2    |                         |
| 7-1     | 43750-90J61-YAY | BRACKET, STEERING (BLACK) | 1    | W/TRANSOM(L)<br>FOR YAY |
| 7-2     | 43750-90J61-QTN | BRACKET, STEERING (WHITE) | 1    | W/TRANSOM(L)<br>FOR QTN |
| 7-3     | 43750-90J71-YAY | BRACKET, STEERING (BLACK) | 1    | W/TRANSOM(X)<br>FOR YAY |
| 7-4     | 43750-90J71-QTN | BRACKET, STEERING (WHITE) | 1    | W/TRANSOM(X)<br>FOR QTN |
| 8       | 09125-05050     | SCREW (5X8)               | 3    |                         |
| 9       | 36895-87D10     | LEAD (L:310)              | 1    |                         |
| 10      | 09160-39001     | WASHER (39.5X64X1.0)      | 2    |                         |
| 11      | 09169-28003     | WASHER                    | 2    |                         |
| 12      | 09181-39001     | SHIM (39.5X64X0.30)       | 4    |                         |
| 13      | 09250-10001     | CAP (OD:14)               | 2    |                         |
| 14      | 09282-39001     | OIL SEAL (39X51X5)        | 1    |                         |
| 15      | 09380-38003     | CIRCLIP                   | 1    |                         |
| 16      | 09440-19028     | SPRING                    | 1    |                         |
| 17      | 41220-95E13     | LEVER, TILT LOCK          | 1    |                         |
| 18      | 41221-95E40     | LEVER, TILT LOCK PORT     | 1    |                         |
| 19      | 41224-95E01     | BUSH, TILT STOPPER ROD    | 2    |                         |
| 20      | 41225-94401     | RUBBER, TILT LOCK LEVER   | 1    |                         |
| 21      | 41228-90J00     | SPRING, TILT LOCK LEVER   | 1    |                         |
| 22      | 41230-95E00     | LINK, TILT LOCK LEVER     | 1    |                         |

FIG.336B




FIG.336B (1-F-3) SWIVEL BRACKET (DF140BG,DF140BZG)

| REF NO. | PART NO.    | DESCRIPTION               | Q'TY | REMARKS |
|---------|-------------|---------------------------|------|---------|
| 23      | 41233-95E10 | BRACKET, TILT LOCK SPRING | 1    |         |
| 24      | 09125-06063 | SCREW (6X10)              | 1    |         |
| 25      | 09140-10032 | NUT                       | 1    |         |
| 26      | 09160-06082 | WASHER (6.5X13X1.0)       | 1    |         |
| 27      | 09204-01006 | PIN                       | 1    |         |
| 28      | 09125-06063 | SCREW (6X10)              | 1    |         |
| 29      | 09125-06063 | SCREW (6X10)              | 1    |         |

FIG.337A




FIG.337A (1-F-4) TRIM CYLINDER (DF115BG,DF115BZG)

| REF NO. | PART NO.    | DESCRIPTION                | Q'TY | REMARKS |
|---------|-------------|----------------------------|------|---------|
| 1       | 48000-90J39 | TRIM ASSY, POWER WITH TILT | 1    |         |
| 2       | 38100-92J13 | .MOTOR ASSY, PTT           | 1    |         |
| 3       | 48400-90J03 | .MANIFOLD ASSY             | 1    |         |
| 4       | 48611-90J00 | .JOINT, METAL              | 1    |         |
| 5       | 48571-87L01 | .TANK, RESERVOIR           | 1    |         |
| 6       | 48572-87J10 | .PLUG                      | 1    |         |
| 7       | 48557-90J00 | .O RING                    | 1    |         |
| 8       | 48862-87J20 | .BOLT, RESERVOIR           | 4    |         |
| 9       | 48502-90J13 | .PUMP ASSY, PTT            | 1    |         |
| 10      | 48583-95E00 | ..JOINT, DRIVE             | 1    |         |
| 11      | 48582-95E01 | ..FILTER                   | 1    |         |
| 12      | 48585-95E00 | ..O RING                   | 1    |         |
| 13      | 48864-93J01 | .MANUAL VALVE              | 1    |         |
| 14      | 48588-90J00 | .O RING SET                | 1    |         |
| 15      | 48862-92J20 | .BOLT, PUMP NO.1           | 1    |         |
| 16      | 48862-92J30 | .BOLT, PUMP NO.2           | 1    |         |
| 17      | 48862-90J21 | .BOLT                      | 1    |         |
| 18      | 31281-92J10 | .BOLT, THROUGH             | 4    |         |
| 19      | 48121-90J00 | SHAFT, TILT CYL LOWER      | 1    |         |
| 20      | 48321-90J00 | SHAFT, TILT CYL UPPER      | 1    |         |
| 21      | 48326-95E00 | BUSH, TILT CYL LOWER       | 4    |         |
| 22      | 09116-10179 | BOLT (10X35)               | 2    |         |
| 23      | 09380-22015 | CIRCLIP                    | 2    |         |
| 24      | 55321-87J01 | ANODE, PROTECTION          | 1    |         |
| 25      | 09103-06281 | BOLT (6X14)                | 1    |         |
| 26      | 36895-87D10 | LEAD (L:310)               | 1    |         |
| 27      | 09125-05050 | SCREW (5X8)                | 1    |         |

FIG.337B




FIG.337B (1-F-5) TRIM CYLINDER ((DF140BG,DF140BZG):E11)

| REF NO. | PART NO.    | DESCRIPTION                | Q'TY | REMARKS |
|---------|-------------|----------------------------|------|---------|
| 1       | 48000-96J15 | TRIM ASSY, POWER WITH TILT | 1    |         |
| 2       | 29404-93J01 | ..CLAMP                    | 1    |         |
| 3       | 31281-92J10 | ..BOLT, THROUGH            | 4    |         |
| 4       | 38100-96J12 | ..MOTOR ASSY, PTT          | 1    |         |
| 5       | 48502-96J05 | ..PUMP ASSY, PTT           | 1    |         |
| 6       | 48503-96J05 | ..MANIFOLD SUB ASSY        | 1    |         |
| 7       | 48401-96J02 | ..PISTON ASSY              | 1    |         |
| 8       | 48601-94900 | ..PISTON/RAM ASSY          | 2    |         |
| 9       | 48627-95E00 | ..O RING SET               | AR   |         |
| 10      | 48630-96J04 | ..HEAD, TRIM CYLINDER      | 2    |         |
| 11      | 48633-94900 | ..O RING SET, HEAD         | 1    |         |
| 12      | 48641-96J04 | ..MANIFOLD, PTT            | 1    |         |
| 13      | 48650-94900 | ..PISTON, FREE             | 1    |         |
| 14      | 48405-93J00 | ..O RING SET               | 1    |         |
| 15      | 48615-97E00 | ..RING SET, PISTON         | 1    |         |
| 16      | 48427-87D00 | ..O RING, PISTON           | 1    |         |
| 17      | 48570-95E01 | ..RESERVOIR ASSY           | 1    |         |
| 18      | 48572-95E00 | ..CAP                      | 1    |         |
| 19      | 48583-95E00 | ..JOINT, DRIVE             | 1    |         |
| 20      | 48585-95E00 | ..O RING                   | 1    |         |
| 21      | 48588-94900 | ..O RING SET               | 1    |         |
| 22      | 48861-92J01 | ..BOLT, RESERVOIR          | 3    |         |
| 23      | 48862-92J20 | ..BOLT, PUMP NO.1          | 1    |         |
| 24      | 48862-92J30 | ..BOLT, PUMP NO.2          | 2    |         |
| 25      | 48121-92J00 | SHAFT, TILT CYL LOWER      | 1    |         |
| 26      | 48311-96J20 | PAD, TRIM CYLINDER RAM     | 2    |         |
| 27      | 48321-87D03 | SHAFT, TILT CYL UPPER      | 1    |         |
| 28      | 48326-95E00 | BUSH, TILT CYL LOWER       | 2    |         |
| 29      | 09116-10179 | BOLT (10X35)               | 2    |         |
| 30      | 09140-10031 | NUT                        | 2    |         |
| 31      | 09162-10005 | LOCK WASHER                | 2    |         |
| 32      | 09306-17001 | BUSH                       | 2    |         |
| 33      | 09380-17009 | CIRCLIP                    | 2    |         |
| 34      | 36894-87D00 | LEAD (L:165)               | 1    |         |
| 35      | 09125-06063 | SCREW (6X10)               | 1    |         |
| 36      | 36895-87D10 | LEAD (L:310)               | 1    |         |

FIG.337B





FIG.337B (1-F-6) TRIM CYLINDER ((DF140BG,DF140BZG):E11)

| REF NO. | PART NO.    | DESCRIPTION       | Q'TY | REMARKS |
|---------|-------------|-------------------|------|---------|
| 37      | 09125-05050 | SCREW (5X8)       | 1    |         |
| 38      | 55321-87J11 | ANODE (MAGNESIUM) | 1    | OPT     |

FIG.337C



DF140BG\_E11\_022\_337C  
TRIM CYLINDER

FIG.337C (1-F-7) TRIM CYLINDER ((DF140BG,DF140BZG):E40)

| REF NO. | PART NO.    | DESCRIPTION                | Q'TY | REMARKS |
|---------|-------------|----------------------------|------|---------|
| 1       | 48000-96J15 | TRIM ASSY, POWER WITH TILT | 1    |         |
| 2       | 29404-93J01 | ..CLAMP                    | 1    |         |
| 3       | 31281-92J10 | ..BOLT, THROUGH            | 4    |         |
| 4       | 38100-96J12 | ..MOTOR ASSY, PTT          | 1    |         |
| 5       | 48502-96J05 | ..PUMP ASSY, PTT           | 1    |         |
| 6       | 48503-96J05 | ..MANIFOLD SUB ASSY        | 1    |         |
| 7       | 48401-96J02 | ..PISTON ASSY              | 1    |         |
| 8       | 48601-94900 | ..PISTON/RAM ASSY          | 2    |         |
| 9       | 48627-95E00 | ..O RING SET               | AR   |         |
| 10      | 48630-96J04 | ..HEAD, TRIM CYLINDER      | 2    |         |
| 11      | 48633-94900 | ..O RING SET, HEAD         | 1    |         |
| 12      | 48641-96J04 | ..MANIFOLD, PTT            | 1    |         |
| 13      | 48650-94900 | ..PISTON, FREE             | 1    |         |
| 14      | 48405-93J00 | ..O RING SET               | 1    |         |
| 15      | 48615-97E00 | ..RING SET, PISTON         | 1    |         |
| 16      | 48427-87D00 | ..O RING, PISTON           | 1    |         |
| 17      | 48570-95E01 | ..RESERVOIR ASSY           | 1    |         |
| 18      | 48572-95E00 | ..CAP                      | 1    |         |
| 19      | 48583-95E00 | ..JOINT, DRIVE             | 1    |         |
| 20      | 48585-95E00 | ..O RING                   | 1    |         |
| 21      | 48588-94900 | ..O RING SET               | 1    |         |
| 22      | 48861-92J01 | ..BOLT, RESERVOIR          | 3    |         |
| 23      | 48862-92J20 | ..BOLT, PUMP NO.1          | 1    |         |
| 24      | 48862-92J30 | ..BOLT, PUMP NO.2          | 2    |         |
| 25      | 48121-92J00 | SHAFT, TILT CYL LOWER      | 1    |         |
| 26      | 48311-96J20 | PAD, TRIM CYLINDER RAM     | 2    |         |
| 27      | 48321-87D03 | SHAFT, TILT CYL UPPER      | 1    |         |
| 28      | 48326-95E00 | BUSH, TILT CYL LOWER       | 2    |         |
| 29      | 09116-10179 | BOLT (10X35)               | 2    |         |
| 30      | 09140-10031 | NUT                        | 2    |         |
| 31      | 09162-10005 | LOCK WASHER                | 2    |         |
| 32      | 09306-17001 | BUSH                       | 2    |         |
| 33      | 09380-17009 | CIRCLIP                    | 2    |         |
| 34      | 36894-87D00 | LEAD (L:165)               | 1    |         |
| 35      | 09125-06063 | SCREW (6X10)               | 1    |         |
| 36      | 36895-87D10 | LEAD (L:310)               | 1    |         |

DF140BG\_E11\_022

FIG.337C




FIG.337C (1-F-8) TRIM CYLINDER ((DF140BG,DF140BZG):E40)

| REF NO. | PART NO.    | DESCRIPTION | Q'TY | REMARKS |
|---------|-------------|-------------|------|---------|
| 37      | 09125-05050 | SCREW (5X8) | 1    |         |

FIG.340A




FIG.340A (1-F-9) PTT MOTOR (DF115BG,DF115BZG)

| REF NO. | PART NO.    | DESCRIPTION         | Q'TY | REMARKS |
|---------|-------------|---------------------|------|---------|
| 1       | 38100-92J13 | MOTOR ASSY, PTT     | 1    |         |
| 2       | 31311-94900 | .ARMATURE           | 1    |         |
| 3       | 31173-94920 | .HOLDER ASSY, BRUSH | 1    |         |
| 4       | 31123-94910 | ..O RING            | 1    |         |
| 5       | 31133-90J10 | ...BRUSH ASSY       | 1    |         |
| 6       | 31133-94910 | ...BRUSH            | 1    |         |
| 7       | 31136-90J20 | ..BREAKER ASSY      | 1    |         |
| 8       | 31135-94900 | ..SPRING            | 2    |         |
| 9       | 33799-97E00 | ..OIL SEAL          | 1    |         |
| 10      | 31111-94900 | ..SCREW             | 2    |         |

FIG.340B




FIG.340B (1-F-10) PTT MOTOR (DF140BG,DF140BZG)

| REF NO. | PART NO.    | DESCRIPTION         | Q'TY | REMARKS |
|---------|-------------|---------------------|------|---------|
| 1       | 38100-96J12 | MOTOR ASSY, PTT     | 1    |         |
| 2       | 31111-94900 | .SCREW              | 3    |         |
| 3       | 31173-94920 | .HOLDER ASSY, BRUSH | 1    |         |
| 4       | 31123-94910 | .O RING             | 1    |         |
| 5       | 31133-90J10 | ..BRUSH ASSY        | 1    |         |
| 6       | 31133-94910 | ...BRUSH            | 1    |         |
| 7       | 31135-94900 | ..SPRING            | 2    |         |
| 8       | 31136-90J20 | ..BREAKER ASSY      | 1    |         |
| 9       | 33799-97E00 | ..OIL SEAL          | 1    |         |
| 10      | 31311-94900 | .ARMATURE           | 1    |         |
| 11      | 48502-96J05 | PUMP ASSY, PTT      | 1    |         |
| 12      | 48582-95E01 | .FILTER             | 1    |         |
| 13      | 48864-96J10 | .VALVE SET, MANUAL  | 1    |         |

FIG.401A





FIG.401A (1-F-11) ENGINE HOLDER

| REF NO. | PART NO.        | DESCRIPTION                | Q'TY | REMARKS |
|---------|-----------------|----------------------------|------|---------|
| 1-1     | 51110-99810-YAY | HOLDER SET, ENGINE (BLACK) | 1    | FOR YAY |
| 1-2     | 51110-99810-Y5S | HOLDER SET, ENGINE (WHITE) | 1    | FOR QTN |
| 2       | 09262-17019     | .BEARING (17X35X8)         | 1    |         |
| 3       | 09282-24003     | .OIL SEAL (24X36X6)        | 2    |         |
| 4       | 09283-32044     | .OIL SEAL (32X47X6)        | 1    |         |
| 5       | 09289-18001     | .OIL SEAL (18X30X8)        | 1    |         |
| 6       | 08331-41359     | .CIRCLIP                   | 1    |         |
| 7       | 09262-35069     | .BEARING (35X62X16)        | 1    |         |
| 8       | 51115-90J00     | UNION, WATER RETURN        | 1    |         |
| 9       | 51211-90J30     | GASKET, ENGINE HOLDER      | 1    |         |
| 10      | 09116-08160     | BOLT (8X70)                | 4    |         |
| 11      | 09116-08178     | BOLT (8X40)                | 4    |         |
| 12      | 09206-08001     | PIN (8X11)                 | 2    |         |
| 13      | 09280-26006     | O RING (D:3.1,ID:26.4)     | 1    |         |
| 14      | 01550-0625C     | BOLT                       | 1    |         |
| 15      | 29117-93J10     | BOLT (8X45)                | 1    |         |
| 16      | 09160-08059     | WASHER (8.5X18X1.6)        | 1    |         |
| 17      | 04211-11129     | PIN                        | 3    |         |
| 18      | 51122-90J00     | COVER, MOUNT CASE          | 1    |         |
| 19      | 51123-90J01     | GASKET, MOUNT CASE COVER   | 1    |         |
| 20      | 01550-0825A     | BOLT                       | 4    |         |
| 21      | 54123-90J01     | PLATE, UPPER MOUNT         | 1    |         |
| 22      | 54112-90J21     | BOLT, UPPER MOUNT          | 2    |         |
| 23      | 54130-90J40     | MOUNT, UPPER               | 2    |         |
| 24      | 09159-12014     | NUT                        | 2    |         |
| 25      | 54114-90J10     | WASHER, UPPER MOUNT BOLT   | 2    |         |
| 26      | 54125-90J11     | MOUNT, UPPER THRUST        | 1    |         |
| 27-1    | 54148-90J11     | COVER, UPPER MOUNT         | 2    | 021     |
| 27-2    | 54148-99L00     | COVER, UPPER MOUNT         | 2    | 022     |
| 28      | 09116-10181     | BOLT (10X44)               | 4    |         |
| 29      | 09159-12014     | NUT                        | 2    |         |
| 30      | 09160-12110     | WASHER (12.5X22X3)         | 2    |         |

**FIG.405A (1-F-12) DRIVE SHAFT HOUSING**

DF140BG\_E11\_022

FIG.407A



DF140BG\_E11\_022\_407A  
GEAR CASE

FIG.407A (1-F-13) GEAR CASE ((DF115BG,DF140BG):E11)

| REF NO. | PART NO.        | DESCRIPTION             | Q'TY | REMARKS                    |
|---------|-----------------|-------------------------|------|----------------------------|
| 1-1     | 55110-90J16-YAY | CASE, GEAR (BLACK)      | 1    | FOR YAY                    |
| 1-2     | 55110-90J16-QTN | CASE, GEAR (WHITE)      | 1    | FOR QTN                    |
| 2       | 09263-28016     | .BEARING (28.6X38X31.8) | 1    |                            |
| 3       | 55125-90J01     | TAB, TRIM               | 1    |                            |
| 4       | 55127-87D00     | UNION, SPEEDOMETER HOSE | 1    |                            |
| 5       | 55321-90J01     | ANODE, GEAR CASE        | 1    |                            |
| 6       | 55332-87D12     | RUBBER, EXHAUST SEAL    | 1    |                            |
| 7       | 55333-87D10     | PLATE, EXHAUST SEAL     | 1    |                            |
| 8       | 09100-06131     | BOLT (6X12)             | 1    |                            |
| 9       | 09116-08137     | BOLT (8X22)             | 1    |                            |
| 10      | 09116-10150     | BOLT (10X55)            | 6    |                            |
| 11      | 09117-10039     | BOLT (10X80)            | 1    |                            |
| 12      | 09160-06085     | WASHER (6.5X15X1.0)     | 1    |                            |
| 13      | 09168-10022     | GASKET (10X17X1.5)      | 2    |                            |
| 14      | 09202-08006     | PIN (8X12)              | 2    |                            |
| 15      | 09248-10008     | PLUG (10X7.5)           | 2    |                            |
| 16-1    | 09355-40805-600 | HOSE (4X8X600)          | 1    | W/TRANSOM(L)<br>L:600->50  |
| 16-2    | 09355-40805-600 | HOSE (4X8X600)          | 1    | W/TRANSOM(X)<br>L:600->100 |
| 17      | 09362-09008     | UNION                   | 1    |                            |
| 18      | 09407-10404     | CLAMP (L:100)           | 2    |                            |
| 19-1    | 58100-90JA0-019 | PROPELLER (3X14X17)     | 1    |                            |
| 19-2    | 58100-90JB0-019 | PROPELLER (3X14X19)     | 1    |                            |
| 19-3    | 58100-90JC0-019 | PROPELLER (3X14X21)     | 1    |                            |
| 19-4    | 58100-90JD0-019 | PROPELLER (3X14X23)     | 1    |                            |
| 19-5    | 58100-90JE0-019 | PROPELLER (3X13.5X15)   | 1    |                            |
| 20      | 58105-90J00     | .BUSH SET, PROPELLER    | 1    |                            |
| 21-1    | 58200-92J40     | PROPELLER (3X13-7/8X15) | 1    | OPT                        |
| 21-2    | 58200-92J50     | PROPELLER (3X13-7/8X17) | 1    | OPT                        |
| 21-3    | 58200-92J60     | PROPELLER (3X13-7/8X19) | 1    | OPT                        |
| 21-4    | 58200-92J70     | PROPELLER (3X13-7/8X21) | 1    | OPT                        |
| 21-5    | 58200-92J80     | PROPELLER (3X13-7/8X23) | 1    | OPT                        |
| 21-6    | 58200-92J90     | PROPELLER (3X13-7/8X25) | 1    | OPT                        |
| 22      | 58105-90J00     | .BUSH SET, PROPELLER    | 1    | OPT                        |
| 23      | 57633-90J02     | SPACER, PROPELLER NUT   | 1    |                            |

DF140BG\_E11\_022

FIG.407A





FIG.407A (1-F-14) GEAR CASE ((DF115BG,DF140BG):E11)

| REF NO. | PART NO.    | DESCRIPTION             | Q'TY | REMARKS             |
|---------|-------------|-------------------------|------|---------------------|
| 24      | 57635-92J01 | STOPPER, PROPELLER BUSH | 1    |                     |
| 25      | 09141-18005 | NUT                     | 1    |                     |
| 26      | 09160-18028 | WASHER (18.5X31X1.0)    | 1    |                     |
| 27      | 09204-03003 | PIN                     | 1    |                     |
| 28      | 55116-87E00 | PLUG, GEAR CASE         | 1    | OPT                 |
| 29      | 57630-90J00 | KIT, PROPELLER NUT      | 1    | OPT                 |
| 30      | 25700-92J00 | SEALING KIT, GEAR CASE  | 1    | OPT,NOT ILLUSTRATED |

FIG.407B




DF140BG\_E11\_022\_407B  
GEAR CASE

FIG.407B (1-G-2) GEAR CASE ((DF115BG,DF140BG):E40)

| REF NO. | PART NO.        | DESCRIPTION             | Q'TY | REMARKS                    |
|---------|-----------------|-------------------------|------|----------------------------|
| 1-1     | 55110-90J16-YAY | CASE, GEAR (BLACK)      | 1    | FOR YAY                    |
| 1-2     | 55110-90J16-QTN | CASE, GEAR (WHITE)      | 1    | FOR QTN                    |
| 2       | 09263-28016     | .BEARING (28.6X38X31.8) | 1    |                            |
| 3       | 55125-90J01     | TAB, TRIM               | 1    |                            |
| 4       | 55127-87D00     | UNION, SPEEDOMETER HOSE | 1    |                            |
| 5       | 55321-90J01     | ANODE, GEAR CASE        | 1    |                            |
| 6       | 55332-87D12     | RUBBER, EXHAUST SEAL    | 1    |                            |
| 7       | 55333-87D10     | PLATE, EXHAUST SEAL     | 1    |                            |
| 8       | 09100-06131     | BOLT (6X12)             | 1    |                            |
| 9       | 09116-08137     | BOLT (8X22)             | 1    |                            |
| 10      | 09116-10150     | BOLT (10X55)            | 6    |                            |
| 11      | 09117-10039     | BOLT (10X80)            | 1    |                            |
| 12      | 09160-06085     | WASHER (6.5X15X1.0)     | 1    |                            |
| 13      | 09168-10022     | GASKET (10X17X1.5)      | 2    |                            |
| 14      | 09202-08006     | PIN (8X12)              | 2    |                            |
| 15      | 09248-10008     | PLUG (10X7.5)           | 2    |                            |
| 16-1    | 09355-40805-600 | HOSE (4X8X600)          | 1    | W/TRANSOM(L)<br>L:600->50  |
| 16-2    | 09355-40805-600 | HOSE (4X8X600)          | 1    | W/TRANSOM(X)<br>L:600->100 |
| 17      | 09362-09008     | UNION                   | 1    |                            |
| 18      | 09407-10404     | CLAMP (L:100)           | 2    |                            |
| 19-1    | 58100-90JA0-019 | PROPELLER (3X14X17)     | 1    |                            |
| 19-2    | 58100-90JB0-019 | PROPELLER (3X14X19)     | 1    |                            |
| 19-3    | 58100-90JC0-019 | PROPELLER (3X14X21)     | 1    |                            |
| 19-4    | 58100-90JD0-019 | PROPELLER (3X14X23)     | 1    |                            |
| 19-5    | 58100-90JE0-019 | PROPELLER (3X13.5X15)   | 1    |                            |
| 20      | 58105-90J00     | .BUSH SET, PROPELLER    | 1    |                            |
| 21      | 57633-90J02     | SPACER, PROPELLER NUT   | 1    |                            |
| 22      | 57635-92J01     | STOPPER, PROPELLER BUSH | 1    |                            |
| 23      | 09141-18005     | NUT                     | 1    |                            |
| 24      | 09160-18028     | WASHER (18.5X31X1.0)    | 1    |                            |
| 25      | 09204-03003     | PIN                     | 1    |                            |
| 26      | 25700-92J00     | SEALING KIT, GEAR CASE  | 1    | OPT,NOT ILLUSTRATED        |

DF140BG\_E11\_022

FIG.407C




DF140BG\_E11\_022\_407C  
GEAR CASE

FIG.407C (1-G-3) GEAR CASE ((DF115BZG,DF140BZG):E11)

| REF NO. | PART NO.        | DESCRIPTION                 | Q'TY | REMARKS                    |
|---------|-----------------|-----------------------------|------|----------------------------|
| 1-1     | 55110-92J01-YAY | CASE, GEAR (BLACK)          | 1    | FOR YAY                    |
| 1-2     | 55110-92J01-QTN | CASE, GEAR (WHITE)          | 1    | FOR QTN                    |
| 2       | 09263-28016     | .BEARING (28.6X38X31.8)     | 1    |                            |
| 3-1     | 55125-92J00-YAY | TAB, TRIM (BLACK)           | 1    | FOR YAY                    |
| 3-2     | 55125-92J00-QTN | TAB, TRIM (WHITE)           | 1    | FOR QTN                    |
| 4       | 55127-87D00     | UNION, SPEEDOMETER HOSE     | 1    |                            |
| 5       | 55321-90J01     | ANODE, GEAR CASE            | 1    |                            |
| 6       | 55332-87D12     | RUBBER, EXHAUST SEAL        | 1    |                            |
| 7       | 55333-87D10     | PLATE, EXHAUST SEAL         | 1    |                            |
| 8       | 09100-06131     | BOLT (6X12)                 | 1    |                            |
| 9       | 09116-08137     | BOLT (8X22)                 | 1    |                            |
| 10      | 09116-10150     | BOLT (10X55)                | 6    |                            |
| 11      | 09117-10039     | BOLT (10X80)                | 1    |                            |
| 12      | 09160-06085     | WASHER (6.5X15X1.0)         | 1    |                            |
| 13      | 09168-10022     | GASKET (10X17X1.5)          | 2    |                            |
| 14      | 09202-08006     | PIN (8X12)                  | 2    |                            |
| 15      | 09248-10008     | PLUG (10X7.5)               | 2    |                            |
| 16-1    | 09355-40805-600 | HOSE (4X8X600)              | 1    | W/TRANSOM(L)<br>L:600->50  |
| 16-2    | 09355-40805-600 | HOSE (4X8X600)              | 1    | W/TRANSOM(X)<br>L:600->100 |
| 17      | 09362-09008     | UNION                       | 1    |                            |
| 18      | 09407-10404     | CLAMP (L:100)               | 2    |                            |
| 19-1    | 58200-92JA0     | PROPELLER (3X13-7/8X17,C/R) | 1    | OPT                        |
| 19-2    | 58200-92JB0     | PROPELLER (3X13-7/8X19,C/R) | 1    | OPT                        |
| 19-3    | 58200-92JC0     | PROPELLER (3X13-7/8X21,C/R) | 1    | OPT                        |
| 19-4    | 58200-92JD0     | PROPELLER (3X13-7/8X23,C/R) | 1    | OPT                        |
| 20      | 58105-90J00     | .BUSH SET, PROPELLER        | 1    | OPT                        |
| 21      | 57633-90J02     | SPACER, PROPELLER NUT       | 1    |                            |
| 22      | 57635-92J01     | STOPPER, PROPELLER BUSH     | 1    |                            |
| 23      | 09141-18005     | NUT                         | 1    |                            |
| 24      | 09160-18028     | WASHER (18.5X31X1.0)        | 1    |                            |
| 25      | 09204-03003     | PIN                         | 1    |                            |
| 26      | 55116-87E00     | PLUG, GEAR CASE             | 1    | OPT                        |
| 27      | 57630-90J00     | KIT, PROPELLER NUT          | 1    | OPT                        |
| 28      | 25700-92J00     | SEALING KIT, GEAR CASE      | 1    | OPT,NOT ILLUSTRATED        |

DF140BG\_E11\_022

FIG.407D



DF140BG\_E11\_022\_407D  
GEAR CASE

FIG.407D (1-G-4) GEAR CASE ((DF115BZG,DF140BZG):E40)

| REF NO. | PART NO.        | DESCRIPTION             | QTY | REMARKS                    |
|---------|-----------------|-------------------------|-----|----------------------------|
| 1-1     | 55110-92J01-YAY | CASE, GEAR (BLACK)      | 1   | FOR YAY                    |
| 1-2     | 55110-92J01-QTN | CASE, GEAR (WHITE)      | 1   | FOR QTN                    |
| 2       | 09263-28016     | .BEARING (28.6X38X31.8) | 1   |                            |
| 3-1     | 55125-92J00-YAY | TAB, TRIM (BLACK)       | 1   | FOR YAY                    |
| 3-2     | 55125-92J00-QTN | TAB, TRIM (WHITE)       | 1   | FOR QTN                    |
| 4       | 55127-87D00     | UNION, SPEEDOMETER HOSE | 1   |                            |
| 5       | 55321-90J01     | ANODE, GEAR CASE        | 1   |                            |
| 6       | 55332-87D12     | RUBBER, EXHAUST SEAL    | 1   |                            |
| 7       | 55333-87D10     | PLATE, EXHAUST SEAL     | 1   |                            |
| 8       | 09100-06131     | BOLT (6X12)             | 1   |                            |
| 9       | 09116-08137     | BOLT (8X22)             | 1   |                            |
| 10      | 09116-10150     | BOLT (10X55)            | 6   |                            |
| 11      | 09117-10039     | BOLT (10X80)            | 1   |                            |
| 12      | 09160-06085     | WASHER (6.5X15X1.0)     | 1   |                            |
| 13      | 09168-10022     | GASKET (10X17X1.5)      | 2   |                            |
| 14      | 09202-08006     | PIN (8X12)              | 2   |                            |
| 15      | 09248-10008     | PLUG (10X7.5)           | 2   |                            |
| 16-1    | 09355-40805-600 | HOSE (4X8X600)          | 1   | W/TRANSOM(L)<br>L:600->50  |
| 16-2    | 09355-40805-600 | HOSE (4X8X600)          | 1   | W/TRANSOM(X)<br>L:600->100 |
| 17      | 09362-09008     | UNION                   | 1   |                            |
| 18      | 09407-10404     | CLAMP (L:100)           | 2   |                            |
| 19      | 57633-90J02     | SPACER, PROPELLER NUT   | 1   |                            |
| 20      | 57635-92J01     | STOPPER, PROPELLER BUSH | 1   |                            |
| 21      | 09141-18005     | NUT                     | 1   |                            |
| 22      | 09160-18028     | WASHER (18.5X31X1.0)    | 1   |                            |
| 23      | 09204-03003     | PIN                     | 1   |                            |
| 24      | 25700-92J00     | SEALING KIT, GEAR CASE  | 1   | OPT,NOT ILLUSTRATED        |

DF140BG\_E11\_022

FIG.410A




FIG.410A (1-G-5) SIDE COVER

| REF NO. | PART NO.        | DESCRIPTION               | Q'TY | REMARKS         |
|---------|-----------------|---------------------------|------|-----------------|
| 1-1     | 61811-99L00-YAY | COVER, SIDE STBD (BLACK)  | 1    | STBD<br>FOR YAY |
| 1-2     | 61811-99L00-QTN | COVER, SIDE STBD (WHITE)  | 1    | STBD<br>FOR QTN |
| 2-1     | 61820-99L00-YAY | COVER, SIDE PORT (BLACK)  | 1    | PORT<br>FOR YAY |
| 2-2     | 61820-99L00-QTN | COVER, SIDE PORT (WHITE)  | 1    | PORT<br>FOR QTN |
| 3       | 61827-99L00     | STAND, SIDE COVER         | 1    |                 |
| 4       | 09136-06149     | SCREW (6X55)              | 4    |                 |
| 5       | 61814-99L00     | SILENCER, SIDE COVER STBD | 1    |                 |
| 6       | 61824-99L00     | SILENCER, SIDE COVER PORT | 1    |                 |
| 7       | 61134-99L00     | SEAL, ENGINE HOLDER       | 1    |                 |
| 8       | 09409-05302-5PK | CLIP (BLACK)              | 2    |                 |
| 9       | 09136-06148     | SCREW (6X35)              | 7    |                 |
| 10      | 17913-93J00     | PLUG, WATER               | 1    |                 |
| 11      | 17914-93J01     | GASKET, WATER PLUG        | 1    |                 |
| 12-1    | 61830-99L00-YAY | PANEL, FRONT (BLACK)      | 1    | FOR YAY         |
| 12-2    | 61830-99L00-QTN | PANEL, FRONT (WHITE)      | 1    | FOR QTN         |
| 13      | 09116-08174     | BOLT (8X38)               | 2    |                 |
| 14      | 09169-08050     | WASHER (ID:8.5)           | 2    |                 |
| 15      | 09320-11023     | CUSHION                   | 2    |                 |
| 16      | 61632-93J00     | SHAFT, ENGINE COVER HOOK  | 2    |                 |
| 17      | 61633-96J02     | LEVER, HOOK REAR STBD     | 1    | STBD            |
| 18      | 61634-96J02     | LEVER, HOOK REAR PORT     | 1    | PORT            |
| 19      | 61641-93J10     | HOOK, ENGINE COVER        | 3    |                 |
| 20-1    | 61645-90J01-YAY | LEVER, HOOK FRONT (BLACK) | 1    | FOR YAY         |
| 20-2    | 61645-90J01-QTN | LEVER, HOOK FRONT (WHITE) | 1    | FOR QTN         |
| 21      | 61673-96J02     | LATCH, HOOK LEVER         | 2    |                 |
| 22      | 09116-06127     | BOLT (6X12)               | 3    |                 |
| 23      | 09160-13014     | WASHER (13.2X25X1)        | 3    |                 |
| 24      | 09164-14008     | WASHER                    | 3    |                 |
| 25      | 09202-04022     | PIN                       | 2    |                 |
| 26      | 09306-13007     | BUSH                      | 2    |                 |
| 27      | 09103-05026     | BOLT (5X10)               | 4    |                 |
| 28      | 61124-99L00     | GROMMET, R/CON CABLE      | 1    |                 |

FIG.410A




FIG.410A (1-G-6) SIDE COVER

| REF NO. | PART NO.    | DESCRIPTION            | Q'TY | REMARKS |
|---------|-------------|------------------------|------|---------|
| 29      | 09407-20405 | CLAMP (L:202)          | 1    |         |
| 30      | 17917-87L00 | CONNECTOR, FLUSH WATER | 1    |         |
| 31      | 09329-14004 | CUSHION                | 1    |         |
| 32      | 09329-14003 | CUSHION (14X20X9)      | 2    |         |
| 33      | 61648-99L00 | SPRING, HOOK LEVER     | 1    |         |
| 34      | 09306-13011 | BUSH                   | 1    |         |
| 35      | 61458-90J01 | LABEL, ENGINE COVER    | 1    |         |
| 36      | 67361-90J10 | ADAPTER, HOSE          | 1    | OPT     |
| 37      | 09208-06011 | PIN                    | 2    | OPT     |

**FIG.420A (1-G-7) ENGINE COVER (DF115BG,DF115BZG)**




FIG.420B




FIG.420B (1-G-8) ENGINE COVER (DF140BG,DF140BZG)

| REF NO. | PART NO.        | DESCRIPTION                | QTY | REMARKS         |
|---------|-----------------|----------------------------|-----|-----------------|
| 1-1     | 61401-99811-YAY | COVER SET, ENGINE (BLACK)  | 1   | FOR YAY         |
| 1-2     | 61401-99821-QTN | COVER SET, ENGINE (WHITE)  | 1   | FOR QTN         |
| 2       | 41225-94401     | .RUBBER, TILT LOCK LEVER   | 1   |                 |
| 3       | 61112-99L00     | .SEAL, ENGINE COVER        | 1   |                 |
| 4       | 61610-93J01     | .FASTENER                  | 3   |                 |
| 5       | 61621-93J01     | .BRACKET, FASTENER         | 3   |                 |
| 6       | 61682-99L00     | .STAND, ENGINE COVER       | 1   |                 |
| 7       | 09329-10024     | .CUSHION                   | 3   |                 |
| 8       | 01547-0616C     | .BOLT                      | 4   |                 |
| 9       | 01547-0620C     | .BOLT                      | 2   |                 |
| 10      | 01550-0612C     | .BOLT                      | 3   |                 |
| 11-1    | 61443-99L00     | .STRIPE, ENGINE COVER STBD | 1   | STBD<br>FOR YAY |
| 11-2    | 61443-99L10     | .STRIPE, ENGINE COVER STBD | 1   | STBD<br>FOR QTN |
| 12-1    | 61453-99L00     | .STRIPE, ENGINE COVER PORT | 1   | PORT<br>FOR YAY |
| 12-2    | 61453-99L10     | .STRIPE, ENGINE COVER PORT | 1   | PORT<br>FOR QTN |
| 13      | 61441-92J10     | .MARK, SUZUKI              | 2   |                 |
| 14      | 68111-93J00     | .EMBLEM, S                 | 1   |                 |
| 15-1    | 61435-99L00     | MARK, EMBLEM REAR          | 1   | FOR YAY         |
| 15-2    | 61435-99L10     | MARK, EMBLEM REAR          | 1   | FOR QTN         |
| 16      | 09800-81841     | TOOL SET                   | 1   |                 |
| 17-1    | 99011-99L01-054 | MANUAL, OWNER'S            | 1   | E11:021         |
| 17-2    | 99011-99L01-03B | MANUAL, OWNER'S            | 1   | E11:021         |
| 17-3    | 99011-99L01-059 | MANUAL, OWNER'S            | 1   | (E11,E40):021   |
| 17-4    | 99011-99L20-054 | MANUAL, OWNER'S            | 1   | E11:022         |
| 17-5    | 99011-99L20-03B | MANUAL, OWNER'S            | 1   | E11:022         |
| 17-6    | 99011-99L20-059 | MANUAL, OWNER'S            | 1   | (E11,E40):022   |

FIG.430A




FIG.430A (1-G-9) FUEL HOSE

| REF NO. | PART NO.    | DESCRIPTION        | Q'TY | REMARKS |
|---------|-------------|--------------------|------|---------|
| 1       | 65700-90J24 | HOSE, FUEL         | 1    |         |
| 2       | 65750-95501 | .SOCKET, FUEL HOSE | 1    |         |
| 3       | 65770-90J13 | .PUMP, SQUEEZE     | 1    |         |
| 4       | 09401-11423 | CLIP               | 1    |         |

FIG.432A




FIG.432A (1-G-10) FUEL TANK (E40)

| REF NO. | PART NO.    | DESCRIPTION           | Q'TY | REMARKS |
|---------|-------------|-----------------------|------|---------|
| 1       | 65000-94L10 | TANK ASSY, FUEL (25L) | 1    |         |
| 2       | 65520-99100 | .CAP ASSY, FUEL TANK  | 1    |         |
| 3       | 65561-95D00 | .GASKET, TANK CAP     | 1    |         |
| 4       | 65740-95D01 | .PLUG, FUEL CONNECTOR | 1    |         |
| 5       | 65700-90J24 | HOSE, FUEL            | 1    |         |
| 6       | 65750-95501 | .SOCKET, FUEL HOSE    | 1    |         |
| 7       | 65770-90J13 | .PUMP, SQUEEZE        | 1    |         |
| 8       | 09401-11423 | CLIP                  | 1    |         |

FIG.442A




FIG.442A (1-G-11) DRAG LINK

| REF NO. | PART NO.    | DESCRIPTION           | Q'TY | REMARKS             |
|---------|-------------|-----------------------|------|---------------------|
| 1       | 41161-94400 | SEAL, STEERING CABLE  | 1    |                     |
| 2       | 67701-90J01 | LINK ASSY, DRAG       | 1    |                     |
| 3       | 67721-99E00 | .SPACER               | 1    |                     |
| 4       | 67725-99E00 | .BOLT, DRAG LINK      | 1    |                     |
| 5       | 67726-99E00 | .NUT, LOCK            | 2    |                     |
| 6       | 67728-99E00 | .WASHER               | 4    |                     |
| 7       | 67600-99L00 | KIT, TIE ROD          | 1    | OPT,NOT ILLUSTRATED |
| 8       | 67631-99L00 | .BRACKET, TIE ROD     | 2    | OPT,NOT ILLUSTRATED |
| 9       | 67725-99E20 | .BOLT, DRAG LINK      | 2    | OPT,NOT ILLUSTRATED |
| 10      | 67726-99E00 | .NUT, LOCK            | 2    | OPT,NOT ILLUSTRATED |
| 11      | 09100-12081 | .BOLT (12X25)         | 4    | OPT,NOT ILLUSTRATED |
| 12      | 09160-12066 | .WASHER (12.5X22X2.5) | 4    | OPT,NOT ILLUSTRATED |
| 13      | 09180-09022 | .SPACER (9.6X18X12)   | 2    | OPT,NOT ILLUSTRATED |

FIG.475A

FIG.475A (1-G-12) SQUEEZE PUMP (E11)

| REF NO. | PART NO.    | DESCRIPTION   | Q'TY | REMARKS |
|---------|-------------|---------------|------|---------|
| 1       | 65770-90J04 | PUMP, SQUEEZE | 1    |         |




FIG.507A




FIG.507A (1-G-13) OPT:WATER PRESSURE GAUGE SUB KIT (SEE NOTE)

| REF NO. | PART NO.        | DESCRIPTION                | Q'TY | REMARKS    |
|---------|-----------------|----------------------------|------|------------|
| 1       | 34660-90J05     | KIT, WATER PRESS GAUGE SUB | 1    |            |
| 2       | 09352-50006-600 | .HOSE (5X9X600)            | 1    | L:600->160 |
| 3       | 09352-50006-600 | .HOSE (5X9X600)            | 1    | L:600->210 |
| 4       | 09367-06006     | .3 WAY                     | 1    |            |
| 5       | 09401-08413     | .CLIP                      | 4    |            |
| 6       | 18498-99EA1     | .PROTECTOR (L:80)          | 1    |            |
| 7       | 09407-20405     | .CLAMP (L:202)             | 1    |            |
| 8       | 09408-00346     | .CLAMP                     | 4    |            |

NOTE : DF115BG,DF115BZG

FIG.507B




FIG.507B (1-G-14) OPT:WATER PRESSURE GAUGE SUB KIT (SEE NOTE)

| REF NO. | PART NO.        | DESCRIPTION                | Q'TY | REMARKS    |
|---------|-----------------|----------------------------|------|------------|
| 1       | 34660-90J05     | KIT, WATER PRESS GAUGE SUB | 1    |            |
| 2       | 09352-50006-600 | .HOSE (5X9X600)            | 1    | L:600->160 |
| 3       | 09352-50006-600 | .HOSE (5X9X600)            | 1    | L:600->210 |
| 4       | 09367-06006     | .3 WAY                     | 1    |            |
| 5       | 09401-08413     | .CLIP                      | 4    |            |
| 6       | 18498-99EA1     | .PROTECTOR (L:80)          | 1    |            |
| 7       | 09407-20405     | .CLAMP (L:202)             | 1    |            |
| 8       | 09408-00346     | .CLAMP                     | 4    |            |
| 9       | 17917-87L00     | CONNECTOR, FLUSH WATER     | 1    |            |

NOTE : DF140BG,DF140BZG

FIG.520A




FIG.520A (1-H-2) OPT:FLUSH MOUNT REMOCON (021)

| REF NO. | PART NO.    | DESCRIPTION                   | Q'TY | REMARKS |
|---------|-------------|-------------------------------|------|---------|
| 1       | 67200-98J24 | REMOTE CONTROL ASSY, FLASH MT | 1    |         |
| 2       | 67271-98J20 | .COVER, BOTTOM BASE           | 1    |         |
| 3       | 67264-98J00 | .COVER, TOP BASE              | 1    |         |
| 4       | 67263-98J20 | .COVER, LEVER                 | 1    |         |
| 5       | 67261-98J20 | .GRIP, A                      | 1    |         |
| 6       | 67261-98J30 | .GRIP, B                      | 1    |         |
| 7       | 67265-98J00 | .BUTTON, NEUTRAL LOCK         | 1    |         |
| 8       | 67255-98J00 | .LINK, NEUTRAL LOCK NO.1      | 1    |         |
| 9       | 67258-98J00 | .PLATE, JOINT                 | 1    |         |
| 10      | 67256-98J00 | .BLOCK, NEUTRAL LOCK          | 1    |         |
| 11      | 67259-98J00 | .SPRING                       | 3    |         |
| 12      | 67251-98J20 | .LEVER, HANDLE                | 1    |         |
| 13      | 67294-98J00 | .SPACER                       | 1    |         |
| 14      | 67254-98J00 | .LINK, NEUTRAL LOCK NO.2      | 1    |         |
| 15      | 67233-98J00 | .SLIDER, NEUTRAL BUTTON       | 1    |         |
| 16      | 67296-98JA0 | .SCREW (4X10)                 | 3    |         |
| 17      | 67234-98J00 | .PLATE, LEVER                 | 1    |         |
| 18      | 67211-98J20 | .HOUSING                      | 1    |         |
| 19      | 67269-98J20 | .CLAMP, LEAD                  | 1    |         |
| 20      | 67296-98JB0 | .SCREW (4X30)                 | 1    |         |
| 21      | 67227-98J20 | .SCREW (4X35)                 | 1    |         |
| 22      | 67227-98J30 | .SCREW (4X20)                 | 1    |         |
| 23      | 67288-98J50 | .WASHER, PLANE                | 8    |         |
| 24      | 67296-98JC0 | .SCREW (6X40)                 | 4    |         |
| 25      | 67287-98J00 | .NUT                          | 4    |         |
| 26      | 67226-98J10 | .BOLT (6X50)                  | 4    |         |
| 27      | 67288-98J60 | .WASHER, INTERNAL TOOTH (M4)  | 3    |         |
| 28      | 67296-98JD0 | .SCREW (5X40)                 | 1    |         |
| 29      | 67238-98J00 | .PIN                          | 2    |         |
| 30      | 67288-98J70 | .WASHER, PLANE                | 5    |         |
| 31      | 67246-98J00 | .SHAFT, DRIVE                 | 1    |         |
| 32      | 67222-98J00 | .PANEL ASSY, BACK             | 1    |         |
| 33      | 67236-98J00 | .ROLLER, DETENT               | 1    |         |
| 34      | 67235-98J00 | .GUIDE, DETENT ROOLER         | 1    |         |
| 35      | 67237-98J00 | .SPRING, DETENT               | 1    |         |
| 36      | 67223-98J00 | .PAD, BRAKE                   | 1    |         |

FIG.520A




FIG.520A (1-H-3) OPT:FLUSH MOUNT REMOCON (021)

| REF NO. | PART NO.    | DESCRIPTION                 | Q'TY | REMARKS |
|---------|-------------|-----------------------------|------|---------|
| 37      | 67296-98JE0 | .SCREW (5X35)               | 1    |         |
| 38      | 67252-98J00 | .BUSH, DRIVE SHAFT          | 1    |         |
| 39      | 67288-98J20 | .WASHER                     | 1    |         |
| 40      | 67292-98J00 | .C RING                     | 1    |         |
| 41      | 15980-98J00 | .POTENTIOMETER              | 1    |         |
| 42      | 67227-98J10 | .LEVER, POTENTIOMETER NO.2  | 1    |         |
| 43      | 67296-94300 | .SCREW (4X10)               | 2    |         |
| 44      | 67288-98J00 | .WASHER, POTENTIOMETER      | 5    |         |
| 45      | 67296-98J10 | .SCREW (5X35)               | 1    |         |
| 46      | 67288-98J10 | .WASHER, SPRING             | 8    |         |
| 47      | 67228-98J50 | .WASHER, WAVE               | 2    |         |
| 48      | 67296-98J60 | .SCREW (8X30)               | 1    |         |
| 49      | 09160-06104 | .WASHER (6.5X24X2)          | 4    |         |
| 50      | 67296-98J50 | .SCREW (5X18)               | 2    |         |
| 51      | 67272-98J00 | .GROMMET, COVER             | 2    |         |
| 52      | 37850-98J03 | .SWITCH ASSY, PTT           | 1    |         |
| 53      | 67269-98J10 | .BAND                       | 1    |         |
| 54      | 67257-98J00 | .MARK, LEVER                | 1    |         |
| 55      | 36890-98J00 | .HARNESS, CONDENSER ADAPTER | 1    |         |

FIG.520B




FIG.520B (1-H-4) OPT:FLUSH MOUNT REMOCON (022)

| REF NO. | PART NO.    | DESCRIPTION                    | Q'TY | REMARKS |
|---------|-------------|--------------------------------|------|---------|
| 1       | 67200-98L20 | R/CON ASSY, FLASH MOUNT        | 1    |         |
| 2       | 67272-98L20 | .GROMMET, R/CON COVER          | 1    |         |
| 3       | 67264-98L00 | .COVER, TOP BASE               | 1    |         |
| 4       | 67284-98L20 | .MARK, HANDLE LEVER            | 1    |         |
| 5       | 67263-98J20 | .COVER, LEVER                  | 1    |         |
| 6       | 67261-98J20 | .GRIP, A                       | 1    |         |
| 7       | 67261-98J30 | .GRIP, B                       | 1    |         |
| 8       | 67265-98J00 | .BUTTON, NEUTRAL LOCK          | 1    |         |
| 9       | 67255-98J00 | .LINK, NEUTRAL LOCK NO.1       | 1    |         |
| 10      | 67258-98J00 | .PLATE, JOINT                  | 1    |         |
| 11      | 67256-98L00 | .BLOCK, NEUTRAL LOCK           | 1    |         |
| 12      | 67259-98J00 | .SPRING                        | 3    |         |
| 13      | 67251-98J20 | .LEVER, HANDLE                 | 1    |         |
| 14      | 67294-98J00 | .SPACER                        | 1    |         |
| 15      | 67254-98J00 | .LINK, NEUTRAL LOCK NO.2       | 1    |         |
| 16      | 67296-98JA0 | .SCREW (4X10)                  | 3    |         |
| 17      | 67234-98J00 | .PLATE, LEVER                  | 1    |         |
| 18      | 67211-98J20 | .HOUSING                       | 1    |         |
| 19      | 67296-98JB0 | .SCREW (4X30)                  | 1    |         |
| 20      | 67227-98J20 | .SCREW (4X35)                  | 1    |         |
| 21      | 67288-98J50 | .WASHER, PLANE                 | 4    |         |
| 22      | 67287-98J00 | .NUT                           | 4    |         |
| 23      | 67226-98J10 | .BOLT (6X50)                   | 4    |         |
| 24      | 67288-98J60 | .WASHER, ININTERNAL TOOTH (M4) | 3    |         |
| 25      | 67238-98J00 | .PIN                           | 2    |         |
| 26      | 67288-98J00 | .WASHER, POTENTIOMETER         | 3    |         |
| 27      | 67296-98J60 | .SCREW (8X30)                  | 1    |         |
| 28      | 09160-06104 | .WASHER (6.5X24X2)             | 4    |         |
| 29      | 37850-98J03 | .SWITCH ASSY, PTT              | 1    |         |
| 30      | 67257-98J00 | .MARK, LEVER                   | 1    |         |
| 31      | 37820-98L00 | .SWITCH ASSY, EMERGENCY        | 1    |         |
| 32      | 37823-98L00 | .PLATE, EMERGENCY SW LOCK      | 1    |         |
| 33      | 37130-98L20 | .SWITCH ASSY, BOAT CONTROL     | 1    |         |
| 34      | 67227-98L00 | .SCREW                         | 1    |         |

FIG.522A





FIG.522A (1-H-5) OPT:HARNESS (1) (021)

| REF NO. | PART NO.    | DESCRIPTION                     | Q'TY | REMARKS |
|---------|-------------|---------------------------------|------|---------|
| 1       | 36620-98J53 | WIRE ASSY, REMOTE CONTROL       | 1    |         |
| 2       | 36612-98J20 | CONNECTOR, COUNTER SELECT       | AR   |         |
| 3       | 36990-87D00 | TERMINAL & SLEEVE SET           | 1    |         |
| 4       | 36667-96L20 | WIRE, GAUGE EXT                 | 1    |         |
| 5       | 33911-88BL0 | CAP, RUBBER                     | 1    |         |
| 6       | 33925-93J00 | CUSHION, ENGINE CONTROL UNIT    | AR   |         |
| 7       | 33926-98J00 | RESISTOR, TERMINAL              | AR   |         |
| 8       | 36623-98J21 | HARNESS ASSY, BCM NO.1 FOR SNGL | 1    |         |
| 9       | 36615-96300 | .TERMINAL                       | 4    |         |
| 10-1    | 36770-98J13 | CONTROLLER ASSY, BOAT ELECTRIC  | 1    |         |
| 10-2    | 36770-98J22 | CONTROLLER ASSY, BOAT ELECTRIC  | 2    |         |
| 11      | 36775-98J00 | HOLDER, BCM LH                  | AR   |         |
| 12      | 36776-98J00 | HOLDER, BCM RH                  | AR   |         |
| 13      | 36622-98J00 | HARNESS ASSY, DUAL STATION MAIN | AR   |         |
| 14      | 09481-10501 | .FUSE (10A)                     | AR   |         |
| 15      | 36624-98J02 | HARNESS ASSY, BCM NO.2 FOR SNGL | 1    |         |
| 16      | 36615-96300 | .TERMINAL                       | 2    |         |
| 17      | 36621-98J00 | HARNESS ASSY, DUAL ENGINE       | AR   |         |
| 18      | 36623-98J30 | HARNESS ASSY, BCM NO.1 FOR MULT | 1    |         |
| 19      | 36615-96300 | .TERMINAL                       | 5    |         |
| 20      | 36624-98J11 | HARNESS ASSY, BCM NO.2 FOR MULT | 1    |         |
| 21      | 36615-96300 | .TERMINAL                       | 2    |         |
| 22      | 36621-98J10 | HARNESS ASSY, TRIPLE ENGINE     | 1    |         |
| 23      | 09403-13402 | CLAMP (ID:13)                   | AR   |         |

FIG.522B



DF140BG\_E11\_022\_522B  
OPT:HARNESS (1)

FIG.522B (1-H-6) OPT:HARNESS (1) (022)

| REF NO. | PART NO.    | DESCRIPTION                           | Q'TY | REMARKS |
|---------|-------------|---------------------------------------|------|---------|
| 1       | 36620-98L00 | WIRE ASSY, REMOTE CONTROL<br>(L:6500) | 1    |         |
| 2       | 33925-98L00 | CUSHION, ENGINE CONTROL UNIT          | AR   |         |
| 3       | 33926-98L00 | RESISTOR, TERMINAL                    | AR   |         |
| 4       | 36623-98L00 | HARNESS ASSY, BCM NO.1 SNGL           | 1    |         |
| 5       | 36615-96300 | .TERMINAL                             | 1    |         |
| 6       | 36770-98L00 | CONTROLLER ASSY, BOAT ELECTRIC        | AR   |         |
| 7       | 36775-98L00 | HOLDER, BCM                           | AR   |         |
| 8       | 36776-98L00 | HOLDER, BCM                           | AR   |         |
| 9       | 36622-98L00 | HARNESS ASSY, DUAL STATION<br>MAIN    | 1    |         |
| 10      | 09481-10501 | .FUSE (10A)                           | 1    |         |
| 11      | 36624-98L00 | HARNESS ASSY, BCM NO.2 SNGL           | 1    |         |
| 12      | 36615-96300 | .TERMINAL                             | 1    |         |
| 13      | 36621-98L00 | HARNESS ASSY, DUAL ENGINE             | AR   |         |
| 14      | 36623-98L30 | HARNESS ASSY, BCM NO.1 FOR<br>MULT    | 1    |         |
| 15      | 36615-96300 | .TERMINAL                             | 1    |         |
| 16      | 36623-98L10 | HARNESS ASSY, BCM NO.1 FOR<br>MULT    | 1    |         |
| 17      | 36615-96300 | .TERMINAL                             | 1    |         |
| 18      | 36624-98L10 | HARNESS ASSY, BCM NO.2 MULTI          | 1    |         |
| 19      | 36615-96300 | .TERMINAL                             | 1    |         |
| 20      | 36624-98L20 | HARNESS ASSY, BCM NO.2 QDRPL          | 1    |         |
| 21      | 36615-96300 | .TERMINAL                             | 1    |         |
| 22      | 36612-98J20 | CONNECTOR, COUNTER SELECT             | AR   |         |
| 23      | 36667-96L60 | WIRE, GAUGE EXT                       | 1    |         |
| 24      | 36990-87D00 | TERMINAL & SLEEVE SET                 | 1    |         |
| 25      | 09403-13402 | CLAMP (ID:13)                         | AR   |         |
| 26      | 37140-98L00 | UNIT, SIGNAL CONVERTER                | 1    |         |
| 27      | 38860-96L10 | RELAY ASSY                            | 1    |         |

DF140BG\_E11\_022

FIG.523A




FIG.523A (1-H-7) OPT:HARNESS (2) (021)

| REF NO. | PART NO.    | DESCRIPTION                     | Q'TY | REMARKS |
|---------|-------------|---------------------------------|------|---------|
| 1       | 36625-98J10 | WIRE ASSY, BATTERY (L:2250)     | AR   |         |
| 2       | 09481-30501 | .FUSE (30A)                     | AR   |         |
| 3       | 36623-98J40 | HARNESS ASSY, BCM FOR QUADRUPLE | 1    |         |
| 4       | 36615-96300 | .TERMINAL                       | 8    |         |
| 5       | 36627-98J00 | .HARNESS, R/CON EXTENSION       | 1    |         |

FIG.523B





FIG.523B (1-H-8) OPT:HARNESS (2) (022)

| REF NO. | PART NO.    | DESCRIPTION                  | Q'TY | REMARKS |
|---------|-------------|------------------------------|------|---------|
| 1-1     | 36625-98J10 | WIRE ASSY, BATTERY (L:2250)  | AR   |         |
| 1-2     | 36625-98J20 | WIRE ASSY, BATTERY (L:6100)  | AR   |         |
| 2       | 09481-30501 | .FUSE (30A)                  | AR   |         |
| 3       | 36623-98L40 | HARNESS ASSY, BCM NO.1 QDRPL | 1    |         |
| 4       | 36615-96300 | .TERMINAL                    | 1    |         |
| 5       | 36627-98L00 | HARNESS, R/CON EXT           | 1    |         |
| 6       | 36627-98L10 | HARNESS ASSY, EM SWITCH EXT  | 1    |         |
| 7       | 36615-96300 | .TERMINAL                    | 1    |         |

FIG.530A



DF140BG\_E11\_022\_530A  
OPT:SWITCH

FIG.530A (1-H-9) OPT:SWITCH (021)

| REF NO. | PART NO.    | DESCRIPTION                        | Q'TY | REMARKS |
|---------|-------------|------------------------------------|------|---------|
| 1       | 37100-98J07 | PANEL ASSY, MAIN SWITCH            | 1    |         |
| 2       | 37110-98J02 | .SWITCH ASSY, MAIN                 | 1    |         |
| 3-1     | 37141-99EA0 | ..KEY (941)                        | 1    |         |
| 3-2     | 37141-99EB0 | ..KEY (942)                        | 1    |         |
| 3-3     | 37141-99E00 | ..KEY (931)                        | 1    |         |
| 3-4     | 37141-99E10 | ..KEY (932)                        | 1    |         |
| 3-5     | 37141-99E20 | ..KEY (933)                        | 1    |         |
| 3-6     | 37141-99E30 | ..KEY (934)                        | 1    |         |
| 3-7     | 37141-99E40 | ..KEY (935)                        | 1    |         |
| 3-8     | 37141-99E50 | ..KEY (936)                        | 1    |         |
| 3-9     | 37141-99E60 | ..KEY (937)                        | 1    |         |
| 3-10    | 37141-99E70 | ..KEY (938)                        | 1    |         |
| 3-11    | 37141-99E80 | ..KEY (939)                        | 1    |         |
| 3-12    | 37141-99E90 | ..KEY (940)                        | 1    |         |
| 4       | 37143-99E01 | ..CAP, KEY                         | 1    |         |
| 5       | 37139-98J10 | .PANEL, MAIN SW                    | 1    |         |
| 6       | 37820-93J11 | .SWITCH ASSY, EMERGENCY            | 1    |         |
| 7       | 37823-92E02 | ..PLATE ASSY, EMERGENCY SW<br>LOCK | 1    |         |
| 8       | 37826-92J10 | ..NUT                              | 1    |         |
| 9       | 03122-05169 | .SCREW                             | 4    |         |
| 10      | 37114-98J00 | .SHEET, MAIN SW PANEL              | 1    |         |
| 11      | 37100-98J11 | PANEL ASSY, SINGLE                 | 1    |         |
| 12      | 37112-98J00 | .NUT                               | 1    |         |
| 13      | 09407-08401 | CLAMP (L:80)                       | AR   |         |
| 14      | 37803-93J06 | PANEL ASSY, EMERGENCY SW           | 1    |         |
| 15      | 37820-93J11 | .SWITCH ASSY, EMERGENCY            | 1    |         |
| 16      | 37823-92E02 | ..PLATE ASSY, EMERGENCY SW<br>LOCK | 1    |         |
| 17      | 37826-92J10 | ..NUT                              | 1    |         |
| 18      | 37825-99E10 | .PANEL, EMERGENCY STOP SW          | 1    |         |
| 19      | 03122-05169 | .SCREW                             | 4    |         |
| 20      | 37100-98J21 | PANEL ASSY, DUAL                   | AR   |         |
| 21      | 37112-98J10 | .NUT                               | AR   |         |
| 22      | 37100-98J31 | PANEL ASSY, TRIPLE                 | 1    |         |
| 23      | 37112-98J10 | .NUT                               | 1    |         |

DF140BG\_E11\_022

FIG.530A




FIG.530A (1-H-10) OPT:SWITCH (021)

| REF NO. | PART NO.    | DESCRIPTION                     | Q'TY | REMARKS |
|---------|-------------|---------------------------------|------|---------|
| 24      | 37860-87L00 | PANEL ASSY, TROLLING CONTROL SW | 1    |         |
| 25      | 37862-87L00 | .PANEL                          | 1    |         |
| 26      | 09131-05004 | .SCREW (5X16)                   | 4    |         |
| 27      | 38500-93J90 | BUZZER, WARNING                 | AR   |         |

FIG.530B





FIG.530B (1-H-11) OPT:SWITCH (022)

| REF NO. | PART NO.    | DESCRIPTION                 | Q'TY | REMARKS |
|---------|-------------|-----------------------------|------|---------|
| 1       | 37100-98L00 | PANEL ASSY, MAIN SWITCH     | 1    |         |
| 2       | 37110-98L00 | ..SWITCH ASSY, MAIN         | 1    |         |
| 3-1     | 37141-98L00 | ..KEY (931)                 | 1    |         |
| 3-2     | 37141-98L10 | ..KEY (932)                 | 1    |         |
| 3-3     | 37141-98L20 | ..KEY (933)                 | 1    |         |
| 3-4     | 37141-98L30 | ..KEY (934)                 | 1    |         |
| 3-5     | 37141-98L40 | ..KEY (935)                 | 1    |         |
| 3-6     | 37141-98L50 | ..KEY (936)                 | 1    |         |
| 3-7     | 37141-98L60 | ..KEY (937)                 | 1    |         |
| 3-8     | 37141-98L70 | ..KEY (938)                 | 1    |         |
| 3-9     | 37141-98L80 | ..KEY (939)                 | 1    |         |
| 3-10    | 37141-98L90 | ..KEY (940)                 | 1    |         |
| 3-11    | 37141-98LA0 | ..KEY (941)                 | 1    |         |
| 3-12    | 37141-98LB0 | ..KEY (942)                 | 1    |         |
| 4-1     | 37141-99E00 | ..KEY (931)                 | 1    |         |
| 4-2     | 37141-99E10 | ..KEY (932)                 | 1    |         |
| 4-3     | 37141-99E20 | ..KEY (933)                 | 1    |         |
| 4-4     | 37141-99E30 | ..KEY (934)                 | 1    |         |
| 4-5     | 37141-99E40 | ..KEY (935)                 | 1    |         |
| 4-6     | 37141-99E50 | ..KEY (936)                 | 1    |         |
| 4-7     | 37141-99E60 | ..KEY (937)                 | 1    |         |
| 4-8     | 37141-99E70 | ..KEY (938)                 | 1    |         |
| 4-9     | 37141-99E80 | ..KEY (939)                 | 1    |         |
| 4-10    | 37141-99E90 | ..KEY (940)                 | 1    |         |
| 4-11    | 37141-99EA0 | ..KEY (941)                 | 1    |         |
| 4-12    | 37141-99EB0 | ..KEY (942)                 | 1    |         |
| 5       | 37138-98L00 | ..COVER, MAIN SW PANEL      | 1    |         |
| 6       | 38500-93J90 | ..BUZZER, WARNING           | 1    |         |
| 7       | 03142-05169 | ..SCREW                     | 4    |         |
| 8       | 37803-98L00 | PANEL ASSY, EMERGENCY SW    | 1    |         |
| 9       | 37820-98L00 | ..SWITCH ASSY, EMERGENCY    | 1    |         |
| 10      | 37823-98L00 | ..PLATE, EMERGENCY SW LOCK  | 1    |         |
| 11      | 37832-98L00 | ..COVER, EMERGENCY SW PANEL | 1    |         |
| 12      | 03142-05169 | ..SCREW                     | 4    |         |
| 13      | 37100-98L10 | PANEL ASSY, MAIN SWITCH     | 1    |         |
| 14      | 37110-98L00 | ..SWITCH ASSY, MAIN         | 1    |         |

FIG.530B




DF140BG\_E11\_022\_530B  
OPT:SWITCH

FIG.530B (1-H-12) OPT:SWITCH (022)

| REF NO. | PART NO.    | DESCRIPTION                   | Q'TY | REMARKS |
|---------|-------------|-------------------------------|------|---------|
| 15-1    | 37141-98L00 | ..KEY (931)                   | 1    |         |
| 15-2    | 37141-98L10 | ..KEY (932)                   | 1    |         |
| 15-3    | 37141-98L20 | ..KEY (933)                   | 1    |         |
| 15-4    | 37141-98L30 | ..KEY (934)                   | 1    |         |
| 15-5    | 37141-98L40 | ..KEY (935)                   | 1    |         |
| 15-6    | 37141-98L50 | ..KEY (936)                   | 1    |         |
| 15-7    | 37141-98L60 | ..KEY (937)                   | 1    |         |
| 15-8    | 37141-98L70 | ..KEY (938)                   | 1    |         |
| 15-9    | 37141-98L80 | ..KEY (939)                   | 1    |         |
| 15-10   | 37141-98L90 | ..KEY (940)                   | 1    |         |
| 15-11   | 37141-98LA0 | ..KEY (941)                   | 1    |         |
| 15-12   | 37141-98LB0 | ..KEY (942)                   | 1    |         |
| 16-1    | 37141-99E00 | ..KEY (931)                   | 1    |         |
| 16-2    | 37141-99E10 | ..KEY (932)                   | 1    |         |
| 16-3    | 37141-99E20 | ..KEY (933)                   | 1    |         |
| 16-4    | 37141-99E30 | ..KEY (934)                   | 1    |         |
| 16-5    | 37141-99E40 | ..KEY (935)                   | 1    |         |
| 16-6    | 37141-99E50 | ..KEY (936)                   | 1    |         |
| 16-7    | 37141-99E60 | ..KEY (937)                   | 1    |         |
| 16-8    | 37141-99E70 | ..KEY (938)                   | 1    |         |
| 16-9    | 37141-99E80 | ..KEY (939)                   | 1    |         |
| 16-10   | 37141-99E90 | ..KEY (940)                   | 1    |         |
| 16-11   | 37141-99EA0 | ..KEY (941)                   | 1    |         |
| 16-12   | 37141-99EB0 | ..KEY (942)                   | 1    |         |
| 17      | 37138-98L10 | ..COVER, MAIN SW PANEL VERT   | 1    |         |
| 18      | 37820-98L00 | ..SWITCH ASSY, EMERGENCY      | 1    |         |
| 19      | 37823-98L00 | ..PLATE, EMERGENCY SW LOCK    | 1    |         |
| 20      | 38500-93J90 | ..BUZZER, WARNING             | 1    |         |
| 21      | 03142-05169 | ..SCREW                       | 4    |         |
| 22      | 37100-98L20 | PANEL ASSY, MAIN SWITCH HORIZ | 1    |         |
| 23      | 37110-98L00 | ..SWITCH ASSY, MAIN           | 1    |         |

DF140BG\_E11\_022

FIG.530B



DF140BG\_E11\_022\_530B  
OPT:SWITCH

FIG.530B (1-H-13) OPT:SWITCH (022)

| REF NO. | PART NO.    | DESCRIPTION                   | Q'TY | REMARKS |
|---------|-------------|-------------------------------|------|---------|
| 24-1    | 37141-98L00 | ..KEY (931)                   | 1    |         |
| 24-2    | 37141-98L10 | ..KEY (932)                   | 1    |         |
| 24-3    | 37141-98L20 | ..KEY (933)                   | 1    |         |
| 24-4    | 37141-98L30 | ..KEY (934)                   | 1    |         |
| 24-5    | 37141-98L40 | ..KEY (935)                   | 1    |         |
| 24-6    | 37141-98L50 | ..KEY (936)                   | 1    |         |
| 24-7    | 37141-98L60 | ..KEY (937)                   | 1    |         |
| 24-8    | 37141-98L70 | ..KEY (938)                   | 1    |         |
| 24-9    | 37141-98L80 | ..KEY (939)                   | 1    |         |
| 24-10   | 37141-98L90 | ..KEY (940)                   | 1    |         |
| 24-11   | 37141-98LA0 | ..KEY (941)                   | 1    |         |
| 24-12   | 37141-98LB0 | ..KEY (942)                   | 1    |         |
| 25-1    | 37141-99E00 | ..KEY (931)                   | 1    |         |
| 25-2    | 37141-99E10 | ..KEY (932)                   | 1    |         |
| 25-3    | 37141-99E20 | ..KEY (933)                   | 1    |         |
| 25-4    | 37141-99E30 | ..KEY (934)                   | 1    |         |
| 25-5    | 37141-99E40 | ..KEY (935)                   | 1    |         |
| 25-6    | 37141-99E50 | ..KEY (936)                   | 1    |         |
| 25-7    | 37141-99E60 | ..KEY (937)                   | 1    |         |
| 25-8    | 37141-99E70 | ..KEY (938)                   | 1    |         |
| 25-9    | 37141-99E80 | ..KEY (939)                   | 1    |         |
| 25-10   | 37141-99E90 | ..KEY (940)                   | 1    |         |
| 25-11   | 37141-99EA0 | ..KEY (941)                   | 1    |         |
| 25-12   | 37141-99EB0 | ..KEY (942)                   | 1    |         |
| 26      | 37138-98L20 | ..COVER, MAIN SW PANEL HORIZ  | 1    |         |
| 27      | 37820-98L00 | ..SWITCH ASSY, EMERGENCY      | 1    |         |
| 28      | 37823-98L00 | ..PLATE, EMERGENCY SW LOCK    | 1    |         |
| 29      | 38500-93J90 | ..BUZZER, WARNING             | 1    |         |
| 30      | 03142-05169 | ..SCREW                       | 4    |         |
| 31      | 37100-98L30 | PANEL ASSY, MAIN SWITCH MULTI | 1    |         |
| 32      | 37110-98L00 | ..SWITCH ASSY, MAIN           | 2    |         |

DF140BG\_E11\_022

FIG.530B





FIG.530B (1-H-14) OPT:SWITCH (022)

| REF NO. | PART NO.    | DESCRIPTION                     | Q'TY | REMARKS |
|---------|-------------|---------------------------------|------|---------|
| 33-1    | 37141-98L00 | ..KEY (931)                     | 2    |         |
| 33-2    | 37141-98L10 | ..KEY (932)                     | 2    |         |
| 33-3    | 37141-98L20 | ..KEY (933)                     | 2    |         |
| 33-4    | 37141-98L30 | ..KEY (934)                     | 2    |         |
| 33-5    | 37141-98L40 | ..KEY (935)                     | 2    |         |
| 33-6    | 37141-98L50 | ..KEY (936)                     | 2    |         |
| 33-7    | 37141-98L60 | ..KEY (937)                     | 2    |         |
| 33-8    | 37141-98L70 | ..KEY (938)                     | 2    |         |
| 33-9    | 37141-98L80 | ..KEY (939)                     | 2    |         |
| 33-10   | 37141-98L90 | ..KEY (940)                     | 2    |         |
| 33-11   | 37141-98LA0 | ..KEY (941)                     | 2    |         |
| 33-12   | 37141-98LB0 | ..KEY (942)                     | 2    |         |
| 34-1    | 37141-99E00 | ..KEY (931)                     | 2    |         |
| 34-2    | 37141-99E10 | ..KEY (932)                     | 2    |         |
| 34-3    | 37141-99E20 | ..KEY (933)                     | 2    |         |
| 34-4    | 37141-99E30 | ..KEY (934)                     | 2    |         |
| 34-5    | 37141-99E40 | ..KEY (935)                     | 2    |         |
| 34-6    | 37141-99E50 | ..KEY (936)                     | 2    |         |
| 34-7    | 37141-99E60 | ..KEY (937)                     | 2    |         |
| 34-8    | 37141-99E70 | ..KEY (938)                     | 2    |         |
| 34-9    | 37141-99E80 | ..KEY (939)                     | 2    |         |
| 34-10   | 37141-99E90 | ..KEY (940)                     | 2    |         |
| 34-11   | 37141-99EA0 | ..KEY (941)                     | 2    |         |
| 34-12   | 37141-99EB0 | ..KEY (942)                     | 2    |         |
| 35      | 37138-98L30 | ..COVER, MAIN SW PANEL MULTIPLE | 1    |         |
| 36      | 37820-98L00 | ..SWITCH ASSY, EMERGENCY        | 1    |         |
| 37      | 37823-98L00 | ..PLATE, EMERGENCY SW LOCK      | 1    |         |
| 38      | 38500-93J90 | ..BUZZER, WARNING               | 2    |         |
| 39      | 03142-05169 | ..SCREW                         | 4    |         |
| 40      | 37860-98L00 | PANEL ASSY, TROLLING CONTROL SW | 1    |         |
| 41      | 37865-98L00 | ..COVER, TROLLING CONTROL SW    | 1    |         |
| 42      | 03142-05169 | ..SCREW                         | 4    |         |
| 43      | 37120-98L00 | PANEL ASSY, DUAL                | 1    |         |
| 44      | 37112-98J10 | ..NUT                           | 1    |         |
| 45      | 37120-98L10 | PANEL ASSY, TRIPLE              | 1    |         |

FIG.530B



DF140BG\_E11\_022\_530B  
OPT:SWITCH

FIG.530B (1-H-15) OPT:SWITCH (022)

| REF NO. | PART NO.    | DESCRIPTION               | Q'TY | REMARKS |
|---------|-------------|---------------------------|------|---------|
| 46      | 37112-98J10 | .NUT                      | 1    |         |
| 47      | 37120-98L20 | PANEL ASSY, QDRPL PORT    | 1    |         |
| 48      | 37112-98J10 | .NUT                      | 1    |         |
| 49      | 37120-98L30 | PANEL ASSY, QDRPL STBD    | 1    |         |
| 50      | 37112-98J10 | .NUT                      | 1    |         |
| 51      | 37120-98L40 | PANEL ASSY, QUINTUPLE     | 1    |         |
| 52      | 37112-98J10 | .NUT                      | 1    |         |
| 53      | 37120-98L50 | PANEL ASSY, SEXTUPLE PORT | 1    |         |
| 54      | 37112-98J10 | .NUT                      | 1    |         |
| 55      | 37120-98L60 | PANEL ASSY, SEXTUPLE STBD | 1    |         |
| 56      | 37112-98J10 | .NUT                      | 1    |         |
| 57      | 38500-93J90 | BUZZER, WARNING           | 1    |         |
| 58      | 09407-08401 | CLAMP (L:80)              | AR   |         |

DF140BG\_E11\_022

FIG.535A




FIG.535A (1-I-2) OPT:KEY LESS START (E11:021)

| REF NO. | PART NO.    | DESCRIPTION                       | Q'TY | REMARKS    |
|---------|-------------|-----------------------------------|------|------------|
| 1       | 37100-96L02 | PANEL ASSY, MAIN SWITCH           | 1    |            |
| 2       | 37110-96L00 | .SWITCH ASSY, MAIN                | 1    |            |
| 3-1     | 37141-99E00 | ..KEY (931)                       | 1    |            |
| 3-2     | 37141-99E10 | ..KEY (932)                       | 1    |            |
| 3-3     | 37141-99E20 | ..KEY (933)                       | 1    |            |
| 3-4     | 37141-99E30 | ..KEY (934)                       | 1    |            |
| 3-5     | 37141-99E40 | ..KEY (935)                       | 1    |            |
| 3-6     | 37141-99E50 | ..KEY (936)                       | 1    |            |
| 4       | 37143-96L00 | ..KNOB, MAIN SWITCH               | 1    |            |
| 5       | 37114-98J00 | .SHEET, MAIN SW PANEL             | 1    |            |
| 6       | 37139-96L30 | .PANEL, MAIN SWITCH               | 1    |            |
| 7       | 37820-93J11 | .SWITCH ASSY, EMERGENCY           | 1    |            |
| 8       | 37823-92E02 | ..PLATE ASSY, EMERGENCY SW LOCK   | 1    |            |
| 9       | 37826-92J10 | ..NUT                             | 1    |            |
| 10      | 03122-05169 | .SCREW                            | 4    |            |
| 11      | 37105-96L04 | HARNESS SET, KLS CONTROLLER       | 1    |            |
| 12      | 32980-38F00 | ..CUSHION, CDI UNIT               | 1    |            |
| 13      | 36623-96L02 | ..HARNESS ASSY, KLS CONTROLLER    | 1    |            |
| 14      | 36615-96300 | ..TERMINAL                        | 1    |            |
| 15      | 36662-96L01 | ..HARNESS ASSY, KLS CAN           | 1    |            |
| 16      | 37173-96L10 | ..HOLDER, KLS PARTS               | 1    | SMALL TYPE |
| 17      | 38500-93J90 | ..BUZZER, WARNING                 | 1    |            |
| 18      | 38860-96L01 | ..RELAY ASSY, KLS                 | 1    |            |
| 19      | 32851-93J00 | ..CUSHION, LEAD WIRE              | 1    |            |
| 20      | 09407-14407 | ..CLAMP (L:145)                   | 1    |            |
| 21-1    | 37170-96L06 | CONTROLLER SET, KLS (433MHZ)      | 1    | 433MHZ     |
| 21-2    | 37170-96L16 | CONTROLLER SET, KLS (315MHZ)      | 1    | 315MHZ     |
| 22      | 37117-96L00 | ..DECAL, KLS                      | 2    |            |
| 23-1    | 37171-96L02 | ..CONTROLLER ASSY, KLS (433MHZ)   | 1    | 433MHZ     |
| 23-2    | 37171-96L12 | ..CONTROLLER ASSY, KLS (315MHZ)   | 1    | 315MHZ     |
| 24-1    | 37172-96L02 | ..REMOCON ASSY, KLS (433MHZ)      | 2    | 433MHZ     |
| 24-2    | 37172-96L11 | ..REMOCON ASSY, KLS (315MHZ)      | 2    | 315MHZ     |
| 25      | 36663-96L00 | WIRE, KLS CAN EXT                 | 1    |            |
| 26      | 36664-96L00 | HARNESS ASSY, KLS CAN (L:810+110) | AR   |            |

FIG.535A




FIG.535A (1-I-3) OPT:KEY LESS START (E11:021)

| REF NO. | PART NO.    | DESCRIPTION       | Q'TY | REMARKS    |
|---------|-------------|-------------------|------|------------|
| 27      | 37173-96L00 | HOLDER, KLS PARTS | 1    | LARGE TYPE |

FIG.535B




FIG.535B (1-I-4) OPT:KEY LESS START (E11:022)

| REF NO. | PART NO.    | DESCRIPTION                        | Q'TY | REMARKS |
|---------|-------------|------------------------------------|------|---------|
| 1       | 37290-98L00 | PANEL ASSY, ENG START SW           | 1    |         |
| 2       | 37292-98L00 | .COVER, ENG START PANEL            | 1    |         |
| 3       | 03142-05169 | .SCREW                             | 4    |         |
| 4       | 37290-98L10 | PANEL ASSY, ENG START SW VERT      | 1    |         |
| 5       | 37292-98L10 | .COVER, ENG START PANEL VERT       | 1    |         |
| 6       | 37820-98L00 | .SWITCH ASSY, EMERGENCY            | 1    |         |
| 7       | 37823-98L00 | ..PLATE, EMERGENCY SW LOCK         | 1    |         |
| 8       | 03142-05169 | .SCREW                             | 4    |         |
| 9       | 37290-98L20 | PANEL ASSY, ENG START SW HORIZ     | 1    |         |
| 10      | 37292-98L20 | .COVER, ENG START PANEL HORIZ      | 1    |         |
| 11      | 37820-98L00 | .SWITCH ASSY, EMERGENCY            | 1    |         |
| 12      | 37823-98L00 | ..PLATE, EMERGENCY SW LOCK         | 1    |         |
| 13      | 03142-05169 | .SCREW                             | 4    |         |
| 14-1    | 37105-98L00 | KIT, KLS (433MHZ)                  | 1    | 433MHZ  |
| 14-2    | 37105-98L10 | KIT, KLS (315MHZ)                  | 1    | 315MHZ  |
| 15      | 32851-93J00 | .CUSHION, LEAD WIRE                | 1    |         |
| 16      | 32980-38F00 | .CUSHION, CDI UNIT                 | 1    |         |
| 17      | 36623-98LA0 | .HARNESS ASSY, KLS CONT            | 1    |         |
| 18      | 36615-96300 | ..TERMINAL                         | 1    |         |
| 19      | 37117-96L00 | .DECAL, KLS                        | 2    |         |
| 20-1    | 37171-98L00 | .CONTROLLER ASSY, KLS 433 (433MHZ) | 1    | 433MHZ  |
| 20-2    | 37171-98L10 | .CONTROLLER ASSY, KLS 315 (315MHZ) | 1    | 315MHZ  |
| 21-1    | 37172-96L02 | .REMOCON ASSY, KLS (433MHZ)        | 2    | 433MHZ  |
| 21-2    | 37172-96L11 | .REMOCON ASSY, KLS (315MHZ)        | 2    | 315MHZ  |
| 22      | 37173-96L10 | .HOLDER, KLS PARTS                 | 1    |         |
| 23      | 38500-93J90 | .BUZZER, WARNING                   | 1    |         |
| 24      | 38860-96L01 | .RELAY ASSY, KLS                   | 1    |         |
| 25      | 09407-14407 | .CLAMP (L:145)                     | 1    |         |
| 26      | 36627-98L20 | HARNESS, CAN EXT                   | 1    |         |

FIG.540A




FIG.540A (1-I-5) OPT:REMOTE CONTROL ASSY DUAL (021)

| REF NO. | PART NO.    | DESCRIPTION                         | Q'TY | REMARKS |
|---------|-------------|-------------------------------------|------|---------|
| 1       | 67200-98J16 | REMOTE CONTROL ASSY, MULTIPLE       | 1    |         |
| 2       | 67211-98J20 | .HOUSING                            | 1    |         |
| 3       | 67251-98J00 | .LEVER, HANDLE                      | 2    |         |
| 4       | 67246-98J10 | .SHAFT, DRIVE REMOCON               | 1    |         |
| 5       | 67261-98J00 | .GRIP, NO.1                         | 1    |         |
| 6       | 67261-98J10 | .GRIP, NO.2                         | 1    |         |
| 7       | 67263-98J00 | .COVER, LEVER                       | 2    |         |
| 8       | 67212-98J30 | .COVER, REMOCON UPPER               | 1    | UPPER   |
| 9       | 67271-98J40 | .COVER, REMOCON BOTTOM              | 1    |         |
| 10      | 67222-98J10 | .PANEL ASSY, BACK                   | 1    |         |
| 11      | 67236-98J10 | .ROLLER, DETENT                     | 2    |         |
| 12      | 67235-98J10 | .GUIDE, DETENT ROLLER               | 2    |         |
| 13      | 67237-98J40 | .SPRING, DETENT                     | 2    |         |
| 14      | 67233-98J10 | .HOLDER, DETENT SPRING              | 2    |         |
| 15      | 67287-92E00 | .NUT (M5)                           | 2    |         |
| 16      | 67239-98J00 | .SCREW, DETENT ADJUSTMENT<br>(5X14) | 2    |         |
| 17      | 67223-98J00 | .PAD, BRAKE                         | 2    |         |
| 18      | 67296-98J50 | .SCREW (5X18)                       | 8    |         |
| 19      | 67296-98JA0 | .SCREW (4X10)                       | 2    |         |
| 20      | 67272-98J10 | .GROMMET, REMOCON COVER             | 2    |         |
| 21      | 67252-98J10 | .BUSH, DRIVE SHAFT                  | 2    |         |
| 22      | 67288-98J20 | .WASHER                             | 2    |         |
| 23      | 67292-98J00 | .C RING                             | 2    |         |
| 24      | 15980-98J00 | .POTENTIOMETER                      | 2    |         |
| 25      | 67227-98J10 | .LEVER, POTENTIOMETER NO.2          | 1    |         |
| 26      | 37850-98J03 | .SWITCH ASSY, PTT                   | 1    |         |
| 27      | 67269-98J01 | .CLAMP, LEAD                        | 1    |         |
| 28      | 67273-98J20 | .PACKING                            | 1    |         |
| 29      | 67296-98J60 | .SCREW (8X30)                       | 2    |         |
| 30      | 67296-98J30 | .SCREW (5X70)                       | 4    |         |
| 31      | 67296-98JG0 | .SCREW (5X14)                       | 2    |         |
| 32      | 67296-98J00 | .SCREW (5X12)                       | 1    |         |
| 33      | 67296-94300 | .SCREW (4X10)                       | 4    |         |
| 34      | 67288-98J40 | .WASHER, BOTTOM COVER               | 14   |         |
| 35      | 67288-98J00 | .WASHER, POTENTIOMETER              | 4    |         |

FIG.540A





FIG.540A (1-I-6) OPT:REMOTE CONTROL ASSY DUAL (021)

| REF NO. | PART NO.    | DESCRIPTION                        | Q'TY | REMARKS |
|---------|-------------|------------------------------------|------|---------|
| 36      | 67288-92E20 | .WASHER                            | 2    |         |
| 37      | 67226-98J00 | .BOLT (5X50)                       | 4    |         |
| 38      | 09160-05024 | .WASHER (5.5X16X1.5)               | 4    |         |
| 39      | 67287-92E00 | .NUT (M5)                          | 4    |         |
| 40      | 67296-98J90 | .SCREW (8X30)                      | 2    |         |
| 41      | 67227-98J00 | .LEVER, POTENTIOMETER NO.1         | 1    |         |
| 42      | 67284-98J10 | .MARK                              | 1    |         |
| 43      | 67257-98J00 | .MARK, LEVER                       | 2    |         |
| 44      | 67269-98J30 | .BAND                              | 1    |         |
| 45      | 67288-98J10 | .WASHER, SPRING                    | 16   |         |
| 46      | 67288-98J30 | .WASHER, LEVER COVER               | 2    |         |
| 47      | 67228-98J50 | .WASHER, WAVE                      | 2    |         |
| 48      | 67211-98J30 | .HOUSING, REMOCON                  | 1    |         |
| 49      | 67222-98J20 | .PANEL ASSY, BACK                  | 1    |         |
| 50      | 67246-98J20 | .SHAFT, DRIVE REMOCON              | 1    |         |
| 51      | 67273-98J10 | .PACKING, FRONT                    | 1    |         |
| 52      | 67273-98J30 | .PACKING, REAR                     | 1    |         |
| 53      | 67277-98J00 | .GROMMET, REMOCON BOTTOM COVER     | 1    |         |
| 54      | 67296-98JF0 | .BOLT, UPPER COVER (5X14)          | 1    |         |
| 55      | 67297-98J00 | .NUT, UPPER COVER BOLT             | 1    |         |
| 56      | 67237-98J50 | .SPRING, DETENT                    | 2    |         |
| 57      | 36890-98J00 | .HARNESS, CONDENSER ADAPTER        | 1    |         |
| 58-1    | 36620-98J33 | WIRE ASSY, REMOTE CONTROL (L:6500) | 1    |         |
| 58-2    | 36620-98J43 | WIRE ASSY, REMOTE CONTROL (L:9500) | 1    |         |

FIG.540B



DF140BG\_E11\_022\_540B  
OPT:REMOTE CONTROL ASSY DUAL

FIG.540B (1-I-7) OPT:REMOTE CONTROL ASSY DUAL (022)

| REF NO. | PART NO.    | DESCRIPTION                               | Q'TY | REMARKS |
|---------|-------------|-------------------------------------------|------|---------|
| 1       | 67200-98L10 | R/CON ASSY, MULTIPLE TOP MOUNT            | 1    |         |
| 2       | 37130-98L10 | .SWITCH ASSY, BOAT CONTROL                | 1    |         |
| 3       | 37850-98L00 | .SWITCH ASSY, PTT                         | 1    |         |
| 4       | 67212-98L10 | .COVER, R/CON UPPER                       | 1    |         |
| 5       | 67284-98L00 | ..MARK, HANDLE LEVER                      | 1    |         |
| 6       | 67284-98L10 | ..MARK, HANDLE LEVER                      | 1    |         |
| 7       | 68111-88L00 | ..EMBLEM, MARK                            | 1    |         |
| 8       | 67226-98J00 | .BOLT (5X50)                              | 4    |         |
| 9       | 67261-98L00 | .GRIP, R/CON NO.1                         | 2    |         |
| 10      | 67261-98L10 | .GRIP, R/CON NO.2                         | 1    |         |
| 11      | 67261-98L20 | .GRIP, R/CON NO.3                         | 1    |         |
| 12      | 67269-98L00 | .CLAMP, LEAD                              | 1    |         |
| 13      | 67271-98L10 | .COVER, R/CON BOTTOM                      | 1    |         |
| 14      | 67272-98L10 | .GROMMET, R/CON COVER                     | 2    |         |
| 15      | 67273-98L10 | .PACKING, R/CON                           | 1    |         |
| 16      | 67277-98L10 | .GROMMET, R/CON GRIP                      | 2    |         |
| 17      | 67277-98L20 | .GROMMET, R/CON BOTTOM COVER              | 1    |         |
| 18      | 67287-92E00 | .NUT (M5)                                 | 4    |         |
| 19      | 67288-98J40 | .WASHER, BOTTOM COVER                     | 12   |         |
| 20      | 67296-98J50 | .SCREW (5X18)                             | 6    |         |
| 21      | 67296-98L00 | .SCREW                                    | 3    |         |
| 22      | 67296-98L10 | .BOLT, UPPER COVER                        | 1    |         |
| 23      | 67297-98J00 | .NUT, UPPER COVER BOLT                    | 1    |         |
| 24      | 09160-05024 | .WASHER (5.5X16X1.5)                      | 4    |         |
| 25      | 09125-04021 | .SCREW                                    | 4    |         |
| 26-1    | 36620-98L00 | WIRE ASSY, REMOTE CONTROL<br>(L:6500)     | 1    |         |
| 26-2    | 36620-98L10 | WIRE ASSY, REMOTE CONTROL<br>(L:9500)     | 1    |         |
| 26-3    | 36620-98L20 | WIRE ASSY, REMOTE CONTROL EXT<br>(L:2000) | 1    |         |
| 27      | 38500-93J90 | BUZZER, WARNING                           | 1    |         |
| 28      | 09407-08401 | CLAMP (L:80)                              | AR   |         |

DF140BG\_E11\_022

FIG.543A





FIG.543A (1-I-8) OPT:REMOTE CONTROL ASSY SINGLE (021)

| REF NO. | PART NO.    | DESCRIPTION                      | Q'TY | REMARKS |
|---------|-------------|----------------------------------|------|---------|
| 1       | 67200-98J06 | REMOTE CONTROL ASSY, SINGLE      | 1    |         |
| 2       | 67211-98J20 | .HOUSING                         | 1    |         |
| 3       | 67251-98J00 | .LEVER, HANDLE                   | 1    |         |
| 4       | 67246-98J10 | .SHAFT, DRIVE REMOCON            | 1    |         |
| 5       | 67261-98J00 | .GRIP, NO.1                      | 1    |         |
| 6       | 67263-98J00 | .COVER, LEVER                    | 1    |         |
| 7       | 67212-98J20 | .COVER, REMOCON UPPER            | 1    | UPPER   |
| 8       | 67271-98J30 | .COVER, REMOCON BOTTOM           | 1    |         |
| 9       | 67222-98J10 | .PANEL ASSY, BACK                | 1    |         |
| 10      | 67236-98J10 | .ROLLER, DETENT                  | 1    |         |
| 11      | 67235-98J10 | .GUIDE, DETENT ROLLER            | 1    |         |
| 12      | 67237-98J30 | .SPRING, DETENT                  | 1    |         |
| 13      | 67233-98J10 | .HOLDER, DETENT SPRING           | 1    |         |
| 14      | 67287-92E00 | .NUT (M5)                        | 1    |         |
| 15      | 67239-98J00 | .SCREW, DETENT ADJUSTMENT (5X14) | 1    |         |
| 16      | 67223-98J00 | .PAD, BRAKE                      | 1    |         |
| 17      | 67296-98J50 | .SCREW (5X18)                    | 6    |         |
| 18      | 67296-98JA0 | .SCREW (4X10)                    | 1    |         |
| 19      | 67272-98J10 | .GROMMET, REMOCON COVER          | 1    |         |
| 20      | 67252-98J10 | .BUSH, DRIVE SHAFT               | 1    |         |
| 21      | 67288-98J20 | .WASHER                          | 1    |         |
| 22      | 67292-98J00 | .C RING                          | 1    |         |
| 23      | 15980-98J00 | .POTENTIOMETER                   | 1    |         |
| 24      | 67227-98J10 | .LEVER, POTENTIOMETER NO.2       | 1    |         |
| 25      | 37850-98J03 | .SWITCH ASSY, PTT                | 1    |         |
| 26      | 67269-98J01 | .CLAMP, LEAD                     | 1    |         |
| 27      | 67273-98J00 | .PACKING                         | 1    |         |
| 28      | 67296-98J60 | .SCREW (8X30)                    | 1    |         |
| 29      | 67274-98J00 | .FLANGE, BASE                    | 1    |         |
| 30      | 67288-92E20 | .WASHER                          | 1    |         |
| 31      | 67296-98J90 | .SCREW (8X30)                    | 1    |         |
| 32      | 67296-98JG0 | .SCREW (5X14)                    | 1    |         |
| 33      | 67296-94300 | .SCREW (4X10)                    | 2    |         |
| 34      | 67288-98J00 | .WASHER, POTENTIOMETER           | 2    |         |
| 35      | 67296-98J20 | .SCREW (5X50)                    | 2    |         |

FIG.543A



DF140BG\_E11\_022\_543A  
OPT:REMOTE CONTROL ASSY SINGLE

FIG.543A (1-I-9) OPT:REMOTE CONTROL ASSY SINGLE (021)

| REF NO. | PART NO.    | DESCRIPTION                           | Q'TY | REMARKS |
|---------|-------------|---------------------------------------|------|---------|
| 36      | 67226-98J00 | .BOLT (5X50)                          | 4    |         |
| 37      | 09160-05024 | .WASHER (5.5X16X1.5)                  | 4    |         |
| 38      | 67287-92E00 | .NUT (M5)                             | 4    |         |
| 39      | 67296-98J00 | .SCREW (5X12)                         | 1    |         |
| 40      | 67288-98J40 | .WASHER, BOTTOM COVER                 | 12   |         |
| 41      | 67296-98J10 | .SCREW (5X35)                         | 1    |         |
| 42      | 67284-98J10 | .MARK                                 | 1    |         |
| 43      | 67257-98J00 | .MARK, LEVER                          | 1    |         |
| 44      | 67269-98J30 | .BAND                                 | 1    |         |
| 45      | 67288-98J10 | .WASHER, SPRING                       | 8    |         |
| 46      | 67288-98J30 | .WASHER, LEVER COVER                  | 1    |         |
| 47      | 67228-98J50 | .WASHER, WAVE                         | 1    |         |
| 48      | 67273-98J10 | .PACKING, FRONT                       | 1    |         |
| 49      | 67273-98J30 | .PACKING, REAR                        | 1    |         |
| 50      | 67277-98J00 | .GROMMET, REMOCON BOTTOM COVER        | 1    |         |
| 51      | 67296-98JF0 | .BOLT, UPPER COVER (5X14)             | 1    |         |
| 52      | 67297-98J00 | .NUT, UPPER COVER BOLT                | 1    |         |
| 53      | 36890-98J00 | .HARNESS, CONDENSER ADAPTER           | 1    |         |
| 54-1    | 36620-98J33 | WIRE ASSY, REMOTE CONTROL<br>(L:6500) | 1    |         |
| 54-2    | 36620-98J43 | WIRE ASSY, REMOTE CONTROL<br>(L:9500) | 1    |         |

DF140BG\_E11\_022

FIG.543B




FIG.543B (1-I-10) OPT:REMOTE CONTROL ASSY SINGLE (022)

| REF NO. | PART NO.    | DESCRIPTION                               | Q'TY | REMARKS |
|---------|-------------|-------------------------------------------|------|---------|
| 1       | 67200-98L00 | R/CON ASSY, SINGLE TOP MOUNT              | 1    |         |
| 2       | 37130-98L00 | .SWITCH ASSY, BOAT CONTROL                | 1    |         |
| 3       | 37850-98L00 | .SWITCH ASSY, PTT                         | 1    |         |
| 4       | 67212-98L00 | .COVER, R/CON UPPER                       | 1    |         |
| 5       | 67284-98L00 | ..MARK, HANDLE LEVER                      | 1    |         |
| 6       | 68111-88L00 | ..EMBLEM, MARK                            | 1    |         |
| 7       | 67226-98J00 | .BOLT (5X50)                              | 4    |         |
| 8       | 67261-98L00 | .GRIP, R/CON NO.1                         | 1    |         |
| 9       | 67261-98L10 | .GRIP, R/CON NO.2                         | 1    |         |
| 10      | 67269-98L00 | .CLAMP, LEAD                              | 1    |         |
| 11      | 67271-98L00 | .COVER, R/CON BOTTOM                      | 1    |         |
| 12      | 67272-98L00 | .GROMMET, R/CON COVER                     | 1    |         |
| 13      | 67273-98L00 | .PACKING, R/CON                           | 1    |         |
| 14      | 67277-98L00 | .GROMMET, R/CON BOTTOM COVER              | 1    |         |
| 15      | 67277-98L10 | .GROMMET, R/CON GRIP                      | 1    |         |
| 16      | 67287-92E00 | .NUT (M5)                                 | 4    |         |
| 17      | 67288-98J40 | .WASHER, BOTTOM COVER                     | 9    |         |
| 18      | 67296-98J50 | .SCREW (5X18)                             | 3    |         |
| 19      | 67296-98L00 | .SCREW                                    | 2    |         |
| 20      | 67296-98L10 | .BOLT, UPPER COVER                        | 1    |         |
| 21      | 67297-98J00 | .NUT, UPPER COVER BOLT                    | 1    |         |
| 22      | 09160-05024 | .WASHER (5.5X16X1.5)                      | 4    |         |
| 23      | 09125-04021 | .SCREW                                    | 4    |         |
| 24-1    | 36620-98L00 | WIRE ASSY, REMOTE CONTROL<br>(L:6500)     | 1    |         |
| 24-2    | 36620-98L10 | WIRE ASSY, REMOTE CONTROL<br>(L:9500)     | 1    |         |
| 24-3    | 36620-98L20 | WIRE ASSY, REMOTE CONTROL EXT<br>(L:2000) | 1    |         |

FIG.585A





FIG.585A (1-1-11) OPT:GASKET SET

| REF NO. | PART NO.    | DESCRIPTION                         | Q'TY | REMARKS |
|---------|-------------|-------------------------------------|------|---------|
| 1       | 11400-99840 | GASKET SET                          | 1    |         |
| 2       | 11141-99L00 | .GASKET, CYLINDER HEAD              | 1    |         |
| 3       | 11189-90J00 | .GASKET, CYLINDER HEAD COVER        | 1    |         |
| 4       | 11265-87E10 | .GASKET, PROTECTION COVER           | 2    |         |
| 5       | 11489-90J10 | .GASKET, OIL PAN                    | 1    |         |
| 6       | 13119-99L00 | .GASKET, INTAKE MANIFOLD            | 4    |         |
| 7       | 13125-99L00 | .GASKET, THROTTLE BODY              | 1    |         |
| 8       | 14151-90J00 | .GASKET, RECT & REGULATOR           | 1    |         |
| 9       | 16941-99L00 | .GASKET, OIL LVL GAGE GUIDE<br>CASE | 1    |         |
| 10      | 17472-87E10 | .GASKET, PUMP CASE PANEL            | 1    |         |
| 11      | 51211-90J30 | .GASKET, ENGINE HOLDER              | 1    |         |

DF140BG\_E11\_022\_601A  
OPT:MULTI FUNCTION GAUGE (1)



DF140BG\_E11\_022

DF140BG\_E11\_022

FIG.601B







FIG.601B (1-I-13) OPT:MULTI FUNCTION GAUGE (1) (022)

| REF NO. | PART NO.    | DESCRIPTION                 | Q'TY | REMARKS |
|---------|-------------|-----------------------------|------|---------|
| 1       | 34011-96L40 | GAUGE SET, MULTI            | 1    |         |
| 2       | 34112-96L00 | .NUT, GAUGE                 | 1    |         |
| 3       | 34193-96L00 | .BEZEL, GAUGE               | 1    |         |
| 4       | 34211-96L00 | .COVER, GAUGE               | 1    |         |
| 5       | 34825-96L00 | .PACKING, GAUGE             | 1    |         |
| 6       | 34011-96L50 | SET, MULTI GAUGE            | 1    |         |
| 7       | 34112-96L00 | .NUT, GAUGE                 | 1    |         |
| 8       | 34193-96L00 | .BEZEL, GAUGE               | 1    |         |
| 9       | 34211-96L00 | .COVER, GAUGE               | 1    |         |
| 10      | 34825-96L00 | .PACKING, GAUGE             | 1    |         |
| 11      | 36662-88L10 | WIRE, 2 EXTENSION           | 1    |         |
| 12      | 36663-88L00 | HARNESS ASSY, NETWORK POWER | 1    |         |
| 13      | 36664-88L00 | CONNECTOR, BRANCH           | 1    |         |
| 14      | 36665-88L00 | UNIT, RESISTOR FEMALE       | 1    |         |
| 15      | 36665-88L10 | UNIT, RESISTOR MALE         | 1    |         |
| 16      | 36667-96L40 | WIRE, DUAL GAUGE ADAPTER    | 1    |         |
| 17      | 36667-96L50 | WIRE, DUAL GAUGE ADAPTER    | 1    |         |

1



| REF NO. | PART NO.    | DESCRIPTION                    | QTY | REMARKS |
|---------|-------------|--------------------------------|-----|---------|
| 1       | 34002-96L17 | KIT, DUAL STATION              | 1   |         |
| 2       | 34011-96L40 | .GAUGE SET, MULTI              | 1   |         |
| 3       | 34112-96L00 | ..NUT, GAUGE                   | 1   |         |
| 4       | 34193-96L00 | ..BEZEL, GAUGE                 | 1   |         |
| 5       | 34211-96L00 | ..COVER, GAUGE                 | 1   |         |
| 6       | 34825-96L00 | ..PACKING, GAUGE               | 1   |         |
| 7       | 36662-88L10 | .WIRE, 2 EXTENSION             | 1   |         |
| 8       | 36664-88L00 | .CONNECTOR, BRANCH             | 1   |         |
| 9       | 36665-96L00 | .ADAPTER, DUAL STATION         | 1   |         |
| 10      | 36666-96L00 | .ADAPTER, GAUGE POWER          | 1   |         |
| 11      | 36682-92E00 | .WIRE, TRIM METER EXT (L:6500) | 1   |         |
| 12      | 34011-96L40 | GAUGE SET, MULTI               | 1   |         |
| 13      | 34112-96L00 | .NUT, GAUGE                    | 1   |         |
| 14      | 34193-96L00 | .BEZEL, GAUGE                  | 1   |         |
| 15      | 34211-96L00 | .COVER, GAUGE                  | 1   |         |
| 16      | 34825-96L00 | .PACKING, GAUGE                | 1   |         |
| 17      | 36001-88L00 | SET, WIRE                      | 1   |         |
| 18      | 36662-88L10 | .WIRE, 2 EXTENSION             | 1   |         |
| 19      | 36663-88L00 | .HARNESS ASSY, NETWORK POWER   | 1   |         |
| 20      | 36664-88L00 | .CONNECTOR, BRANCH             | 1   |         |
| 21      | 36665-88L00 | .UNIT, RESISTOR FEMALE         | 1   |         |
| 22      | 36665-88L10 | .UNIT, RESISTOR MALE           | 1   |         |
| 23      | 34190-88L00 | SENSOR ASSY, PAD WHEEL         | 1   |         |
| 24      | 36662-88L20 | WIRE, 6 EXTENSION              | 1   |         |
| 25      | 36662-88L30 | WIRE, 15 EXTENSION             | 1   |         |
| 26      | 39950-88L02 | MODULE ASSY, GPS RECEIVER      | 1   |         |
| 27      | 36662-88L00 | WIRE, 25 EXTENSION             | 1   |         |
| 28      | 36663-88L00 | HARNESS ASSY, NETWORK POWER    | 1   |         |
| 29      | 36665-88L00 | UNIT, RESISTOR FEMALE          | 1   |         |
| 30      | 36665-88L10 | UNIT, RESISTOR MALE            | 1   |         |
| 31      | 36662-88L10 | WIRE, 2 EXTENSION              | 1   |         |
| 32      | 36664-88L00 | CONNECTOR, BRANCH              | 1   |         |
| 33      | 67237-98J20 | SPRING, DETENT                 | 1   |         |

FIG.602B




FIG.602B (1-J-2) OPT:MULTI FUNCTION GAUGE (2) (022)

| REF NO. | PART NO.    | DESCRIPTION                  | Q'TY | REMARKS |
|---------|-------------|------------------------------|------|---------|
| 1       | 34011-96L40 | GAUGE SET, MULTI             | 1    |         |
| 2       | 34112-96L00 | .NUT, GAUGE                  | 1    |         |
| 3       | 34193-96L00 | .BEZEL, GAUGE                | 1    |         |
| 4       | 34211-96L00 | .COVER, GAUGE                | 1    |         |
| 5       | 34825-96L00 | .PACKING, GAUGE              | 1    |         |
| 6       | 34011-96L50 | SET, MULTI GAUGE             | 1    |         |
| 7       | 34112-96L00 | .NUT, GAUGE                  | 1    |         |
| 8       | 34193-96L00 | .BEZEL, GAUGE                | 1    |         |
| 9       | 34211-96L00 | .COVER, GAUGE                | 1    |         |
| 10      | 34825-96L00 | .PACKING, GAUGE              | 1    |         |
| 11      | 36001-88L00 | SET, WIRE                    | 1    |         |
| 12      | 36662-88L10 | .WIRE, 2 EXTENSION           | 1    |         |
| 13      | 36663-88L00 | .HARNESS ASSY, NETWORK POWER | 1    |         |
| 14      | 36664-88L00 | .CONNECTOR, BRANCH           | 1    |         |
| 15      | 36665-88L00 | .UNIT, RESISTOR FEMALE       | 1    |         |
| 16      | 36665-88L10 | .UNIT, RESISTOR MALE         | 1    |         |
| 17      | 34190-88L00 | SENSOR ASSY, PAD WHEEL       | 1    |         |
| 18      | 36662-88L20 | WIRE, 6 EXTENSION            | 1    |         |
| 19      | 36662-88L30 | WIRE, 15 EXTENSION           | 1    |         |
| 20      | 39950-88L02 | MODULE ASSY, GPS RECEIVER    | 1    |         |
| 21      | 36662-88L00 | WIRE, 25 EXTENSION           | 1    |         |
| 22      | 36663-88L00 | HARNESS ASSY, NETWORK POWER  | 1    |         |
| 23      | 36665-88L00 | UNIT, RESISTOR FEMALE        | 1    |         |
| 24      | 36665-88L10 | UNIT, RESISTOR MALE          | 1    |         |
| 25      | 36662-88L10 | WIRE, 2 EXTENSION            | 1    |         |
| 26      | 36664-88L00 | CONNECTOR, BRANCH            | 1    |         |

| PART NO.        | FIG.NO.-REF.NO. | PART NO.        | FIG.NO.-REF.NO. | PART NO.        | FIG.NO.-REF.NO. |
|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| 10000           |                 | 12220-99L00     | 116A-9          | 12892-69G10-278 | 121A-4-25       |
|                 |                 | 12300-85830     | 116A-12-1       | 12892-69G10-280 | 121A-4-26       |
|                 |                 | 12300-85830-012 | 116A-12-2       | 12892-69G10-283 | 121A-4-27       |
|                 |                 | 12300-85854-OAA | 116A-11-6       | 12892-69G10-285 | 121A-4-28       |
|                 |                 | 12300-85854-OBA | 116A-11-7       | 12892-69G10-288 | 121A-4-29       |
|                 |                 | 12300-85854-OCA | 116A-11-8       | 12892-69G10-290 | 121A-4-30       |
|                 |                 | 12300-85854-ODA | 116A-11-9       | 12892-69G10-293 | 121A-4-31       |
|                 |                 | 12300-85854-OEA | 116A-11-10      | 12892-69G10-295 | 121A-4-32       |
| 11100-99L00     | 111A-1          | 12340-85FB3-OA0 | 116A-11-1       | 12892-69G10-298 | 121A-4-33       |
| 11112-90J00     | 113A-9          | 12340-85FB3-OB0 | 116A-11-2       | 12892-69G10-300 | 121A-4-34       |
| 11115-85FA1-001 | 111A-4          | 12340-85FB3-OC0 | 116A-11-3       | 12911-86FA2     | 121A-5          |
| 11117-89J00     | 111A-10         | 12340-85FB3-OD0 | 116A-11-4       | 12915-86F51     | 121A-6          |
| 11117-90J10     | 113A-4          | 12340-85FB3-OE0 | 116A-11-5       | 12921-90J01     | 121A-7          |
| 11118-95J00     | 204A-1          | 12632-92J12     | 175A-1          | 12931-90J00     | 121A-8          |
| 11141-99L00     | 111A-11         | 12711-99L00     | 121A-1          | 12932-85FA0     | 121A-9          |
| 585A-2          | 111A-15         | 12720-99L00     | 121A-2          | 12933-86510     | 121A-10         |
| 11170-99L00     | 111A-14         | 12732-90J01     | 119A-1          | 13110-99L00     | 122A-1          |
| 11173-99L00     | 111A-16         | 12733-90J00     | 119A-4          | 13119-99L00     | 122A-2          |
| 11174-99L00     | 111A-19         | 12741-90J01     | 119A-2          |                 | 585A-6          |
| 11179-90J00     | 111A-17         | 12761-90J10     | 119A-9          | 13125-99L00     | 122A-3          |
| 11189-90J00     | 585A-3          | 12771-90J00     | 119A-10         |                 | 585A-7          |
| 11194-99L00     | 111A-21         | 12810-90J00     | 119A-11         | 13300-99L00     | 163A-1          |
| 11196-99L00     | 162A-1          | 12812-90J00     | 119A-13         | 13315-99L01     | 163A-2          |
| 11216-90J10     | 113A-5          | 12813-73G00     | 119A-12         | 13370-99L00     | 143A-2          |
| 11241-73003     | 175A-15         | 12831-90J02     | 119A-14         | 13370-99L10     | 143B-2          |
| 11261-87E10     | 310A-3          | 12891-69G00     | 121A-3          | 13575-40F00     | 326A-2          |
| 11261-93J00     | 111A-5          | 12892-69G10-218 | 121A-4-1        |                 | 326B-2          |
|                 | 113A-11         | 12892-69G10-220 | 121A-4-2        | 13580-98J03     | 326A-1          |
| 11265-87E10     | 310A-4          | 12892-69G10-223 | 121A-4-3        |                 | 326B-1          |
|                 | 585A-4          | 12892-69G10-225 | 121A-4-4        | 13614-89J00     | 143B-15         |
| 11291-99L00     | 113A-1          | 12892-69G10-228 | 121A-4-5        | 13614-93J00     | 143B-24         |
| 11301-99L00     | 113A-3          | 12892-69G10-230 | 121A-4-6        | 13650-52G00     | 315A-1          |
| 11382-93J00     | 111A-18         | 12892-69G10-233 | 121A-4-7        |                 | 315B-1          |
| 11400-99840     | 585A-1          | 12892-69G10-235 | 121A-4-8        | 13655-87J01     | 315A-2          |
| 11489-90J10     | 180A-1          | 12892-69G10-238 | 121A-4-9        |                 | 315B-2          |
|                 | 585A-5          | 12892-69G10-240 | 121A-4-10       | 13684-99L00     | 143A-11         |
| 11501-90J20-QTN | 180A-2-2        | 12892-69G10-243 | 121A-4-11       |                 | 143B-11         |
| 11501-90J20-YAY | 180A-2-1        | 12892-69G10-245 | 121A-4-12       | 13710-99E00     | 134A-1          |
|                 | 180A-2-3        | 12892-69G10-248 | 121A-4-13       | 13810-99L00     | 134A-2          |
| 11511-99L00     | 136A-1          | 12892-69G10-250 | 121A-4-14       | 13813-99L00     | 134A-3          |
| 11512-99L00     | 136A-4          | 12892-69G10-253 | 121A-4-15       | 14151-90J00     | 310A-7          |
| 11514-99L00     | 136A-2          | 12892-69G10-255 | 121A-4-16       |                 | 585A-8          |
| 11515-99L00     | 136A-5          | 12892-69G10-258 | 121A-4-17       | 15100-96J01     | 146A-1-1        |
| 12100-92840-025 | 116A-8-2        | 12892-69G10-260 | 121A-4-18       | 15100-96J11     | 146A-1-2        |
| 12100-92841-OA0 | 116A-8-1        | 12892-69G10-263 | 121A-4-19       | 15190-99L00     | 146A-2          |
| 12100-99L00-050 | 116A-14         | 12892-69G10-265 | 121A-4-20       | 15192-99L00     | 146A-5          |
| 12111-99L00     | 116A-1          | 12892-69G10-268 | 121A-4-21       | 15193-99L00     | 146A-14         |
| 12140-92J10     | 116A-2          | 12892-69G10-270 | 121A-4-22       | 15195-96L00     | 146A-4          |
| 12140-92J10-050 | 116A-15         | 12892-69G10-273 | 121A-4-23       | 15195-96L10     | 146A-12         |
| 12151-99L00     | 116A-3          | 12892-69G10-275 | 121A-4-24       | 15200-92J20     | 143A-3          |
| 12160-92J10     | 116A-5          |                 |                 |                 |                 |
| 12163-35F00     | 116A-6          |                 |                 |                 |                 |

| PART NO.    | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. |
|-------------|-----------------|-------------|-----------------|-------------|-----------------|
| 15200-92J30 | 143B-3          | 15660-99L00 | 143B-10         | 17416-92J11 | 160A-19         |
| 15410-92J10 | 146A-6          |             | 143A-31         |             | 160B-19         |
| 15411-92J10 | 146A-7          | 15681-99L00 | 143B-31         | 17461-90J01 | 160A-2          |
| 15412-92J00 | 146A-8          |             | 144A-1          |             | 160B-2          |
| 15413-92J00 | 146A-9          |             | 144C-1          | 17471-92J00 | 160A-3          |
| 15415-92J00 | 146A-10         | 15681-99L10 | 144B-1          | 17471-92J10 | 160B-3          |
| 15421-99L00 | 146A-11         |             | 144D-1          | 17472-87E10 | 160A-4          |
| 15423-99L00 | 144A-4          | 15691-92J00 | 143A-30         |             | 160B-4          |
|             | 144C-4          |             | 143B-30         |             | 585A-10         |
| 15600-99L00 | 143A-1          | 15710-99L00 | 144A-2          | 17500-90J11 | 160A-22         |
| 15600-99L10 | 143B-1          |             | 144B-2          |             | 160B-22         |
| 15610-92J00 | 143A-27         |             | 144C-2          | 17520-90J00 | 160A-23         |
|             | 143B-27         |             | 144D-2          |             | 160B-23         |
| 15612-88L00 | 143A-21         | 15716-65DT0 | 144A-3          | 17561-90J03 | 160A-5-1        |
|             | 143B-21         |             | 144B-3          |             | 160B-5-1        |
| 15613-88L00 | 143A-22         |             | 144C-3          | 17561-90J13 | 160A-5-2        |
|             | 143B-22         |             | 144D-3          |             | 160B-5-2        |
| 15613-92J00 | 143A-25         | 15751-99L00 | 144A-5          | 17562-90J01 | 160A-6          |
|             | 143B-25         |             | 144C-5          |             | 160B-6          |
| 15614-88L00 | 143A-23         | 15751-99L10 | 144B-4          | 17563-87D01 | 160A-7          |
|             | 143B-23         |             | 144D-4          |             | 160A-24         |
| 15620-99L00 | 143A-26         | 15760-88L00 | 143A-12         |             | 160B-7          |
| 15620-99L10 | 143B-26         |             | 143B-12         |             | 160B-24         |
| 15626-92J01 | 143A-4          | 15762-90J00 | 144C-7          | 17564-87D00 | 160A-8          |
| 15626-92J10 | 143B-4          |             | 144D-5          |             | 160B-8          |
| 15628-99E00 | 143A-5          | 15830-90J00 | 144C-10         | 17581-99L00 | 162A-14         |
|             | 143B-5          | 15830-99L00 | 144B-11         | 17611-90J00 | 162A-2          |
| 15629-99E10 | 143A-6          | 15830-99L10 | 144D-11         | 17612-90J01 | 160A-20         |
|             | 143B-6          | 15831-96L00 | 146A-16         |             | 160B-20         |
| 15641-88L00 | 143A-7          | 15980-98J00 | 520A-41         | 17631-90J00 | 160A-9          |
| 15641-88L10 | 143B-7          |             | 540A-24         |             | 160B-9          |
| 15641-88L31 | 143A-18         |             | 543A-23         | 17632-90J00 | 160A-10         |
|             | 143B-18         | 16113-92J11 | 175A-2          |             | 160B-10         |
| 15641-88L51 | 143A-19         | 16400-99L00 | 175A-3          | 17635-87E00 | 160A-25         |
|             | 143B-19         | 16440-99E01 | 175A-4          |             | 160B-25         |
| 15642-88L00 | 143A-8          | 16510-61A31 | 175A-14         | 17635-90J00 | 160A-11         |
|             | 143B-8          | 16520-90J00 | 175A-5          |             | 160B-11         |
| 15642-88L10 | 143A-20         | 16531-99L00 | 175A-16         | 17660-98L01 | 162A-3          |
|             | 143B-20         | 16539-99L01 | 175A-17         | 17670-90J01 | 162A-4-1        |
| 15643-88L10 | 143A-17         | 16910-99L00 | 180A-13         | 17670-90J11 | 162A-4-2        |
|             | 143B-17         | 16930-99L00 | 180A-14         | 17681-99L00 | 162A-5          |
| 15644-88L00 | 143A-13         | 16934-99L00 | 180A-17         | 17710-99L00 | 162A-13         |
| 15644-88L10 | 143B-13         | 16941-99L00 | 180A-18         | 17711-90J00 | 162A-6          |
| 15645-88L00 | 143A-14         |             | 585A-9          | 17712-99L00 | 162A-10         |
|             | 143B-14         | 17400-92J11 | 160B-21         | 17913-93J00 | 180A-3          |
| 15648-92J00 | 143A-16         | 17400-92J23 | 160A-21         |             | 410A-10         |
|             | 143B-16         | 17410-92J00 | 160A-1          | 17914-93J01 | 180A-12         |
| 15650-99E00 | 143A-9          |             | 160B-1          |             | 410A-11         |
|             | 143B-9          | 17413-92J01 | 160A-18         | 17915-99L00 | 162A-12         |
| 15654-88L00 | 143A-10         | 17413-92J11 | 160B-18         | 17917-87L00 | 410A-30         |

| PART NO.    | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. |
|-------------|-----------------|-------------|-----------------|-------------|-----------------|
| 18213-98J30 | 507B-9          | 29117-93J10 | 401A-15         | 32851-93J00 | 331A-1          |
|             | 315A-7          | 29404-93J01 | 337B-2          |             | 331B-1          |
|             | 315B-7          |             | 337C-2          |             | 535A-19         |
| 18498-99EA1 | 507A-6          | 29404-93J11 | 310A-17         |             | 535B-15         |
| 18590-59S00 | 507B-6          |             |                 | 32890-99L00 | 310A-11         |
|             | 315A-3          |             |                 | 32980-38F00 | 331A-2          |
|             | 315B-3          |             |                 |             | 331B-2          |
| 18640-98L01 | 315A-5          | 30000       |                 |             | 535A-12         |
|             | 315B-5          |             |                 |             | 535B-16         |
| 19110-99L01 | 204A-2          |             |                 |             |                 |
|             |                 |             | 31100-92J00     | 301A-1      | 33220-64L10     |
| 20000       |                 | 31111-94900 | 340A-10         | 33410-99L00 | 310A-1          |
|             |                 |             | 340B-2          | 33634-96J00 | 322A-8          |
|             |                 | 31123-94910 | 340A-4          | 33799-97E00 | 322C-8          |
|             |                 |             | 340B-4          |             | 340A-9          |
| 21110-99L00 | 204A-3          | 31133-90J10 | 340A-5          | 33810-90J30 | 340B-9          |
| 21151-99L00 | 204A-4          |             | 340B-5          |             | 322A-1          |
| 21155-99L00 | 204A-5          | 31133-94910 | 340A-6          |             | 322B-1          |
| 21210-99L00 | 204A-6          |             | 340B-6          |             | 322C-1          |
| 21230-99L00 | 204A-7          | 31135-94900 | 340A-8          |             | 322D-1          |
| 21241-99L00 | 204A-8          |             | 340B-7          | 33911-88BL0 | 522A-5          |
| 22511-99011 | 204A-9          | 31136-90J20 | 340A-7          | 33920-99L00 | 326B-21-1       |
|             | 336A-1-1        |             | 340A-7          | 33920-99L10 | 326A-21-1       |
|             | 336A-1-2        | 31150-92J00 | 340B-8          | 33920-99L50 | 326B-21-2       |
|             | 336B-1          | 31170-92J00 | 301A-2          | 33920-99L60 | 326A-21-2       |
| 23111-90J02 | 204A-10-1       | 31173-94920 | 301A-3          | 33925-93J00 | 522A-6          |
| 23111-90J12 | 204A-10-2       |             | 301A-4          | 33925-98L00 | 522B-2          |
| 23115-99L00 | 204A-11         |             | 340A-3          | 33925-99L00 | 326A-22         |
| 25111-92J00 | 210A-6-1        | 31191-92J00 | 340B-3          |             | 326B-22         |
|             | 210B-6-1        | 31192-92J00 | 301A-5          | 33926-98J00 | 522A-7          |
| 25111-92J10 | 210A-6-2        | 31220-92J00 | 301A-6          | 33926-98L00 | 522B-3          |
|             | 210B-6-2        | 31261-75F10 | 301A-7          | 34000-96L67 | 601A-1          |
| 25131-92J01 | 210A-1          | 31281-92J10 | 301A-8          | 34000-96L77 | 601A-9          |
|             | 210B-1          |             | 337A-18         | 34002-96L17 | 602A-1          |
| 25141-92J01 | 210A-2          |             | 337B-3          | 34011-96L40 | 602A-1          |
|             | 210B-2          | 31311-63J00 | 337C-3          |             | 601A-10         |
| 25222-90J01 | 210A-3          | 31311-94900 | 301A-9          |             | 601B-1          |
|             | 210B-3          |             | 340A-2          |             | 602A-2          |
| 25232-90J00 | 210A-4          | 31312-92J00 | 340B-10         |             | 602A-12         |
|             | 210B-4          | 31320-92J00 | 301A-11         |             | 602B-1          |
| 25321-92J10 | 210A-5          | 31340-92J00 | 301A-12         | 34011-96L50 | 601B-6          |
| 25321-92J20 | 210B-5          | 31341-92J00 | 301A-10         |             | 602B-6          |
| 25700-92J00 | 407A-30         | 31343-63J00 | 301A-13         | 34112-96L00 | 601A-3          |
|             | 407B-26         | 31344-63J00 | 301A-14         |             | 601A-11         |
|             | 407C-28         | 31912-90J00 | 301A-15         |             | 601B-2          |
|             | 407D-24         | 31918-92J01 | 301A-16         |             | 601B-7          |
| 29103-93J00 | 315A-21         | 32102-99L00 | 301A-17         |             | 602A-3          |
|             | 315B-21         | 32120-99L00 | 303A-1          |             | 602A-13         |
| 29116-93J00 | 210A-8          | 32160-99L00 | 303A-2          |             | 602B-2          |
|             | 210B-8          | 32800-99L00 | 303A-3          |             | 602B-7          |
|             |                 |             | 310A-10         | 34190-88L00 | 602A-23         |

| PART NO.    | FIG.NO.-REF.NO.                        | PART NO.    | FIG.NO.-REF.NO.                          | PART NO.    | FIG.NO.-REF.NO.                          |
|-------------|----------------------------------------|-------------|------------------------------------------|-------------|------------------------------------------|
| 34193-96L00 | 602B-17<br>601A-4<br>601A-12<br>601B-3 | 36612-96J01 | 322D-24<br>322A-21<br>322B-20<br>322C-21 | 36617-93J10 | 322D-23<br>143A-33<br>143B-33<br>303A-12 |
|             | 601B-8<br>602A-4<br>602A-14            |             | 322D-20<br>522A-2<br>522B-22             |             | 315A-18<br>315B-18<br>322A-20            |
|             | 602B-3<br>602B-8                       | 36612-98J20 | 331A-4<br>331B-4                         |             | 322B-19<br>322C-20                       |
|             | 601A-5                                 | 36615-96300 | 522A-9                                   |             | 322D-19                                  |
| 34211-96L00 | 601A-13<br>601B-4<br>601B-9<br>602A-5  |             | 522A-16<br>522A-19<br>522A-21<br>522B-5  | 36618-43410 | 322A-9<br>322B-8<br>322C-9<br>322D-8     |
|             | 602A-15<br>602B-4                      |             | 522B-12<br>522B-15                       |             |                                          |
|             | 602B-9<br>507A-1<br>507B-1             | 34660-90J05 | 522B-17<br>507A-1<br>522B-21             | 36620-98J33 | 540A-58-1<br>543A-54-1                   |
| 34825-96L00 | 601A-6<br>601A-14<br>601B-5            |             | 523A-4<br>523B-4<br>523B-7               | 36620-98J43 | 540A-58-2<br>543A-54-2                   |
|             | 601B-10<br>602A-6<br>602A-16           |             | 535A-14<br>535B-18<br>601A-8             | 36620-98J53 | 522A-1                                   |
|             | 602B-5                                 |             | 601A-16                                  | 36620-98L00 | 522B-1                                   |
|             | 602B-10                                |             | 322A-3-1                                 |             | 540B-26-1                                |
| 34830-87J20 | 315A-4<br>315B-4                       | 36616-99L00 | 322C-3-1<br>322A-3-2                     | 36620-98L10 | 543B-24-1<br>540B-26-2<br>543B-24-2      |
|             | 315A-6<br>315B-6                       | 36616-99L01 | 322B-3<br>322C-3-2                       | 36620-98L20 | 540B-26-3<br>543B-24-3                   |
| 34840-98J03 | 315A-8<br>315B-8                       |             | 322D-3<br>322A-4                         | 36621-98J00 | 522A-17                                  |
| 34841-92J00 | 315A-9<br>315B-9                       |             | 322B-4<br>322C-4                         | 36621-98J10 | 522A-22                                  |
| 34842-92J01 | 315A-10<br>315B-10                     |             | 322D-4<br>310A-8                         | 36621-98L00 | 522B-13                                  |
| 34843-87L00 | 315A-13<br>315B-13                     | 36616-99L20 | 326A-3<br>326B-3                         | 36622-98J00 | 522A-13                                  |
| 34845-92J00 | 315A-11<br>315B-11                     | 36617-87L20 | 310A-9<br>322A-19                        | 36622-98L00 | 522B-9                                   |
| 34846-87L00 | 602A-17<br>602B-11                     | 36617-88L00 | 322C-19<br>322B-18                       | 36623-96L02 | 331A-3                                   |
|             | 322C-7                                 |             | 322D-18                                  | 36623-98L00 | 535A-13                                  |
| 36001-88L00 | 322A-7                                 |             | 143A-32                                  | 36623-98L10 | 522A-8                                   |
| 36610-99L00 | 322D-7                                 | 36617-93J00 | 143B-32                                  | 36623-98J30 | 522A-18                                  |
| 36610-99L10 | 303A-5                                 |             | 303A-5                                   | 36623-98J40 | 523A-3                                   |
| 36610-99L50 | 322B-7                                 |             | 322A-24                                  | 36623-98L00 | 522B-4                                   |
| 36611-99L00 | 322B-24<br>322C-25                     |             | 322B-23<br>322C-24                       | 36623-98L10 | 522B-16                                  |
|             |                                        |             |                                          | 36623-98L30 | 522B-14                                  |
|             |                                        |             |                                          | 36623-98L40 | 523B-3                                   |
|             |                                        |             |                                          | 36623-98LA0 | 331B-3                                   |
|             |                                        |             |                                          |             | 535B-17                                  |
|             |                                        |             |                                          |             | 522A-15                                  |
|             |                                        |             |                                          |             | 522A-20                                  |
|             |                                        |             |                                          |             | 522B-11                                  |
|             |                                        |             |                                          |             | 522B-18                                  |
|             |                                        |             |                                          |             | 522B-20                                  |
|             |                                        |             |                                          |             | 523A-1                                   |
|             |                                        |             |                                          |             | 523B-1-1                                 |
|             |                                        |             |                                          |             | 523B-1-2                                 |

| PART NO.    | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. |
|-------------|-----------------|-------------|-----------------|-------------|-----------------|
| 36627-98J00 | 523A-5          | 36667-96L00 | 601A-22         | 37112-98J10 | 530A-21         |
| 36627-98L00 | 523B-5          | 36667-96L11 | 601A-23         |             | 530A-23         |
| 36627-98L10 | 523B-6          | 36667-96L20 | 522A-4          |             | 530B-44         |
| 36627-98L20 | 535B-26         | 36667-96L30 | 601A-24         |             | 530B-46         |
| 36661-96L20 | 601A-7          | 36667-96L40 | 601B-16         |             | 530B-48         |
|             | 601A-15         | 36667-96L50 | 601B-17         |             | 530B-50         |
| 36662-88L00 | 602A-27         | 36667-96L60 | 522B-23         |             | 530B-52         |
|             | 602B-21         | 36682-92E00 | 602A-11         |             | 530B-54         |
| 36662-88L10 | 601A-17         | 36770-98J13 | 522A-10-1       |             | 530B-56         |
|             | 601B-11         | 36770-98J22 | 522A-10-2       | 37114-98J00 | 530A-10         |
|             | 602A-7          | 36770-98L00 | 522B-6          |             | 535A-5          |
|             | 602A-18         | 36775-98J00 | 522A-11         | 37117-96L00 | 331A-6          |
|             | 602A-31         | 36775-98L00 | 522B-7          |             | 331B-5          |
|             | 602B-12         | 36776-98J00 | 522A-12         |             | 535A-22         |
|             | 602B-25         | 36776-98L00 | 522B-8          |             | 535B-19         |
| 36662-88L20 | 602A-24         | 36890-98J00 | 520A-55         | 37120-98L00 | 530B-43         |
|             | 602B-18         |             | 540A-57         | 37120-98L10 | 530B-45         |
| 36662-88L30 | 602A-25         |             | 543A-53         | 37120-98L20 | 530B-47         |
|             | 602B-19         | 36894-87D00 | 336A-3          | 37120-98L30 | 530B-49         |
| 36662-96L01 | 331A-5          |             | 336B-3          | 37120-98L40 | 530B-51         |
|             | 535A-15         |             | 337B-34         | 37120-98L50 | 530B-53         |
| 36663-88L00 | 601A-18         |             | 337C-34         | 37120-98L60 | 530B-55         |
|             | 601B-12         | 36894-95201 | 336A-2          | 37130-98L00 | 543B-2          |
|             | 602A-19         |             | 336B-2          | 37130-98L10 | 540B-2          |
|             | 602A-28         | 36895-87D10 | 336A-9          | 37130-98L20 | 520B-33         |
|             | 602B-13         |             | 336B-9          | 37138-98L00 | 530B-5          |
|             | 602B-22         |             | 337A-26         | 37138-98L10 | 530B-17         |
| 36663-96L00 | 535A-25         |             | 337B-36         | 37138-98L20 | 530B-26         |
| 36664-88L00 | 601A-19         |             | 337C-36         | 37138-98L30 | 530B-35         |
|             | 601B-13         | 36990-87D00 | 522A-3          | 37139-96L30 | 535A-6          |
|             | 602A-8          |             | 522B-24         | 37139-98J10 | 530A-5          |
|             | 602A-20         | 37100-96L02 | 535A-1          | 37140-98L00 | 522B-26         |
|             | 602A-32         | 37100-98J07 | 530A-1          | 37141-98L00 | 530B-3-1        |
|             | 602B-14         | 37100-98J11 | 530A-11         |             | 530B-15-1       |
|             | 602B-26         | 37100-98J21 | 530A-20         |             | 530B-24-1       |
| 36664-96L00 | 535A-26         | 37100-98J31 | 530A-22         |             | 530B-33-1       |
| 36665-88L00 | 601A-20         | 37100-98L00 | 530B-1          | 37141-98L10 | 530B-3-2        |
|             | 601B-14         | 37100-98L10 | 530B-13         |             | 530B-15-2       |
|             | 602A-21         | 37100-98L20 | 530B-22         |             | 530B-24-2       |
|             | 602A-29         | 37100-98L30 | 530B-31         |             | 530B-33-2       |
|             | 602B-15         | 37105-96L04 | 535A-11         | 37141-98L20 | 530B-3-3        |
|             | 602B-23         | 37105-98L00 | 535B-14-1       |             | 530B-15-3       |
| 36665-88L10 | 601A-21         | 37105-98L10 | 535B-14-2       |             | 530B-24-3       |
|             | 601B-15         | 37110-96L00 | 535A-2          |             | 530B-33-3       |
|             | 602A-22         | 37110-98J02 | 530A-2          | 37141-98L30 | 530B-3-4        |
|             | 602A-30         | 37110-98L00 | 530B-2          |             | 530B-15-4       |
|             | 602B-16         |             | 530B-14         |             | 530B-24-4       |
|             | 602B-24         |             | 530B-23         |             | 530B-33-4       |
| 36665-96L00 | 602A-9          |             | 530B-32         | 37141-98L40 | 530B-3-5        |
| 36666-96L00 | 602A-10         | 37112-98J00 | 530A-12         |             | 530B-15-5       |

| PART NO.    | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. |
|-------------|-----------------|-------------|-----------------|-------------|-----------------|
|             | 530B-24-5       |             | 530B-16-4       | 37171-96L02 | 331A-7-1        |
| 37141-98L50 | 530B-33-5       |             | 530B-25-4       |             | 535A-23-1       |
|             | 530B-3-6        |             | 530B-34-4       | 37171-96L12 | 331A-7-2        |
|             | 530B-15-6       |             | 535A-3-4        |             | 535A-23-2       |
|             | 530B-24-6       | 37141-99E40 | 530A-3-7        | 37171-98L00 | 331B-6-1        |
|             | 530B-33-6       |             | 530B-4-5        |             | 535B-20-1       |
| 37141-98L60 | 530B-3-7        |             | 530B-16-5       | 37171-98L10 | 331B-6-2        |
|             | 530B-15-7       |             | 530B-25-5       |             | 535B-20-2       |
|             | 530B-24-7       |             | 530B-34-5       | 37172-96L02 | 331A-8-1        |
|             | 530B-33-7       |             | 535A-3-5        |             | 331B-7-1        |
| 37141-98L70 | 530B-3-8        | 37141-99E50 | 530A-3-8        |             | 535A-24-1       |
|             | 530B-15-8       |             | 530B-4-6        |             | 535B-21-1       |
|             | 530B-24-8       |             | 530B-16-6       | 37172-96L11 | 331A-8-2        |
|             | 530B-33-8       |             | 530B-25-6       |             | 331B-7-2        |
| 37141-98L80 | 530B-3-9        |             | 530B-34-6       |             | 535A-24-2       |
|             | 530B-15-9       |             | 535A-3-6        |             | 535B-21-2       |
|             | 530B-24-9       | 37141-99E60 | 530A-3-9        | 37173-96L00 | 535A-27         |
| 37141-98L90 | 530B-33-9       |             | 530B-4-7        | 37173-96L10 | 331A-9          |
|             | 530B-3-10       |             | 530B-16-7       |             | 331B-8          |
|             | 530B-15-10      |             | 530B-25-7       |             | 535A-16         |
|             | 530B-24-10      |             | 530B-34-7       |             | 535B-22         |
| 37141-98LA0 | 530B-33-10      | 37141-99E70 | 530A-3-10       | 37290-98L00 | 535B-1          |
|             | 530B-3-11       |             | 530B-4-8        | 37290-98L10 | 535B-4          |
|             | 530B-15-11      |             | 530B-16-8       | 37290-98L20 | 535B-9          |
|             | 530B-24-11      |             | 530B-25-8       | 37292-98L00 | 535B-2          |
|             | 530B-33-11      |             | 530B-34-8       | 37292-98L10 | 535B-5          |
| 37141-98LB0 | 530B-3-12       | 37141-99E80 | 530A-3-11       | 37292-98L20 | 535B-10         |
|             | 530B-15-12      |             | 530B-4-9        | 37721-93J00 | 326A-4          |
|             | 530B-24-12      |             | 530B-16-9       |             | 326B-4          |
|             | 530B-33-12      |             | 530B-25-9       | 37724-99L00 | 326A-5          |
| 37141-99E00 | 530A-3-3        |             | 530B-34-9       |             | 326B-5          |
|             | 530B-4-1        | 37141-99E90 | 530A-3-12       | 37726-99L00 | 326A-6          |
|             | 530B-16-1       |             | 530B-4-10       |             | 326B-6          |
|             | 530B-25-1       |             | 530B-16-10      | 37803-93J06 | 530A-14         |
|             | 530B-34-1       |             | 530B-25-10      | 37803-98L00 | 530B-8          |
|             | 535A-3-1        |             | 530B-34-10      | 37820-93J11 | 530A-6          |
| 37141-99E10 | 530A-3-4        | 37141-99EA0 | 530A-3-1        |             | 530A-15         |
|             | 530B-4-2        |             | 530B-4-11       |             | 535A-7          |
|             | 530B-16-2       |             | 530B-16-11      | 37820-98L00 | 520B-31         |
|             | 530B-25-2       |             | 530B-25-11      |             | 530B-9          |
|             | 530B-34-2       |             | 530B-34-11      |             | 530B-18         |
|             | 535A-3-2        | 37141-99EB0 | 530A-3-2        |             | 530B-27         |
| 37141-99E20 | 530A-3-5        |             | 530B-4-12       |             | 530B-36         |
|             | 530B-4-3        |             | 530B-16-12      |             | 535B-6          |
|             | 530B-16-3       |             | 530B-25-12      |             | 535B-11         |
|             | 530B-25-3       |             | 530B-34-12      | 37820-99E02 | 315A-12         |
|             | 530B-34-3       | 37143-96L00 | 535A-4          |             | 315B-12         |
|             | 535A-3-3        | 37143-99E01 | 530A-4          | 37823-92E02 | 530A-7          |
| 37141-99E30 | 530A-3-6        | 37170-96L06 | 535A-21-1       |             | 530A-16         |
|             | 530B-4-4        | 37170-96L16 | 535A-21-2       |             | 535A-8          |

| PART NO.                                                                | FIG.NO.-REF.NO.                                                          | PART NO.                                                             | FIG.NO.-REF.NO.                                                                                                                 | PART NO.                                                                                                                  | FIG.NO.-REF.NO.                                                                                                   |
|-------------------------------------------------------------------------|--------------------------------------------------------------------------|----------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| 37823-98L00                                                             | 520B-32<br>530B-10<br>530B-19<br>530B-28<br>530B-37<br>535B-7<br>535B-12 |                                                                      | 322B-12<br>322B-13<br>322C-13<br>322C-14<br>322D-12<br>322D-13<br>326A-30<br>326B-30<br>331A-11<br>331B-10<br>535A-9<br>530B-11 |                                                                                                                           | 336B-20<br>420A-2<br>420B-2<br>210A-7<br>210B-7<br>336A-21<br>336B-21<br>336A-22<br>336B-22<br>336A-23<br>336B-23 |
| 37825-99E10<br>37826-92J10                                              | 530A-18<br>530A-8<br>530A-17<br>535A-9                                   | 38860-96L01                                                          | 326A-30<br>326B-30<br>331A-11<br>331B-10<br>535A-18                                                                             | 41230-95E00                                                                                                               | 336A-22<br>336B-22<br>336A-23<br>336B-23                                                                          |
| 37832-98L00<br>37850-92J00                                              | 530B-11<br>326A-7<br>326B-7                                              | 38860-96L10<br>38890-99L00                                           | 535B-24<br>522B-27<br>326A-23                                                                                                   | 43111-90J40-QTN<br>43111-90J40-YAY<br>43111-90J50-QTN                                                                     | 336A-4-2<br>336A-4-1<br>336A-4-4                                                                                  |
| 37850-98J03                                                             | 520A-52<br>520B-29<br>540A-26<br>543A-25<br>540B-3<br>543B-3             | 38892-98J01<br>38895-99L00<br>38915-90J00                            | 326B-23<br>326A-24<br>326B-24<br>326A-25<br>326B-25<br>326A-31<br>326B-31                                                       | 43111-90J50-YAY<br>43111-92J80-QTN<br>43111-92J80-YAY<br>43111-92J90-QTN<br>43111-92J90-YAY<br>43112-99E00<br>43211-93J11 | 336A-4-3<br>336B-4-2<br>336B-4-1<br>336B-4-4<br>336B-4-3<br>180A-4<br>336A-5<br>336B-5                            |
| 37856-92J00<br>37857-92J01                                              | 326A-8<br>326B-8<br>326A-9<br>326B-9                                     | 39950-88L02                                                          | 602A-26<br>602B-20                                                                                                              | 43711-97E11                                                                                                               | 336A-6<br>336B-6                                                                                                  |
| 37860-87L00<br>37860-98L00<br>37862-87L00<br>37865-98L00<br>38100-92J13 | 530A-24<br>530B-40<br>530A-25<br>530B-41<br>337A-2<br>340A-1             |                                                                      |                                                                                                                                 | 43750-90J61-QTN<br>43750-90J61-YAY<br>43750-90J71-QTN                                                                     | 336A-7-2<br>336B-7-2<br>336A-7-1<br>336B-7-1<br>336A-7-4<br>336B-7-4                                              |
| 38100-96J12                                                             | 337B-4<br>337C-4<br>340B-1                                               | 41111-90J13-QTN<br>41111-90J13-YAY<br>41111-92J03-QTN                | 335A-1-2<br>335A-1-1<br>335B-1-2                                                                                                | 43750-90J71-YAY                                                                                                           | 336A-7-3<br>336B-7-3                                                                                              |
| 38410-93J21                                                             | 326A-19<br>326B-19                                                       | 41111-92J03-YAY<br>41121-90J21-QTN                                   | 335B-1-1<br>335A-2-2                                                                                                            | 45421-87D03<br>45421-90J00<br>48000-90J39                                                                                 | 335B-15<br>335A-15<br>337A-1                                                                                      |
| 38415-93J20                                                             | 326A-20<br>326B-20<br>331A-10<br>331B-9                                  | 41121-90J21-YAY<br>41121-92J21-QTN<br>41121-92J21-YAY<br>41130-92J30 | 335A-2-1<br>335B-2-2<br>335B-2-1<br>335A-3                                                                                      | 48000-96J15                                                                                                               | 337B-1<br>337C-1<br>337A-19<br>337B-25<br>337C-25                                                                 |
| 38500-93J90                                                             | 530A-27<br>530B-6<br>530B-20<br>530B-29<br>530B-38<br>530B-57            | 41135-92J00<br>41161-94400<br>41220-95E13                            | 335A-11<br>335B-4<br>442A-1<br>336A-17<br>336B-17                                                                               | 48311-96J20<br>48321-87D03<br>48321-90J00<br>48326-95E00                                                                  | 337B-26<br>337C-26<br>337B-27<br>337C-27<br>337A-20<br>337A-21<br>337B-28<br>337C-28                              |
| 38860-76F01                                                             | 535A-17<br>535B-23<br>540B-27<br>322A-13<br>322A-14                      | 41221-95E40<br>41224-95E01<br>41225-94401                            | 336A-18<br>336B-18<br>336A-19<br>336B-19<br>336A-20                                                                             | 48400-90J03<br>48401-96J02                                                                                                | 337A-3<br>337B-7                                                                                                  |

| PART NO.                                                                                                                                                                                                       | FIG.NO.-REF.NO.                                                                                                                                                                                                                                                                      | PART NO.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | FIG.NO.-REF.NO.                                                                                                                                                                                                                                                                                                                                                                                                   | PART NO.                                                                               | FIG.NO.-REF.NO.                                                                                                                                                                                                                                                                                                                                                                                                  |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 48405-93J00<br>48427-87D00                                                                                                                                                                                     | 337C-7<br>337B-14<br>337C-14<br>337B-16<br>337C-16<br>337A-9<br>337B-5<br>337C-5<br>340B-11<br>337B-6<br>337C-6                                                                                                                                                                      | 48862-92J30<br>48864-93J01<br>48864-96J10                                                                                                                                                                                                                                                                                                                                                                                                                                                               | 337C-23<br>337A-16<br>337B-24<br>337C-24<br>337A-13<br>340B-13                                                                                                                                                                                                                                                                                                                                                    | 55116-87E00<br>55125-90J01<br>55125-92J00-QTN<br>55125-92J00-YAY<br>55127-87D00        | 407A-28<br>407C-26<br>407A-3<br>407B-3<br>407C-3-2<br>407D-3-2<br>407C-3-1<br>407D-3-1<br>407A-4<br>407B-4<br>407C-4<br>407D-4<br>335A-4<br>335B-5                                                                                                                                                                                                                                                               |
| 48502-90J13<br>48502-96J05<br>48503-96J05<br>48557-90J00<br>48570-95E01                                                                                                                                        | 337A-9<br>337B-5<br>337C-5<br>340B-11<br>337B-6<br>337C-6<br>337A-7<br>337B-17<br>337C-17                                                                                                                                                                                            | 50000                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                   | 55320-94900                                                                            | 335A-4<br>335B-5                                                                                                                                                                                                                                                                                                                                                                                                 |
| 48571-87L01<br>48572-87J10<br>48572-95E00<br>48582-95E01<br>48583-95E00                                                                                                                                        | 337A-5<br>337A-6<br>337B-18<br>337C-18<br>337A-11<br>340B-12<br>337A-10<br>337B-19<br>337C-19<br>337A-12<br>337B-20<br>337C-20                                                                                                                                                       | 51110-99810-Y5S<br>51110-99810-YAY<br>51115-90J00<br>51122-90J00<br>51123-90J01<br>51211-90J30<br>52111-90J02-QTN<br>52111-90J02-YAY<br>52111-90J12-QTN<br>52111-90J12-YAY<br>54112-90J21<br>54114-90J10<br>54121-87D01<br>54123-90J01<br>54125-90J11<br>54130-90J40<br>54148-90J11<br>54148-99L00<br>54151-90J00<br>54160-90J20<br>54166-90J11<br>54211-90J01-QTN<br>54211-90J01-YAY<br>54221-90J02-QTN<br>54221-90J02-YAY<br>55110-90J16-QTN<br>55110-90J16-YAY<br>55110-92J01-QTN<br>55110-92J01-YAY | 401A-1-2<br>401A-1-1<br>401A-8<br>401A-18<br>401A-19<br>401A-9<br>585A-11<br>405A-1-2<br>405A-1-1<br>405A-1-4<br>405A-1-3<br>401A-22<br>401A-25<br>405A-13<br>405A-8<br>401A-21<br>401A-26<br>401A-23<br>401A-27-1<br>401A-27-2<br>405A-14<br>405A-9<br>405A-10<br>405A-15-2<br>405A-15-1<br>405A-6-2<br>405A-6-1<br>407A-1-2<br>407B-1-2<br>407A-1-1<br>407B-1-1<br>407C-1-2<br>407D-1-2<br>407C-1-1<br>407D-1-1 | 55321-87J01<br>55321-87J11<br>55321-90J01<br>55321-94910<br>55332-87D02<br>55332-87D12 | 111A-7<br>113A-13<br>310A-5-1<br>337A-24<br>310A-5-2<br>337B-38<br>407A-5<br>407B-5<br>407C-5<br>407D-5<br>335A-17<br>335B-17<br>160A-26<br>160B-26<br>407A-6<br>407B-6<br>407C-6<br>407D-6<br>160A-27<br>160B-27<br>407A-7<br>407B-7<br>407C-7<br>407D-7<br>56120-92J01-QTN<br>56120-92J01-YAY<br>56120-92J12-QTN<br>56120-92J12-YAY<br>56123-92J00<br>56130-90J00<br>56140-92J00<br>56140-92J30<br>57110-92J60 |
| 48588-90J00<br>48588-94900<br>48601-94900<br>48611-90J00<br>48615-97E00<br>48627-95E00<br>48630-96J04<br>48633-94900<br>48641-96J04<br>48650-94900<br>48661-92J01<br>48662-87J20<br>48662-90J21<br>48662-92J20 | 337B-20<br>337C-20<br>337A-14<br>337B-21<br>337C-21<br>337B-8<br>337C-8<br>337A-4<br>337B-15<br>337C-15<br>337B-9<br>337C-9<br>337B-10<br>337C-10<br>337B-11<br>337C-11<br>337B-12<br>337C-12<br>337B-13<br>337C-13<br>337B-22<br>337C-22<br>337A-8<br>337A-17<br>337A-15<br>337B-23 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                                                                                                                                                   |                                                                                        |                                                                                                                                                                                                                                                                                                                                                                                                                  |

| PART NO.        | FIG.NO.-REF.NO.       | PART NO.        | FIG.NO.-REF.NO.        | PART NO.        | FIG.NO.-REF.NO.      |
|-----------------|-----------------------|-----------------|------------------------|-----------------|----------------------|
| 57110-92J70     | 220A-1-2<br>220B-16-2 | 58200-92JA0     | 407C-19-1<br>407C-19-2 | 61811-99L00-QTN | 410A-1-2<br>410A-1-1 |
| 57130-92J01     | 405A-5                | 58200-92JB0     | 407C-19-3              | 61814-99L00     | 410A-5               |
| 57133-90J02     | 220A-2<br>220B-17     | 58200-92JC0     | 407C-19-4              | 61820-99L00-QTN | 410A-2-2<br>410A-2-1 |
| 57300-99L10     | 220A-7                | 58200-92JD0     |                        | 61820-99L00-YAY | 410A-6               |
| 57300-99L30     | 220B-22               | 60000           |                        | 61827-99L00     | 410A-3               |
| 57500-87861     | 220A-11               |                 |                        | 61830-99L00-QTN | 410A-12-2            |
| 57500-87873     | 220A-9<br>220B-24     |                 |                        | 61830-99L00-YAY | 410A-12-1            |
| 57500-92813     | 220A-15<br>220B-30    |                 |                        | 65000-94L10     | 432A-1               |
| 57610-99L00     | 220A-18               |                 |                        | 65520-99L00     | 432A-2               |
| 57610-99L10     | 220B-34               | 61112-99L00     | 420A-3                 | 65561-95D00     | 432A-3               |
| 57616-90J00     | 220A-26               | 61124-99L00     | 410A-28                | 65700-90J24     | 430A-1               |
| 57616-92J00     | 220B-42               | 61134-99L00     | 410A-7                 |                 | 432A-5               |
| 57621-99L00     | 220A-19               | 61150-99E01     | 180A-5                 | 65740-95D01     | 432A-4               |
|                 | 220B-35               | 61155-99E01     | 180A-7                 | 65750-95501     | 430A-2               |
| 57630-90J00     | 407A-29               | 61401-99811-YAY | 420A-1-1               |                 | 432A-6               |
|                 | 407C-27               |                 | 420B-1-1               | 65770-90J04     | 475A-1               |
| 57631-92J10     | 220A-21<br>220B-36    | 61401-99821-QTN | 420A-1-2               | 65770-90J13     | 430A-3               |
| 57633-90J02     | 407A-23<br>407B-21    |                 | 420B-1-2               |                 | 432A-7               |
|                 | 407C-21               | 61435-99L00     | 420B-15-1              | 67200-98J06     | 543A-1               |
| 57635-92J01     | 407D-19               | 61435-99L10     | 420B-15-2              | 67200-98J16     | 540A-1               |
|                 | 407B-22               | 61435-99L20     | 420A-15-1              | 67200-98J24     | 520A-1               |
|                 | 407C-22               | 61435-99L30     | 420A-15-2              | 67200-98L00     | 543B-1               |
|                 | 407D-20               | 61441-92J10     | 420A-13                | 67200-98L10     | 540B-1               |
| 58100-90JA0-019 | 407A-19-1             |                 | 420B-13                | 67200-98L20     | 520B-1               |
| 58100-90JB0-019 | 407B-19-1             | 61443-99L00     | 420A-11-1              | 67211-98J20     | 520A-18              |
| 58100-90JC0-019 | 407A-19-2             |                 | 420B-11-1              |                 | 520B-18              |
| 58100-90JD0-019 | 407B-19-2             | 61443-99L10     | 420A-11-2              |                 | 540A-2               |
| 58100-90JE0-019 | 407A-19-3             |                 | 420B-11-2              | 67246-98J00     | 543A-2               |
|                 | 407B-19-3             | 61453-99L00     | 420A-12-1              | 67246-98J10     | 540A-4               |
|                 | 407A-19-4             |                 | 420B-12-1              |                 | 543A-4               |
|                 | 407B-19-4             | 61453-99L10     | 420A-12-2              | 67246-98J20     | 540A-50              |
|                 | 407C-20               | 61458-90J01     | 420B-12-2              | 67251-98J00     | 540A-3               |
| 58200-92J40     | 407A-21-1             |                 | 410A-35                |                 | 543A-3               |
| 58200-92J50     | 407A-21-2             | 61494-99L00     | 136A-11                | 67251-98J20     | 520A-12              |
| 58200-92J60     | 407A-21-3             | 61610-93J01     | 420A-4                 |                 | 520B-13              |
| 58200-92J70     | 407A-21-4             |                 | 420B-4                 | 67252-98J00     | 520A-38              |
| 58200-92J80     | 407A-21-5             | 61621-93J01     | 420A-5                 | 67252-98J10     | 540A-21              |
| 58200-92J90     | 407A-21-6             |                 | 420B-5                 |                 | 543A-20              |
|                 |                       | 61632-93J00     | 410A-16                | 67254-98J00     | 520A-14              |
|                 |                       | 61633-96J02     | 410A-17                |                 | 520B-15              |
|                 |                       | 61634-96J02     | 410A-18                | 67255-98J00     | 520A-8               |
|                 |                       | 61641-93J10     | 410A-19                |                 | 520B-9               |
|                 |                       | 61645-90J01-QTN | 410A-20-2              | 67256-98J00     | 520A-10              |
|                 |                       | 61645-90J01-YAY | 410A-20-1              | 67256-98L00     | 520B-11              |
|                 |                       | 61648-99L00     | 410A-33                | 67257-98J00     | 520A-54              |
|                 |                       | 61673-96J02     | 410A-21                |                 | 520B-30              |
|                 |                       | 61682-99L00     | 420A-6                 |                 | 540A-43              |
|                 |                       |                 | 420B-6                 |                 | 543A-43              |

| PART NO.    | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. |
|-------------|-----------------|-------------|-----------------|-------------|-----------------|
|             | 540A-25         | 67258-98J00 | 520A-9          | 67273-98L10 | 540B-15         |
|             | 543A-24         |             | 520B-10         | 67274-98J00 | 543A-29         |
| 67227-98J20 | 520A-21         | 67259-98J00 | 520A-11         | 67277-98J00 | 540A-53         |
|             | 520B-20         |             | 520B-12         |             | 543A-50         |
| 67227-98J30 | 520A-22         | 67261-98J00 | 540A-5          | 67277-98L00 | 543B-14         |
| 67227-98L00 | 520B-34         |             | 543A-5          | 67277-98L10 | 540B-16         |
| 67228-98J50 | 520A-47         | 67261-98J10 | 540A-6          |             | 543B-15         |
|             | 540A-47         | 67261-98J20 | 520A-5          | 67277-98L20 | 540B-17         |
|             | 543A-47         |             | 520B-6          | 67284-98J10 | 540A-42         |
| 67233-98J00 | 520A-15         | 67261-98J30 | 520A-6          |             | 543A-42         |
| 67233-98J10 | 540A-14         |             | 520B-7          | 67284-98L00 | 540B-5          |
|             | 543A-13         | 67261-98L00 | 540B-9          |             | 543B-5          |
| 67234-98J00 | 520A-17         |             | 543B-8          | 67284-98L10 | 540B-6          |
|             | 520B-17         | 67261-98L10 | 540B-10         | 67284-98L20 | 520B-4          |
| 67235-98J00 | 520A-34         |             | 543B-9          | 67287-92E00 | 540A-15         |
| 67235-98J10 | 540A-12         | 67261-98L20 | 540B-11         |             | 540A-39         |
|             | 543A-11         | 67263-98J00 | 540A-7          |             | 540B-18         |
| 67236-98J00 | 520A-33         |             | 543A-6          |             | 543A-14         |
| 67236-98J10 | 540A-11         | 67263-98J20 | 520A-4          |             | 543A-38         |
|             | 543A-10         |             | 520B-5          |             | 543B-16         |
| 67237-98J00 | 520A-35         | 67264-98J00 | 520A-3          | 67287-98J00 | 520A-25         |
| 67237-98J20 | 602A-33         | 67264-98L00 | 520B-3          |             | 520B-22         |
| 67237-98J30 | 543A-12         | 67265-98J00 | 520A-7          | 67288-92E20 | 540A-36         |
| 67237-98J40 | 540A-13         |             | 520B-8          |             | 543A-30         |
| 67237-98J50 | 540A-56         | 67269-98J01 | 540A-27         | 67288-98J00 | 520A-44         |
| 67238-98J00 | 520A-29         |             | 543A-26         |             | 520B-26         |
|             | 520B-25         | 67269-98J10 | 520A-53         |             | 540A-35         |
| 67239-98J00 | 540A-16         | 67269-98J20 | 520A-19         |             | 543A-34         |
|             | 543A-15         | 67269-98J30 | 540A-44         | 67288-98J10 | 520A-46         |
| 67246-98J00 | 520A-31         |             | 543A-44         |             | 540A-45         |
| 67246-98J10 | 540A-4          | 67269-98L00 | 540B-12         |             | 543A-45         |
|             | 543A-4          |             | 543B-10         | 67288-98J20 | 520A-39         |
| 67246-98J20 | 540A-50         | 67271-98J20 | 520A-2          |             | 540A-22         |
| 67251-98J00 | 540A-3          | 67271-98J30 | 543A-8          |             | 543A-21         |
|             | 543A-3          | 67271-98J40 | 540A-9          | 67288-98J30 | 540A-46         |
| 67251-98J20 | 520A-12         | 67271-98L00 | 543B-11         |             | 543A-46         |
|             | 520B-13         | 67271-98L10 | 540B-13         | 67288-98J40 | 540A-34         |
| 67252-98J00 | 520A-38         | 67272-98J00 | 520A-51         |             | 540B-19         |
| 67252-98J10 | 540A-21         | 67272-98J10 | 540A-20         |             | 543A-40         |
|             | 543A-20         |             | 543A-19         |             | 543B-17         |
| 67254-98J00 | 520A-14         | 67272-98L00 | 543B-12         | 67288-98J50 | 520A-23         |
|             | 520B-15         | 67272-98L10 | 540B-14         |             | 520B-21         |
| 67255-98J00 | 520A-8          | 67272-98L20 | 520B-2          | 67288-98J60 | 520A-27         |
|             | 520B-9          | 67273-98J00 | 543A-27         |             | 520B-24         |
| 67256-98J00 | 520A-10         | 67273-98J10 | 540A-51         | 67288-98J70 | 520A-30         |
| 67256-98L00 | 520B-11         |             | 543A-48         | 67292-98J00 | 520A-40         |
| 67257-98J00 | 520A-54         | 67273-98J20 | 540A-28         |             | 540A-23         |
|             | 520B-30         | 67273-98J30 | 540A-52         |             | 543A-22         |
|             | 540A-43         |             | 543A-49         | 67294-98J00 | 520A-13         |
|             | 543A-43         | 67273-98L00 | 543B-13         |             | 520B-14         |

| PART NO.    | FIG.NO.-REF.NO.                          | PART NO.                                  | FIG.NO.-REF.NO.            | PART NO.                                  | FIG.NO.-REF.NO.                          |
|-------------|------------------------------------------|-------------------------------------------|----------------------------|-------------------------------------------|------------------------------------------|
| 67296-94300 | 520A-43<br>540A-33<br>543A-33            | 67725-99E00<br>67725-99E20<br>67726-99E00 | 442A-4<br>442A-9<br>442A-5 | 01547-0625C<br>01547-0635A<br>01547-0655C | 111A-23<br>175A-11<br>111A-24            |
| 67296-98J00 | 540A-32<br>543A-39                       | 67726-99E00                               | 442A-10<br>442A-6          | 01550-0612C                               | 143A-40<br>143B-40                       |
| 67296-98J10 | 520A-45<br>543A-41                       | 68111-88L00                               | 540B-7<br>543B-6           |                                           | 144B-12<br>144D-12                       |
| 67296-98J20 | 543A-35                                  | 68111-93J00                               | 420A-14                    |                                           | 162A-28                                  |
| 67296-98J30 | 540A-30                                  |                                           | 420B-14                    |                                           | 162A-29                                  |
| 67296-98J50 | 520A-50                                  | 69711-93E11                               | 136A-12                    |                                           | 303A-17                                  |
|             | 540A-18<br>540B-20<br>543A-17<br>543B-18 |                                           |                            |                                           | 310A-21<br>322A-26<br>322B-25<br>322C-26 |
| 67296-98J60 | 520A-48                                  |                                           |                            |                                           | 322D-25                                  |
|             | 520B-27                                  | 99011-99L01-03B                           | 420A-17-2                  |                                           | 326A-15                                  |
|             | 540A-29                                  |                                           | 420B-17-2                  |                                           | 326B-15                                  |
| 67296-98J90 | 543A-28                                  | 99011-99L01-054                           | 420A-17-1                  |                                           | 420A-10                                  |
|             | 540A-40                                  |                                           | 420B-17-1                  |                                           | 420B-10                                  |
|             | 543A-31                                  | 99011-99L01-059                           | 420A-17-3                  | 01550-0616A                               | 119A-16                                  |
| 67296-98JA0 | 520A-16                                  |                                           | 420B-17-3                  |                                           | 175A-12                                  |
|             | 520B-16                                  | 99011-99L20-03B                           | 420A-17-5                  | 01550-0616C                               | 146A-21                                  |
|             | 540A-19                                  |                                           | 420B-17-5                  |                                           | 180A-16                                  |
|             | 543A-18                                  | 99011-99L20-054                           | 420A-17-4                  |                                           | 204A-28                                  |
| 67296-98JB0 | 520A-20                                  |                                           | 420B-17-4                  |                                           | 303A-9                                   |
|             | 520B-19                                  | 99011-99L20-059                           | 420A-17-6                  |                                           | 322A-5                                   |
| 67296-98JC0 | 520A-24                                  |                                           | 420B-17-6                  |                                           | 322B-5                                   |
| 67296-98JD0 | 520A-28                                  |                                           |                            |                                           | 322C-5                                   |
| 67296-98JE0 | 520A-37                                  |                                           |                            |                                           | 322D-5                                   |
| 67296-98JF0 | 540A-54                                  |                                           |                            |                                           | 326A-26                                  |
|             | 543A-51                                  |                                           |                            |                                           | 326B-26                                  |
| 67296-98JG0 | 540A-31                                  |                                           |                            | 01550-0620A                               | 119A-17                                  |
|             | 543A-32                                  |                                           |                            | 01550-0620C                               | 162A-20                                  |
| 67296-98L00 | 540B-21                                  |                                           |                            |                                           | 162A-21                                  |
|             | 543B-19                                  |                                           |                            |                                           | 310A-2                                   |
| 67296-98L10 | 540B-22                                  | 01421-0616A                               | 119A-15                    |                                           | 310A-19                                  |
|             | 543B-20                                  | 01421-0820C                               | 144A-12                    |                                           | 326A-27                                  |
| 67297-98J00 | 540A-55                                  |                                           | 144B-8                     |                                           | 326B-27                                  |
|             | 540B-23                                  |                                           | 144C-12                    | 01550-06257                               | 310A-18                                  |
|             | 543A-52                                  |                                           | 144D-8                     | 01550-0625C                               | 144A-6                                   |
|             | 543B-21                                  | 01421-0830C                               | 122A-4                     |                                           | 144C-6                                   |
| 67361-90J10 | 410A-36                                  | 01500-06167                               | 322A-11                    |                                           | 180A-19                                  |
| 67467-89J01 | 204A-12                                  |                                           | 322B-10                    |                                           | 401A-14                                  |
| 67467-89J10 | 204A-13                                  |                                           | 322C-11                    | 01550-0630C                               | 310A-20                                  |
| 67471-99E00 | 204A-14                                  |                                           | 322D-10                    | 01550-06357                               | 326A-28                                  |
| 67471-99E10 | 204A-15                                  | 01547-0616C                               | 420A-8                     |                                           | 326B-28                                  |
| 67600-99L00 | 442A-7                                   |                                           | 420B-8                     | 01550-0655C                               | 162A-22                                  |
| 67631-99L00 | 442A-8                                   | 01547-0620C                               | 420A-9                     |                                           | 326A-29                                  |
| 67701-90J01 | 442A-2                                   |                                           | 420B-9                     |                                           | 326B-29                                  |
| 67721-99E00 | 442A-3                                   | 01547-0625A                               | 175A-10                    | 01550-08207                               | 301A-18                                  |

| PART NO.    | FIG.NO.-REF.NO.             | PART NO.                                  | FIG.NO.-REF.NO.                 | PART NO.                   | FIG.NO.-REF.NO.             |
|-------------|-----------------------------|-------------------------------------------|---------------------------------|----------------------------|-----------------------------|
| 01550-0820C | 111A-9<br>113A-15<br>163A-3 | 08113-62090<br>08211-30382<br>08310-00067 | 326B-17<br>220A-32<br>220A-12-1 | 09103-06266<br>09103-06281 | 111A-2<br>111A-8<br>113A-14 |
| 01550-0825A | 401A-20                     |                                           | 322A-12                         |                            | 310A-6                      |
| 01550-0825C | 175A-18                     |                                           | 322A-23                         |                            | 337A-25                     |
|             | 204A-29                     |                                           | 322B-11                         | 09103-12049                | 119A-3                      |
| 01550-0830C | 204A-30                     |                                           | 322B-22                         | 09103-16004                | 303A-7                      |
| 01550-0835A | 119A-18                     |                                           | 322C-12                         | 09106-05030                | 303A-10                     |
| 01550-0835C | 122A-5                      |                                           | 322C-23                         | 09106-10065                | 335A-12                     |
| 01550-0840C | 113A-8                      |                                           | 322D-11                         |                            | 335B-13                     |
| 01550-0855C | 204A-31                     |                                           | 322D-22                         | 09108-06060                | 136A-7                      |
| 01550-0860C | 163A-4                      | 08316-10067                               | 136A-10                         | 09116-06121                | 162A-7                      |
| 01550-0880C | 204A-32                     | 08316-1006A                               | 119A-19                         |                            | 335A-5                      |
| 01550-1050C | 301A-19                     | 08316-10087                               | 322A-2                          |                            | 335B-6                      |
| 01550-12167 | 144A-13                     |                                           | 322B-2                          | 09116-06127                | 410A-22                     |
|             | 144B-9                      |                                           | 322C-2                          | 09116-06517                | 134A-6                      |
| 01550-1230C | 113A-2                      |                                           | 322D-2                          |                            | 143A-28                     |
| 02112-0408A | 143A-15                     | 08316-1008C                               | 122A-6                          |                            | 143B-28                     |
| 02112-0612A | 111A-25                     |                                           | 144A-14                         |                            | 310A-22                     |
| 02122-04167 | 326A-16                     |                                           | 144B-10                         | 09116-08122                | 220A-34                     |
|             | 326B-16                     |                                           | 144C-14                         |                            | 220B-14                     |
| 02142-0408B | 143A-24                     |                                           | 144D-10                         | 09116-08131                | 160A-12                     |
| 02142-0616C | 322A-6                      |                                           | 146A-19                         |                            | 160B-12                     |
|             | 322B-6                      | 08321-0105C                               | 326A-18                         | 09116-08137                | 335A-14                     |
|             | 322C-6                      |                                           | 326B-18                         |                            | 335B-8                      |
|             | 322D-6                      | 08321-01067                               | 322A-22                         |                            | 407A-9                      |
| 02162-05207 | 315A-14                     |                                           | 322B-21                         |                            | 407B-9                      |
| 03122-05169 | 530A-9                      |                                           | 322C-22                         |                            | 407C-9                      |
|             | 530A-19                     |                                           | 322D-21                         |                            | 407D-9                      |
|             | 535A-10                     | 08331-3112A                               | 175A-13                         | 09116-08160                | 401A-10                     |
| 03142-05169 | 530B-7                      | 08331-41269                               | 119A-8                          | 09116-08174                | 410A-13                     |
|             | 530B-12                     | 08331-41359                               | 204A-33                         | 09116-08177                | 111A-12                     |
|             | 530B-21                     |                                           | 401A-6                          | 09116-08178                | 180A-8                      |
|             | 530B-30                     | 08341-31059                               | 303A-11                         |                            | 401A-11                     |
|             | 530B-39                     | 09100-06131                               | 407A-8                          | 09116-10129                | 180A-9                      |
|             | 530B-42                     |                                           | 407B-8                          | 09116-10150                | 407A-10                     |
|             | 535B-3                      |                                           | 407C-8                          |                            | 407B-10                     |
|             | 535B-8                      |                                           | 407D-8                          |                            | 407C-10                     |
|             | 535B-13                     | 09100-12081                               | 442A-11                         |                            | 407D-10                     |
| 03542-06209 | 136A-3                      | 09100-12090                               | 335A-6-2                        | 09116-10179                | 337A-22                     |
| 04211-11129 | 401A-17                     |                                           | 335B-7-2                        |                            | 337B-29                     |
| 04211-13149 | 301A-20                     | 09100-12091                               | 335A-6-1                        |                            | 337C-29                     |
| 04211-13189 | 111A-13                     |                                           | 335B-7-1                        | 09116-10181                | 401A-28                     |
| 04221-04089 | 116A-7                      | 09103-05026                               | 410A-27                         |                            | 405A-2                      |
| 04221-05109 | 119A-5                      | 09103-05028                               | 315B-14                         |                            | 405A-7                      |
| 06111-07004 | 220A-23                     | 09103-06093                               | 315A-15                         | 09117-08110                | 220A-38                     |
|             | 220B-38                     |                                           | 315B-15                         |                            | 220B-15                     |
| 06111-11004 | 220A-24                     | 09103-06211                               | 146A-20                         | 09117-10039                | 407A-11                     |
|             | 220B-39                     | 09103-06231                               | 303A-6                          |                            | 407B-11                     |
| 07130-05167 | 326A-17                     | 09103-06240                               | 136A-6                          |                            | 407C-11                     |

| PART NO.    | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. |
|-------------|-----------------|-------------|-----------------|-------------|-----------------|
| 09125-04021 | 407D-11         | 09160-05029 | 326A-10         | 09160-39001 | 336A-10         |
|             | 540B-25         |             | 326B-10         |             | 336B-10         |
|             | 543B-23         |             | 204A-16         |             | 220B-28-3       |
| 09125-05046 | 160A-13         | 09160-06055 | 336A-26         | 09160-60004 | 220B-28-4       |
|             | 160B-13         |             | 336B-26         |             | 220B-28-5       |
|             | 315A-16         |             | 136A-8          |             | 220B-28-6       |
| 09125-05050 | 315B-16         | 09160-06084 | 310A-12         | 09160-60006 | 220B-28-7       |
|             | 336A-8          |             | 407A-12         |             | 220B-28-1       |
|             | 336B-8          |             | 407B-12         |             | 220B-28-2       |
| 09125-06063 | 337A-27         | 09160-06085 | 407C-12         | 09160-60007 | 220B-28-7       |
|             | 337B-37         |             | 407D-12         |             | 220B-28-1       |
|             | 337C-37         |             | 204A-17         |             | 220B-28-2       |
| 09125-06063 | 160A-28         | 09160-06094 | 520A-49         | 09160-60008 | 220B-28-2       |
|             | 160B-28         |             | 520B-28         |             | 220B-28-2       |
|             | 336A-24         |             | 401A-16         |             | 220B-28-2       |
| 09125-06063 | 336A-28         | 09160-06104 | 335A-13         | 09160-60009 | 220B-28-2       |
|             | 336B-24         |             | 335B-14         |             | 220B-27         |
|             | 336B-28         |             | 442A-12         |             | 220B-28-8       |
| 09125-06063 | 336B-29         | 09160-08059 | 335A-10         | 09160-60013 | 220B-28-9       |
|             | 337B-35         |             | 335B-12         |             | 220B-28-10      |
|             | 337C-35         |             | 401A-30         |             | 220B-28-11      |
| 09131-05004 | 530A-26         | 09160-10082 | 335A-13         | 09160-60016 | 220B-28-12      |
|             | 160A-17         |             | 335B-14         |             | 220B-28-13      |
|             | 160B-17         |             | 442A-12         |             | 220B-28-14      |
| 09132-04034 | 410A-9          | 09160-12066 | 335A-10         | 09160-60017 | 220B-28-15      |
|             | 410A-4          |             | 335B-12         |             | 220A-13         |
|             | 337B-30         |             | 401A-30         |             | 220B-29         |
| 09140-10031 | 337C-30         | 09160-12110 | 335A-9          | 09161-16008 | 160A-14         |
|             | 337C-30         |             | 335B-11         |             | 160B-14         |
|             | 337C-30         |             | 405A-12         |             | 337B-31         |
| 09140-10032 | 336A-25         | 09160-12128 | 405A-16         | 09162-10005 | 337C-31         |
|             | 336B-25         |             | 410A-23         |             | 410A-24         |
|             | 220A-8          |             | 303A-8          |             | 220A-3          |
| 09140-14024 | 220B-23         | 09160-13014 | 407A-26         | 09164-14008 | 220B-18         |
|             | 407A-25         |             | 407B-24         |             | 407A-13         |
|             | 407B-23         |             | 407C-24         |             | 407B-13         |
| 09141-18005 | 407C-23         | 09160-16048 | 407D-22         | 09168-10022 | 407C-13         |
|             | 407D-21         |             | 220A-8          |             | 407D-13         |
|             | 335A-7          |             | 220A-12-2       |             | 180A-10         |
| 09159-12014 | 335B-9          | 09160-18028 | 220A-12-3       | 09168-12012 | 144A-7          |
|             | 401A-24         |             | 220A-12-4       |             | 144B-5          |
|             | 401A-29         |             | 220A-12-5       |             | 175A-6          |
| 09159-14020 | 335A-16         | 09160-30036 | 220A-12-6       | 09168-16002 | 322A-31         |
|             | 335B-16         |             | 220A-12-7       |             | 322B-30         |
|             | 335A-8          |             | 220A-12-8       |             | 322C-31         |
| 09159-22006 | 335B-10         | 09160-30037 | 220A-12-9       | 09168-16002 | 322D-30         |
|             | 540A-38         |             | 220B-43         |             | 310A-15         |
|             | 540B-24         |             | 220B-44         |             | 310A-23         |
| 09160-05024 | 543A-37         | 09160-30038 | 220B-26-6       | 09169-06062 | 134A-4          |
|             | 543B-22         |             | 220B-26-8       |             | 143A-29         |
|             |                 |             | 220B-26-4       |             | 143B-29         |
| 09160-05024 |                 | 09160-35006 | 220B-26-5       | 09169-06090 | 136A-9          |
|             |                 |             | 220B-26-7       |             | 410A-14         |
|             |                 |             | 220B-26-9       |             | 336A-11         |
| 09160-05024 |                 | 09160-35008 | 220B-26-3       | 09169-06097 | 336B-11         |
|             |                 |             | 220B-26-2       |             | 220A-4          |
|             |                 |             | 220B-26-1       |             | 220B-19         |

| PART NO.    | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. |
|-------------|-----------------|-------------|-----------------|-------------|-----------------|
| 09180-09022 | 442A-13         | 09181-70003 | 220B-31-5       | 09181-70003 | 407C-15         |
|             | 175A-7          |             | 220A-16-3       |             | 407D-15         |
|             | 220A-5          |             | 220B-31-7       |             | 180A-11         |
| 09181-31001 | 220B-20         | 09181-70004 | 220A-16-4       | 09181-70004 | 204A-21         |
|             | 336A-12         |             | 220B-31-9       |             | 09248-12009     |
|             | 336B-12         |             | 220A-16-5       |             | 09248-12011     |
| 09181-40186 | 220A-10-1       | 09181-70006 | 220B-31-1       | 09181-70006 | 204A-21         |
|             | 220B-25-1       |             | 220A-16-10      |             | 113A-6          |
|             | 220A-10-7       |             | 09251-07003     |             | 336A-13         |
| 09181-40190 | 220B-25-7       | 09181-70008 | 220B-31-10      | 09181-70008 | 336B-13         |
|             | 220B-25-7       |             | 09260-10005     |             | 146A-3          |
|             | 220A-10-11      |             | 09261-05006     |             | 204A-22         |
| 09181-41002 | 220B-25-11      | 09181-70010 | 220B-31-2       | 09181-70010 | 175A-8          |
|             | 220A-10-2       |             | 220B-16-7       |             | 09262-17019     |
|             | 220B-25-2       |             | 220B-31-4       |             | 119A-6          |
| 09181-41003 | 220A-10-3       | 09181-70011 | 220A-16-8       | 09181-70011 | 09262-35068     |
|             | 220B-25-3       |             | 220B-31-6       |             | 09262-35069     |
|             | 220B-25-3       |             | 220A-16-9       |             | 407A-2          |
| 09181-41004 | 220A-10-4       | 09181-70012 | 220B-31-8       | 09181-70012 | 407C-2          |
|             | 220B-25-4       |             | 410A-25         |             | 407D-2          |
|             | 220A-10-5       |             | 09202-04022     |             | 220A-29         |
| 09181-41005 | 220B-25-5       | 09202-05027 | 116A-10         | 09202-05027 | 220B-3          |
|             | 220A-10-6       |             | 160A-15         |             | 09263-45004     |
|             | 220B-25-6       |             | 160B-15         |             | 220B-13         |
| 09181-41006 | 220B-25-6       | 09202-06031 | 220A-20         | 09202-06031 | 220A-41         |
|             | 220A-10-8       |             | 220B-40         |             | 220B-4          |
|             | 220B-25-8       |             | 405A-3          |             | 220A-6          |
| 09181-41009 | 220A-10-9       | 09202-08006 | 407A-14         | 09202-08006 | 220B-21         |
|             | 220B-25-9       |             | 407B-14         |             | 220B-45         |
|             | 220A-10-10      |             | 407C-14         |             | 220B-32         |
| 09181-41010 | 220B-25-10      | 09204-01006 | 407D-14         | 09204-01006 | 220A-17         |
|             | 220A-10-12      |             | 204A-18         |             | 220B-33         |
|             | 220B-25-12      |             | 204A-19         |             | 144B-13         |
| 09181-41013 | 220A-10-13      | 09280-09016 | 336A-27         | 09280-09016 | 144D-13         |
|             | 220B-25-13      |             | 336B-27         |             | 180A-6          |
|             | 220A-10-14      |             | 407A-27         |             | 180A-15         |
| 09181-41014 | 220B-25-14      | 09204-03003 | 407B-25         | 09204-03003 | 111A-6          |
|             | 220A-14-1       |             | 407C-25         |             | 113A-12         |
|             | 220A-14-2       |             | 407D-23         |             | 175A-9          |
| 09181-45003 | 220A-14-3       | 09205-04014 | 210A-9          | 09205-04014 | 09280-22020     |
|             | 220A-14-4       |             | 210B-9          |             | 09280-22022     |
|             | 220A-14-5       |             | 111A-3          |             | 119A-7          |
| 09181-45007 | 220A-14-6       | 09206-08001 | 401A-12         | 09206-08001 | 111A-20         |
|             | 220A-14-7       |             | 220A-10         |             | 162A-8          |
|             | 220A-14-8       |             | 220B-12         |             | 162A-15         |
| 09181-45013 | 220A-14-9       | 09206-09012 | 204A-20         | 09206-09012 | 401A-13         |
|             | 220A-14-10      |             | 113A-7          |             | 146A-13         |
|             | 220A-14-11      |             | 09206-13019     |             | 220A-36         |
| 09181-45016 | 220A-14-12      | 09208-06011 | 410A-37         | 09208-06011 | 220B-9          |
|             | 220A-14-13      |             | 113A-10         |             | 210A-10         |
|             | 220A-16-1       |             | 09246-04009     |             | 210B-10         |
| 09181-70001 | 220B-31-3       | 09248-10008 | 144C-13         | 09248-10008 | 220A-30         |
|             | 220A-16-2       |             | 144D-9          |             | 220B-5          |
|             |                 |             | 407A-15         |             | 401A-3          |
| 09181-70002 |                 |             | 407B-15         |             | 220A-37         |
|             |                 |             |                 |             | 220B-10         |
|             |                 |             |                 |             |                 |

| PART NO.        | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. | PART NO.    | FIG.NO.-REF.NO. |
|-----------------|-----------------|-------------|-----------------|-------------|-----------------|
| 09282-30007     | 220A-31         |             | 407A-16-2       |             | 143B-41         |
|                 | 220B-6          |             | 407B-16-1       |             | 303A-13         |
| 09282-39001     | 336A-14         |             | 407B-16-2       |             | 315A-24         |
|                 | 336B-14         |             | 407C-16-1       |             | 315B-24         |
| 09283-10011     | 210A-11         |             | 407C-16-2       |             | 322A-27         |
|                 | 210B-11         |             | 407D-16-1       |             | 322B-26         |
| 09283-32044     | 401A-4          |             | 407D-16-2       |             | 322C-27         |
| 09283-52006     | 116A-13         | 09360-12008 | 144A-9          |             | 322D-26         |
| 09289-06003     | 121A-11         | 09360-12013 | 144C-9          |             | 326A-11         |
| 09289-18001     | 401A-5          | 09362-09008 | 407A-17         |             | 326B-11         |
| 09306-06004     | 204A-23         |             | 407B-17         | 09403-12314 | 146A-15         |
| 09306-10022     | 204A-24         |             | 407C-17         | 09403-12420 | 162A-23         |
| 09306-12014     | 204A-25         |             | 407D-17         | 09403-13311 | 303A-14         |
| 09306-13007     | 410A-26         | 09363-08004 | 144A-10         |             | 322A-29-1       |
| 09306-13011     | 410A-34         | 09367-05004 | 143A-37         |             | 322C-29-1       |
| 09306-17001     | 337B-32         |             | 143B-37         | 09403-13402 | 522A-23         |
|                 | 337C-32         | 09367-06006 | 507A-4          |             | 522B-25         |
| 09320-08062     | 144A-8          |             | 507B-4          | 09403-13413 | 303A-15         |
|                 | 144B-6          | 09380-17009 | 337B-33         |             | 315A-22         |
|                 | 144C-8          |             | 337C-33         |             | 315B-22         |
|                 | 144D-6          | 09380-22015 | 337A-23         | 09403-16313 | 303A-16         |
| 09320-08510     | 322A-10         | 09380-38003 | 336A-15         | 09403-16416 | 162A-24         |
|                 | 322B-9          |             | 336B-15         | 09403-20308 | 322A-29-2       |
|                 | 322C-10         | 09381-21002 | 116A-4          |             | 322B-28         |
|                 | 322D-9          | 09383-08005 | 204A-26         |             | 322C-29-2       |
| 09320-08517     | 111A-27         | 09387-45001 | 405A-4          |             | 322D-28         |
|                 | 143A-34         | 09387-52001 | 220A-33         | 09407-08401 | 530A-13         |
|                 | 143B-34         |             | 220B-7          |             | 530B-58         |
| 09320-09016     | 310A-14         | 09401-08412 | 143A-38         |             | 540B-28         |
|                 | 310A-24         |             | 143B-38         | 09407-10404 | 315A-17         |
| 09320-09059     | 134A-5          | 09401-08413 | 162A-17         |             | 315B-17         |
| 09320-10075     | 310A-13         |             | 507A-5          |             | 326A-12         |
| 09320-11023     | 410A-15         |             | 507B-5          |             | 326B-12         |
| 09329-01007     | 310A-16         | 09401-11006 | 146A-18         |             | 407A-18         |
| 09329-10024     | 420A-7          | 09401-11423 | 430A-4          |             | 407B-18         |
|                 | 420B-7          |             | 432A-8          |             | 407C-18         |
| 09329-12006     | 111A-28         | 09401-11425 | 144A-11         |             | 407D-18         |
| 09329-14003     | 410A-32         |             | 144B-7          | 09407-14403 | 322A-28         |
| 09329-14004     | 410A-31         |             | 144C-11         |             | 322B-27         |
| 09352-11154-050 | 162A-9          |             | 144D-7          |             | 322C-28         |
| 09352-50003-065 | 143A-35         | 09401-14409 | 146A-17         |             | 322D-27         |
|                 | 143B-35         |             | 162A-18         | 09407-14407 | 315A-19         |
| 09352-50003-120 | 143A-36         | 09401-15414 | 162A-16         |             | 315B-19         |
|                 | 143B-36         | 09401-20409 | 111A-22         |             | 326A-13         |
| 09352-50006-600 | 162A-11         | 09401-31407 | 162A-19         |             | 326B-13-1       |
|                 | 507A-2          | 09403-07340 | 315A-23         |             | 326B-13-2       |
|                 | 507A-3          |             | 315B-23         |             | 331A-12         |
|                 | 507B-2          | 09403-08329 | 143A-39         |             | 331B-11         |
|                 | 507B-3          |             | 143B-39         |             | 535A-20         |
| 09355-40805-600 | 407A-16-1       | 09403-11321 | 143A-41         |             | 535B-25         |

| PART NO.        | FIG.NO.-REF.NO. | PART NO. | FIG.NO.-REF.NO. | PART NO. | FIG.NO.-REF.NO. |
|-----------------|-----------------|----------|-----------------|----------|-----------------|
| 09407-18402     | 315A-20         |          |                 |          |                 |
|                 | 315B-20         |          |                 |          |                 |
| 09407-20405     | 410A-29         |          |                 |          |                 |
|                 | 507A-7          |          |                 |          |                 |
|                 | 507B-7          |          |                 |          |                 |
| 09408-00056     | 162A-25         |          |                 |          |                 |
| 09408-00174     | 162A-26         |          |                 |          |                 |
| 09408-00175     | 162A-27         |          |                 |          |                 |
| 09408-00213     | 322A-30         |          |                 |          |                 |
|                 | 322B-29         |          |                 |          |                 |
|                 | 322C-30         |          |                 |          |                 |
|                 | 322D-29         |          |                 |          |                 |
| 09408-00346     | 507A-8          |          |                 |          |                 |
|                 | 507B-8          |          |                 |          |                 |
| 09409-05302-5PK | 410A-8          |          |                 |          |                 |
| 09420-05009     | 160A-16         |          |                 |          |                 |
|                 | 160B-16         |          |                 |          |                 |
| 09440-07071     | 204A-27         |          |                 |          |                 |
| 09440-09040     | 220A-22         |          |                 |          |                 |
|                 | 220B-37         |          |                 |          |                 |
| 09440-19028     | 336A-16         |          |                 |          |                 |
|                 | 336B-16         |          |                 |          |                 |
| 09440-49004     | 220A-25         |          |                 |          |                 |
|                 | 220B-41         |          |                 |          |                 |
| 09448-10006     | 326A-14         |          |                 |          |                 |
|                 | 326B-14         |          |                 |          |                 |
| 09481-10501     | 522A-14         |          |                 |          |                 |
|                 | 522B-10         |          |                 |          |                 |
| 09481-10504     | 322A-15         |          |                 |          |                 |
|                 | 322B-14         |          |                 |          |                 |
|                 | 322C-15         |          |                 |          |                 |
| 09481-15504     | 322D-14         |          |                 |          |                 |
|                 | 322A-16         |          |                 |          |                 |
|                 | 322B-15         |          |                 |          |                 |
|                 | 322C-16         |          |                 |          |                 |
|                 | 322D-15         |          |                 |          |                 |
| 09481-30501     | 523A-2          |          |                 |          |                 |
|                 | 523B-2          |          |                 |          |                 |
| 09481-30504     | 322A-17         |          |                 |          |                 |
|                 | 322B-16         |          |                 |          |                 |
|                 | 322C-17         |          |                 |          |                 |
|                 | 322D-16         |          |                 |          |                 |
| 09481-60403     | 322A-18         |          |                 |          |                 |
|                 | 322B-17         |          |                 |          |                 |
|                 | 322C-18         |          |                 |          |                 |
|                 | 322D-17         |          |                 |          |                 |
| 09482-00649     | 111A-26         |          |                 |          |                 |
| 09800-81841     | 420A-16         |          |                 |          |                 |
|                 | 420B-16         |          |                 |          |                 |

## **SUZUKI DF140BG/115BG PARTS CATALOGUE**

---

SUZUKI MOTOR CORPORATION All rights reserved

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION

Service Material Development Group, Automobile & Motorcycle Service Engineering Dept.  
300 Takatsuka, Minami, Hamamatsu, Japan

# **SUZUKI MOTOR CORPORATION**